



CHAPTER 5

Managing Location Server Users and Groups

This chapter describes how to configure and manage users, groups, and hot access.

This chapter contains the following sections:

- [“Managing Groups” section on page 5-2](#)
- [“Managing Users” section on page 5-3](#)
- [“Managing Host Access” section on page 5-5](#)

Managing Groups

This section describes how to add, delete, and edit user groups.

Adding User Groups

To add a user group to a location server, follow these steps:

-
- Step 1** In Cisco WCS, choose **Location > Location Servers**.
 - Step 2** Click the name of the location server you want to edit.
 - Step 3** Click **Accounts** (left).
 - Step 4** Click **Groups**.
 - Step 5** Choose **Add Group** from the drop-down menu (right-hand side) and click **GO**.
 - Step 6** Enter the name of the group in the Group Name field.
 - Step 7** Choose a permission level from the Permission drop-down menu.

There are three permissions levels to choose from:

- Read Access
- Write Access
- Full Access (required for Cisco WCS to access location servers)

- Step 8** Click **Save** to add the new group to the location server.
-

**Caution**

Group permissions override individual user permissions. For example, if you give a user full access permission and add that user to a group with read access permission, that user will not be able to configure location server settings.

Deleting User Groups

To delete user groups from a location servers, follow these steps:

-
- Step 1** In Cisco WCS, choose **Location > Location Servers**.
 - Step 2** Click the name of the location server you want to edit.
 - Step 3** Click **Accounts** (left).
 - Step 4** Click **Groups**.
 - Step 5** Check the check boxes of the groups that you want to delete.
 - Step 6** Choose **Delete Group** from the drop-down menu (right-hand side) and click **GO**.
 - Step 7** Click **OK** to confirm that you want to delete the selected groups.
-

Changing User Group Permissions

To change user group permissions, follow these steps:

-
- Step 1** In Cisco WCS, choose **Location > Location Servers**.
 - Step 2** Click the name of the location server you want to edit.
 - Step 3** Click **Accounts** (left).
 - Step 4** Click **Groups**.
 - Step 5** Click the name of the group you want to edit.
 - Step 6** Choose a permission level from the Permission drop-down menu.
 - Step 7** Click **Save** to apply your change.
-

**Caution**

Group permissions override individual user permissions. For example, if you give a user full access permission and add that user to a group with read access permission, that user will not be able to configure location server settings.

Managing Users

This section describes how to add, delete, and edit users. It also describes how to view active user sessions.

Adding Users

To add a users to a location server, follow these steps:

-
- Step 1** In Cisco WCS, choose **Location > Location Servers**.
 - Step 2** Click the name of the location server you want to edit.
 - Step 3** Click **Accounts** (left).
 - Step 4** Click **Users**.
 - Step 5** Choose **Add User** from the drop-down menu (right-hand side) and click **GO**.
 - Step 6** Enter the username in the Username field.
 - Step 7** Enter a password in the Password field.
 - Step 8** Enter the name of the group to which the user belongs in the Group Name field.

- Step 9** Choose a permission level from the Permission drop-down menu.
There are three permission levels to choose from: Read Access, Write Access, and Full Access

**Caution**

Group permissions override individual user permissions. For example, if you give a user full access permission and add that user to a group with read access permission, that user will not be able to configure location server settings.

- Step 10** Click **Save** to add the new user to the location server.
-

Deleting Users

To delete a user from a location server, follow these steps:

-
- Step 1** In Cisco WCS, choose **Location > Location Servers**.
- Step 2** Click the name of the location server you want to edit.
- Step 3** Click **Accounts** (left).
- Step 4** Click **Users**.
- Step 5** Check the check boxes of the users that you want to delete.
- Step 6** Choose **Delete User** from the drop-down menu (right-hand side) and click **GO**.
- Step 7** Click **OK** to confirm that you want to delete the selected users.
-

Changing User Properties

To change user properties, follow these steps:

-
- Step 1** In Cisco WCS, choose **Location > Location Servers**.
- Step 2** Click the name of the location server you want to edit.
- Step 3** Click **Accounts** (left).
- Step 4** Click **Users**.
- Step 5** Click the name of the group that you want to edit.
- Step 6** Make the required changes to the Password, Group Name, and Permission fields.
- Step 7** Click **Save** to apply your change.
-

Viewing Active User Sessions

To view active user sessions, follow these steps:

-
- Step 1** In Cisco WCS, choose **Location > Location Servers**.
 - Step 2** Click the name of the location server.
 - Step 3** Click **Administration** (left) to display the administrative configuration options.
 - Step 4** Click **Active Sessions**.

Cisco WCS displays a list of active location server sessions. For every session, Cisco WCS displays the following information:

- Session identifier
 - IP address from which the location server is accessed
 - Username of the connected user
 - Date and time when the session started
 - Date and time when the location server was last accessed
 - How long the session was idle for since the last access
-

Managing Host Access

This section describes how to add, delete, and edit host access records.

Adding Host Access

You can use Cisco WCS to add host access records to the location server database. Using host access records, you can control which hosts have access to the location server and when. You can also control access preference by assigning priorities to host access.

To add a new host access record, follow these steps:

-
- Step 1** In Cisco WCS, choose **Location > Location Servers**.
 - Step 2** Click the name of the location server you want to configure.
 - Step 3** Click **Accounts** (left).
 - Step 4** Click **Host Access**.
 - Step 5** Choose **Add Host Access** from the drop-down menu (right-hand side) and click **GO**.

- Step 6** Enter the IP address and netmask of the host using the *ddd.ddd.ddd.ddd/ddd* format. Following are examples of IP address and netmask entries:

| IP Address/Netmask | Description |
|--------------------|---|
| 120.10.0.0/8 | Specifies hosts on a class A subnet (120.x.x.x). |
| 120.10.0.0/16 | Specifies hosts on a class B subnet (120.10.x.x). |
| 120.10.223.0/16 | Specifies hosts on a class C subnet (120.10.223.x). |
| 120.10.223.10/32 | Specifies a single host (120.10.223.10). |

- Step 7** To allow host access, check the **Enable** check box of the Permit field.
To deny host access, uncheck the **Enable** check box.
- Step 8** Enter a priority number from 0 to 99999 in the Priority field.
Hosts with high priority have access preference over hosts with low priority.
- Step 9** Enter the time of day when the host may access the location server in the Start Access field.
In the Hrs. field, enter a value from 0 to 23. In the Mins field, enter a value from 0 to 59.
- Step 10** Enter the time of day when host access ends.
In the Hrs. field, enter a value from 0 to 23. In the Mins field, enter a value from 0 to 59.
- Step 11** Click **Save** to add the new host access to the location server.

Deleting Host Access

To delete a host access record, follow these steps:

- Step 1** In Cisco WCS, choose **Location > Location Servers**.
- Step 2** Click the name of the location server you want to configure.
- Step 3** Click **Accounts** (left).
- Step 4** Click **Users**.
- Step 5** Check the check boxes of the host access records that you want to delete.
- Step 6** Choose **Delete Host Access** from the drop-down menu (right-hand side) and click **GO**.
- Step 7** Click **OK** to confirm that you want to delete the selected host access records.

Editing Host Access

To edit a host access record, follow these steps:

-
- Step 1** In Cisco WCS, choose **Location > Location Servers**.
 - Step 2** Click the name of the location server you want to configure.
 - Step 3** Click **Accounts** (left).
 - Step 4** Click **Host Access**.
 - Step 5** Click the name of the host access that you want to configure.
 - Step 6** Make the required changes to the Permit, Priority, Start Access, and End Access fields.
 - Step 7** Click **Save** to apply your changes.
-

