



Release Notes for Cisco Aironet Client Utilities 2.72 and Driver 2.72 for Windows CE

Contents

This document contains the following sections:

- [Introduction, page 2](#)
- [System Requirements, page 2](#)
- [Important Notes, page 3](#)
- [New and Changed Information, page 5](#)
- [Installing or Upgrading to a New Client Utility and Driver Release, page 5](#)
- [Caveats, page 9](#)
- [Troubleshooting, page 10](#)
- [Related Documentation, page 10](#)
- [Obtaining Documentation, page 10](#)
- [Documentation Feedback, page 11](#)
- [Cisco Product Security Overview, page 11](#)
- [Obtaining Technical Assistance, page 12](#)
- [Obtaining Additional Publications and Information, page 14](#)



Corporate Headquarters:
Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA

© <year> Cisco Systems, Inc. All rights reserved.

Introduction

This document describes system requirements, important notes, new and changed information, installation and upgrade procedures, and caveats for the following releases of Cisco Aironet client adapter software:

- 2.72 of the Cisco Aironet client utilities for Windows CE
- 2.72 of the Cisco Aironet client adapter driver for Windows CE

The client utilities, driver, and help files are released together in a single file entitled WinCE-PCMCIA-LMC-v272.exe.

System Requirements

You need the following in order to install client utility and driver release 2.72 for Windows CE:

- One of the following Windows CE devices equipped with a Type II or Type III PC card slot:
 - HPC 2000 device running Windows CE 3.0 with an ARM, StrongARM, MIPS, SH4, or X86 platform
 - PPC 2000 device running Windows CE 3.0 with an ARM, StrongARM, MIPS, or SH3 platform
 - PPC 2002 device running Windows CE 3.0 with a StrongARM platform
 - PPC 2003 device running Windows CE .NET 4.2 with a StrongARM platform
 - Windows CE .NET device running Windows CE .NET 4.0 or 4.1 with an ARMv4I, ARMv4T, or MIPSII platform
 - Windows CE .NET device running Windows CE .NET 4.2 with a StrongARM (ARMv4), ARMv4I, or X86 platform
- Cisco Aironet 350 Series Wireless LAN Client Adapter (PC card or LM card)



Note Client adapter utility and driver release 2.72 is not supported for use with Cisco Aironet 340 series client adapters.

- Client adapter firmware version 5.60.21 (recommended)
- Laptop or PC running a Windows operating system and Microsoft ActiveSync
- ActiveSync connection (which can be serial, USB, etc.) to the Windows CE device
- A PPC 2002, PPC 2003, or Windows CE .NET 4.2 device, if your wireless network uses EAP-FAST, EAP-TLS, or PEAP authentication
- Certificate Authority (CA) and user certificates for EAP-TLS authentication or CA certificate for PEAP authentication
- If your wireless network uses PEAP authentication with a One-Time Password (OTP) user database:
 - The hardware token from an OTP vendor
 - Your hardware token password

- The following information from your system administrator:
 - The logical name for your Windows CE device (also referred to as *client name*)
 - The case-sensitive service set identifier (SSID) for your RF network
 - The primary and secondary Domain Name System (DNS) and Windows Internet Name Service (WINS) to be assigned to your Windows CE device
 - If your network setup does not include a DHCP server, the IP address, subnet mask, and default gateway address to be assigned to your device
 - The wired equivalent privacy (WEP) keys of the access points with which your client adapter will communicate, if your wireless network uses static WEP for security
 - Your username and password for LEAP, EAP-FAST, or PEAP authentication, if your wireless network uses one of these authentication types
 - Your username for EAP-TLS authentication, if your wireless network uses EAP-TLS authentication
 - Protected access credentials (PAC) file if your wireless network uses EAP-FAST authentication with manual PAC provisioning
- Access points to which your client adapter may attempt to authenticate must use the following firmware versions or later: 12.00T (340, 350, and 1200 series access points) or Cisco IOS Release 12.2(4)JA (1100 series access points).
- All necessary infrastructure devices such as access points, servers, gateways, and user databases must be properly configured for the authentication type you plan to enable on the client.

Important Notes

Support for Earlier CE Devices

Although this release can be installed on earlier CE devices and might work properly for most applications, no testing was performed for these earlier devices. Cisco cannot guarantee complete functionality. Cisco will not support or address any issues that arise from installing this release on those devices.

Recommended Firmware Version

Client adapter firmware version 5.60.21 is recommended for use with client utility and driver release 2.72 for Windows CE. If your client adapter is using a previous firmware version, follow the instructions in the *Cisco Aironet 350 Series Wireless LAN Client Adapters Installation and Configuration Guide for Windows CE* (part number OL-1375-05) to upgrade the firmware after installing client utility and driver release 2.72.

Delay in Windows CE DHCP Handler

A delay in the Windows CE DHCP handler prevents a device from recovering in less than 15 seconds.

GTK2 Packet Not Transmitted by PSC Handheld Device

If you turn a PSC handheld device on and off several times at a rapid rate, the device can still associate, but it cannot authenticate. The client device does not obtain an IP address and cannot function. If the device is in such a state, wait a few seconds in the On state and then powercycle the device.

Microsoft PEAP Issue for PPC 2002 Devices

Microsoft PEAP may not function properly on PPC 2002 devices.

Microsoft PEAP and Fast Reconnect

Microsoft PEAP does not support fast reconnect. Any interruption to the session requires the user to re-enter his or her credentials.

**Note**

The ACS backend server cannot be configured for fast reconnect.

Recommendation for EAP-TLS

Cisco recommends connecting Windows CE devices to an EAP-TLS network only when the devices have the proper certificate import tools for your network.

**Note**

These certificate import tools are not necessarily provided by Cisco.

Using Client Adapters with Both Windows and Windows CE Devices

After you install Cisco Aironet client adapter Install Wizard 1.0 or later on a Windows computer, the firmware of any client adapter that is inserted into that computer may be automatically upgraded to the version included in the Install Wizard file. If you insert a client adapter that has been upgraded to firmware version 5.02.19 or later into a Windows CE device, the adapter functions only if the device is running client utility and driver release 2.30 or later for Windows CE.

Supporting Documentation

Version OL-1375-05 of the *Cisco Aironet 350 Series Wireless LAN Client Adapters Installation and Configuration Guide for Windows CE* pertains specifically to client utility and driver releases 2.60, 2.70, and 2.72. If you are using, installing, or upgrading to an older release of client adapter software, refer to a previous version of this manual for information and instructions.

New and Changed Information

Support for Additional Platform

Client utility and driver release 2.72 supports one new Windows CE .NET platform: ARMv4I.

Support for WPA-PSK

Wi-Fi Protected Access (WPA) supports two mutually exclusive key management types: WPA and WPA-Pre-shared Key (WPA-PSK). With WPA key management, clients and the authentication server authenticate to each other by using an EAP authentication method, and the client and the server generate a pairwise master key (PMK). The server generates the PMK dynamically and passes it to the access point. However, with WPA-PSK key management, you configure a pre-shared key on both the client and the access point. The pre-shared key is used as the PMK.

In previous releases, you could only configure WPA-PSK through the Windows CE wireless configuration utility. In release 2.72, you can configure WPA-PSK from the ACU. You can now select “WPA-PSK” in the “Network Security Type” field and then enter the WPA-PSK pass phrase in the “User Password” field.



Note WPA-PSK functionality only applies to CE 4.x. Software releases for CE 3 and Pocket PC 2002 do not support this functionality.

Installing or Upgrading to a New Client Utility and Driver Release

This section describes how to install or upgrade to client utility and driver release 2.72 for Windows CE.

Uninstalling the Current Driver and Client Utilities

Cisco recommends that you uninstall the existing driver and client utilities for your client adapter before upgrading to more recent releases. Follow these steps to uninstall your client adapter’s current driver and client utilities.

-
- Step 1** Eject the client adapter and remove it from the Windows CE device.
 - Step 2** Tap **Start > Settings > System** tab > **Remove Programs** (on PPC devices) or **Start > Settings > Control Panel > Remove Programs** (on HPC and Windows CE .NET devices).
 - Step 3** Tap **Cisco Wireless LAN Adapter**.
 - Step 4** Tap the **Remove** button.
 - Step 5** When asked to verify your decision to remove the adapter, tap **Yes**.
 - Step 6** Tap **OK**. The driver, client utilities, registry entries, and Cisco directory are removed.

- Step 7** Go to the “[Loading a New Driver and Client Utilities](#)” section below for instructions on loading the new driver and client utilities.
-

Loading a New Driver and Client Utilities

Follow these steps to install client utility and driver release 2.72 for your client adapter.

- Step 1** Connect your Windows CE device to a laptop or PC running Microsoft ActiveSync. This is typically done using a serial or USB cable.

A message appears on the Windows CE device indicating that it is connecting to the host. After the Windows CE device is connected, the New Partnership window appears on the laptop or PC. This window asks if you want to set up a partnership.



Note Cisco recommends that you install the latest release of ActiveSync.

- Step 2** Perform one of the following:

- If you want to establish a partnership that enables you to synchronize files between the laptop or PC and the Windows CE device, choose **Yes**, click **Next**, and follow the instructions on the screen to specify the files to be synchronized and to finish setting up the partnership.
- If you do not want to synchronize files and want to connect as a “guest,” choose **No** and click **Next**. The screen indicates that you are connected as a guest.

- Step 3** Use your laptop or PC’s web browser to access the following URL:

<http://www.cisco.com/public/sw-center/sw-wireless.shtml>

- Step 4** Click **Option #2: Aironet Wireless Software Display Tables**.



Note You can download software from the Software Selector tool instead of the display tables. To do so, click **Option #1: Aironet Wireless Software Selector**, follow the instructions on the screen, and go to [Step 9](#).

- Step 5** Click **Cisco Aironet Wireless LAN Client Adapters**.

- Step 6** Find the section for Windows CE client adapter drivers and utilities.

- Step 7** Click the link for Windows CE 3.0 or Windows CE .NET, depending on your device’s operating system.

- Step 8** Click the **WinCE-PCMCIA-LMC-v272.exe** file.

- Step 9** Complete the encryption authorization form; then read and accept the terms and conditions of the Software License Agreement.




- Step 10** Click the **WinCE-PCMCIA-LMC-v272.exe** file to download it.

- Step 11** Save the file to the hard drive of your laptop or PC.

- Step 12** Find the file using Windows Explorer, double-click it, and extract its files to a folder.



Note Make sure you keep all of the extracted files together in one folder. Moving them to different locations may prevent the software from operating correctly.

- Step 13** Double-click the **ceInstall.exe** file.
- Step 14** If you are using a PPC 2002 device, the Install 802.1X Support screen appears. If you are planning to use EAP-TLS or PEAP authentication, click **Yes**. Otherwise, click **No**.
-  **Note** If you choose Yes, the PPC 2002 802.1X backport, which provides support for 802.1X security, is installed. The backport then becomes part of the base Windows CE operating system and cannot be uninstalled.
- Step 15** If you are using a PPC 2002, PPC 2003, or Windows CE .NET 4.2 device, the Cisco PEAP screen appears. If you are planning to use Cisco PEAP authentication, make sure the **Install Cisco PEAP Support** check box is checked and click **Next**. Otherwise, uncheck the **Install Cisco PEAP Support** check box and click **Next**.
-  **Note** If you install the Cisco PEAP supplicant and later want to use the Microsoft PEAP supplicant, you must default your Windows CE device and reinstall the client adapter software.
- Step 16** If you installed the 802.1X backport on a PPC 2002 device, a message appears indicating that you must reset your device when the installation is complete. Click **OK**.
- Step 17** If you are not using a PPC 2002 device, the Cisco Aironet Wireless LAN Adapter Setup screen appears. Click **Next** to start the Windows CE Application Manager (CeAppMgr), which is installed with ActiveSync. CeAppMgr interrogates the Windows CE device to determine its platform type.
-  **Note** If a Windows CE device is not connected to the laptop or PC (as instructed in [Step 1](#)), click **Exit** to quit the setup program and connect a Windows CE device or click **Next** to continue the installation. If you choose **Exit**, click **OK** to shut down CeAppMgr and start again beginning with [Step 1](#). If you choose **Next**, a message appears indicating that the software will be downloaded the next time a mobile device is connected. Click **OK**. The next time a Windows CE device is connected to the laptop or PC via ActiveSync, CeAppMgr starts automatically, and you are prompted to install the software.
- Step 18** When the Installing Applications dialog box appears asking if you want to install the client adapter using the default application installation directory, click **Yes**. The default directory is \Windows\Start Menu\Programs\Cisco on PPC devices and \Windows\Programs\Cisco on HPC and Windows CE .NET devices.
- A message and a progress bar appear indicating that the client adapter (and 802.1X backport if you are using a PPC 2002 device) is being installed.
- The driver and help files are copied to the \Windows directory, and the client utilities are installed in the \Windows\Start Menu\Programs\Cisco directory on PPC devices or the \Windows\Programs\Cisco directory on HPC and Windows CE .NET devices. Shortcuts to ACU and WLM are automatically added to the desktop on HPC and Windows CE .NET devices.
- Step 19** When the installation process is complete on the laptop or PC, a message appears asking you to view the screen of the Windows CE device to see if any additional steps are required to complete the installation. Click **OK** to terminate the installation process on the laptop or PC.
- Step 20** Complete any required steps on the Windows CE device.
- Step 21** Disconnect the Windows CE device.

- Step 22** If you are using a PPC 2002 device and you installed the 802.1X backport, reset your Windows CE device now. (You should have been notified earlier that a reset would be required after installation.)
- Step 23** Insert the client adapter into the PC card slot of the Windows CE device. The Windows CE device should configure the client adapter, and the green LED on the adapter should blink. If this does not happen, remove the client adapter, reset the Windows CE device, and reinsert the client adapter.
- Step 24** The Cisco Wireless LAN Adapter Settings dialog box appears. If the dialog box does not appear, perform one of the following:
- Tap **Start > Settings > the Connections tab > Connections > Advanced > Network Card > Cisco Wireless LAN Adapter** on PPC 2003 devices.
 - Tap **Start > Settings > the Connections tab > Network Adapters > Cisco Wireless LAN Adapter > Properties** on PPC 2002 devices.
 - Tap **Start > Settings > Control Panel > Network > the Adapters tab > Cisco Wireless LAN Adapter > Properties** on HPC devices.
 - Tap **Start > Settings > Network and Dial-up Connections > the Cisco Wireless LAN Client Adapter icon** on Windows CE .NET devices.
- Step 25** Perform one of the following:
- If your device is connected to a DHCP server, choose **Obtain an IP address via DHCP** or **Use server-assigned IP address** and tap **OK**.
 - If your device is not connected to a DHCP server, choose **Specify an IP address** or **Use specific IP address** and follow these steps:
 - a. Enter the IP address, subnet mask, and default gateway address you want to assign to your device. They can be obtained from your system administrator.
 - b. Choose the **Name Servers** tab and enter the primary and secondary DNS and WINS you want to assign to your device. They can be obtained from your system administrator.
 - c. Tap **OK**.

The driver and client utility installation is complete. To verify that you have properly installed the driver and client utilities, check the client adapter's LEDs. If the installation was successful, the client adapter's green LED blinks.



Note Refer to the *Cisco Aironet 350 Series Wireless LAN Client Adapters Installation and Configuration Guide for Windows CE* (part number OL-1375-05) for information on configuring your client adapter.

Caveats

This section describes resolved and open caveats for client utility and driver release 2.72 for Windows CE.

Resolved Caveats

- CSCsc87195—Throughput on PSC handheld LM350 greatly reduced when run with Symbol MC50
When Chariot upstream Filesndl.scr with PSC scanner and Symbol MC50 are run at the same time, the throughput on the PSC scanner is approximately one-third of the throughput on the Symbol device. This condition occurs when WPA-PSK is used. Running PSC by itself does not have a low throughput.
- CSCsc99838—ACU WEP utility does not allow a single key in index other than in index 1
If you attempt to put a single WEP key in an index other than index 1, the ACU requests a WEP key. However, if you set the same key in index 1 but set the transmit key to another key, the ACU does not request a WEP key and the client associates correctly.
- CSCsd12752—Windows CE.Net 4.2 PSC Falcon 4423 scanner with Cisco Embedded Mini-PCI card does not renew DHCP-generated IP address after controller disassociates and deauthenticates client
The controller disassociates and deauthenticates the client and deletes its context, but the client reassociates before its 10-second disconnect timer expires and notifies the Windows CE stack. The client already has an IP address, but the controller creates a new context and is not aware that the client has an IP address.

Open Caveats

The following caveat is not resolved in client utility and driver release 2.72 for Windows CE.

- CSCsc15223—Windows CE device with ACU 2.70 does not reconnect if external profile is used.
A 350 LMC wireless client is installed on a Symbol PDT8100 that is running Windows CE 4.20.0. The ACU is installed on the device. In the ACU, the “External Setting” is configured as “Select Active Profile” so that EAP-TLS can be configured for the Microsoft supplicant (an external profile). The Symbol PDT8100 initially associates to the AP1200. When the device goes out of radio coverage range but later comes within range, the device does not automatically associate to the access point.
Workaround: Manually reconnect the SSID, or restart the device that is running Windows CE.

Getting Bug Information on Cisco.com

If you are a Cisco registered user, you can use the Cisco TAC Software Bug Toolkit, which consists of three tools (Bug Navigator, Bug Watcher, and Search by Bug ID Number) that help you to identify existing bugs (or caveats) in Cisco software products.

Access the TAC Software Bug Toolkit today at:

http://www.cisco.com/cgi-bin/Support/Bugtool/launch_bugtool.pl

Troubleshooting

For the most up-to-date, detailed troubleshooting information, refer to the Cisco TAC website at <http://www.cisco.com/en/US/support/index.html>

Click **Hardware Support > Wireless Devices**. Then choose your product and **Troubleshooting** to find information on the problem you are experiencing.

Related Documentation

For more information about Cisco Aironet 350 series client adapters for Windows CE, refer to the following documents:

- *Cisco Aironet 350 Series Wireless LAN Client Adapters Installation and Configuration Guide for Windows CE*, OL-1375-05
http://www.cisco.com/en/US/products/hw/wireless/ps4555/products_installation_and_configuration_guide_book09186a0080380cd3.html
- *Release Notes for Cisco Aironet 350 and CB20A Client Adapter Firmware 5.60.21*, OL-8496-01
http://www.cisco.com/en/US/products/hw/wireless/ps4555/prod_release_note09186a00805579db.html

Obtaining Documentation

Cisco documentation and additional literature are available on Cisco.com. Cisco also provides several ways to obtain technical assistance and other technical resources. These sections explain how to obtain technical information from Cisco Systems.

Cisco.com

You can access the most current Cisco documentation at this URL:

<http://www.cisco.com/techsupport>

You can access the Cisco website at this URL:

<http://www.cisco.com>

You can access international Cisco websites at this URL:

http://www.cisco.com/public/countries_languages.shtml

Product Documentation DVD

Cisco documentation and additional literature are available in the Product Documentation DVD package, which may have shipped with your product. The Product Documentation DVD is updated regularly and may be more current than printed documentation.

The Product Documentation DVD is a comprehensive library of technical product documentation on portable media. The DVD enables you to access multiple versions of hardware and software installation, configuration, and command guides for Cisco products and to view technical documentation in HTML. With the DVD, you have access to the same documentation that is found on the Cisco website without being connected to the Internet. Certain products also have .pdf versions of the documentation available.

The Product Documentation DVD is available as a single unit or as a subscription. Registered Cisco.com users (Cisco direct customers) can order a Product Documentation DVD (product number DOC-DOCDVD=) from Cisco Marketplace at this URL:

<http://www.cisco.com/go/marketplace/>

Ordering Documentation

Beginning June 30, 2005, registered Cisco.com users may order Cisco documentation at the Product Documentation Store in the Cisco Marketplace at this URL:

<http://www.cisco.com/go/marketplace/>

Nonregistered Cisco.com users can order technical documentation from 8:00 a.m. to 5:00 p.m. (0800 to 1700) PDT by calling 1 866 463-3487 in the United States and Canada, or elsewhere by calling 011 408 519-5055. You can also order documentation by e-mail at tech-doc-store-mkpl@external.cisco.com or by fax at 1 408 519-5001 in the United States and Canada, or elsewhere at 011 408 519-5001.

Documentation Feedback

You can rate and provide feedback about Cisco technical documents by completing the online feedback form that appears with the technical documents on Cisco.com.

You can send comments about Cisco documentation to bug-doc@cisco.com.

You can submit comments by using the response card (if present) behind the front cover of your document or by writing to the following address:

Cisco Systems
Attn: Customer Document Ordering
170 West Tasman Drive
San Jose, CA 95134-9883

We appreciate your comments.

Cisco Product Security Overview

Cisco provides a free online Security Vulnerability Policy portal at this URL:

http://www.cisco.com/en/US/products/products_security_vulnerability_policy.html

From this site, you can perform these tasks:

- Report security vulnerabilities in Cisco products.
- Obtain assistance with security incidents that involve Cisco products.
- Register to receive security information from Cisco.

A current list of security advisories and notices for Cisco products is available at this URL:

<http://www.cisco.com/go/psirt>

If you prefer to see advisories and notices as they are updated in real time, you can access a Product Security Incident Response Team Really Simple Syndication (PSIRT RSS) feed from this URL:

http://www.cisco.com/en/US/products/products_psirt_rss_feed.html

Reporting Security Problems in Cisco Products

Cisco is committed to delivering secure products. We test our products internally before we release them, and we strive to correct all vulnerabilities quickly. If you think that you might have identified a vulnerability in a Cisco product, contact PSIRT:

- Emergencies—security-alert@cisco.com

An emergency is either a condition in which a system is under active attack or a condition for which a severe and urgent security vulnerability should be reported. All other conditions are considered nonemergencies.

- Nonemergencies—psirt@cisco.com

In an emergency, you can also reach PSIRT by telephone:

- 1 877 228-7302
- 1 408 525-6532



Tip

We encourage you to use Pretty Good Privacy (PGP) or a compatible product to encrypt any sensitive information that you send to Cisco. PSIRT can work from encrypted information that is compatible with PGP versions 2.x through 8.x.

Never use a revoked or an expired encryption key. The correct public key to use in your correspondence with PSIRT is the one linked in the Contact Summary section of the Security Vulnerability Policy page at this URL:

http://www.cisco.com/en/US/products/products_security_vulnerability_policy.html

The link on this page has the current PGP key ID in use.

Obtaining Technical Assistance

Cisco Technical Support provides 24-hour-a-day award-winning technical assistance. The Cisco Technical Support & Documentation website on Cisco.com features extensive online support resources. In addition, if you have a valid Cisco service contract, Cisco Technical Assistance Center (TAC) engineers provide telephone support. If you do not have a valid Cisco service contract, contact your reseller.

Cisco Technical Support & Documentation Website

The Cisco Technical Support & Documentation website provides online documents and tools for troubleshooting and resolving technical issues with Cisco products and technologies. The website is available 24 hours a day, at this URL:

<http://www.cisco.com/techsupport>

Access to all tools on the Cisco Technical Support & Documentation website requires a Cisco.com user ID and password. If you have a valid service contract but do not have a user ID or password, you can register at this URL:

<http://tools.cisco.com/RPF/register/register.do>



Note

Use the Cisco Product Identification (CPI) tool to locate your product serial number before submitting a web or phone request for service. You can access the CPI tool from the Cisco Technical Support & Documentation website by clicking the **Tools & Resources** link under Documentation & Tools. Choose **Cisco Product Identification Tool** from the Alphabetical Index drop-down list, or click the **Cisco Product Identification Tool** link under Alerts & RMAs. The CPI tool offers three search options: by product ID or model name; by tree view; or for certain products, by copying and pasting **show** command output. Search results show an illustration of your product with the serial number label location highlighted. Locate the serial number label on your product and record the information before placing a service call.

Submitting a Service Request

Using the online TAC Service Request Tool is the fastest way to open S3 and S4 service requests. (S3 and S4 service requests are those in which your network is minimally impaired or for which you require product information.) After you describe your situation, the TAC Service Request Tool provides recommended solutions. If your issue is not resolved using the recommended resources, your service request is assigned to a Cisco engineer. The TAC Service Request Tool is located at this URL:

<http://www.cisco.com/techsupport/servicerequest>

For S1 or S2 service requests or if you do not have Internet access, contact the Cisco TAC by telephone. (S1 or S2 service requests are those in which your production network is down or severely degraded.) Cisco engineers are assigned immediately to S1 and S2 service requests to help keep your business operations running smoothly.

To open a service request by telephone, use one of the following numbers:

Asia-Pacific: +61 2 8446 7411 (Australia: 1 800 805 227)

EMEA: +32 2 704 55 55

USA: 1 800 553-2447

For a complete list of Cisco TAC contacts, go to this URL:

<http://www.cisco.com/techsupport/contacts>

Definitions of Service Request Severity

To ensure that all service requests are reported in a standard format, Cisco has established severity definitions.

Severity 1 (S1)—Your network is “down,” or there is a critical impact to your business operations. You and Cisco will commit all necessary resources around the clock to resolve the situation.

Severity 2 (S2)—Operation of an existing network is severely degraded, or significant aspects of your business operation are negatively affected by inadequate performance of Cisco products. You and Cisco will commit full-time resources during normal business hours to resolve the situation.

Severity 3 (S3)—Operational performance of your network is impaired, but most business operations remain functional. You and Cisco will commit resources during normal business hours to restore service to satisfactory levels.

Severity 4 (S4)—You require information or assistance with Cisco product capabilities, installation, or configuration. There is little or no effect on your business operations.

Obtaining Additional Publications and Information

Information about Cisco products, technologies, and network solutions is available from various online and printed sources.

- Cisco Marketplace provides a variety of Cisco books, reference guides, documentation, and logo merchandise. Visit Cisco Marketplace, the company store, at this URL:

<http://www.cisco.com/go/marketplace/>

- *Cisco Press* publishes a wide range of general networking, training and certification titles. Both new and experienced users will benefit from these publications. For current Cisco Press titles and other information, go to Cisco Press at this URL:

<http://www.ciscopress.com>

- *Packet* magazine is the Cisco Systems technical user magazine for maximizing Internet and networking investments. Each quarter, Packet delivers coverage of the latest industry trends, technology breakthroughs, and Cisco products and solutions, as well as network deployment and troubleshooting tips, configuration examples, customer case studies, certification and training information, and links to scores of in-depth online resources. You can access Packet magazine at this URL:

<http://www.cisco.com/packet>

- *iQ Magazine* is the quarterly publication from Cisco Systems designed to help growing companies learn how they can use technology to increase revenue, streamline their business, and expand services. The publication identifies the challenges facing these companies and the technologies to help solve them, using real-world case studies and business strategies to help readers make sound technology investment decisions. You can access iQ Magazine at this URL:

<http://www.cisco.com/go/iqmagazine>

or view the digital edition at this URL:

<http://ciscoiq.texterity.com/ciscoiq/sample/>

- *Internet Protocol Journal* is a quarterly journal published by Cisco Systems for engineering professionals involved in designing, developing, and operating public and private internets and intranets. You can access the Internet Protocol Journal at this URL:
<http://www.cisco.com/ipj>
- Networking products offered by Cisco Systems, as well as customer support services, can be obtained at this URL:
<http://www.cisco.com/en/US/products/index.html>
- Networking Professionals Connection is an interactive website for networking professionals to share questions, suggestions, and information about networking products and technologies with Cisco experts and other networking professionals. Join a discussion at this URL:
<http://www.cisco.com/discuss/networking>
- World-class networking training is available from Cisco. You can view current offerings at this URL:
<http://www.cisco.com/en/US/learning/index.html>

This document is to be used in conjunction with the documents listed in the “[Related Documentation](#)” section.

CCSP, CCVP, the Cisco Square Bridge logo, Follow Me Browsing, and StackWise are trademarks of Cisco Systems, Inc.; Changing the Way We Work, Live, Play, and Learn, and iQuick Study are service marks of Cisco Systems, Inc.; and Access Registrar, Aironet, BPX, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Cisco Unity, Enterprise/Solver, EtherChannel, EtherFast, EtherSwitch, Fast Step, FormShare, GigaDrive, GigaStack, HomeLink, Internet Quotient, IOS, IP/TV, iQ Expertise, the iQ logo, iQ Net Readiness Scorecard, LightStream, Linksys, MeetingPlace, MGX, the Networkers logo, Networking Academy, Network Registrar, *Packet*, PIX, Post-Routing, Pre-Routing, ProConnect, RateMUX, ScriptShare, SlideCast, SMARTnet, The Fastest Way to Increase Your Internet Quotient, and TransPath are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

All other trademarks mentioned in this document or Website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0601R)

Copyright © 2006 Cisco Systems, Inc.
All rights reserved.

