



Release Notes for Cisco IOS Release 15.2(7)E3

First Published: September 14, 2020
Last Updated: October 5, 2020

Cisco IOS Release 15.2(7)E3 runs on these platforms:

- Cisco 2500 Series Connected Grid Switches (CGS2520)
- Cisco Connected Grid Ethernet Switch Module (CGR2010 ESM)
- Cisco Embedded Service 2020 Series Switches (ESS2020)
- Cisco Industrial Ethernet 2000 Series Switches (IE2000)
- Cisco Industrial Ethernet 2000U Series Switches (IE2000U)
- Cisco Industrial Ethernet 3000 Series Switches (IE3000)
- Cisco Industrial Ethernet 3010 Series Switches (IE3010)
- Cisco Industrial Ethernet 4000 Series Switches (IE4000)
- Cisco Industrial Ethernet 4010 Series Switches (IE4010)
- Cisco Industrial Ethernet 5000 Series Switches (IE5000)

These release notes include important information about Cisco IOS Release 15.2(7)E3 and any limitations, restrictions, and caveats that apply to the release. Verify that these release notes are correct for your switch:

- If you are installing a new switch, see the Cisco IOS release label on the rear panel of your switch.
- If your switch is on, use the **show version** command. See [Finding the Software Version and Feature Set, page 6](#).
- If you are upgrading to a new release, see the software upgrade filename for the software version. See [Deciding Which Files to Use, page 6](#).

For a complete list of documentation for the platforms associated with this release, see [Closed Caveats, page 14](#).

You can download the switch software from this site (registered Cisco.com users with a login password):

<http://software.cisco.com/download/navigator.html>

Organization

This document includes the following sections:

Conventions, page 2	Conventions used in this document.
New Features in Cisco IOS Release 15.2(7)E3, page 3	New features supported for Releases 15.2(7)E3.
Device Manager Localization, page 5	Summarizes the language translations supported by the Device Manager online help (OLH).
Express Setup Requirements, page 5	Summarizes the hardware and software requirements for the Windows platform.
Upgrading the Switch Software, page 5	Procedures for downloading software.
Caveats, page 11	Summarizes Open, Resolved and Closed caveats in Release 15.2(7)E3.
Related Documentation, page 14	Links to the documentation for the hardware platforms associated with this release.

Conventions

This document uses the following conventions.

Conventions	Indication
bold font	Commands and keywords and user-entered text appear in bold font .
<i>italic font</i>	Document titles, new or emphasized terms, and arguments for which you supply values are in <i>italic font</i> .
[]	Elements in square brackets are optional.
{x y z }	Required alternative keywords are grouped in braces and separated by vertical bars.
[x y z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
courier font	Terminal sessions and information the system displays appear in <code>courier font</code> .
< >	Nonprinting characters such as passwords are in angle brackets.
[]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.

Note: Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the manual.

Caution: Means *reader be careful*. In this situation, you might perform an action that could result in equipment damage or loss of data.

Warning: IMPORTANT SAFETY INSTRUCTIONS

Means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents. Use the statement number provided at the end of each warning to locate its translation in the translated safety warnings

that accompanied this device.

SAVE THESE INSTRUCTIONS

Regulatory: Provided for additional information and to comply with regulatory and customer requirements.

New Features in Cisco IOS Release 15.2(7)E3

Table 1

Feature	Platform	Description	Related Documentation
CISCO-PTP-MIB Enhancements	CGS2520 , IE2000, IE2000U, IE3000, IE4000, IE4010, IE5000	Extends the PTP MIB support to the power profile. New capabilities include support for time property to the PTP-MIB and addition of PTP-MIB support to IE2000.	Precision Time Protocol Software Configuration Guide for IE4000, IE4010, and IE5000 Device Manager Online help
DSCP values for Precision Timing Protocol (PTP) configurable by User and New Minimum Value (Boundary Clock Mode and GM-BC)	CGS2520 , IE2000, IE2000U, IE3000, IE4000, IE4010, IE5000	Two new DSCP Value messages available for Precision Timing Protocol (PTP): <ul style="list-style-type: none"> ■ DSCP Value for Event Message (Boundary clock mode and GM-BC mode): Provides a value for event messages that are tagged with a timestamp. DSCP messages are used for a Quality of Service (QoS) configuration to prioritize the PTP packets as they pass through the network. Range is 0 to 63. (Previously, this was a set value of 59) ■ DSCP Value for General Message: (Boundary clock and GM-BC mode) PTP messages are not tagged with a timestamp. Range is 0 to 63. (Previously, this was a set value of 47). 	Precision Time Protocol Software Configuration Guide for IE4000, IE4010 and IE5000 Switches Device Manager Online help
Enhanced Port Security	IE4000, IE4010, IE5000	Provides Utility Substation port security to prevent illegal spoofing of a tele-protection relay MAC address.	Cisco Industrial Ethernet 4000, 4010 and 5000 Switch Software Configuration Guide See “Configuring Port-Based Traffic Control” chapter in the guide above

Table 1

Feature	Platform	Description	Related Documentation
Hide and Mask Enable Password	CGS2520 , IE2000, IE4000, IE4010, IE5000	<p>Allows you to hide and/or mask the password, when you create and/or change the user's password and enable mode password for switch-based authentication.</p> <p>S5400-winter1(config)#username cisco masked-secret</p> <p>S5400-winter1(config)#enable masked-secret</p> <p>Note: This feature auto-converts type-0 password to type-9, which will cause the Device Manager login page to open slowly on low-end platforms such as IE2000, CSG2520 and IE3000.</p>	<p>Cisco Industrial Ethernet 4000, 4010 and 5000 Switch Software Configuration Guide</p> <p>See "Configuring Switch-Based Authentication" in the guide above.</p> <p>Device Manager Online help</p>
MAC Address Change for VLAN Interface	IE4000, IE4010, IE5000	<p>Allows you to modify the MAC address for a Layer 3 VLAN interface, specifically the Switch Virtual Interface (SVI) to a customer-assigned value.</p>	<p>Horizontal Stacking Software Configuration Guide for IE5000 Switches</p>
Seamless Operation of Precision Transfer Protocol (PTP) Over the Port Channel Member Channel Interfaces when Operating in Boundary Clock Mode	CGS2520 , IE2000, IE2000U IE3000, IE4000, IE4010, IE5000	<p>Allows Precision Transfer Protocol to work over the Port-channel interface in the following mode:</p> <ul style="list-style-type: none"> ■ Boundary clock 	<p>Precision Time Protocol Software Configuration Guide for IE4000, IE4010 and IE5000 Switches</p> <p>Device Manager Online help</p>
PTP Master Only Port	CGS2520 , IE2000, IE2000U IE3000, IE4000, IE4010, IE5000	<p>Provides additional security for the PTP Master Only port. See command below.</p> <p>Switch(config)#int gigabitEthernet 1/9</p> <p>Switch(config-if)#ptp gmc-block</p> <p>Note: Its operation is comparable to the bpduguard in the Spanning Tree Protocol.</p>	<p>Precision Time Protocol Software Configuration Guide for IE4000, IE4010 and IE5000 Switches</p> <p>Device Manager Online help</p>
SUDI 2099 Support - Software SUDI	CGS2520 , IE2000U	<p>Provides alignment with Cisco Trustworthy Systems.</p>	<p>Cisco Trustworthy Systems</p>
Upgrade History Logging Message	CGS2520 , IE2000, IE4000, IE4010, IE5000	<p>Provides history of software and downgrade history</p>	<p>Cisco Industrial Ethernet 4000, 4010 and 5000 Switch Software Configuration Guide</p> <p>See "Working with the Flash File System" in the guide above.</p> <p>Device Manager Online help</p>

Device Manager Localization

Online help for the Device Manager is available in the following languages for the IE 2000, IE 2000U, IE 3000, IE 4000, IE 4010 and IE 5000 switches:

- Chinese (Traditional) (code: 2052)
- Chinese (Simplified) (code: 1028)
- (Default): English (code: 1033)
- French (code: 1036)
- German (code: 1031)
- Japanese (code: 1041)
- Spanish (LATAM) (code: 9226)

Express Setup Requirements

This section summarizes the hardware and software requirements for the Windows platform.

For a listing of Express Setup documentation, see [Table 3 Methods for Assigning IP Information, page 9](#).

Hardware

- 1 gigahertz (GHz) or faster 32-bit (x86) or 64-bit (x64) processor
- 1 gigabyte (GB) RAM (32-bit) or 2 GB RAM (64-bit)
- 16 GB available hard disk space (32-bit) or 20 GB (64-bit)

Software

- PC with Windows 7, Windows 10, or Mac OS 10.6.x
- Web browser (Internet Explorer 10.0 or 11.0, or Firefox 48.x and above) with JavaScript enabled
- Straight-through or crossover Category 5 or 6 cable

Express Setup verifies the browser version when starting a session, and it does not require a plug-in.

Upgrading the Switch Software

These are the procedures for downloading software. Before downloading software, read these sections for important information:

- [Finding the Software Version and Feature Set, page 6](#)
- [Deciding Which Files to Use, page 6](#)
- [Archiving Software Images, page 7](#)
- [Upgrading a Switch by Using the CLI, page 7](#)
- [Upgrading IOS and FPGA on the Ethernet Switch Module \(ESM\), page 8](#)
- [Installation Notes, page 9](#)

Finding the Software Version and Feature Set

The Cisco IOS image is stored as a bin file in a directory that is named with the Cisco IOS release. A subdirectory contains the files needed for web management. The image is stored on the compact flash memory card.

You can use the **show version** privileged EXEC command to see the software version that is running on your switch. The second line of the display shows the version.

You can also use the **dir filesystem:** privileged EXEC command to see the directory names of other software images stored in flash memory. For example, use the **dir flash:** command to display the images in the flash memory.

Deciding Which Files to Use

The upgrade procedures in these release notes describe how to perform the upgrade by using a combined tar file. This file contains the Cisco IOS image file and the files needed for the embedded device manager. You must use the combined tar file to upgrade the switch through Express Setup. To upgrade the switch through the command-line interface (CLI), use the tar file and the **archive download-sw** privileged EXEC command.

Table 2 lists the filenames for this software release.

Note: If you download the IP services image and plan to use Layer 3 functionality, you must use the Switch Database Management (SDM) routing template. To determine the currently active template, enter the **show sdm prefer** privileged EXEC command. If necessary, enter the **sdm prefer** global configuration command to change the SDM template to a specific template. For example, if the switch uses Layer 3 routing, change the SDM template from the default to the routing template. You must reload the switch for the new template to take effect.

Note: Beginning with Cisco IOS Release 15.2(5)E, we **no longer release** the IE 3000 IP services image. The latest release for the IP services image on the IE 3000 is 15.2(4)EA1.

Table 2 Cisco IOS Software Image Files

File Name	Description
cgs2520-ipserviceslmk9-tar.152-7.E3.tar	CGS 2520 IP services image file
cgs2520-lanbaselmk9-tar.152-7.E3.tar	CGS 2520 LAN base image file
c2020-universalk9-tar.152-7.E3.tar	ESS 2020 universal image file
ie2000-universalk9-tar.152-7.E3.tar	IE 2000 universal image file
ie2000u-ipserviceslmk9-tar.152-7.E3.tar	IE 2000U IP services image file
ie2000u-lanbaselmk9-tar.152-7.E3.tar	IE 2000U LAN base image file
ie3010-ipservicesk9-tar.152-7.E3.tar	IE 3010 IP services image file
ie3010-lanbasek9-tar.152-7.E3.tar	IE 3010 LAN base image file
ies-lanbasek9-tar.152-7.E3.tar	IE 3000 LAN base image file
grwicdes-ipserviceslmk9-tar.152-7.E3.tar	ESM IP services image file
grwicdes-lanbaselmk9-tar.152-7.E3.tar	ESM LAN base image file
ie4000-universalk9-tar.152-7.E3.tar	IE 4000 Universal image file
ie4010-universalk9-tar.152-7.E3.tar	IE 4010 Universal image file
ie5000-universalk9-tar.152-7.E3.tar	IE 5000 Universal image file

Archiving Software Images

Before upgrading your switch software, make sure that you archive copies of both your current Cisco IOS release and the Cisco IOS release to which you are upgrading. Keep these archived images until you have upgraded all devices in the network to the new Cisco IOS image and verified that the new Cisco IOS image works properly in your network.

Cisco routinely removes old Cisco IOS versions from Cisco.com. See *Product Bulletin 2863* for information: http://www.cisco.com/en/US/prod/collateral/iosswrel/ps8802/ps6969/ps1835/prod_bulletin0900aecd80281c0e.html

You can copy the bin software image file on the flash memory to the appropriate TFTP directory on a host by using the **copy flash: tftp:** privileged EXEC command.

Note: Although you can copy any file on the flash memory to the TFTP server, it is time consuming to copy all of the HTML files in the tar file. We recommend that you download the tar file from Cisco.com and archive it on an internal host in your network.

You can also configure the switch as a TFTP server to copy files from one switch to another without using an external TFTP server by using the **tftp-server** global configuration command.

Upgrading a Switch by Using the CLI

This procedure is for copying the combined tar file to the switch. You copy the file to the switch from a TFTP server and extract the files. You can download an image file and replace or keep the current image.

Note: Make sure that the compact flash card is in the switch before downloading the software.

To download software, follow these steps:

1. Use [Table 2 on page 6](#) to identify the file that you want to download.
2. Download the software image file. If you have a SMARTnet support contract, go to this URL, and log in to download the appropriate files:

<http://software.cisco.com/download/navigator.html>

For example, to download the image for an IE 2000 switch, select Products > Switches > Industrial Ethernet Switches > Cisco Industrial Ethernet 2000 Series Switches, then select your switch model. Select IOS Software for Software Type, then select the image you want to download.

3. Copy the image to the appropriate TFTP directory on the workstation, and make sure that the TFTP server is properly configured.

For more information, see the “Assigning the Switch IP Address and Default Gateway” chapter in the applicable document for your switch as listed in [Table 3](#).

4. Log into the switch through the console port or a Telnet session.
5. (Optional) Ensure that you have IP connectivity to the TFTP server by entering this privileged EXEC command:

```
Switch# ping tftp-server-address
```

For more information about assigning an IP address and default gateway to the switch, see [Table 3](#).

6. Download the image file from the TFTP server to the switch.

If you are installing the same version of software that currently exists on the switch, overwrite the current image by entering this privileged EXEC command:

```
Switch# archive download-sw /overwrite /reload tftp://location /directory /image-name.tar
```

Upgrading the Switch Software

The command above untars/unzips the file. The system prompts you when it completes successfully.

- The **/overwrite** option overwrites the software image in flash memory with the downloaded one.

If you specify the command without the **/overwrite** option, the download algorithm verifies that the new image is not the same as the one on the switch Flash device. If the images are the same, the download does not occur. If the images are different, the old image is deleted, and the new one is downloaded. If there is not enough space to install the new image and keep the current running image, the download process stops, and an error message displays.

- The **/reload** option reloads the system after downloading the image unless the configuration has been changed and not saved.
- For **// location**, specify the IP address of the TFTP server. or hostname.
- For **/directory/image-name.tar**, specify the directory and the image to download. Directory and image names are case sensitive. The directory is for file organization and it is generally a *tftpboot/user-ID* path.

This example shows how to download an image from a TFTP server at 198.30.20.19 and to overwrite the image on the switch:

```
Switch# archive download-sw /overwrite tftp://198.30.20.19/image-name.tar
```

You can also download the image file from the TFTP server to the switch and keep the current image by replacing the **/overwrite** option with the **/leave-old-sw** option. If there is not enough space to install the new image and keep the current running image, the download process stops, and an error message displays.

Upgrading IOS and FPGA on the Ethernet Switch Module (ESM)

This procedure is for copying the combined tar file to the switch. You copy the file to the switch from a TFTP server and extract the files. You can download an image file and replace or keep the current image.

To download software, follow these steps:

1. Refer to [Deciding Which Files to Use, page 6](#) to identify the file that you want to download.
2. Download the software image file. If you have a SMARTnet support contract, go to the URL below and log in to download the appropriate files.

<http://software.cisco.com/download/navigator.html>

For example, to download the image for a Connected Grid 10-Port Ethernet Switch Module Interface Card, select Products > Cisco Interfaces and Modules > Connected Grid Modules > Connected Grid 10-Port Ethernet Switch Module Interface Card. Select IOS Software for Software Type, then select the image you want to download.

Copy the image to the appropriate TFTP directory on the workstation, and make sure that the TFTP server is properly configured. For more information, see the “Assigning the Switch IP Address and Default Gateway” chapter in the applicable document listed in [Table 3 Methods for Assigning IP Information, page 9](#).

3. Copy the image to the appropriate TFTP directory on the workstation, and make sure that the TFTP server is properly configured.
4. Log in to the switch through the console port or a Telnet session.
5. (Optional) Ensure that you IP connectivity to the TFTP server by entering this privileged EXEC command:

```
Switch# ping tftp-server-address
```

6. Download the image file from the TFTP server to the switch.

If you are installing the same version of software that currently exists on the switch, overwrite the current image by entering this privileged EXEC command:

Upgrading the Switch Software

```
Switch# archive download-sw /overwrite tftp: //location /directory /image-name.tar
```

The command above untars/unzips the file. The system prompts you when it completes successfully.

- The **/overwrite** option overwrites the software image in flash memory with the downloaded one.

If you specify the command without the **/overwrite** option, the download algorithm verifies that the new image is not the same as the one on the switch Flash device. If the images are the same, the download does not occur. If the images are different, the old image is deleted, and the new one is downloaded. If there is not enough space to install the new image and keep the current running image, the download process stops, and an error message displays.

- The **/reload** option reloads the system after downloading the image unless the configuration has been changed and not saved.
- For *// location*, specify the IP address of the TFTP server. or hostname.
- For */directory/image-name.tar*, specify the directory and the image to download. Directory and image names are case sensitive. The directory is for file organization and it is generally a *tftpboot/user-ID* path.

This example shows how to download an image from a TFTP server at 198.30.20.19 and to overwrite the image on the switch:

```
Switch# archive download-sw /overwrite tftp://198.30.20.19/image-name.tar
```

You can also download the image file from the TFTP server to the switch and keep the current image by replacing the **/overwrite** option with the **/leave-old-sw** option. If there is not enough space to install the new image and keep the current running image, the download process stops, and an error message displays.

7. After the download and the untar are complete, power cycle the CGR2010.

Installation Notes

You can assign IP information to your switch using the methods shown in [Table 3](#)

Table 3 Methods for Assigning IP Information

Method	Platform	Document
Express setup program	IE2000	Cisco IE 2000 Switch Hardware Installation Guide
	IE3000	Cisco IE 3000 Switch Getting Started Guide, Device Manager Online Help
	ESM	Connected Grid Ethernet Switch Module Interface Card Getting Started Guide
	IE4000	Cisco IE 4000 Switch Hardware Installation Guide
	IE4010	Cisco IE 4010 Switch Hardware Installation Guide
	IE5000	Cisco IE 5000 Hardened Aggregator Hardware Installation Guide

Table 3 Methods for Assigning IP Information (continued)

Method	Platform	Document
CLI-based setup program	ESS2020	Cisco Embedded Service 2020 Series Software Configuration Guide
	IE2000	Cisco IE 2000 Switch Hardware Installation Guide
	IE2000U	Cisco IE 2000U Switch Hardware Installation Guide
	IE3000	Cisco IE 3000 Series Switch Hardware Installation Guide
	IE3010	Cisco IE 3010 Switch Hardware Installation Guide
	CGS2520	Cisco CGS 2520 Hardware Installation Guide
	ESM	Cisco CGS 2520 Hardware Installation Guide Note: The <i>Cisco CGS 2520 Hardware Installation Guide</i> serves as CLI-based Setup reference for the ESM.
	IE4000	Cisco IE 4000 Switch Hardware Installation Guide
	IE4010	Cisco Industrial Ethernet 4000, 4010 and 5000 Switch Software Configuration Guide
	IE5000	Cisco IE 5000 Hardened Aggregator Hardware Installation Guide
DHCP-based autoconfiguration	ESS2020	Cisco Embedded Service 2020 Series Software Configuration Guide
	IE2000	Cisco IE 2000 Series Switch Software Configuration Guide
	IE2000U	System Management Software Configuration Guide for Cisco IE 2000U and Connected Grid Switches
	IE3000	Cisco IE 3000 Series Switch Software Configuration Guide
	IE3010	Cisco IE 3010 Series Switch Software Configuration Guide
	CGS2520	CGS 2520 Switch Software Configuration Guide
	ESM	Cisco Connected Grid Ethernet Switch Module Interface Card Software Configuration Guide
	IE4000	Cisco Industrial Ethernet 4000 Series Switch Software Configuration Guide
	IE4010	Cisco Industrial Ethernet 4000, 4010 and 5000 Switch Software Configuration Guide
	IE5000	Cisco IE 5000 Hardened Aggregator Hardware Installation Guide

Table 3 Methods for Assigning IP Information (continued)

Method	Platform	Document
Manually assigning an IP address	IE2000	Cisco IE 2000 Series Switch Software Configuration Guide
	IE2000U	System Management Software Configuration Guide for Cisco IE 2000U and Connected Grid Switches
	IE3000	Cisco IE 3000 Series Switch Software Configuration Guide
	IE3010	Cisco IE 3010 Series Switch Software Configuration Guide
	CGS2520	CGS 2520 Switch Software Configuration Guide
	ESM	Cisco Connected Grid Ethernet Switch Module Interface Card Software Configuration Guide
	IE4000	Cisco Industrial Ethernet 4000 Series Switch Software Configuration Guide
	IE4010	Cisco Industrial Ethernet 4000, 4010 and 5000 Switch Software Configuration Guide
	IE5000	Cisco IE 5000 Hardened Aggregator Hardware Installation Guide

Documentation Updates

- On all IoT switches: As part of tightening security, **enable secret 0**, will automatically be converted to authentication type '9' in Cisco IOS release 15.2(7)E3. When 'Type 9' encryption is enabled on low-end platforms (CGS2520, IE 2000, IE 2000U, and IE3000), Device Manager users will experience an approximate delay of two minutes before the Device Manager pages open. This slowness issue is projected to be resolved in Cisco IOS Release 15.2(7)E4 (CSCvu66982).

To workaround this issue, Device Manager users on low-end platforms are advised to configure authentication type '5' using the CLI command: **enable algorithm-type md5 secret <password>**.

Caveats

- [Cisco Bug Search Tool, page 11](#)
- [Open Caveats, page 12](#)
- [Resolved Caveats, page 12](#)
- [Closed Caveats, page 14](#)

Cisco Bug Search Tool

The Bug Search Tool (BST), which is the online successor to Bug Toolkit, is designed to improve the effectiveness in network risk management and device troubleshooting. The BST allows partners and customers to search for software bugs based on product, release, and keyword, and aggregates key data such as bug details, product, and version. The tool has a provision to filter bugs based on credentials to provide external and internal bug views for the search input.

Caveats

To view the details of a caveat listed in this document:

1. Access the BST (use your Cisco user ID and password) at <https://tools.cisco.com/bugsearch/>.
2. Enter the bug ID in the Search For: field

Open Caveats

Table 4 Open Caveats in Cisco IOS Release 15.2(7)E3

Bug ID	Headline
CSCvu62758	MRP: PTP announce message sent via blocked port (IE4000)
CSCvu66982	Delay in loading WebUI on Low-end Devices when type 9 encryption is enabled

Resolved Caveats

Table 5 Resolved Caveats in Cisco IOS Release 15.2(7)E3

Bug ID	Headline
CSCvr82329	IE5000: MACSEC is showing inherited status as secured, no peer in one hsr ring port. (IE4000, IE4010, IE5000)
CSCvs10217	Shut down of dot1x with NEAT authenticated Interface is shown as trunk mode in show run (CGS2520)
CSCvs30049	IE5000: PTP over SAP macsec not working on default boundary mode on uplink ports
CSCvs31988	IE5000: '\show macsec interface\' incorrectly increments Encrypted packet counts
CSCvs36043	MKA-MACSEC: C9300 key server, 10Gig intf between IE5000 & 9300: traffic loss after shut / no shut
CSCvs41335	IE-5000-12S12P-10G: MACSEC doesn't work when one gig SFP is inserted in 10 Gig port
CSCvs44048	RSPAN on REP ring to activate need to flap REP interface (IE2000, IE3000, IE4000, IE4010, IE5000)
CSCvs44057	PTP port state shows \"MASTER\" on REP ALT port (IE2000, IE3000, IE4000, IE4010, IE5000, CGS2520)
CSCvs44292	MACSEC incompatibility B/W Uplink ports of IE5K-1Gig and downlinks ports of IE5K-10gig and IE4000
CSCvs73240	Seeing 'Error: OID not increasing' while doing snmpwalk for cPtpClockParentDSTable (All IE platforms: IE2000, IE3000, IE4000, IE4010, IE5000)
CSCvs86638	cPtpClockPortRunningRole is not displaying correct values (IE platforms: IE2000, IE2000U, IE4000, IE4010, IE5000)
CSCvt11890	IE5000: PTP MPD is high (120ns) and offset goes high (100ns) with 75% line rate traffic on 10G ports
CSCvt15089	IE5000: traffic is not passed in 10G interface after MACSEC enable/disable on KS
CSCvt29628	IE5000 running in HSTACK mode crashes while responding to certain SNMP PTP OIDs
CSCvt37606	IE4000: specific interface may start to flap after a reload
CSCvt47393	PTP packets don't seem to follow IEEE standard 1588-2008 13.3.2.6
CSCvt57097	PTP Sync fails when changing modes from forward to boundary (IE2000, IE3000, IE4000, IE4010, IE5000)
CSCvt60418	IE4000 SFP TX_disable Not Asserted During Shutdown

Caveats

Table 5 Resolved Caveats in Cisco IOS Release 15.2(7)E3

Bug ID	Headline
CSCvt81172	IE-5000-12S12P-10G: Traffic failures on 10G uplinks while operating in 1G mode in certain scenario
CSCvu00222	IE4000: dot1as feature is broken
CSCvu00410	Crash seen while express set-up when we press for 6-10 sec (IE2000, IE4000, IE4010, IE5000)
CSCvu33241	IE5000: Getting message when adding alarm profile to 10Gig interface (without SFP) in member device
CSCvu82135	IE2000 returning wrong value for OID 1.3.6.1.2.1.105.1.3.1.1.3.(pethMainPseOperStatus)
CSCvu84390	IE4010: Crash with two clients using the Siemens Proneta Software
CSCvv06705	SNMP reported an unreasonable value of power supply B temperature on IE4010
CSCvv16921	IE4010 Unmatched-PdelFwUp and Unmatched-PdelResp errors increasing on uplinks with PTP enabled
CSCvv49308	PD's connected to POE interface is not recovered when power to 2nd PSU is connected back (IE4000)

Closed Caveats

Table 6 Closed Caveats in Cisco IOS Release 15.2(7)E3

Bug ID	Headline
CSCvs83948	PN device not discoverable if Profinet and Port Access Vlans are different (IE4000)
CSCvu62589	CPU Utilization Spikes during SNMP with snmp walk on CISCO-FLASH-MIB
CSCvu75772	Switch may see Link Flaps with SFPs that don't squelch the RX Data Signal AND no cable connected. (IE5000)

Related Documentation

Table 7 Related Documentation

Device or Feature	Related Documents
Cisco 2500 Series Connected Grid Switches	http://www.cisco.com/go/cgs2520
Cisco Embedded Service 2020 Series Switches (ESS 2020)	http://www.cisco.com/c/en/us/support/switches/embedded-service-2020-series-switches/tsd-products-support-series-home.html
Cisco Ethernet Switch Module (ESM) for CGR 2010	http://www.cisco.com/go/cgr2000
Cisco Industrial Ethernet 2000 Series Switches	http://www.cisco.com/go/ie2000
Cisco Industrial Ethernet 2000U Series Switches	http://www.cisco.com/go/ie2000u
Cisco Industrial Ethernet 3000 Series Switches	http://www.cisco.com/go/ie3000
Cisco Industrial Ethernet 3010 Series Switches	http://www.cisco.com/go/ie3010
Cisco Industrial Ethernet 4000 Series Switches	http://www.cisco.com/go/ie4000
Cisco Industrial Ethernet 4010 Series Switches	http://www.cisco.com/go/ie4010
Cisco Industrial Ethernet 5000 Series Switches	http://www.cisco.com/go/ie5000

No combinations are authorized or intended under this document.

Copyright 2020 Cisco systems, Inc. All rights reserved.