



Send documentation comments to n5kdocfeedback@cisco.com



Cisco Nexus 5000 Series NX-OS System Management Operations Guide, Release 5.0(3)N2(1)

For Cisco Nexus 5000 Platform Switches
and Cisco Nexus 5500 Platform Switches

December 5, 2011

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

Text Part Number: OL-28437-01

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: www.cisco.com/go/trademarks. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

*Cisco Nexus 5000 Series NX-OS System Management Operations Guide, Release 5.0(3)N2(1)
© 2010–2011 Cisco Systems, Inc. All rights reserved.*

C O N T E N T S

Preface 3

Audience	3
Document Conventions	3
Related Documentation	5
Obtaining Documentation and Submitting a Service Request	5

CHAPTER 1

Configuration Synchronization Operations 1-1

Overview	1-1
Benefits of Configuration Synchronization	1-2
Requirements	1-2
Guidelines and Limitations	1-2
vPC Configurations	1-3
Cisco Fabric Services Over IP	1-4
Switch Profiles	1-5
Switch Profile Commands	1-6
User-Based Access Controls	1-6
Verification Checks	1-7
Mutual Exclusion Check	1-7
Merge Check	1-8
Commit	1-8
Buffering	1-8
Import	1-9
Configuration Synchronization Best Practices	1-9
Configuration Examples	1-10
Configuring a vPC Topology Using Configuration Synchronization	1-10
Active/Active FEX Topology Examples	1-12
Dual-Homed FEX Topology (Active/Active FEX Topology)	1-13
New Deployments in an Active/Active FEX Topology	1-14
Existing Deployment with an Active/Active FEX Topology	1-17
Straight-Through Topology Examples	1-19
Switch vPC Topology and Straight-Through FEX Topologies (Host vPC)	1-19
New Deployment in a vPC Topology and Straight-Through FEX Topology	1-21
Existing Deployments in a vPC Topology and Straight-Through FEX Topology	1-24

Send documentation comments to n5kdocfeedback@cisco.com

Reloading a Cisco Nexus 5000 Series Switch	1-26
Synchronizing the Peer Switches After a Switch Reload	1-27
vPC Peer-Link Failures	1-28
mgmt0 Interface Connectivity is Lost	1-31
Rollback Failures with Conditional Features	1-31
Channel Group Failures	1-32
At-A-Glance Configuration Modes	1-33
Terminology	1-33

INDEX



Preface

This preface describes the audience, organization, and conventions of the *Cisco Nexus 5000 Series NX-OS System Management Operations Guide, Release 5.0(3)N2(1)*. It also provides information on how to obtain related documentation.

This chapter includes the following topics:

- [Audience, page 3](#)
- [Document Conventions, page 3](#)
- [Related Documentation, page 5](#)
- [Obtaining Documentation and Submitting a Service Request, page 5](#)

Audience

This publication is for experienced network administrators who configure and maintain Cisco NX-OS on Cisco Nexus 5000 Platform switches and Cisco Nexus 5500 Platform switches.

Document Conventions

Command descriptions use the following conventions:

Convention	Description
bold	Bold text indicates the commands and keywords that you enter literally as shown.
<i>Italic</i>	Italic text indicates arguments for which the user supplies the values.
[x]	Square brackets enclose an optional element(keyword or argument).
[x y]	Square brackets enclosing keywords or arguments separated by a vertical bar indicate an optional choice.
{x y}	Braces enclosing keywords or arguments separated by a vertical bar indicate a required choice.

Send documentation comments to n5kdocfeedback@cisco.com

[x {y z}]	Nested set of square brackets or braces indicate optional or required choices within optional or required elements. Braces and a vertical bar within square brackets indicate a required choice within an optional element.
variable	Indicates a variable for which you supply values, in context where italics cannot be used.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.

Screen examples use the following conventions::

Convention	Description
screen font	Terminal sessions and information the switch displays are in screen font.
boldface screen font	Information you must enter is in boldface screen font.
<i>italic screen font</i>	Arguments for which you supply values are in italic screen font.
< >	Nonprinting characters, such as passwords, are in angle brackets.
[]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.



Note

Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the manual.



Caution

Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.

Send documentation comments to n5kdocfeedback@cisco.com

Related Documentation

Documentation for Cisco Nexus 5000 Series Switches and Cisco Nexus 2000 Series Fabric Extenders is available at the following URL:

http://www.cisco.com/en/US/products/ps9670/tsd_products_support_series_home.html

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as an RSS feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service. Cisco currently supports RSS Version 2.0.

Send documentation comments to n5kdocfeedback@cisco.com

Configuration Synchronization Operations

This chapter provides information about configuration synchronization operations in Virtual Port Channel (vPC) topologies.

This chapter includes the following sections:

- [Overview, page 1-1](#)
- [Configuration Synchronization Best Practices, page 1-9](#)
- [Configuration Examples, page 1-10](#)
- [At-A-Glance Configuration Modes, page 1-33](#)
- [Terminology, page 1-33](#)

Overview

Some Cisco NX-OS software features require consistent configurations across Cisco Nexus 5000 Series switches in the network. For example, vPC topologies require identical configurations on peer switches. As a result, you, as the network administrator, must repeat configurations on both peer switches. This process, which can cause errors due to misconfigurations or omissions, can result in additional service disruptions because of mismatched configurations. Configuration synchronization eliminates these problems by allowing you to configure one switch and automatically synchronize the configuration on the peer switch.

In a vPC topology, an EtherChannel can be formed across two physical switches and vPCs can be connected to any networking device or end host. Because each Cisco Nexus 5000 Series switch forms an EtherChannel bundle to a downstream device, each Cisco Nexus 5000 Series switch must have some matching parameters. You can use a vPC consistency check to verify that both Cisco Nexus 5000 Series switches have the same configuration (Type 1 or Type 2). If they do not match, depending on whether it is a global (for example, spanning-tree port mode), a port-level (for example, speed, duplex, or channel-group type), or even a port-channel interface, the vPC can go into a suspended state or a VLAN can go into a blocking state on both peer switches. As a result, you must ensure that the configuration from one switch is copied identically to the peer switch.

Configuration synchronization allows you to synchronize the configuration between a pair of switches in a network. You use a switch profile to create a configuration file that you can apply locally and you use it to synchronize the configuration to its peer. Configuration synchronization and vPCs are two independent features and configuration synchronization does not eliminate vPC consistency checks. The checks will continue. If there is a configuration mismatch, the vPC can still go into a suspended state. One important benefit of configuration synchronization is that it eliminates the need to manually repeat the same configuration on both switches.

Send documentation comments to n5kdocfeedback@cisco.com

This section includes the following topics:

- [Benefits of Configuration Synchronization, page 1-2](#)
- [Requirements, page 1-2](#)
- [Guidelines and Limitations, page 1-2](#)
- [Cisco Fabric Services Over IP, page 1-4](#)
- [Switch Profiles, page 1-5](#)
- [User-Based Access Controls, page 1-6](#)
- [Verification Checks, page 1-7](#)
- [Commit, page 1-8](#)
- [Buffering, page 1-8](#)
- [Import, page 1-9](#)

Benefits of Configuration Synchronization

Configuration synchronization benefits are as follows:

- Provides a mechanism to synchronize configuration from one switch to another switch.
- Merges configurations when connectivity is established between peers.
- Allows you to choose which configuration is synchronized.
- Provides mutual exclusion for commands.
- Provides verify and commit Cisco NX-OS commands.
- Supports existing session and port profile functionality.
- Provides an **import** command to migrate existing vPC configurations to a switch profile.
- Supports Gigabit Expansion Module (GEM) and Fabric Extender (FEX) pre-provisioning.

Requirements

The requirements for configuration synchronization are as follows:

- Cisco NX-OS Release 5.0(2)N1(1) or a later release.
- Cisco Fabric Services over IP (CFS over IP) enabled on each peer, including an identical CFS over IP multicast address.
- Identical switch profiles on each switch.
- Configured peer IP addresses.

Guidelines and Limitations

The guidelines for configuration synchronization are as follows:

- You must configure the following interfaces in a switch profile:
 - Port-channel interfaces
 - Ports that are not channel-group members

Send documentation comments to n5kdocfeedback@cisco.com

- You must configure all port-channel members outside the switch profile in configuration terminal mode.
- You must follow configurations in a specified order.
- Depending on the type of vPC topology (active/active or straight-through) and the type of configuration that is needed (port channel, nonport channel, FEX, QoS, and so on), you must use the switch profile mode or the configuration terminal mode. See the “[At-A-Glance Configuration Modes](#)” section on page 1-33 to identify what mode is used for different types of configurations.

Configuration synchronization has the following configuration limitations:

- FCoE in vPC Topologies—FCoE configurations are not supported in switch profiles because configurations are typically different on peer switches. If you enable FCoE on a vPC peer switch, you must not configure the port channel in the switch profile.
- Feature Commands—The **feature** *feature name* commands that enable a conditional feature are not supported in switch profiles. You should independently configure these commands on each peer switch in configuration terminal mode.
- Configuration Rollback and Conditional Features—With configuration synchronization, when a conditional feature is present in a checkpoint and not in the running configuration, a configuration rollback to that checkpoint fails. The workaround is to reconfigure the conditional feature (“feature xyz”) before the configuration rollback is executed. This workaround also applies to **the vpc domain** command and **the peer-keepalive** command in vpc-domain mode.

vPC Configurations

Configuration synchronization requires two Cisco Nexus 5000 Series peer switches that are configured in a vPC topology. [Figure 1-1](#) shows a vPC topology configured on two Cisco Nexus 5000 Series switches (N5k-1 and N5k-2).

Figure 1-1 vPC Topology



To configure vPC on two Cisco Nexus 5000 Series switches, follow these steps:

Step 1 Create a vPC domain and configure a vPC keepalive link.

You must create identical vPC domain IDs on both vPC peer switches.

The domain ID is used to automatically form the vPC system MAC address.

```
N5k-1(config)# vpc domain 10
```

Send documentation comments to n5kdocfeedback@cisco.com

```
N5k-2 (config) # vpc domain 10
```

Step 2 Configure a vPC peer-keepalive link.

You can configure the destination IP for the peer-keepalive link that carries the keepalive messages. Optionally, you can configure other parameters for the keepalive messages.

```
N5k-1 (config) # vpc domain 10
N5k-1 (config-vpc-domain) # peer-keepalive destination 10.29.170.8 vrf management
```

```
N5k-2 (config) # vpc domain 10
N5k-2 (config-vpc-domain) # peer-keepalive destination 10.29.170.7 vrf management
```

Step 3 Create and configure a vPC peer link.

You can create a peer link by designating an EtherChannel on each switch as the peer link for the specified vPC domain. We recommend that you configure the EtherChannels that you are designating as the vPC peer link in trunk mode and that you use two ports on separate modules on each vPC peer switch for redundancy.

```
N5k-1 (config) # interface port-channel 10
N5k-1 (config-if) # vpc peer-link
```

```
N5k-1 (config) # interface ethernet 1/17-18
N5k-1 (config-if-range) # switchport mode trunk
N5k-1 (config-if-range) # channel-group 10
```

```
N5k-2 (config) # interface port-channel 10
N5k-2 (config-if) # vpc peer-link
```

```
N5k-2 (config) # interface ethernet 1/17-18
N5k-2 (config-if-range) # switchport mode trunk
N5k-2 (config-if-range) # channel-group 10
```



Note

You can configure a vPC peer link between the two Cisco Nexus 5000 Series switches either manually on both switches or with configuration synchronization from any one of the two peer switches. For information about the configuration synchronization method to configure the vPC peer link, see the [“Configuring a vPC Topology Using Configuration Synchronization”](#) section on page 1-10. For additional information on the vPC feature, see the *Cisco Nexus 5000 Series NX-OS Layer 2 Switching Configuration Guide, Release 5.0(2)N2(1)* at the following URL:

http://www.cisco.com/en/US/docs/switches/datacenter/nexus5000/sw/layer2/502_n2_1/Cisco_n5k_layer2_config_gd_rel_502_N2_1_chapter8.html

Cisco Fabric Services Over IP

The Cisco Fabric Services over IP (CFSoIP) protocol transports configuration synchronization over the mgmt0 interface (mgmt virtual routing and forwarding [VRF]). You must ensure the connectivity to the mgmt0 interface. CFSoIP and Cisco Fabric Services (CFS) are different protocols. CFS runs across the peer link for a vPC. Although both protocols are based on the CFS protocol, they exchange different control packets.

To use the CFSoIP protocol for configuration synchronization, follow these steps:

Send documentation comments to n5kdocfeedback@cisco.com

Step 1 Configure the CFSoIP multicast address on each peer switch:

```
N5k-1# config terminal
N5k-1(config)# cfs ipv4 mcast-address 10.29.170.1
Distribution over this IP type will be affected
Change multicast address for CFS-IP?
Are you sure? (y/n) [n] y
```

```
N5k-2# config terminal
N5k-2(config)# cfs ipv4 mcast-address 10.29.170.1
Distribution over this IP type will be affected
Change multicast address for CFS-IP?
Are you sure? (y/n) [n] y
```

Step 2 Enable CFSoIP manually on each peer switch:

```
N5k-1(config)# cfs ipv4 distribute
```

```
N5k-2(config)# cfs ipv4 distribute
```



Note

CFSoIP is not supported on the switch virtual interface (SVI)/default VRF.

Step 3 Establish the peer connection over the mgmt0 transport interface:

```
N5k-1(config)# interface mgmt 0
N5k-1(config-if)# ip address 10.29.170.7/24
N5k-1(config-if)# vrf context management
N5k-1(config-vrf)# ip route 0.0.0.0/0 10.29.170.1
```

```
N5k-2(config)# interface mgmt 0
N5k-2(config-if)# ip address 10.29.170.8/24
N5k-2(config-if)# vrf context management
N5k-2(config-vrf)# ip route 0.0.0.0/0 10.29.170.1
```

Switch Profiles

Beginning with Cisco NX-OS Release 5.0(2)N1(1), config-sync mode allows you to create a switch profile. A switch profile contains a predefined configuration that you can use to configure a peer switch so that both peers have the same configuration. In config-sync mode, you define the peer and the configuration in the switch profile. Peers are identified by their IP address and they are local to each switch profile. Commands entered in config-sync mode are buffered until they are committed. Configuration changes made in configuration terminal mode apply only to the local switch.

You must create an identical switch profile on each peer switch in config-sync mode. This configuration is not automatically synchronized and you must configure it on each peer switch.

To create the switch profiles, enter the following commands:

```
N5k-1# config sync
N5k-1(config-sync)# switch-profile Test
N5k-1(config-sync)# sync-peers destination 10.29.170.8
```

```
N5k-2# config sync
N5k-2(config-sync)# switch-profile Test
N5k-2(config-sync)# sync-peers destination 10.29.170.7
```

[Send documentation comments to n5kdocfeedback@cisco.com](mailto:n5kdocfeedback@cisco.com)

**Note**

The switch profile name must be identical on both peers. You can create only one switch profile on each peer switch.

In Cisco NX-OS Release 5.0(2)N1(1), switch profiles do not support all commands. The config-sync mode commands are limited to vPC configurations.

Switch Profile Commands

The following configuration commands are supported in a switch profile:

- VLAN
- ACL
- Spanning-Tree Protocol (STP)
- Quality of Service (QoS)
- Interface configurations (Ethernet, port channel, or vPC interfaces)

The following commands are not supported in a switch profile:

- Enable feature sets (you must manually enable a specific feature before relevant configurations can be added)
- vPC domain
- vPC peer-keepalive
- FCoE

User-Based Access Controls

In Cisco NX-OS Release 5.0(2)N1(1), only the user who creates a switch profile can edit the switch profile even if another user has the same admin privileges. Beginning with Cisco NX-OS Release 5.0(2)N2(1), you can add, delete, or modify a switch profile configuration based on Role Based Access Control (RBAC) configurations. Users that have the appropriate privilege level to access the switch profile can successfully modify the switch profile and commit the configuration.

For more information on RBAC, see the *Cisco Nexus 5000 Series System Management Configuration Guide*.

As a network administrator, you can restrict a user from accessing a switch profile. When a restricted user has permission to access a switch profile, that user can successfully commit the switch profile on the initiating switch. However, issuing a particular command (for example, the **switchport mode access** command), fails or succeeds in a switch profile according to the RBAC policies and rules assigned to that user.

In addition, the same username and privilege level must exist for a successful commit on the peer switch. If the same username and privilege level does not exist on the peer switch, the commit fails. You must ensure that configuration synchronization peers have the same configured users and roles. Occasionally, the same username can exist but roles might be mismatched. Also, the same user on one peer switch could have a more restricted role on the other peer switch and in that case the commit might fail. You must configure usernames with matching roles on peer switches to avoid these problems. As a best practice, the user with the network administrator role should create the switch profile to reduce the risk of configurations failing to commit due to permission issues.

Send documentation comments to n5kdocfeedback@cisco.com

In vPC topologies, when one peer switch is running Cisco NX-OS Release 5.0(2)N1(1) and a second peer switch is running Cisco NX-OS Release 5.0(2)N2(1), a successful commit depends on which switch was used to issue the commit. On a switch running Cisco NX-OS Release Cisco NX-OS Release 5.0(2)N1(1), only the user who created the switch profile can issue the commit. On a switch running Cisco NX-OS Release 5.0(2)N2(1), users with appropriate privileges can issue the commit.

Verification Checks

To reduce the possibility of overriding switch profile configurations or configurations that are not part of a switch profile, two types of validation checks are performed:

- [Mutual Exclusion Check, page 1-7](#)
- [Merge Check, page 1-8](#)

Mutual Exclusion Check

The Mutual exclusion check identifies potential conflicts between a switch profile configuration and the global configurations (configurations that are not part of a switch profile). A command that is included in a switch profile cannot be configured outside of the switch profile. The same rules apply on the peer switch.

The mutual exclusion check is done locally and on the peer switch. When entering the **verify** or **commit** command, if the peer switch is reachable using the mgmt0 interface, the check is done on both the local switch and the peer switch. If the peer switch is not reachable, the check is only done on the local switch.

If the mutual exclusion check fails, you must manually correct the configuration and enter the **commit** command again.

The following commands are exceptions and they can exist inside and outside the switch profile without receiving a mutual exchange error:

- Interface configuration commands except port-channel interfaces
- Shutdown/no shut commands
- System Quality of Service (QoS) (**system qos** command) command

For implementations including port channels, consider the following guidelines to minimize mutual exchange errors:

- Port channels created in switch profile mode should not be configured using global configuration (config terminal) mode.
- If a port-channel is created in global configuration mode, channel groups including member interfaces must also be created using global configuration mode.
- Port-channels that are configured within switch profile mode may have members both inside and outside of a switch profile.
- If you want to import a member interface to a switch profile, the port-channel that corresponds with the member interface must also be present within the switch profile.

For more information on configuring port channels, see the *Cisco NX-OS Layer 2 Switching Configuration Guide*. For more information on configuring switch profiles, see the *Cisco NX-OS 5000 System Management Configuration Guide*.

[Send documentation comments to n5kdocfeedback@cisco.com](mailto:n5kdocfeedback@cisco.com)

Merge Check

A Merge check is done on the peer switch to ensure that the received configuration does not conflict with the switch profile configuration that already exists on the receiving switch. If a merge check failure occurs, you must manually correct the configuration and enter the **commit** command again.

Commit

Use the **commit** command to synchronize the configuration with the peer switch and to apply the configuration locally. Configurations are stored in the buffer until the **commit** command is issued. A commit can be executed by a vPC primary switch or a secondary switch. The initiator is the switch on which the **commit** command was issued. You can enter the **commit** command only on one switch at any given time. If a commit is attempted while another commit is in progress, it fails and the following syslog message appears:

```
Failed: Session Database already locked, Verify/Commit in Progress
```

As a best practice, you should assign one switch as the initiator, make all configurations on that switch, and then synchronize the configuration on the peer switch to simplify the process and reduce any possible confusion.

All configuration changes (including configuration terminal mode changes for all supported commands) are prevented when a switch profile session is in progress.



Note

If the peer switch is reachable and you enter the **commit** command, the configuration is applied locally and to its peer switch. If the commit is unsuccessful, the configuration is not applied on the local or remote switch (atomic behavior).

Commands are executed in the same order in which they are buffered. If there is an order dependency for certain commands (for example, QoS policy commands), the commands must be defined before they are applied. The order of commands can be edited in the buffer. If you are including commands that are part of a feature that requires the feature to be enabled, you must ensure that the feature is enabled and defined manually on each switch.



Note

The **feature** command is not synchronized between peers (for example, **feature vpc** or **feature lacp**).

When you enter the **commit** command, the CLI prompt may not return right away. The length of time it takes to apply the configuration may be longer if the size of the configuration is very large. This operation is normal and we recommend that you do not abort the commit (by pressing **Ctrl-c** or **Ctrl-z**) because it might leave the configuration in an inconsistent state.

Buffering

The switch profile configuration is stored in a buffer until the **commit** command is entered. You can add, delete, or move configurations in the buffer. Once the configuration has been pushed using the **commit** command, it is applied to the system configuration. Use the **show running** command to verify that the configuration has been applied. You can also use the **show running switch-profile** command to specifically check what configuration was synchronized using the switch profile.

Consider the following guidelines for the configuration that is stored in the buffer:

Send documentation comments to n5kdocfeedback@cisco.com

- Configurations are buffered until a successful commit.
- You can add, delete, or move configurations in the buffer.
- Commands are executed in the same order in which they are buffered. You can change the order inside the buffer by using the **buffer-delete** command or the **buffer-move** command.

Import

When you upgrade to Cisco NX-OS Release 5.0(2)N1(1), you have the option to enter the **import** command to copy supported running configuration commands to a switch profile. The **switch -profile import** command allows you to import the entire running configuration or you can choose specific interfaces to merge. Changes are not supported during the import process. If you add new commands in addition to the import configurations, the commit might fail. The commands remain in the buffer. You have the option to correct the buffer and enter the **commit** command again or abort the import mode. If you abort the import, the commands in the buffer are lost.

Configuration Synchronization Best Practices

Configuration synchronization is primarily used in vPC topologies. You should follow the best practice guidelines in this section to ensure a successful configuration synchronization.



Caution

You must follow the best practices for configuration synchronization described in this chapter for Cisco NX-OS Release 5.0(2)N1(1). Failure to do so might leave configurations in an inconsistent state.

In addition to configuration synchronization, Cisco NX-OS Release 5.0(2)N1(1) introduced three additional features:

- Pre provisioning—Allows you to configure offline GEM and FEX interfaces.
- Port profiles—Allows you to define consistent interface configurations that are applied to multiple ports.
 - Port profiles apply to ports and switch profiles apply to switch configurations; they are not the same.
 - Port profiles are not required for a configuration synchronization but they can be included in a configuration synchronization.
- Configuration Rollback—Allows you to create checkpoints of the running configuration and then perform a rollback to those checkpoints.

Use pre-provisioning, port profiles, and configuration rollbacks to enhance configuration synchronization and provide maximum benefits in a vPC topology. These features are included in the examples found in this chapter. See the *Cisco Nexus 5000 Series Configuration Guides* for additional information on these features.



Note

These features are independent of configuration synchronization; you do not need to enable them to use configuration synchronization.

Send documentation comments to n5kdocfeedback@cisco.com

Configuration Examples

This section describes the following configuration examples:

- [Configuring a vPC Topology Using Configuration Synchronization, page 1-10](#)
- [Active/Active FEX Topology Examples, page 1-12](#)
- [Straight-Through Topology Examples, page 1-19](#)
- [Reloading a Cisco Nexus 5000 Series Switch, page 1-26](#)
- [vPC Peer-Link Failures, page 1-28](#)
- [mgmt0 Interface Connectivity is Lost, page 1-31](#)
- [Rollback Failures with Conditional Features, page 1-31](#)

**Note**

The following examples are current as of Cisco NX-OS Release 5.0(2)N1(1).

Configuring a vPC Topology Using Configuration Synchronization

In [Figure 1-2](#), N5k-1 and N5k-2 are part of vPC Domain 10. The peer keepalive is configured over the mgmt0 interface and Ethernet 1/17-18 are bundled into P010 to form the peer link. Configuration synchronization maintains a consistent configuration on the peer switches and simplifies the switch administration in a vPC topology.

Figure 1-2 *vPC Topology*



[Example 1-1](#) shows the sample running configuration required for the vPC to become operational.

Send documentation comments to n5kdocfeedback@cisco.com

Example 1-1 Running Configuration of Peer Switches in a vPC Topology

vPC Configuration for N5k-1	vPC Configuration for N5k-2
vlan 1-10	vlan 1-10
feature vpc	feature vpc
vpc domain 10 peer-keepalive destination 10.29.170.8 peer-config-check-bypass	vpc domain 10 peer-keepalive destination 10.29.170.7 peer-config-check-bypass
interface port-channel10 switchport mode trunk vpc peer-link spanning-tree port type network	interface port-channel10 switchport mode trunk vpc peer-link spanning-tree port type network
interface Ethernet1/17 switchport mode trunk channel-group 10	interface Ethernet1/17 switchport mode trunk channel-group 10
interface Ethernet1/18 switchport mode trunk channel-group 10	interface Ethernet1/18 switchport mode trunk channel-group 10



Note

Peer-config-check-bypass is a best practice configuration for vPCs. For more information, see the *Cisco Nexus 5000 Series Design Guide* at the following URL:
http://www.cisco.com/en/US/prod/collateral/switches/ps9441/ps9670/C07-572829-01_Design_N5K_N2K_vPC_DG.pdf

To configure the vPC topology shown in [Figure 1-2](#), follow these steps:

- Step 1** Enable the vPC feature on the peer switches.
- ```
N5k-1# config terminal
N5k-1(config-vpc-domain)# feature vpc

N5k-2# config terminal
N5k-2(config-vpc-domain)# feature vpc
```
- Step 2** Configure the peer keepalive on both switches using the mgmt0 interface.
- ```
N5k-1(config)# vpc domain 10
N5k-1(config-vpc-domain)# peer-keepalive destination 10.29.170.8

N5k-2(config)# vpc domain 10
N5k-2(config-vpc-domain)# peer-keepalive destination 10.29.170.7
```
- Step 3** Configure the CFSoIP multicast address on each peer switch:
- ```
N5k-1(config)# cfs ipv4 mcast-address 10.29.170.1
Distribution over this IP type will be affected
Change multicast address for CFS-IP?
Are you sure? (y/n) [n] y

N5k-2(config)# cfs ipv4 mcast-address 10.29.170.1
Distribution over this IP type will be affected
Change multicast address for CFS-IP?
Are you sure? (y/n) [n] y
```

**Send documentation comments to [n5kdocfeedback@cisco.com](mailto:n5kdocfeedback@cisco.com)**

**Step 4** Enable CFSoIP on both switches.

```
N5k-1(config)# cfs ipv4 distribute
```

```
N5k-2(config)# cfs ipv4 distribute
```

**Step 5** Configure the switch profile with the same name on both switches.

```
N5k-1(config)# config sync
```

```
N5k-1(config-sync)# switch-profile Test
```

```
N5k-2(config)# config sync
```

```
N5k-2(config-sync)# switch-profile Test
```

**Step 6** Enter the **sync peer destination** command to configure both switches.

```
N5k-1# config sync
```

```
N5k-1(config-sync)# switch-profile Test
```

```
N5k-1(config-sync-sp)# sync-peers destination 10.29.170.8
```

```
N5k-2# config sync
```

```
N5k-2(config-sync)# switch-profile Test
```

```
N5k-2(config-sync-sp)# sync-peers destination 10.29.170.7
```

**Step 7** In switch-profile mode, create the port-channel interface for the peer link.

```
N5k-1(config-if)# config sync
```

```
N5k-1(config-sync)# switch-profile Test
```

```
N5k-1(config-sync-sp)# int po10
```

```
N5k-1(config-sync-sp-if)# exit
```

```
N5k-1(config-sync-sp)# commit
```

**Step 8** In interface mode, associate the port-channel member to PO 10.

```
N5k-1(config)# int ether 1/17-18
```

```
N5k-1(config-if)# channel-group 10
```

```
N5k-2(config)# int ether 1/17-18
```

```
N5k-2(config-if)# channel-group 10
```

**Step 9** In switch profile mode, add the appropriate configurations under the port-channel interface to form the peer link.

```
N5k-1(config-if)# config sync
```

```
N5k-1(config-sync)# switch-profile Test
```

```
Switch-Profile started, Profile ID is 1
```

```
N5k-1(config-sync-sp)# interface po10
```

```
N5k-1(config-sync-sp-if)# switchport mode trunk
```

```
N5k-1(config-sync-sp-if)# vpc peer-link
```

```
N5k-1(config-sync-sp-if)# commit
```

```
Verification successful...
```

```
Proceeding to apply configuration. This might take a while depending on amount of configuration in buffer.
```

```
Please avoid other configuration changes during this time.
```

```
Commit Successful
```

## Active/Active FEX Topology Examples

This section includes the following examples:


## ***Send documentation comments to [n5kdocfeedback@cisco.com](mailto:n5kdocfeedback@cisco.com)***

- [Dual-Homed FEX Topology \(Active/Active FEX Topology\)](#) , page 1-13
- [New Deployments in an Active/Active FEX Topology](#), page 1-14
- [Existing Deployment with an Active/Active FEX Topology](#), page 1-17

### **Dual-Homed FEX Topology (Active/Active FEX Topology)**

Figure 1-3 shows that each FEX is dual-homed with two Cisco Nexus 5000 Series switches. The FEX-fabric interfaces for each FEX are configured as a vPC on both peer switches. The host interfaces on the FEX appear on both peer switches. If these host interfaces are bundled in a port channel, you must configure the port channel identically on both peer switches. Configuration synchronization helps keep the FEX configuration synchronized between the pair of vPC peer switches.

**Figure 1-3** *Dual-Homed FEX Active/Active Topology*



In Figure 1-3, the vPC is already operational. FEX 100 is dual-homed to both parent switches: N5k-1 and N5k-2 on FEX-fabric interfaces Ethernet 1/1. Because the FEX is pre-provisioned, there is no existing running configuration on Ethernet 1/1.

**Note**

---

A port channel within the same FEX is supported on Cisco Nexus 2200 Series Fabric Extenders.

---

FEX 100 is configured to have two types of host interfaces. One interface is Ethernet100/1/1, which is singly attached to a server (nonport-channel member), and the other interface is Ethernet 100/1/2-3, which is configured in a port channel to the server (port-channel member).

Example 1-2 shows the sample running configuration for the peer switches. Two types of configurations are shown:

- Basic Configuration

**Send documentation comments to [n5kdocfeedback@cisco.com](mailto:n5kdocfeedback@cisco.com)**

- Port profile configuration.

You can use either option or you can use both configurations together.



**Note**

You can use port profiles to reduce operational overhead although they are not required.

**Example 1-2 Running Configuration of a FEX in an Active/Active Topology for the Peer Switches**

| Basic Configuration—No Port Profile                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | Port Profile Configuration                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <pre>vlan 1-10  interface port-channel100   switchport mode fex fabric   vpc 100   fex associate 100  interface port-channel 200   switchport mode trunk   switchport trunk allowed vlan 1-5  interface Ethernet1/1   fex associate 100   switchport mode fex fabric   channel-group 100  interface Ethernet100/1/1   switchport mode trunk   switchport trunk allowed vlan 1-10  interface Ethernet100/1/2   switchport mode trunk   switchport trunk allowed vlan 1-5   channel-group 200  interface Ethernet100/1/3   switchport mode trunk   switchport trunk allowed vlan 1-5   channel-group 200</pre> | <pre>vlan 1-10  port-profile type ethernet eth-profile   switchport mode trunk   state enabled  port-profile type port-channel pc-profile   switchport mode trunk   state enabled  interface port-channel100   switchport mode fex fabric   vpc 100   fex associate 100  interface port-channel 200   inherit port-profile pc-profile   switchport trunk allowed vlan 1-5  interface Ethernet1/1   fex associate 100   switchport mode fex fabric   channel-group 100  interface Ethernet100/1/1   inherit port-profile eth-profile   switchport trunk allowed vlan 1-10  interface Ethernet100/1/2   switchport mode trunk   switchport trunk allowed vlan 1-5   channel-group 200  interface Ethernet100/1/3   switchport mode trunk   switchport trunk allowed vlan 1-5   channel-group 200</pre> |

## New Deployments in an Active/Active FEX Topology

In a new deployment, configuration synchronization is introduced from the beginning to synchronize the configuration across peer switches. As a result, there is no existing running configuration on the FEX ports.

To configure the dual-homed FEX active/active topology shown in [Figure 1-3](#), follow these steps:

**Step 1** Configure the CFSolP multicast address on each peer switch:

```
N5k-1# config terminal
```

**Send documentation comments to [n5kdocfeedback@cisco.com](mailto:n5kdocfeedback@cisco.com)**

```
N5k-1(config)# cfs ipv4 mcast-address 10.29.170.1
Distribution over this IP type will be affected
Change multicast address for CFS-IP?
Are you sure? (y/n) [n] y
```

```
N5k-2# config terminal
N5k-2(config)# cfs ipv4 mcast-address 10.29.170.1
Distribution over this IP type will be affected
Change multicast address for CFS-IP?
Are you sure? (y/n) [n] y
```

**Step 2** Enable CFS-IP on both switches.

```
N5k-1(config)# cfs ipv4 distribute
```

```
N5k-2(config)# cfs ipv4 distribute
```

**Step 3** Create a switch profile on both switches.

```
N5k-1# config sync
N5k-1(config-sync)# switch-profile Test
N5k-1(config-sync-sp)# sync-peers destination <out of band mgmt0 IP address of peer switch
N5k-2>
```

```
N5k-2# config sync
N5k-2(config-sync)# switch-profile Test
N5k-2(config-sync-sp)# sync-peers destination <out of band mgmt0 IP address of peer switch
N5k-1>
```

**Step 4** Pre-provision the FEX.

**Note**

In a FEX active/active topology, always pre-provision the FEXs that are dual-homed inside the switch profile. This process helps configuration synchronization when the FEX is not connected to a Cisco Nexus 5000 Series switch.

```
N5k-1(config-sync-sp)# slot 100
N5k-1(config-sync-sp-slot)# provision model N2k-C2232P
N5k-1(config-sync-sp-slot)# exit

N5k-1(config-sync-sp-if)# sh switch-profile buffer

switch-profile : Test

Seq-no Command

1 slot 100
1.1 provision model N2K-C2232P
```

**Step 5** Add referred global configuration to the switch profile.

**Note**

Because interface configurations will be synchronized, all policies that are applied on the interface must be synchronized (for example, port profiles, QoS, and ACL policies).

```
N5k-1(config-sync-sp)# port-profile type ethernet eth-profile
N5k-1(config-sync-port-prof)# switchport mode trunk
N5k-1(config-sync-port-prof)# state enabled
```

```
N5k-1(config-sync-sp)# port-profile type port-channel pc-profile
N5k-1(config-sync-port-prof)# switchport mode trunk
```

**Send documentation comments to [n5kdocfeedback@cisco.com](mailto:n5kdocfeedback@cisco.com)**

```
N5k-1(config-sync-port-prof)# state enabled
```

**Step 6** Configure the Ethernet interfaces (the non-port-channel members) inside the switch profile.

```
N5k-1(config-sync-sp)# interface Ethernet100/1/1
N5k-1(config-sync-sp-if)# inherit port-profile eth-profile
N5k-1(config-sync-sp-if)# switchport trunk allowed vlan 1-10
```

**Step 7** Create the port-channel interface inside the switch profile.

**Note**


---

You must configure port-channel interfaces in the switch profile, not in configuration terminal mode.

---

This example shows that port channel 100 (vPC 100) is the EtherChannel from N5k to N2k:

```
N5k-1(config-sync-sp)# interface Port-channel100
```

This example shows that port channel 200 is the EtherChannel from N2k to the end device:

```
N5k-1(config-sync-sp)# interface Port-channel200
```

**Step 8** Commit the configuration inside the switch profile.

```
N5k-1(config-sync-sp)# commit
```

**Step 9** Add members to the port channel in configuration terminal mode on both switches.

**Note**


---

The configuration must be done on both switches in configuration terminal mode.

---

This example shows that N5k-1- Ethernet1/1 is a FEX-fabric member of port channel 100:

```
N5k-1(config)# int ether1/1
N5k-1(config-if)# channel-group 100 force
```

This example shows that N5k-1- Ethernet1/100/2-3 are members of port channel 200:

```
N5k-1(config)# interface Ethernet100/1/2-3
N5k-1(config-if-range)# channel-group 200 force
```

This example shows that N5k-2- Ethernet1/1 is a FEX-fabric interface that is in port channel 100:

```
N5k-2(config)# int ether1/1
N5k-2(config-if)# channel-group 100 force
```

This example shows that N5k-2- Ethernet1/100/2-3 are members of port channel 200:

```
N5k-2(config)# interface Ethernet100/1/2-3
N5k-2(config-if-range)# channel-group 200 force
```

**Note**


---

In Cisco NX-OS Release 5.0(2)N2(1), if you do not use the **channel-group 200 force** command on the Ethernet interfaces, a problem will occur on pre-provisioned interfaces that are offline. In this example, if module 100 is offline, the configuration on PO 200 in [Step 9](#) must be specifically configured on each member interface, in addition to the **channel-group** command. The **channel-group 200 force** command is not supported in Cisco NX-OS Release 5.0(2)N1(1) and earlier releases.

---

```
N5k-1(config)# interface Ethernet100/1/2-3
N5k-1(config-if-range)# switchport mode trunk
N5k-1(config-if-range)# switchport trunk allowed vlan 1-5
```

```
N5k-2(config)# interface Ethernet100/1/2-3
```



## Send documentation comments to [n5kdocfeedback@cisco.com](mailto:n5kdocfeedback@cisco.com)

```
N5k-2(config-if-range)# switchport mode trunk
N5k-2(config-if-range)# switchport trunk allowed vlan 1-5
```

**Step 10** Modify the port-channel configuration in the switch profile.

```
N5k-1(config-sync-sp-if)# interface Port-Channel100
N5k-1(config-sync-sp-if)# switchport mode fex-fabric
N5k-1(config-sync-sp-if)# fex associate 100
N5k-1(config-sync-sp-if)# vpc 100

N5k-1(config-sync-sp)# interface Port-channel200
N5k-1(config-sync-sp-if)# inherit port-profile pc-profile
N5k-1(config-sync-sp-if)# switchport trunk allowed vlan 1-5
```

**Step 11** Commit the configuration in the switch profile.

```
N5k-1(config-sync-sp)# commit
```

## Existing Deployment with an Active/Active FEX Topology

In an existing deployment, the configurations are already present and configuration synchronization is used to simplify future configuration modifications.

To configure peer switches in the vPC topology shown in [Figure 1-3](#), follow these steps:

**Step 1** Configure the CFS-IP multicast address on each peer switch:

```
N5k-1# config terminal
N5k-1(config)# cfs ipv4 mcast-address 10.29.170.1
Distribution over this IP type will be affected
Change multicast address for CFS-IP?
Are you sure? (y/n) [n] y

N5k-2# config terminal
N5k-2(config)# cfs ipv4 mcast-address 10.29.170.1
Distribution over this IP type will be affected
Change multicast address for CFS-IP?
Are you sure? (y/n) [n] y
```

**Step 2** Enable CFS-IP on both switches.

```
N5k-1(config)# cfs ipv4 distribute

N5k-2(config)# cfs ipv4 distribute
```

**Step 3** Create a switch profile on both switches.

```
N5k-1# config sync
N5k-1(config-sync)# switch-profile Test

N5k-2# config sync
N5k-2(config-sync)# switch-profile Test
```

**Step 4** Pre-provision the FEX on both switches.



### Note

In a FEX active/active topology, always pre-provision the FEXs that are dual-homed inside the switch profile.

## Send documentation comments to [n5kdocfeedback@cisco.com](mailto:n5kdocfeedback@cisco.com)

```
N5k-1(config-sync-sp)# slot 100
N5k-1(config-sync-sp-slot)# provision model N2k-C2232P
N5k-1(config-sync-sp-slot)# exit
```

```
N5k-2(config-sync-sp)# slot 100
N5k-2(config-sync-sp-slot)# provision model N2k-C2232P
N5k-2(config-sync-sp-slot)# exit
```

**Step 5** Commit the configuration in the switch profile on both switches.

```
N5k-1(config-sync-sp)# commit
```

```
N5k-2(config-sync-sp)# commit
```

**Step 6** Import the running configuration.

```
N5k-1(config-sync-sp)# import running-config
N5k-1(config-sync-sp-import)# show switch-profile Test buffer
```

Import the configuration to the switch profile on both switches. You can import the configuration using one of the following three methods:

- **Running configuration**—All configurations that are allowed inside a switch profile are imported. You must remove unwanted configurations. For example, you must remove port-channel member configurations if the member interfaces do not match on the peer switches.
- **Interface configuration**—Only specified interface configurations are imported.
- **Manual mode**—Selected configurations are imported. If the configuration that needs to be imported is small, use the manual mode to paste the desired configuration.

Table 1-1 shows the command sequence to import the running configuration:

**Table 1-1** Command Sequence to Import the Running Configuration

| Sequence Number | Command                            |
|-----------------|------------------------------------|
| 1               | vlan 1-10                          |
| 2               | interface port-channel100          |
| 2.1             | switchport mode fex-fabric         |
| 2.2             | vpc 100                            |
| 2.3             | fex associate 100                  |
| 3               | interface port-channel200          |
| 3.1             | switchport mode trunk              |
| 3.2             | switchport trunk allowed vlan 1-5  |
| 4               | interface Ethernet1/1              |
| 4.1             | fex associate 100                  |
| 4.2             | switchport mode fex-fabric         |
| 4.3             | channel-group 100                  |
| 5               | interface Ethernet100/1/1          |
| 5.1             | switchport mode trunk              |
| 5.2             | switchport trunk allowed vlan 1-10 |
| 6               | interface Ethernet100/1/2          |
| 6.1             | switchport mode trunk              |
| 6.2             | switchport trunk allowed vlan 1-5  |
| 6.3             | channel-group 200                  |
| 7               | interface Ethernet100/1/3          |
| 7.1             | switchport mode trunk              |
| 7.2             | switchport trunk allowed vlan 1-5  |
| 7.3             | channel-group 200                  |

## Send documentation comments to [n5kdocfeedback@cisco.com](mailto:n5kdocfeedback@cisco.com)

**Step 7** Remove member interfaces of PO 100 and PO 200 from the buffer.

```
N5k-1(config-sync-sp-import)# buffer-delete 4, 6, 7
```

Use the **buffer-delete** command to delete the unwanted configuration from the buffer.

**Step 8** Commit the configuration in the switch profile on both switches.

```
N5k-1(config-sync-sp-import)# commit
```

```
N5k-2(config-sync-sp-import)# commit
```

**Step 9** Add the sync peer on both switches.



### Note

When importing the configuration, you must use the **sync-peers** command after the configurations are imported independently on both switches.

```
N5k-1# config sync
```

```
N5k-1(config-sync)# switch-profile sp
```

```
N5k-1(config-sync-sp)# sync-peers destination <out of band mgmt0 IP address of peer switch
N5k-2>
```

```
N5k-2# config sync
```

```
N5k-2(config-sync)# switch-profile sp
```

```
N5k-2(config-sync-sp)# sync-peers destination <out of band mgmt0 IP address of peer switch
N5k-1>
```



### Caution

When you remove a switch profile using the **no switch-profile name [all-config | local-config]** command, the configuration in the switch profile is immediately removed from the running configuration. This disrupts the configurations that were present in the switch profile, for example port channel and vPC configurations. For current information about this issue, refer to CSCt187240 and CSCt187260 in the *Cisco Nexus 5000 Series Switch and Cisco Nexus 2000 Series Fabric Extender Release Notes* and in the Cisco Bug Toolkit located at the following URL: <http://tools.cisco.com/Support/BugToolKit/action.do?hdnAction=searchBugs>.

## Straight-Through Topology Examples

This section includes the following examples:

- [Switch vPC Topology and Straight-Through FEX Topologies \(Host vPC\), page 1-19](#)
- [New Deployment in a vPC Topology and Straight-Through FEX Topology, page 1-21](#)
- [Existing Deployments in a vPC Topology and Straight-Through FEX Topology, page 1-24](#)

### Switch vPC Topology and Straight-Through FEX Topologies (Host vPC)

In [Figure 1-4](#), the Cisco Nexus 5000 Series switch ports are directly connected to another switch or host and are configured as part of a port channel that becomes part of a vPC.

[Figure 1-4](#) shows that vPC 20 is configured on port channel 20, which has Eth1/10 on N5k-1 and Eth2/1 on N5k-2 as members.

***Send documentation comments to [n5kdocfeedback@cisco.com](mailto:n5kdocfeedback@cisco.com)***

**Figure 1-4**      **Switch vPC Topology**



In [Figure 1-5](#), each FEX is single-homed (straight-through FEX topology) with a Cisco Nexus 5000 Series switch. The host interfaces on this FEX are configured as port channels and those port channels are configured as vPCs.

Eth100/1/1 on N5k-1 and Eth102/1/5 on N5k-2 are configured as members of PO200 and PO200 is configured for vPC 200.

**Figure 1-5**      **FEX Straight-Through Topology (Host vPC)**



In both topologies, port channels P020 and P0200 must be configured identically on the peer switches and configuration synchronization is used to synchronize the configurations of the vPC switches.

## Send documentation comments to [n5kdocfeedback@cisco.com](mailto:n5kdocfeedback@cisco.com)

Example 1-3 shows the sample running configuration that must be configured for the peer switches shown in the vPC topologies in Figure 1-4 and Figure 1-5.

### Example 1-3 Running Configuration Example for the Nexus 5000 Series Switches in a vPC Straight-Through Topology.

| Basic Configuration—No Port Profile                                                                                                                                                                                                                                                                                                                                                                                                      | Port Profile Configuration                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <pre>vlan 1-10  interface port-channel 20   switchport mode trunk   vpc 20   switchport trunk allowed vlan 1-5  interface port-channel 200   switchport mode trunk   vpc 200   switchport trunk allowed vlan 1-5  interface Ethernet1/10   switchport mode trunk   switchport trunk allowed vlan 1-5   channel-group 20  interface Ethernet100/1/1   switchport mode trunk   switchport trunk allowed vlan 1-5   channel-group 200</pre> | <pre>vlan 1-10  port-profile type port-channel pc-profile   switchport mode trunk   state enabled  interface port-channel 20   inherit port-profile pc-profile   vpc 20   switchport trunk allowed vlan 1-5  interface port-channel 200   inherit port-profile pc-profile   vpc 200   switchport trunk allowed vlan 1-5  interface Ethernet1/10   switchport mode trunk   switchport trunk allowed vlan 1-5   channel-group 20  interface Ethernet100/1/1   switchport mode trunk   switchport trunk allowed vlan 1-5   channel-group 200</pre> |

## New Deployment in a vPC Topology and Straight-Through FEX Topology

In a new deployment, configuration synchronization is introduced initially to synchronize the new configuration. Because it is a new deployment, there is no existing running configuration on the FEX ports.



### Note

In a straight-through FEX topology, you must use configuration terminal mode to pre-provision FEXs or GEMs.

To configure the peer switches in the topologies shown in Figure 1-4 and Figure 1-5, follow these steps:

### Step 1 Pre-provision the FEX configuration in configuration terminal mode for both switches as follows:

Provision the N5k-1- slot 100 for FEX 100.

```
N5k-1# config terminal
N5k-1(config)# slot 100
N5k-1(config-slot)# provision model N2K-C2232P
N5k-1(config)# int ether 1/1-2
N5k-1(config-if-range)# channel-group 100
N5k-1(config-if-range)# int po100
N5k-1(config-if)# fex associate 100
N5k-1(config-if)# switchport mode fex-fabric
```

**Send documentation comments to [n5kdocfeedback@cisco.com](mailto:n5kdocfeedback@cisco.com)**

Provision the N5k-2- slot 102 for FEX 102.

```
N5k-2# config terminal
N5k-2(config)# slot 102
N5k-2(config-slot)# provision model N2K-C2232P
N5k-2(config)# int ether 1/1-2
N5k-2(config-if-range)# channel-group 102
N5k-2(config-if-range)# int po102
N5k-2(config-if)# fex associate 102
N5k-2(config-if)# switchport mode fex-fabric
```

Provision the N5k-2- slot 2 for a GEM.

```
N5k-2(config)# slot 2
N5k-2(config-slot)# provision model N55-M16P
```

**Step 2** Configure the CFSolP multicast address on each peer switch:

```
N5k-1(config)# cfs ipv4 mcast-address 10.29.170.1
Distribution over this IP type will be affected
Change multicast address for CFS-IP?
Are you sure? (y/n) [n] y
```

```
N5k-2(config)# cfs ipv4 mcast-address 10.29.170.1
Distribution over this IP type will be affected
Change multicast address for CFS-IP?
Are you sure? (y/n) [n] y
```

**Step 3** Enable CFSolP on both switches.

```
N5k-1(config)# cfs ipv4 distribute
```

```
N5k-2(config)# cfs ipv4 distribute
```

**Step 4** Create a switch profile and configure the peer on both switches.

```
N5k-1# config sync
N5k-1(config-sync)# switch-profile Test
N5k-1(config-sync-sp)# sync-peers destination <out of band mgmt0 IP address of peer switch N5k-2>
```

```
N5k-2# config sync
N5k-2(config-sync)# switch-profile Test
N5k-2(config-sync-sp)# sync-peers destination <out of band mgmt0 IP address of peer switch N5k-1>
```

**Step 5** Add the referred global configuration to the switch profile. Because the configuration on the interfaces will be synchronized, all policies that are applied on the interface must be synchronized (for example, port profiles, QoS and ACL policies).

```
N5k-1(config-sync-sp)# port-profile type port-channel pc-profile
N5k-1(config-sync-port-prof)# switchport mode trunk
N5k-1(config-sync-port-prof)# state enabled
```

**Step 6** Create port-channel interfaces inside the switch profile.



**Note** Use switch profile mode to create the port-channel interfaces.

```
N5k-1(config-sync-sp)# interface port-channel 20
N5k-1(config-sync-sp)# interface port-channel 200
```

**Step 7** Commit the configuration in the switch profile.

**Send documentation comments to [n5kdocfeedback@cisco.com](mailto:n5kdocfeedback@cisco.com)**

```
N5k-1(config-sync-sp)# commit
```

- Step 8** Add members to the port channel in configuration terminal mode on both switches. When the configuration is done in configuration terminal mode, both switches must be configured independently.

**Note**

In this topology, port-channel members must not be identical on the peer switches. For Cisco NX-OS Release 5.0(2)N1(1), port-channel members should only be configured in configuration terminal mode, not in the switch profile.

```
N5k-1(config)# interface Ethernet1/10
N5k-1(config-if)# channel-group 20 force
N5k-1(config)# interface Ethernet100/1/1
N5k-1(config-if)# channel-group 200 force
```

```
N5k-2(config)# interface Ethernet2/1
N5k-2(config-if)# channel-group 20 force
N5k-2(config)# interface Ethernet102/1/5
N5k-2(config-if)# channel-group 200 force
```

**Note**

In Cisco NX-OS Release 5.0(2)N2(1), if you do not use the **channel-group 200 force** command on the Ethernet interfaces, a problem will occur on pre-provisioned interfaces that are offline. In this example, if module 100 is offline, the configuration on P0200 in [Step 8](#) must be configured on the member interfaces. The **channel-group 200 force** command is not supported in Cisco NX-OS Release 5.0(2)N1(1) and earlier releases.

```
N5k-1(config)# interface Ethernet100/1/1
N5k-1(config-if)# switchport mode trunk
N5k-1(config-if)# switchport trunk allowed vlan 1-5
```

```
N5k-2(config)# interface Ethernet2/1
N5k-2(config-if)# switchport mode trunk
N5k-2(config-if)# switchport trunk allowed vlan 1-5
```

```
N5k-2(config)# interface Ethernet102/1/5
N5k-2(config-if)# switchport mode trunk
N5k-2(config-if)# switchport trunk allowed vlan 1-5
```

**Note**

Ethernet 1/10 is not included in the list because it is not pre-provisioned (it is an offline interface).

- Step 9** Modify the port-channel configuration in the switch profile.

```
N5k-1(config-sync-sp)# interface port-channel 20
N5k-1(config-sync-sp-if)# inherit port-profile pc-profile
N5k-1(config-sync-sp-if)# vpc 20
N5k-1(config-sync-sp-if)# switchport trunk allowed vlan 1-5
N5k-1(config-sync-sp)# interface port-channel 200
N5k-1(config-sync-sp-if)# inherit port-profile pc-profile
N5k-1(config-sync-sp-if)# vpc 200
N5k-1(config-sync-sp-if)# switchport trunk allowed vlan 1-5
```

- Step 10** Commit the configuration in the switch profile.

```
N5k-1(config-sync-sp)# commit
```

***Send documentation comments to [n5kdocfeedback@cisco.com](mailto:n5kdocfeedback@cisco.com)***

## Existing Deployments in a vPC Topology and Straight-Through FEX Topology

In an existing deployment, the configurations are already present and configuration synchronization is used to simplify future configuration modifications.



### Note

In a straight-through FEX topology, use configuration terminal mode to pre-provision FEXs and GEMs.

To configure the peer switches in the topologies shown in [Figure 1-4](#) and [Figure 1-5](#), follow these steps:

**Step 1** Pre-provision the FEXs in configuration terminal mode on both switches.

```
N5k-1(config)# slot 100
```

```
N5k-2(config)# slot 102
```

**Step 2** Configure the CFSOIP multicast address on each peer switch:

```
N5k-1# config terminal
N5k-1(config)# cfs ipv4 mcast-address 10.29.170.1
Distribution over this IP type will be affected
Change multicast address for CFS-IP?
Are you sure? (y/n) [n] y
```

```
N5k-2# config terminal
N5k-2(config)# cfs ipv4 mcast-address 10.29.170.1
Distribution over this IP type will be affected
Change multicast address for CFS-IP?
Are you sure? (y/n) [n] y
```

**Step 3** Enable CFSOIP on both switches.

```
N5k-1(config)# cfs ipv4 distribute
```

```
N5k-2(config)# cfs ipv4 distribute
```

**Step 4** Create a switch profile on both switches.

```
N5k-1# config sync
N5k-1(config-sync)# switch-profile Test
```

```
N5k-2# config sync
N5k-2(config-sync)# switch-profile Test
```

**Step 5** Import the running configuration.

```
N5k-1(config-sync-sp)# import running-config
N5k-1(config-sync-sp-import)# show switch-profile Test buffer
```

Import the configuration to the switch profile on both switches. You can import the configuration using one of the following three methods:

- **Running configuration**—All configurations that are allowed inside a switch profile are imported. You must remove unwanted configurations. For example, you must remove port-channel member configurations.
- **Interface configuration**—Only specified interface configurations are imported.
- **Manual mode**—Selected configurations are imported. If the configuration that needs to be imported is small, use the manual mode to paste the desired configuration.

[Table 1-2](#) shows the command sequence to import the running configuration for Step 4:



***Send documentation comments to [n5kdocfeedback@cisco.com](mailto:n5kdocfeedback@cisco.com)***

**Table 1-2 Command Sequence to Import the Running Configuration (Step 4)**

| Sequence Number | Command                           |
|-----------------|-----------------------------------|
| 1               | vlan 1-10                         |
| 2               | interface port-channel20          |
| 2.1             | switchport mode trunk             |
| 2.2             | vpc 20                            |
| 2.3             | switchport trunk allowed vlan 1-5 |
| 3               | interface port-channel100         |
| 3.1             | switchport mode fex-fabric        |
| 3.2             | fex associate 100                 |
| 3               | interface port-channel200         |
| 3.1             | switchport mode trunk             |
| 3.2             | vpc 200                           |
|                 | switchport trunk allowed vlan 1-5 |
| 4               | interface port-channel20          |
| 4.1             | switchport mode trunk             |
| 4.2             | vpc 20                            |
| 4.3             | switchport trunk allowed vlan 1-5 |
| 5               | interface Ethernet1/1             |
| 5.1             | fex associate 100                 |
| 5.2             | switchport mode fex-fabric        |
| 5.3             | channel-group 100                 |
| 6               | interface Ethernet1/2             |
| 6.1             | fex associate 100                 |
| 6.2             | switchport mode fex-fabric        |
| 6.3             | channel-group 100                 |
| 7               | interface Ethernet1/10            |
| 7.1             | switchport mode trunk             |
| 7.2             | switchport trunk allowed vlan 1-5 |
| 7.3             | channel-group 20                  |
| 8               | interface Ethernet100/1/1         |
| 8.1             | switchport mode trunk             |
| 8.2             | switchport trunk allowed vlan 1-5 |
| 8.3             | channel-group 200                 |

```
N5k-2(config-sync-sp)# import running-config
```

**Step 6** (Optional) If you do not want to synchronize the fabric configuration, remove the fabric configuration and the member interfaces of PO 20 and PO 200 from the buffer.

```
N5k-1(config-sync-sp-import)# buffer-delete 3,5,6-8
```

The **buffer-delete** command deletes the unwanted configuration from the buffer.

**Step 7** Commit the configuration in the switch profile on both switches.

```
N5k-1(config-sync-sp-import)# commit
```

```
N5k-2(config-sync-sp-import)# commit
```

**Step 8** Add the sync peer on both switches.



**Note**

When importing a configuration, use the **sync-peers** command after you import configurations on both switches independently.

## Send documentation comments to [n5kdocfeedback@cisco.com](mailto:n5kdocfeedback@cisco.com)

```
N5k-1# config sync
N5k-1(config-sync)# switch-profile Test
N5k-1(config-sync-sp)# sync-peers destination <out of band mgmt0 IP address of peer switch
N5k-2>

N5k-2# config sync
N5k-2(config-sync)# switch-profile Test
N5k-2(config-sync-sp)# sync-peers destination <out of band mgmt0 IP address of peer switch
N5k-1>
```



### Caution

When you remove a switch profile using the **no switch-profile name [all-config | local-config]** command, the configuration in the switch profile is immediately removed from the running configuration. This disrupts the configurations that were present in the switch profile, for example port channel and vPC configurations. For current information about this issue, refer to CSCt187240 and CSCt187260 in the *Cisco Nexus 5000 Series Switch and Cisco Nexus 2000 Series Fabric Extender Release Notes* and in the Cisco Bug Toolkit located at the following URL: <http://tools.cisco.com/Support/BugToolKit/action.do?hdnAction=searchBugs>.

## Reloading a Cisco Nexus 5000 Series Switch

In this deployment, the N5k-2 switch reboots and a new configuration was committed on N5k-1 using a switch profile.

[Example 1-4](#) shows the configuration that was synchronized between the peers prior to the N5k-2 reload.

### Example 1-4 Synchronized Configuration for Peer Switches Prior to the N5k-2 Reload

| N5k-1 Running Configuration                         | N5k-2 Running Configuration                         |
|-----------------------------------------------------|-----------------------------------------------------|
| interface Ethernet100/1/11<br>switchport mode trunk | interface Ethernet100/1/11<br>switchport mode trunk |

This example shows the configuration change that was made on the N5k-1 during the N5k-2 reload:



### Note

If the peer is unreachable once the commit is issued (for example, on the N5k-1 switch), the configuration is applied locally.

```
N5k-1(config-sync)# switch-profile Test
Switch-Profile started, Profile ID is 1
N5k-1(config-sync-sp)# int ether 100/1/11
N5k-1(config-sync-sp-if)# switchport trunk allowed vlan 5,6
N5k-1(config-sync-sp)# commit
```

```
Verification successful...
Proceeding to apply configuration. This might take a while depending on
amount of configuration in buffer.
Please avoid other configuration changes during this time.
Commit Successful
```

```
N5k-1(config-sync)# show run int ether 100/1/11

interface Ethernet100/1/11
```

## Send documentation comments to [n5kdocfeedback@cisco.com](mailto:n5kdocfeedback@cisco.com)

```
switchport mode trunk
switchport trunk allowed vlan 5-6
```

This example shows how to display the vPC consistency parameters:

```
N5k-1(config-sync)# switch-profile Test
Switch-Profile started, Profile ID is 1
N5k-1(config-sync-sp)# int ether 100/1/11
N5k-1# show vpc consistency-parameters int ether 100/1/11
```

Legend:

Type 1 : vPC will be suspended in case of mismatch

| Name                  | Type | Local Value | Peer Value       |
|-----------------------|------|-------------|------------------|
| -----                 | ---- | -----       | -----            |
| Allowed VLANs         | -    | 5-6         | 1-3967,4048-4093 |
| Local suspended VLANs | -    | -           | -                |

## Synchronizing the Peer Switches After a Switch Reload

To synchronize the configurations on the peer switches after one of the peer switches reloads, follow these steps:

**Step 1** Reapply the configurations that were changed on N5k-1.

```
N5k-2(config-sync)# switch-profile Test
N5k-2(config-sync-sp)# interface ethernet100/1/11
N5k-2(config-sync-sp-if)# switchport trunk all vlan 5-6
```

**Step 2** Enter the **commit** command on N5k-2.

```
N5k-2(config-sync)# switch-profile Test
N5k-2(config-sync-sp)# commit
Verification successful...
Proceeding to apply configuration. This might take a while depending on
amount of configuration in buffer.
Please avoid other configuration changes during this time.
Commit Successful
```

**Step 3** Verify that the configuration is applied correctly and is synchronized on the peers.

```
N5k-2# show vpc consistency-parameters int ether 100/1/11
Legend:
```

Type 1 : vPC will be suspended in case of mismatch

| Name                  | Type | Local Value | Peer Value |
|-----------------------|------|-------------|------------|
| -----                 | ---- | -----       | -----      |
| Allowed VLANs         | -    | 5-6         | 5-6        |
| Local suspended VLANs | -    | -           | -          |

```
N5k-2# show run int ether 100/1/11
```

```
!Command: show running-config interface Ethernet100/1/11
```

```
interface Ethernet100/1/11
switchport mode trunk
switchport trunk allowed vlan 5-6
```

***Send documentation comments to [n5kdocfeedback@cisco.com](mailto:n5kdocfeedback@cisco.com)***



**Note**

All configurations are applied serially in a best-effort fashion when the FEX comes online.

## vPC Peer-Link Failures

When there is a peer-link failure and both switches are operational, the secondary switch shuts down its vPC ports. In a FEX active/active topology, this situation disconnects the active/active FEX on the secondary switch. If the switch profile configuration is changed on the primary switch, the configuration will not be accepted on the secondary switch unless the active/active FEX is pre-provisioned. We recommend that you pre-provision all active/active FEXs when using configuration synchronization.



**Note**

Even if the FEXs have been originally configured in configuration terminal mode and they are operational, you should provision the FEXs in the switch profile to qualify as a provisioned FEX.

In this topology, FEX 100 is provisioned and FEX 101 is not provisioned, and both FEX 100 and 101 are already operational.

[Example 1-5](#) shows the sample running configuration that is present for FEX 100 (which is in an operational state).

### **Example 1-5 Running Configuration for FEX 100**

#### **Running Configuration for FEX 100**

```
fex 100
 pinning max-links 1
 description "FEX0101"

interface port-channel200
 switchport mode fex-fabric
 vpc 200
 fex associate 100

interface Ethernet1/10
 description connects to Fex 100
 fex associate 100
 switchport mode fex-fabric
 channel-group 200
```

The next step is to provision FEX 100 inside the switch profile.

[Example 1-6](#) shows the running configuration when FEX 100 is provisioned.

**Send documentation comments to [n5kdocfeedback@cisco.com](mailto:n5kdocfeedback@cisco.com)****Example 1-6 Running Configuration for FEX 100 Provisioned****Running Configuration for FEX 100 with Provisioning**

```

fex 100
 pinning max-links 1
 description "FEX0101"

slot 100
 provision model N2K-C2148T

interface port-channel200
 switchport mode fex-fabric
 vpc 200
 fex associate 100

interface Ethernet1/10
 description connects to Fex 100
 fex associate 100
 switchport mode fex-fabric
channel-group 200

```

**Working Example**

This example shows how to provision the FEX:

```

N5k-1(config-sync-sp)# slot 100
N5k-1(config-sync-sp-slot)# provision model N2K-C2148T
N5k-1(config-sync-sp-slot)# exit
N5k-1(config-sync-sp)#
N5k-1(config-sync-sp)# commit

```

This example shows that the vPC peer link fails:

```

N5k-1(config-sync-sp)# sh vpc

```

Legend:

(\*) - local vPC is down, forwarding via vPC peer-link

```

vPC domain id : 10
Peer status : peer link is down
vPC keepalive status : peer is alive

```

This examples shows that in the switch profile, a configuration is added under Ethernet 100/1/1:

```

N5k-1(config-sync)# switch-profile Test
Switch-Profile started, Profile ID is 1
N5k-1(config-sync-sp)# int ether 100/1/1
N5k-1(config-sync-sp-if)# switchport mode trunk
N5k-1(config-sync-sp-if)# commit
Verification successful...
Proceeding to apply configuration. This might take a while depending on
amount of configuration in buffer.
Please avoid other configuration changes during this time.
Commit Successful

```

This example shows how to verify that both switches are synchronized:

```

N5k-1(config-if)# sh run int ether 100/1/1
interface Ethernet100/1/1
 switchport mode trunk

N5k-2(config-if)# sh run int ether 100/1/1
interface Ethernet100/1/1
 switchport mode trunk

```

***Send documentation comments to [n5kdocfeedback@cisco.com](mailto:n5kdocfeedback@cisco.com)***

### Nonworking Example

[Example 1-7](#) shows the running configuration for FEX 101 that is not provisioned inside the switch profile.

#### **Example 1-7 Running Configuration for FEX 101**

---

##### **Running Configuration for FEX 101**

---

```
fex 101
 pinning max-links 1
 description "FEX0101"

interface port-channel201
 switchport mode fex-fabric
 vpc 201
 fex associate 101

interface Ethernet1/11
 description connects to Fex 101
 fex associate 101
 switchport mode fex-fabric
 channel-group 201
```

---

This example shows that the vPC peer link fails:

```
N5k-1(config-sync-sp)# show vpc
```

Legend:

(\*) - local vPC is down, forwarding via vPC peer-link

```
vPC domain id : 10
Peer status : peer link is down
vPC keepalive status : peer is alive
```

This example shows that configuration changes made on N5k-1 for Ethernet 101/1/1 fail because FEX 101 is not provisioned inside the switch profile:

```
N5k-1(config-sync)# switch-profile Test
Switch-Profile started, Profile ID is 1
N5k-1(config-sync-sp)# int ethernet 101/1/1
N5k-1(config-sync-sp-if)# switchport mode trunk
N5k-1(config-sync-sp-if)# commit
Verification successful...
Failed to Commit: Commit Failed
```

This example shows how to correct the issue by provisioning FEX 101 inside the switch profile. If FEX 101 is not provisioned inside the switch profile, the configuration changes must be done manually on both switches:

```
N5k-1(config-sync)# switch-profile Test
Switch-Profile started, Profile ID is 1
N5k-1(config-sync-sp)# slot 101
N5k-1(config-sync-sp-slot)# provision model N2K-C2148T
N5k-1(config-sync-sp-slot)# commit
```

This example shows how to make the same configuration change again:

```
N5k-1(config-sync)# switch-profile Test
Switch-Profile started, Profile ID is 1
N5k-1(config-sync-sp)# int ether 101/1/1
```

## Send documentation comments to [n5kdocfeedback@cisco.com](mailto:n5kdocfeedback@cisco.com)

```
N5k-1(config-sync-sp-if)# switchport mode trunk
N5k-1(config-sync-sp-if)# commit

Verification successful...
Proceeding to apply configuration. This might take a while depending on
amount of configuration in buffer.
Please avoid other configuration changes during this time.
Commit Successful

!Command: show running-config interface Ethernet101/1/1

interface Ethernet101/1/1
 switchport mode trunk

!Command: show running-config interface Ethernet101/1/1
!Time: Tue Oct 19 01:18:14 2010

version 5.0(2)N1(1)

interface Ethernet101/1/1
 switchport mode trunk
 speed 1000
```

## mgmt0 Interface Connectivity is Lost

Configuration synchronization sends switch profile configurations over the mgmt0 interface to the peer switch. When the mgmt0 interface connectivity is lost and the configuration needs to be changed, configure the switch profile on both switches. When the mgmt0 interface is restored, both switches become synchronized.



### Note

If you make configuration changes when the mgmt0 interface is down, the configurations that are applied on each switch must be identical. If the configurations are not identical, when the mgmt0 interface comes up and you enter a **commit** command on either switch, the commit fails because of a configuration mismatch.

If you enter the **commit** command when the mgmt0 interface is up and then the mgmt0 interface goes down, the commit eventually fails when both switches detect that the peer switch is no longer reachable from the mgmt0 interface.

## Rollback Failures with Conditional Features

With configuration synchronization, when a conditional feature is present in a checkpoint and not in the running configuration, a rollback to that checkpoint fails. As a workaround, you can reconfigure the conditional feature before a rollback is executed. The workaround applies to the **vpc domain** and **peer-keepalive** commands in vpc-domain mode.

This example shows the running configuration of the system when a checkpoint called chkpt is created:

```
feature vpc

vpc domain 100
 vpc peer-keepalive destination 10.0.0.1

interface Ethernet 1/1
 switchport mode trunk
```

## Send documentation comments to [n5kdocfeedback@cisco.com](mailto:n5kdocfeedback@cisco.com)

```
channel-group 100

switch-profile Test
 interface port-channel 100
 switchport mode trunk
 vpc peer-link
```

If you perform a write-erase at this point and you reload the switch and attempt to perform a rollback to the checkpoint `chkpt`, the rollback fails. This example shows a rollback failure when this situation occurs:



### Note

To avoid the rollback failure, preconfigure the feature `vpc`, `vpc domain`, and `peer-keepalive` command before performing the rollback.

```
N5k-1# rollback running-config checkpoint chkpt verbose
```



### Note

Applying a configuration in parallel might cause a rollback verification to fail.

```
Collecting Running-Config
Generating Rollback patch for switch profile
Executing Rollback patch for switch profiles. WARNING - This will change the configuration
of switch profiles and will also affect any peers if configured
=====
`config sync `
`switch-profile Test`
Switch-Profile started, Profile ID is 1
`interface port-channel100`
`switchport mode trunk`
Syntax error while parsing 'vpc peer-link'

=====
Generating Running-config for verification

Verification failed, rolling back to previous configuration
Collecting Running-Config
2010 Oct 14 07:43:12 switch %$ VDC-1 %$ %ASCII-CFG-2-ACFG_OPER_FAIL: Operation failed
because of Rollback Patch is not Empty
...
```

## Channel Group Failures

The **channel-group** command fails for port profiles or pre-provisioned interfaces if the port channel does not exist (auto-creation is not supported). The workaround is to explicitly create the port channel first using the **interface port-channel xxx** command.



### Note

Port-channel members must be configured in configuration terminal mode.

### Nonworking Example

This example shows the error message that appears when the port-channel interface is not created first:

```
N5k-1(config-if-range)# int ether 100/1/2-3
N5k-1(config-if-range)# channel-group 200
Pre-provisioned interface: port channel must exist first
```



***Send documentation comments to [n5kdocfeedback@cisco.com](mailto:n5kdocfeedback@cisco.com)***

The **channel-group** command fails when a module comes online if you make a configuration change on a port channel but not on the pre-provisioned interfaces. The failure does not occur in Cisco NX-OS Release 5.0(2)N2(1) which supports the **channel-group xxx force** command.

## At-A-Glance Configuration Modes

Table 1-3 shows which mode is used to configure features and interfaces in an active/active or straight-through topology and for the switches and hosts in a vPC topology.

For example, to configure a port-channel interface in an active/active topology, use the switch profile configuration mode.

**Table 1-3 At-A-Glance Topology Configuration Modes**

| Configuration                                                            | FEX Active/Active Topology  | Straight-Through Topology   | Switch / Host vPC Topology  |
|--------------------------------------------------------------------------|-----------------------------|-----------------------------|-----------------------------|
| Nonport-channel member                                                   | Switch profile mode         | Switch profile mode         | Switch profile mode         |
| Port-channel interface (interface port channel command)                  | Switch profile mode         | Switch profile mode         | Switch profile mode         |
| Port-channel member interfaces                                           | Configuration terminal mode | Configuration terminal mode | Configuration terminal mode |
| FEX/GEM pre-provisioning                                                 | Switch profile mode         | Configuration terminal mode | Configuration terminal mode |
| Global configurations (for example, port profiles, QoS, ACLs, and so on) | Switch profile mode         | Switch profile mode         | Switch profile mode         |

## Terminology

- Port-channel interface—Interface that is part of a port channel.
- Nonport-channel member—Stand-alone interface that is not part of any port channel.
- Port-channel member—Interface that is a member of a port channel.
- Switch profile—Predefined configuration profile that is used to synchronize a consistent configuration across peer switches. Switch profiles are used in the configuration synchronization feature.
- Port profile—Interface-command profile that can be applied to a range of interfaces (for example, Ethernet, VLAN network interface, or port channel).
- Configuration synchronization—Feature that uses a switch profile to synchronize consistent configurations between two peer switches.
- config-sync mode—Configuration mode that is used to define and access a switch profile.
- Configuration terminal mode (config-t)—Configuration mode used to commit configurations locally on a switch.

***Send documentation comments to [n5kdocfeedback@cisco.com](mailto:n5kdocfeedback@cisco.com)***

- Pre-provisioning—Ability to configure offline interfaces before they are connected (or brought online). Pre-provisioning can be done on Cisco Nexus 2000 Fabric Extenders (FEXs) and/or Generic Expansion Module (GEMs).

## INDEX

---

### A

Active/Active FEX Topology [1-13](#)

---

### B

buffer

configuration guidelines [1-8](#)

buffering

switch profile configuration [1-8](#)

---

### C

CFS/IP

configuring [1-4](#)

CFS protocol [1-4](#)

channel group

failure [1-32](#)

workaround [1-32](#)

Cisco Fabric Services over IP

about [1-4](#)

requirements [1-2](#)

Cisco Nexus 5000 Series switch

reloading [1-26](#)

synchronizing peer switches after a reload [1-27](#)

commit

about [1-8](#)

best practice [1-8](#)

command [1-8](#)

order dependency for commands [1-8](#)

process duration [1-8](#)

unreachable peer [1-26](#)

unsuccessful [1-8, 1-9, 1-31](#)

config-sync mode [1-5](#)

supported commands [1-6](#)

configuration modes

selecting [1-33](#)

configuration rollback [1-9](#)

conditional features

limitation [1-31](#)

workaround [1-31](#)

configuration synchronization [1-1](#)

benefits [1-2](#)

best practices [1-9](#)

configuration examples [1-10](#)

configuring a dual-homed FEX topology  
(Active/Active FEX topology) [1-13](#)

configuring an existing deployment with an A/A  
topology [1-17](#)

configuring a vPC topology using configuration  
synchronization [1-10](#)

definition [1-33](#)

guidelines [1-2](#)

limitations [1-3](#)

configuration rollback [1-3](#)

FCoE [1-3](#)

feature commands [1-3](#)

new deployment in a vPC topology and  
straight-through FEX topology [1-21](#)

requirements [1-2](#)

switch vPC topology and straight-through FEX  
topology (host vPC) [1-19](#)

---

### D

dual-homed A/A topology

configuring [1-14](#)

***Send documentation comments to [n5kdocfeedback@cisco.com](mailto:n5kdocfeedback@cisco.com)***

---

**E**

Etherchannel [1-1](#)

---

**F**

Fabric Extender (FEX)

pre-provisioning [1-2](#)

FEX

configuring a FEX in an A/A topology [1-14](#)

how to provision [1-29](#)

straight-through topology [1-20](#)

---

**G**

Gigabit Expansion Module (GEM)

pre-provisioning [1-2](#)

---

**I**

import

abort [1-9](#)

configuration changes during [1-9](#)

methods [1-18, 1-24](#)

importing switch profile commands

about [1-9](#)

initiator switch [1-8](#)

---

**M**

merge checks [1-8](#)

mgmt0 interface [1-4](#)

lost connectivity [1-31](#)

mutual exclusion check

about [1-7](#)

command exceptions [1-7](#)

failure [1-7](#)

---

**P**

peer keepalive

configuring [1-11](#)

peer switch

running configuration in a vPC topology [1-11](#)

running configuration of FEX in A/A topology [1-14](#)

policies

synchronizing [1-22](#)

port channel members

peer switch requirements [1-23](#)

port-profiles [1-9](#)

pre-provisioning [1-9](#)

FEX in dual-homed topology [1-17](#)

offline interfaces [1-16, 1-23](#)

---

**R**

Role Based Access Control (RBAC)

switch profile requirements [1-6](#)

---

**S**

straight-through topology

diagram [1-20](#)

switch profile

configuration modes [1-33](#)

definition [1-33](#)

switch profiles [1-1](#)

about [1-5](#)

commands

not supported [1-6](#)

supported [1-6](#)

commit

requirements [1-7](#)

copying commands to [1-9](#)

creating [1-5](#)

limit [1-6](#)

naming [1-6](#)

***Send documentation comments to [n5kdocfeedback@cisco.com](mailto:n5kdocfeedback@cisco.com)***

synchronization

configuration changes made during [1-8](#)

---

## T

terminology [1-33](#)

---

## U

User-Based Access Controls

about [1-6](#)

---

## V

Verification Checks [1-7](#)

vPC

Active/Active topology [1-3](#)

and straight-through FEX topologies [1-19](#)

and straight-through FEX topology

existing deployments [1-24](#)

configurations [1-3](#)

configuring [1-3, 1-11](#)

consistency check [1-1](#)

peer-config-check-bypass best practice [1-11](#)

peer-link failure [1-28](#)

straight-through topology

running configuration example [1-21](#)

topology [1-1](#)

topology diagram [1-3](#)

vPC topologies

running different versions of Cisco NX-OS [1-7](#)

vPC topology

and straight-through FEX topology new  
deployment [1-21](#)

***Send documentation comments to [n5kdocfeedback@cisco.com](mailto:n5kdocfeedback@cisco.com)***