



NETWORKERS 2004

GETTING THE RIGHT EVENTS FROM NETWORK ELEMENTS

NMS-3011

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

1

This Tutorial Is ...

Cisco.com

- **NOT** about
 - Fault Management Return On Investment
 - A level 1 type of presentation
 - Marketing slides
 - Polling the device to “discover” the fault
 - Fault Management Applications details
- **about**
 - How to generate the right events from your network elements!

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

2

The Network Management TAC Team in EMEA

Cisco.com



NM
953

3

Polling vs. Event Notification

Cisco.com

- Network sizes are getting larger and larger
- Polling for Fault Management doesn't always scale
- Event Notification
 - Sent only at the occurrence of a fault
 - Allows to tune fault management to your users and network
- Message:
 - Let the network elements monitor themselves
 - Let's tune the right fault management events from the network elements


NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

4

Polling vs. Event Notification

Cisco.com



NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

5

Polling vs. Event Notification

Cisco.com

| | Polling | Event |
|-------------|--|---|
| Load on | Network Manager Station, Links, Network devices | Network engineer, initially, to configure the event |
| Application | Performance Management (Availability monitoring, Utilization and Forecasting) Fault Management | Proactive Fault Monitoring, Operational Monitoring |

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

6

Agenda

Cisco.com

- **SNMP Notification: Traps and Informs**
- **Syslog Message**
- **RMON Event / Alarm**
- **EVENT-MIB**
- **EXPRESSION-MIB**
- **Specific Scenarios**
- **Embedded Event Manager**
- **Embedded Syslog Manager**

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

7

SNMP NOTIFICATION



EVERYBODY KNOWS ABOUT TRAPS!

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

8

SNMP Notifications

Cisco.com

- Notifications are the messages being generated from the SNMP Agent, regardless of the mechanism to deliver them

- SNMP Notification implemented in SNMPv2:

Traps

Unacknowledged UDP packet

Implemented since SNMPv1

Informs

Acknowledged UDP packet

Implemented since SNMPv2c


NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

9

SNMP Trap Notification

Cisco.com



NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

10

How to Enable SNMP Traps Notification?

Cisco.com

- On a Cisco Router:

```
Router (config)# snmp-server enable traps
<trap_type>

Router (config)# snmp-server host <NMS host>
version <v1/v2c/v3 [auth | noauth | priv]>
<trap_community> <trap_type>
```

- On a Cisco Switch:

```
Switch>(enable) set snmp trap enable <trap_type>
Switch>(enable) set snmp trap <NMS_host>
```

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

11

Traps - Show Commands

Cisco.com

```
Router#show snmp
...
22689 SNMP packets output
  0 Too big errors (Maximum packet size 1500)
 229 No such name errors
  0 Bad values errors
  0 General errors
22450 Response PDUs
 172 Trap PDUs

SNMP logging: enabled
Logging to 10.48.71.130.162, 0/10, 86 sent, 0 dropped.
Logging to 144.254.7.167.162, 0/10, 85 sent, 1 dropped.
```

```
Router(config)# snmp-server
queue-length <length>
```

NM
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

12

SNMP V2 Notification

Cisco.com

```
Router(config-if)# shut
Nov 21 07:44:17: %LINK-3-UPDOWN: Interface Serial1/2, changed state
to down
4d23h: SNMP: V2 Trap, reqid 2, errstat 0, erridx 0
sysUpTime.0 = 43061874
snmpTrapOID.0 = snmpTraps.3
ifEntry.1.23 = 23
ifEntry.2.23 = Serial1/2
ifEntry.3.23 = 24
lifEntry.20.23 = administratively down
```

| | | | | |
|----------|------------|---|---|--|
| PDU type | Request-id | 0 | 0 | Variable-bindings: sysUpTime, snmpTrapOID, ... |
|----------|------------|---|---|--|

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

13

linkUp/linkDown Notification

Cisco.com

```
linkDown
  ifIndex.4 4
  ifDescr.4 Serial 1/2
  ifType.4 propPointToPointSerial(22)
  loclfReason.4 keepalive failed
```

Cisco redefinition
CISCO-GENERAL-TRAPS

Instance 4
Serial 1/2

```
linkDown
  ifIndex.4 4
  ifAdminStatus.4 Down
  ifOperStatus.4 lowerLayerDown
```

IETF notification
IF-MIB
(RFC2233/RFC2863)

```
router(config)# snmp-server trap link ietf
```

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

14

How to Enable SNMP Inform Notification?

Cisco.com

Enable trap and inform notifications. Ideally “notification” !

```
Router(config)# snmp-server enable traps ...
```

```
Router(config)# snmp-server host <host-id> informs
version [2c | 3 [auth | noauth | priv]]
<community-string>...
```

```
Router(config)# snmp-server informs [retries
retries] [timeout seconds] [pending pending]
```

By default: 3 retries, 30 sec timeout, 25 informs pending for acknowledgement

- “snmp-server enable informs ...” no functionality!
- Switches:
 - so far, needed the SNMPv3 architecture
 - 8.3(1): simplified v2c inform CLI

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

15

SNMP Inform Notification Format

Cisco.com

- InformRequest-PDU (Protocol Data Unit)

| | | | | |
|----------|------------|----------------|---------------|-------------------|
| PDU type | Request-id | ErrorStatus =0 | ErrorIndex =0 | Variable-bindings |
|----------|------------|----------------|---------------|-------------------|

↓ =0 ↓ =0

- Response-PDU

↑ =? ↑ =?

| | | | | |
|----------|------------|-------------|------------|-------------------|
| PDU type | Request-id | ErrorStatus | ErrorIndex | Variable-bindings |
|----------|------------|-------------|------------|-------------------|

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

16

Informs - Show Commands

Cisco.com

```
Router#show snmp
...
SNMP Manager-role output packets ...
  20 Inform-request PDUs
  0 Timeouts
  0 Drops
...
SNMP Manager-role input packets ...
  20 Response PDUs
  0 Response with errors
...
SNMP informs: enabled
...
...
SNMP informs: enabled
  Informs in flight 0/25 (current/max)
  Logging to 10.48.71.163.162
  2 sent, 0 in-flight, 0 retries, 0 failed, 0 dropped
```


NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

17

SNMP Source Trap Notification

Cisco.com



```
Router(config)# snmp-server trap-source ethernet 0
(notification sent even if ethernet 0 is down)
```

Or even better

```
Router(config)# snmp-server trap-source loopback 0
```

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

18

SNMP Traps vs. Informs

Cisco.com

| | Traps | Informs |
|-------------|--------------------------------|-----------------|
| Reliability | None | Some |
| Retries | Not Applicable | 3 (default) |
| Resources | x | X |
| Source | Source Interface configuration | Not Implemented |

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

19

Notification and Time

Cisco.com

SNMPv2-Notification-PDU

sysUpTime in the device

| PDU type | Request-id | ErrorStatus =0 | ErrorIndex =0 | Variable-bindings: sysUpTime ... |
|----------|------------|----------------|---------------|----------------------------------|
| | | | | |

- For alarms correlation, the right time is important
 - Use NTP between network elements
 - Use NTP between network elements and the notification receiver (attention to different timezone)
 - Note: SNMPv1 Trap also sends the sysUpTime
- Alarms correlation and informs:

The management system must do alarms deduplication based on the time!

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

20

How to Find Out about Traps and Informs?

Cisco.com

```
cognac(config)#snmp-server enable traps ?  
atm      Enable SNMP atm traps  
bgp      Enable BGP state change traps  
config   Enable SNMP config traps  
dial     Enable SNMP dial control traps  
dlsw     Enable SNMP dlsw traps  
...
```

- TAC Web document

<http://www.cisco.com/warp/customer/477/SNMP/SNMPTrapsInImages.html>

- Working on “Traps & Syslog in Images”

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

21

How to Find Out about Traps and Informs?

Cisco.com

- Provided in corresponding MIBs supported on Cisco devices.
- What device supports which MIB?

<http://www.cisco.com/go/mibs>

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

22

NOTIFICATION-LOG-MIB

Cisco.com

- RFC-3014 “NOTIFICATION-LOG MIB”
- Notification buffer: allow a management station to retrieve notifications that have been missed.
- Notifications visualization without a receiver. Useful for troubleshooting!
- No persistence across reload

```
Router(config)#snmp mib notification-log ?
  default      create/configure default log
  globalageout modify the global ageout
  globalsize   modify the global size
```

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

23

NOTIFICATION-LOG-MIB

Cisco.com

```
Router#show snmp mib notification-log all
Notification ID cisco.0.1
  sysUpTime when logged 4057361, Accessed by
  1 log(s), contains 8 varbinds
Notification ID snmpTraps.4
  sysUpTime when logged 4098180, Accessed by
  1 log(s), contains 6 varbinds
```

- The MIB returns the MIB values, not the CLI

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

24

SYSLOG MESSAGE



WHAT HAPPENS IF THE NOTIFICATION DOESN'T EXIST?
OR IF THERE IS NO SNMP NOTIFICATION RECEIVER?


NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

25

Syslog Message

Cisco.com



NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

26

Syslog Message

Cisco.com

- Syslog produces (mostly) structured logs of information. Allowing software subsystems to report and save important error messages either locally or to a remote logging server
- Very basic reporting mechanism: no variable bindings, plain english text
- Very basic “standard”, now an Informational RFC 3164
- Text messages sent to a Syslog daemon, on UDP port 514
- Syslog message is complementary to other events (SNMP notifications)


NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

27

Syslog Message Format

Cisco.com



<facility(X)>.<level(Y)>

WHAT messages are logged?
emergency 0, alert 1, critical 2, error 3,
warning 4, notification 5, information 6,
debug 7

WHERE is the message logged in the Syslog Server?
local0 ... local7, cron, user, etc...

- <facility.level> is not retained in the Syslog message file
- Additional timestamp is added by logging host
- Header example

Message Header: local7.emergency

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

28

How to Enable Syslog Message on Cisco IOS?

Cisco.com

- On a Cisco Router:

```
Router(config)# logging on
Router(config)# logging <server_ip_address>
Router(config)# logging facility local6
Router(config)# service sequence-numbers
Router(config)# service timestamps log
[datetime | uptime]
Router(config)# service timestamps log datetime
[msec] [localtime] [show-timezone] [year]
```

Optional: default is in UTC with no milliseconds and no time zone

Note: UTC, Universal Time, since 1970


NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

29

Syslog Message "Body" Format in the Cisco IOS

Cisco.com



- NTP is needed!
- Header:level can be different than Body:severity

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

30

Syslog - Show Commands on Cisco IOS (Cont.)

Cisco.com

```
Router# show logging
```

```
Syslog logging: enabled (0 messages dropped, 13 messages rate-limited, 0 flushes, 0 overruns)
```

```
Console logging: level debugging, 34 messages logged
```

```
Monitor logging: level debugging, 0 messages logged
```

```
Buffer logging: level debugging, 47 messages logged
```

```
Logging Exception size (8192 bytes)
```

```
Trap logging: level debugging, 51 message lines logged
```

```
Logging to 10.48.71.225, 51 message lines logged
```

```
Log Buffer (8192 bytes):
```

```
*Apr 10 08:21:32 CET: %SYS-5-RESTART: System restarted --
```

```
*Apr 10 08:21:32 CET: %SNMP-5-COLDSTART: SNMP agent on host popo is undergoing a cold start
```

```
*Apr 10 08:21:32 CET: %LINK-5-CHANGED: Interface FastEthernet5/1, changed state to administratively down
```

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

31

How to Enable Syslog Message on Catalyst OS?

Cisco.com

- On a Cisco Catalyst Switch:

```
Switch(enable)> set logging session enable
```

```
Switch(enable)> set logging server  
<Server_ip_address>
```

```
Switch(enable)> set logging server facility  
local7
```

```
Switch(enable)> set logging server severity 3
```

```
Switch(enable)> set logging console enable
```

```
Switch(enable)> set logging timestamp enable
```

Local time configured on the switch (Optional)


NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

32

Syslog Source Interface

Cisco.com



```
Router(config)# logging source-interface loopback 0
```

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

33

Syslog Message Filtering: Example 1

Cisco.com

- How to get the error messages which have severity level equal or lower than error?

```
Router(config)# logging 10.10.10.10  
Router(config)# logging facility local6  
Router(config)# logging trap errors  
Router(config)# logging console debugging
```

Confusing!
Should be level!!
(the one in the syslog header)

- On the Syslog server(UNIX), the corresponding line in Syslog.conf file is:

```
local6.errors /var/log/mylog
```

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

34

Syslog Message Filtering: Example 2

Cisco.com

- How to only log the error messages related to spanning tree?

```
Switch> (enable) set logging session enable
Switch> (enable) set logging server 10.10.10.10
Switch> (enable) set logging server severity 0
Switch> (enable) set logging level spantree 0
Switch> (enable) set logging server facility local5
Switch> (enable) set logging console enable
```

- On the Syslog server(UNIX), the corresponding line in Syslog.conf file is:

```
local5.emerg /var/log/spantree
```

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

35

Syslog Messages vs. SNMP Notifications

Cisco.com

| | Syslog | Notification |
|---------------|---------------------------------------|--|
| NMS | Syslog Daemon | Trap receiver |
| Protocol/Port | UDP 514 | UDP 162 |
| Filtering | Yes | Limited |
| Format | easy-to-read format, No MIB needed | More rigid format, parse able |
| Reliability | None (RFC 3195 reliable syslog) | None with traps Some with informs (NOTIFICATION-LOG MIB) |

Note: the syslog message could be sent faster!

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

36

Convert a Syslog Message to a SNMP Notification?

Cisco.com

- **Why?**
 - Not all error messages are supported via notifications
 - Syslog daemon not running in the NMS
 - Events correlation need
- **Send a trap/inform from the CISCO-SYSLOG-MIB when a new syslog message is generated**
- **How to convert to a trap?**

```
Router (config)# snmp-server enable traps syslog
```

Attention to the <all> keyword !!!

- **How to convert to an inform?**

```
Router (config)# snmp-server host <x.x.x.x>  
informs version 2c public syslog
```

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

37

Syslog Writing to Flash

Cisco.com

- **System error and debug messages saved on the router's CompactFlash Disks (also known as ATA Flash disks)**
- **Persistent across reboot**
- **Introduced in 12.0(26)S**

```
Router(config)# logging buffered  
Router(config)# logging persistent url  
disk0/syslog size 134217728 filesize 16384  
  
Router# copy slot0:/syslog  
ftp://myuser/mypass@192.21.1.129/syslog
```

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

38

Syslog Issue Consistent Message Format

Cisco.com

- **Syslog isn't consistently used across different Cisco Platforms and IOS versions**

Example: environmental monitor initiated shutdown event

IOS 11.2 -> ENVM-1-SHUTDOWN

IOS 12.0 -> ENVM-0-SHUT

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

39

How to Find Out about Syslog Messages?

Cisco.com

- **'Cisco IOS Software System Error Messages' per IOS release**

For IOS version 12.2:

http://www.cisco.com/en/US/partner/products/sw/iosswrel/ps1835/products_system_message_guide_book09186a008009e73d.html

- **'System message' per Cisco Switch, Cisco 6000 switch:**

http://www.cisco.com/en/US/partner/products/hw/switches/ps700/products_system_message_guide_chapter09186a00800f2709.html

- **Error Message Decoder**

<http://www.cisco.com/cgi-bin/Support/Errordecoder/home.pl>

- **Output Interpreter**

<https://www.cisco.com/cgi-bin/Support/OutputInterpreter/home.pl>

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

40

XML Interface to Syslog Messages

Cisco.com

- Enable syslog messages to be sent in an Extensible Markup Language (XML) format
- Logs in a standardized XML format can be more readily used in external customized monitoring tools
- Tags are hard-coded
- Available in 12.2(15)T
- Configuration:

```
Router(config)#logging console xml
Router(config)#logging monitor xml 6
Router(config)#logging host 128.107.165.215 xml
Router(config)#logging host 171.69.1.129
Router(config)#logging buffered xml 10000
```

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

41

XML Interface to Syslog Messages Events Comparison

Cisco.com

```
000013: *Oct 11 14:52:10.039: %SYS-5-CONFIG_I:
    Configured from console by vty0 (172.19.208.14)
```


```
<ios-log-msg>
  <facility>SYS</facility>
  <severity>5</severity>
  <msg-id>CONFIG_I</msg-id>
  <seq>000013</seq>
  <time>*Oct 11 14:52:10.039</time>
  <args>
    <arg id="0">console</arg>
    <arg id="1">vtty0 (172.19.208.14)</arg>
  </args>
</ios-log-msg>
```

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

42

RMON EVENT AND ALARM




**SOMETIMES THE EXACT NOTIFICATION DOESN'T EXIST!
BUT THE SNMP OBJECTS TO TRIGGER THE NOTIFICATION
DO EXIST!**

NMS-3011
9593_04_2004_c2

© 2004, Cisco Systems, Inc. All rights reserved.

43



RMON Event and Alarm

Cisco.com

- **Allows Proactive monitoring:**
 - The device polls itself
- **RMON-MIB used to configure SNMP traps:**
 - Traps, no informs (will be an enhancement)
 - Integer32, Counter32, Counter64, Gauge or Timeticks may be sampled
- **Included in all Cisco IOS software images**
 - since IOS 11.1
 - CLI or SNMP configuration
- **Included in all the Switches images**
 - Only SNMP configuration

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

45

How to Enable RMON Event and Alarm via CLI?

Cisco.com

- **Configure RMON to generate a trap if CPU utilization reaches 80%, and rearm the trap if utilization drops below 40%, sampling interval is 20 seconds**

T (sec)

```
Router(config)#rmon alarm 1  
cpmCPUTotalEntry.3.0 20 absolute  
rising-threshold 80 1 falling-threshold  
40 2 owner me
```

Triggering event#2

Rising condition

Triggering event#1

```
Router(config)#rmon event 1 log Trap  
public description "cpu busy" owner me
```

```
Router(config)#rmon event 2 log  
description "cpu not too busy"
```


NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

46

RMON Reaction Condition

Cisco.com



T: internal sampled interval (20 sec)

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

47

How to Enable RMON Event and Alarm via SNMP?

Cisco.com


- Send a trap when the number of bytes going into interface with ifIndex 12, during the last 2 minutes is above 140000000

```
snmpset -c private <router> eventStatus.123 integer 2
snmpset -c private <router> eventDescription.123 string "above 140000000"
snmpset -c private <router> eventType.123 integer 4
snmpset -c private <router> eventCommunity.123 string "public"
snmpset -c private <router> eventOwner.123 string "event_owner"
snmpset -c private <router> eventStatus.123 integer 1
snmpset -c private <router> alarmStatus.321 integer 4
snmpset -c private <router> alarmStatus.321 integer 2
snmpset -c private <router> alarmInterval.321 integer 120
snmpset -c private <router> alarmVariable.321 integer ifInOctets.12
snmpset -c private <router> alarmRisingThreshold.321 integer 140000000
snmpset -c private <router> alarmFallingThreshold.321 integer 10
snmpset -c private <router> alarmRisingEventIndex.321 integer 123
snmpset -c private <router> alarmOwner.321 string "alarm_owner"
snmpset -c private <router> alarmStatus.321 integer 1
```


Which MIB Variables to Monitor?

Cisco.com

dot3StatsCarrierSenseErrors bufferFail
 ciscoEnvMonTemperatureState
 cpmCPUTotal5min
 ifOutDiscards ciscoEnvMonFanState
 bufferNoMem
 locIfResets
 locIfCollisions locIfCollisions ifOperStatus
 ciscoMemoryPoolFree
 locIfInputQueueDrops locIfCarTrans
 locIfInCRC
 bufferFail locIfOutputQueueDrops



See the APPENDIX

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

49

Fault Management Which MIB Variables to Monitor?

Cisco.com

| Interface | Object Descr | OID | Poll Int | Threshold |
|-----------------|--|---------------------------|----------|-----------|
| locIfResets | number of times the interface internally reset | .1.3.6.1.4.1.9.2.2.1.1.17 | 15 min | |
| ifOperStatus | The current operational state of the interface. The testing(3) state indicates that no operational packets can be passed | .1.3.6.1.2.1.2.2.1.8 | 5 min | != 1 |
| locIfCarTrans | Number of times interface saw the carrier signal transition | .1.3.6.1.4.1.9.2.2.1.1.21 | 15 min | |
| locIfCollisions | number of output collisions detected on this interface | 1.3.6.1.4.1.9.2.2.1.1.25 | 15 min | |
| locIfInCRC | number of input packets which had cyclic redundancy checksum errors | .1.3.6.1.4.1.9.2.2.1.1.12 | 15 min | |

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

50

ifIndex and RMON Persistence

Cisco.com

- ifIndex persistence

Router

```
router(conf) snmp-server ifindex persist
router(conf-if) snmp-server ifindex persist
```

Switch: ifIndex persistence by default

- RMON persistence

- Router: event/alarm saved in the startup configuration
- Switch: no event/alarm persistence

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

51

RMON Event/Alarm Issue Mapping the 2 Events to the Alarm

Cisco.com

```
Router(config)#rmon alarm 1 cpmCPUTotalEntry.3.0 20
absolute rising-threshold 80 1
falling-threshold 40 2 owner me

Router(config)#rmon event 1 log trap public
description "cpu busy" owner me

Router(config)#rmon event 2 log trap public
description "cpu not too busy"
```

- From the NMS point of view, no link between the event “cpu busy” and the alarm setting: MIB variable, threshold, sampling period

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

52

EVENT-MIB



**SOMETIMES THE EXACT NOTIFICATION DOESN'T EXIST!
BUT THE SNMP OBJECTS TO TRIGGER THE
NOTIFICATION DO EXIST!**

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

53

Event-MIB Advantages Versus RMON Event and Alarm

Cisco.com

- **The EVENT MIB provides a superset of the capabilities of the RMON alarm and event**
- **The EVENT MIB calls "triggers"
The RMON MIB calls "alarms,"
but the concepts are the same**
- **More flexible test types with the EVENT-MIB**
 - Existence test: absent, present, changed
 - Boolean test: <>, =, <, <=, >, >=
 - Wildcard
- **Event MIB proposed by Cisco to IETF DISMON
Working Group, accepted standard track RFC-2981**

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

54

Event-MIB Advantages Versus RMON Event and Alarm

Cisco.com

- **EVENT MIB can monitor**
 - any MIB object (existence)
 - any integer/counter (boolean, threshold)
- **RMON MIB can only monitor**
 - integer/counter (threshold)
- **EVENT-MIB allows alarms to be generated for MIB objects that are on another network element**
- **EVENT-MIB sends an SNMP notification in response to a trigger (like RMON) but add the concept of setting a MIB object (integers)**
- **EVENT-MIB can specify which variables to add to the notification**

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

55

EVENT-MIB: Example 1 Wildcarding

Cisco.com

- **Wildcarding is a powerful functionality which allows you to monitor multiple instances of an object**
- **Can specify a single OID for monitoring, or use wildcarding to specify a group of OIDs**
- **Example:**

monitor ifInOctets for all interfaces. The EVENT-MIB is configured to monitor the delta values of ifInOctets for all interfaces once per minute. If any of the samples exceed the delta rising or falling triggers, a trap notification will be sent


NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

56

EVENT-MIB: Example 2 Add Variable to Notification

Cisco.com



NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

57

How to Find Out about EVENT-MIB Support in Cisco IOS?

Cisco.com

- Event MIB Support in Cisco IOS Release 12.1(3)T and 12.0(12)S
- RFC 2981-compliant support is in IOS release 12.2(4)T
http://www.cisco.com/en/US/products/sw/iosswre/ps1839/products_feature_guide09186a00800c391a.html
- Only SNMP support so far
- No CLI. Scriptable Interface for adding command line support in 13.(7)T


NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

58

EVENT-MIB: Example 3 Remote Device Monitoring (foreseen by RFC)

Cisco.com



- “Remote monitoring uses the tag service of the Management Target MIB [RFC2573] to select and access remote systems as an ordinary SNMP- based management application.”, RFC2981

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

59

How to Enable the EVENT-MIB? Step 1. Any MIB Object Type

Cisco.com

- Each trigger is configured to watch a single object or a group of objects specified by a wildcard
- The object-type can be any one of the types:

| | |
|-------------------|-----------------|
| INTEGER_TYPE | OCTET_PRIM_TYPE |
| NULL_TYPE | OBJECT_ID_TYPE |
| SEQUENCE_TYPE | INTEGER_32_TYPE |
| IP_ADDR_PRIM_TYPE | COUNTER_TYPE |
| GAUGE_TYPE | TIME_TICKS_TYPE |
| OPAQUE_PRIM_TYPE | COUNTER_32_TYPE |
| GAUGE_32_TYPE | UNSIGNED32_TYPE |
| COUNTER_64_TYPE | |

However, the type of sampling dictates the types of objects that can be monitored

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

60

How to Enable the EVENT-MIB? Step 2. Possibility: Sampling Type

Cisco.com

- The Event MIB process checks the state of this watched object at predefined intervals.
- The type of sampling that can be done on an object is of two types:
 - Absolute
 - Delta
- Configurable observation interval

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

61

How to Enable the EVENT-MIB? Step 3. Test Type and Parameters

Cisco.com

- The test that can be done on the watched object is one or a combination of the following:
 - Existence
 - Absent, Present, Changed
 - Boolean
 - Unequal, Equal, Less, LessOrEqual, Greater, GreaterOrEqual
 - Threshold
 - Rising, Falling, Rising or Falling

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

62

How to Enable the EVENT-MIB? Step 4. Actions

Cisco.com

- This could one or both of the following:
 - Notifications (Traps/Informs), with the possibility to add extra Object ID's to the notification.
 - SNMP Set

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

63

How to Enable EVENT-MIB?

Cisco.com

Define the trigger

mteTriggerTable
INDEX: mteOwner, IMPLIED
mteTriggerName
mteTriggerObjects
mteTrigger*Event

Define which variable(s) to add to the notification

mteObjectsTable
INDEX: mteOwner,
mteObjectsName,
mteObjectsIndex

Define the notification

mteEventNotificationTable
INDEX: mteOwner, IMPLIED
mteEventName

Define the event

mteEventTable
INDEX: mteOwner, IMPLIED
mteEventName
mteEventAction

Define the SNMP Set


mteEventSetTable
INDEX: mteOwner, IMPLIED
mteEventName

AND/
OR

64

EVENT-MIB – Example 4 SNMP Set

Cisco.com



- **Boolean**
test that can be done on the watched object: *Unequal*
- **SNMP Set**


NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

65

Event MIB vs. RMON Event&Alarm

Cisco.com



NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

66

Event MIB vs. RMON Event&Alarm

Cisco.com

- If we want a trigger:
 - Threshold based,
 - On the local device (not remote),
 - Without wildcard,
 - With no extra objects in notification,
 - With no SNMP Set
- Then it is easier to use the RMON Event/Alarm

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

67

EVENT-MIB Feature MIB Persistence

Cisco.com

- Allows the MIB to be persistent across reloads, i.e. MIB information retains the same set object values each time a networking device reboots

```
Router(config)# snmp mib persist [event]
```

- Write to NVRAM by using the “write mib-data”
- Any modified MIB data must be written to NVRAM memory using the “write mib-data”

```
Router# write mib-data
```

- Added in 12.2(4)T3

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

68

EVENT-MIB Show Command and Debug

Cisco.com

- Displays the SNMP Event values that have been configured on your routing device through the use of the Event MIB

```
Router# show management event
```

- Prints messages to the console whenever a the Event MIB evaluates a specified trigger

```
Router# debug management event mib
```

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

69

Show Command Example

Cisco.com

```
Router#show management event
Mgmt Triggers:
(1): Owner: john
(1): 01 , Comment: test, Sample: Del, Freq: 60
Test: Threshold
ObjectOwner: , Object:
OID: ifEntry.10, Enabled 1, Row Status 2
Threshold Entry:
Rising: 0, Falling: 0, DeltaRising: 0, DeltaFalling: 0
ObjOwn: , Obj:
RisEveOwn: , RisEve: , FallEveOwn: , FallEve:
DelRisEveOwn: , DelRisEve: , DelFallEveOwn: , DelFallEve:

Delta Value Table:

Mgmt Events:

Object Table:

Failures: Event = 0, Trigger = 0
```

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

70

Show Command Example, Commented

Cisco.com

```
Router#show management event
Mgmt Triggers:
(1): Owner: john (mteOwner)
(1): 01 (mteTriggerName), Comment (mteTriggerComment):
"test", Sample (mteTriggerSampleType): Del (this means
delta), Freq (mteTriggerFrequency): 60
Test (mteTriggerTest): Threshold
ObjectOwner: , Object:
OID (mteTriggerValueID): ifEntry.10, Enabled
(mteTriggerEnabled) 1, Row Status (mteTriggerEntryStatus) 2
Threshold Entry:
Rising: 0, Falling: 0, DeltaRising: 0, DeltaFalling: 0
ObjOwn: , Obj:
RisEveOwn: , RisEve: , FallEveOwn: , FallEve:
DelRisEveOwn: , DelRisEve: , DelFallEveOwn: , DelFallEve:

Delta Value Table:

Mgmt Events:

Object Table:

Failures: Event = 0, Trigger = 0 0
```

9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

71

EXPRESSION-MIB



**SOMETIMES THE DESIRED SNMP OBJECT DOESN'T EXIST
BUT CAN BE DERIVED FROM MULTIPLE OTHER OBJECTS**

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

72

EXPRESSION-MIB

Cisco.com

- Allows you to create new SNMP objects based upon existing MIB variables and formulas
- Based on IETF draft, again in the DISMON Working Group, and numbered in Cisco's namespace
- Interesting when combined with the EVENT-MIB
- Note that RFC 2982 exists now
- Available in IOS since 12.0(5)T, added delta and wildcard support in 12.1(3)T

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

73

EVENT-MIB & EXPRESSION-MIB Example 1: Notification

Cisco.com

- An access router would like to send a trap only for the high speed interface
- RouterA sends a Trap when Serial0 has:
 BW>100Kbits & OperStatus=DOWN
- Steps:

Expression-MIB

Create an expression that will return "1" when the condition is TRUE and "0" when FALSE

Exp1 = (ifSpeed > 100000) && (ifOperStatus == 2)

Event-MIB

If Exp1 == "1" generates an Event. This will be checked every minute

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

74

EVENT-MIB & EXPRESSION-MIB Example 1: Notification

e1exp in ASCII

```
snmpset -v 2c -c private RouterA expNameStatus.101.49.101.120.112
integer 6
snmpset -v 2c -c private RouterA expNameStatus.101.49.101.120.112
integer 5
snmpset -v 2c -c private RouterA expExpressionIndex .101.49.101.120.112
gauge 1
snmpset -v 2c -c private RouterA expExpressionComment.1 octetstring "e1
expression"
snmpset -v 2c -c private RouterA expExpression.1 octetstring '$1 <
100000 && $2 == 2'
snmpset -v 2c -c private RouterA expObjectID.1.1 objectidentifier
ifSpeed.16
snmpset -v 2c -c private RouterA expObjectID.1.2 objectidentifier
ifOperStatus.16
snmpset -v 2c -c private RouterA expObjectSampleType.1.1 integer 1
snmpset -v 2c -c private RouterA expObjectSampleType.1.2 integer 1
snmpset -v 2c -c private RouterA expObjectStatus.1.1 integer 1
snmpset -v 2c -c private RouterA expObjectStatus.1.2 integer 1
snmpset -v 2c -c private RouterA expNameStatus.101.49.101.120.112
integer 1
```

NMS-3
9593

EVENT-MIB & EXPRESSION-MIB Example 1: Notification

#N characters for
the mteOwner

mteOwner = tom

#mteTriggername =
trigger1

```
mteTriggerEntry Index=3.116.111.109.116.114.105.103.103.101.114.49 = Y
mteEventEntry Index= 3.116.111.109.101.116.101.110.116.49 = Z
snmpset -v 2c -c private RouterA mteTriggerEntryStatus.Y integer 1
snmpset -v 2c -c private RouterA mteTriggerEntryStatus.Y integer 1
snmpset -v 2c -c private RouterA mteTriggerValueID.Y objectidentifier
1.3.6.1.4.1.9.10.22.1.4.1.1.2.1.0.0.0
snmpset -v 2c -c private RouterA mteTriggerValueIDWildcard.Y integer 2
snmpset -v 2c -c private RouterA mteTriggerTest.Y o "40"
snmpset -v 2c -c private RouterA mteTriggerFrequency.Y gauge 60
snmpset -v 2c -c private RouterA mteTriggerSampleType.Y integer 1
snmpset -v 2c -c private RouterA mteTriggerEnabled.Y integer 1
snmpset -v 2c -c private RouterA mteEventEntryStatus.Z integer 6
snmpset -v 2c -c private RouterA mteEventEntryStatus.Z integer 5
snmpset -v 2c -c private RouterA mteEventActions.Z o "80"
```

#mteEventname
= event1

Existence(0)
Boolean(1)
Threshold(2)

Absolute (1)

When condition
is met>send
notification

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

76

EVENT-MIB & EXPRESSION-MIB Example 1: Notification

Cisco.com

```
snmpset -v 2c -c private RouterA mteTriggerBooleanValue.Y i 1
snmpset -v 2c -c private RouterA mteTriggerBooleanComparison.Y i 2
snmpset -v 2c -c private RouterA mteTriggerBooleanObjectsOwner.Y o "tom"
snmpset -v 2c -c private RouterA mteTriggerBooleanObjects.Y o "objects "
snmpset -v 2c -c private RouterA mteTriggerBooleanEventOwner.Y o "tom"
snmpset -v 2c -c private RouterA mteTriggerBooleanEvent.Y o "event1"
Creating the ObjectTable
snmpset -v 2c -c private RouterA mteObjectEntryStatus.Z.1 i 6
snmpset -v 2c -c private RouterA mteObjectEntryStatus.Z.1 i 5
snmpset -v 2c -c private RouterA mteObjectsID.Z o ifAdmin.13
snmpset -v 2c -c private RouterA mteObjectEntryStatus.Z.1 i 1
Attaching the object to the event:
snmpset -v 2c -c private RouterA mteEventNotificationObjectsOwner.Z o "tom"
snmpset -v 2c -c private RouterA mteEventNotificationObjects.Z o "objects1"
Activating the Trigger and the Event
```

Unequal(1)
Equal(2)
less(3)...

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

77

EVENT-MIB & EXPRESSION-MIB Example 2: Simple Capacity Planning

Cisco.com

- If my link utilization is above 50% for an hour, it's time to upgrade the link

- Steps:

Create an expression

$$\text{utilization} = (\text{ifInOctets} + \text{ifOutOctets}) * 800 / \text{hour} / \text{ifSpeed}$$

Expression-MIB

If utilization above 50% of the bandwidth generates an Event. This will be checked every minute

Event-MIB

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

78

EVENT-MIB & EXPRESSION-MIB Example 3: Table Entry Count

Cisco.com

- Sometimes there is no counter for the number of table entries in the MIB definition
- Create an expression1 that will match all entries
- Create an expression2 that will sum expression1
- Other examples:
 - Number of ethernet interfaces up
 - Number of entries in the CAM table
 - Number of static route in the routing table

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

79

EXPRESSION-MIB Show Command and Debug

Cisco.com

- Show commands

```
Router# show management expression
```

- Debug commands

```
Router# debug management expression ?  
evaluator  Expression MIB evaluator  
mib        Expression MIB SNMP operations  
parser     Expression MIB parsing
```

- CLI show commands
- CLI debug commands
- SNMP configuration (no CLI yet)

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

80

Expression MIB Feature MIB Persistence

Cisco.com

- Allows the MIB to be persistent across reloads, i.e. MIB information retains the same set object values each time a networking device reboots

```
Router(config)# snmp mib persist [expression]
```

- Any modified MIB data must be written to NVRAM memory using the “write mib-data”

```
Router# write mib-data
```

- Added in 12.2(4)T3

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

81

EVENT-MIB & EXPRESSION-MIB

Cisco.com

- Feedback?

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

82

SPECIFIC SCENARIOS



**MPLS/VPN SYSLOG & SNMP NOTIFICATION,
SAA & SNMP,
NBAR,
ETC...**

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

83

Disabling the Logging of Some Interfaces

Cisco.com

- Limit the amount of output that is logged from the group-async interface and ISDN D channels.
- Occurs regularly on access interfaces. Dialer interfaces going up and down is normal behavior and does not indicate a problem.

```
Router(config)# interface Group-Async 1
Router(config-if)# no logging event link-status
Router(config-if)# no snmp trap link-status

Router(config)# snmp ifmib trap throttle
```

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

84

Monitoring Service Service Assurance Agent

Cisco.com

- Active probing from the router
- THE feature to monitor services
- Wide measurement capabilities (UDP, TCP, ICMP, delay, jitter,...)
- Accessible using CLI and SNMP
- Proactive notification via SNMP traps


NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

85

Monitoring Service Service Assurance Agent

Cisco.com



NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

86

Monitoring Service VOIP Example

Cisco.com

```
rtr 11 type jitter dest-ipaddr 198.198.198.1
  dest-port 3000 codec G711alaw
  tag jitter-with-voice-scores

rtr reaction-configuration 11 react connectionLoss
  threshold-type immediate action-type trapOnly
rtr reaction-configuration 11 react jitterAvg
  threshold-value 1 1 action-type trapOnly
  threshold-type immediate
rtr reaction-configuration 11 react MOS threshold-
  value 390 220 action-type trapOnly
  threshold-type immediate

rtr logging traps

rtr schedule 11 start-time now

snmp-server host 10.48.71.94 version 2c public
snmp-server enable traps syslog
```

Available in 12.3(7)T


NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

87

SNMP VRF Aware (VRF Aware Polling)

Cisco.com



```
Router(config)# snmp-server host <host-address>
  <community-string> [vrf vrf-name]
```

- Allow a certain community name to come from a specific VRF only
- Note: not all MIBs are VRF aware


NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

88

VRF Aware Notifications

Cisco.com



- Notifications sent to a receiver in a VRF

```
Router(config)#snmp-server host  
                  <receiver-ip-addr> vrf yellow public
```


NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

89

VRF Aware Syslog (Under Development)

Cisco.com



- Syslog messages sent to a server in a VRF

```
Router(config)#logging host vrf <yellow>  
                  <syslog-ip-address>
```

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

90

NBAR-MIB

Cisco.com

- **Network Based Application Recognition**
- **Accounting (bytes, packets, rate) per protocol discovered by protocol-discovery**
 - "show ip nbar protocol-discovery"
- **Real Time thresholding with traps:**
 - redefined the event/alarm trap from RMON
 - Awareness of what NBAR does to the CPU

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

91

EMBEDDED EVENT MANAGER



THE NEWEST IN CISCO IOS

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

92

Embedded Event Manager (EEM) 1.0 Overview

Cisco.com

- In-box monitoring of different components of the system via a set of software agents (event detectors)
- Event detectors (ED) notify EEM when an event of interest occurs
- Advantages:
 - Local programmable actions, triggered by specific events
- Introduced in 12.0(26)S, 12.3(4)T


NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

93

Embedded Event Manager (EEM) The Framework

Cisco.com



NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

94

Embedded Event Manager (EEM) Overview

Cisco.com

- **Event Detectors**
 - EEM 1.0 SNMP & Syslog Event Detectors
 - EEM 2.0 will deliver: other Event Detectors, ability to invoke TCL scripts
 - **Current Actions**
 - Log a prioritized message to Syslog
 - Send an event to CNS Bus for upstream processing by a Cisco CNS device
 - Reload the entire system (*)
 - Switch-over to Standby Route Processor in a 'dual RP' configuration (*)
- (*) EEM 1.0 originally developed to support IOS High Availability, even if applicable to more general situation

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

95

Embedded Event Manager (EEM) 1.0 Example 1

Cisco.com

- Applets are groupings of an 'event specification' and a policy action that is taken when the specified event occurs

```
event manager applet fe0trans
  event syslog pattern .*UPDOWN.*FastEthernet0/0.*
  action 1.0 syslog priority emergency msg "New
  syslog $_syslog_msg"
  action 2.0 cns-event CNS event data
```

- **Example:** causes an emergency level syslog message and a CNS event to be sent when a log message indicates that the FastEthernet0/0 port changed state to either up or down

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

96

Embedded Event Manager (EEM) 1.0 Example 2

Cisco.com

ciscoMemoryPoolFree

```
event manager applet memory-demo
event snmp oid 1.3.6.1.4.1.9.9.48.1.1.1.6.1 get-
type exact entry-op lt entry-val 5120000 poll-
interval 10
action 1.0 syslog priority critical msg "Memory exh
austed; current available memory is $_snmp_oid_val
bytes"
action 2.0 force-switchover
```

- **Example:** The applet will run when the available memory on the primary RP falls below the specified threshold of 5120000 bytes

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

97

Embedded Event Manager (EEM) 1.0 Environment Variables

Cisco.com

- These environment variables can be used in 'msg' text
- Will be replaced with the relevant text
- Environment Variable Available for All Events
 - `$_event_type` The event type that triggered the event
 - `$_event_pub_time` The time at which the event type was published
- Environment Variable Available for SNMP Events
 - `$_snmp_oid` The SNMP object OID that caused the event to be published
 - `$_snmp_oid_val` The SNMP object ID value when the event was published
- Environment Variable Available for Syslog Events
 - `$_syslog_msg` The syslog message that caused the event to be published

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

98

Embedded Event Manager (EEM) 1.0 Advantages

Cisco.com

- **SNMP monitoring AND syslog as event detectors**
- **More flexible threshold than RMON Event/Alarm**
 - Greater than, greater or equal, ...
 - Like the EVENT-MIB
- **Can customize the notification**
 - Some environment variables
 - Redefined syslog priority level
- **Control is in the customer's hands: full customization**
- **Better hysteresis mechanism control thanks to the exit options**

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

99

EMBEDDED SYSLOG MANAGER



THE NEWEST IN CISCO IOS

NMS-3011
9593_04_2004_c2


© 2004 Cisco Systems, Inc. All rights reserved.

100

Embedded Syslog Manager (ESM)

Cisco.com

- Post-process Syslog messages with selected ESM filters (Proactive Rules-based analysis)
- User definable scripting (TCL)
- New message queue in *Parallel* with classic Syslog
- Available in images with TCL 8.3.4, in 12.3(2)T



NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

101

Embedded Syslog Manager (ESM) Configuration Example

Cisco.com

```
Router(config)# logging filter <URL> [<position>]
                    [args <argstring>]
```

“URL”, the location of the TCL script (Cisco IOS, flash, web, tftp server)

“Position”, ordering of filters when multiple exist

“Args”, arguments to the Tcl scrip

```
Router(config)# logging console filtered
Router(config)# logging host <x.x.x.x> filtered [stream_id]
```

The stream_ID is added by the script, for event routing

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

102

Embedded Syslog Manager (ESM) Example 1

Cisco.com

- **Severity Escalation:** Messages that Cisco deemed low priority may be very important to some customers
- **Example:** escalate syslog messages that contain the word 'CONFIG_I' to severity level of 4 (they are by default level 5)

```
Router(config)# logging filter slot0:/escalate.tcl CONFIG_I 4
```

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

103

Embedded Syslog Manager (ESM) Example 1

Cisco.com

```
# Embedded Syslog Manager, Severity Escalation Module
# =====
# Usage: Set CLI Args to "mnemonic new_severity"
# Namespace: global
# Check for null message

if { [string length $::orig_msg] == 0 } {
    return ""
}

if { [info exists ::cli_args] } {
    set args [split $::cli_args]
    if { [ string compare -nocase [lindex $args 0] $::mnemonic ] == 0 } {
        set ::severity [lindex $args 1]
        set sev_index [ string first [lindex $args 0] $::orig_msg ]
        if { $sev_index >= 2 } {
            incr sev_index -2
            return [string replace $::orig_msg $sev_index $sev_index \
                [lindex $args 1]]
        }
    }
}

return $::orig_msg
```

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

104

Embedded Syslog Manager (ESM) Example 2

Cisco.com

- **Message Correlation** – To help reduce the volume of messages when certain well-known network events occur, ESM can correlate local events, and summarize them.
- **Example: link-flapping messages can be counted over a period of time, and a single syslog message sent**

```
00:22:11: %LINK-3-UPDOWN: serial1 flapping  
(4 changes to up/4 changes to down between 00:21:09 and 00:22:11)
```

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

105

Embedded Syslog Manager (ESM) Other Examples

Cisco.com

- **Message Routing:** customers may wish to categorize messages using criteria other than facility or severity
Example: Send all Spanning tree messages to a separate syslog server
- **SMTP-based email alerts:** capability for notifications using TCP to external servers, such as TCP-based syslog collectors or Simple Mail Transfer Protocol (SMTP) servers
Example: “configuration changes” sent to administrators via an email message
- **Your example ...** The possibilities are never-ending!

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

106

SUMMARY



Principles of Fault Management in Cisco Devices

Cisco.com

- **Quick fault detections is strategic to Network Management**
- **Systematic network element polling doesn't always scale**
- **Let's tune the right fault management events from the network elements themselves**
- **We investigated a few ways**
- **Then potentially event-based polling ...**

Other Network Management Sessions

Cisco.com

- NMS-1N01 - Introduction to Network Management – Networkers On-Line
- NMS-1N02 - Introduction to SNMP and MIBs – Networkers On-Line
- NMS-1N03 - Accurate Time Synchronization – Networkers On-Line
- NMS-1N04 - Introduction to Service Assurance Agent – Networkers On-Line
- NMS-1N41 - Introduction to Performance Management – Networkers On-Line
- NMS-1011 - Principles of Fault Management
- NMS-1101 - Understanding DNS and DHCP
- NMS-2001 - Network Troubleshooting Tools and Techniques
- NMS-2021 - Large Scale Deployments of CiscoWorks
- NMS-2031 - Traffic Accounting Scenarios
- NMS-2032 - NetFlow for Accounting, Analysis and Attack
- NMS-2042 - Performance Measurement with Cisco Devices
- NMS-2051 - Securely Managing Your Network
- NMS-2102 - Deploying and Troubleshooting NAT
- NMS-2101 - DNS Deployment and Operation
- NMS-4012 - MPLS Embedded Management Tools
- NMS-4043 - Advanced Service Assurance Agent
- NMS-2T00 - Network Management Best Practices - Techtorial

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

109

Complete Your Online Session Evaluation!

Cisco.com


- WHAT:** Complete an online session evaluation and your name will be entered into a daily drawing
- WHY:** Win fabulous prizes! Give us your feedback!
- WHERE:** Go to the Internet stations located throughout the Convention Center
- HOW:** Winners will be posted on the onsite Networkers Website; four winners per day

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

110

Q and A




NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

111

CISCO SYSTEMS



NMS-3011
9593_04_2004_c2

© 2003 Cisco Systems, Inc. All rights reserved.

112

Appendix



NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

113

Fault Management Which MIB variables to monitor?

Cisco.com

| Interface | Object Descr | OID | Poll Int | Threshold |
|-----------------|--|---------------------------|----------|-----------|
| loclfResets | number of times the interface internally reset | .1.3.6.1.4.1.9.2.2.1.1.17 | 15 min | |
| ifOperStatus | The current operational state of the interface. The testing(3) state indicates that no operational packets can be passed | .1.3.6.1.2.1.2.2.1.8 | 5 min | != 1 |
| loclfCarTrans | Number of times interface saw the carrier signal transition | .1.3.6.1.4.1.9.2.2.1.1.21 | 15 min | |
| loclfCollisions | number of output collisions detected on this interface | 1.3.6.1.4.1.9.2.2.1.1.25 | 15 min | |
| loclfInCRC | number of input packets which had cyclic redundancy checksum errors | .1.3.6.1.4.1.9.2.2.1.1.12 | 15 min | |

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

114

Fault Management Which MIB variables to monitor?

Cisco.com

| Interface | Object Descr | OID | Poll Int | Threshold |
|-----------------------|--|---------------------------|----------|---------------------------|
| ifOutOctets | The total number of octets transmitted out of the interface, including framing characters | .1.3.6.1.2.1.2.2.1.16 | 30 min | |
| loclnInputQueueDrops | The number of packets dropped because the input queue was full | .1.3.6.1.4.1.9.2.2.1.1.26 | 30 min | > 1% of incoming traffic |
| loclfOutputQueueDrops | The number of packets dropped because the output queue was full | .1.3.6.1.4.1.9.2.2.1.1.27 | 30 min | > 10% of outgoing traffic |
| ifInDiscards | The number of inbound packets which were chosen to be discarded even though no errors had been detected to prevent their being deliverable to a higher-layer protocol. One possible reason for discarding such a packet could be to free up buffer space | .1.3.6.1.2.1.2.2.1.13 | 30 min | |

9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

110

Fault Management Which MIB variables to monitor?

Cisco.com

| Ethernet | Object Descr | OID | Poll Int | Threshold |
|------------------------------------|---|--------------------------|----------|------------------------|
| dot3StatsCarrierSenseErrors | Number of times that the carrier sense condition was lost or never asserted when attempting to transmit a frame | .1.3.6.1.2.1.10.7.2.1.11 | 15 min | >= 2 |
| dot3StatsDeferredTransmissions | A count of frames for which the first transmission attempt on a particular interface is delayed because the medium is busy. | .1.3.6.1.2.1.10.7.2.1.7 | 15 min | |
| dot3StatsExcessiveCollisions | Count of frames for which transmission failed because of excessive collisions | .1.3.6.1.2.1.10.7.2.1.9 | 15 min | 0.2% of traffic |
| dot3StatsInternalMacReceiveErrors | Count of frames for which reception fails because of an internal MAC sublayer receive error. | .1.3.6.1.2.1.10.7.2.1.16 | 15 min | 1% of incoming traffic |
| dot3StatsInternalMacTransmitErrors | Count of frames for which transmission fails because of an internal MAC sublayer transmit error. | .1.3.6.1.2.1.10.7.2.1.10 | 15 min | 1% of outgoing traffic |

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

116

Fault Management Which MIB variables to monitor?

Cisco.com

| Memory | Object Descr | OID | Poll Int | Threshold |
|-----------------------------|--|-----------------------------|----------|-----------|
| bufferFail | number of buffer allocation failures | .1.3.6.1.4.1.9.2.1.46 | 15 min | |
| bufferNoMem | number of buffer create failures due to no free memory | .1.3.6.1.4.1.9.2.1.47 | 15 min | >= 1 |
| ciscoMemoryPool Free | number of bytes from the memory pool that are currently unused on the managed device | 1.3.6.1.4.1.9.9.48.1.1.1.6 | 30 min | |
| ciscoMemoryPool LargestFree | largest number of contiguous bytes from the memory pool currently unused | .1.3.6.1.4.1.9.9.48.1.1.1.7 | 30 min | |
| ciscoMemoryPool Used | number of bytes from the memory pool that are currently in use | .1.3.6.1.4.1.9.9.48.1.1.1.5 | 30 min | |
| ciscoMemoryPool Free | number of bytes from the memory pool that are currently unused on the managed device | .1.3.6.1.4.1.9.9.48.1.1.1.6 | 15 min | |

9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

117

Fault Management Which MIB variables to monitor?

Cisco.com

| Environment | Object Descr | OID | Poll Int | Threshold |
|------------------------------|---|-----------------------------|----------|-----------|
| ciscoEnvMonFan State | The current state of the fan being instrumented. | .1.3.6.1.4.1.9.9.13.1.4.1.3 | 15 min | >= 1 |
| ciscoEnvMonSupply State | The current state of the power supply being instrumented. | .1.3.6.1.4.1.9.9.13.1.5.1.3 | 15 min | >= 1 |
| ciscoEnvMon TemperatureState | The current state of the testpoint being instrumented. | .1.3.6.1.4.1.9.9.13.1.3.1.6 | 15 min | != 1 |
| ciscoEnvMon VoltageState | The current state of the testpoint being instrumented. | .1.3.6.1.4.1.9.9.13.1.2.1.7 | 15 min | != 1 |

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

118

Fault Management

Which MIB variables to monitor?

Cisco.com

Miscellaneous

| | Object Descr | OID | Poll Int | Threshold |
|-----------------|---|--------------------------------|----------|-----------|
| cpmCPUTotal5min | Overall CPU busy percentage in the last 5 min period This object deprecates the avgBusy5 object from the OLD-CISCO-SYSTEM-MIB | .1.3.6.1.4.1.9.9.109.1.1.1.1.5 | 5 min | |
| sysUpTime | system uptime in 1/100ths of seconds | .1.3.6.1.2.1.1.3 | 5 min | < 30000 |

NMS-3011
9593_04_2004_c2

© 2004 Cisco Systems, Inc. All rights reserved.

119