



Codec C90



Codec C60



Codec C40



Codec C20



Quick Set C20/C20 Plus



**TC5**



The next generation Cisco TelePresence System team collaboration solution.

The Profile, the MX200/300, the Quick Set C20 and Quick Set C20 Plus, as well as solutions based on the Codec C Series, bring colleagues face-to-face at the touch of a button through a user-friendly touch screen interface.

Easily share presentations and multimedia to spark ideas and generate better discussions.

## Cisco TelePresence Systems Profile Series/Codec C Series/Quick Set C20/MX200/MX300

# Use with Cisco TelePresence Touch



Profile 65" Dual



Profile 65"



Profile 52" Dual



Profile 52"



Profile 42"



MX200  
MX300

# What's in this guide?

The top menu bar and the entries in the Table of Contents are all hyperlinks. Just click on them to go to the topic.

We recommend that you visit the Cisco web site regularly for updated versions of this guide. Go to: <http://www.cisco.com>

This document describes the use of the Cisco TelePresence Touch with the Cisco TelePresence System Profile Series, Codec C Series, MX200 and Quick Set C20.

For a description of the use of these video systems with the remote control Cisco TRC5 (not applicable to the MX200/MX300), we refer to the TC5 User Guide, Remote control version, which is available separately for download.

## Getting started

The basics of the Touch Controller .....	4
Selfview and camera control .....	5
Adding a near end camera preset .....	6
Changing an existing near end camera preset .....	7
Removing an existing near end camera preset .....	8
Camera whitebalance, exposure, and backlight compensation .....	8
Sound matters .....	9
Receiving calls .....	9
Ring tones and sounds .....	9
Do not disturb .....	9

## Placing calls

Calling someone by entering the name, address or number .....	11
Searching and calling an entry in any of the lists ....	12
Calling an entry in one of the lists.....	13
Calling more than one.....	14

## Using Favorites, Directory and History

History.....	16
Searching.....	16
Directory .....	16
Favorites .....	16

## In-call features

Features in a call—an overview .....	18
Calling participants to add them to an ongoing call (Multisite) .....	19
Calling participants to add them to an ongoing call (Multiway™).....	20
Receiving another incoming call .....	21
Putting Far end on hold and back again .....	21
Putting a member of a group on hold and back again.....	22
Putting an entire group on hold and back again ..	22
Transferring an ongoing call.....	23

Transferring a member of an ongoing conference ...	24
Near end camera control .....	25
Far end camera control (in a call only) .....	25
Using Touch Tones (DTMF) in a call.....	25
Near end camera presets .....	25
Sharing contents—conducting presentations .....	26
Layout control .....	27

## Scheduled meetings

Looking into the List of Meetings.....	29
Joining a Meeting .....	30
Joining while already in a call .....	30
Parallel meetings .....	30
Extending an ongoing meeting .....	30

## The Settings

Gaining access to the Settings .....	32
System Information .....	33
Call Status.....	34
Language .....	35
Camera Control & Settings .....	36
Ringtone & Sound Settings.....	37
Main source selection.....	38
Administrator settings—Date, Time & Location.....	39
Administrator settings—Call settings .....	40
Administrator settings—IP settings for the codec ..	41
Administrator settings—IP settings for the Touch controller .....	42
Administrator settings—Pairing.....	43
Administrator settings—H.323 settings .....	44
Administrator settings—SIP settings.....	45
Administrator settings—Provisioning .....	46
Administrator settings—Multiway Settings.....	47
Administrator settings—EMC Resilience mode.....	48
Administrator settings—Reset.....	49
Administrator settings—Restart system.....	50



# Chapter 1

## Getting started

## The basics of the Touch Controller



## Basic operating principles



Tap the touch screen to wake up the system, if needed



Tap a button to activate its function



Scroll in lists as outlined

## Selfview and camera control



You may want to check how you appear on the screen. To do this, tap **Selfview** as outlined...



If this reveals a need for camera adjustments, then tap **Camera control** as outlined.



Tap as outlined to expand the menu, if needed.



Use + and - to adjust the zoom and the arrow keys to adjust the camera's angle.

You may also define or edit camera presets in this menu, see ► “Adding a near end camera preset” on page 6 for details.

Entering **Camera Control** will also cause the system to show selfview, so if you know that camera adjustments are needed, you do not have to activate selfview first.



Tap as outlined, or anywhere outside the menu to exit **Camera control**.



## Adding a near end camera preset

Use Camera presets to quickly change your camera's pan, tilt and zoom—for example to change between participants and whiteboard presentation.



Tap **Camera control** as shown...



... then tap as outlined to expand the menu



Using the expanded menu, adjust camera pan, tilt and zoom, as required.



If needed, scroll down to show **Add new Preset** (1) and then tap it (2).



Key in a name for the new preset.



Tap **Save** (1) to put changes into effect, then tap anywhere outside the menu (2) to exit.

## Changing an existing near end camera preset

Changes to any of the Camera presets can be made any time.



Tap **Camera control** as shown...



... then tap as outlined to expand the menu



Using the expanded menu, adjust camera pan, tilt and zoom, as required.



If needed, scroll to show the camera preset to be updated (1) and then tap > of that preset to expand the menu (2).



Tap **Update to current position**.



Tap anywhere outside the menu to exit.

## Removing an existing near end camera preset



Tap **Camera control** as shown...



If needed, scroll to show the camera preset to be removed (1) and then tap > of that preset to expand the menu (2).




Tap **Remove**.

## Camera whitebalance, exposure, and backlight compensation


Backlight compensation compensates for light behind you.



Tap **More** (1) followed by **Settings** (2), as shown...



Scroll down to **Camera control and settings**. Tap this field.



Make your adjustments. Tap **Exit** to put changes into effect.



## Sound matters

You may deactivate the microphone for privacy reasons, if needed (❶).

Tap as outlined (❷) to adjust the sound volume.



## Ring tones and sounds

To set ringtones and sound, tap More (❶) followed by Settings (❷). Then tap **Ringtone & Sound Settings** (❸).




Set **Keytones** to **On** or **Off**, the **Ringtone volume** and select the ringtone of your choice. Tap **Exit** to go back.

## Do not disturb

When set to **Do Not Disturb**, ringtones are muted and call attempts made by others to reach you will appear as missed calls.

You may, however, place calls as much as you like. To activate Do Not Disturb, press the **Available** icon as outlined. Press again to deactivate.



You may also hide the Do Not Disturb poster by tapping **Hide**. This will not deactivate the Do Not Disturb, as such.

## Receiving calls

When someone calls you, the below display will appear. Tap **ACCEPT** to take the call or **DECLINE** to reject it.






## Chapter 2

### Placing calls



## Calling someone by entering the name, address or number





This will produce the virtual keyboard.

Tap **123** to switch to the numerical keyboard (2). To switch back to QWERTY keyboard tap **ABC**.



Key in the name, number or address (3)



# Searching and calling an entry in any of the lists



## Calling an entry in one of the lists



**Favorites.** The list of favorites is your own shortlist of people and places you frequently call or otherwise want to have easy access to.

**Directory.** The directory serves as your corporate phone book. This directory cannot be edited by you. You may, however, copy entries to your list of favorites and edit them there.

**History** lists the received, placed and missed calls since the last time the list was cleared.

**Keypad.** Tap the keypad icon to produce the keypad to enter a number or URI.



## Calling more than one

Calling more than one is an optional feature that may, or may not, be present on your system. If in doubt, ask your System Administrator.



If your system permits conferencing, you may set up a list of several participants and then call them all in one go. Ask your system administrator, if in doubt.

Enter a name, number or address, or pick an entry from the **Directory**, the list of **Favorites**, or from the **History**.



Then tap **Add Participant**, as outlined, to add the entry to the list of participants to be called.



Locate the next to be called in the same way as the first.



Tap **Add participant** again. The maximum number of participants permitted will depend on your system configuration. Ask your system administrator, if in doubt.



When all have been added (two in this example), tap **CALL** to call them all.



Tap **END** to terminate the entire conference. To disconnect just one of the participants, tap the participant's name along the bottom line and then tap **END**.



## Chapter 3

### Using Favorites, Directory and History

## History

**History** lists the received, placed and missed calls since the last time the list was cleared.


Tap **History** to produce the list ...

... then tap an entry.



You will now be able to:

- Call the entry by tapping **Start**.
- Add the entry to an ongoing call (optional feature).
- Add the entry to **Favorites**.
- Edit the entry information and then place the call.
- Change the call rate settings.
- Remove the entry from the list.
- Clear the entire list. To do this, scroll as outlined beyond what appears to be the top of the list. A **Clear List** button will then appear as outlined.



## Directory

The **Directory** serves as your corporate phone book. This directory cannot be edited by you. You may, however, copy entries to your list of favorites and edit them there.

Tap **Contacts** (if needed) and then tap **Directory**. The directory is typically organized as folders.



Tap a folder (1) to show its contents, scroll (2) if needed to locate a folder or an entry within a folder.

Once located, tap the entry to call, edit or add to your list of favorites in the same way as with the history list.

It may happen that an entry copied from the directory to the list of favorites later is updated in the directory. This update will not be reflected in your list of favorites—you must then manually update the entry in the list of favorites.

## Favorites

**Favorites** is your own shortlist of contacts you frequently call or otherwise want to have easy access to.

**Adding to Favorites.** To add someone to the list of favorites, locate the entry in **Directory** or **History** and tap it (1). This will produce a dialog box which allows you to tap **Add to Favorites** (2).



You may now edit the entry, if needed—just tap a field and the keyboard will be produced. Tap **Save** to put changes into effect..



**Favorites** should be considered as an editable directory and is used in the same way as **History**.

## Searching

You may search for entries (names, numbers or addresses). Searches will be conducted within all the folders, i.e. within the **Favorites**, the **Directory** and the **History**.

Tap in the **Search or Dial** field and key in the name, address or number. Matches will appear as you search.

Once located, tap the entry to call, edit or add to **Favorites**.



When searching within the corporate **Directory**, the search will apply to the current directory folder and its subfolders only. To go one level up, tap **Back**. To make the search apply to the entire corporate directory, do not enter (tap) any folder before the search is commenced.



## Chapter 4

### In-call features

## Features in a call—an overview

**Do not disturb** on or off

**Camera control** lets you pan and zoom your own camera as well as define and use camera presets

**Selfview** on or off

The chosen layout of the screen is shown here (Multisite only)

Change the layout of images on the screen (MultiSite only).

Add participants to create a conference (optional feature)

Any meetings scheduled by CUCM can be shown by tapping this

Share contents (PC, video, doc. camera etc)

Tap here in the white field to control the far end camera of this participant and to exclude this participant from the call

Tap here to gain access to **Layout** and **Settings**

This participant's microphone is muted

Tap here in the white field to control the far end camera of this participant and to exclude this participant from the call

Gain access to the **Settings**

Use **Touch Tones** (DTMF) e.g. for extensions and pin codes to conferences

End the ongoing call

Put any of the participants on hold





## Calling participants to add them to an ongoing call (Multisite)


Calling more than one using Multisite is an optional feature that may, or may not, be present on your system. If in doubt, ask your System Administrator.




While in a call you may add participants provided that your system permits to do so. Tap **Add** ...



... then select, in the usual way, whom to add to the ongoing call.




Once you have selected someone, tap **ADD TO MEETING** to include this participant in the meeting.



Repeat the procedure to include more participants, if needed.

The maximum number of participants possible will depend on the system used, consult your System Administrator, if in doubt.

Even voice-only participants may be added!



Tap **END** to terminate the entire conference. To disconnect just one of the participants, tap the participant's name along the bottom line and then tap **END**.

## Calling participants to add them to an ongoing call (Multiway™)

Calling more than one using Multiway™ is an optional feature that may, or may not, be present on your system. If in doubt, ask your System Administrator.




While in a call you may add participants provided that your system permits to do so. Tap **Hold** to put the ongoing call on hold...



... then select, in the usual way, whom to add to the ongoing call.



Once you have selected someone, tap **START** to begin including this participant in the meeting.




The call will now be transferred to the Multiway™ server and handled from there. This may take a little while...



When everything is ready the **Join** button will appear. Tap this and the bottom line will change to read **Meeting**. This may take a little while.


Since the calls have been transferred to the Multiway server you are still in a point-to-point call, but now with the Multiway server as the far end. This applies to all the other participants as well.



Tap **END** to disconnect yourself. The other participants must do the same to disconnect themselves from the Multiway server.

## Receiving another incoming call

This is an optional feature that may, or may not, be present on your system. If in doubt, ask your System Administrator.



Assume that you are in a call. This call can be a point-to-point call or a multisite call. Furthermore assume that another person calls you.

You may now:

- Tap **ACCEPT & JOIN** to include the incoming call in the conference.
- Tap **DECLINE** to carry on as you did.
- Tap **Accept & Hold Current** to accept the call, while at the same time put the current call on hold.
- Tap **Accept & End Current** to accept the call, while at the same time end the current call.
- Tap **Ignore** to carry on as you did, without sending decline signal to the other end.

Even an entire group can be put on hold, so the above options apply equally well to point-to-point calls as to multisite calls.

## Putting Far end on hold and back again

This is an optional feature that may, or may not, be present on your system. If in doubt, ask your System Administrator.



Tap **Hold**. The far end will be put on hold immediately.

To enable resume, tap the name on the bottom line.

Tap **RESUME**.  
To cancel the action, tap anywhere outside the dialog box.

## Putting a member of a group on hold and back again

This is an optional feature that may, or may not, be present on your system. If in doubt, ask your System Administrator.

**1**

Assume that you are in a call with more than one. Tap the member you intend to put on hold.

**2**

When you now tap **Hold**, the selected participant will be put on hold, but none of the others.

**3**

Tap **SWAP** to resume, while at the same time putting the other(s) on hold, or tap **Join** to restore the call with all participants. To cancel this action, just tap somewhere outside the dialog box.

## Putting an entire group on hold and back again

This is an optional feature that may, or may not, be present on your system. If in doubt, ask your System Administrator.

**1**

Assume that you are in a call with more than one. To put the entire group on hold, just tap **Hold**.

**2**

In order to resume the call with the group, tap the **Group on hold** field, as outlined.

**3**

Then tap **Resume**. To cancel this action, just tap somewhere outside the dialog box.

## Transferring an ongoing call


This is an optional feature that may, or may not, be present on your system. If in doubt, ask your System Administrator.

1




In an ongoing call, tap the name along the bottom line, as outlined...

2



... then tap **Transfer**...

3



... followed by **Contacts** ...

4



Select from the lists whom to transfer to in the usual way. You may also key in the name, number or address.

5





Tap **TRANSFER TO** to put your intention into effect.





## Transferring a member of an ongoing conference

This is an optional feature that may, or may not, be present on your system. If in doubt, ask your System Administrator.

- 

Tap the one to be transferred...
- 

... then tap **Transfer**...
- 

... followed by **Contacts** ...
- 

Select from the lists whom to transfer to in the usual way. You may also key in the name, number or address.
- 

Tap **TRANSFER TO** to put your intention into effect.

## Near end camera control



## Near end camera presets



## Far end camera control (in a call only)

This works in point-to-point as well as in multisite calls, but only on systems with remotely controllable cameras.



## Using Touch Tones (DTMF) in a call

Sometimes you may be urged to enter touch tones (DTMF) during a call, typically to reach extensions or to provide a pin code.



## Sharing contents—conducting presentations

You may alter the screen layout when sharing contents—see the next page for more. You must be in a call to be allowed to do layout changes.



Make sure your presentation source is connected to the video system before you start.



## Layout control

This applies to all multisite calls and to point-to-point calls having a presentation running.




You may alter the screen layout when you are in a call.  
To do this start by tapping **More** ...



... then tap **Layout** ...



... and finally select your preferred layout.



Takes you one menu level back

The one who speaks get the full screen. Nothing else is shown.

The one who speaks gets the main frame. The others are shown as PiP (Picture in Picture).

The one who speaks gets the main frame. The others are shown as images below the main frame.

All participants are shown in frames of identical sizes.

When a presentation is included in a call, all participants will be shown **above** the presentation, instead of below. This will provide a better feeling of eye contact.

Full screen will show the presentation only.

Observe that changes to this set of layouts made by the TC-console utility are not supported and will be ignored when using TC5 devices together with Touch.

## **Chapter 5**

# Scheduled meetings



## Looking into the List of Meetings

This is an optional feature.

1



Tap **Meetings** to display the list of upcoming meetings on this endpoint...

2



The List of Meetings contains 14 days of scheduled meetings. The list is sorted using Grouping headers. The main grouping category is by day (eg: Today, Tomorrow, Thursday, then WEDNESDAY, October 26, 2011).

3



On your video system a Meeting reminder will appear at the top of the List of Meetings once it is possible to join a meeting. Exactly when that is will depend on the Start time buffer setting. Default buffer setting is 10 minutes.

4



If you tap an item in the list (1) then more information will become available. When the **JOIN MEETING** button is gray (as shown here) you are outside the time window permitting you to join the meeting. Tap as outlined (2) to expand the dialog box to get more information.

5



The dialog box will also state when it is possible to join the meeting. Tap as outlined to collapse the dialog box.

When a scheduled meeting appears as *Private meeting* it will contain information about the organizer only. There will be no title, no expandable meeting outline as well as no dial-in information.


## Joining a Meeting

All features shown on this page are optional.




When a scheduled meeting is about to start a reminder will appear. To join the meeting tap **JOIN MEETING** (1), as outlined. This connects you to the “dial-in” address.

The meeting title field is expandable—tap as shown (2).




The expanded field contains meeting details and dial-in information. Depending on the amount of information it may be scrollable.



Besides joining the meeting, you may tap **Snooze** to temporarily hide the Reminder for 5 minutes or **Dismiss** to close the Reminder.


## Joining while already in a call



If you already are in a call, the **JOIN MEETING** button will change to **JOIN & END CURRENT**.


- Tap the **JOIN & END CURRENT** button to join the new meeting, ending the current.
- Tap **Join & Hold Current** to temporarily join the meeting.
- Tap **Snooze** to temporarily hide the Reminder for 5 minutes.
- Tap **Dismiss** to go on with your current meeting.

## Parallel meetings



When Parallel Meetings occur (two or more meetings taking place simultaneously), the reminder will be displayed in context of the meeting list, displaying all upcoming meetings. Choose which meeting to join and then join the selected meeting.

## Extending an ongoing meeting



Scheduled meetings have a fixed start and end time. You may want to extend an ongoing meeting. This will be accepted by the system provided that no other meeting is scheduled for the video system during the period of extension.

If an extension is sustainable, the **Meeting will end** notification will include an **Extend** and a **Dismiss** option.

- To extend a meeting, tap the **Extend** button.


The video endpoints whose use is described in this manual can be configured via the touch screen controller or via its web interface. For full access to all configurable parameters the web interface must be used—the Touch Controller provides access to a limited set of parameters only.

## **Chapter 6**

# The Settings

## Gaining access to the Settings

Access the Settings as follows:



... and then you get access to the settings available. Observe that there are several other settings available, but these can be accessed from the web interface only. See the Administrator guide for your Cisco product. This guide is available for download separately.

## System Information

The **System Information** pane contains information on the system's software and hardware versions and connections, SIP and H.323 status etc.

Settings		Exit
System Information	System Name: Codec C90 Uptime: 23 hours, 23 minutes	
Call Status	<b>NETWORK</b> IPv4 Address: IPv6 Address: Touch Screen IPv4 Address: Touch Screen IPv6 Address:	
Language	<b>H323</b> Number: n/a ID: Gatekeeper: Status: Registered	
Camera Control & Settings	<b>SIP</b> Address: Proxy: Status: Registered. Unsecured. Not verified.	
Ringtone & Sound Settings	<b>SOFTWARE</b> Version: TC5.0.0.271089 Touch Screen: TT3.0.0.271089 Options Installed: MultiSite, NaturalPresenter, PremiumResolution	
Main Source Selection		
Administrator Settings		
Restart		



## Call Status

The **Call Status** pane provides information on call rate, encryption, as well as important video and audio parameters.

Settings

Exit

System Information

Call Status

Language

Camera Control & Settings

Ringtone & Sound Settings

Main Source Selection

Administrator Settings

Restart

Remote URI:

Call Rate:

n/a

Encryption Type:

n/a

Protocol:

n/a

Encryption Status:

n/a

VIDEO

Transmit

Presentation

Receive

Presentation

Protocol:

n/a

n/a

n/a

n/a

Resolution:

n/a

n/a

n/a

n/a

Frame Rate:

n/a

n/a

n/a

n/a

Channel Rate:

n/a

n/a

n/a

n/a

Total Packet Loss (%):

n/a

n/a

Current Packet Loss (%):

n/a

n/a

Jitter:

n/a

n/a

AUDIO

Transmit

Receive

Protocol:

n/a

n/a

Channel Rate:

n/a

n/a

Total Packet Loss (%):

n/a

n/a

Current Packet Loss (%):

n/a

n/a


Jitter:

n/a

n/a

## Language

The **Language** pane lets you specify the Touch interface menu language.




## Camera Control & Settings

The **Camera Control & Settings** pane lets you set the whitebalance and exposure of the camera. If you do not want to tweak this yourself, just leave it up to the system by selecting **Auto**.

**Backlight compensation** comes in handy when there is much light behind you. Without compensation you will easily appear very dark to the far end.

Note how the settings chosen are indicated. In the example shown, Backlight compensation is set to Off.




## Ringtone & Sound Settings

The **Ringtone & Sound Settings** pane lets you specify:

- **Keytones** on or off. When set to on you will hear a sound every time you tap a field on the Touch controller.
- **Ringtone volume**. How loud your ringtone shall sound.
- **Ringtone**. Select among several ringtones. You will hear a sample every time you tap a ringtone.

Note how the settings chosen are indicated. In the example shown, Keytones is set to Off.




The screenshot shows the 'Settings' application with the 'Ringtone & Sound Settings' pane selected. The interface includes a sidebar with a list of settings categories and a main area for configuring specific settings.

Settings	Keytones	Ringtone Volume (60)	Ringtone
System Information	OFF	0	Marbles
Call Status	ON	100	IceCrystals
Language			Polaris
Camera Control & Settings			Alert
Ringtone & Sound Settings			Discreet
Main Source Selection			Fantasy
Administrator Settings			Jazz
Restart			Nordic
			Echo
			Rhythmic

## Main source selection

Select what shall be the principal main source set as default. You may still choose another when working with the system, but this will be the default setting.






## Administrator settings—Date, Time & Location

The **Date, Time & Location** settings let you specify:

- 24h or 12h time format.
- Your preferred date format.
- Your preferred time zone.
- Whether date and time shall be set automatically or manually.

Note how the settings chosen are indicated. In the example shown, Time format is set to 24h.



The screenshot shows the 'Administrator Settings' window with the 'Date, Time & Location' tab selected. The settings are as follows:


Setting	Value
Time Format	24h (selected), 12h
Date Format	dd.mm.yy (selected), mm.dd.yy, yy.mm.dd
Time Zone	- GMT+01:00 (Amsterdam, Berlin, Bern, F) +
Date & Time Mode	Auto, Manual (selected)
NTP Mode	Auto (selected), Manual
NTP Server	10.81.254.131

## Administrator settings—Call settings

The **Call Settings** pane lets you specify:

- **Auto Answer** On or Off. If you set this to **On**, the system will respond automatically to incoming calls. Note that the microphone will NOT be muted. If risk of eavesdropping is an issue, you may want to set this setting to **Off**.
- **Auto Answer Delay**. Specify the time until your system actually responds to an incoming call.
- **Default Call Rate**. If your connection has limited capacity you may want to use this setting.
- **Max Incoming/Outgoing Bandwidth**. You may specify these separately. May come in handy if you are on an asymmetric connection.
- **Default Call Protocol**. Specify which protocol to use as default.

Note how the settings chosen are indicated. In the example shown, Auto Answer is set to Off.



The screenshot shows the 'Administrator Settings' window with a sidebar on the left and a main content area on the right. The sidebar has five items: 'Date, Time & Location', 'Call Settings' (highlighted in light blue), 'Network Settings' (with a right arrow), 'EMC Resilience Mode', and 'Reset'. The main content area has a title bar with 'Back' and 'Exit' buttons. It contains the following settings:

- Auto Answer**: Two buttons, 'OFF' (selected) and 'ON'.
- Auto Answer Delay**: Three buttons, '-' (disabled), '2s', and '+' (disabled).
- Call Rate**: A section header.
- Default Call Rate**: Three buttons, '-' (disabled), '768', and '+' (disabled).
- Max Incoming Bandwidth**: Three buttons, '-' (disabled), '6000', and '+' (disabled).
- Max Outgoing Bandwidth**: Three buttons, '-' (disabled), '6000', and '+' (disabled).
- Default Call Protocol**: Two buttons, 'H323' (selected) and 'Sip'.

## Administrator settings—IP settings for the codec

The **IP settings** pane for the Codec of the system lets you specify whether to use IPv4 or IPv6.

Back
Network Settings
Exit

IP & VLAN - Codec	IP Settings	
IP & VLAN - Touch	IP Version	<input type="radio"/> IPv4 <input checked="" type="radio"/> IPv6
Pairing	IP Assignment	<input checked="" type="radio"/> Auto <input type="radio"/> Manual
H323 Settings	IP Address	<input type="text" value=""/>
SIP Settings	Subnet Mask	<input type="text" value="255.255.255.0"/>
Provisioning	Gateway	<input type="text" value=""/>
Multiway	DNS Server 1	<input type="text" value=""/>
	DNS Server 2	<input type="text" value=""/>
	DNS Server 3	<input type="text" value=""/>
	DNS Domain Name	<input type="text" value=""/>

## Administrator settings—IP settings for the Touch controller

The **IP settings** pane for the Touch of the system lets you specify whether to use IPv4 (below left) or IPv6 (below right).

Back
Network Settings
Exit

IP & VLAN - Codec
IP & VLAN - Touch
Pairing
H323 Settings
SIP Settings
Provisioning
Multiway

### IP Settings

IP Version

IPv4 IPv6

IP Assignment

Auto Manual

IP Address

Subnet Mask

Gateway

### Link Settings

Voice VLAN Mode

Auto Manual Off

Voice VLAN ID

## Administrator settings—Pairing

The **Pairing** pane shows status on the pairing of the Codec and the Touch controller of your video system. It also provides you with the option of unpairing the two.

Back
Network Settings
Exit

IP & VLAN - Codec	Paired with:	Codec C90
IP & VLAN - Touch	Product:	Codec C90
Pairing	SIP URI:	
H323 Settings	Software:	TC5.0.0.271089
SIP Settings	IP address:	
Provisioning	Serial number:	
Multiway		

Unpair



## Administrator settings—H.323 settings

The **H.323 Settings** pane lets you specify:


- An **H.323 alias**.
- Your **H.323 id**.
- **Gatekeeper discovery (Manual or Automatic)**.
- The **Gatekeeper address** must be specified by you if discovery has been set to manual.
- **Authentication mode *On* or *Off***. If set to *On*, the video system will send **Login name** and Password to the Gatekeeper for authentication.

In addition there are:

- Two fields to enter **Login name** and **Password**. The alphanumeric keyboard will appear whenever needed.

Be sure to:

- Tap **Save** to put changes into effect.



The screenshot shows the 'H.323 Settings' pane within the 'Network Settings' section. The pane has a 'Back' button at the top left and an 'Exit' button at the top right. The settings are organized into two columns. The left column contains a list of settings: 'IP & VLAN - Codec', 'IP & VLAN - Touch', 'Pairing', 'H323 Settings' (highlighted), 'SIP Settings', 'Provisioning', and 'Multiway'. The right column contains the corresponding input fields and controls for each setting. The 'H323 Settings' section includes fields for 'H323 Number', 'H323 Id', 'Gatekeeper Discovery' (with 'Auto' and 'Manual' buttons), 'Gatekeeper Address', 'Authentication Mode' (with 'OFF' and 'ON' buttons), 'Login Name', and 'Password'.

Setting	Value/Control
IP & VLAN - Codec	H323 Number
IP & VLAN - Touch	H323 Id
Pairing	Gatekeeper Discovery (Auto, Manual)
H323 Settings	Gatekeeper Address
SIP Settings	Authentication Mode (OFF, ON)
Provisioning	Login Name
Multiway	Password


## Administrator settings—SIP settings

The **SIP settings** pane lets you specify:

- Your **URI**.
- The **Default transport layer**, this can be set to **TCP**, **UDP**, **TLS** or **Auto**.
- The **Proxy type** can be set to **Standard**, **Alcatel**, **Avaya**, **Cisco**, **Microsoft**, **Nortel**, **Experimental**, **Siemens**.  
The experimental setting is for testing purposes.
- **Outbound** is not used in this version.
- **Proxy discovery** can automatic or manual. In the case of manual the proxy address must be specified by you.
- **Login name** and **Password** is required by the VCS.

Be sure to:

- Tap **Save** to put settings into effect.




The screenshot shows the 'Network Settings' screen with a sidebar on the left and a main settings area on the right. The sidebar contains the following items: IP & VLAN - Codec, IP & VLAN - Touch, Pairing, H323 Settings, SIP Settings (highlighted in blue), Provisioning, Multiway, and an empty space. The main settings area has the following fields:

- URI**: A text input field containing a masked value.
- Default Transport**: A set of four buttons: TCP (selected), UDP, TLS, and Auto.
- Proxy Type**: A dropdown menu showing 'Cisco' with minus and plus icons on either side.
- Proxy Discovery**: Two buttons: Auto (selected) and Manual.
- Proxy Address**: A text input field containing a masked value.
- Login Name**: A text input field.
- Password**: A text input field.

## Administrator settings—Provisioning

Provisioning connects you to CUCM, Callway or VCS. When either of these were ordered and received from Cisco you should also have obtained the necessary information and codes. Just follow the wizard.



## Administrator settings—Multiway Settings

All endpoints using the TC series software offers Multiway as a means of creating video conferences with more than just two participants.

Note that a successful use of Multiway requires the presence of certain infrastructure products and installations. If in doubt, consult your Cisco partner.

This page of the Settings offers the ability enter the path to the Multiway enabled MCU. This is required to make the Multiway functionality work.


Back
Network Settings
Exit

IP & VLAN - Codec	<b>Multiway Settings</b>  Multiway Address <input type="text"/>
IP & VLAN - Touch	
Pairing	
H323 Settings	
SIP Settings	
Provisioning	
Multiway	

## Administrator settings—EMC Resilience mode

If the Touch controller is used in environments with considerable amounts of electromagnetic noise present, you may experience an appearance of false signals—as if someone tapped the Touch controller when nobody obviously did so.


To cope with this you may set the **EMC Resilience Mode** to **On**. You must then press and hold for a little while, rather than just tap, in order to make the system aware of your tapping. This will avoid the appearance of false signals.






## Administrator settings—Reset

You may want to reset your video system. Note that you will lose all configurations, the call history and your local list of contacts. Release keys and options installed will be retained.



## Administrator settings—Restart system

Use this to restart your system in an orderly manner.



THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Cisco and the Cisco Logo are trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and other countries. A listing of Cisco's trademarks can be found at [www.cisco.com/go/trademarks](http://www.cisco.com/go/trademarks). Third party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1005R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.



On our web site you will find an overview of the worldwide Cisco contacts.

Go to: <http://www.cisco.com/web/siteassets/contacts/index.html>

Corporate Headquarters  
Ciso Systems, Inc.  
170 West Tasman Dr.  
San Jose, CA 95134 USA