



Cisco Unified Communications Manager with Cisco Expressway (SIP Trunk)

Deployment Guide

Cisco Expressway X8.1
CUCM 8.6.x, 9.x

January 2015

Contents

Introduction	4
Deployment scenario	4
Configuring Unified CM for an Expressway trunk	5
Prerequisites	5
Configuration summary	5
Configuring the SIP Profile for Expressway	5
Configuring the region with an appropriate session bit rate for video calls	8
Configuring the SIP Profile for phone devices	8
Adding a phone device	9
Configuring the device directory number	9
Configuring the SIP Trunk security profile	9
Configuring the SIP Trunk device	10
Configuring the Cluster Fully Qualified Domain Name	14
Allowing numeric dialing from Cisco phones to Expressway	14
Allowing dialing to Expressway domain from Cisco phones	15
Checking the message size limit on Unified CM	16
Configuring Expressway routing	17
Prerequisites	17
Configuration summary	17
Ensuring a consistent URI format	17
Creating a neighbor zone for Unified CM	18
Creating a search rule to route calls to the Unified CM neighbor zone	20
Creating a transform that converts number@<IP address of cucm> to number@exp.domain	22
Creating a transform to convert other Unified CM-supplied domain variants to number@exp.domain	22
Connecting Expressway to Unified CM using TLS	24
Ensuring certificate trust between Unified CM and Expressway	24
Loading server and trust certificates on Expressway	24
Loading server and trust certificates on Unified CM	25
Setting the Cluster Security Mode to Mixed Mode	25
Configuring a SIP trunk security profile on Unified CM	26
Updating the Unified CM trunk to Expressway to use TLS	27
Updating the Expressway neighbor zone to Unified CM to use TLS	27
Verifying that the TLS connection is operational	28
Network of Expressways	28
Encrypted calls to endpoints registered to Unified CM	28
Appendix 1: Troubleshooting	29
Problems connecting Expressway-C local calls	29
Look at “Search history” to check the applied transforms	29
Look at call history to check how the call progressed	29
Check for errors	30
Tracing calls	30
Call failures with Cisco TelePresence Server	30
In-call problems	30
Calls clear down when a call transfer from a video phone on Unified CM transfers a call to Expressway	30
Poor video quality from Unified CM	30


Taking a trace on Unified CM using RTMT	31
Configure Unified CM to enable tracing	31
Installing RTMT – Real Time Monitoring Tool	31
Running RTMT	31
Taking a trace using RTMT	31
Call failures	32
TLS calls fail when Unified CM uses SRV trunk destinations	32
Encrypted call failures	32
Appendix 2: Connecting Unified CM to an Expressway cluster	33
Configuring the trunk to Expressway to specify the DNS SRV address for the Expressway cluster	33
Configuring the trunk to Expressway to specify a list of Expressway peers	34
Appendix 3: Connecting Expressway to a cluster of Unified CM nodes	35
Option 1: Using a single neighbor zone	35
Unified CM configuration	35
Expressway-C configuration	35
Option 2: Using a DNS zone	35
Unified CM configuration	35
DNS server configuration	36
Expressway-C configuration	36
Appendix 4: Additional information	38
IP address dialing	38
Characters allowed in SIP URIs	38
Document revision history	39

Introduction

This deployment guide provides guidelines on how to configure the Cisco Expressway (Expressway) version X8.1 and Cisco Unified Communications Manager (Unified CM) versions 8.6.x and 9.x to interwork via a SIP trunk.

Deployment scenario

A company already has Unified CM running their telephone/video system. They want to integrate this via a SIP trunk to an Expressway-C to provide further services such as integration with Jabber Guest servers or another Expressway managing integration to Microsoft Lync.



For the purposes of this example, the existing Unified CM system uses telephone (digit-only) numbers to specify who to call:

- Endpoints connected to the Unified CM are identified by 3xxx extension numbers.
- Endpoints and systems that are contacted via the Expressway-C are identified by 4xxx extension numbers.

Note that more complicated dial plans can also be supported, including alphanumeric dialing; they would require additional transforms/routing configuration.

Unified CM and the Expressway-C are connected together using a SIP trunk across an IP network; the Expressway-C domain is `exp.domain`. Calls sent to Unified CM will have the domain portion set to the Expressway domain; calls from Unified CM to Expressway will arrive with the domain portion set as `<FQDN of Expressway>:5060` for TCP and `<FQDN of Expressway>:5061` for TLS.

This guide specifies how to configure both the Unified CM and the Expressway-C so that SIP calls can be routed between each system. It does not describe how to configure the onward routing, such as additional neighbor zones from the Expressway to other systems (such as another Expressway, Jabber Guest servers or a Cisco VCS).

Initially the configuration use non-secure TCP connections, as this allows for easier troubleshooting. It then describes how to secure the video network over TLS.

Configuring Unified CM for an Expressway trunk

Prerequisites

Ensure that Unified CM contains a basic configuration and has already set up at least:

- System > Server
- System > Cisco Unified CM
- System > Cisco Unified CM Group
- System > Date / Time Group
- System > Presence Group
- System > Region Information
- System > Device Pool
- System > DHCP
- System > Location
- System > Physical location
- System > Enterprise parameters
- System > Licensing

Configuration summary

The configuration on Unified CM contains the following tasks:


- Configuring the SIP Profile for Expressway (already exists if using version 9.x)
- Configuring the region with an appropriate session bit rate for video calls
- Configuring a SIP Profile for phone devices
- Adding a phone device: add the new phone device to the list of supported endpoints on Unified CM
- Configuring the device directory number: specify the telephone number that will cause this phone to ring
- Configuring the SIP Trunk security profile
- Configuring the SIP Trunk device
- Configuring the Cluster Fully Qualified Domain Name
- Allowing numeric dialing from Cisco phones to Expressway
- Allowing dialing to Expressway domain from Cisco phones
- Checking the message size limit on Unified CM

These tasks are explained in detail below.

Configuring the SIP Profile for Expressway

Note that you can skip this step if you are using version 9.x as a "Standard SIP Profile For Cisco VCS" will already exist (the Cisco VCS profile may be used with Expressway).

1. On Unified CM, go to **Device > Device Settings > SIP Profile**.
2. Click **Copy** against the **Standard SIP Profile**.



3. Configure the fields as follows (leave other fields as default values):

Name	"Standard SIP Profile For Cisco VCS" (the profile is named "for Cisco VCS" for consistency with other Unified CM versions)
Default MTP Telephony Event Payload Type	101
Redirect by Application	Select the check box
Use Fully Qualified Domain in SIP Requests	Select the check box
Allow Presentation Sharing using BFCP	Select the check box (in Unified CM 8.6.1 or later)
Timer Invite Expires	180
Timer Register Delta	5
Timer Register Expires	3600
Timer T1	500
Timer T2	Leave as default (typically 4000 or 5000)
Retry INVITE	6
Retry non-INVITE	10
Start Media Port	16384
Stop Media Port	32766
Call Pickup URI	x-cisco-serviceuri-pickup
Call Pickup Group Other URI	x-cisco-serviceuri-opickup
Call Pickup Group URI	x-cisco-serviceuri-gpickup
Meet Me Service URI	x-cisco-serviceuri-meetme
Timer Keep Alive Expires	120
Timer Subscribe Expires	120
Timer Subscribe Delta	5
Maximum Redirections	70
Off Hook To First Digit Timer	15000
Call Forward URI	x-cisco-serviceuri-cfwdall
Abbreviated Dial URI	x-cisco-serviceuri-abbrdial
Reroute Incoming Request to new Trunk based on	Never

4. Click **Save**.

SIP Profile Configuration
Related Links: [Back To Find/List](#) Go

Save ✖ Delete 📄 Copy 🔄 Reset 🔧 Apply Config + Add New

Status

i Status: Ready

i All SIP devices using this profile must be restarted before any changes will take affect.

SIP Profile Information

Name *	Standard SIP Profile For Cisco VCS
Description	Default SIP Profile
Default MTP Telephony Event Payload Type*	101
Resource Priority Namespace List	< None >
Early Offer for G.Clear Calls*	Disabled
SDP Session-level Bandwidth Modifier for Early Offer and Re-invites*	TIAS and AS
User-Agent and Server header information *	Send Unified CM Version Information as User-Agen

Redirect by Application

Disable Early Media on 180

Outgoing T.38 INVITE include audio mline

Enable ANAT

Require SDP Inactive Exchange for Mid-Call Media Change

Use Fully Qualified Domain Name in SIP Requests

Allow Presentation Sharing using BFCP

Parameters used in Phone

Timer Invite Expires (seconds) *	180
Timer Register Delta (seconds) *	5
Timer Register Expires (seconds) *	3600
Timer T1 (msec) *	500
Timer T2 (msec) *	4000
Retry INVITE *	6
Retry Non-INVITE *	10
Start Media Port *	16384
Stop Media Port *	32766
Call Pickup URI *	x-cisco-serviceuri-pickup
Call Pickup Group Other URI *	x-cisco-serviceuri-opickup
Call Pickup Group URI *	x-cisco-serviceuri-gpickup

Meet Me Service URI*	x-cisco-serviceuri-meetme
User Info*	None
DTMF DB Level*	Nominal
Call Hold Ring Back*	Off
Anonymous Call Block*	Off
Caller ID Blocking*	Off
Do Not Disturb Control*	User
Telnet Level for 7940 and 7960*	Disabled
Timer Keep Alive Expires (seconds)*	120
Timer Subscribe Expires (seconds)*	120
Timer Subscribe Delta (seconds)*	5
Maximum Redirections*	70
Off Hook To First Digit Timer (milliseconds)*	15000
Call Forward URI*	x-cisco-serviceuri-cfwdall
Speed Dial (Abbreviated Dial) URI*	x-cisco-serviceuri-abbrdial
<input checked="" type="checkbox"/> Conference Join Enabled <input type="checkbox"/> RFC 2543 Hold <input checked="" type="checkbox"/> Semi Attended Transfer <input type="checkbox"/> Enable VAD <input type="checkbox"/> Stutter Message Waiting	
Trunk Specific Configuration	
Reroute Incoming Request to new Trunk based on*	Never
RSVP Over SIP*	Local RSVP
<input checked="" type="checkbox"/> Fall back to local RSVP	
SIP Rel1XX Options*	Disabled
<input type="checkbox"/> Deliver Conference Bridge Identifier <input type="checkbox"/> Early Offer support for voice and video calls (insert MTP if needed) <input type="checkbox"/> Send send-receive SDP in mid-call INVITE	
SIP OPTIONS Ping	
<input type="checkbox"/> Enable OPTIONS Ping to monitor destination status for Trunks with Service Type "None (Default)"	
Ping Interval for In-service and Partially In-service Trunks (seconds)*	60
Ping Interval for Out-of-service Trunks (seconds)*	120
Ping Retry Timer (milliseconds)*	500
Ping Retry Count*	6
<input type="button" value="Save"/> <input type="button" value="Delete"/> <input type="button" value="Copy"/> <input type="button" value="Reset"/> <input type="button" value="Apply Config"/> <input type="button" value="Add New"/>	

Configuring the region with an appropriate session bit rate for video calls

Ensure that your regions have an appropriate session bit rate for video calls:

1. Go to **System > Region Information > Region**.
2. Select the region (for example the **Default** region).
3. Set **Maximum Session Bit Rate for Video Calls** to a suitable upper limit for your system, for example 6000 kbps.
4. Click **Save** and then click **Apply Config**.

Configuring the SIP Profile for phone devices

This creates the SIP Profile that is to be applied to all phone devices.

1. On Unified CM, go to **Device > Device Settings > SIP Profile**.
2. Click **Copy** against the **Standard SIP Profile**.
3. Configure the following fields, leaving everything else as its default value:

Name	Standard SIP Profile – for phone devices
-------------	--

Use Fully Qualified Domain in SIP Requests	Select the check box
Allow Presentation Sharing using BFCP	Select the check box if BFCP (Dual video / presentation sharing) is required.

4. Click **Save**.

Adding a phone device

1. Go to **Device > Phone**.
2. Click **Add New**.
3. Select a **SIP Profile** of *Standard SIP Profile – for phone devices*.
4. Configure the other fields as required.
5. Click **Save** and click **OK**.
6. Click **Apply Config** and click **OK**.

Alternatively, if there is already another phone configured, copy its configuration by selecting “super copy”, entering the new phone’s MAC address and then changing the description (especially correct the MAC address part of the description).

Configuring the device directory number

1. Go to **Device > Phone**.
2. Select the relevant device name.
3. On the left hand side, select a line.
4. Set up the required directory number (for this example use a 3xxx number).

Configuring the SIP Trunk security profile

Version 8.6.x

1. Go to **System > Security > SIP Trunk Security Profile**.
2. Click **Add New**.
3. Configure the fields as follows:

Name	Non Secure SIP Trunk Profile
Device Security Mode	Non Secure
Incoming Transport Type	TCP+UDP
Outgoing Transport Type	TCP
Incoming Port	5060
Accept Unsolicited Notification	Select this check box
Accept Replaces Header	Select this check box

4. Click **Save**.

Version 9.x

In version 9.x, the Non Secure SIP Trunk Profile will already exist, but **it must be modified**.

1. On Unified CM, go to **System > Security > SIP Trunk Security Profile**.
2. Select **Non Secure SIP Trunk Profile**.
3. Modify the fields as follows:

Accept Unsolicited Notification	Select this check box
Accept Replaces Header	Select this check box

4. Click **Save**.

The screenshot shows the Cisco Unified CM Administration interface. The page title is "SIP Trunk Security Profile Configuration". The status is "Ready". The "SIP Trunk Security Profile Information" section contains the following fields:

- Name*: Non Secure SIP Trunk Profile
- Description: Non Secure SIP Trunk Profile authenticated by null Stri
- Device Security Mode: Non Secure
- Incoming Transport Type*: TCP+UDP
- Outgoing Transport Type: TCP
- Enable Digest Authentication
- Nonce Validity Time (mins)*: 600
- X.509 Subject Name:
- Incoming Port*: 5060
- Enable Application Level Authorization
- Accept Presence Subscription
- Accept Out-of-Dialog REFER**
- Accept Unsolicited Notification
- Accept Replaces Header
- Transmit Security Status
- SIP V.150 Outbound SDP Offer Filtering*: Use Default Filter

The "Accept Unsolicited Notification" and "Accept Replaces Header" checkboxes are highlighted with a red box in the original image.

Configuring the SIP Trunk device

1. On Unified CM, go to **Device > Trunk**.
2. Click **Add New**.
3. Select a **Trunk Type** of *SIP Trunk*.
 - **Device Protocol** displays *SIP*.
 - If asked for a **Trunk Service Type**, select *None (Default)*.
4. Click **Next**.
5. Configure the **Device Information** fields as follows:

Device Name	As required, such as Expressway_system
Device Pool	(As set up in System > Device Pool)
Call classification	OnNet
Location	(As set up in System > Location)
Packet Capture Mode	None
Media Termination Point Required	Clear this check box if any video phones registered to Unified CM are to make or receive video calls with endpoints routed via Expressway. Select this check box if audio devices only are registered to Unified CM.
SRTP Allowed	Select this check box
Run On All Active Unified CM Nodes	Select this check box

6. Configure the **Call Routing Information > Inbound Calls** fields as follows:


Significant digits	All
Connected Line ID Presentation	Default
Connected Name Presentation	Default
Calling Search Space	(As set up in Call Routing > Class of Control > Calling Search Space)
Prefix DN	<blank>
Redirecting Diversion Header Delivery – Inbound	Select this check box

7. Configure the **Call Routing Information > Outbound Calls** fields as follows:


Calling Party Selection	Originator
Calling Line ID Presentation	Default
Calling Name Presentation	Default
Caller ID DN	<blank>
Caller Name	<blank>

8. Configure the **SIP Information** fields as follows:

Destination address is an SRV	Select this check box if a domain is specified for the destination address, and the DNS server uses DNS SRV records to direct the domain to a cluster of Expressways. Do not select this check box if an IP address is specified as the Destination address .
--------------------------------------	---

Destination address	<FQDN of Expressway / Expressway cluster>. Alternatively you can enter the <IP address of Expressway>. If you are not using SRV records and need to specify multiple peers, click  to add extra Destination address rows. The content of the Expressway transform configured at Configuring Expressway routing [p.17] depends on which form of address is entered here.
Destination port	5060 (this displays as zero if you are using SRV records)
Presence Group	Standard Presence Group (or whichever presence group has been configured in System > Presence Group)
SIP Trunk Security Profile	Non Secure SIP Trunk Profile
SIP Profile	Standard SIP Profile for Cisco VCS
DTMF Signaling Method	RFC 2833
Normalization Script	vcs-interop (if available, the vcs-interop script may be used with Expressway)

9. Click **Save**.
10. Click **Reset**.
11. Click **Reset**.



The screenshot shows the 'Trunk Configuration' page in the Cisco Unified CM Administration console. The page title is 'Trunk Configuration' and it includes a 'Save' button and a 'Status: Ready' indicator. The main section is 'Device Information', which contains the following fields and options:

- Product: SIP Trunk
- Device Protocol: SIP
- Trunk Service Type: None(Default)
- Device Name*: Expressway_system
- Description: Expressway system location
- Device Pool*: Default
- Common Device Configuration: LABCM6
- Call Classification*: OnNet
- Media Resource Group List: < None >
- Location*: Reston LABCM6A51
- AAR Group: < None >
- Tunneled Protocol*: None
- QSIG Variant*: No Changes
- ASN.1 ROSE OID Encoding*: No Changes
- Packet Capture Mode*: None
- Packet Capture Duration: 0
- Media Termination Point Required
- Retry Video Call as Audio
- Path Replacement Support
- Transmit UTF-8 for Calling Party Name
- Transmit UTF-8 Names in QSIG APDU
- Unattended Port
- SRTP Allowed - When this flag is checked, Encrypted TLS needs to be configured in the network to provide end to end security. Failure to do so will expose keys and other information.
- Consider Traffic on This Trunk Secure*: When using both sRTP and TLS
- Route Class Signaling Enabled*: Default
- Use Trusted Relay Point*: Default
- PSTN Access
- Run On All Active Unified CM Nodes

Intercompany Media Engine (IME)
 E.164 Transformation Profile < None >

Multilevel Precedence and Preemption (MLPP) Information
 MLPP Domain < None >

Call Routing Information

Remote-Party-Id
 Asserted-Identity
 Asserted-Type* Default
 SIP Privacy* Default

Inbound Calls

Significant Digits* All
 Connected Line ID Presentation* Default
 Connected Name Presentation* Default
 Calling Search Space LABCM6
 AAR Calling Search Space < None >
 Prefix DN

Redirecting Diversion Header Delivery - Inbound

Incoming Calling Party Settings

If the administrator sets the prefix to Default this indicates call processing will use prefix at the next level setting (DevicePool/Service Parameter). Otherwise, the value configured is used as the prefix unless the field is empty in which case there is no prefix assigned.

Number Type	Prefix	Strip Digits	Calling Search Space	Use Device Pool CSS
Incoming Number	<input type="text" value="Default"/>	<input type="text"/>	< None >	<input checked="" type="checkbox"/>

Connected Party Settings

Connected Party Transformation CSS < None >
 Use Device Pool Connected Party Transformation CSS

Outbound Calls

Called Party Transformation CSS < None >
 Use Device Pool Called Party Transformation CSS
 Calling Party Transformation CSS < None >
 Use Device Pool Calling Party Transformation CSS
 Calling Party Selection* Originator
 Calling Line ID Presentation* Default
 Calling Name Presentation* Default
 Caller ID DN
 Caller Name

Redirecting Diversion Header Delivery - Outbound
 Redirecting Party Transformation CSS < None >
 Use Device Pool Redirecting Party Transformation CSS

SIP Information

Destination

Destination Address is an SRV

Destination Address	Destination Address IPv6	Destination Port
1* <input type="text" value="exp-name.exp.domain"/>	<input type="text"/>	<input type="text" value="0"/>

MTP Preferred Originating Codec* 711ulaw
 Presence Group* Standard Presence group
 SIP Trunk Security Profile* Non Secure SIP Trunk Profile
 Rerouting Calling Search Space < None >
 Out-Of-Dialog Refer Calling Search Space < None >
 SUBSCRIBE Calling Search Space < None >
 SIP Profile* Standard SIP Profile For Cisco VCS
 DTMF Signaling Method* RFC 2833

Normalization Script

Normalization Script vc3-interop
 Enable Trace

Parameter Name	Parameter Value
1 <input type="text"/>	<input type="text"/>

Geolocation Configuration

Geolocation < None >
 Geolocation Filter < None >
 Send Geolocation Information

Configuring the Cluster Fully Qualified Domain Name

Unified CM must be configured with a **Cluster Fully Qualified Domain Name** so that it can receive calls to addresses in the format <address>@domain. (It is also required when Unified CM is clustered so that Expressway can send the call to any Unified CM node.)

1. Go to **System > Enterprise parameters**, and find the **Clusterwide Domain Configuration** section.
2. Set the **Cluster Fully Qualified Domain Name** to the same domain as the video network, for example exp.domain.

This parameter defines one or more Fully Qualified Domain Names (FQDNs) for this cluster. Multiple FQDNs must be separated by a space. Requests containing URLs (for example, SIP calls) whose host portion matches any of the FQDNs in this parameter will be recognized as a request destined for this cluster and/or devices attached to it.

3. Click **Save**.

Clusterwide Domain Configuration	
Organization Top Level Domain	<input type="text"/>
Cluster Fully Qualified Domain Name	<input type="text" value="exp.domain"/>

Allowing numeric dialing from Cisco phones to Expressway

Unified CM can be configured to take a prefix and route calls to a SIP trunk based on a specific prefix. Configure Unified CM to route calls dialed as 4xxx to the Expressway:

1. On Unified CM, go to **Call Routing > Route/Hunt > Route Pattern**.
2. Click **Add New**.
3. Configure a Route Pattern to route calls dialed 4xxx to the Expressway trunk (no change to dialed number).

Pattern Definitions	
Route Pattern	4XXX
Route Partition	(As set up in System > Device Pool)
Description	As required, for example "Route 4 xxx to Expressway SIP trunk"
Gateway/Route List	Required Trunk to route calls to the Expressway-C
Call Classification	<i>OnNet</i>
Provide Outside Dial Tone	Not selected
Called Party Transformations	
Discard Digits	< None >

Pattern Definition

Route Pattern*

Route Partition

Description

Numbering Plan

Route Filter

MLPP Precedence*

Gateway/Route List* (Edit)

Route Option
 Route this pattern
 Block this pattern

Call Classification*

Allow Device Override Provide Outside Dial Tone Allow Overlap Sending Urgent Priority

Require Forced Authorization Code

Authorization Level*

Require Client Matter Code

Calling Party Transformations

Use Calling Party's External Phone Number Mask

Calling Party Transform Mask

Prefix Digits (Outgoing Calls)

Calling Line ID Presentation*

Calling Name Presentation*

Connected Party Transformations

Connected Line ID Presentation*

Connected Name Presentation*

Called Party Transformations

Discard Digits

Allowing dialing to Expressway domain from Cisco phones

Configure a SIP route pattern that tells Unified CM that anything with, for example, a domain exp.domain needs to be sent down the Expressway SIP trunk. This is required to permit dialing from endpoints that support SIP URIs with domains, and also for enabling the reverse path to the Expressway for certain signaling.

1. On Unified CM, go to **Call Routing > SIP Route Pattern**.
2. Click **Add New**.
3. Configure the fields as follows:

Pattern Usage	<i>Domain Routing</i>
IPv4 Pattern	Domain for calls, for example exp.domain
Route Partition	Default is "<None>"; set according to dial plan restrictions
SIP Trunk	Required Trunk to route calls to the Expressway-C

4. Click **Save**.

Pattern Definition

Pattern Usage: Domain Routing

IPv4 Pattern*: exp.domain

IPv6 Pattern:

Description: Expressway system domain

Route Partition: LABCM6

SIP Trunk/Route List*: Expressway_system [\(Edit\)](#)

Block Pattern

Calling Party Transformations

Use Calling Party's External Phone Mask

Calling Party Transformation Mask:

Prefix Digits (Outgoing Calls):

Calling Line ID Presentation*: Default

Calling Line Name Presentation*: Default

Connected Party Transformations

Connected Line ID Presentation*: Default

Connected Line Name Presentation*: Default

When nnnn@exp.domain is dialed by an endpoint registered to Unified CM, Unified CM will route the call to the Expressway as nnnn@<FQDN of Expressway>:5060 (TCP) or nnnn@<FQDN of Expressway>:5061 (TLS). (The domain may alternatively be the IP address of Expressway, depending on what is configured as the SIP Trunk **Destination Address**.)

Checking the message size limit on Unified CM


SIP messages for video are considerably larger than SIP messages for audio calls, in particular, when a Cisco TelePresence Server is used in the video network.

Ensure that the **SIP Max Incoming Message Size** on Unified CM is set to 11000:

1. Go to **System > Service Parameters**.
2. Select the appropriate server.
3. Select *Cisco CallManager (Active)* as the service.
4. Select **Advanced**.
5. In the **Clusterwide Parameters (Device – SIP)** configure the field as follows:

SIP Max Incoming Message Size	11000
--------------------------------------	-------

6. Click **Save**.



Configuring Expressway routing

Prerequisites

The Expressway-C must be configured with IP address, DNS and NTP information, and is accessible for management via its web interface (see [Expressway Basic Configuration Deployment Guide](#)).

Rich media session licenses must be installed.

Configuration summary

The configuration on Expressway-C contains the following tasks:

- Creating a transform to ensure a consistent URI format
- Configuring a neighbor zone that contains the Unified CM
- Configuring a search rule to route calls to that zone
- Configuring a transform that converts number@<IP address of cucm> to number@exp.domain
- Configuring a transform to convert other Unified CM-supplied domain variants to number@exp.domain

These tasks are explained in detail below.

Ensuring a consistent URI format

In this deployment scenario, users want to be able to route calls via the Expressway to other devices or endpoints (not registered to Unified CM) that have a 4xxx extension number. Unified CM endpoints are to be dialed using a 3xxx number. This dialing model can be supported by H.323 (if the endpoint registers the 4-digit E.164 alias), however, SIP does not support dialing by numbers alone. If a number (without a domain appended) is dialed from a SIP endpoint the endpoint will automatically append its own domain.

For consistency with both SIP and H.323 dialing, this deployment scenario always uses the URI form for routing calls (that is, dialed_digits@domain). When the Expressway receives a call request, the dialed number:

- will contain the 4 digit extension number that identifies the specific endpoint to route to
- may or may not include a domain (only included when a SIP endpoint is making the call)

Thus, a transform is needed to ensure that the dialed number is transformed into a consistent form, in this case to add the domain (exp.domain) if required. To achieve this, a regex is used: `([^@] *)` transforms to `\1@exp.domain` (any dialed information which does not contain a domain – does not contain an '@' – has the '@exp.domain' added.)

See the Regular Expression Reference in the Appendices section of [Expressway Administrator Guide](#) for further details, or alternatively search the internet for the term “Regular Expression”.

To create the transform:

1. Go to **Configuration > Dial plan > Transforms**.
2. Click **New**.
3. Configure the fields as follows:

Priority	2
Description	“Add domain where none exists” for example
Pattern type	<i>Regex</i>
Pattern string	<code>([^\@]*)</code>
Pattern behavior	<i>Replace</i>
Replace string	<code>\1@exp.domain</code>
State	<i>Enabled</i>

- Click **Create transform**.

Create transform You are here: [Configuration](#) > [Dial plan](#) > [Transforms](#) > Create transform

Configuration

Priority	<input type="text" value="2"/> i
Description	<input type="text" value="Add domain where none exists"/> i
Pattern type	Regex i
Pattern string	* <input type="text" value="([^\@]*)"/> i
Pattern behavior	Replace i
Replace string	<input type="text" value="\1@exp.domain"/> i
State	Enabled i

Creating a neighbor zone for Unified CM

- Go to **Configuration > Zones > Zones**.
- Click **New**.
- Configure the fields as follows (leave all other fields with default values):

Name	CUCM Neighbor
Type	<i>Neighbor</i>
Hop count	15
H.323 mode	<i>Off</i> (H.323 access is not required for communication with Unified CM)
SIP mode	<i>On</i>
SIP port	5060 (if the SIP access port on Unified CM is not 5060, change the SIP Port value to be the same as used by Unified CM)
Transport	<i>TCP</i>
Media encryption mode	<i>Auto</i>

SIP authentication trust mode	<i>Off</i>
Peer 1 address	IP address of Unified CM, or the FQDN of Unified CM. If you are planning to ultimately use a TLS connection, then typically you will need to specify the FQDN of Unified CM here as this is the name that will be used to authenticate the certificate presented by Unified CM.
Zone profile (Advanced section)	This depends upon your version of Unified CM: <ul style="list-style-type: none">• Select <i>Cisco Unified Communications Manager</i> for versions prior to 8.6.1• Select <i>Cisco Unified Communications Manager (8.6.1 or later)</i> for 8.6.1 or 8.6.2• Select <i>Custom</i> for 9.x or later and:<ul style="list-style-type: none">◦ Set Call signaling routed mode to <i>Always</i>◦ Leave all the other fields as their default values Note that Unified CM 8.6.1 or later is required for BFCP (dual video / presentation sharing).

This configures the Expressway to use SIP over TCP to communicate with the Unified CM. To use TLS, complete the configuration as described here for TCP and then see [Connecting Expressway to Unified CM using TLS \[p.24\]](#).

4. Click **Create zone**.

Create zone You are here: [Configuration](#) > [Zones](#) > [Zones](#) > Create zone

Configuration

Name * CUCM Neighbor ⓘ

Type * Neighbor ⓘ

Hop count * 15 ⓘ

H.323

Mode Off ⓘ

Port * 1719 ⓘ

SIP

Mode On ⓘ

Port * 5060 ⓘ

Transport TCP ⓘ

Media encryption mode Auto ⓘ

Authentication

Authentication policy Do not check credentials ⓘ

SIP authentication trust mode Off ⓘ

Location

Peer 1 address 10.1.2.22 ⓘ

Advanced

Zone profile Cisco Unified Communications Manager ⓘ

Creating a search rule to route calls to the Unified CM neighbor zone

Search rules specify the range of telephone numbers / URIs to be handled by this neighbor Unified CM. They can also be used to transform URIs before they are sent to the neighbor.

In this example deployment, the transforms set up in [Ensuring a consistent URI format \[p. 17\]](#) ensure that dial strings are in URI format number@exp.domain.

1. Go to **Configuration > Dial plan > Search rules**.
2. Click **New**.

3. Configure the fields as follows to route the call to Unified CM:

Rule name	Route to CUCM
Description	For example: Send 3xxx@exp.doman calls to CUCM
Priority	100
Protocol	Any
Source	Any
Request must be authenticated	Configure this setting according to your authentication policy
Mode	Alias pattern match
Pattern type	Regex
Pattern string	(3\d{3})@exp.domain(.*)
Pattern behavior	Leave (@domain formatted addresses will work in Unified CM due to the Cluster Fully Qualified Domain Name enterprise parameter)
On successful match	Stop
Target zone	CUCM Neighbor
State	Enabled

4. Click **Create search rule**.

Create search rule You are here: [Configuration](#) > [Dial plan](#) > [Search rules](#) > Create search rule

Configuration

Rule name	* Route to CUCM i
Description	Send 3xxx@exp.doman calls to CUCM i
Priority	* 100 i
Protocol	Any i
Source	Any i
Request must be authenticated	No i
Mode	Alias pattern match i
Pattern type	Regex i
Pattern string	* (3\d{3})@exp.domain(*) i
Pattern behavior	Leave i
On successful match	Stop i
Target	* CUCM Neighbor i
State	Enabled i

See the “Zones and Neighbors” section of [Expressway Administrator Guide](#) for further details.

Creating a transform that converts number@<IP address of cucm> to number@exp.domain

When a call is made from Unified CM to Expressway, the callback address is presented as number@<ip address of cucm>. If the destination endpoint returns the call, the Expressway needs to be able to route it back to Unified CM. To enable this, the domain portion of the address must have the IP address removed and the video domain added (so that the existing search rule can route the call to Unified CM). A transform is required:

1. Go to **Configuration > Dial plan > Transforms**.
2. Click **New**.
3. Configure the fields as follows:

Priority	3
Description	"CUCM IP to domain" for example
Pattern type	Regex
Pattern string	(.*)@<ip address of Unified CM>((:;).*)? If a Unified CM cluster is in use, the regex must cater for the IP address of every possible node, for example (.*)(10\1\2\22 10\1\2\23)((:;).*)?
Pattern behavior	Replace
Replace string	\1@exp.domain\2
State	Enabled

4. Click **Create transform**.

Create transform You are here: [Configuration](#) > [Dial plan](#) > [Transforms](#) > Create transform

Configuration

Priority	<input type="text" value="3"/> ⓘ
Description	<input type="text" value="CUCM IP to domain"/> ⓘ
Pattern type	Regex ⓘ
Pattern string	* (.*?)@=ip address of CUCM=((:;).*)? ⓘ
Pattern behavior	Replace ⓘ
Replace string	<input type="text" value="\1@exp.domain\2"/> ⓘ
State	Enabled ⓘ

Creating a transform to convert other Unified CM-supplied domain variants to number@exp.domain

This transform converts URIs received from Unified CM to the format used in the Expressway's neighbor zones.

The domain portion of the URI received from Unified CM depends on its SIP Trunk configuration (see [Configuring the SIP Trunk device \[p.10\]](#)). Thus, this could be the IP address:port of the Expressway or the FQDN of the Expressway or Expressway cluster.

In this example, it is matching URIs received from Unified CM in the form 4xxx@exp-name.exp.domain:<port> and converting it into 4xxx@exp.domain.

1. Go to **Configuration > Dial plan > Transforms**.
2. Click **New**.
3. Configure the fields as follows:

Description	Convert Unified CM supplied domain information to the Expressway SIP domain
Priority	Enter a high priority such as 5 (the priority of this transform should be before any transforms that need to be applied for searching neighbor zones)
Pattern type	Regex
Pattern string	For example: (4\d{3})@exp-name.exp.domain(:.*)?
Pattern behavior	Replace
Replace string	For example: \1@exp.domain
State	Enabled

4. Click **Create transform**.

Create transform You are here: [Configuration](#) > [Dial plan](#) > [Transforms](#) > Create transform

Configuration

Priority	<input type="text" value="5"/> <small>i</small>
Description	<input type="text" value="Convert Unified CM supplied domain information to the Expressway SIP domain"/> <small>i</small>
Pattern type	Regex <small>i</small>
Pattern string	* (4\d{3})@exp-name.exp.domain(:.*)? <small>i</small>
Pattern behavior	Replace <small>i</small>
Replace string	\1@exp.domain <small>i</small>
State	Enabled <small>i</small>

Connecting Expressway to Unified CM using TLS

These instructions explain how to take a system that is already configured and working using a TCP interconnection between Expressway and Unified CM, and to convert that connection to use TLS instead. This process involves:

- Ensuring certificate trust between Unified CM and Expressway
- Setting the Cluster Security Mode of the Unified CM to 1 (Mixed Mode)
- Configuring a SIP trunk security profile on Unified CM
- Updating the Unified CM trunk to Expressway to use TLS
- Updating the Expressway neighbor zone to Unified CM to use TLS

Ensuring certificate trust between Unified CM and Expressway

For Unified CM and Expressway to establish a TLS connection with each other:

- Expressway and Unified CM must both have valid server certificates loaded (you must replace the Expressway's default server certificate with a valid server certificate)
- Unified CM must trust Expressway's server certificate (the root CA of the Expressway server certificate must be loaded onto Unified CM)
- Expressway must trust Unified CM's server certificate (the root CA of the Unified CM server certificate must be loaded onto Expressway)

See [Expressway Certificate Creation and Use Deployment Guide](#) for full details about loading certificates and how to generate CSRs on Expressway to acquire certificates from a Certificate Authority (CA).

Note that in a clustered environment, you must install CA and server certificates on each peer/node individually.

We strongly recommend that you do not use self-signed certificates in a production environment.

Loading server and trust certificates on Expressway

Expressway server certificate

Expressway has only one server certificate. By default, this is a certificate signed by a temporary certificate authority. We recommend that it is replaced by a certificate generated by a trusted certificate authority.

To upload a server certificate:

1. Go to **Maintenance > Security certificates > Server certificate**.
2. Use the **Browse** button to select and upload the **server certificate** PEM file.
3. If you used an external system to generate the certificate request you must also upload the **server private key** PEM file that was used to encrypt the server certificate. (The private key file will have been automatically generated and stored earlier if the Expressway was used to produce the signing request for this server certificate.)
 - The **server private key** must not be password protected.
 - You cannot upload a server private key if a certificate signing request is in progress.
4. Click **Upload server certificate data**.

Expressway trusted CA certificate

The **Trusted CA certificate** page ([Maintenance > Security certificates > Trusted CA certificate](#)) allows you to manage the list of certificates for the Certificate Authorities (CAs) trusted by this Expressway. Certificates presented to the Expressway must be signed by a trusted CA on this list and there must be a full chain of trust (intermediate CAs) to the root CA.

The root CA of the Unified CM server certificate must be loaded into the Expressway's trusted CA certificate list.

To upload a new file of CA certificates, **Browse** to the required PEM file and click **Append CA certificate**. This will append any new certificates to the existing list of CA certificates. Note that if you are replacing existing certificates for a particular issuer and subject, you have to manually delete the previous certificates.

Repeat this process on every Expressway that will communicate with this Unified CM.

Loading server and trust certificates on Unified CM

Certificate management for Unified CM is performed in the [Cisco Unified OS Administration](#) application.

All existing certificates are listed under [Security > Certificate Management](#). Server certificates are of type *certs* and trusted CA certificates are of type *trust-certs*.

Unified CM server certificate

By default, Unified CM has a self-signed server certificate **CallManager.pem** installed. We recommend that this is replaced with a certificate generated from a trusted certificate authority.

Unified CM trusted CA certificate

To load the root CA certificate of the authority that issued the Expressway certificate (if it is not already loaded):

1. Click **Upload Certificate/Certificate chain**.
2. Select a **Certificate Name** of *CallManager-trust*.
3. Click **Browse** and select the file containing the root CA certificate of the authority that issued the Expressway certificate.
4. Click **Upload File**.

Repeat this process on every Unified CM server that will communicate with Expressway. Typically this is every node that is running the CallManager service.


Setting the Cluster Security Mode to Mixed Mode

The Cisco Unified Communications Manager cluster must be in Mixed Mode to allow the registration of both secure devices and non-secure devices. This allows for best effort encryption between the Expressway and the Cisco Unified Communications Manager. Read [Setting up secure RTP between UCM and VCS](#) for background on best effort encryption between Expressway and Unified CM.

As of version 10.0, you can use the CLI to change the cluster security mode. On earlier versions, you must use the Cisco CTL Client plugin to change the cluster security mode. The security mode change updates the CTL file, so you must restart the Cisco CallManager and Cisco Tftp services after the change.

The process is summarized below, but you should refer to the *Cisco Unified Communications Manager Security Guide* for your version, which you can find on the [Cisco Unified Communications Manager \(CallManager\) Maintain and Operate Guides](#) page.

1. Obtain access to the Unified CM publisher node, including hardware security tokens (if using the CTL Client plugin).
2. (Pre 10.0) Download and install the Cisco CTL Client plugin from Unified CM.
3. Run the CTL Client plugin to enable Mixed Mode. On 10.0 or later, you can use `utils ctl set-cluster mixed-mode` at the CLI.



4. Update the CTL file (via the plugin or `utils ctl update CTLFile`).
5. Restart the Cisco CallManager and Cisco Tftp services (via Cisco Unified Serviceability).

Configuring a SIP trunk security profile on Unified CM

On Unified CM:

1. Select **Cisco Unified CM Administration**, click **Go** and log in.
2. Go to **System > Security > SIP Trunk Security Profile**.
3. Click **Add New**.
4. Configure the fields as follows:

Name	A name indicating that this is an encrypted profile.
Description	Enter a textual description as required.
Device Security Mode	<i>Encrypted.</i>
Incoming Transport Type	<i>TLS.</i>
Outgoing Transport Type	<i>TLS.</i>
Enable Digest Authentication	Leave unselected.

X.509 Subject Name	The subject name or an subject alternate name provided by the Expressway in its certificate. For Expressway clusters, ensure that this list includes all of the names contained within all of the peers' certificates. To specify multiple X.509 names, separate each name by a space, comma, semicolon or colon.
Incoming Port	5061
Accept Unsolicited Notification	Select this check box
Accept Replaces Header	Select this check box
Other parameters	Leave all other parameters unselected.

5. Click **Save**.

Updating the Unified CM trunk to Expressway to use TLS

On Unified CM:

1. Go to **Device > Trunk**.
2. Using Find, select the **Device Name** previously set up for the trunk to the Expressway.
3. Configure the following fields:

SIP Information section

Destination Port	5061 (unless using DNS SRV, in which case ensure the SRV records are set up correctly). Note that some versions of Unified CM cannot perform TLS SRV lookups. See TLS calls fail when Unified CM uses SRV trunk destinations [p.32] for more information.
SIP Trunk Security Profile	Select the trunk profile set up above.

Leave other parameters as previously configured.

4. Click **Save**.
5. Click **Reset**.

Updating the Expressway neighbor zone to Unified CM to use TLS

Note that Expressway will report that the Unified CM zone is active even while it is communicating with Unified CM over TCP. The changes below are necessary to enable communications over TLS.

On Expressway:

1. Go to **Configuration > Zones > Zones**, then select the zone to Unified CM.
2. Configure the following fields:

SIP section

Port	5061
Transport	TLS
TLS verify mode	On
Authentication trust mode	Off

Leave other parameters as previously configured.

3. Click **Save**.

Verifying that the TLS connection is operational

To verify correct TLS operation, check that the Expressway zone reports its status as active and then make some test calls.

1. Check the Expressway zone is active:
 - a. Go to **Configuration > Zones > Zones**.
 - b. Check the **SIP status** of the zone.
If the zone is not active, try resetting or restarting the trunk again on Unified CM.
2. Make a test call from a system routed through an Expressway to a Unified CM phone.
3. Make a test call from a Unified CM phone to a system routed through an Expressway.

Network of Expressways

If there is a network of Expressways behind this Expressway neighbored to Unified CM, then, either:

- Unified CM must trust the certificates of all the Expressways in the network ('optimal' routing mode), or
- The Expressway neighbor zone to Unified CM must 'always' route the signaling. In effect this sets up this Expressway as a gateway to Unified CM, and is the preferred option. The *Cisco Unified Communications Manager* and *Cisco Unified Communications Manager (8.6.1 or later)* zone profiles are pre-configured to 'always' route the signaling, thus no additional configuration is required providing one of these profiles is used.

Encrypted calls to endpoints registered to Unified CM

Endpoints registered to Unified CM need to be configured with a "SIP Secure profile" to provide encrypted media and call negotiation. If such a profile is not available by default, it will need to be created via **System > Security > Phone Security**.

See [Securing Cisco TelePresence Products](#) for further information on using the Cisco CTL Client and configuring Unified CM for secure communications.

Appendix 1: Troubleshooting

Problems connecting Expressway-C local calls

Look at “Search history” to check the applied transforms

Search history entries report on any searches initiated from a SETUP/ARQ /LRQ in H323 and from an INVITE/OPTIONS in SIP.

1. Go to **Status > Search history**.
The summary shows the source and destination call aliases, and whether the destination alias was found.
2. Select the relevant search attempt.

The search history for that search attempt shows:

- the incoming call's details
- any transforms applied by admin or user policy or CPL
- and in priority order, zones which matched the required (transformed) destination, reporting on:
 - any transforms the zone may apply
 - found or not found status
 - if not found, the error code as seen in the zone's search response
 - repeated until a zone is found that can accept the call, or all zone matches have been attempted (the search may be “not found” due to lack of bandwidth or because the search from the zone resulted in an H.323 rejection reason or a non 2xx response to a SIP request)

If the search indicates:

- Found: False
- Reason: 480 Temporarily Not Available

this could be because the Expressway zone links are not correctly set up. From the command line execute `xcommand DefaultLinksAdd` to set up the required links for the Expressway's default zones; also check the links for other zones that have been created.

Note that each H.323 call will have two entries in the search history:

- The first for an ARQ to see if the endpoint can be found.
- The second for the Setup to actually route the call.

The ARQ search does not depend on links or link bandwidth, and so if links do not exist or link bandwidth is insufficient it may still pass, even though the Setup search will subsequently fail.

Each SIP call will usually have only a single search history entry for the SIP INVITE.

Look at call history to check how the call progressed

1. Go to **Status > Calls > History**.
The summary shows the source and destination call aliases, call duration and protocol (including any interworking).
2. Select the relevant call attempt and then the relevant call components.
This shows the incoming and outgoing call leg details and the zone and subzone routing.

Check for errors

Check the Event Log which is accessible from the web browser: [Status > Logs > Event Log](#).

Tracing calls

Tracing calls at SIP / H.323 level in Expressway

1. Go to **Maintenance > Diagnostics > Diagnostic logging**.
2. Optionally, select **Take tcpdump while logging**.
3. Click **Start new log**.
4. (Optional) Enter some **Marker** text and click **Add marker**.
 - The marker facility can be used to add comment text to the log file before certain activities are performed. This helps to subsequently identify the relevant sections in the downloaded diagnostic log file.
 - You can add as many markers as required, at any time while the diagnostic logging is in progress.
 - Marker text is added to the log with a "**DEBUG_MARKER**" tag.
5. Reproduce the system issue you want to trace in the diagnostic log.
6. Click **Stop logging**.
7. Click **Download log** to save the diagnostic log to your local file system. You are prompted to save the file (the exact wording depends on your browser).
8. If appropriate, click **Download tcpdump** to also download the tcpdump file to your local file system.

Call failures with Cisco TelePresence Server

SIP messages from Cisco TelePresence Server can be > 5,000 bytes (which is the default **SIP Max Incoming Message Size** configured in Unified CM).

Increase the **SIP Max Incoming Message Size** – see [Checking the message size limit on Unified CM \[p.16\]](#).

In-call problems

Calls clear down when a call transfer from a video phone on Unified CM transfers a call to Expressway

Even if use of a media termination point (MTP) is not requested on the SIP trunk between Unified CM and Expressway, if DTMF signaling method is configured as “No preference” on the SIP trunk on Unified CM, Unified CM will try and use a Media Transfer Point and the call will fail.

To resolve this, ensure that DTMF signaling method is configured as *RFC 2833* on Unified CM on the SIP trunk from Unified CM to Expressway.

Poor video quality from Unified CM

Ensure that your Unified CM region has an appropriate session bit rate for video calls as described in [Configuring the region with an appropriate session bit rate for video calls \[p.8\]](#).

Taking a trace on Unified CM using RTMT

RTMT is a tool that lets you monitor system health, view graphs and collect logs from Unified CM. There are versions for both Linux and Windows. Unified CM must also be configured to specify what can be traced.

Configure Unified CM to enable tracing

1. Log in to Unified CM.
2. In the **Navigation** drop-down select **Cisco Unified Serviceability** and click **Go**.
3. Go to the **Troubleshooting Trace Settings** page (**Trace > Troubleshooting Trace Settings**).
4. Select the **Check All Services** check box.
5. Click **Save**.

Installing RTMT – Real Time Monitoring Tool

1. Log in to Unified CM using a Linux or Windows PC.
2. Go to **Application > Plugins**.
3. Select **Find** with 'Name begins with <blank>' and 'Plugin Type equals Installation'.
4. Scroll down to the entry for 'Cisco Unified CM Real-Time Monitoring Tool – Linux' or 'Cisco Unified CM Real-Time Monitoring Tool – Windows', as required.
5. Click on the **Download** link.
6. When downloaded, run the downloaded install file.
7. Follow the instructions in the install wizard.
8. When complete, click **Done** to exit the installer.

Running RTMT

1. Run RTMT. (For example, under windows this is in **Start > All Programs > Cisco > CallManager Serviceability > Real-Time Monitoring Tool**.)
2. In the Login window enter the **Host IP Address**, **User Name** and **Password**.
3. Click **OK**.

Taking a trace using RTMT

1. Select **Trace & Log Central**.
2. Double-click on **Real Time Trace**.
3. Double-click **View Real Time Data**.
4. Select a Node – the Unified CM instance that is to have the trace run on it.
5. Click **Next >**.
6. Select the following:
 - **Products** = *UCM*
 - **Services** = *Cisco CallManager*
 - **Trace File Type** = *sdi*
7. Click **Finish**.

Note that:

- Logs can take a while to download.
- The sdi (System Diagnostic Interface) trace contains alarms, error information and SIP stack trace information.

Call failures

TLS calls fail when Unified CM uses SRV trunk destinations

Calls from Unified CM may fail if they use a TLS trunk security profile and SRV trunk destinations (requiring "_sips._tcp" SRV record lookups in DNS).

See bug CSCue37440 in the [Cisco Bug Search Tool](#) for up-to-date information regarding the versions of Unified CM in which this issue has been fixed.

If you need to address one or more Expressway peers you can work around this problem by not using SRV records. Instead, in the SIP trunk, specify each Expressway **Destination Address** individually using DNS A-records or static IP addresses. However, note that these addresses affect the domain portion of the URI received by Expressway from Unified CM. You may need to set up appropriate transforms on the Expressway to cater for this (see [Creating a transform to convert other Unified CM-supplied domain variants to number@exp.domain \[p.22\]](#)).

Encrypted call failures

Calls between endpoints registered to Unified CM and endpoints proxied via Expressway will fail if the Unified CM endpoint requests best effort encryption and the other endpoint does not support encryption. (Unified CM has a proprietary method for indicating fall back to no encryption - X-cisco-srtp-fallback – which Expressway currently does not support.)

Appendix 2: Connecting Unified CM to an Expressway cluster

From Unified CM version 8.5, to connect Unified CM with a cluster of Expressway peers there are 2 methods of providing Unified CM with the addresses of the Expressway cluster peers:

- the trunk to Expressway specifies the DNS SRV address for the Expressway cluster
- the trunk to Expressway specifies a list of Expressway peers

Prior to Unified CM 8.5, the trunk to Expressway had to specify the DNS SRV address for the Expressway cluster.

Configuring the trunk to Expressway to specify the DNS SRV address for the Expressway cluster

Ensure that in the DNS server used by Unified CM a DNS SRV record exists for the cluster of Expressway peers; in the DNS SRV record each peer should be set with equal priority and equal weight.

1. On Unified CM, go to **Device > Trunk**.
2. Select the previously configured Trunk.
3. Scroll down and configure the **SIP Information** section fields as follows:

Destination address	<DNS SRV name of Expressway cluster>
Destination address is an SRV	Select this check box.

4. Click **Save**.
5. Click **Reset**.
6. Click **Reset**.
7. On Expressway, ensure that the cluster name is configured as a SIP domain (**Configuration > Domains**).

SIP Information

Destination

Destination Address is an SRV

Destination Address	Destination Address IPv6	Destination Port
1* exp-name.exp.domain		0

MTP Preferred Originating Codec*	711ulaw
BLF Presence Group*	Standard Presence group
SIP Trunk Security Profile*	Non Secure SIP Trunk Profile
Rerouting Calling Search Space	< None >
Out-Of-Dialog Refer Calling Search Space	< None >
SUBSCRIBE Calling Search Space	< None >
SIP Profile*	Standard SIP Profile
DTMF Signaling Method*	RFC 2833

Configuring the trunk to Expressway to specify a list of Expressway peers

1. On Unified CM, go to **Device > Trunk**.
2. Select the previously configured Trunk.
3. Scroll down and configure the **SIP Information** fields as follows:
(Click **+** to obtain additional destination address entries.)

Destination address is an SRV	Ensure that this check box is not selected
Destination address 1 and Destination port 1	IP address or DNS name of Expressway peer 1 5060 or 5061 depending on connectivity (TCP/TLS)
Destination address 2 and Destination port 2	IP address or DNS name of Expressway peer 2 5060 or 5061 depending on connectivity (TCP/TLS)
Destination address 3 and Destination port 3	IP address or DNS name of Expressway peer 3 – if it exists 5060 or 5061 depending on connectivity (TCP/TLS)
... up to Destination address 6 and Destination port 6	... repeat up to IP address or DNS name of Expressway peer 6 – where they exist

4. Click **Save**.
5. Click **Reset**.
6. Click **Reset**.

The screenshot shows the 'SIP Information' configuration page. Under the 'Destination' section, there is a checkbox for 'Destination Address is an SRV' which is unchecked. Below this is a table with three columns: 'Destination Address', 'Destination Address IPv6', and 'Destination Port'. The first row is labeled '1*' and contains three empty input fields. To the right of the table are two buttons: a plus sign (+) and a minus sign (-).

Appendix 3: Connecting Expressway to a cluster of Unified CM nodes

When connecting Expressway to a cluster of Unified CM nodes, Expressway needs to be able to route calls to each Unified CM node.

This can be done in 2 ways, in order of preference:

1. With a single neighbor zone in Expressway with the Unified CM nodes listed as location peer addresses.
2. By using DNS SRV records and an Expressway DNS zone.

Note that both options ensure that the Expressway to Unified CM call load is shared across Unified CM nodes.

Option 1: Using a single neighbor zone

Unified CM configuration

When in a cluster, Unified CM needs to accept calls routed to number@domain (instead of number@<ip address of Unified CM>) so that Expressway can send the call to any Unified CM node without having to make sure that the domain portion matches the IP address of the node that the call is being sent to.

Ensure that the **Cluster Fully Qualified Domain Name** (**System > Enterprise parameters**, in the **Clusterwide Domain Configuration** section) is set to the same domain as the video network, for example exp.domain.

Expressway-C configuration

The Expressway configuration requires an update to the neighbor zone:

1. Go to **Configuration > Zones**.
2. Select the Unified CM neighbor zone.
3. Configure the fields as follows:

Peer 1 address	IP address of Unified CM node 1, or the domain of Unified CM node 1.
Peer 2 address	IP address or the domain of Unified CM node 2.
Peer 3 address	IP address or the domain of Unified CM node 3, or blank if no Unified CM node 3.
... up to Peer 6 address	... repeat up to the IP address or the domain of Unified CM node 6, or leaving it blank if there is no Unified CM node.

Option 2: Using a DNS zone

Unified CM configuration

Ensure that the **Cluster Fully Qualified Domain Name** (**System > Enterprise parameters**, in the **Clusterwide Domain Configuration** section) is set to the same domain as the video network, for example exp.domain.

DNS server configuration

Configure the DNS server (that is used by the Expressway) with DNS SRV records for the Unified CM cluster.

- `_sips._tcp.fqdn_of_cucm_cluster` records for TLS connectivity (one record for each Unified CM node); or
- `_sip._tcp.fqdn_of_cucm_cluster` records for TCP connectivity (one record for each Unified CM node)

Expressway-C configuration

Expressway configuration requires 3 steps:

- Create a Unified CM DNS zone
- Adjust search rule to use the DNS zone
- Delete the old Unified CM neighbor zone

Creating a Unified CM DNS zone

1. Go to **Configuration > Zones > Zones**.
2. Click **New**.
3. Configure the fields as follows:

Name	CUCM Cluster Neighbor DNS Zone
Type	<i>DNS</i>
Hop count	15
H.323 mode	<i>Off</i> H.323 access is not required for communication with Unified CM
SIP mode	<i>On</i>
TLS verify mode	<i>Off</i>
Media encryption mode	<i>Auto</i>
Include address record	<i>Off</i>
Zone profile	Select <i>Cisco Unified Communications Manager</i> or <i>Cisco Unified Communications Manager (8.6.1 or later)</i> as appropriate.

4. Click **Create zone**.

Create zone You are here: [Configuration](#) > [Zones](#) > [Zones](#) > Create zone

Configuration

Name * CUCM Cluster Neighbor DNS Zone i

Type * DNS i

Hop count * 15 i

H.323

Mode Off i

SIP

Mode On i

TLS verify mode Off i

Media encryption mode Auto i

Advanced

Include address record Off i

Zone profile Cisco Unified Communications Manager i

Adjusting the search rule

Change the search rule to point to this Unified CM DNS zone.

1. Go to **Configuration > Dial plan > Search rules**.
2. Select the existing “Route to Unified CM” search rule.
3. Update the **Target zone** to use the *CUCM Cluster Neighbor DNS Zone* created above.
4. Click **Save**.

Deleting the old Unified CM neighbor zone

Delete the now unused neighbor zone “Unified CM Neighbor”.

1. Go to **Configuration > Zones > Zones**.
2. Select the check box next to the “CUCM Neighbor” zone.
3. Click **Delete**.

Appendix 4: Additional information

IP address dialing

Unified CM cannot dial out to IP addresses, but the Expressway can. To support IP address dialing from endpoints registered to Unified CM, we recommend the following procedure:

1. Define a prefix to use for dialing the IP address, for example 8.
2. Add a Route Pattern in Unified CM to match the prefix and send it via the SIP trunk to Expressway.
3. On Expressway, add a search rule (or transform) with a regex to match, for example: `8 (\d{3}) (\d{3}) (\d{3}) (\d{3}) . *` and then replace it with `\1 . \2 . \3 . \4`
This example regex matches an IP address dialed in the format of 12 digits (inserting the leading zeroes in each octet), so for example 64.102.6.247 would be dialed as prefix 8 followed by 064102006247. The replace string then inserts dots after the 3rd, 6th and 9th digits.

Characters allowed in SIP URIs

The following character set is allowed in SIP URIs (further details may be found in RFC 3261):

`a-z / A-Z / 0-9 / "-" / "_" / "." / "!" / "~" / "*" / "" / "(" / ")" / "&" / "=" / "+" / "$" / "," / ";" / "?" / "/"`

If other characters are needed they must be “escaped” using “%” followed by a pair of hexadecimal digits that represents the ASCII value for the required character.

For example, “alice smith@example.com” must be encoded as `alice%20smith@example.com` (where %20 represents the space character).

Document revision history

The following table summarizes the changes that have been applied to this document.

Date	Description
January 2015	Updated with summary of enabling Mixed Mode on CUCM.
December 2013	Initial release.

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Cisco and the Cisco Logo are trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and other countries. A listing of Cisco's trademarks can be found at www.cisco.com/go/trademarks. Third party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1005R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

© 2015 Cisco Systems, Inc. All rights reserved.