



Cisco Expressway IP Port Usage for Firewall Traversal

Cisco Expressway X8.5

December 2014


Contents: Cisco Expressway IP port usage

Which IP ports are used with Cisco Expressway?

Which IP ports need to be allowed through firewalls?

- Format of information
- Traversing firewalls
 - Administration
 - SIP calls
 - H.323 calls
- Internal
 - Administration
 - SIP calls
 - H.323 calls

Guide to this document: format of information



	Expressway-E source port	Server listening port
Management control	DMZ to public	
Open firewall	DMZ to public	
IP address	IP address of Expressway-E	IP address of DNS server
IP Ports	DNS UDP <i>S</i> <i>>= 1024</i>	UDP 53 <i>53</i>

Direction firewall needs to be opened

Destination of messaging

Direction of management / calls

S = Source port, typically ≥ 1024

Details of what defines the IP port ID / range

Destination of messaging: IP address

Source of messaging: IP address

Destination of messaging: IP port

- letter reference for more details
- default / expected port range in italics

Source of messaging: IP port


- letter reference for more details
- default / expected port range in italics

Firewall needs to have a pinhole open for at least

- all source ports at IP address of source to
- all listening ports at IP address of listener

When a firewall allows an outbound message through, it is assumed that responses (up to about 20 to 30 seconds after the original send) will be allowed back through the firewall

Administration: Cisco Expressway-C




		Management system source port	Expressway-C listening port
Management control		Private network	
Open firewall		n/a	
IP address		IP address of management computer(s)	IP address of Expressway-C
IP Ports	http	TCP S >= 1024	TCP 80 80
	https	TCP S >= 1024	TCP 443 443
	ssh	TCP S >= 1024	TCP 22 22
	SNMP	UDP S >= 1024	UDP 161 161

		Management system listening port	Expressway-C source port
Management control		Private network	
Open firewall		n/a	
IP address		IP address of management computer(s)	IP address of Expressway-C
IP Ports	NTP	UDP 123 123	UDP 123 123
	LDAP	TCP 389 389	TCP S >= 1024
	http (feedback to TMS)	TCP 80 80	TCP S >= 1024
	DNS	UDP 53 53	UDP S >= 1024

S = Source port , typically >= 1024

Administration: Cisco Expressway-E



		Management system source port	Expressway-E (listening) port
Management control		Private to DMZ	
Open firewall		Private to DMZ	
IP address		IP address of management computer(s)	IP address of Expressway-E
IP Ports	http	TCP S >= 1024	TCP 80 80
	https	TCP S >= 1024	TCP 443 443
	ssh	TCP S >= 1024	TCP 22 22
	SNMP	UDP S >= 1024	UDP 161 161

S = Source port , typically >= 1024


		PC listening port	Expressway-E source port
Management control		DMZ to private	
Open firewall		DMZ to private	
IP address		IP address of management computer(s)	IP address of Expressway-E
IP Ports	NTP	UDP 123 123	UDP 123 123
	LDAP (for login)	TCP 389 or 636 389 or 636	TCP Ue 30000 to 35999
	Syslog	UDP 514 514	UDP Ve 30000 to 35999

Ue = Expressway TCP ephemeral port range defaults to 30000 to 35999

Ve = Expressway UDP ephemeral port range defaults to 30000 to 35999

Open ports only for the management methods to be used


Administration: Cisco Expressway-E



		Expressway-E source port	Server listening port
	Management control	DMZ to public	
	Open firewall	DMZ to public	
	IP address	IP address of Expressway-E	IP address of DNS Server
IP Ports	DNS	UDP S >= 1024	UDP 53 53

S = Source port , typically >= 1024


Unified Communications : Expressway-C to Unified CM, IM&P



		Management system listening port	Expressway-C source port
		←-----→	
Management control		Private network	
Open firewall		n/a	
IP address		IP address of Unified CM, IM and Presence servers and CUC	IP address of Expressway-C
IP Ports	XMPP (IM and Presence)	TCP 7400 (IM&P server)	TCP Ue 30000 to 35999
	UDS (provisioning and phonebook)	TCP 8443 (Unified CM server)	TCP Ue 30000 to 35999
	SOAP (IM and Presence Service)	TCP 8443 (IM&P node)	TCP Ue 30000 to 35999
	HTTP (configuration file retrieval)	TCP 6970 (Unified CM server)	TCP Ue 30000 to 35999
	CUC (voicemail)	TCP 443 (CUC server)	TCP Ue 30000 to 35999

Ue = Expressway TCP ephemeral port range defaults to 30000 – 35999

Unified Communications : Control (private) to Expressway (DMZ)



		Expressway-C source port	Expressway-E server (listening) port
Message direction		Inbound and outbound calls	
Open firewall		Private to DMZ	
IP address		IP address of Expressway-C	IP address of Expressway-E
IP Ports	XMPP (IM and Presence)	TCP U_e 30000 to 35999	TCP 7400
	SSH (HTTP/S tunnels)	TCP U_e 30000 to 35999	TCP 2222
	SIP signaling	TCP & TLS A 25000 to 29999	TCP and TLS B 7001
	SIP media	UDP Y_C 36002 to 59999 *	UDP Y_E 36000 / 36001 *
	TURN server control	UDP >= 1024	UDP 3478 (to 3483) R

A = Protocols > SIP > TCP Outbound port start to end: *default = 25000 to 29999*

B = Zones > Traversal Client > SIP port, typically 7001 for first traversal zone, 7002 for second etc.

R = On Large Expressway systems you can configure a range of TURN request listening ports


U_e = Expressway TCP ephemeral port range defaults to 30000 to 35999

Y_C = Local Zone > Traversal Subzone > Traversal Media port start to end (configured on Expressway-C): *default = 36000 to 59999 **

Y_E = Local Zone > Traversal Subzone > Traversal Media port start to end (configured on Expressway-E): *default = 36000 to 59999 **

* In Large systems the first 12 ports in the range – 36000 to 36011 – are used for multiplexed traffic only. In Small/Medium systems you can either explicitly specify the 2 ports to use for multiplexed traffic or use the first 2 ports from the media port range.

Unified Communications: Expressway (DMZ) to public internet



		Expressway-E source port	Internet endpoint server (listening) port	Expressway-E server (listening) port	Internet endpoint source port
Message direction		Outbound to an endpoint in the Internet		Inbound from an endpoint in the Internet	
Open firewall		DMZ to Internet		Internet to DMZ	
IP address		Address of Expressway-E	Any IP address	Address of Expressway-E	Any IP address
IP Ports	XMPP (IM and Presence)	n/a	n/a	TCP 5222	TCP S ≥ 1024
	UDS (phonebook and provisioning)	n/a	n/a	TCP 8443	TCP S ≥ 1024
	TURN server control / media	n/a	n/a	UDP 3478 (to 3483) R / 24000 to 29999	UDP S ≥ 1024
	SIP signaling	TLS 25000 to 29999	TLS S ≥ 1024	TLS 5061	TLS S ≥ 1024
	SIP media	UDP Y_E 36002 to 59999 *	UDP N ≥ 1024	UDP Y_E 36002 to 59999 *	UDP N ≥ 1024

N = Expressway waits until it receives media, then it sends its media to the IP port from which the media was received (egress port of the media from the far end non SIP-aware firewall): any port ≥ 1024


R = On Large Expressway systems you can configure a range of TURN request listening ports

S = Source port, typically ≥ 1024

Y_E = Local Zone > Traversal Subzone > Traversal Media port start to end (configured on Expressway-E): default = 36000 to 59999 *

* In Large systems the first 12 ports in the range – 36000 to 36011 – are used for multiplexed traffic only. In Small/Medium systems you can either explicitly specify the 2 ports to use for multiplexed traffic or use the first 2 ports from the media port range.

Unified Communications: Jabber Guest (internet to Expressway-E)




S = Source port, typically ≥ 1024

		Expressway-E Listening Port	Internet SIP UA Source Port
Management Control		Inbound from SIP UA in the Internet	
Open Firewall		Internet to DMZ	
IP Address		IP address of - Expressway-E	IP address of - Any (or specific IP)
IP Ports	HTTPS traffic	TCP 9443	TCP S (to TCP 443)
	HTTP traffic	TCP 9980	TCP S (to TCP 80)
	TURN Server Control	UDP 3478 (to 3483)	UDP S ≥ 1024

Must translate the destination port of 443 to 9443 for all HTTPS (and 80 to 9980 for HTTP) traffic that targets the Expressway-E address from Jabber Guest clients.

Unified Communications: Jabber Guest (Expressway-C to Expressway-E)



		Expressway-C Source Port	Expressway-E Listening Port
Management Control		Outbound from Expressway-C to Expressway-E	
Open Firewall		Private to Public NAT'd	
IP Address		IP address of - Expressway-C	IP address of - Expressway-E (Public)
IP Ports	SSH (HTTP/S tunnels)	TCP E 30000 to 35999	SSH 2222
	Traversal Zone SIP signal	TLS T_C 25000 to 29999	TLS T_E
	Media	UDP Y_C 36002 to 59999	UDP Y_E 24000 to 29999

E = TCP ephemeral port range (on Expressway-C)


T_C = TCP outbound port range (on Expressway-C)

T_E = SIP port for Unified Communications traversal zone between Expressway-C (on Expressway-E)

Y_C = Traversal media ports range (on Expressway-C)

Y_E = TURN relays media ports range (Expressway-E)

Unified Communications: Jabber Guest (Expressway-E to Expressway-C)




		Expressway-C Listening Port	Expressway-E Source Port
Management Control		Inbound from Expressway-E (public) to Expressway-C	
Open Firewall		Public NAT'd to Private	
IP Address		IP address of - Expressway-C	IP address of - Expressway-E (public)
Ports	IP	Media UDP Y_C 36000 to 59999	Media UDP Y_E 24000 to 29999

Y_C = Traversal media ports range (on Expressway- C)

Y_E = TURN relays media ports range (on Expressway-E)


Unified Communications: XMPP federation (Expressway-C and Expressway-E / IM&P Server)



		Expressway-C Source Port	Expressway-E Listening Port
XMPP		Outbound from Expressway-C to Expressway-E (DMZ)	
Open Firewall		Private to DMZ	
IP Address		IP address of - Expressway-C	IP address of - Expressway-E
IP Ports	XMPP	TCP E (Ephemeral port)	TCP 7400
		IM&P Server Listening Port	Expressway-C Source Port
XMPP		Outbound from Expressway-C to IM&P Server	
Open Firewall		-	
IP Address		IP address of - IM&P Server	IP address of - Expressway-C
IP Ports	XMPP	TCP 7400	TCP E (Ephemeral port)

E = TCP ephemeral port range defaults to 30000 to 35999


Unified Communications: XMPP federation (Expressway-E and Internet)



		Expressway-E Listening Port	Federated XMPP Server Source Port
		←-----	
XMPP		Inbound from public internet to Expressway-E (DMZ)	
Open Firewall		Internet to DMZ	
IP Address		IP address of - Expressway-E	IP address of - Federated XMPP Server
IP Ports	XMPP	TCP 5269	TCP Ephemeral port
		Expressway-E Source Port	Federated XMPP Server Listening Port
		-----→	
XMPP		Outbound from Expressway-E (DMZ) to public internet	
Open Firewall		DMZ to Internet	
IP Address		IP address of - Expressway-E	IP address of - Federated XMPP Server
IP Ports	XMPP	TCP E (Ephemeral port)	TCP 5269

E = TCP ephemeral port range defaults to 30000 to 35999

SIP traversal call



		Expressway-C source port	Expressway-E listening port
Call direction		Inbound and outbound calls	
Open firewall		Private to DMZ	
IP address		IP address of Expressway-C	IP address of Expressway-E
IP Ports	SIP signaling	TCP & TLS A 25000 to 29999	TCP and TLS B 7001
	Assent RTP (traversal media)	UDP Y_C 36002 to 59998 *	UDP Y_E 36000 *
	Assent RTCP (traversal media)	UDP Y_C 36003 to 59999 *	UDP Y_E 36001 *

A = Protocols > SIP > TCP Outbound port start to end: *default = 25000 to 29999*


B = Zones > Traversal Client > SIP port, typically 7001 for first traversal zone, 7002 for second etc.

Y_C = Local Zone > Traversal Subzone > Traversal Media port start to end (configured on Expressway-C): *default = 36000 to 59999 **

Y_E = Local Zone > Traversal Subzone > Traversal Media port start to end (configured on Expressway-E): *default = 36000 to 59999 **

* In Large systems the first 12 ports in the range – 36000 to 36011 – are used for multiplexed traffic only. In Small/Medium systems you can either explicitly specify the 2 ports to use for multiplexed traffic or use the first 2 ports from the media port range.

SIP call to endpoint with public IP address



		Expressway-E source port	Internet endpoint server (listening) port	Expressway-E listening port	Internet endpoint source port
Call direction		Outbound to an endpoint in the Internet		Inbound from an endpoint in the Internet	
Open firewall		DMZ to Internet		Internet to DMZ	
IP address		IP address of Expressway-E	Any IP address	IP address of Expressway-E	Any IP address
IP Ports	SIP signaling	UDP C 5060 TCP & TLS A 25000 to 29999	UDP & TCP & TLS F 5060 or >= 1024	UDP: C 5060 TCP: K 5060 TLS: L 5061	UDP G 5060 or >= 1024 TCP & TLS H >= 1024
	RTP	UDP Y_E 36002 to 59998 *	UDP E >= 1024	UDP Y_E 36002 to 59998 *	UDP E >= 1024
	RTCP	UDP Y_E 36003 to 59999 *	UDP E >= 1024	UDP Y_E 36003 to 59999 *	UDP E >= 1024

C = Protocols > SIP > UDP port: *default* = 5060

A = Protocols > SIP > TCP Outbound port start to end: *default* = 25000 to 29999

F = IP port is defined by DNS lookup; any port >= 1024, often 5060 for UDP

K = Protocols > SIP > TCP port: *default* = 5060

L = Protocols > SIP > TLS port: *default* = 5061

G = any port >= 1024, often 5060 for hard endpoints


H = any port >= 1024

Y_E = Local Zone > Traversal Subzone > Traversal Media port start to end (configured on Expressway-E): *default* = 36000 to 59999 *

E = Endpoint media port range; value used is specified in the SDP:
 = any IP port above 1024
 = 36000 to 59999 * for another Expressway
 = 2326 to 2385 for MXP static setting
 = 11000 to 65000 for MXP dynamic setting

* In Large systems the first 12 ports in the range – 36000 to 36011 – are used for multiplexed traffic only. In Small/Medium systems you can either explicitly specify the 2 ports to use for multiplexed traffic or use the first 2 ports from the media port range.

SIP call to endpoint behind non SIP-aware firewall



		Expressway-E source port	Internet endpoint server (listening) port	Expressway-E listening port	Internet endpoint source port
Call direction		Outbound to an endpoint behind a firewall		Inbound from an endpoint behind a firewall	
Open firewall		DMZ to Internet		Internet to DMZ	
IP address		IP address of Expressway-E	Any IP address	IP address of Expressway-E	Any IP address
IP Ports	SIP signaling	UDP C 5060 TCP & TLS A 25000 to 29999	UDP & TCP & TLS F 5060 or ≥ 1024	UDP: C 5060 TCP: K 5060 TLS: L 5061	UDP, TCP & TLS: Q ≥ 1024
	RTP	UDP Y_E 36002 to 59998 *	UDP N ≥ 1024	UDP Y_E 36002 to 59998 *	UDP N ≥ 1024
	RTCP	UDP Y_E 36003 to 59999 *	UDP N ≥ 1024	UDP Y_E 36003 to 59999 *	UDP N ≥ 1024

C = Protocols > SIP > UDP port: *default = 5060*

A = Protocols > SIP > TCP Outbound port start to end: *default = 25000 to 29999*

F = IP port is defined by DNS lookup; any port ≥ 1024 , often 5060 for UDP

K = Protocols > SIP > TCP port: *default = 5060*

L = Protocols > SIP > TLS port: *default = 5061*


Q = Egress IP port from far end non-NAT aware firewall: any port ≥ 1024

Y_E = Local Zone > Traversal Subzone > Traversal Media port start to end (configured on Expressway-E): *default = 36000 to 59999 **

N = Expressway waits until it receives media, then it sends its media to the IP port from which the media was received (egress port of the media from the far end non SIP-aware firewall): any port ≥ 1024

* In Large systems the first 12 ports in the range – 36000 to 36011 – are used for multiplexed traffic only. In Small/Medium systems you can either explicitly specify the 2 ports to use for multiplexed traffic or use the first 2 ports from the media port range.

SIP – additional ports for ICE




		Expressway-E source port	Internet endpoint server (listening) port	Expressway-E listening port	Internet endpoint source port
message direction		Outbound from Expressway to endpoint in internet		Inbound from an endpoint in internet to Expressway	
Open firewall		DMZ to Internet		Internet to DMZ	
IP address		IP address of Expressway-E	Any IP address	IP address of Expressway-E	Any IP address
IP Ports	TURN server control	N/A	N/A	UDP R 3478 (to 3483)	UDP M >= 1024
	TURN server media	UDP 24000 to 29999	UDP N >= 1024	UDP 24000 to 29999	UDP N >= 1024

M = IP port of signalling from endpoint – may be ephemeral IP port of endpoint (if no firewall), or IP port of the outside firewall :
= any IP port above 1024

N = IP port of relevant ICE candidate – host IP port, Server reflexive IP port (outside firewall port) or TURN server port:
= any IP port above 1024

R = On Large Expressway systems you can configure a range of TURN request listening ports

H.323 traversal call using Assent



		Expressway-C source port	Expressway-E listening port
Call direction		Inbound and outbound calls	
Open firewall		Private to DMZ	
IP address		IP address of Expressway-C	IP address of Expressway-E
IP Ports	Initial RAS connection	UDP 1719	UDP D 6001
	Q 931 / H.225 signaling	TCP P 15000 to 19999	TCP T 2776
	H.245	TCP P 15000 to 19999	TCP T 2776
	Assent RTP (traversal media)	UDP Y_C 36002 to 59998 *	UDP Y_E 36000 *
	Assent RTCP (traversal media)	UDP Y_C 36003 to 59999 *	UDP Y_E 36001 *

P = Protocols > H.323 > Gatekeeper > Call signaling port range start to end:
default = 15000 to 19999

D = Zones > Traversal Zone > H.323 port, typically 6001 for first traversal zone,
6002 for second etc.


T = Traversal > Ports > H.323 Assent call signaling port: *default = 2776*

Y_C = Local Zone > Traversal Subzone > Traversal Media port start to end
(configured on Expressway-C): *default = 36000 to 59999 **

Y_E = Local Zone > Traversal Subzone > Traversal Media port start to end
(configured on Expressway-E): *default = 36000 to 59999 **

* In Large systems the first 12 ports in the range – 36000 to 36011 – are used for multiplexed traffic only. In Small/Medium systems you can either explicitly specify the 2 ports to use for multiplexed traffic or use the first 2 ports from the media port range.

H.323 traversal call using H.460.18 / 19 non-muxed media



		Expressway-C source port	Expressway-E listening port
Call direction		Inbound and outbound calls	
Open firewall		Private to DMZ	
IP address		IP address of Expressway-C	IP address of Expressway-E
IP Ports	Initial RAS connection	UDP 1719	UDP D 6001
	Q 931 / H.225 signaling	TCP P 15000 to 19999	TCP M 1720
	H.245	TCP P 15000 to 19999	TCP U 2777
	Assent RTP (traversal media)	UDP Y_C 36002 to 59998 *	UDP Y_E 36002 to 59998 *
	Assent RTCP (traversal media)	UDP Y_C 36003 to 59999 *	UDP Y_E 36003 to 59999 *

P = Protocols > H.323 > Gatekeeper > Call signaling port range start to end:
default = 15000 to 19999

D = Zones > Traversal Zone > H.323 port, typically 6001 for first traversal zone,
6002 for second etc.

M = Protocols > H.323 Call signaling TCP port: *default = 1720*


U = Traversal > Ports > H.323 H.460.18 call signaling port: *default = 2777*

Y_C = Local Zone > Traversal Subzone > Traversal Media port start to end
(configured on Expressway-C): *default = 36000 to 59999 **

Y_E = Local Zone < Traversal Subzone > Traversal Media port start to end
(configured on Expressway-E) : *default = 36000 to 59999 **

* In Large systems the first 12 ports in the range – 36000 to 36011 – are used for multiplexed traffic only. In Small/Medium systems you can either explicitly specify the 2 ports to use for multiplexed traffic or use the first 2 ports from the media port range.

H.323 traversal call using H.460.18 / 19 multiplexed media



		Expressway-C source port	Expressway-E listening port
Call direction		Inbound and outbound calls	
Open firewall		Private to DMZ	
IP address		IP address of Expressway-C	IP address of Expressway-E
IP Ports	Initial RAS connection	UDP 1719	UDP D 6001
	Q 931 / H.225 signaling	TCP P 15000 to 19999	TCP M 1720
	H.245	TCP P 15000 to 19999	TCP U 2777
	Assent RTP (traversal media)	UDP Y_C 36002 to 59998 *	UDP Y_E 36000 *
	Assent RTCP (traversal media)	UDP Y_C 36003 to 59999 *	UDP Y_E 36001 *

P = Protocols > H.323 > Gatekeeper > Call signaling port range start to end:
default = 15000 to 19999

D = Zones > Traversal Zone > H.323 port, typically 6001 for first traversal zone,
6002 for second etc.

M = Protocols > H.323 Call signaling TCP port: *default = 1720*


U = Traversal > Ports > H.323 H.460.18 call signaling port: *default = 2777*

Y_C = Local Zone > Traversal Subzone > Traversal Media port start to end
(configured on Expressway-C): *default = 36000 to 59999 **

Y_E = Local Zone < Traversal Subzone > Traversal Media port start to end
(configured on Expressway-E) : *default = 36000 to 59999 **

* In Large systems the first 12 ports in the range – 36000 to 36011 – are used for multiplexed traffic only. In Small/Medium systems you can either explicitly specify the 2 ports to use for multiplexed traffic or use the first 2 ports from the media port range.


H.323 call with a non-registered endpoint with public IP



		Expressway-E source port	Internet endpoint server (listening) port	Expressway-E listening port	Internet endpoint source port
Call direction		Outbound to an endpoint in the Internet		Inbound from an endpoint in the Internet	
Open firewall		DMZ to Internet		Internet to DMZ	
IP address		IP address of Expressway-E	Any IP address	IP address of Expressway-E	Any IP address
IP Ports	Initial RAS connection	-	-	-	-
	Q 931 / H.225 signaling	TCP P 15000 to 19999	TCP G 1720	TCP M 1720	TCP K 1720
	H.245	TCP P 15000 to 19999	TCP H ≥ 1024	TCP P 15000 to 19999	TCP H ≥ 1024
	RTP	UDP Y_E 36000 to 59998	UDP E ≥ 1024	UDP Y_E 36000 to 59998	UDP E ≥ 1024
	RTCP	UDP Y_E 36001 to 59999	UDP E ≥ 1024	UDP Y_E 36001 to 59999	UDP E ≥ 1024

- P** = Protocols > H.323 > Gatekeeper > Call signaling port range start to end: *default* = 15000 to 19999
- G** = Endpoint signaling port, specified by
 - a) IP Port in call request
 - b) DNS lookup for URI to call
 - c) 1720 if IP address but no port specified
 Can be: any port ≥ 1024, typically 1720
- M** = Protocols > H.323 Call signaling TCP port: *default* = 1720
- K** = Endpoint signaling port: any port ≥ 1024, typically 1720
- H** = Endpoint H.245 signaling port:
 - = any IP port ≥ 1024
 - = 15000 to 19999 to another Expressway
 - = 5555 to 5574 for MXP static setting
 - = 11000 to 65000 for MXP dynamic setting
- Y_E** = Local Zone > Traversal Subzone > Traversal Media port start to end (configured on Expressway-E): *default* = 36000 to 59999
- E** = Endpoint media port range; value used is specified in codec negotiations:
 - = any IP port above 1024
 - = 36000 to 59999 for another Expressway
 - = 2326 to 2385 for MXP static setting
 - = 11000 to 65000 for MXP dynamic setting

SIP: internal




		Expressway-C source port	Endpoint listening port	Expressway-C listening port	Endpoint source port
Call direction		Expressway-C to endpoint		Endpoint to Expressway-C	
Open firewall		n/a		n/a	
IP address		IP address of Expressway-C	IP address of endpoint	IP address of Expressway-C	IP address of endpoint
IP Ports	SIP signaling	UDP C 5060 TCP & TLS A 25000 to 29999	UDP & TCP & TLS F 5060 or >= 1024	UDP: C 5060 TCP: K 5060 TLS: L 5061	UDP G 5060 or >= 1024 TCP & TLS H >= 1024
	RTP	UDP Y_C 36002 to 59998 *	UDP E >= 1024	UDP Y_C 36002 to 59998 *	UDP E >= 1024
	RTCP	UDP Y_C 36003 to 59999 *	UDP E >= 1024	UDP Y_C 36003 to 59999 *	UDP E >= 1024

- C** = Protocols > SIP > UDP port: *default = 5060*
- A** = Protocols > SIP > TCP Outbound port start to end: *default = 25000 to 29999*
- F** = IP port is defined by DNS lookup; any port >= 1024, often 5060 for UDP
- K** = Protocols > SIP > TCP port: *default = 5060*
- L** = Protocols > SIP > TLS port: *default = 5061*
- G** = any port >= 1024, often 5060 for hard endpoints
- H** = any port >= 1024
- Y_C** = Local Zone > Traversal Subzone > Traversal Media port start to end (configured on Expressway-C): *default = 36000 to 59999 **
- E** = Endpoint media port range; value used is specified in the SDP:
 - = any IP port above 1024
 - = 36000 to 59999 * for another Expressway
 - = 2326 to 2385 for MXP static setting
 - = 11000 to 65000 for MXP dynamic setting

* In Large systems the first 12 ports in the range – 36000 to 36011 – are used for multiplexed traffic only. In Small/Medium systems you can either explicitly specify the 2 ports to use for multiplexed traffic or use the first 2 ports from the media port range.

H.323: internal




		Expressway-C source port	Endpoint listening port	Expressway-C listening port	Endpoint source port
Call direction		Expressway-C to endpoint		Endpoint to Expressway-C	
Open firewall		n/a		n/a	
IP address		IP address of Expressway-C	Any IP address	IP address of Expressway-C	Any IP address
IP Ports	Initial RAS connection	-	-	UDP 1719	UDP J 1719
	Q 931 / H.225 signaling	TCP P 15000 to 19999	TCP G 1720	TCP M 1720	TCP K 1720
	H.245	TCP P 15000 to 19999	TCP H >= 1024	TCP P 15000 to 19999	TCP H >= 1024
	RTP	UDP Y _C 36002 to 59998 *	UDP E >= 1024	UDP Y _C 36002 to 59998 *	UDP E >= 1024
	RTCP	UDP Y _C 36003 to 59999 *	UDP E >= 1024	UDP Y _C 36003 to 59999 *	UDP E >= 1024

- J** = Endpoint RAS source port, typically 1719
- P** = Protocols > H.323 > Gatekeeper > Call signaling port range start to end: *default* = 15000 to 19999
- G** = Endpoint signaling port, any port >= 1024, typically 1720
- M** = Protocols > H.323 Call signaling TCP port: *default* = 1720
- K** = Endpoint signaling port: any port >= 1024, typically 1720
- H** = Endpoint H.245 signaling port:
= any IP port >= 1024
= 15000 to 19999 to another Expressway
= 5555 to 5574 for MXP static setting
= 11000 to 65000 for MXP dynamic setting
- Y_C** = Local Zone > Traversal Subzone > Traversal Media port start to end (configured on Expressway-C): *default* = 36000 to 59999 *
- E** = Endpoint media port range; value used is specified in codec negotiations:
= any IP port above 1024
= 36000 to 59999 * for another Expressway
= 2326 to 2385 for MXP static setting
= 11000 to 65000 for MXP dynamic setting

* In Large systems the first 12 ports in the range – 36000 to 36011 – are used for multiplexed traffic only. In Small/Medium systems you can either explicitly specify the 2 ports to use for multiplexed traffic or use the first 2 ports from the media port range.

SIP B2BUA and Microsoft Lync



* On Large Expressway systems you can configure a range of TURN request listening ports (3478 to 3483).

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Cisco and the Cisco Logo are trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and other countries. A listing of Cisco's trademarks can be found at www.cisco.com/go/trademarks. Third party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1005R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

© 2014 Cisco Systems, Inc. All rights reserved.