

Cisco Sensor Connect for IoT Services Quick Start Guide

Overview of Cisco Sensor Connect for IoT Services

Cisco Sensor Connect for IoT Services solution enables delivery of advanced BLE capabilities over Cisco Catalyst Wireless infrastructure. The key component of this solution is the IoT Orchestrator which is a Cisco IOx application that can be deployed on any existing Cisco Catalyst 9800 Wireless Controller platforms running software version Cisco IOS-XE 17.15.3 and later. With the Cisco Sensor Connect for IoT Services solution, you have capabilities to securely onboard and control BLE devices, and consume data telemetry using the Message Queuing Telemetry Transport (MQTT).

Prerequisites for IoT Orchestrator

- Controller must be configured for initial configuration with APs joined and clients connected to the network.
- Controller must run on version Cisco IOS-XE 17.15.3 or 17.17.1.
- Download the IoT Orchestrator (**Spaces Orchestrator Software**) image that will be posted in the following page:

<https://software.cisco.com/download/home/286323456/type>

For more information about the Sensor Connect for IoT Services, see the **Related Documentation**.

Related Documentation

- [Cisco Sensor Connect for IoT Services Configuration Guide](#)
- [Cisco Sensor Connect for IoT Services Programmability Guide](#)
- [Cisco Sensor Connect for IoT Services Online Help](#)
- [Cisco Sensor Connect for IoT Services Release Notes](#)

Licenses

- Cisco Spaces Smart Operation
- Cisco Spaces ACT
- Cisco Spaces Unlimited
- Cisco Wireless Advantage

System Configuration

Supported Cisco Wireless Controller Platforms

- Cisco Catalyst CW9800H1 and CW9800H2 Wireless Controllers
- Cisco Catalyst CW9800M Wireless Controller
- Cisco Catalyst 9800-40 Wireless Controller
- Cisco Catalyst 9800-80 Wireless Controller
- Cisco Catalyst 9800-L Wireless Controller

Supported Access Points

For supported access points, see the *Cisco Sensor Connect for IoT Services Release Notes, Release 1.1*.

Deployment Workflow




Figure 1.
Deployment Workflow

Day-0 Activities

- Deploying IoT Orchestrator Application on Cisco Catalyst 9800 Wireless Controller
- Launching IoT Orchestrator
- Day-0 WebUI Wizard for IoT Orchestrator Application
- Changing your Username and Password

Day-1 Activities

- Day-1: Configuring Cisco Catalyst 9800 Wireless Controller from IoT Orchestrator
- Register the Third-Party Applications
- **Error! Reference source not found.**
- Registering Partner Application to Interact with the IoT Orchestrator Application

Day-0: Deploying the IoT Orchestrator Application on Cisco Catalyst 9800 Wireless Controller

Before you begin

- Download IoT Orchestrator and save it on your system where you will login to the Controller Web UI.

Summary:

If you want to use the IoT Orchestrator application, you will need to deploy the IoT Orchestrator application on Cisco Catalyst 9800 Wireless Controller.

Deploying IoT Orchestrator Application on Cisco Catalyst 9800 Wireless Controller

Step 1. Log in to the Cisco Catalyst 9800 Wireless Controller Web UI.




Figure 2.
Cisco Catalyst 9800 Wireless Controller Web UI





Figure 3.
Configuration > Services > IoT Services

Step 2. Navigate to **Configuration > Services > IoT Services**.



Step 3. Enter the IP address of the IoT Orchestrator.

Note: The IP addresses must be unique and different from the other IP addresses configured in Cisco Catalyst 9800 Wireless Controller. If you configure an IP address that overlaps with other interfaces, you will get an error message as the deployment flow will fail. For example, in the subnet 192.168.1.0/30, 192.168.1.1 can be used as the IP address of the IoT Orchestrator, and 192.168.1.2 can be used as the IP address of the default gateway.

Step 4. Enter the subnet mask of the IoT Orchestrator.

Note: The recommended size of the mask is /30 that allows two valid hosts (IoT Orchestrator and VirtualPortGroup Interface of Cisco Catalyst 9800 Wireless Controller).

Step 5. Enter the IP address of the default gateway for the IoT Orchestrator.

Note: The default gateway IP address is the IP address of the VirtualPortGroup interface in Cisco Catalyst 9800 Controller.

Step 6. Enter the NAT IP address used by Cisco Access Points to reach the IoT Orchestrator.

Note: This configuration is necessary only when a direct connection between Cisco Access Points and the IoT Orchestrator is not possible, such as when a Cisco Catalyst 9800 Wireless Controller is behind a firewall or in a remote data center. For more information, see the **NAT Configuration** chapter in *Cisco Sensor Connect for IoT Services Configuration Guide*.

Step 7. In the **Image File Path** field, click **Select File** to select the IoT Orchestrator image and click **Open**.

Note: You must have the IoT Orchestrator image downloaded on your local machine.

Step 8. Click **Enable IoT Services** to upload the image from your machine to the Cisco Catalyst 9800 controller.




Figure 4.
Enabling IoT Services

You get to view a banner that displays the following status:

- Installing
- Activating
- Starting
- Running

Note: It might take few minutes to complete from Installation to Running.

Note:

- When the status moves from Installing to Activating, this implies that the application is installed by the Cisco IOS-XE infrastructure.
- When the status moves from Activating to Starting, this implies that the application is getting started by the Cisco IOS-XE infrastructure.
- When the status moves from Starting to Running, this implies that the application is in Running state.

Thus, the IoT Orchestrator image is uploaded from your laptop or computer to the Cisco Catalyst 9800 Wireless Controller.

Once the IoT Orchestrator application deployment is successful, you get to view the application name (IoT Orchestrator by default) and IP address of the application.




Figure 5.
Viewing Application Name and IP Address

NOTE:

- The Cisco IOS-XE application framework is used to deploy and start the containers. The application now runs as an IOx container in the Cisco Catalyst 9800 Wireless Controller.
- The use of app-hosting commands to install, uninstall, activate, deactivate, start, or stop is not supported and may lead to an error state of the IoT Orchestrator. The use of the IOx web interface (from **Configuration > Services > IOx**) is also not supported for performing any operations on the IoT Orchestrator. Only the IoT Services web interface (from **Configuration > Services > IoT Services**) is supported for Day-0 and Day-1 management operations for the IoT Orchestrator.

Launching IoT Orchestrator

Before you begin

- Ensure that the IoT Orchestrator status is in Running state.
- Ensure that the IP address of the IoT Orchestrator is reachable from your computer or laptop.
- The IoT Orchestrator may take up to an additional 2 minutes after reaching the Running state to discover HA capabilities in the Cisco Catalyst 9800 Wireless Controller and to synchronize all databases between controllers.

Summary:

If you want to access the IoT Orchestrator Web UI, you will need to launch the IoT Orchestrator application.

Procedure

On the **Configuration > Services > IoT Services** page, click **Launch IoT Orchestrator**.




Figure 6.
Launching IoT Orchestrator

Note: To verify the IP network is reachable, you will need to ping the IP address using the terminal session.

When there is a firewall or similar device (such as a router with Access Control Lists (ACLs)), between Cisco Access Points and Wireless IoT Orchestrator or between Wireless IoT Orchestrator and external custom application, the firewall or similar device must be configured with rules that allow proper connectivity.

Connectivity Between Cisco Access Points and Wireless IoT Orchestrator

The following ports must be opened from Cisco Access Points to Wireless IoT Orchestrator:

Table 1. Protocol, Port, and Usage Details

Protocol	Port	Usage
TCP	50221	AP initial HTTP Connection with Wireless IoT Orchestrator
TCP	43626	Establish a gRPC connection with Wireless IoT Orchestrator

Connectivity Between External Applications and Wireless IoT Orchestrator

The following ports must be opened from external application to Wireless IoT Orchestrator:

Table 2. Protocol, Port, and Usage Details

Protocol	Port	Usage
TCP	8081	Wireless IoT Orchestrator REST API interface
TCP	41883	MQTT Publisher listening port

Licensing Details to Use IoT Orchestrator

Read the terms and conditions and click **I Accept**.

By installing and using IoT Orchestrator you agree to the following terms:

Your use of IoT Orchestrator and/or the Spaces Connect for IoT Services feature (hereinafter "Spaces Connect"), is governed by [Cisco's General Terms](#). To use IoT Orchestrator and Spaces Connect, make sure you have appropriate **wireless licenses**.

By Clicking "**I Accept**" below, you represent and warrant that you agree to these terms and that you have purchased the appropriate Cisco Spaces licenses required for the use of the Spaces Connect feature (one license per device). If you do not agree with any of the above, do not proceed to use IoT Orchestrator and Spaces Connect, and click "Decline".

I Accept

Decline

The **IoT Orchestrator** login page is displayed.




Figure 7.
IoT Orchestrator Login Page

Day-0 WebUI Wizard for IoT Orchestrator Application

Summary:

To login to the IoT Orchestrator application for Day-0, you will need to perform the following steps:

Procedure

Enter **admin** for username and **password** for password (default credentials).




Figure 8.
Default Credentials Login Page

Changing your Username and Password

Summary:

To create a Day-0 user profile, you will need to change the default username and password.

Note:

- You will need to enter the IoT Orchestrator password in the Login Page.
- This login is the IoT Orchestrator login credentials and not the same as the controller login credentials.




Figure 9.

Changing your Username and Password




Figure 10.

User Saved Successful Pop-Up

Note:

- If you do not remember your admin credentials, you will need to perform a password recovery procedure. For more information, see the *Recovering Admin Password from the Wireless IoT Orchestrator* document.
- If you enter the incorrect password three times consecutively, a lockdown timer will appear. After the timer completes, if you enter the login password incorrectly again, the timer will update, extending up to an hour.

Day-1: Configuring Cisco Catalyst 9800 Wireless Controller from IoT Orchestrator

In the IoT Orchestrator dashboard, choose the **Administrator > 9800 Wireless Controller configuration** page and perform the following:

Summary:

To connect the APs (available in the Controller) to the IoT Orchestrator, you will need to connect the IoT Orchestrator to the Cisco Catalyst 9800 Wireless Controller and push the token and certificate to the controller.

IoT Orchestrator Logout

Config eWLC

Connect with eWLC - Controller Not Configured

- Controller Username:
- Controller Wireless Management Interface IP:
- Controller Login Password:
- Controller Enable Password:
-

Figure 11.
Connect with the Controller

A pop-up window is displayed stating the following:

The connection establishment with the controller is successful.

Note: To verify if all the APs connected to the controller are connected to the IoT Orchestrator, check the **Inventory > Access Points** page from the IoT Orchestrator UI.

IoT Orchestrator Logout

AP Inventory

Total: 20 Connected: 20 Disconnected: 0 Refresh Export

show 50 ☐ Select all AP VERSION: 17.10.0.92 WLC IP ADDRESS: 10.195.78.100

AP NAME	AP MAC ADDRESS	AP PLATFORM	AP IP ADDRESS	STATUS	LAST HEARD	BLE MAC ADDRESS	BLE CONNECTIONS	RADIO STATUS
<input type="checkbox"/> AP-D4:E8-80:00:00:10	D4:E8-80:00:00:10	CW9166I-B	172.17.0.2	Connected	2024-07-23 15:04:48	30:FB:10:53:C0:B9	0 / 50	Up
<input type="checkbox"/> AP-D4:E8-80:00:00:00	D4:E8-80:00:00:00	CW9166I-B	172.17.0.2	Connected	2024-07-23 15:04:48	30:FB:10:53:C0:B9	0 / 50	Up
<input type="checkbox"/> AP-D4:E8-80:00:00:11	D4:E8-80:00:00:11	C9136I-B	172.17.0.2	Connected	2024-07-23 15:04:55	30:FB:10:53:C0:B9	0 / 50	Up
<input type="checkbox"/> AP-D4:E8-80:00:00:01	D4:E8-80:00:00:01	C9136I-B	172.17.0.2	Connected	2024-07-23 15:04:48	30:FB:10:53:C0:B9	0 / 50	Up
<input type="checkbox"/> AP-D4:E8-80:00:00:12	D4:E8-80:00:00:12	CW9166I-B	172.17.0.2	Connected	2024-07-23 15:04:55	30:FB:10:53:C0:B9	0 / 50	Up
<input type="checkbox"/> AP-D4:E8-80:00:00:13	D4:E8-80:00:00:13	C9136I-B	172.17.0.2	Connected	2024-07-23 15:04:55	30:FB:10:53:C0:B9	0 / 50	Up
<input type="checkbox"/> AP-D4:E8-80:00:00:02	D4:E8-80:00:00:02	CW9166I-B	172.17.0.2	Connected	2024-07-23 15:04:55	30:FB:10:53:C0:B9	0 / 50	Up
<input type="checkbox"/> AP-D4:E8-80:00:00:03	D4:E8-80:00:00:03	CW9166I-B	172.17.0.2	Connected	2024-07-23 15:04:55	30:FB:10:53:C0:B9	0 / 50	Up

Figure 12.
AP Inventory Page

AP BLE Transmit Configuration (Optional)

Transmit Configuration

Procedure

- Step 1.** Log in to the Cisco Catalyst 9800 Wireless Controller Web UI.
- Step 2.** From the **MENU**, choose **Configuration > Transmit Configuration**.




Figure 13.
IoT Orchestrator Dashboard – Configuration > Transmit Configuration

- Step 3.** Click **Add**.





Figure 14.
Transmit Configuration Page



Configuration Name : ④

☒ iBeacon
 ☐ ED url
 ☐ ED uid
 ☐ No Adv ⑤

UUID
 TX Power
 Major
 Minor
 Interval
 Adv TxPower


Save Config ⑥

Figure 15.
Transmit Configuration – Add Page

Step 4. Enter a name for the transmit configuration.

Step 5. Choose one of the following transmission methods:

- **iBeacon:** Enter the UUID, TX power, major, minor, interval, and Adv TxPower values.
- **ED url:** Enter the ED url.



Configuration Name : ×

☐ iBeacon
 ☒ ED url
 ☐ ED uid
 ☐ No Adv

ED Url

Save Config

Figure 16.
ED url Configuration

- **ED uid:** Enter the ED ns and ED instance values.

Configuration Name :

☐ iBeacon
 ☐ ED url
 ☒ ED uid
 ☐ No Adv

ED ns

ED Instance

Save Config

Figure 17.
ED uid Configuration

- **No Advertisement:**

Configuration Name :

☐ iBeacon
 ☐ ED url
 ☐ ED uid
 ☒ No Adv

This will create a No Advertisement Config profile!

Save Config

Figure 18.
No Adv Configuration

Step 9. Click Save Config.

☒

Transmit configuration saved successfully

Ok

Figure 19.
Transmit Configuration Successful Message




Figure 20.
Transmit Configuration List

Scan Configuration

Step 1. Log in to the Cisco Catalyst 9800 Wireless Controller Web UI.

Step 2. From the **MENU**, choose **Configuration > Scan Configuration**.




Figure 21.
IoT Orchestrator Dashboard – Configuration > Scan Configuration

Step 10. Click Add.




Figure 22.
Scan Configuration Page

Configuration Name :

Drop random private mac address

☐ true

☐ false

Enable

☐ true

☐ false

Confirm

Figure 23.
Configuration pop-up




Figure 24.
Scan Configuration Successful Message

The value gets added to the scan configuration list.

CONFIGURATION NAME	DROP RANDOM PRIVATE MAC	ENABLE	ACTION
default-ap-profile	true	true	
scan-config	true	true	

Figure 25.
Scan Configuration List

Register the Third-Party Applications

Summary:

If you want to access the BLE devices, you will need to register your third-party applications in the IoT Orchestrator application.

Uploading Custom Certificates for REST API Authentication

By default, the IoT Orchestrator listens on port 8081 for API requests over HTTPS. APIs are authenticated using API keys generated by the IoT Orchestrator, and the HTTPS server uses a self-signed certificate automatically provisioned by the IoT Orchestrator during the Day-0 flow.

To overwrite the default certificate, perform the following:

Step 1. Choose the **Administrator > Certificate Management** page. To generate certificates, see **Creating a Server Certificate** section.




Figure 26.

Administrator > Certificate Management Dashboard Page

The **Upload Certificates** page is displayed.

IoT Orchestrator

Logout

Upload Certificates

Server Identity :

Add your private key : No file chosen ②

Add your public key : No file chosen

☐ Authenticate using Certificates ③

Client Identity :

Add your trustroot : No file chosen ④

⑤

Figure 27.

Upload Certificates Page

Step 2. In the **Server Identity** section, select the private and public keys. To authenticate RESTful APIs using API keys, skip **Step 3** and **Step 4**.

Step 3. Select the **Auth using Certificates** check box to authenticate REST APIs with certificates.

Step 4. In the **Client Identity** section, select the root certificate for certificate verification during TLS handshake.

Step 5. Click **Submit** to validate the certificate and key.

A pop-up is displayed stating that the HTTPS server is created.

Creating a Server Certificate

The following process is required when using a certificate generated by a Certificate Authority (CA). By default, the IoT Orchestrator is ready to onboard or connect and stream data, creating self-signed certificates to secure requests to the REST API interface or when protecting MQTT streaming with a TLS layer. If a certificate signed by a Certificate Authority (CA) is needed, then a certificate signing request (CSR) is required.

The following procedure details how to obtain this CSR and upload it to the IoT Orchestrator:

Before you begin

- The **openssl** must be available in the terminal.

Step 1. Generate a private key and Certificate Signing Request (CSR) for server by executing the following commands:

```
openssl genrsa -out server.key 2048
```

```
openssl req -new -key server.key -out server.csr
```

You will be prompted to enter the following information:

- Country Name (2 letter code)
- State or Province Name (full name)
- Locality Name (e.g., city)
- Organization Name (e.g., company)
- Organizational Unit Name (e.g., department)
- Common Name (domain name or IP address of IoT Orchestrator)
- Email Address

Note: Use the CSR file generated with the Certificate Authority (CA) of your choice to generate a new certificate for the IoT Orchestrator.

Step 2. Upload the **server.key** and the certificate provided by your digital certificate service provider.

Note:

- If you want to authenticate RESTful APIs using APIKeys, you must attach the private key (**server.key**) and the certificate generated by the Certificate Authority (CA) of your choice. The former should be added within the **Add your private key** section and the later within the **Add your public key** section.
- To authenticate RESTful APIs using certificates, in addition to the private key (**server.key**) and the certificate generated by the Certificate Authority (CA), you will also need the Root Certificate, which can be downloaded from the Certificate Authority (CA) website. The Root Certificate should be added in the **Add your trustroot** field under the **Client Identity** section.

Note:

- The file extension for private key must be **.key**.
- The file extension for public key must be **.crt**.

Registering Partner Application to Interact with the IoT Orchestrator Application

Summary:

You need to register the partner applications (such as onboard application, control application, and data receiver application) to access BLE devices using the IoT Orchestrator.

You can register the partner applications using one of the following ways:

- API keys (or)
- Certificates. For information, see the **Auth using Certificates** in [Uploading Certificate and Key to Open HTTP Server and Listen for APIs](#) section.

How do you authorize:

You can authorize the applications by generating keys.

Procedure

Step 1. Choose the **Administrator > App Registration > Generate Keys**.




Figure 28.
Administrator > App Registration > Generate Keys Page

The **Generate Keys** page is displayed.

A screenshot of the 'Generate Keys' page in the IoT Orchestrator web application. The page has a light blue header with the 'IoT Orchestrator' logo and a 'Logout' button. The main content area is titled 'Generate Keys' and contains a form with the heading 'Enter your app ID to register'. Below the heading, there are four input fields labeled 'onboardApplication', 'controlAppID', 'controlApplication', and 'dataReceiverAppID'. A 'Submit' button is located at the bottom left of the form.

Figure 29.
Generate Keys

Step 2. Enter the application IDs for the onboard application, control application, and data receiver application.

Note:

- The application IDs are used to generate keys.
- The application IDs can be any string, but do not use the colon (':') character in the application ID, as it is not supported.

Step 3. Click **Submit**.

The keys are generated successfully.




Figure 30.
Keys Generated Message Pop-Up

Step 4. From MENU, choose the **Administrator > App Registration > Show Registered Apps**.




Figure 31.
Administrator > App Registration > Show Registered Apps Page

The **Registered Apps** page is displayed. You get to view the keys or certificates generated for the applications.

Log out

Registered Apps

APPLICATION ID	APPLICATION TYPE	AUTHENTICATION TYPE	KEY	CERTIFICATE	ACTION
controlApplication	CONTROL	APIKEY	b952d79d984a1ddfe6ed982280a552ab8b3664d08a6c089dcf8c0e6ee9752		
dataApplication	DATA	APIKEY	42bb0ca710f24a84d3b6674f69f3718047b8e2a91d24f26f6717131f3d9869f		
onboardApplication	ONBOARD	APIKEY	e4daa96b3387e36534fd1fdae6c50e530eb7468a448a8bb31d590ecc481eb319		

Figure 32.
Keys or Certificates Generated for Applications

Device Onboarding

For information on onboarding BLE devices using SCIM, see the Onboarding BLE Devices using SCIM section in *Cisco Sensor Connect for IoT Services Programmability Guide*.

BLE Inventory

Summary:

You will be able to view the information of the BLE devices that are onboarded in the IoT Orchestrator. Displays the BLE devices that are onboarded and the respective states.

Step 1. From the MENU, choose the **Inventory > BLE Client**.

MENU

Dashboard

Inventory

Access Point

BLE Client

Configuration

Serviceability

KPI

Administrator

Topic Subscription

Figure 33.
Inventory > BLE Client Page

BLE DEVICE ID	BLE MAC ADDRESS	BLE DEVICE NAME	ACCESS POINT	RSSI	CONNECTED TIME	LAST HEARD TIME	DEVICE STATE
912a45fa-feb0-4637-98f2-e6caf9b640a	FF:00:01:00:00:01	BLE Heart Monitor	-	0	-	-	ONBOARDED
449132d4-51d0-4ab8-a096-718890191c41	FF:00:04:00:00:03	BLE Heart Monitor	-	0	-	-	ONBOARDED
51d68c00-2dc3-4313-bc24-e439b30d755	FF:00:04:00:00:01	BLE Heart Monitor	-	0	-	-	ONBOARDED
3c2f5d3a-3d84-4556-8bb7-54917574dc59	FF:00:01:00:00:04	BLE Heart Monitor	-	0	-	-	ONBOARDED
a9972099-2699-4cb1-9441-d0d613652c45	FF:00:00:00:00:03	BLE Heart Monitor	-	0	-	-	ONBOARDED
8df052fe-fa36-4268-a7e2-a748f66ab6	FF:00:02:00:00:01	BLE Heart Monitor	-	0	-	-	ONBOARDED
182f654c-182b-481b-8d16-d7af3523018c	FF:00:03:00:00:00	BLE Heart Monitor	-	0	-	-	ONBOARDED
e544b284-74cc-42db-a15e-600012a09f50	FF:00:02:00:00:00	BLE Heart Monitor	-	0	-	-	ONBOARDED
c98e4d89-8c1a-4122-b96d-b00456a370a3	FF:00:00:00:00:00	BLE Heart Monitor	-	0	-	-	ONBOARDED
6b964962-4f0b-46ce-bcd3-5a81f0da3cf2	FF:00:00:00:00:01	BLE Heart Monitor	-	0	-	-	ONBOARDED
9624032c-9972-40c1-b391-7f8060698c25	FF:00:03:00:00:04	BLE Heart Monitor	-	0	-	-	ONBOARDED

Figure 34.
BLE Inventory

Device Control & Telemetry

Registering Data Receiver Application

Summary:

You will need to register the data receiver application to receive the streaming messages from the IoT Orchestrator.

For information on registering data application, see the **Registering the Data Receiver Application** section in *Cisco Sensor Connect for IoT Services Programmability Guide*.

Registering a Topic

Summary:

You will need to register the topic to receive the streaming messages from the BLE devices.

For information on registering a topic, see the **Registering a Topic** section in *Cisco Sensor Connect for IoT Services Programmability Guide*.

Subscribing to a Topic

Summary:

You will need to subscribe to a topic to receive the streaming messages from the BLE devices using the registered data receiver applications.

For information on subscribing to a topic, see the **Subscribing to Advertisements and Notifications** section in *Cisco Sensor Connect for IoT Services Programmability Guide*.

BLE Connectionless Use Case for Asset Tracking

For information on BLE connectionless use case, receive onboarded BLE device advertisements in Data Receiver application, see the **Use Case 1: Asset Tracking** section in **Cisco Sensor Connect for IoT Services Programmability Guide**.

BLE Connection Based Use Case

For information on BLE connection-based use case, see the **Use Case 2: Remote Patient Health Monitoring (requiring BLE connection, reading, and writing)** section in **Cisco Sensor Connect for IoT Services Programmability Guide**.

BLE Connection Based Use Case with GATT Notification

For information on BLE connection-based use case with GATT notification, see the **Use Case 3: BLE Notification-based Use Cases** section in **Cisco Sensor Connect for IoT Services Programmability Guide**.

Release Table

This document is the quick start guide for Cisco Sensor Connect for IoT Services.

Date	Release Version
April 1, 2025	Release 1.1

Communications, Services, and Additional Information

- To receive timely, relevant information from Cisco, sign up at [Cisco Profile Manager](#).
- To get the business impact you're looking for with the technologies that matter, visit [Cisco Services](#).
- To submit a service request, visit [Cisco Support](#).
- To discover and browse secure, validated enterprise-class apps, products, solutions, and services, visit [Cisco DevNet](#).
- To obtain general networking, training, and certification titles, visit [Cisco Press](#).
- To find warranty information for a specific product or product family, access [Cisco Warranty Finder](#).

Cisco Bug Search Tool

[Cisco Bug Search Tool](#) (BST) is a gateway to the Cisco bug-tracking system, which maintains a comprehensive list of defects and vulnerabilities in Cisco products and software. The BST provides you with detailed defect information about your products and software.

Documentation Feedback

To provide feedback about Cisco technical documentation, use the feedback form available in the right pane of every online document.

Copyright © 2025, Cisco Systems, Inc. All rights reserved.