

# Configuration of GARP VLAN Registration Protocol (GVRP) on 300 Series Managed Switches

## Objective

GARP VLAN registration protocol (GVRP) allows devices to dynamically exchange VLAN configuration information to make configuration of VLANs easier. When the switch receives VLAN information through GVRP and GVRP Registration, the receiving interface joins that VLAN. If an interface attempts to join a VLAN that does not exist and Dynamic VLAN creation is enabled, the switch automatically creates the VLAN.

This article explains how to enable and configure GVRP on the 300 Series Managed Switches.

## Applicable Devices

- SF/SG 300 Series Managed Switches

## Software Version

- v1.3.0.62

## Configure GVRP

### Globally Enable GVRP

Step 1. Log in to the web configuration utility and choose **VLAN Management > GVRP Settings**. The *GVRP Settings* page opens:

### GVRP Settings

GVRP Global Status:  Enable

#### GVRP Setting Table

Filter: *Interface Type* equals to

	Entry No.	Interface	GVRP State	Dynamic VLAN Creation	GVRP Registration
<input type="radio"/>	1	GE1	Disabled	Enabled	Enabled
<input type="radio"/>	2	GE2	Disabled	Enabled	Enabled
<input type="radio"/>	3	GE3	Disabled	Enabled	Enabled
<input type="radio"/>	4	GE4	Disabled	Enabled	Enabled
<input type="radio"/>	5	GE5	Disabled	Enabled	Enabled

Step 2. Check the **GVRP Global Status** check box to globally enable GVRP on the switch.

Step 3. Click **Apply** to enable GVRP features.

## Configure GVRP Settings

Step 1. Log in to the web configuration utility and choose **VLAN Management > GVRP Settings**. The *GVRP Settings* page opens:

### GVRP Settings

GVRP Global Status:  Enable

#### GVRP Setting Table

Filter: *Interface Type* equals to

	Entry No.	Interface	GVRP State	Dynamic VLAN Creation	GVRP Registration
<input type="radio"/>	1	GE1	Disabled	Enabled	Enabled
<input type="radio"/>	2	GE2	Disabled	Enabled	Enabled
<input type="radio"/>	3	GE3	Disabled	Enabled	Enabled
<input type="radio"/>	4	GE4	Disabled	Enabled	Enabled
<input type="radio"/>	5	GE5	Disabled	Enabled	Enabled

Step 2. Choose either **Port** or **LAG** from the Filter: Interface Type equals to drop-down list.

Step 3. Click **Go** to display the settings for the chosen interface type.

Step 4. Click the radio button of the interface on which you would like to configure GVRP.

Step 5. Click **Edit** to modify the GVRP settings for the selected interface. The *Edit GVRP Setting* window appears.

<input type="radio"/>	22	GE22	Disabled	Enabled	Enabled
<input type="radio"/>	23	GE23	Disabled	Enabled	Enabled
<input type="radio"/>	24	GE24	Disabled	Enabled	Enabled
<input checked="" type="radio"/>	25	GE25	Disabled	Enabled	Enabled
<input type="radio"/>	26	GE26	Disabled	Enabled	Enabled
<input type="radio"/>	27	GE27	Disabled	Enabled	Enabled
<input type="radio"/>	28	GE28	Disabled	Enabled	Enabled

Copy Settings... Edit...

Step 6. (Optional) Click the appropriate radio button and choose a new interface from the Port or LAG drop-down list to change the interface whose settings you want to change.

Interface:  Port GE25  LAG 1

GVRP State:  Enable

Dynamic VLAN Creation:  Enable

GVRP Registration:  Enable

Apply Close

**Note:** Ports must be configured in General or Trunk mode to support GVRP. For more information, refer to the article [Trunk Port Setup on the 200/300 Series Managed Switches](#).

Step 7. (Optional) Check the **Enable** check box in the *GVRP State* field to enable GVRP features on this interface.

Step 8. (Optional) Check the **Enable** check box in the *Dynamic VLAN Creation* field to have a VLAN dynamically created if it does not exist when GVRP information is received for that VLAN on the selected interface. If Dynamic VLAN Creation is disabled, the switch only recognizes VLANs that have been manually created.

Step 9. (Optional) Check the **Enable** check box in the *GVRP Registration* field to have the selected interface join a VLAN when GVRP information is received for that VLAN on the selected interface. If GVRP registration is disabled, an interface only associates with a VLAN that it is manually configured to be on.

Step 10. Click **Apply** to save the updated GVRP settings for the selected interface and then click **Close** to exit the *Edit GVRP Setting* window.

## Copy GVRP Settings

Step 1. Log in to the web configuration utility and choose **VLAN Management > GVRP Settings**. The *GVRP Settings* page opens:

### GVRP Settings

GVRP Global Status:  Enable

#### GVRP Setting Table

Filter: *Interface Type equals to*

	Entry No.	Interface	GVRP State	Dynamic VLAN Creation	GVRP Registration
<input type="radio"/>	1	GE1	Disabled	Enabled	Enabled
<input type="radio"/>	2	GE2	Disabled	Enabled	Enabled
<input type="radio"/>	3	GE3	Disabled	Enabled	Enabled
<input type="radio"/>	4	GE4	Disabled	Enabled	Enabled
<input type="radio"/>	5	GE5	Disabled	Enabled	Enabled

Step 2. Choose either **Port** or **LAG** from the *Filter: Interface Type equals to* drop-down list.

Step 3. Click **Go** to display the settings for the chosen interface type.

Step 4. (Optional) To copy the GVRP settings of one interface to several other interfaces, click the radio button of the desired interface and click **Copy Settings**. The *Copy Settings* window appears.

<input type="radio"/>	23	GE23	Disabled	Enabled	Enabled
<input type="radio"/>	24	GE24	Disabled	Enabled	Enabled
<input checked="" type="radio"/>	25	GE25	Enabled	Enabled	Enabled
<input type="radio"/>	26	GE26	Disabled	Enabled	Enabled
<input type="radio"/>	27	GE27	Disabled	Enabled	Enabled
<input type="radio"/>	28	GE28	Disabled	Enabled	Enabled

Step 5. Enter the interface number(s) or interface name(s) of the interface(s) to which you wish to copy the settings of the chosen interface in the provided field.

Copy configuration from entry 25 (GE25)

to:  (Example: 1,3,5-10 or GE1,GE3-GE5)

Step 6. Click **Apply** to apply the settings or click **Close** to cancel your changes.