



IW Monitor Management

- [IW MONITOR management, on page 1](#)
- [Configure IW MONITOR management using CLI, on page 2](#)
- [Configure IW MONITOR management using GUI, on page 2](#)

IW MONITOR management

IW MONITOR is a standalone on-premise monitoring application that enables comprehensive network visibility and management.

- Dashboard monitoring and topology visualization
- Real-time performance monitoring and telemetry data processing
- Network events logging for authentication and configuration changes

IW MONITOR capabilities and features

The on-premises IW MONITOR supports these primary capabilities:

- Dashboard to MONITOR network status
- Topology view of the network
- Real time and history charts for wireless Key Performance Indicators (KPIs)
- Real time performance monitoring
- Process the telemetry data sent by IW devices
- Network events logging

UIW Release 17.12.1 provides this support for IW MONITOR dashboard:

- Attach and detach functions.
- Telemetry protocol support.
- CLI and GUI management.

The following table outlines the IW MONITOR features supported from UIW release 17.12.1 onwards.

Table 1: IW MONITOR features support

Feature	Description
IW MONITOR log for RADIUS	RADIUS authentication attempts by mobile units are logged to IW MONITOR
IW MONITOR log CLI SSH access	SSH connections attempts are logged to IW MONITOR
IW MONITOR log GUI access	GUI logins are logged to IW MONITOR
IW MONITOR log ethernet link change	Physical link changes of LAN ports are buffered and logged to IW MONITOR
IW MONITOR log configuration change	Changes applied to the unit configuration through CLI or GUI are logged to MONITOR

Configure IW MONITOR management using CLI

Configure IW MONITOR management to enable network monitoring capabilities including dashboard monitoring, topology view, real-time performance monitoring, telemetry data processing, and network events logging.

IW MONITOR does not require any configuration, and access points are added to the IW MONITOR. Use the CLI to detach the device from the IW MONITOR server and troubleshoot the connection.

Procedure

Step 1 Use the **configure monitor detach** command to detach the device from the IW MONITOR server.

Example:

```
Device# configure monitor detach
```

Step 2 Use the **show monitor** command to verify the IW MONITOR management status.

Example:

```
Device# show monitor
IW MONITOR: enabled
Status: Connected
```

Configure IW MONITOR management using GUI

Enables IW MONITOR management to provide network monitoring capabilities.

The UIW Release 17.12.1 introduces support for IW MONITOR, a standalone on-premise monitoring application supporting network monitoring features.

Procedure


Step 1 Enable the **IW MONITOR** option in the **Cisco URWB IW9165E or IW9167E Configurator** window.

The screenshot displays the Cisco URWB IW9165E Configurator interface. The top header shows the Cisco logo and the text "Cisco URWB IW9165E Configurator" and "5.81.160.244 - MESH END MODE". On the left, a sidebar lists various settings categories: "IW Service" (Offline), "IW Monitor" (Disabled), "GENERAL SETTINGS", "NETWORK CONTROL", "ADVANCED SETTINGS", and "MANAGEMENT SETTINGS". The main content area is titled "GENERAL MODE" and contains the following settings:

- General Mode**: A sub-section with a note: "Select MESH POINT mode if you are attaching an IP edge device (i.e. network camera, encoder, etc.) to this Cisco IOT IW9165E Series Access Point or if you are using this unit as a relay point in the mesh network."
 - Mode**: Radio buttons for "mesh point" (selected), "mesh end", and "gateway".
 - Radio-off**: A checkbox that is currently unchecked.
- LAN Parameters**: A section with input fields for:
 - Local IP: 10.115.11.180
 - Local Netmask: 255.255.255.0
 - Default Gateway: 10.115.11.1
 - Local Dns 1: 8.8.8.8
 - Local Dns 2: (empty field)

At the bottom of the main content area, there are "Reset" and "Save" buttons. A copyright notice "© 2023 Cisco and/or its affiliates. All rights reserved." is visible at the very bottom of the page.

Step 2 Verify that the **IW-MONITOR connection info** appears.



ULTRA RELIABLE
WIRELESS BACKHAUL

Cisco URWB IW9165E Configurator
5.81.160.244 - MESH END MODE

IW Service Offline

IW Monitor Disabled

GENERAL SETTINGS

- general mode
- wireless radio
- antenna alignment and stats

NETWORK CONTROL

- advanced tools

ADVANCED SETTINGS

- advanced radio settings
- static routes
- allowlist / blocklist
- multicast
- snmp
- radius
- ntp
- ethernet filter
- l2tp configuration
- vlan settings
- Fluidity
- misc settings
- smart license

MANAGEMENT SETTINGS

- remote access
- firmware upgrade
- status
- configuration settings
- reset factory default
- reboot
- logout

IW-MONITOR

IW-MONITOR connection info

Server Host:	10.115.11.53
Status:	Connected

Detach

© 2023 Cisco and/or its affiliates. All rights reserved.