



## Configuring the DHCP Relay Agent

---

The Dynamic Host Configuration Protocol (DHCP) servers provide configuration parameters to DHCP clients. When DHCP clients and associated servers do not reside on the same IP network or subnet, a DHCP relay agent can transfer DHCP messages between them. To configure a DHCP relay agent on a CSS, define DHCP server destinations on a circuit and enable the DHCP relay agent on the circuit.

You must first assign an IP address on the circuit to be able to configure the DHCP relay agent for the circuit. Use the **ip address** command in the specific circuit mode to assign the IP address and a subnet mask. For example:

```
(config-circuit[VLAN2])# ip address 178.3.6.53/8
```

This chapter contains the following major sections:

- [DHCP Relay Agent Configuration Quick Start](#)
- [Enabling and Disabling DHCP on the Circuit](#)
- [Defining the Hops Field Value for Forwarding DHCP Messages](#)
- [Displaying the DHCP Relay Configuration](#)

# DHCP Relay Agent Configuration Quick Start

[Table 8-1](#) provides a quick overview of the steps required to configure the DHCP relay agent for the circuit. Each step includes the CLI command required to complete the task. For a complete description of each feature and all the options associated with the CLI command, see the sections following [Table 8-1](#).

**Table 8-1 DHCP Relay Agent Configuration Quick Start**

---

## Task and Command Example

---

1. Specify the DHCP relay destination IP address in dotted-decimal notation.

```
(config-circuit[VLAN2])# dhcp relay-to 192.168.22.25
```

---

2. Enable the DHCP relay agent on the CSS circuit.

```
(config-circuit[VLAN2])# dhcp-relay-agent
```

---

3. Set the maximum allowable number in the hops field of the BOOTP header.

```
(config)# dhcp-agent max-hops 10
```

---

4. (Optional) Verify the DHCP configuration.

```
(config)# # show dhcp-relay-agent global
```

---

The following running-configuration example shows the results of entering the commands in [Table 8-1](#).

```
!***** GLOBAL *****
  dhcp-agent max-hops 10

!***** CIRCUIT *****
circuit VLAN2
  dhcp relay-to 192.168.22.25
  dhcp-relay-agent
```

## Adding a DHCP Destination on a Circuit

A CSS circuit acts as the DHCP relay agent. For each circuit on the CSS, you can configure a maximum of five DHCP destinations. The initial DHCP broadcast request is sent to all of the configured destinations.

Do not configure a relay destination on a circuit when the relay destination is directly connected to or reachable from one of the ports on the same circuit. In this case, the DHCP packets reach the relay destination through normal broadcast and a relay agent is not required.

Use the **dhcp relay-to** command to specify the DHCP relay destination address. This command is available in circuit configuration mode. Enter an IP address in dotted-decimal notation.

For example, to add a destination address of 192.168.22.25 to a DHCP server, enter:

```
(config-circuit[VLAN2])# dhcp relay-to 192.168.22.25
```

To remove the relay destination address, enter:

```
(config-circuit[VLAN2])# no dhcp relay-to 192.168.22.25
```

## Enabling and Disabling DHCP on the Circuit

After you enable the DHCP relay agent on the CSS circuit, the CSS transfers DHCP messages between DHCP clients and servers. Use the **dhcp-relay-agent** command to enable the agent on the circuit. This command is available in circuit configuration mode.

For example:

```
(config-circuit[VLAN2])# dhcp-relay-agent
```

To disable the DHCP relay agent on the circuit, enter:

```
(config-circuit[VLAN2])# no dhcp-relay-agent
```

# Defining the Hops Field Value for Forwarding DHCP Messages

The CSS forwards or discards a DHCP message based on the hops field value in the BOOTP header. When messages have values in the hops fields that exceed the maximum value set on the CSS, the CSS discards the message. Use the **dhcp-agent max-hops** global configuration command to set the maximum allowable number in the hops field. By default, the maximum allowable number is 4. You can set a number from 1 to 15.

For example, to set the maximum allowable value of 10, enter:

```
(config)# dhcp-agent max-hops 10
```

To reset the maximum allowable number in the hops field to the default of 4, enter:

```
(config)# no dhcp-agent max-hops
```

## Displaying the DHCP Relay Configuration

Use the **show dhcp-relay-agent global** command to display the DHCP configuration information on the CSS. This command is available in all modes. For example:

```
# show dhcp-relay-agent global
```

[Table 8-2](#) describes the fields in the **show dhcp-relay-agent global** command output.

**Table 8-2** Field Descriptions for the **show dhcp-relay-agent global** Command

Field	Description
Max Hops	The maximum allowable number in the hops field of the BOOTP header. The CSS does not forward packets with headers that contain a larger number.
Number of circuits configured for DHCP	The number of CSS circuits configured for DHCP.
Circuit	The circuit configured for DHCP.

**Table 8-2** *Field Descriptions for the show dhcp-relay-agent global Command*

<b>Field</b>	<b>Description</b>
IfAddress	The interface address for the circuit.
DHCP State	The DHCP relay agent state on the circuit (Enabled or Disabled).
Relay destination	The DHCP relay destination address for the server. Each circuit can have five destination addresses.

■ **Displaying the DHCP Relay Configuration**