



## Cisco WAAS Software Command Summary

This chapter summarizes the Cisco WAAS 6.1.1 software commands.

[Table 2-1](#) lists the WAAS commands (alphabetically) and indicates the command mode for each command. The commands used to access configuration modes are marked with an asterisk. Commands that do not indicate a particular mode are EXEC mode commands. The same command may have different effects when entered in a different command mode, so they are listed and documented separately. (See [Chapter 1, “Using the WAAS Command-Line Interface”](#) for a discussion about using CLI command modes.)

In [Table 2-1](#), in the Device Mode column “All” indicates that the particular CLI command is supported in both central-manager mode and application-accelerator mode.

**Table 2-1** Command Summary

Command	Description	CLI Mode	Device Mode
<a href="#">(config) aaa accounting</a>	Configures AAA accounting.	global configuration	All
<a href="#">(config) aaa authorization commands</a>	Configures AAA authorization.	global configuration	All
<a href="#">(config) accelerator epm</a>	Enables the EPM application accelerator.	global configuration	application- accelerator
<a href="#">(config) accelerator http</a>	Enables the HTTP application accelerator.	global configuration	application- accelerator
<a href="#">(config) accelerator ica</a>	Enables the ICA application accelerator.	global configuration	application- accelerator
<a href="#">(config) accelerator mapi</a>	Enables the MAPI application accelerator.	global configuration	application- accelerator
<a href="#">(config) accelerator nfs</a>	Enables the NFS application accelerator.	global configuration	application- accelerator
<a href="#">(config) accelerator smb</a>	Enables the SMB application accelerator.	global configuration	application- accelerator
<a href="#">(config) accelerator ssl</a>	Enables the SSL application accelerator.	global configuration	application- accelerator
<a href="#">(config) alarm overload-detect</a>	Configures the detection of an alarm overload.	global configuration	All

Table 2-1 Command Summary (continued)

Command	Description	CLI Mode	Device Mode
(config) asset	Configures the tag name for the asset tag string.	global configuration	All
(config-wccp-service) assignment-method	Configures the WCCP assignment method.	WCCP configuration	application- accelerator
(config-sn) authentication	Configures the WN authentication key.	service node configuration	application- accelerator
(config) authentication configuration	Configures administrative authentication and authorization parameters.	global configuration	All
(config)authentication enable	Configures enable authentication to use local admin user account password instead of using external authentication servers.	global configuration	application- accelerator central manager
(config) authentication content-request	Configures request for content authentication and authorization parameters.	global configuration	All
(config) authentication fail-over	Configures authentication failover if the primary authentication server is unreachable.	global configuration	All
(config) authentication login	Configures administrative login authentication and authorization parameters.	global configuration	All
(config) authentication strict-password-policy	Configures strong password policy parameters.	global configuration	All
(config) auto-discovery	Discovers origin servers that cannot receive TCP packets with options and adds the IP addresses to a blacklist for a specified number of minutes.	global configuration	application- accelerator
(config) auto-register	Enables the discovery of a primary interface on a WAE and its automatic registration with the WAAS Central Manager through DHCP.	global configuration	application- accelerator
(config-if) autosense	Sets the current interface to autosense.	interface configuration	All
(config-if) bandwidth	Sets the specified interface bandwidth to 10, 100, or 1000 Mbps.	interface configuration	All
(config) banner	Configures message-of-the-day, login, login and EXEC banners.	global configuration	All
(config-ca) ca-certificate	Sets the certification authority file.	certification authority configuration	All
cd	Changes the directory.	user-level EXEC and privileged-level EXEC	All
(config) cdp	Enables the Cisco Discovery Protocol (CDP) for the WAAS device.	global configuration	All
(config-if) cdp	Enables CDP on an interface.	interface configuration	All

Table 2-1 Command Summary (continued)

Command	Description	CLI Mode	Device Mode
(config) central-manager	In application-accelerator mode, used to specify the IP address of the WAAS Central Manager with which the WAE needs to register. In central-manager mode, used to specify the WAAS Central Manager's role and GUI port number.	global configuration	All
(config-if) channel-group	Configures the port channel group for an interface.	interface configuration	All
(config-cipher-list) cipher	Configures a cipher suite on the cipher list.	cipher list configuration	All
(config-ssl-accelerated) cipher-list	Configures secure socket layer (SSL) encryption cipher lists on a WAAS device.	SSL accelerated service configuration	All
(config-ssl-global) cipher-list	Configures secure socket layer (SSL) encryption cipher lists on a WAAS device.	SSL global service configuration	All
(config-ssl-peering) cipher-list	Configures secure socket layer (SSL) encryption cipher lists on a WAAS device.	SSL host peering service configuration	All
(config-ssl-mgmt) cipher-list	Configures secure socket layer (SSL) encryption cipher lists on a WAAS device.	SSL management service configuration	All
(config) class-map	Configures optimization class maps.	global configuration	application- accelerator
clear arp-cache	Resets the ARP cache.	privileged-level EXEC	application- accelerator
clear cache	Resets the cached objects.	privileged-level EXEC	application- accelerator
clear cdp	Resets Cisco Discovery Protocol statistics.	privileged-level EXEC	All
clear connection	Resets one or more connections.	privileged-level EXEC	application- accelerator
clear dre	Clears DRE configurations.	privileged-level EXEC	All
clear ip	Resets IP access list statistics.	privileged-level EXEC	All
clear license	Resets licensing configuration.	privileged-level EXEC	All
clear logging	Resets the syslog messages saved in a disk file.	privileged-level EXEC	All
clear statistics	Resets statistics data.	privileged-level EXEC	All

Table 2-1 Command Summary (continued)

Command	Description	CLI Mode	Device Mode
<a href="#">clear statistics accelerator</a>	Resets all global statistics.	privileged-level EXEC	All
<a href="#">clear statistics connection</a>	Resets connection statistics.	privileged-level EXEC	All
<a href="#">clear transaction-log</a>	Archives the working transaction log file.	privileged-level EXEC	application accelerator
<a href="#">clear users</a>	Resets user connections or unlocks users that have been locked out.	privileged-level EXEC	All
<a href="#">clear windows-domain</a>	Clears Windows domain server information.	privileged-level EXEC	All
<a href="#">clear windows-domain-log</a>	Clears user connections and unlocks users that have been locked out.	privileged-level EXEC	All
<a href="#">(config-ssl-accelerated) client-cert-verify</a>	Enables verification of client certificates.	SSL accelerated service configuration	All
<a href="#">(config-ssl-accelerated) client-cert-key</a>	Configures a certificate and private key	SSL accelerated service configuration	All
<a href="#">(config-ssl-accelerated) client-version-rollback-check</a>	Disables the client SSL version rollback check.	SSL accelerated service configuration	All
<a href="#">clock</a>	Manages the system clock.	privileged-level EXEC	All
<a href="#">(config) clock</a>	Sets the summer daylight saving time of day and time zone.	global configuration	All
<a href="#">cms</a>	Configures the parameters for the Centralized Management System (CMS) embedded database.	privileged-level EXEC	All
<a href="#">cms secure-store</a>	Configures secure store encryption	privileged-level EXEC	All
<a href="#">(config) cms</a>	Schedules the maintenance and enables the Centralized Management System on a specific WAAS device.	global configuration	All
<a href="#">configure*</a>	Enters configuration mode from privileged EXEC mode.	privileged-level EXEC	All
<a href="#">copy cdrom</a>	Copies files from a CD-ROM.	privileged-level EXEC	All
<a href="#">copy compactflash</a>	Copies files from the Compact Flash card.	privileged-level EXEC	All
<a href="#">copy disk</a>	Copies configuration information or files from a disk.	privileged-level EXEC	All
<a href="#">copy ftp</a>	Copies files from an FTP server.	privileged-level EXEC	All

Table 2-1 Command Summary (continued)

Command	Description	CLI Mode	Device Mode
<code>copy http</code>	Copies files from an HTTP server.	privileged-level EXEC	All
<code>copy monitoring-log</code>	Copies SMB statistics data to the local disk or an FTP server.	privileged-level EXEC	All
<code>copy running-config</code>	Copies information from the current system configuration.	privileged-level EXEC	All
<code>copy scp</code>	Copies files from an SCP server.	privileged-level EXEC	All
<code>copy startup-config</code>	Copies information from the startup configuration.	privileged-level EXEC	All
<code>copy sysreport</code>	Copies system troubleshooting information.	privileged-level EXEC	All
<code>copy system-status</code>	Copies the system status for debugging reference.	privileged-level EXEC	All
<code>copy tech-support</code>	Copies system information for technical support.	privileged-level EXEC	All
<code>copy tftp</code>	Copies the software image from the TFTP server.	privileged-level EXEC	All
<code>copy usb</code>	Copies files from an external USB drive.	privileged-level EXEC	All
<code>cpfile</code>	Copies a file to the current directory.	privileged-level EXEC	All
<code>crypto delete</code>	Removes SSL certificate and key files.	privileged-level EXEC	application- accelerator
<code>crypto export</code>	Exports SSL certificate and key files.	privileged-level EXEC	application- accelerator
<code>crypto generate</code>	Generates a self-signed certificate or a certificate signing request.	privileged-level EXEC	All
<code>crypto import</code>	Imports SSL certificate and key files.	privileged-level EXEC	application- accelerator
<code>crypto pki</code>	Initializes the PKI managed store.	privileged-level EXEC	All
<code>(config) crypto pki</code>	Configures public key infrastructure (PKI) encryption parameters.	global configuration	All
<code>(config) crypto ssl</code>	Configures secure sockets layer (SSL) encryption parameters.	global configuration	All
<code>debug aaa accounting</code>	Configures AAA accounting debugging.	privileged-level EXEC	All
<code>debug aaa authorization</code>	Configures AAA authorization debugging.	privileged-level EXEC	All
<code>debug accelerator</code>	Configures accelerator debugging.	privileged-level EXEC	application- accelerator

Table 2-1 Command Summary (continued)

Command	Description	CLI Mode	Device Mode
<a href="#">debug all</a>	Configures all debugging.	privileged-level EXEC	All
<a href="#">debug authentication</a>	Configures authentication debugging.	privileged-level EXEC	All
<a href="#">debug auto-discovery</a>	Configures auto discovery debugging.	privileged-level EXEC	application- accelerator
<a href="#">debug buf</a>	Configures buffer manager debugging.	privileged-level EXEC	All
<a href="#">debug cdp</a>	Configures CDP debugging.	privileged-level EXEC	All
<a href="#">debug cli</a>	Configures CLI debugging.	privileged-level EXEC	All
<a href="#">debug cmm</a>	Configures cluster membership manager debugging.	privileged-level EXEC	All
<a href="#">debug cms</a>	Configures CMS debugging.	privileged-level EXEC	All
<a href="#">debug connection</a>	Configures connection debugging.	privileged-level EXEC	application- accelerator
<a href="#">debug dataserver</a>	Configures data server debugging.	privileged-level EXEC	All
<a href="#">debug dhcp</a>	Configures DHCP debugging.	privileged-level EXEC	All
<a href="#">debug dre</a>	Configures DRE debugging.	privileged-level EXEC	application- accelerator
<a href="#">debug egress-method</a>	Configures egress method debugging.	privileged-level EXEC	application- accelerator
<a href="#">debug encryption-service</a>	Configures encryption service debugging.	privileged-level EXEC	All
<a href="#">debug fda</a>	Configures flow distribution agent service debugging.	privileged-level EXEC	All
<a href="#">debug fdm</a>	Configures flow distribution manager service debugging.	privileged-level EXEC	All
<a href="#">debug filtering</a>	Configures filtering debugging.	privileged-level EXEC	application- accelerator
<a href="#">debug flow</a>	Configures network traffic flow debugging.	privileged-level EXEC	All
<a href="#">debug generic-gre</a>	Configures generic GRE egress method debugging.	privileged-level EXEC	application- accelerator
<a href="#">debug hw-raid</a>	Configures hardware RAID debugging.	privileged-level EXEC	All
<a href="#">debug imd</a>	Configures interface manager debugging.	privileged-level EXEC	All

Table 2-1 Command Summary (continued)

Command	Description	CLI Mode	Device Mode
<code>debug inline</code>	Configures inline debugging.	privileged-level EXEC	All
<code>debug key-manager</code>	Configures key manager debugging.	privileged-level EXEC	central-manager
<code>debug logging</code>	Configures logging debugging.	privileged-level EXEC	All
<code>debug monapi</code>	Configures monitoring API debugging.	privileged-level EXEC	central-manager
<code>debug ntp</code>	Configures NTP debugging.	privileged-level EXEC	All
<code>debug rbcip</code>	Configures RBCIP debugging.	privileged-level EXEC	application- accelerator
<code>debug rmd</code>	Configures route manager debugging.	privileged-level EXEC	All
<code>debug rpc</code>	Configures record remote procedure calls debugging.	privileged-level EXEC	All
<code>debug service-insertion</code>	Configures service-insertion module debugging.	privileged-level EXEC	All
<code>debug service-policy</code>	Configures service policy debugging.	privileged-level EXEC	All
<code>debug snmp</code>	Configures SNMP debugging.	privileged-level EXEC	All
<code>debug standby</code>	Configures standby debugging.	privileged-level EXEC	application- accelerator
<code>debug statistics</code>	Configures statistics debugging.	privileged-level EXEC	All
<code>debug tfo</code>	Configures TFO flow optimization debugging.	privileged-level EXEC	application- accelerator
<code>debug translog</code>	Configures transaction logging debugging.	privileged-level EXEC	application- accelerator
<code>debug wccp</code>	Configures WCCP information debugging.	privileged-level EXEC	application- accelerator
<code>(config-std-nacl) delete</code>	Deletes a line from the standard ACL.	standard ACL configuration	All
<code>(config-ext-nacl) delete</code>	Deletes a line from the extended ACL.	extended ACL configuration	All
<code>delfile</code>	Deletes a file.	privileged-level EXEC	All
<code>deltree</code>	Deletes a directory and its subdirectories.	privileged-level EXEC	All

Table 2-1 Command Summary (continued)

Command	Description	CLI Mode	Device Mode
<code>(config-std-nacl) deny</code>	Adds a line to a standard access list that specifies the type of packets that you want the WAAS device to drop.	standard ACL configuration	All
<code>(config-ext-nacl) deny</code>	Adds a line to an extended access-list that specifies the type of packets that you want the WAAS device to drop.	extended ACL configuration	All
<code>(config-ca) description</code>	Configures a description for the certification authority.	certification authority configuration	All
<code>(config-if) description</code>	Configures the description for an interface.	interface configuration	All
<code>(config-ssl-accelerated) description</code>	Configures a description for SSL accelerated service.	SSL accelerated service configuration	All
<code>(config) device mode</code>	Specifies the device mode of the WAAS device.	global configuration	All
<code>dir</code>	Displays the files in a long list format.	user-level EXEC and privileged-level EXEC	All
<code>disable</code>	Turns off the privileged EXEC commands.	privileged-level EXEC	All
<code>disk</code>	Configures the disks on the WAAS device.	privileged-level EXEC	All
<code>(config) disk disk-name</code>	Disables a RAID-1 disk for online removal.	global configuration	All
<code>(config) disk cache</code>	Configures Akamai cache and Object cache partitions	global configuration	application-accelerator
<code>(config) disk encrypt</code>	Enables disk encryption.	global configuration	application- accelerator
<code>(config) disk error-handling</code>	Configures how the disk errors should be handled.	global configuration	All
<code>(config) disk logical shutdown</code>	Shuts down the RAID-5 logical disk drive.	global configuration	All
<code>(config) disk object-cache extend</code>	Enables extended object cache.	global configuration	All
<code>dnslookup</code>	Resolves a DNS hostname.	user-level EXEC and privileged-level EXEC	All
<code>(config) dre</code>	Enables and configures DRE auto bypass and load monitor settings.	global configuration	application- accelerator



Table 2-1 Command Summary (continued)

Command	Description	CLI Mode	Device Mode
(config-wccp-service) egress-method	Configures the WCCP egress method.	WCCP configuration	application- accelerator
enable*	Accesses the privileged EXEC commands.	user-level EXEC	All
(config-wccp-service) enable	Enables or disables WCCP.	WCCP configuration	application- accelerator
(config-if) encapsulation dot1Q	Sets the VLAN ID of traffic leaving an inline group interface.	interface configuration	application- accelerator
(config) end	Exits configuration and privileged EXEC modes.	global configuration	All
(config) exec-timeout	Configures the length of time that an inactive Telnet or SSH session remains open.	global configuration	All
exit	Exits from privileged EXEC mode.	privileged-level EXEC	All
(config) exit	Exits from global configuration mode.	global configuration	All
(config-if) exit	Exits from interface configuration mode.	interface configuration	All
(config-std-nacl) exit	Exits from standard ACL configuration mode.	standard ACL configuration	All
(config-ext-nacl) exit	Exits from extended ACL configuration mode.	extended ACL configuration	All
(config-wccp-service) exit	Exits from WCCP configuration mode.	WCCP configuration	application- accelerator
	Configures the maximum time for the inline interface to transition traffic to another port after a failure event.	interface configuration	All
(config-wccp-service) failure-detection	Configure the WCCP failure detection timeout.	WCCP configuration	application- accelerator
find-pattern	Searches for a particular pattern in a file.	privileged-level EXEC	All
(config) help	Configures network traffic flow monitoring.	global configuration	application- accelerator
(config-if) full-duplex	Sets the current interface to the full-duplex mode.	interface configuration	All
(config-if) half-duplex	Sets the current interface to half-duplex mode.	interface configuration	All
help	Provides assistance for the WAAS command-line interface in EXEC mode.	user-level EXEC and privileged-level EXEC	All

Table 2-1 Command Summary (continued)

Command	Description	CLI Mode	Device Mode
(config) help	Provides assistance for the WAAS command-line interface.	global configuration	All
(config) hostname	Configures the hostname of the WAAS device in global configuration mode.	global configuration	All
(config) inetd	Enables FTP and TFTP services.	global configuration	All
(config) inline	Configures the ports on an interface module to operate in inline mode.	global configuration	application- accelerator
(config-if) inline	Configures inline interception for an inlineGroup interface.	interface configuration	All
(config) inline vlan-id-connection-check	Enables VLAN ID checking on intercepted traffic.	global configuration	application- accelerator
(config-ssl-accelerated) inservice	Enables the accelerated service.	SSL accelerated service configuration	All
install	Installs a new image into Flash memory.	privileged-level EXEC	All
(config) interception	Configures an interception access list.	global configuration	All
(config) interception-method	Configures an interception access list.	global configuration	application- accelerator appnav-controller
(config) interface GigabitEthernet*	Configures a Gigabit Ethernet interface. Provides access to interface configuration mode.	global configuration	All
(config) interface InlineGroup*	Configures a Inline Group channel, or standby interface. Provides access to interface configuration mode.	global configuration	All
(config) interface PortChannel*	Configures a port channel interface. Provides access to interface configuration mode.	global configuration	All
(config) interface standby*	Configures a standby interface. Provides access to interface configuration mode.	global configuration	All
(config) interface TenGigabitEthernet*	Configures a 10-Gigabit Ethernet interface. Provides access to interface configuration mode.	global configuration	All
(config) ip	Configures the initial network device configuration settings (for example, the IP address of the default gateway) on a WAAS device.	global configuration	All
(config-if) ip	Configures the IP address, subnet mask, or DHCP IP address negotiation on the interface of the WAAS device or inline module.	interface configuration	All
(config-if) ip access-group	Controls the connections on a specific interface by applying a predefined access list.	interface configuration	All

Table 2-1 Command Summary (continued)

Command	Description	CLI Mode	Device Mode
<a href="#">(config) ip access-list*</a>	Creates and modifies the access lists for controlling access to interfaces or applications. Provides access to ACL configuration mode.	global configuration	All
<a href="#">(config) ip icmp rate-limit unreachable</a>	Limits the rate at which Internet Control Message Protocol (ICMP) destination unreachable messages are generated.	global configuration	All
<a href="#">(config) ip unreachable df</a>	Enables the IP unreachable ICMP service.	global configuration	All
<a href="#">(config) kerberos</a>	Configures user authentication against a Kerberos database.	global configuration	All
<a href="#">(config) kernel kdb</a>	Enables the kernel debugger configuration mode.	global configuration	All
<a href="#">(config) kernel kdump enable</a>	Enables the kernel crash dump mechanism.	global configuration	All
<a href="#">less</a>	Displays the contents of a file using the LESS application.	user-level EXEC and privileged-level EXEC	All
<a href="#">license add</a>	Adds a software license.	privileged-level EXEC	All
<a href="#">(config) line</a>	Specifies the terminal line settings.	global configuration	All
<a href="#">(config-std-nacl) list</a>	Displays a list of specified entries within the standard ACL	standard ACL configuration	All
<a href="#">(config-ext-nacl) list</a>	Displays a list of specified entries within the extended ACL	extended ACL configuration	All
<a href="#">lls</a>	Displays the files in a long list format.	user-level EXEC and privileged-level EXEC	All
<a href="#">(config-if) load-interval</a>	Configures the statistics polling interval for an interface.	interface configuration	All
<a href="#">(config) logging console</a>	Configures system logging (syslog) to the console.	global configuration	All
<a href="#">(config) logging disk</a>	Configures system logging (syslog) to a disk file.	global configuration	All
<a href="#">(config) logging facility</a>	Sets the facility parameter for system logging (syslog).	global configuration	All
<a href="#">(config) logging host</a>	Configures system logging (syslog) to a remote host.	global configuration	All

Table 2-1 Command Summary (continued)

Command	Description	CLI Mode	Device Mode
<code>ls</code>	Lists the files and subdirectories in a directory on the device hard disk.	user-level EXEC and privileged-level EXEC	All
<code>lsusb</code>	Lists the files and subdirectories in a directory on a USB storage device.	user-level EXEC and privileged-level EXEC	All
<code>(config-ssl-global) machine-cert-key</code>	Configures a certificate and private key.	SSL global service configuration	All
<code>mkdir</code>	Makes a directory.	privileged-level EXEC	All
<code>mkfile</code>	Makes a file (for testing).	privileged-level EXEC	All
<code>(config-std-nacl) move</code>	Moves a line to a new position within the standard ACL	standard ACL configuration	All
<code>(config-ext-nacl) move</code>	Moves a line to a new position within the extended ACL	extended ACL configuration	All
<code>(config-if) mtu</code>	Sets the interface Maximum Transmission Unit (MTU) packet size.	interface configuration	All
<code>(config) ntp</code>	Configures the NTP server.	global configuration	All
<code>ntpdate</code>	Sets the NTP server name.	privileged-level EXEC	All
<code>(config-pki-global-settings) ocsp</code>	Configures the URL to be used as the global settings for the Online Certificate Status Protocol (OCSP) protocol revocation status checking.	PKI global-settings configuration	All
<code>packet-capture</code>	Captures packets.	privileged-level EXEC	All
<code>(config-wccp-service) password</code>	Configures the WCCP service password.	WCCP configuration	application- accelerator
<code>(config) peer</code>	Enables/disables peer optimization.	global configuration	application- accelerator
<code>(config-ssl-peering) peer-cert-verify</code>	Enables verification of peer certificates.	SSL host peering service configuration	All
<code>(config-ssl-mgmt) peer-cert-verify</code>	Enables verification of peer certificates.	SSL management service configuration	All

Table 2-1 Command Summary (continued)

Command	Description	CLI Mode	Device Mode
(config-std-nacl) permit	Adds a line to a standard access list that specifies the type of packets that you want the WAAS device to permit for further processing.	standard ACL configuration	All
(config-ext-nacl) permit	Adds a line to an extended access list that specifies the type of packets that you want the WAAS device to permit for further processing.	extended ACL configuration	All
ping	Sends the echo packets.	user-level EXEC and privileged-level EXEC	All
(config) port-channel	Configures the port channel load-balancing options.	global configuration	All
(config) primary-interface	Configures a primary interface for the WAAS device.	global configuration	All
(config) radius-server	Enables and disables WAAS print services and configures an administrative group.	global configuration	All
pwd	Displays the present working directory.	user-level EXEC and privileged-level EXEC	All
(config) radius-server	Configures the RADIUS parameters on a WAAS device.	global configuration	All
(config-wccp-service) redirect-method	Configures the WCCP redirect method.	WCCP configuration	application- accelerator
reload	Halts a device and performs a cold restart.	privileged-level EXEC	All
rename	Renames a file.	privileged-level EXEC	All
restore	Restores a device to its manufactured default status.	privileged-level EXEC	All
(config-ca) revocation-check	Configures the certification authority revocation checking method.	certification authority configuration	All
(config-pki-global-settings) revocation-check	Configures the the global settings revocation checking method.	PKI global-settings configuration	All
rmdir	Removes a directory.	privileged-level EXEC	All
(config-wccp-service) router-list-num	Configures the WCCP router list.	WCCP configuration	application- accelerator
scp	Specifies the SCP client.	privileged-level EXEC	All

Table 2-1 Command Summary (continued)

Command	Description	CLI Mode	Device Mode
<code>script</code>	Checks the errors in a script or executes a script.	privileged-level EXEC	All
<code>(config-ssl-accelerated) server-cert-key</code>	Configures a certificate and private key.	SSL accelerated service configuration	All
<code>(config-ssl-accelerated) server-cert-verify</code>	Enables verification of server certificates.	SSL accelerated service configuration	All
<code>(config-ssl-accelerated) server-domain</code>	Configures the accelerated server domain and TCP port.	SSL accelerated service configuration	All
<code>(config-ssl-accelerated) server-ip</code>	Configures the accelerated server IP address and TCP port.	SSL accelerated service configuration	All
<code>(config-ssl-accelerated) server-name</code>	Configures the accelerated server hostname and TCP port.	SSL accelerated service configuration	All
<code>(config) service-policy</code>	Configures entities.	global configuration	application- accelerator
<code>(config) service-policy</code>	Configures optimization policy.	global configuration	application- accelerator
<code>setup</code>	Configures the basic configuration settings. Invokes the interactive setup utility.	privileged-level EXEC	All
<code>show aaa accounting</code>	Displays the AAA accounting configuration.	user-level EXEC and privileged-level EXEC	All
<code>show aaa authorization</code>	Displays the AAA authorization configuration.	user-level EXEC and privileged-level EXEC	All
<code>show accelerator</code>	Displays the status and configuration of the application accelerators.	privileged-level EXEC	application- accelerator
<code>show alarms</code>	Displays information on various types of alarms, their status, and history.	privileged-level EXEC	All
<code>show arp</code>	Displays the ARP entries.	privileged-level EXEC	All
<code>show authentication</code>	Displays the authentication configuration.	user-level EXEC and privileged-level EXEC	All

Table 2-1 Command Summary (continued)

Command	Description	CLI Mode	Device Mode
<a href="#">show auto-discovery</a>	Displays auto-discovery information for a WAE.	user-level EXEC and privileged-level EXEC	application- accelerator
<a href="#">show auto-register</a>	Displays the status of the autoregistration feature for a WAE.	privileged-level EXEC	application- accelerator
<a href="#">show banner</a>	Displays the message of the day, login, and EXEC banner settings.	privileged-level EXEC	All
<a href="#">show bmc</a>	Displays the Baseboard Management Controller information.	user-level EXEC and privileged-level EXEC	application- accelerator
<a href="#">show cache http-metadacache</a>	Displays HTTP metadata cache information.	privileged-level EXEC	application- accelerator
<a href="#">show cdp</a>	Displays the CDP configuration.	privileged-level EXEC	All
<a href="#">show class-map</a>	Displays the matching criteria configured for a class map.	privileged-level EXEC	application- accelerator
<a href="#">show clock</a>	Displays the system clock.	user-level EXEC and privileged-level EXEC	All
<a href="#">show cms</a>	Displays the management service information.	privileged-level EXEC	All
<a href="#">show cms secure-store</a>	Displays the secure disk encryption status.	privileged-level EXEC	All
<a href="#">show crypto</a>	Displays crypto layer information.	user-level EXEC and privileged-level EXEC	All
<a href="#">show debugging</a>	Displays the state of each debugging option.	privileged-level EXEC	All
<a href="#">show device-id</a>	Displays the device ID.	user-level EXEC and privileged-level EXEC	All
<a href="#">show device-mode</a>	Displays the device mode.	privileged-level EXEC	All
<a href="#">show disks</a>	Displays the disk configurations.	user-level EXEC and privileged-level EXEC	All
<a href="#">show filtering list</a>	Displays TFO flow information for a WAE.	privileged-level EXEC	application- accelerator

Table 2-1 Command Summary (continued)

Command	Description	CLI Mode	Device Mode
<a href="#">show flash</a>	Displays the flash memory information.	privileged-level EXEC	All
<a href="#">show flow record</a>	Displays collection information for a WAE device.	EXEC	application-accelerator central-manager
<a href="#">show hardware</a>	Displays the system hardware information.	privileged-level EXEC	All
<a href="#">show hosts</a>	Displays the IP domain name, name servers, IP addresses, and host table.	user-level EXEC and privileged-level EXEC	All
<a href="#">show inetd</a>	Displays the status of TCP/IP services.	privileged-level EXEC	All
<a href="#">show interception-method</a>	Displays the interception method.	privileged-level EXEC	application- accelerator
<a href="#">show interface</a>	Displays the hardware interface information.	privileged-level EXEC	All
<a href="#">show inventory</a>	Displays the system inventory information.	privileged-level EXEC	All
<a href="#">show ip access-list</a>	Displays the information about access lists that are defined and applied to specific interfaces or applications.	privileged-level EXEC	All
<a href="#">show ip routes</a>	Displays the IP routing table.	privileged-level EXEC	All
<a href="#">show kdump</a>	Displays the kernel crash dump information.	privileged-level EXEC	All
<a href="#">show kerberos</a>	Displays the Kerberos authentication configuration.	user-level EXEC and privileged-level EXEC	All
<a href="#">show key-manager</a>	Displays the key manager information for a WAAS device.	privileged-level EXEC	All
<a href="#">show license</a>	Displays the license information.	privileged-level EXEC	All
<a href="#">show logging</a>	Displays the system logging configuration.	user-level EXEC and privileged-level EXEC	All
<a href="#">show memory</a>	Displays the memory blocks and statistics.	privileged-level EXEC	All
<a href="#">show ntp</a>	Displays the NTP configuration status.	user-level EXEC and privileged-level EXEC	All



Table 2-1 Command Summary (continued)

Command	Description	CLI Mode	Device Mode
<a href="#">show peer optimization</a>	Displays the configured serial peers for a WAE.	privileged-level EXEC	application- accelerator
<a href="#">show policy-map</a>	Displays the configured policy map rules.	privileged-level EXEC	application- accelerator
<a href="#">show processes</a>	Displays the process status.	privileged-level EXEC	All
<a href="#">show radius-server</a>	Displays the RADIUS server information.	user-level EXEC and privileged-level EXEC	All
<a href="#">show reload</a>	Displays scheduled reload information.	user-level EXEC and privileged-level EXEC	All
<a href="#">show running-config</a>	Displays the current operating configuration.	privileged-level EXEC	All
<a href="#">show services</a>	Displays information related to services.	privileged-level EXEC	All
<a href="#">show smb-conf</a>	Displays the smb-conf configurations.	privileged-level EXEC	All
<a href="#">show snmp</a>	Displays the SNMP statistics.	user-level EXEC and privileged-level EXEC	All
<a href="#">show ssh</a>	Displays the status and configuration of the Secure Shell (SSH) service.	privileged-level EXEC	All
<a href="#">show startup-config</a>	Displays the startup configuration.	privileged-level EXEC	All
<a href="#">show statistics accelerator</a>	Displays the application accelerator statistics information.	privileged-level EXEC	application- accelerator
<a href="#">show statistics aoim</a>	Displays AO (accelerator) Information Manager statistics.	privileged-level EXEC	application- accelerator
<a href="#">show statistics application</a>	Displays the status of the application statistics.	privileged-level EXEC	All
<a href="#">show statistics authentication</a>	Displays the authentication statistics.	user-level EXEC and privileged-level EXEC	All
<a href="#">show statistics auto-discovery</a>	Displays TFO auto-discovery statistics for a WAE.	user-level EXEC and privileged-level EXEC	application- accelerator

Table 2-1 Command Summary (continued)

Command	Description	CLI Mode	Device Mode
<code>show statistics class-default</code>	Displays statistics information about the class-default class map.	privileged-level EXEC	application- accelerator
<code>show statistics class-map</code>	Displays statistics information about about class maps.	privileged-level EXEC	application- accelerator
<code>show statistics connection</code>	Displays the connection statistics for a WAE.	privileged-level EXEC	application- accelerator
<code>show statistics connection auto-discovery</code>	Displays the auto-discovery connection statistics for a WAE.	privileged-level EXEC	application- accelerator
<code>show statistics connection closed</code>	Displays the closed connection statistics for a WAE.	privileged-level EXEC	application- accelerator
<code>show statistics connection conn-id</code>	Displays the connection ID statistics for a WAE.	privileged-level EXEC	application- accelerator
<code>show statistics connection egress-methods</code>	Displays detailed egress method-related information about the connection segments for a WAE.	privileged-level EXEC	application- accelerator
<code>show statistics connection optimized</code>	Displays optimized information about the connection segments for a WAE.	privileged-level EXEC	application- accelerator
<code>show statistics connection pass-through</code>	Displays pass through information about the connection segments for a WAE.	privileged-level EXEC	application- accelerator
<code>show statistics crypto ssl ciphers</code>	Displays crypto SSL cipher usage statistics.	privileged-level EXEC	application- accelerator
<code>show statistics datamover</code>	Displays internal datamover information.	user-level EXEC and privileged-level EXEC	application- accelerator
<code>show statistics dre</code>	Displays the Data Redundancy Elimination (DRE) statistics for a WAE.	privileged-level EXEC	application- accelerator
<code>show statistics filtering</code>	Displays TFO flow statistics for a WAE.	user-level EXEC and privileged-level EXEC	application- accelerator
<code>show statistics flow</code>	Displays the flow statistics.	user-level EXEC and privileged-level EXEC	application- accelerator
<code>show statistics generic-gre</code>	Displays the generic GRE tunnel statistics.	user-level EXEC and privileged-level EXEC	application- accelerator
<code>show statistics icmp</code>	Displays the ICMP statistics.	user-level EXEC and privileged-level EXEC	All

Table 2-1 Command Summary (continued)

Command	Description	CLI Mode	Device Mode
<code>show statistics ip</code>	Displays the IP statistics.	user-level EXEC and privileged-level EXEC	All
<code>show statistics netstat</code>	Displays the Internet socket connection statistics.	user-level EXEC and privileged-level EXEC	All
<code>show statistics pass-through</code>	Displays the pass-through statistics.	privileged-level EXEC	application- accelerator
<code>show statistics peer</code>	Displays the DRE peer statistics for a WAE.	privileged-level EXEC	application- accelerator
<code>show statistics radius</code>	Displays the RADIUS authentication statistics.	user-level EXEC and privileged-level EXEC	All
<code>show statistics services</code>	Displays the services statistics.	user-level EXEC and privileged-level EXEC	All
<code>show statistics sessions</code>	Displays the dynamic match session statistics.	user-level EXEC and privileged-level EXEC	application- accelerator
<code>show statistics snmp</code>	Displays the SNMP statistics.	user-level EXEC and privileged-level EXEC	All
<code>show statistics system cpu</code>	Displays detailed parameters of the cpu utilization.	user-level EXEC and privileged-level EXEC	application- accelerator
<code>show statistics tacacs</code>	Displays the TACACS+ authentication and authorization statistics.	user-level EXEC and privileged-level EXEC	All
<code>show statistics tcp</code>	Displays the Transmission Control Protocol statistics.	user-level EXEC and privileged-level EXEC	All
<code>show statistics tfo</code>	Displays the Transport Flow Optimization (TFO) statistics for a WAE.	user-level EXEC and privileged-level EXEC	application- accelerator

Table 2-1 Command Summary (continued)

Command	Description	CLI Mode	Device Mode
<code>show statistics udp</code>	Displays the User Datagram Protocol (UDP) statistics.	user-level EXEC and privileged-level EXEC	All
<code>show statistics wccp</code>	Displays the WCCP statistics for a WAE.	user-level EXEC and privileged-level EXEC	application- accelerator
<code>show statistics windows-domain</code>	Displays the Windows domain configuration.	user-level EXEC and privileged-level EXEC	All
<code>show statistics windows-print requests</code>	Displays the Windows print accelerator statistics.	user-level EXEC and privileged-level EXEC	application- accelerator
<code>show sysfs volumes</code>	Displays system file system information.	privileged-level EXEC	application- accelerator
<code>show sysfs volumes</code>	Displays the system file system (SYSFS) information.	user-level EXEC and privileged-level EXEC	All
<code>show tacacs</code>	Displays the TACACS+ configuration.	user-level EXEC and privileged-level EXEC	All
<code>show tcp</code>	Displays the TCP configuration.	user-level EXEC and privileged-level EXEC	All
<code>show tech-support</code>	Displays the system information for Cisco technical support.	privileged-level EXEC	All
<code>show telnet</code>	Displays the Telnet services configuration.	privileged-level EXEC	All
<code>show tfo tcp</code>	Displays TFO TCP buffer information.	privileged-level EXEC	application- accelerator
<code>show transaction-logging</code>	Displays the transaction logging information for a WAE.	user-level EXEC and privileged-level EXEC	application- accelerator
<code>show user</code>	Displays information about a particular user.	privileged-level EXEC	All

Table 2-1 Command Summary (continued)

Command	Description	CLI Mode	Device Mode
<code>show users administrative</code>	Displays the administrative users.	user-level EXEC and privileged-level EXEC	All
<code>show version</code>	Displays the software version.	user-level EXEC and privileged-level EXEC	All
<code>show wccp</code>	Displays the WCCP information for a WAE.	user-level EXEC and privileged-level EXEC	application- accelerator
<code>show windows-domain</code>	Displays the Windows domain configuration.	user-level EXEC and privileged-level EXEC	All
<code>(config-if) shutdown</code>	Shuts down the specified interface.	interface configuration	All
<code>shutdown</code>	Shuts down the device (stops all applications and operating system).	privileged-level EXEC	All
<code>(config) smb-conf</code>	Manually configures parameters in the Samba configuration file, <i>smb-conf</i> .	global configuration	All
<code>(config) snmp-server access-list</code>	Configures an access control list to allow access through an SNMP agent.	global configuration	All
<code>(config) snmp-server community</code>	Enables SNMP; sets the community string, optionally names the group, and enables the read-write access with the community string.	global configuration	All
<code>(config) snmp-server contact</code>	Specifies the text for the system contact MIB object.	global configuration	All
<code>(config) snmp-server enable traps</code>	Enables the SNMP traps.	global configuration	All
<code>(config) snmp-server group</code>	Defines a user security model group.	global configuration	All
<code>(config) snmp-server host</code>	Specifies the hosts to receive SNMP traps.	global configuration	All
<code>(config) snmp-server location</code>	Specifies the path for MIB object sysLocation.	global configuration	All
<code>(config) snmp-server mib</code>	Configures the persistence for the SNMP Event MIB.	global configuration	All
<code>(config) snmp-server notify inform</code>	Configures the SNMP inform request.	global configuration	All
<code>(config) snmp-server trap-source</code>	Configures the SNMP trap source.	global configuration	All

Table 2-1 Command Summary (continued)

Command	Description	CLI Mode	Device Mode
(config) snmp-server user	Defines a user who can access the SNMP engine.	global configuration	All
(config) snmp-server view	Defines an SNMPv2 MIB view.	global configuration	All
ssh	Creates or deletes SNMP triggers on a MIB variable.	privileged-level EXEC	All
ssh	Allows secure encrypted communications between an untrusted client machine and a WAAS device over an insecure network.	user-level EXEC and privileged-level EXEC	All
(config) sshd	Configures the parameters for the Secure Shell (SSH) service.	global configuration	All
(config) ssh-key-generate	Generates a SSH host key.	global configuration	All
(config-if) standby	Configures an interface to be a backup for another interface.	interface configuration	All
(config) stats-collector logging	Configures SMB statistics logging.	global configuration	application- accelerator
(config) system jumbomtu	Configures a jumbo MTU on all interfaces.	global configuration	application- accelerator
(config) tacacs	Configures the TACACS+ parameters on a WAAS device.	global configuration	All
(config) tcp	Configures the TCP parameters.	global configuration	All
tcpdump	Dumps the TCP traffic on the network.	privileged-level EXEC	All
telnet	Starts the Telnet client.	user-level EXEC and privileged-level EXEC	All
(config) telnet enable	Enables the Telnet services.	global configuration	All
terminal	Sets the terminal output commands.	user-level EXEC and privileged-level EXEC	All
test	Performs diagnostic tests and displays the results.	user-level EXEC and privileged-level EXEC	All
tethereal	Analyzes network traffic from the command line.	privileged-level EXEC	All

Table 2-1 Command Summary (continued)

Command	Description	CLI Mode	Device Mode
(config) tfo exception	Configures TFO exception handling.	global configuration	application- accelerator
(config) tfo optimize	Configures TFO optimization for DRE or full generic optimization on the WAE.	global configuration	application- accelerator
(config) tfo tcp adaptive-buffer-sizing	Configures TFO optimization with TCP adaptive buffer sizing.	global configuration	application- accelerator
(config) tfo tcp keepalive	Configures TFO optimization with a TCP keepalive on a WAE.	global configuration	application- accelerator
(config) tfo tcp optimized-mss	Configures TFO optimization with an optimized-side TCP maximum segment size on a WAE.	global configuration	application- accelerator
(config) tfo tcp optimized-receive-buffer	Configures TFO optimization with an optimized-side receive buffer on a WAE.	global configuration	application- accelerator
(config) tfo tcp optimized-send-buffer	Configures TFO optimization with an optimized-side send buffer on a WAE.	global configuration	application- accelerator
(config) tfo tcp original-mss	Configures TFO optimization with an unoptimized-side TCP maximum segment size on the WAE.	global configuration	application- accelerator
(config) tfo tcp original-receive-buffer	Configures TFO optimization with an unoptimized-side receive buffer on a WAE.	global configuration	application- accelerator
(config) tfo tcp original-send-buffer	Configures TFO optimization with an unoptimized-side send buffer on a WAE.	global configuration	application- accelerator
(config) threshold-monitor	Configures monitoring thresholds in a WAAS deployment.	global configuration	application- accelerator
top	Displays the current top CPU activities.	privileged-level EXEC	All
traceroute	Traces the route to a remote host.	user-level EXEC and privileged-level EXEC	All
transaction-log	Forces the transaction logging for TFO and export on a WAE.	privileged-level EXEC	application- accelerator
(config) transaction-logs	Configures the transaction logging on a WAE.	global configuration	application- accelerator
type	Displays a file.	user-level EXEC and privileged-level EXEC	All
type-tail	Displays the last several lines of a file.	user-level EXEC and privileged-level EXEC	All

Table 2-1 Command Summary (continued)

Command	Description	CLI Mode	Device Mode
<code>(config) username</code>	Establishes the username authentication.	global configuration	All
<code>(config-ssl-accelerated) version</code>	Specifies the type of SSL protocol to use for accelerated services.	SSL accelerated service configuration	All
<code>(config-ssl-global) version</code>	Specifies the type of SSL protocol to use for global services.	SSL global service configuration	All
<code>(config-ssl-peering) version</code>	Specifies the type of SSL protocol to use for management services.	SSL host peering service configuration	All
<code>(config-ssl-mgmt) version</code>	Specifies the type of SSL protocol to use for management services.	SSL management service configuration	All
<code>vm</code>	Initializes the virtual machine, and configures the host clock sync setting.	privileged-level EXEC	application- accelerator
<code>(config) wccp access-list</code>	Configures the IP access list for inbound Web Cache Coordination Protocol (WCCP) GRE-encapsulated traffic on a WAE.	global configuration	application- accelerator
<code>(config) wccp router-list</code>	Enables the WCCP flow protection feature on a WAE.	global configuration	application- accelerator
<code>(config) wccp router-list</code>	Creates a router list on a WAE for use in the WCCP Version 2 services.	global configuration	application- accelerator
<code>(config) wccp shutdown</code>	Sets the maximum time interval after which the WAE will perform a clean shut down.	global configuration	application- accelerator
<code>(config) wccp tcp-promiscuous service-pair</code>	Configures and enables the TCP promiscuous mode service on a WAE.	global configuration	application- accelerator
<code>(config-wccp-service) weight</code>	Configures the weight assigned to a WAE.	WCCP configuration	application- accelerator
<code>waas-tcptrace</code>	Lists WAAS devices in the path to a destination host.	user-level EXEC and privileged-level EXEC	All
<code>whoami</code>	Displays the name of the current user.	user-level EXEC and privileged-level EXEC	All
<code>windows-domain</code>	Accesses Windows domain utilities.	privileged-level EXEC	All



**Table 2-1**      *Command Summary (continued)*

Command	Description	CLI Mode	Device Mode
<code>(config) windows-domain</code>	Configures Windows domain server options.	global configuration	All
<code>write</code>	Writes or erases the startup configurations to NVRAM or to a terminal session, or writes the MIB persistence configuration to disk.	privileged-level EXEC	All

