

Logical Edge Devices

A Logical Edge Device (LED) is a virtual edge device within the cBR-8 and can be provisioned for static or dynamic sessions.

Contents

- Information about Logical Edge Devices, on page 1
- How to Configure the Logical Edge Devices, on page 1
- Configuration Examples, on page 8
- Feature Information for Logical Edge Devices, on page 9

Information about Logical Edge Devices

An LED interfaces remotely to a head end video Session Resource Manager (SRM) using the GQI protocol. It also represents a group of locally managed table-based video sessions.

In Cisco cBR-8, you can create up to 32 LEDs to simultaneously manage the video QAM carriers. Each LED manages a set of virtual QAM carriers independently. Due to the limitation of the GQI protocol, a GQI LED can only manage a set of QAM carriers in a single line card, unlike the table-based LED, which can manage more than a single line card.

In addition, an LED can be optionally configured to support the D6 discovery protocol to report a QAM resource to the SRM.

How to Configure the Logical Edge Devices

This section describes how to configure LEDs for the video session on Cisco cBR-8.

Configuring Session-Based (Dynamic) Logical Edge Devices

GQI is a protocol for the GQI LED to interface with the remote SRM.

For system using discovery protocol, the D6 discovery protocol should be enabled to report the QAM resources of the LED to the remote SRM.

An active flag should be enabled on the LED to indicate that it is active. This flag indicates that the connectivity with the SRM can be setup and the LED can start handling GQI message exchange from the SRM.

You cannot edit or remove the LED data when it is in the active mode. To do so, you must first move the LED to inactive mode and then disconnect it from the SRM.

Due to the limitations of the GQI protocol, GQI LED cannot have Virtual Carrier Groups that span across multiple cable line cards (CLC).



Note

In Cisco IOS-XE Release 3.18.0S, only GQI version 2 is supported for all GQI LEDs.

Before You Begin

The following data is necessary to define a GQI LED:

- The Management IP address that the SRM uses to setup connectivity with the LED. The IP address must be in the same subnet as configured in the VirtualPortGoup.
- A unique MAC address per LED. Using the chassis MAC address as a basis, increment the least significant number to give a unique identifier (MAC address) for each LED. This number should be unique with respect to the GQI server and does not really relate to a true MAC address. Thus, the number is irrelevant, but needs to be unique.



Tip

Use the **show diag all eeprom detail | include MAC** command to get the chassis MAC address.

- The primary and secondary IP addresses of the remote SRM.
- Virtual Carrier Group (VCG). For more information, see Virtual Carrier Group.
- Connection-orientated controls such as, keep alive, reset interval, and timeout value.
- Virtual Edge Input (VEI) configured with a routable IP address from within the network. For more information, see Video Virtual Carrier Group and Virtual Edge Input.

To configure the session-based LEDs, complete the following procedure:

```
configure terminal
cable video
logical-edge-device name [id number]
protocol gqi
mgmt-ip ip address
server ip address
virtual-edge-input ip address input-port-number port number
vcg vcg name
vcg vcg name
mac-address mac address
keepalive retry retry count interval seconds
reset interval seconds
active
```

Verifying the Session-Based (Dynamic) Logical Edge Devices Configuration

To verify a GQI LED configuration, use the **show cable video logical-edge-device** command as shown in the example below:

show cable video logical-edge-device id ${\bf 1}$

```
Logical Edge Device: led
Id: 1
Protocol: GQI
Service State: Active
Discovery State: Disable
Management IP: 1.33.2.10
MAC Address: c414.3c17.6000
Number of Servers: 2
  Server 1: 1.200.1.193
   Server 2: 1.200.1.183
Reset Interval: 5
                        Retry Count:3
Keepalive Interval: 5
Number of Virtual Carrier Groups: 2
Number of Share Virtual Edge Input: 1
Number of Physical Qams: 94
Number of Sessions: 240
No Reserve PID Range
Virtual Edge Input:
Input Port VEI
                                   Slot/Bay
                                                 Bundle
                                                              Gateway
ID
             ΙP
                                                 ID
                                                              ΙP
             174.102.1.1
                                   7/0
Virtual Carrier Group:
                                        Total
                                                               Service-Distribution-Group
    Name
                                                    Total
    Service-Distribution-Group
                                        VET
                                                    RF-channel Name
    ID
1
      vcg
                                        0
                                                    28
                                                               sda
    1
2
                                        Ω
                                                    19
      vcg-2
                                                               sdg
                                                                  ONTD
Integrated
                Physical
                          Admin
                                       Operational TSID
                                                                                Output
VCG
                           Encryption
Cable
                QAM ID
                           State
                                       State
                                                                                Port
             ID
                           Capable
ID
7/0/0:20
                                                                  1000
                2.0
                           ON
                                       IJΡ
                                                     1
                                                                                1
1
             1
                           powerkey
7/0/0:21
                           ON
                                       UP
                                                                  1000
                                                                                2
1
             1
                           powerkey
7/0/0:22
                           ON
                                       UP
                                                                  1000
                                                                                3
1
             1
                           powerkey
7/0/0:23
                2.3
                                       IJΡ
                                                     4
                                                                  1000
                                                                                4
                           ON
             1
                           powerkey
7/0/0:24
                2.4
                            ON
                                       UP
                                                     5
                                                                  1000
                                                                                5
             1
1
                           powerkey
7/0/0:25
                25
                            ON
                                       UP
                                                     6
                                                                  1000
                                                                                6
             1
                           powerkey
7/0/0:26
                2.6
                                       IJΡ
                                                                  1000
                                                                                7
                           ON
1
             1
                           powerkey
7/0/0:27
                                                     8
                                                                                8
                27
                                                                  1000
                           ON
                                       UP
1
             1
                           powerkey
7/0/0:28
                28
                           ON
                                       UP
                                                     9
                                                                  1000
                                                                                9
             1
                           powerkey
```

7/0/0:29		29	ON	UP	10	1000	10
1	1	20	powerkey	IID	1.1	1000	1.1
7/0/0:30 1	1	30	ON powerkey	UP	11	1000	11
7/0/0:31	1	31	ON	UP	12	1000	12
1 7/0/0:32 1	1	32	powerkey ON powerkey	UP	13	1000	13
7/0/0:33	1	33	ON powerkey	UP	14	1000	14
7/0/0:34 1	1	34	ON powerkey	UP	15	1000	15
7/0/0:35 1	1	35	ON powerkey	UP	16	1000	16
7/0/0:36 1	1	36	ON powerkey	UP	17	1000	17
7/0/0:37 1	1	37	ON powerkey	UP	18	1000	18
7/0/0:38 1	1	38	ON powerkey	UP	19	1000	19
7/0/0:39 1	1	39	ON powerkey	UP	20	1000	20
7/0/0:40 1	1	40	ON powerkey	UP	21	1000	21
7/0/0:41 1	1	41	ON powerkey	UP	22	1000	22
7/0/0:42 1	1	42	ON powerkey	UP	23	1000	23
7/0/0:43 1	1	43	ON powerkey	UP	24	1000	24
7/0/0:44 1	1	44	ON powerkey	UP	25	1000	25
7/0/0:45 1	1	45	ON powerkey	UP	26	1000	26
7/0/0:46 1	1	46	ON powerkey	UP	27	1000	27
7/0/0:47 1	1	47	ON powerkey	UP	28	1000	28
7/0/7:20 1	1	20	ON powerkey	UP	1	1000	1
7/0/7:21 1	1	21	ON powerkey	UP	2	1000	2
7/0/7:22 1	1	22	ON powerkey	UP	3	1000	3
7/0/7:23 1	1	23	ON powerkey	UP	4	1000	4
7/0/7:24 1	1	24	ON powerkey	UP	5	1000	5
7/0/7:25 1	1	25	ON powerkey	UP	6	1000	6
7/0/7:26 1	1	26	ON powerkey	UP	7	1000	7
7/0/7:27 1	1	27	ON powerkey	UP	8	1000	8
7/0/7:28 1	1	28	ON powerkey	UP	9	1000	9
7/0/7:29 1	1	29	ON powerkey	UP	10	1000	10
7/0/7:30 1	1	30	ON powerkey	UP	11	1000	11
7/0/7:31 1	1	31	ON powerkey	UP	12	1000	12
7/0/7:32 1	1	32	ON powerkey	UP	13	1000	13

7/0/7:33 1	1	33	ON	UP	14	1000	14
7/0/7:34		34	powerkey ON	UP	15	1000	15
1 7/0/7:35	1	35	powerkey ON	UP	16	1000	16
1 7/0/7:36	1	36	powerkey ON	UP	17	1000	17
1	1	37	powerkey				
7/0/7:37	1		ON powerkey	UP	18	1000	18
7/0/7 : 38 1	1	38	ON powerkey	UP	19	1000	19
7/0/7:39 1	1	39	ON powerkey	UP	20	1000	20
7/0/7:40		40	ON	UP	21	1000	21
1 7/0/7:41	1	41	powerkey ON	UP	22	1000	22
1 7/0/7:42	1	42	powerkey ON	UP	23	1000	23
1 7/0/7:43	1	43	powerkey ON	UP	24	1000	24
1	1		powerkey				
7/0/7:44 1	1	44	ON powerkey	UP	25	1000	25
7/0/7:45 1	1	45	ON powerkey	UP	26	1000	26
7/0/7:46 1	1	46	ON powerkey	UP	27	1000	27
7/0/7:47		47	ON	UP	28	1000	28
1 7/0/0:1	1	1	powerkey ON	UP	29	1000	29
2 7/0/0:2	1	2	powerkey ON	UP	30	1000	30
2 7/0/0:3	1	3	powerkey ON	UP	31	1000	31
2	1		powerkey				
7/0/0:4	1	4	ON powerkey	UP	32	1000	32
7/0/0:5 2	1	5	ON powerkey	UP	33	1000	33
7/0/0:6 2	1	6	ON powerkey	UP	34	1000	34
7/0/0:7 2		7	ON	UP	35	1000	35
7/0/0:8	1	8	powerkey ON	UP	36	1000	36
2 7/0/0:9	1	9	powerkey ON	UP	37	1000	37
2 7/0/0:10	1	10	powerkey ON	UP	38	1000	38
2 7/0/0:11	1	11	powerkey ON	UP	39	1000	39
2	1		powerkey				
7/0/0:12 2	1	12	ON powerkey	UP	40	1000	40
7/0/0:13 2	1	13	ON powerkey	UP	41	1000	41
7/0/0:14 2	1	14	ON	UP	42	1000	42
7/0/0:15		15	powerkey ON	UP	43	1000	43
2 7/0/0:16	1	16	powerkey ON	UP	44	1000	44
2 7/0/0:17	1	17	powerkey ON	UP	45	1000	45
2	1		powerkey				

7/0/0:18		18	ON	UP	46	1000	46
2	1		powerkey				
7/0/0:19		19	ON	UP	47	1000	47
2	1		powerkey				
7/0/7:1	_	1	ON	UP	29	1000	29
	-	1		OF	29	1000	23
2	1		powerkey				
7/0/7:2		2	ON	UP	30	1000	30
2	1		powerkey				
7/0/7:3		3	ON	UP	31	1000	31
2	1		powerkey				
7/0/7:4		4	ON	UP	32	1000	32
2	1		powerkey				
7/0/7:5		5	ON	UP	33	1000	33
	-	J		OF	33	1000	33
2	1	_	powerkey				
7/0/7:6		6	ON	UP	34	1000	34
2	1		powerkey				
7/0/7:7		7	ON	UP	35	1000	35
2	1		powerkey				
7/0/7:8		8	ON	UP	36	1000	36
2	1		powerkey				
7/0/7:9	_	9	ON	UP	37	1000	37
	1	9		OF	31	1000	3 /
2	1	4.0	powerkey		2.2	4000	
7/0/7:10		10	ON	UP	38	1000	38
2	1		powerkey				
7/0/7:11		11	ON	UP	39	1000	39
2	1		powerkey				
7/0/7:12		12	ON	UP	40	1000	40
2	1		powerkey				
7/0/7:13	_	13	ON	UP	41	1000	41
2	1	10		OI	41	1000	4.1
	1		powerkey			4000	
7/0/7:14		14	ON	UP	42	1000	42
2	1		powerkey				
7/0/7:15		15	ON	UP	43	1000	43
2	1		powerkey				
7/0/7:16		16	ON	UP	44	1000	44
2	1		powerkey				
7/0/7:17	_	17	ON	UP	45	1000	45
2	1	Ι/		OI	43	1000	40
	1	1.0	powerkey		4.6	1000	4.5
7/0/7:18		18	ON	UP	46	1000	46
2	1		powerkey				
7/0/7:19		19	ON	UP	47	1000	47
2	1		powerkey				

Configuring the D6 Discovery Protocol

D6 discovery protocol is the discovery portion of the Comcast Next Generation on Demand (NGOD) specification. D6 discovery protocol sends out carrier information such as frequency, annex, modulation mode, interleave, and edge input information such as IP address and maximum bandwidth to an Edge Resource Manager (ERM). D6 discovery protocol also sends unique structured names (topological location information) for each edge input or carrier output. From these structured names, and input and RF port numbers, the ERM can infer the topological network location of both the QAM streaming input port (IP) and RF output port (MPEG).

The D6 discovery protocol configuration can be performed only when the LED protocol is either table-based or GQI. The LED must be in inactive mode to edit or create a D6 discovery protocol configuration. The D6 discovery protocol configuration parameters are:

• Management IP—The source IP address used to establish a connection with the external D6 discovery protocol server (ERM). The IP address must be in the same subnet as configured in a virtual port group.

For GQI LED, this configuration is not needed under D6 discovery protocol as it is automatically fetched from the LED configuration.

- D6 discovery protocol server IP address and port—Identifies the remote D6 discovery protocol server (ERM) IP address and listening port used by the D6 discovery protocol client in LED to setup a connection with the peer. You can configure only one server address and port per LED.
- FQDN (Fully Qualified Domain Name)—This can be given instead of IP address for D6 discovery protocol server.
- Streaming zone—Streaming zone as configured in the D6 discovery protocol server (ERM). The name should match with the configured D6 discovery protocol server in the ERM for the connection to be established.
- Component name—The name of the Edge QAM device. Each LED is considered by the D6 discovery
 protocol server as a separate Edge QAM component. This name is used by the D6 discovery protocol
 server to represent the LED.
- Timeout value—(Optional) Time to wait for connection in socket call.
- Hold time value—(Optional) Time interval that decides the interval of the keepalive message exchange between the client and the server.
- Input group—(Optional) Each virtual edge input IP address under the LED can be assigned an input group name and the maximum bandwidth that is used to send traffic to it. This information is used in D6 discovery protocol messages when advertising the edge inputs to the D6 discovery protocol server. If these parameters are not configured then for group name, the LED or the VCG name, and the default bandwidth of 20 Gbps are used. You must repeat this command for each VEI and VCG under the LED. For GQI LED, there is no option to set VEI IP under the VCG, so, this input group CLI is not available for the VCGs for GQI LEDs.

To configure the D6 discovery protocol, complete the following procedure:

```
configure terminal
cable video
logical-edge-device device name [id number]
protocol gqi | table-based
mqmt-ip ip address
server ip address
virtual-edge-input ip address input-port-number port number
vcq vcq name
vcg vcg name
mac-address mac address
keepalive retry retry count interval seconds
reset interval seconds
discovery d6
streaming-zone name
component-name name
d6-server ip address [port]
d6-server fqdn domain-name
timeout seconds
holdtime seconds
input-group led vei-ip led vei ip address group-name group name [bandwidth mbps]
```

exit active

Verifying the D6 Configuration

To verify the D6 discovery protocol configuration, use the **show cable video logical-edge-device** command as shown in the example below.

This CLI command shows the status and statistics of the D6 client associated to the LED. In the example below, it shows the duration and number of open, updated, keepalive and notification messages exchanged between the D6 client and the server in that duration. It also indicates how many unknown or unrecognized messages are received from the server. When the open message count is more than 1, it indicates that the connection is terminated and reconnected.

```
show cable video logical-edge-device id 1 d6
```

Configuration Examples

This section provides configuration examples for the LED configuration.

Example: GQI LED Configuration

Example: Example: GQI LED Configuration

```
cable video
  mgmt-intf VirtualPortGroup 0
  encryption
    linecard 7/0 ca-system powerkey scrambler des
  service-distribution-group sdg id 1
    onid 1000
    rf-port integrated-cable 7/0/0
```

```
rf-port integrated-cable 7/0/7
virtual-carrier-group vcg id 1
 encrypt
 rf-channel 20-47 tsid 1-28 output-port-number 1-28
virtual-carrier-group vcg-2 id 2
 encrypt
  rf-channel 1-19 tsid 29-47 output-port-number 29-47
bind-vcg
 vcg vcg sdg sdg
 vcg vcg-2 sdg sdg
logical-edge-device led id 1
 protocol gqi
   mgmt-ip 1.33.2.10
   mac-address c414.3c17.6000
   server 1.200.1.193
   server 1.200.1.183
   virtual-edge-input-ip 174.102.1.1 input-port-number 1
   vcg vcg
   vcg vcg-2
   active
```

Feature Information for Logical Edge Devices

The following table provides release information about the feature or features described in this module. This table lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Table 1: Feature Information for Logical Edge Devices

Feature Name	Releases	Feature Information
Logical Edge Devices		This feature was introduced on the Cisco cBR Series Converged Broadband Routers.

Feature Information for Logical Edge Devices