



Preface

This preface describes who should read the *Cisco Service Control Application for Broadband Reference Guide*, how it is organized, its document conventions, and how to obtain documentation and technical assistance. This guide assumes a basic familiarity with the concept of the Cisco Service Control solution, the Service Control Engine (SCE) platforms, and related components.

This guide provides information about the data structures created and used by SCA BB. It is intended for:

- The administrator who is responsible for daily operation of the Cisco Service Control solution
- Integrators who are developing applications on top of SCA BB

Document Revision History

The Document Revision History below records changes to this document.

Revision	Cisco Service Control Release and Date	Change Summary
OL-8410-07	3.1.6 May, 2008	Updated Default Service Configuration Reference Tables, page 1-1
OL-8410-06	3.1.5 November, 2007	Updated Default Service Configuration Reference Tables, page 1-1 Added the following new feature: <ul style="list-style-type: none">• DSCP ToS Classification (see ToS CSV Files, page 5-5)
OL-8410-04	3.1.0 May, 2007	Added the following new features: <ul style="list-style-type: none">• NetFlow (see NetFlow Records: Formats and Field Contents, page 3-1)• Virtual Links Usage RDR, page 2-24 (see also Table VLINK_INI, page 4-11)• Unidirectional Classification (see Protocols Identified on Unidirectional Flows, page 1-35)
OL-8410-03	3.0.5 November, 2006	Added the following new feature: <ul style="list-style-type: none">• Quota State Restore RDRs, page 2-30

Revision	Cisco Service Control Release and Date	Change Summary
OL-8410-02	3.0.3 May, 2006	Added the following new feature: <ul style="list-style-type: none"> • Media Flow RDR, page 2-35 (see also Table RPT_MEDIA, page 4-6) Added the following section to the document: <ul style="list-style-type: none"> • SCE Subscriber Template CSV File, page 5-6
OL-8410-01	3.0.0 December, 2005	First version of this document. Chapters 1, 2, 3 of this document are based on Appendixes B, C, D of the Release 2.5.5 <i>Cisco Service Control Application for Broadband User Guide</i> .

Organization

This guide contains the following sections:

Chapter	Description
Chapter 1, “Default Service Configuration Reference Tables”	Describes the default service configuration provided with the Cisco Service Control Application for Broadband (SCA BB).
Chapter 2, “Raw Data Records: Formats and Field Contents”	Lists the various RDRs produced by the Service Control Engine (SCE) platform and gives their structure, describes the columns and fields of each RDR, and states under what conditions each kind of RDR is generated. Also provides field-content information for fields generated by Service Control components (such as tags), and a description of the Periodic RDR Zero Adjustment Mechanism.
Chapter 3, “NetFlow Records: Formats and Field Contents”	Lists the RDRs whose data can be generated as NetFlow records and describes the fields that may be contained in a NetFlow record.
Chapter 4, “Database Tables: Formats and Field Contents”	Presents the different database tables used for storing RDRs (after their conversion by an adapter), and a description of the table columns (field names and types).
Chapter 5, “CSV File Formats”	Describes the location and structure of CSV files pertaining to service configuration, subscriber management, and data collection management.
Chapter 6, “SCA BB Proprietary MIB Reference”	Describes that part of the Cisco SCE proprietary MIB that provides configuration and runtime status for SCA BB.

Related Publications

Use this *Cisco Service Control Application for Broadband Reference Guide* in conjunction with the following Cisco documentation:

- [Cisco Service Control Application for Broadband User Guide](#)
- [Cisco Service Control Application for Broadband Service Configuration API Programmer Guide](#)
- [Cisco Service Control Management Suite Collection Manager User Guide](#)
- [Cisco Service Control Management Suite Subscriber Manager User Guide](#)
- [Cisco Service Control Application Reporter User Guide](#)
- The SCE platform installation and configuration guides:
 - [Cisco SCE 1000 2xGBE Installation and Configuration Guide](#)
 - [Cisco SCE 2000 4xGBE Installation and Configuration Guide](#)
 - [Cisco SCE 2000 4/8xFE Installation and Configuration Guide](#)
- [Cisco Service Control Engine \(SCE\) CLI Command Reference](#)
- [Cisco Service Control Engine \(SCE\) Software Configuration Guide](#)

Conventions

This document uses the following conventions:

Convention	Indication
bold font	Commands and keywords and user-entered text appear in bold font .
<i>italic font</i>	Document titles, new or emphasized terms, and arguments for which you supply values are in <i>italic font</i> .
[]	Elements in square brackets are optional.
{x y z }	Required alternative keywords are grouped in braces and separated by vertical bars.
[x y z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
<code>courier font</code>	Terminal sessions and information the system displays appear in <code>courier font</code> .
< >	Nonprinting characters such as passwords are in angle brackets.
[]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.



Note

Means *reader take note*.

**Tip**

Means *the following information will help you solve a problem.*

**Caution**

Means *reader be careful.* In this situation, you might perform an action that could result in equipment damage or loss of data.

**Timesaver**

Means *the described action saves time.* You can save time by performing the action described in the paragraph.

**Warning**

Means *reader be warned.* In this situation, you might perform an action that could result in bodily injury.

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS version 2.0.