



Rogue AP Containment on Wired and Wireless Networks

- [Rogue AP Containment Overview, on page 1](#)
- [Wired Rogue AP Containment, on page 2](#)
- [Wireless Rogue AP Containment, on page 3](#)
- [Cisco Rogue AP Containment Actions Compatibility Matrix, on page 5](#)
- [View Tasks and Audit Logs of Rogue AP Containment Type, on page 6](#)

Rogue AP Containment Overview

The Cisco DNA Center Rogue AP Containment feature contains the wired and wireless rogue APs. In case of wired rogue AP containment, Cisco DNA Center brings the **ACCESS** mode switchport interface to the **DOWN** state in which the rogue AP is attached. In case of **Wireless Rogue AP Containment**, Cisco DNA Center instructs the strongest detecting wireless controller to initiate containment on wireless rogue BSSIDs. The wireless controller, in turn, instructs the strongest detecting APs for those BSSIDs to stream the deauthentication packets to disrupt the communication between the rogue APs and the wireless clients of that rogue AP.

Rogue AP containment is further classified as:

- **Wired Rogue AP Containment:** The rogue AP MAC addresses classified as **Rogue on Wire** on the Cisco DNA Center rogue threat dashboard.
- **Wireless Rogue AP Containment:** The rogue AP MAC addresses classified as **Honey_pot**, **Interferer**, or **Neighbor** on the Cisco DNA Center rogue threat dashboard.

Rogue AP containment is supported on Cisco AireOS Controllers and Cisco Catalyst 9800 Series Wireless Controllers.



Note Containment is not supported on aWIPS threats.

Wired Rogue AP Containment

The Wired Rogue AP Containment feature allows Cisco DNA Center to shut down the ACCESS mode interface on the switch to which a rogue AP is physically attached. Cisco DNA Center performs wired rogue AP containment only on ACCESS mode interfaces, because shutting down any other mode might bring the network down.

If the rogue AP is attached to non-ACCESS mode interfaces, the network admin must contain the interface either manually or through a CLI command.

This procedure describes how to perform wired rogue AP containment on an ACCESS mode interface classified as **Rogue on Wire** in Cisco DNA Center.

Before you begin

Download and install the Rogue and aWIPS application package. For more information, see [Download and Install the Rogue and aWIPS Application Package on Cisco DNA Center](#).

Ensure that you have write permission from the provision API, scheduler API, and rogue side to perform this procedure.

Step 1 From the top-left corner, click the menu icon and choose **Assurance > Rogue and aWIPS > Threats**.

Step 2 Click the rogue AP MAC address is classified as **Rogue on Wire** in the **Threat MAC address** column.
The **Threat 360** window appears.

Step 3 From the **Action** drop-down list, choose **Shutdown Switchport**.

A warning dialog box displays the list of ACCESS mode interfaces to be shut down on the corresponding device, and **Configuration Preview** information.

Note The **Shutdown Switchport** option appears in the **Action** drop-down list only when the rogue AP MAC address is marked as **Rogue on Wire**. For more information, see the [Cisco Rogue AP Containment Actions Compatibility Matrix, on page 5](#).

The **Shutdown Switchport** action is irreversible. You must manually bring the switchport back up.

Step 4 In the **Configuration Preview** tab, review the configurations and click **Yes**.

Note **Configuration Preview** tab appears only when **Configuration Preview** is enabled. For information on how to enable Configuration Preview, see the "Enable Visibility and Control of Configurations" topic in the [Cisco DNA Center Administrator Guide](#).

Step 5 The **Threat 360** window displays the wired rogue AP containment status:

- A banner with a blue check mark indicates that the wired rogue AP containment request is in progress.
- A banner with a green check mark indicates that the wired rogue AP containment is initiated successfully on the corresponding interface.
- A banner with a red check mark indicates that the wired rogue AP containment request failed.

- Note**
- After containment is initiated, it takes some time for the interface state to be updated from **Rogue on Wire** to another threat classification type.
 - The **Rogue on Wire** classification type changes to another classification type upon the arrival of the next wireless rogue message for the same rogue AP.

If a rogue AP MAC address is classified as **Rogue on Wire**, but no ACCESS mode interfaces are up to initiate the containment, Cisco DNA Center disables the **Shutdown Switchport** option in the **Action** drop-down list.

- Note** You cannot initiate **Wireless Rogue AP Containment** unless the rogue AP to which it corresponds to is as long as in the **Rogue on Wire** classification type. For more information, see [Wireless Rogue AP Containment, on page 3](#).

Wireless Rogue AP Containment

The Wireless Rogue AP Containment feature allows Cisco DNA Center to contain the wireless clients connected to a rogue AP.

Containment is illegal in some countries because it disrupts the communication between the clients attached to a rogue AP. Cisco DNA Center warns you about the legal consequences while initiating wireless rogue AP containment.

This procedure describes how to start and stop wireless rogue AP containment on wireless clients connected to a rogue AP.

Before you begin

Download and install the Rogue and aWIPS application package. For more information, see [Download and Install the Rogue Management and aWIPS Application Package on Cisco DNA Center](#).

Ensure that you have write permission from the provision API and scheduler API to perform this procedure.

Step 1 From the top-left corner, click the menu icon and choose **Assurance > Rogue and aWIPS > Threats**.

Step 2 To perform wireless rogue AP containment, click a rogue AP MAC address listed under the **Threat MAC address** column, marked as **Honeypot**, **Interferer**, or **Neighbor** classification types.

- Note** Cisco Catalyst 9800 Series Wireless Controller has a limit of only 625 rogue containment configurations at a time. Once the limit is reached, containment won't work for any new rogues on those devices.

The **Threat 360** window is displayed.

- Note** A rogue AP MAC address comprises multiple rogue BSSIDs.

Step 3 From the **Action** drop-down list, choose **Start Containment** and **Configuration Preview**.

A warning dialog box with information about the legal consequences and a list of rogue BSSIDs to be contained on wireless controller and **Configuration Preview** is displayed.

Note The **Start Containment** option appears in the **Action** drop-down list only when the rogue AP MAC address is marked as **Honeypot**, **Interferer**, or **Neighbor** classification type. For more information, see the [Cisco Rogue AP Containment Actions Compatibility Matrix](#).

Step 4 By default, the **Rogue BSSID** list is displayed.

In the **Configuration Preview** tab, review the configurations and click **Yes**.

Note The **Configuration Preview** tab is displayed only when the **Configuration Preview** is enabled. For information on how to enable **Configuration Preview**, see the "Enable Visibility and Control of Configurations" topic in the [Cisco DNA Center Administrator Guide](#).

Step 5 The **Threat 360** window displays the wired rogue AP containment status as follows:

- Banner with a blue check mark indicates that the wireless rogue AP containment request is in progress.
- Banner with a green check mark indicates that the wireless rogue AP containment request is submitted successfully to the strongest detecting AP. A red vertical line appears next to the strongest detecting AP based on the RSSI value.
- Banner with a red check mark indicates that the wireless rogue AP containment request has failed.

Note After containment is initiated, it takes some time for the **Containment Status** column to get update with another wireless containment status.

In the **Threat 360** window, hover your cursor over the **i** icon next to the **Containment** column. A tooltip stating **This always shows current Wireless Containment Status** is displayed.

Step 6 Cisco DNA Center allows you to monitor the **Containment Status** of a wireless rogue AP in the **Rogue and aWIPS** dashboard threat table within Assurance.

Hover your cursor over the **i** icon adjacent to the **Containment Status** column to view the following possible values.

Table 1: Wireless Containment Status Possible Values

Wireless Containment Status	Meaning
Contained	Rogue AP actively contained by the wireless controller.
Pending	Wireless controller has kept this rogue in containment Pending state.
Open	Rogue AP is not contained.
Partial	Some of the rogue BSSIDs are in Open state and the rest of them are either in the Contained or the Containment Pending state.

Note For a rogue AP with wireless containment status as **Partial**, an **i** icon appears adjacent to **Partial** state under the **Containment** column in the **Threat 360** window. Hover your cursor over the **i** icon to view the current wireless containment status of the **Rogue SSIDs**.

The wireless controller can keep the wireless rogue AP containment in **Pending** state because of the following reasons:

- **Resource outage:** After the rogue BSSID containment request is submitted, the wireless controller puts the rogue BSSID containment either in **Containment** or **Containment Pending** state because of the three rogue BSSIDs per radio limitation for client-serving radios, and six rogue BSSIDs per radio limitation for monitor mode. When the

radio exceeds the specified limitation, the next submitted rogue BSSID for containment goes to the **Pending** state by the wireless controller until one of the rogue BSSIDs goes out of **Contained** state.

- **Protected Management Frames (PMF)**: The wireless controller does not initiate containment as long as the Protected Management Frames (PMF) are enabled on rogue BSSIDs and the containment status in **Pending** state. When the PMF is disabled, the wireless controller initiates the containment.
- **Dynamic Frequency Selection (DFS)**: The wireless controller keeps the containment status in Pending state and does not attempt to contain the rogue BSSID if it broadcasts on the Dynamic Frequency Selection (DFS) channels. After the rogue BSSID moves out of the DFS channel, the wireless controller initiates the containment.

Step 7 To bring back all the rogue BSSIDs of the wireless rogue AP marked in **Contained**, **Pending** or **Partial** state to **Open** state, click the corresponding rogue AP MAC address listed under the **Threat MAC address** column.

The **Threat 360** window appears.

Step 8 From the **Action** drop-down list, choose **Stop Containment**.

Note The **Stop Containment** option appears in the **Action** drop-down list only when wireless rogue AP is in **Contained**, **Pending** or **Partial** state. For more information, see the [Cisco Rogue AP Containment Actions Compatibility Matrix, on page 5](#).

- A blue check mark is displayed as a banner on the **Threat 360** window, indicating the progress of the **Stop Containment** process on the wireless rogue AP.
- A green check mark is displayed as a banner on the **Threat 360** window, indicating the progress of the **Stop Containment** process on the wireless rogue AP.

Cisco Rogue AP Containment Actions Compatibility Matrix

The following table shows the behavior of rogue AP containment actions for the current state of rogue APs on the **Threat 360** window.

Table 2: Rogue AP Containment Actions Compatibility Matrix

Rogue AP Threat Type	Rogue AP Current Containment State	Start Containment Option in Actions Drop-Down List	Stop Containment Option in Actions Drop-Down List
Beacon Wrong Channel	Open	Disabled	Disabled
	Contained/Pending/Partial	Disabled	Enabled
Beacon DS Attack	Open	Disabled	Disabled
	Contained/Pending/Partial	Disabled	Enabled
AP Impersonation	Open	Disabled	Disabled
	Contained/Pending/Partial	Disabled	Enabled

View Tasks and Audit Logs of Rogue AP Containment Type

Rogue on Wire	Open/Contained/Pending/Partial	Not Visible Shutdown Switchport is shown	Not Visible Shutdown Switchport is shown
Allowed List	Open	Disabled	Disabled
	Contained/Pending/Partial	Disabled	Enabled
Honeypot	Open	Enabled	Disabled
	Contained/Pending/Partial	Disabled	Enabled
Interferer	Open	Enabled	Disabled
	Contained/Pending/Partial	Disabled	Enabled
Friendly	Open	Disabled	Disabled
	Contained/Pending/Partial	Disabled	Enabled
Neighbor	Open	Enabled	Disabled
	Contained/Pending/Partial	Disabled	Enabled
Custom Rule (High, Potential)	Open	Enabled	Disabled
	Contained/Pending/Partial	Disabled	Enabled
Custom Rule (Informational)	Open	Disabled	Disabled
	Contained/Pending/Partial	Disabled	Enabled

View Tasks and Audit Logs of Rogue AP Containment Type

In case of containment failure, Cisco DNA Center allows you to view the tasks and audit logs of submitted requests of wired and wireless rogue AP containment.

-
- Step 1** From the top-left corner, click the menu icon and choose **Activity**.
- Step 2** In the **Activity** window, click the **Tasks** tab.
- Step 3** Enter **ROGUE** in the **Search** field, or choose **ROGUE** from the list.
A list of submitted requests relating to wired and wireless rogue AP containment is displayed.
- Step 4** Click the corresponding containment request.
The **ROGUE** window is displayed along with the rogue AP containment operation details, status, date, and time.
- Step 5** Click the **Audit Logs** tab to view the rogue AP containment type and corresponding device IP address.

Note

- For Cisco AireOS, the containment request audit logs show the CLI commands.
 - For Cisco Catalyst 9800 Series Wireless Controllers, the containment request audit logs show the NETCONF requests.
 - For **Wired Rogue AP containment**, the audit logs show the CLI commands executed on the switch to bring the switchport down.
-

