

## **Installing Software Maintenance Update**

• Software Maintenance Update (SMU) version 11.5(2) on Cisco DCNM 11.5(1) to use Network Insights Applications, on page 1

# Software Maintenance Update (SMU) version 11.5(2) on Cisco DCNM 11.5(1) to use Network Insights Applications

Cisco DCNM Release 11.5(2) offers a Software Maintenance Update (SMU) that can be applied only on top of the DCNM Release 11.5(1) for the OVA/ISO/Appliance form factor. The DCNM LAN Fabric 11.5(2) release is the first release version that supports Cisco Nexus Insights, Release 5.1 or higher, with Cisco Nexus Dashboard, Release 2.0.2 or higher.

After installing Cisco DCNM, you can download and install various applications from the Cisco App Center.

To download, add, start, stop, and delete applications from the Cisco DCNM Web UI, choose **Applications** > **Catalog** > **Browse App Center**. Refer to Installing and Deploying Applications for instructions.



Note SMU version 11.5(2) is supported with Cisco DCNM Release 11.5(1) only.

Cisco DCNM allows you to upload the NI 5.1 application without the maintenance update. However, you cannot start the application. An error appears asking you to install the SMU before using the NI 5.1 applications.

Note Only a root user must install the SMU version 11.5(2) on Cisco DCNM Release 11.5(1).

For information about SMU version 11.5(2), refer to Cisco DCNM Release Notes, Release 11.5(2).

This chapter contains the following sections:

## Installing SMU version 11.5(2) on Cisco DCNM 11.5(1) Standalone Deployment

To apply the Software Maintenance Update (SMU) on Cisco DCNM LAN Fabric installation in Standalone deployment mode, perform the following steps:

#### Before you begin

- Ensure that Cisco DCNM 11.5.(1) appliance is operational.
- Take a backup of the application data using the appmgr backup command.

dcnm# appmgr backup

Copy the backup file to a safe location outside the DCNM server.

- If Cisco DCNM appliance is installed in VMware environment, ensure that you take a snapshot of the virtual machine. For instructions, refer to VMware Snapshot Support for Cisco DCNM.
- Ensure that you plan for a maintenance window to install SMU version 11.5(2).

#### Procedure

Step 1	Download the SMU file.		
-	a) Go to the following site: http://software.cisco.com/download/.		
	A list of the latest release software for Cisco DCNM available for download is displayed.		
	b) In the Latest Releases list, choose Release 11.5(2).		
	c) Locate DCNM 11.5(2) Maintenance Update for VMWare, KVM, Bare-metal, and Appliance servers file, and click Download icon.		
	d) Save the <b>dcnm-va-patch.11.5.2.iso.zip</b> file to your directory that is easy to find when you start to apply the SMU.		
Step 2	Unzip the dcnm-va-patch.11.5.2.iso.zip file and upload the file to the /root/ folder of the DCNM setup.		
Step 3	Log on to the Cisco DCNM appliance using SSH as a sysadmin user.		
	Run the <b>su</b> command to enable <b>root</b> user.		
	dcnm# <b>su</b> Enter the root password: [root@dcnm]#		
Step 4	Run the following command to create a screen session.		
	[root@dcnm]# screen		
	This creates a session which allows you to execute the commands. The commands continue to run even when the window is not visible or if you get disconnected.		
Step 5	Create a folder named iso using the mkdir -p /mnt/iso command.		
	[root@dcnm]# mkdir -p /mnt/iso		
Step 6	Mount the DCNM SMU version 11.5(2) file in the /mnt/iso folder.		
	[root@dcnm]# mount -o loop dcnm-va-patch.11.5.2.iso /mnt/iso		
Step 7	Navigate to /scripts/ directory.		
	<pre>[root@dcnm]# cd /mnt/iso/packaged-files/scripts/</pre>		
Step 8	Run the ./inline-upgrade.sh script.		

[root@dcnm]# ./inline-upgrade.sh

- **Note** After the SMU is installed successfully, the DCNM process restarts. This results in a momentary loss of access to the DCNM Web UI.
- **Step 9** Ensure the DCNM application is functional, by using the **appmgr status all** command.

[root@dcnm]# appmgr status all

**Step 10** Terminate the screen session, by using the exit command.

[root@dcnm]# exit

**Step 11** Unmount the dcnm-va-patch.11.5.2.iso file from the DCNM setup.

**Note** You must terminate the **screen** session before unmounting the SMU file.

[root@dcnm] # umount /mnt/iso

#### What to do next

Log on to the DCNM Web UI with appropriate credentials. The version shows 11.5(2) on the login screen.

Note

If you try to install the maintenance update again, a note appears stating that the patch is already applied on the Cisco DCNM.

You can now start the NI 5.1 applications on the Cisco DCNM Web UI. Refer to Installing and Deploying Applications for instructions.

## Installing SMU version 11.5(2) on Cisco DCNM 11.5(1) Native HA Deployment

To apply the Software Maintenance Update (SMU) on Cisco DCNM LAN Fabric installation in Native HA deployment mode, perform the following steps:

#### Before you begin

• Ensure that both the Cisco DCNM 11.5.(1) Active and Standby peers are up and running.

To apply this software maintenance update on Cisco DCNM Virtual Appliance in Native HA Mode, apply this update on the Active appliance. Wait until the role of the Active appliance is Active again. Apply the update on the Standby appliance, later.

• Check and ensure that the Active and Standby servers are operational, using the **appmgr show ha-role** command.

Example:

On the Active node:

```
dcnml# appmgr show ha-role
Native HA enabled.
Deployed role: Active
Current role: Active
```

On the Standby node:

dcnm2# appmgr show ha-role Native HA enabled. Deployed role: Standby Current role: Standby

• Take a backup of the application data using the **appmgr backup** command on both Active and Standby appliances.

dcnm1# appmgr backup

dcnm2# appmgr backup

Copy the backup file to a safe location outside the DCNM server.

- If Cisco DCNM appliance is installed in VMware environment, ensure that you take a snapshot of the virtual machine. For instructions, refer to VMware Snapshot Support for Cisco DCNM.
- Ensure that you plan for a maintenance window to install SMU version 11.5(2).

#### Procedure

Step 1	Download the SMU file. a) Go to the following site: http://software.cisco.com/download/.		
	Al	ist of the latest release software for Cisco DCNM available for download is displayed.	
	<ul><li>b) In t</li><li>c) Loo</li><li>d) Sav</li><li>stan</li></ul>	he Latest Releases list, choose Release 11.5(1). cate Software Maintenance Update (SMU) version 11.5(2) file and click Download icon. re the dcnm-va-patch.11.5.2.iso.zip file to your directory that is easy to find when you rt to apply the SMU.	
Step 2	Unzip the <b>dcnm-va-patch.11.5.2.iso.zip</b> file and upload the file to the /root/ folder in both Active and Standby node of the DCNM setup.		
	Note	For example, let us indicate Active and Standby appliances as dcnm1 and dcnm2 respectively.	
Step 3	Log on to the Cisco DCNM appliance using SSH as a sysadmin user.		
	Run the <b>su</b> command to enable <b>root</b> user.		
	dcnm1# <b>su</b> Enter the root password: [root@dcnm1]#		
	dcnm2# Enter [root@	dcnm2# <b>su</b> Enter the root password: [root@dcnm2]#	
Step 4	Run the following command to create a screen session.		
	[root@dcnm1]# screen		
	[root@dcnm2]# screen		
	This creates a session which allows you to execute the commands. The commands continue to run even wher the window is not visible or if you get disconnected.		
Step 5	On the Active node, install the SMU version 11.5(2).		

a) Create a folder named iso using the mkdir /mnt/iso command.

[root@dcnm1]# mkdir -p /mnt/iso

- b) Mount the SMU version 11.5(2) file on the Active node in the /mnt/iso folder.
   [root@dcnm1]# mount -o loop dcnm-va-patch.11.5.2.iso /mnt/iso
- c) Navigate to /scripts/ directory.

[root@dcnm1]# cd /mnt/iso/packaged-files/scripts/

d) Run the ./inline-upgrade.sh script.

[root@dcnm1]# ./inline-upgrade.sh

- **Note** After the SMU is installed successfully, the DCNM process restarts. This results in a momentary loss of access to the DCNM Web UI.
- e) Ensure the DCNM application is functional, by using the **appmgr status all** command.

[root@dcnm1]# appmgr status all

- **Note** Ensure that all the services are up and running on the Cisco DCNM Active node before proceeding to apply SMU on the Standby node.
- **Step 6** On the Standby node, install the SMU version 11.5(2).
  - a) Create a folder named iso using the mkdir /mnt/iso command.
     [root@dcnm2]# mkdir -p /mnt/iso
  - b) Mount the SMU version 11.5(2) file on the Standby node in the /mnt/iso folder. [root@dcnm2]# mount -o loop dcnm-va-patch.11.5.2.iso /mnt/iso
  - c) Navigate to /scripts/ directory.

[root@dcnm2] # cd /mnt/iso/packaged-files/scripts/

d) Run the ./inline-upgrade.sh script.

[root@dcnm2]# ./inline-upgrade.sh --standby

- e) Ensure the DCNM application is functional, by using the appmgr status all command. [root@dcnm2]# appmgr status all
- **Step 7** Terminate the screen session, by using the exit command.

[root@dcnm1]# exit

[root@dcnm2]# exit

Step 8Unmount the dcnm-va-patch.11.5.2.iso file in both Active and Standby node of the DCNM setup.NoteYou must terminate the screen session before unmounting the SMU file.

[root@dcnm1]# umount /mnt/iso
[root@dcnm2]# umount /mnt/iso

#### What to do next

Log on to the DCNM Web UI with appropriate credentials. The version shows 11.5(2) on the login screen.



Note

If you try to install the maintenance update again, a note appears stating that the patch is already applied on the Cisco DCNM.

You can now start the NI 5.1 applications on the Cisco DCNM Web UI. Refer to Installing and Deploying Applications for instructions.

### Installing SMU version 11.5(2) on Cisco DCNM 11.5(1) Compute Nodes

To apply the maintenance update to use NI 5.1 applications with Cisco DCNM LAN Fabric installation on the Compute Nodes, perform the following steps:

#### Before you begin

- Ensure that both the Cisco DCNM 11.5.1(1) Active and Standby peers, and all Compute nodes are operational.
- Ensure that you have installed the SMU version 11.5(2) on both Active and Standby appliances.

For instructions, refer to Installing SMU version 11.5(2) on Cisco DCNM 11.5(1) Native HA Deployment, on page 3.

• Ensure that you plan for a maintenance window to install SMU version 11.5(2).

#### Procedure

- **Step 1** Download the SMU file.
  - a) Go to the following site: http://software.cisco.com/download/.

A list of the latest release software for Cisco DCNM available for download is displayed.

- b) In the Latest Releases list, choose Release 11.5(1).
- c) Locate Software Maintenance Update (SMU) version 11.5(2) file and click Download icon.
- d) Save the dcnm-va-patch.11.5.2.iso.zip file to your directory that is easy to find when you start to apply the SMU.
- **Step 2** Unzip the dcnm-va-patch.11.5.2.iso.zip file and upload the file to the /root/ folder on all the Compute Nodes in the DCNM setup.
  - **Note** For example, let us indicate the 3 compute nodes as **dcnm-compute1**, **dcnm-compute2**, and **dcnm-compute3** respectively.
- Step 3 Log on to the Cisco DCNM Compute node using SSH as a sysadmin user.

Run the su command to enable root user.

dcnm-compute1# su
Enter the root password:
[root@dcnm-compute1]#

```
dcnm-compute2# su
Enter the root password:
[root@dcnm-compute2]#
```

dcnm-compute3# su
Enter the root password:
[root@dcnm-compute3]#

**Step 4** Run the following command to create a screen session.

[root@dcnm-compute1]# screen

[root@dcnm-compute2]# screen

[root@dcnm-compute3]# screen

This creates a session which allows you to execute the commands. The commands continue to run even when the window is not visible or if you get disconnected.

**Step 5** On Compute Node1, apply the SMU version 11.5(2).

a) Create a folder named iso using the mkdir /mnt/iso command.

[root@dcnm-compute1]# mkdir -p /mnt/iso

b) Mount the DCNM SMU version 11.5(2) file in the /mnt/iso folder.

[root@dcnm-compute1]# mount -o loop dcnm-va-patch.11.5.2.iso /mnt/iso

c) Navigate to /scripts/ directory.

[root@dcnm-compute1]# cd /mnt/iso/packaged-files/scripts/

d) Run the ./inline-upgrade.sh script.

[root@dcnm-compute1]# ./inline-upgrade.sh

**Note** After the SMU is installed successfully, the Compute node restarts.

- **Step 6** Execute the instructions in Step 5, on page 7 on Compute Node2 and Compute Node3 to apply the SMU version 11.5(2).
- **Step 7** Terminate the screen session, by using the exit command.

[root@dcnm-compute1]# exit
[root@dcnm-compute2]# exit
[root@dcnm-compute3]# exit

Step 8 Unmount the dcnm-va-patch.11.5.2.iso file on all the Compute Nodes, by using the umount /mnt/iso command.

**Note** You must terminate the **screen** session before unmounting the patch file.

[root@dcnm-compute1]# umount /mnt/iso [root@dcnm-compute2]# umount /mnt/iso [root@dcnm-compute3]# umount /mnt/iso

#### What to do next

Log on to the DCNM Web UI with appropriate credentials.

Choose Applications > Compute. The Compute IP status shows Joined.



Note If you try to install the SMU again, a note appears stating that the SMU is already applied on the Cisco DCNM.