



## D Commands

---

- [data-pattern-file](#), on page 3
- [deadtime \(radius group configuration\)](#), on page 4
- [deadtime \(tacacs+ group configuration\)](#), on page 5
- [deadtime \(server group configuration mode\)](#), on page 6
- [delete](#), on page 7
- [delete ca-certificate](#), on page 9
- [delete certificate](#), on page 10
- [delete crt](#), on page 11
- [deny \(IPv6-ACL configuration\)](#), on page 12
- [description](#), on page 15
- [destination interface](#), on page 16
- [destination-group](#), on page 18
- [destination-profile](#), on page 20
- [destination-profile \(telemetry\)](#), on page 23
- [device-alias \(IVR fcdomain database configuration submode\)](#), on page 24
- [device-alias \(SDV virtual device configuration submode\)](#), on page 25
- [device-alias abort](#), on page 26
- [device-alias commit](#), on page 27
- [device-alias commit force](#), on page 28
- [device-alias confirm-commit enable](#), on page 29
- [device-alias database](#), on page 30
- [device-alias distribute](#), on page 31
- [device-alias import fcalias](#), on page 32
- [device-alias mode enhanced](#), on page 33
- [debug ldap](#), on page 35
- [device-alias name](#), on page 36
- [diagnostic bootup level](#), on page 37
- [diagnostic isl latency-test](#), on page 38
- [diagnostic isl multi\\_hop generator](#), on page 39
- [diagnostic isl multi\\_hop reflector](#), on page 41
- [diagnostic isl show status](#), on page 43
- [diagnostic monitor interval module](#), on page 44
- [diagnostic monitor module](#), on page 46

- [diagnostic ondemand iteration](#), on page 47
- [diagnostic ondemand action-on-failure](#), on page 48
- [diagnostic start interface fc test link-diag](#), on page 49
- [diagnostic start module](#), on page 52
- [diagnostic stop interface fc test link-diag](#), on page 53
- [diagnostic stop module](#), on page 54
- [dir](#), on page 55
- [disable](#), on page 57
- [discover](#), on page 58
- [discover custom-list](#), on page 59
- [discover scsi-target](#), on page 60
- [distribute](#), on page 62
- [dmm module](#), on page 63
- [dmm module job](#), on page 64
- [do](#), on page 66
- [dpvm abort](#), on page 68
- [dpvm activate](#), on page 69
- [dpvm auto-learn](#), on page 70
- [dpvm commit](#), on page 72
- [dpvm database](#), on page 73
- [dpvm database copy active](#), on page 75
- [dpvm database diff](#), on page 76
- [dpvm distribute](#), on page 77
- [dpvm enable](#), on page 78
- [dpvm overwrite-duplicate-pwwn](#), on page 79
- [dscp](#), on page 80
- [dst-grp](#), on page 82
- [duplicate-message throttle](#), on page 84

# data-pattern-file

To configure data pattern file for a SAN tuner extension N port, use the **data-pattern-file** command in interface configuration submenu. To remove data pattern file, use the **no** form of the command.

**data-pattern-file** *filename*  
**no data-pattern-file**

## Syntax Description

<i>filename</i>	Specifies the data pattern file name.
-----------------	---------------------------------------

## Command Default

All zero pattern.

## Command Modes

SAN extension N port configuration submenu.

## Command History

Release	Modification
2.0(x)	This command was introduced.

## Usage Guidelines

By default, an all-zero pattern is used as the pattern for data generated by the virtual N ports. You can optionally specify a file as the data pattern to be generated by selecting a data pattern file from one of three locations: the bootflash: directory, the volatile: directory, or the slot0: directory. This option is especially useful when testing compression over FCIP links. You can also use Canterbury corpus or artificial corpus files for benchmarking purposes.

## Examples

The following example configures the data pattern file for an N port:

```
switch# san-ext-tuner
switch(san-ext) # nwwn 10:00:00:00:00:00:00:00
switch(san-ext) # nport pwn 12:00:00:00:00:00:00:00:56 vsan 13 interface gigabitethernet 1/2
switch(san-ext-nport) # data-pattern-file bootflash://DataPatternFile
```

## Related Commands

Command	Description
<b>nport pwn</b>	Configures SAN extension tuner N port pWWNs.
<b>san-ext-tuner</b>	Enters SAN extension tuner configuration mode.
<b>show san-ext-tuner</b>	Displays SAN extension tuner information.

# deadtime (radius group configuration)

To configure a periodic time interval where a nonreachable (non-responsive) RADIUS server is monitored for responsiveness, use the **deadtime** command in RADIUS group configuration submode. To disable the monitoring of the non-responsive server, use the **no** form of the command.

**deadtime** *time*

**no deadtime** *time*

## Syntax Description

<i>time</i>	Specifies the time interval (in minutes) for monitoring the server. The time range is 1 to 1440 minutes.
-------------	--

## Command Default

Zero.

## Command Modes

RADIUS group configuration submode.

## Command History

Release	Modification
3.0(1)	This command was introduced.

## Usage Guidelines

If the dead time interval for an individual RADIUS server is greater than zero (0), that value takes precedence over the value set for the server group.

When the dead time interval is 0 minutes, RADIUS server monitoring is not performed unless the RADIUS server is part of a server group and the dead time interval for the group is greater than 0 minutes.

## Examples

The following example shows the **deadtime** command in RADIUS group configuration submode:

```
switch# config terminal
switch(config)# aaa group server radius testgroup
switch(config-radius)# deadtime 10
```

## Related Commands

Command	Description
<b>radius-server deadtime</b>	Sets a time interval for monitoring a nonresponsive RADIUS server.
<b>show radius-server</b>	Displays RADIUS server information.

## deadtime (tacacs+ group configuration)

To configure a periodic time interval where a non-reachable (non responsive) TACACS+ server is monitored for responsiveness, use the **deadtime** command in TACACS+ group configuration submenu. To disable the monitoring of the non responsive server, use the **no** form of the command.

**deadtime** *time*  
**no deadtime** *time*

<b>Syntax Description</b>	<table><tr><td><i>time</i></td><td>Specifies the time interval (in minutes) for monitoring the server. The time range is 1 to 1440 minutes.</td></tr></table>	<i>time</i>	Specifies the time interval (in minutes) for monitoring the server. The time range is 1 to 1440 minutes.
<i>time</i>	Specifies the time interval (in minutes) for monitoring the server. The time range is 1 to 1440 minutes.		

<b>Command Default</b>	Zero.
------------------------	-------

<b>Command Modes</b>	TACACS+ group configuration submenu.
----------------------	--------------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	3.0(1)	This command was introduced.

<b>Usage Guidelines</b>	If the dead time interval for an individual TACACS+ server is greater than zero (0), that value takes precedence over the value set for the server group.
-------------------------	---

When the dead time interval is 0 minutes, TACACS+ server monitoring is not performed unless the TACACS+ server is part of a server group and the dead time interval for the group is greater than 0 minutes.

### Examples

The following example shows the **deadtime** command in TACACS+ group configuration submenu:

```
switch# config terminal
switch(config)# aaa group server tacacs mygroup
switch(config-tacacs)# deadtime 5
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show tacacs-server</b>	Displays TACACS+ server information.
	<b>tacacs-server deadtime</b>	Sets a time interval for monitoring a nonresponsive TACACS+ server.

## deadtime (server group configuration mode)

To configure deadtime within the context of LDAP server groups, use the **deadtime** command in server group configuration mode. To disable this feature, use the no form of the command.

**deadtime** *minutes*  
**no deadtime** *minutes*

**Syntax Description** This command has no arguments or keywords.

**Command Default** None.

**Command Modes** Server group configuration mode.

Command History	Release	Modification
	NX-OS 5.0(1a)	This command was introduced.

**Usage Guidelines** None.

**Examples** The following example shows how to configure deadtime within the context of LDAP server groups:

```
switch(config-ldap) # deadtime minutes
switch(config-ldap) #
```

Related Commands	Command	Description
	<b>show ldap-server groups</b>	Displays the configured LDAP server groups.

# delete

To delete a specified file or directory on a flash memory device, use the **delete** command in EXEC mode.

**delete** {**bootflash**:*filename* | **debug**:*filename* | **log**:*filename* | **modflash**:*filename* | **slot0**:*filename* | **volatile**:*filename*}

## Syntax Description

<b>bootflash:</b>	Flash image that resides on the supervisor module.
<i>filename</i>	The name of the file to be deleted.
<b>debug:</b>	Contains the debug files.
<b>log:</b>	Contains the two default logfiles. The file dmesg contains the kernel log-messages and the file messages contains the system application log-messages.
<b>modflash:</b>	Flash image that resides on a module.
<b>slot0:</b>	Flash image that resides on another module.
<b>volatile:</b>	Flash image that resides on the volatile file system.

## Command Default

None.

## Command Modes

EXEC mode.

## Command History

Release	Modification
1.0(2)	This command was introduced.
2.1(1a)	Added debug, log, and modflash keywords.

## Usage Guidelines

When you delete a file, the software erases the file.

If you attempt to delete the configuration file or image specified by the CONFIG\_FILE or BOOTLDR environment variable, the system prompts you to confirm the deletion. Also, if you attempt to delete the last valid system image specified in the BOOT environment variable, the system prompts you to confirm the deletion.



### Caution

If you specify a directory, the **delete** command deletes the entire directory and all its contents.

## Examples

The following example deletes the file named test from the flash card inserted in slot 0:

```
switch# delete slot0:test
Delete slot0:test? [confirm]
```

The following example deletes a file from a directory:

```
switch# delete dns_config.cfg
```

The following example deletes a file from an external CompactFlash (slot0):

```
switch# delete slot0:dns_config.cfg
```

The following example deletes the entire my-dir directory and all its contents:

```
switch# delete bootflash:my-dir
```

The following example deletes the entire user created dk log file on the active supervisor:

```
switch# delete log://sup-active/
log://sup-active/dk          log://sup-active/dmesg      log://sup-active/messages
switch# delete log://sup-active/dk
switch# dir log:
      31      Feb 04 18:22:03 2005  dmesg
    14223      Feb 04 18:25:30 2005  messages
Usage for log://sup-local
    35393536 bytes used
    174321664 bytes free
    209715200 bytes total
switch#
```

## Related Commands

Command	Description
<b>cd</b>	Changes the default directory or file system.
<b>dir</b>	Displays a list of files on a file system.
<b>show boot</b>	Displays the contents of the BOOT environment variable, the name of the configuration file pointed to by the CONFIG_FILE environment variable, the contents of the BOOTLDR environment variable, and the configuration register setting.



# delete ca-certificate

To delete certificate authority certificates, use the **delete ca-certificate** command in trust point configuration submode.

**delete ca-certificate**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None.

**Command Modes** Trust point configuration submode.

Command History	Release	Modification
	3.0(1)	This command was introduced.

**Usage Guidelines** This command deletes the CA certificate or certificate chain corresponding to the trust point CA. As a result, the trust point CA is no longer trusted. If there is an identity certificate from the CA, you should delete it before attempting to delete the CA certificate. Doing so prevents the accidental deletion of a CA certificate when you have not yet deleted the identity certificate from that CA. This action may be necessary when you do not want to trust the CA any more for a reason such as the CA is compromised or the CA certificate is already expired, with the latter being a very rare event.



**Note** The trust point configuration, certificates, and key pair configurations are made persistent only after saving to the startup configuration. To be consistent with this configuration behavior, the delete behavior is also the same. That is, the deletions are made persistent only after saving to the startup configuration. Use the **copy running-config startup-config** command to make the certificate and key pair deletions persistent.

## Examples

The following example shows how to delete a certificate authority certificate:

```
switch# config terminal
switch(config)# crypto ca trustpoint admin-ca
switch(config-trustpoint)# delete ca-certificate
```

Related Commands	Command	Description
	<b>delete certificate</b>	Deletes the identity certificate.
	<b>delete crl</b>	Deletes the crl from the trustpoint.

# delete certificate

To delete the identity certificate, use the **delete certificate** command in trust point configuration submode.

**delete certificate** [**force**]

## Syntax Description

<b>force</b>	(Optional) Forces the deletion of the identity certificate.
--------------	---

## Command Default

None.

## Command Modes

Trust point configuration submode.

## Command History

Release	Modification
3.0(1)	This command was introduced.

## Usage Guidelines

Use this command to delete the identity certificate from the trust point CA. This action may be necessary when the identity certificate expires or the corresponding key pair is compromised. Applications will be left without any identity certificate to use after the deletion of the last or the only identity certificate present. Accordingly, an error message is generated if the certificate being deleted is the last or only identity certificate present. If needed, the deletion can still be accomplished by forcing it using the force option.



### Note

The trust point configuration, certificates, and key pair configurations are made persistent only after saving to the startup configuration. To be consistent with this configuration behavior, the delete behavior is also the same. That is, the deletions are made persistent only after saving to the startup configuration. Use the **copy running-config startup-config** command to make the certificate and key pair deletions persistent.

## Examples

The following example shows how to delete the identity certificate:

```
switch# config terminal
switch(config)# crypto ca trustpoint admin-ca
switch(config-trustpoint)# delete certificate
```

The following example shows how to force the deletion of the identity certificate:

```
switch(config-trustpoint)# delete certificate force
```

## Related Commands

Command	Description
<b>delete ca-certificate</b>	Deletes the certificate authority certificate.
<b>delete crl</b>	Deletes the crl from the trustpoint.

# delete crl

To delete the crl from the trustpoint, use the **delete crl** command in trust point configuration submode.

**delete crl**

**Syntax Description** This command has no argument or keywords.

**Command Default** None.

**Command Modes** Trust point configuration submode.

Command History	Release	Modification
	3.0(1)	This command was introduced.

**Usage Guidelines** None.

**Examples** The following example shows how to delete the crl from the trustpoint:

```
switch# config terminal
switch(config)# crypto ca trustpoint admin-ca
switch(config-trustpoint)# delete crl
```

Related Commands	Command	Description
	<b>delete ca-certificate</b>	Deletes the certificate authority certificate.
	<b>delete certificate</b>	Deletes the identity certificate.

## deny (IPv6-ACL configuration)

To configure deny conditions for an IPv6 access control list (ACL), use the **deny** command in IPv6-ACL configuration submode. To remove the conditions, use the **no** form of the command.

```
deny {ipv6-protocol-number | ipv6} {source-ipv6-prefix/prefix-length | any | host source-ipv6-address}
{dest-ipv6-prefix/prefix-length | any | host dest-ipv6-address} [log-deny]
deny icmp {source-ipv6-prefix/prefix-length | any | host source-ipv6-address}
{dest-ipv6-prefix/prefix-length | any | host dest-ipv6-address} [icmp-type [icmp-code]] [log-deny]
deny tcp {source-ipv6-prefix/prefix-length | any | host source-ipv6-address} [source-port-operator
source-port-number | range source-port-number source-port-number] {dest-ipv6-prefix/prefix-length |
any | host dest-ipv6-address} [dest-port-operator dest-port-number | range dest-port-number
dest-port-number] [established] [log-deny]
deny udp {source-ipv6-prefix/prefix-length | any | host source-ipv6-address} [source-port-operator
source-port-number | range source-port-number source-port-number] {dest-ipv6-prefix/prefix-length | any
| host dest-ipv6-address} [dest-port-operator dest-port-number | range dest-port-number dest-port-number]
[log-deny]
no deny {ipv6-protocol-number | ipv6 | icmp | tcp | udp}
```

### Syntax Description

<i>ipv6-protocol-number</i>	Specifies an IPv6 protocol number. The range is 0 to 255.
<b>ipv6</b>	Applies the ACL to any IPv6 packet.
<i>source-ipv6-prefix/prefix-length</i>	Specifies a source IPv6 network or class of networks. The format is <i>X:X:X::X/n</i> .
<b>any</b>	Applies the ACL to any source or destination prefix.
<b>host</b> <i>source-ipv6-address</i>	Applies the ACL to the specified source IPv6 host address. The format is <i>X:X:X::X</i> .
<i>dest-ipv6-prefix/prefix-length</i>	Specifies a destination IPv6 network or class of networks. The format is <i>X:X:X::X/n</i> .
<b>host</b> <i>dest-ipv6-address</i>	Applies the ACL to the specified destination IPv6 host address. The format is <i>X:X:X::X</i> .
<b>log-deny</b>	(Optional) For packets that are dropped, creates an informational log message about the packet that matches the entry. The message includes the input interface.
<b>icmp</b>	Applies the ACL to any Internet Control Message Protocol (ICMP) packet.
<i>icmp-type</i>	Specifies an ICMP message type. The range is 0 to 255.
<i>icmp-code</i>	Specifies an ICMP message code. The range is 0 to 255.
<b>tcp</b>	Applies the ACL to any TCP packet.
<i>source-port-operator</i>	Specifies an operand that compares the source ports of the specified protocol. The operands are <b>lt</b> (less than), <b>gt</b> (greater than), and <b>eq</b> (equals).

<i>source-port-number</i>	Specifies the port number of a TCP or UDP port. The number can be from 0 to 65535. A range requires two port numbers.
<b>udp</b>	Applies the ACL to any UDP packet.
<i>dest-port-operator</i>	Specifies an operand that compares the destination ports of the specified protocol. The operands are <b>lt</b> (less than), <b>gt</b> (greater than), and <b>eq</b> (equals).
<i>dest-port-number</i>	Specifies the port number of a TCP or UDP port. The number can be from 0 to 65535. A range requires two port numbers.
<b>range</b>	Specifies a range of ports to compare for the specified protocol.
<b>established</b>	(Optional) Indicates an established connection, which is defined as a packet whose SYN flag is not set.

**Command Default** None.

**Command Modes** IPv6-ACL configuration submode.

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	3.0(1)	This command was introduced.

**Usage Guidelines** The following guidelines can assist you in configuring an IPv6-ACL.

You can apply IPv6-ACLs to VSAN interfaces, the management interface, Gigabit Ethernet interfaces on IPS modules and MPS-14/2 modules, and Ethernet PortChannel interfaces. However, if IPv6-ACLs are already configured in a Gigabit Ethernet interface, you cannot add this interface to a Ethernet PortChannel group.



**Caution** Do not apply IPv6-ACLs to just one member of a PortChannel group. Apply IPv6-ACLs to the entire channel group.

- Use only the TCP or ICMP options when configuring IPv6-ACLs on Gigabit Ethernet interfaces.
- Configure the order of conditions accurately. Because the IPv6-ACL filters are applied sequentially to the IP flows, the first match determines the action taken. Subsequent matches are not considered. Be sure to configure the most important condition first. If no conditions match, the software drops the packet.

## Examples

The following example configures an IPv6-ACL called List1, enters IPv6-ACL submode, and adds an entry to deny TCP traffic from any source address to any destination address:

```
switch# config terminal
switch(config)# ipv6 access-list List1
switch(config-ipv6-acl)# deny tcp any any
```

The following example removes a deny condition set for any destination prefix on a specified UDP host:

```
switch# config terminal
```

```
switch(config)# ipv6 access-list List1  
switch(config-ipv6-acl)# no deny udp host 2001:db8:200d::4000 any
```

The following example removes the IPv6-ACL called List1 and all its entries:

```
switch# config terminal  
switch(config)# no ipv6 access-list List1
```

#### Related Commands

Command	Description
<b>ipv6 access-list</b>	Configures an IPv6 ACL and enters IPv6-ACL configuration submode.
<b>permit</b>	Configures permit conditions for an IPv6 ACL.

# description

To configure a description for the Event Manager policy, use the description command.

**description** *policy-description*

## Syntax Description

<i>policy-description</i>	Configures a descriptive string for the policy. The string can be any alphanumeric string up to 80 characters. Enclose the string in quotation marks.
---------------------------	---

## Command Default

None.

## Command Modes

Embedded Event Manager.

## Command History

Release	Modification
NX-OS 4.1(3)	This command was introduced.

## Usage Guidelines

None.

## Examples

The following example shows how to configure a descriptive string for the policy:

```
switch# configure terminal
switch(config)# event manager applet eem-applet
switch(config-applet)# description "Monitors interface shutdown."
switch(config-applet)#
```

## Related Commands

Command	Description
<b>show interface</b>	Displays an interface configuration for a specified interface.
<b>shutdown</b>	Disables and enables an interface.

# destination interface

To configure a switched port analyzer (SPAN) destination interface, use the **destination interface** command in SPAN session configuration submode. To disable this feature, use the **no** form of the command.

**destination interface** {*fc slot/port* | **fc-tunnel** *tunnel-id*}  
**no destination interface** {*fc slot/port* | **fc-tunnel** *tunnel-id*}

<b>Syntax Description</b>	<b>fc</b> <i>slot/port</i>	Specifies the Fibre Channel interface ID at a slot and port.
	<b>fc-tunnel</b> <i>tunnel-id</i>	Specifies the Fibre Channel tunnel interface ID.
<b>Command Default</b>	Disabled.	
<b>Command Modes</b>	SPAN session configuration submode.	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	6.2(5)	SPAN is supported and RSPAN is not supported in Cisco MDS 9250i Multiservice Fabric Switch.
	1.0(2)	This command was introduced.
	1.2(1)	Added the fc-tunnel parameter.

**Usage Guidelines** The SPAN destination interface must be configured as SPAN destination port (SD port) mode using the **switchport** command before the interface can be associated with SPAN session as a destination interface.

**Examples** The following example shows how to configure an interface as a SPAN destination port (SD port), create a SPAN session, and then configure the interface fc3/13 as the SPAN destination interface:

```
switch# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# interface fc3/13
switch(config-if)# switchport mode

switch# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# interface fc3/13
switch(config-if)# switchport mode sd
switch(config-if)# exit
switch(config)# span session 1
switch(config-span)# destination interface fc3/13
switch(config-span)# do show span session 1
switch(config-span)# show span session 1
Session 1 (inactive as destination is down)
  Destination is fc3/13
  No session filters configured
  No ingress (rx) sources
  No egress (tx) sources
switch(config-span)#
```



**Related Commands**

Command	Description
<b>show span session</b>	Displays specific information about a SPAN session.
<b>source</b>	Configures a SPAN source.
<b>span session</b>	Selects or configures the SPAN session and changes to SPAN configuration submode.
<b>suspend</b>	Suspends a SPAN session.
<b>switchport</b>	Configures the switch port mode on the Fibre Channel interface.

# destination-group

To create a destination group and enter destination group configuration mode, use the **destination-group** command. To remove the destination group, use the **no** form of this command.

**destination-group** *id*

**no destination-group** *id*

## Syntax Description

<i>id</i>	Destination group ID. Range is from 1 to 4095.
-----------	--

## Command Default

No destination group exists.

## Command Modes

Telemetry configuration mode (config-telemetry)

## Command History

Release	Modification
8.3(1)	This command was introduced.

## Usage Guidelines

Currently, destination group ID supports only numeric ID values.

## Examples

This example shows how to create a destination group and enter destination group configuration mode:

```
switch# configure
switch(config)# telemetry
switch(config-telemetry)# destination-group 100
switch(conf-tm-dest)#
```

This example shows how to remove a destination group:

```
switch# configure
switch(config)# telemetry
switch(config-telemetry)# no destination-group 100
```

## Related Commands

Command	Description
<b>destination-profile</b>	Specifies the default destination profile and enters destination profile configuration mode.
<b>feature telemetry</b>	Enables the SAN Telemetry Streaming feature.
<b>ip (destination-group)</b>	Configures an IPv4 or IPv6 destination address for a destination group.
<b>show running-config telemetry</b>	Displays the existing telemetry configuration.

Command	Description
<b>show telemetry</b>	Displays telemetry configuration.
<b>telemetry</b>	Enters SAN Telemetry Streaming configuration mode.

## destination-profile

To configure the attributes of the destination such as the e-mail address or the message level with the Call Home function, use the **destination-profile** command in Call Home configuration submode. To disable this feature, use the **no** form of the command.

```
{destination-profile {profile-name | XML-destination | full-txt-destination | short-txt-destination}
alert-group {all | cisco-Tac | Crash | environmental | inventory | license | linecard-hardware | rmon |
supervisor-hardware | syslog-group-port | system | test} | email-addr email-address | http https-or-http
url | message-level message-level | message-size message-size | transport-method {email | http}}
{no destination-profile {profile-name | XML-destination | full-txt-destination | short-txt-destination}
alert-group {all | cisco-Tac | Crash | environmental | inventory | license | linecard-hardware | rmon |
supervisor-hardware | syslog-group-port | system | test} | email-addr email-address | http https-or-http
url | message-level message-level | message-size message-size | transport-method {email | http}}
```

### Syntax Description

<i>profile-name</i>	Specifies a user-defined user profile with a maximum of 32 alphanumeric characters.
<b>XML-destination</b>	Configures the destination profile for XML messages.
<b>full-txt-destination</b>	Configures the destination profile for plain text messages.
<b>short-txt-destination</b>	Configures the destination for short text messages.
<b>alert-group</b>	Specifies one or more of the alert groups.
<b>all</b>	Specifies an alert group consisting of all Call Home messages.
<b>cisco-Tac</b>	Specifies an alert group consisting of events that are meant only for Cisco TAC.
<b>Crash</b>	Specifies an alert group consisting of software crash events for Call Home.
<b>environmental</b>	Specifies an alert group consisting of power, fan, and temperature-related events.
<b>inventory</b>	Specifies an alert group consisting of inventory status events.
<b>license</b>	Specifies an alert group consisting of license status events.
<b>linecard-hardware</b>	Specifies an alert group consisting of module related events.
<b>rmon</b>	Specifies an alert group consisting of RMON status events.
<b>supervisor-hardware</b>	Specifies an alert group consisting of supervisor-related events.
<b>syslog-port-group</b>	Specifies an alert group consisting of syslog port group status events.
<b>system</b>	Specifies an alert group consisting of software-related events.
<b>test</b>	Specifies an alert group consisting of user-generated test events.
<b>email-addr</b>	E-mail transport method.

<i>email-address</i>	Specifies the E-mail address.
<b>http</b>	HTTP transport method.
<i>https-or-http url</i>	Specifies the HTTP or HTTPs URL.
<b>message-level</b> <i>message-level</i>	Specifies Call Home message level (0 is the lowest urgency, 9 is the highest urgency).
<b>message-size</b> <i>message-size</i>	Configures the maximum message size (default 2500000).
<b>transport-method</b>	Specifies Call Home message-sending transport method.
<b>email</b>	Specifies the e-mail transport method.
<b>http</b>	Specifies the HTTP transport method.

**Command Default**

None.

**Command Modes**

Call Home configuration submode.

**Command History**

Release	Modification
NX-OS 4.2(1)	Deleted Avanti keyword from the syntax description. Added the Usage guideline.
NX-OS 4.1(3)	Added the HTTPs URL and transport method for syntax description.
1.0(2)	This command was introduced.

**Usage Guidelines**

The transport method as well as the HTTP URL is distributed only to the switches in the fabric running images for 4.2(1) and later. The switches running in the lower version images will simply ignore the HTTP configuration.

The HTTP configuration also will not be distributed to switches that support the HTTP configuration but do not distribute it.

**Examples**

The following example shows how to configure XML destination profiles for the HTTP URL:

```
switch(config-callhome) # destination-profile XML-destination http http://site.service.com
switch(config-callhome) # no destination-profile XML-destination http http://site.service.com
```

The following example enables the transport method for destination profile:

```
switch(config-callhome) # destination-profile XML-destination transport-method http
switch(config-callhome) # no destination-profile XML-destination transport-method http
switch(config-callhome) #
switch(config-callhome) # destination-profile XML-destination transport-method email
switch(config-callhome) # no destination-profile XML-destination transport-method email
switch(config-callhome) #
```

The following example shows how to configure full-text destination profiles:

```
switch# config terminal  
Enter configuration commands, one per line. End with CNTL/Z.  
switch(config)# callhome  
switch(config-callhome)# destination-profile full-txt-destination email-addr person@place.com  
switch(config-callhome)# destination-profile full-txt-destination message-size 1000000
```

The following example shows how to configure short-text destination profiles:

```
switch(config-callhome)# destination-profile short-txt-destination email-addr person@place.com  
switch(config-callhome)# destination-profile short-txt-destination message-size 100000
```

#### Related Commands

Command	Description
<b>call home</b>	Configures the Call Home function.
<b>callhome test</b>	Sends a dummy test message to the configured destinations.
<b>show callhome</b>	Displays configured Call Home information.

# destination-profile (telemetry)

To specify the default destination profile and enter destination profile configuration mode, use the **destination-profile** command. To remove the default destination profile, use the **no** form of this command.

**destination-profile**

**no destination-profile**

## Syntax Description

This command has no arguments or keywords.

## Command Default

No destination profile exists.

## Command Modes

Telemetry configuration mode (config-telemetry)

## Command History

Release	Modification
8.3(1)	This command was introduced.

## Examples

This example shows how to specify the default destination profile and enter destination profile configuration mode:

```
switch# configure
switch(config)# telemetry
switch(config-telemetry)# destination-profile
switch(conf-tm-dest-profile)#
```

This example shows how to remove the default destination profile:

```
switch# configure
switch(config)# telemetry
switch(config-telemetry)# no destination-profile
```

## Related Commands

Command	Description
<b>destination-group</b>	Creates a destination group and enters destination group configuration mode.
<b>feature telemetry</b>	Enables the SAN Telemetry Streaming feature.
<b>ip (destination-group)</b>	Configures an IPv4 or IPv6 destination address for a destination group.
<b>show running-config telemetry</b>	Displays the existing telemetry configuration.
<b>show telemetry</b>	Displays telemetry configuration.
<b>telemetry</b>	Enters SAN Telemetry Streaming configuration mode.

# device-alias (IVR fcdomain database configuration submode)

To map a device alias to a persistent FC ID for IVR, use the **device-alias** command in IVR fcdomain database configuration submode. To remove the mapping for the device alias, use the **no** form of the command.

**device-alias** *device-name fc-id*

**no device-alias** *device-name*

## Syntax Description

<i>device-name</i>	Specifies the device name. Maximum length is 64 characters.
<i>fc-id</i>	Specifies the FC ID for the device.

## Command Default

None.

## Command Modes

IVR fcdomain database configuration submode.

## Command History

Release	Modification
2.1(2)	This command was introduced.

## Usage Guidelines

Only one FC ID can be mapped to a device alias.

## Examples

The following example shows how to map the device alias to the persistent FC ID:

```
switch# config t
switch(config)# ivr fcdomain database autonomous-fabric-num 10 vsan 20
switch(config-fcdomain)# native-autonomous-fabric-num 20 native-vsan 30 domain 15
switch(config-fcdomain-fcid)# device-alias SampleName 0x123456
```

The following example shows how to remove the mapping between the device alias and the FC ID:

```
switch# config t
switch(config)# ivr fcdomain database autonomous-fabric-num 10 vsan 20
switch(config-fcdomain)# native-autonomous-fabric-num 20 native-vsan 30 domain 15
switch(config-fcdomain-fcid)# no device-alias SampleName
```

## Related Commands

Command	Description
<b>ivr fcdomain database autonomous-fabric-num</b>	Creates IVR persistent FC IDs.
<b>native-autonomous-fabric-num</b>	Creates an IVR persistent FC ID database entry.
<b>show ivr fcdomain database</b>	Displays IVR fcdomain database entry information.



## device-alias (SDV virtual device configuration submode)

To add a device alias to a virtual device, use the **device-alias** command in SDV virtual device configuration submode. To remove a device alias, use the **no** form of the command.

**device-alias** *device-name* [**primary**]  
**no device-alias** *device-name* [**primary**]

### Syntax Description

<i>device-name</i>	Specifies the device name. Maximum length is 64 characters.
<b>primary</b>	(Optional) Specifies the device as a primary device.

### Command Default

None.

### Command Modes

SDV virtual device configuration submode.

### Command History

Release	Modification
3.1(2)	This command was introduced.

### Usage Guidelines

None.

### Examples

The following example shows how to configure a virtual target alias name:

```
switch# config terminal  
Enter configuration commands, one per line. End with CNTL/Z.  
switch(config)# sdv virtual-device name sql vsan 1  
switch(config-sdv-virt-dev)# device-alias group1 primary
```

### Related Commands

Command	Description
<b>sdv enable</b>	Enables or disables SAN device virtualization.
<b>show sdv statistics</b>	Displays SAN device virtualization statistics.

# device-alias abort

To discard a Distributed Device Alias Services (device alias) Cisco Fabric Services (CFS) distribution session in progress, use the **device-alias abort** command in **configuration mode**.

**device-alias abort**

**Syntax Description** This command has no other arguments or keywords.

**Command Default** None.

**Command Modes** Configuration mode.

Command History	Release	Modification
	2.0(x)	This command was introduced.

**Usage Guidelines** None.

**Examples** The following example shows how to discard a device alias CFS distribution session in progress:

```
switch# config terminal
switch(config)# device-alias abort
```

Related Commands	Command	Description
	<b>device-alias database</b>	Configures and activates the device alias database.
	<b>device-alias distribute</b>	Enables CFS distribution for device aliases.
	<b>show device-alias</b>	Displays device alias information.

# device-alias commit

To apply the pending configuration pertaining to the Distributed Device Alias Services (device alias) Cisco Fabric Services (CFS) distribution session in progress in the fabric, use the **device-alias commit** command in configuration mode.

## device-alias commit

### Syntax Description

This command has no other arguments or keywords.

### Command Default

None.

### Command Modes

Configuration mode.

### Command History

Release	Modification
2.0(x)	This command was introduced.

### Usage Guidelines

None



#### Note

Once the **device-alias commit** is done the running configuration has been modified on all switches participating in device-alias distribution. You can then use the **copy running-config startup-config fabric** command to save the running-config to the startup-config on all the switches in the fabric.



#### Note

When the **device-alias commit** is in progress, you must not issue the **clear device-alias** command, until the device-alias commit is successful.

### Examples

The following example shows how to commit pending changes to the active DPVM database:

```
switch# config terminal
switch(config)# device-alias commit
```

### Related Commands

Command	Description
<b>device-alias database</b>	Configures and activates the device alias database.
<b>device-alias distribute</b>	Enables CFS distribution for device aliases.
<b>show device-alias</b>	Displays device alias information.

# device-alias commit force

Forcefully save the pending configuration changes pertaining to the Distributed Device Alias Services (device alias) Cisco Fabric Services (CFS) distribution session in progress in the fabric, use the **device-alias commit** command in configuration mode.

**device-alias commit force**

**Syntax Description** This command has no other arguments or keywords.

**Command Default** None.

**Command Modes** Configuration mode.

Command History	Release	Modification
	9.3(1)	This command was introduced.

**Usage Guidelines** None



**Note** When the **device-alias commit force** is in progress, you must not issue the **clear device-alias** command, until the device-alias commit is successful.

## Examples

The following example shows how to commit pending changes to the active DPVM database:

```
switch# config terminal
switch(config)# device-alias commit force
```

Related Commands	Command	Description
	<b>device-alias commit</b>	Commits changes to the temporary device alias database to the active device alias database.
	<b>device-alias database</b>	Configures and activates the device alias database.
	<b>device-alias distribute</b>	Enables CFS distribution for device aliases.
	<b>show device-alias</b>	Displays device alias information.

# device-alias confirm-commit enable

To enable the display of the device-alias pending-diff and subsequent confirmation of pending-diff on issuing a device-alias commit, use the **device-alias confirm-commit enable** command in configuration mode. To disable this feature command, use the **no** form of this command.

**device-alias confirm-commit enable**  
**no device-alias confirm-commit enable**

<b>Syntax Description</b>	This command has no other arguments or keywords.
---------------------------	--

<b>Command Default</b>	Disabled.
------------------------	-----------

<b>Command Modes</b>	Configuration mode.
----------------------	---------------------

Command History	Release	Modification
	6.2(9)	This command was introduced.

<b>Usage Guidelines</b>	If the <b>device-alias confirm-commit</b> command is enabled, on committing the pending database, the pending-diff is displayed on the console and the user is prompted for Yes or No. If the <b>device-alias confirm-commit</b> command is disabled, the pending-diff is not displayed and the user is not prompted for Yes or No.
-------------------------	---



<b>Note</b>	If this feature is enabled, downgrade is blocked by a configuration check. To resume downgrade correctly, confirm-commit has to be disabled.
-------------	--

## Examples

The following example shows how to enable the confirm-commit mode for device-alias:

```
switch# config terminal
switch(config)# device-alias confirm-commit enable
switch(config)#
```

The following example shows how to disable the confirm-commit mode for device-alias:

```
switch# config terminal
switch(config)# no device-alias confirm-commit enable
switch(config)#
```

# device-alias database

To initiate a Distributed Device Alias Services (device alias) session and configure device alias database, use the **device-alias database** command.

## device-alias database

**Syntax Description** This command has no other arguments or keywords.

**Command Default** Deactivated.

**Command Modes** Configuration mode.

Command History	Release	Modification
	2.0(x)	This command was introduced.

**Usage Guidelines** The **device-alias database** command starts a device alias session that locks all the databases on all the switches in this fabrics. When you exit device alias database configuration submode, the device alias session ends and the locks are released.

You can only perform all modifications in the temporary device alias database. To make the changes permanent, use the **device-alias commit** command.

## Examples

The following example shows how to activate a device alias session and enter device alias database configuration submode:

```
switch# config terminal
switch(config)# device-alias database
switch(config-device-alias-db)#
```

Related Commands	Command	Description
	<b>device-alias commit</b>	Commits changes to the temporary device alias database to the active device alias database.
	<b>show device-alias</b>	Displays device alias database information.

# device-alias distribute

To enable Cisco Fabric Services (CFS) distribution for Distributed Device Alias Services (device alias), use the **device-alias distribute** command. To disable this feature, use the **no** form of the command.

**device-alias distribute**  
**no device-alias distribute**

<b>Syntax Description</b>	This command has no other arguments or keywords.
---------------------------	--

<b>Command Default</b>	Enabled.
------------------------	----------

<b>Command Modes</b>	Configuration mode.
----------------------	---------------------

Command History	Release	Modification
	2.0(x)	This command was introduced.

<b>Usage Guidelines</b>	Use the <b>device-alias commit</b> command to apply pending changes to the CFS distribution session.
-------------------------	--

<b>Examples</b>	The following example shows how to enable distribution for device alias information:
-----------------	--

```
switch# config terminal
switch(config)# device-alias distribute
```

Related Commands	Command	Description
	<b>device-alias commit</b>	Commits changes to the active device alias database.
	<b>device-alias database</b>	Configures and activates the device alias database.
	<b>show device-alias</b>	Displays device alias information.

# device-alias import fcalias

To import device alias database information from another VSAN, use the **device-alias import fcalias** command. To revert to the default configuration or factory defaults, use the **no** form of the command.

**device-alias import fcalias vsan** *vsan-id*  
**no device-alias import fcalias vsan** *vsan-id*

## Syntax Description

<b>vsan</b> <i>vsan-id</i>	Specifies the VSAN ID. The range is 1 to 4093.
-------------------------------	--

## Command Default

None.

## Command Modes

Configuration mode.

## Command History

Release	Modification
2.0(x)	This command was introduced.

## Usage Guidelines

You can import legacy device name configurations using this feature without losing data, if they satisfy the following restrictions:

- Each fcalias has only one member.
- The member type is supported by the device name implementation.

If any name conflict exists, the fcalias are not imported. The device name database is completely independent from the VSAN dependent fcalias database.

When the import operation is complete, the modified global fcalias table can distributed to all other switches in the physical fabric using the **device-alias distribute** command so that new definitions are available everywhere.

## Examples

The following example shows how to import device alias information:

```
switch# config terminal
switch(config)# device-alias import fcalias vsan 10
```

## Related Commands

Command	Description
<b>device-alias database</b>	Configures and activates the device alias database.
<b>device-alias distribute</b>	Distributes fcalias database changes to the fabric.
<b>show device-alias</b>	Displays device alias database information.



# device-alias mode enhanced

To configure device aliases to operate in enhanced mode, use the `device-alias mode enhanced` command. To disable this feature and return to the default mode, use the **no** form of the command.

**device-alias mode enhanced**  
**no device-alias mode enhanced**

## Syntax Description

This command has no arguments or keywords.

## Command Default

Prior to Cisco MDS NX-OS Release 8.5(1), the default device alias mode was basic mode.  
 From Cisco MDS NX-OS Release 8.5(1), the default device alias mode is enhanced mode.

## Command Modes

Configuration mode.

## Command History

Release	Modification
8.5(1)	The default device alias mode was changed to enhanced mode.
3.1(1)	This command was introduced.

## Usage Guidelines

When a device alias is configured in basic mode, all the applications operate like 3.0 switches. For example, when you attempt to configure the device aliases, immediately the device alias are expanded to a PWWN. This operation continues until the mode is changed to enhanced.

When a device alias is configured in enhanced mode, all the applications accept a device alias name in its native format, instead of expanding the device alias to a PWWN, the device alias name is stored in the configuration and distributed in its native device alias format.

To use enhanced mode, all switches in the fabric must be running in the Cisco SAN-OS Release 3.1(1) or later, or NX-OS 4.1(1b) later.



### Note

Enhanced mode, or native device alias based configurations are not accepted in interop mode. VSANs. IVR zoneset activation will fail in interop mode VSANs if the corresponding zones have native device alias-based members

## Examples

The following example shows how to configure the device alias in enhanced mode:

```
switch# config terminal
switch(config)# device-alias mode enhanced
switch(config)#
```

## Related Commands

Command	Description
<b>device-alias commit</b>	Commits changes to the active device alias database.
<b>device-alias database</b>	Configures and activates the device alias database.

Command	Description
<b>show device-alias</b>	Displays device alias information.

# debug ldap

To configure debugging for LDAP, use the **debug ldap** command. To disable this feature, use the **no** form of the command.

**debug ldap** {aaa-request | aaa-request-lowlevel | all | config | config-lowlevel}  
**no debug ldap** {aaa-request | aaa-request-lowlevel | all | config | config-lowlevel}

## Syntax Description

<b>aaa-request</b>	Enables LDAP AAA request debug.
<b>aaa-request-lowlevel</b>	Enables LDAP AAA request low level debugging.
<b>config</b>	Enables LDAP configuration debugging.
<b>config-lowlevel</b>	Enables LDAP configuring low level debugging.
<b>all</b>	Enables all the debug flags.

## Command Default

None.

## Command Modes

EXEC mode.

## Command History

Release	Modification
NX-OS 5.0(1a)	This command was introduced.

## Usage Guidelines

None.

## Examples

The following example shows how to configure LDAP AAA request debug:

```
switch# debug ldap aaa-request  
switch#
```

The following example shows how to configure LDAP AAA request low level debugging:

```
switch# debug ldap aaa-request-lowlevel  
switch#
```

## Related Commands

Command	Description
<b>show debug</b>	Displays all Cisco SME related debug commands configured on the switch.

# device-alias name

To configure device names in the device alias database, use the **device-alias name** command. To remove device names from the device alias database, use the **no** form of the command.

**device-alias name** *device-name* **pwwn** *pwwn-id*

**no device-alias name** *device-name*

## Syntax Description

<i>device-name</i>	Specifies the device name. Maximum length is 64 characters in Cisco MDS NX-OS Release 9.2(1) or later and 63 characters in Cisco MDS NX-OS Release 9.2(2) or later.
<b>pwwn</b> <i>pwwn-id</i>	Specifies the pWWN ID. The format is <i>hh:hh:hh:hh:hh:hh:hh:hh</i> , where <i>h</i> is a hexadecimal number.

## Command Default

None.

## Command Modes

Device alias database configuration submenu.

## Command History

Release	Modification
9.2(2)	The maximum device-name length supported was changed to 63 characters.
2.0(x)	This command was introduced.

## Usage Guidelines

None.

## Examples

The following example shows how to configure a device name alias entry in the device name database:

```
switch# config terminal
switch(config)# device-alias database
switch(config-device-alias-db)# device-alias name Device1 pwwn 21:00:00:20:37:6f:db:bb
```

## Related Commands

Command	Description
<b>device-alias database</b>	Enters device alias database configuration submenu.
<b>show device-alias</b>	Displays device alias database information.

# diagnostic bootup level

To configure the bootup diagnostic level to trigger diagnostics when the device boots, use the **diagnostic bootup level** command. To remove this diagnostic bootup level, use the **no** form of the command.

```
{diagnostic bootup level bypass | complete}  
{no diagnostic bootup level bypass | complete}
```

## Syntax Description

<b>bypass</b>	Specifies the skip all bootup test. Do not perform any bootup diagnostics.
<b>complete</b>	Specifies all bootup diagnostics. The default is complete.

## Command Default

None.

## Command Modes

Configuration mode.

## Command History

Release	Modification
6.2(1)	This command was introduced.

## Usage Guidelines

None.

## Examples

The following example shows how to configure all bootup diagnostics level:

```
switch# config terminal  
switch(config)# diagnostic bootup level complete  
switch(config)#
```

## Related Commands

Command	Description
<b>show diagnostic bootup level</b>	Displays the bootup diagnostic level (bypass or complete) that is currently in place on the device.
<b>show diagnostic events</b>	Displays diagnostic events by error and information event type.

# diagnostic isl latency-test

To configure a generator switch to start and display the results for a latency test, use the **diagnostic isl latency-test interface fc slot/port** command.

**diagnostic isl latency-test interface fc slot/port**

## Syntax Description

<b>interface fc slot/port</b>	Fibre Channel port.
-------------------------------	---------------------

## Command Default

None

## Command Modes

User EXEC (#)  
Privileged EXEC (#)

## Command History

Release	Modification
7.3(0)D1(1)	This command was introduced.

## Examples

This example displays how to start and display results for the latency test on the interface fc4/9:

```
switch# diagnostic isl latency-test interface fc4/9
waiting for link to be in sync ...
-----
Latency test Result for port: fc4/9
Latency in the switch(In nano-seconds):396
Latency in the cable(In nano-seconds):36
Length of the cable approximately (+/-2m):2 metres
```

## Related Commands

Command	Description
<b>diagnostic isl multi_hop generator</b>	Configures an interface on a generator switch to run the Multihop Traffic Test for a given VSAN, destination domain (domain ID of the reflector switch), frame count, link speed, and frame size parameters.
<b>diagnostic isl multi_hop reflector</b>	Enables or disables a test interface on a reflector switch by setting it to loopback mode for a given VSAN and domain ID of a generator switch for Multihop Traffic Test.
<b>diagnostic isl show status</b>	Displays the status of configured Inter-Switch Link (ISL) diagnostic tests per port.

## diagnostic isl multi\_hop generator

To configure an interface on a generator switch to run the Multihop Traffic Test for a given VSAN, destination domain (domain ID of the reflector switch), frame count, link speed, and frame size parameters, use the **diagnostic isl multi\_hop generator** command.

```
diagnostic isl multi_hop generator interface fc slot/port { start { vsan vsan-id
dest_domain destination-id { duration seconds | frame-count number } [ rate divider-line-rate
] [ frame_size min size max size step size ] | stop }
```

### Syntax Description

<b>interface fc slot/port</b>	Fibre Channel port.
<b>start</b>	Specifies to start traffic generation.
<b>vsan id</b>	Specifies entries based on a VSAN ID. Range is from 1–4096.
<b>dest_domain destination-id</b>	Domain ID of a reflector switch. Range is from 0–255.
<b>duration seconds</b>	Duration of the traffic test.
<b>frame_count number</b>	Frame count to transmit. Range is 1–2000000000.
<b>rate divider-line-rate</b>	Specifies a speed value to generate traffic.
<b>frame_size</b>	Specifies packet size range for traffic generation.
<b>min size</b>	Minimum packet size for packet generation. Range is 16–517.
<b>max size</b>	Maximum packet size for packet generation. Range is 16–517.
<b>step size</b>	Step size, in the range between minimum and maximum frame size, for traffic generation. Range is 1–100.
<b>stop</b>	Specifies to stop traffic generation.

### Command Default

None

### Command Modes

User EXEC (#)  
Privileged EXEC (#)

### Command History

Release	Modification
7.3(0)D1(1)	This command was introduced.
8.4(1)	The command syntax was changed.

### Examples

This example displays how to start traffic generation on the interface fc4/11 of a generator switch for a duration of 5 seconds:

```
switch# diagnostic isl multi_hop generator interface fc4/11 start vsan 1 dest_domain 36
duration 5
```

This example displays how to stop traffic generation on the interface fc4/11 of a generator switch:

```
switch# diagnostic isl multi_hop generator interface fc4/11 vsan 1 dest_domain 36 stop
```

```
Generator is stopped. Clean-up in progress.
Please wait....
```

```
-----
Traffic test Result for port: fc4/11
Packets Transmitted:111734
Packets Recieved in ISL :111734
ISL traffic Efficiency(in percentage):100.000000
-----
```

## Related Commands

Command	Description
<b>diagnostic isl multi_hop reflector</b>	Enables or disables a test interface on a reflector switch by setting it to loopback mode for a given VSAN and domain ID of a generator switch for Multihop Traffic Test.
<b>diagnostic isl show status</b>	Displays the status of configured Inter-Switch Link (ISL) diagnostic tests per port.



## diagnostic isl multi\_hop reflector

To enable or disable a test interface on a reflector switch by setting it to loopback mode for a given VSAN and domain ID of a generator switch for Multihop Traffic Test, use the **diagnostic isl multi\_hop reflector** command.

```
diagnostic isl multi_hop reflector loop-back interface fc slot/port { enable { vsan  
vsan-id source_domain source-domain-id } | disable }
```

### Syntax Description

<b>loop-back</b>	Specifies loopback.
<b>interface fc slot/port</b>	Fibre Channel port.
<b>enable</b>	Enable loopback.
<b>vsan vsan-id</b>	Specifies entries based on a VSAN ID. Range is from 1 to 4096.
<b>source_domain source-domain-id</b>	Source ID of a generator switch. Range is from 0 to 255.
<b>disable</b>	Disable loopback.

### Command Default

Loopback for an interface is disabled by default.

### Command Modes

User EXEC (#)  
Privileged EXEC (#)

### Command History

Release	Modification
7.3(0)D1(1)	This command was introduced.
8.4(1)	The command syntax was changed.

### Examples

This example displays how to enable Multihop Traffic Test on the interface fc1/39 of a reflector switch:

```
switch# diagnostic isl multi_hop reflector loop-back interface fc1/39 enable vsan 1  
source_domain 2
```

This example displays how to disable Multihop Traffic Test on the interface fc1/39 of a reflector switch:

```
switch# diagnostic isl multi_hop reflector loop-back interface fc1/39 vsan 1 source_domain  
2 disable
```

**Related Commands**

Command	Description
<b>diagnostic isl multi_hop generator</b>	Configures an interface on a generator switch to run the Multihop Traffic Test for a given VSAN, destination domain (domain ID of the reflector switch), frame count, link speed, and frame size parameters.
<b>diagnostic isl show status</b>	Displays the status of configured Inter-Switch Link (ISL) diagnostic tests per port.

# diagnostic isl show status

To display the status of configured Inter-Switch Link (ISL) diagnostic tests per port, use the **diagnostic isl show status** command.

**diagnostic isl show status** *index start index num number*

## Syntax Description

<b>index</b>	Index of the ISL diagnostic port status.
<b>start index</b>	Index number of the ISL diagnostic port status.
<b>num number</b>	Number of entries of the ISL diagnostic port status array.

## Command Default

None

## Command Modes

User EXEC (#)  
Privileged EXEC (#)

## Command History

Release	Modification
7.3(0)D1(1)	This command was introduced.

## Examples

This example displays the ISL diagnostic tests for the port fc2/2:

```
switch# diagnostic isl show status index start 1 num 1
Status of isl_daig tests in progress:
-----
Index  Interface      Mode <Gen/Ref>      Test
-----
1      fc2/2              Generator           MH Traffic Test
-----
```

## Related Commands

Command	Description
<b>diagnostic isl multi_hop generator</b>	Configures an interface on a generator switch to run the Multihop Traffic Test for a given VSAN.
<b>diagnostic isl multi_hop reflector</b>	Enables or disables a test interface on a reflector switch by setting it to loopback mode for a given VSAN and domain ID of the generator switch for Multihop Traffic Test.

# diagnostic monitor interval module

To configure diagnostic monitoring tests interval for a module, use the **diagnostic monitor interval module** command. To remove this diagnostic monitor interval module, use the **no** form of the command.

**diagnostic monitor interval module** *module-number* **test** [*test-id* | **name** | **all**] **hour** *hour* **min** *minutes* **second** *sec*

**no diagnostic monitor interval module** *module-number* **test** [*test-id* | **name** | **all**] **hour** *hour* **min** *minutes* **second** *sec*

## Syntax Description

<i>module-number</i>	Specifies the module number. The range is from 1 to 10.
<b>test</b>	Specifies the diagnostic test selection.
<i>test-id</i>	Specifies test IDs. The range is from 1 to 10.
<b>name</b>	Specifies the test name. Can be any case-sensitive alphanumeric string up to 32 characters.
<b>all</b>	Specifies all test ID.
<b>hour</b>	Specifies hour of the day.
<i>hour</i>	Specifies interval in hours. The range is from 0 to 23.
<b>min</b>	Specifies minute of an hour.
<i>minutes</i>	Specifies interval in minutes. The range is from 0 to 59.
<b>second</b>	Specifies second of a minute.
<i>sec</i>	Specifies interval in seconds. The range is from 0 to 59.

## Command Default

None.

## Command Modes

Configuration mode.

## Command History

Release	Modification
6.2(1)	This command was introduced.

## Usage Guidelines

None.

## Examples

The following example shows how to configure diagnostic monitoring tests interval for a module:

```
switch# config terminal
switch(config)# diagnostic monitor interval module 6 test 3 hour 1 min 0 sec 0
switch(config)#
```

**Related Commands**

Command	Description
<b>diagnostic monitor module</b>	Activates the specified test.
<b>show diagnostic content module</b>	Displays information about the diagnostics and their attributes.

# diagnostic monitor module

To configure diagnostic monitoring tests for a module, use the **diagnostic monitor module** command. To remove this diagnostic monitor module, use the **no** form of the command.

**diagnostic monitor module** *module-number* **test** [*test-id* | **name** | **all**]  
**no diagnostic monitor module** *module-number* **test** [*test-id* | **name** | **all**]

## Syntax Description

<i>module-number</i>	Specifies the module number. The range is from 1 to 10.
<b>test</b>	Specifies the diagnostic test selection.
<i>test-id</i>	Specifies test IDs. The range is from 1 to 10.
<b>name</b>	Specifies the test name. Can be any case-sensitive alphanumeric string up to 32 characters.
<b>all</b>	Specifies all test ID.

## Command Default

None.

## Command Modes

Configuration mode.

## Command History

Release	Modification
6.2(1)	This command was introduced.

## Usage Guidelines

None.

## Examples

The following example shows how to configure diagnostic monitoring tests for a module:

```
switch# config terminal
switch(config)# diagnostic monitor module 6 test 3
switch(config)#
```

## Related Commands

Command	Description
<b>diagnostic monitor interval module</b>	Configures the interval at which the specified test is run.
<b>show diagnostic content module</b>	Displays information about the diagnostics and their attributes.

# diagnostic ondemand iteration

To configure the number of times that the on demand test runs, use the **diagnostic ondemand iteration** command. To remove this diagnostic ondemand iteration, use the **no** form of the command.

**diagnostic ondemand iteration** *number*  
**no diagnostic ondemand iteration** *number*

## Syntax Description

<i>number</i>	Specifies number of times to repeat ondemand test list. The range is from 1 to 999.
---------------	---

## Command Default

1.

## Command Modes

Configuration mode.

## Command History

Release	Modification
6.2(1)	This command was introduced.

## Usage Guidelines

None.

## Examples

The following example shows how to configure the number of times that the on demand test runs:

```
switch# diagnostic ondemand iteration 4
switch(config)#
```

## Related Commands

Command	Description
<b>diagnostic ondemand action-on-failure</b>	Configures the action to take if the on-demand test fails.
<b>show diagnostic ondemand setting</b>	Displays information about on-demand diagnostics.

# diagnostic ondemand action-on-failure

To configure the action to take if the on demand test fails, use the **diagnostic ondemand action-on-failure** command. To remove this feature command, use the **no** form of the command.

**diagnostic ondemand action-on-failure** {**continue failure-count** *num-fails* | **stop**}  
**no diagnostic ondemand action-on-failure** {**continue failure-count** *num-fails* | **stop**}

## Syntax Description

<b>continue</b>	Specifies the continue ondemand test until test failure limit is reached.
<b>failure-count</b>	Specifies the continue failing tests these many times.
<i>num-fails</i>	The num-fails range is from 1 to 999.
<b>stop</b>	Stop ondemand tests immediately if a test fails.

## Command Default

1.

## Command Modes

Configuration mode.

## Command History

Release	Modification
6.2(1)	This command was introduced.

## Usage Guidelines

None.

## Examples

The following example shows how to configure the action to take if the on demand test fails:

```
switch# diagnostic ondemand action-on-failure stop
switch#
```

## Related Commands

Command	Description
<b>diagnostic ondemand iteration</b>	Configures the number of times that the on-demand test runs.
<b>show diagnostic ondemand setting</b>	Displays information about on-demand diagnostics.



# diagnostic start interface fc test link-dia

To run link diagnostics tests on the diagnostic port to check the connectivity between servers and storage area networks (SANs), use the **diagnostic start interface fc test link-dia** command.

```
diagnostic start interface fc slot/port test link-dia [duration seconds | frame-count count]
[frame-size min min_bytes max max_bytes step step_size] [gen-interface fc slot/port] [level {remote
levels | remote-all}] [payload {random | fixed fixed_payload}] [rate line_rate]
```

Syntax Description		
	<i>slot/port</i>	Slot and the port numbers of the Fibre Channel interface.
	<b>duration</b> <i>seconds</i>	Specifies the duration of the link diagnostics tests per level. The range is from 1-86400.
	<b>frame-count</b> <i>count</i>	Generates frames required to conduct the traffic tests. The range is from 1-2147483646. The default is 1000000.
	<b>frame-size</b> <b>min</b> <i>min_bytes</i>	Configures the minimum frame size for the traffic generated. The value of <b>frame-size min</b> must be a multiple of four. The range is from 64-2048. The default is 2048.
	<b>frame-size</b> <b>max</b> <i>max_bytes</i>	Configures the maximum frame size for the traffic generated. The value of <b>frame-size max</b> must be a multiple of four. The range is from 64-2048. The default is 2048.
	<b>step</b> <i>step_size</i>	Configures the step size for the traffic generated. The range is from 4-100. The default is 4. The value of <i>step_size</i> must be a multiple of four. The <i>step_size</i> value is ignored if the values of <i>min_bytes</i> and <i>max_bytes</i> are the same.
	<b>gen-interface</b> <b>fc</b>	Configures the Fibre Channel generator port. The generator port cannot be the same as the diagnostic port.
	<b>level</b>	Specifies the level of the diagnostics tests to be conducted.
	<b>remote</b> <i>levels</i>	Runs the selected level of the diagnostics test on the diagnostic port. You can select any one of the following levels at a time: <ul style="list-style-type: none"> <li>• <b>elec</b>—Electrical</li> </ul> <p><b>Note</b> When <b>elec</b> level is selected, the <b>frame-count</b> <i>count</i> value is fixed at 20000.</p> <ul style="list-style-type: none"> <li>• <b>mac</b>—MAC</li> <li>• <b>xcvr-optical</b>—Optical</li> </ul>
	<b>remote-all</b>	Runs all the supported levels of the link diagnostics tests on the diagnostic port. <p><b>Note</b> Even though the peer supports remote switched loopback, if <b>remote-all</b> is selected while running link diagnostics tests, remote switched loopback will be ignored.</p>

<b>payload</b>	Configures the payload for the traffic generated.
<b>random</b>	Configures a random payload pattern.
<b>fixed</b> <i>fixed_payload</i>	Configures a fixed payload pattern. The range is from 0x0-0xf.
<b>rate</b> <i>line_rate</i>	<p>Configures the rate of the traffic generation of the generator port. You can select any one of the following line rates at one time:</p> <ul style="list-style-type: none"> <li>• 100%—100% of the line rate</li> <li>• 12.5%—12.5% of the line rate</li> <li>• 25%—25% of the line rate</li> <li>• 50%—50% of the line rate</li> <li>• 6.25%—6.25% of the line rate</li> </ul> <p>The default is 50%.</p>

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Privileged EXEC mode
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	8.2(1)	This command was introduced.

## Usage Guidelines

### Running Link Diagnostics Tests on a Port

The following example shows how to run link diagnostic tests on a port for a duration of 7200 seconds:

```
switch# diagnostic start interface fc 1/1 test link-diag duration 7200
```

The following example shows how to run link diagnostic tests on a port for 1000030 frames generated:

```
switch# diagnostic start interface fc 1/1 test link-diag frame-count 1000030
```

The following example shows how to run link diagnostic tests on a port with a minimum frame size of 64, maximum frame size of 2044, and a step size of 8:

```
switch# diagnostic start interface fc 1/23 test link-diag frame-size min 64 max 2044 step 8
```

The following example shows how to run link diagnostic tests on a port with a user-specified generator port:

```
switch# diagnostic start interface fc 1/23 test link-diag gen-interface fc 1/3
```

The following example shows how to run all traffic tests available on a port:

```
switch# diagnostic start interface fc 1/23 test link-diag level remote-all
```

The following example shows how to run the Optical level tests on a port:

```
switch# diagnostic start interface fc 1/23 test link-diag level remote xcvr-optical
```

The following example shows how to run link diagnostics tests on a port with a fixed payload pattern:

```
switch# diagnostic start interface fc 1/23 test link-diag level payload fixed 0xe
```

The following example shows how to run link diagnostics tests on a port along with a configured speed of traffic generation:

```
switch# diagnostic start interface fc 1/23 test link-diag rate 12.5%
```

#### Related Commands

Command	Description
<b>diagnostic result interface fc test link-diag</b>	Displays the results of the link diagnostics tests that are performed on a diagnostic port.
<b>diagnostic stop interface fc test link-diag</b>	Stops the link diagnostics tests that are running on a diagnostic port.
<b>switchport link-diag</b>	Enables the link diagnostic mode on a diagnostic port.
<b>show diagnostic test link-diag status</b>	Checks the status of the link diagnostics tests that are running on the switch.

# diagnostic start module

To start one or more diagnostic tests on a module, use the **diagnostic start module** command. To remove this feature command, use the **no** form of the command.

**diagnostic start module** *module-number* **test** [*test-id* | **name** | **all** | **non-disruptive**] [**port** *port-number* | **all**]

**no diagnostic start module** *module-number* **test** [*test-id* | **name** | **all** | **non-disruptive**] [**port** *port-number* | **all**]

## Syntax Description

<i>module-number</i>	Specifies the module number. The range is from 1 to 10.
<b>test</b>	Specifies the diagnostic test selection.
<i>test-id</i>	Specifies test IDs. The range is from 1 to 10.
<b>name</b>	Specifies the test name. Can be any case-sensitive alphanumeric string up to 32 characters.
<b>all</b>	Specifies all test ID.
<b>non-disruptive</b>	Specifies non disruptive diagnostics.
<b>port</b>	Specifies the port.
<i>port-number</i>	Specifies the port number. The port range is from 1 to 48.

## Command Default

1.

## Command Modes

Configuration mode.

## Command History

Release	Modification
6.2(1)	This command was introduced.

## Usage Guidelines

None.

## Examples

The following example shows how to start one or more diagnostic tests on a module:

```
switch# diagnostic start module 6 test all
switch#
switch#
```

## Related Commands

Command	Description
<b>diagnostic run module</b>	Starts the selected test on a module and displays the result on the completion of the test.
<b>diagnostic stop module</b>	Stops one or more diagnostic tests on a module.

# diagnostic stop interface fc test link-diag

To stop the link diagnostics tests that are running on the diagnostic port, use the **diagnostic stop interface fc test link-diag** command.

**diagnostic stop interface fc** *slot/port* **test link-diag**

<b>Syntax Description</b>	<i>slot/port</i> Slot and the port numbers of the Fibre Channel interface.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Privileged EXEC mode
----------------------	----------------------

<b>Command History</b>	<b>Release</b> <b>Modification</b>
	8.2(1) This command was introduced.

## Usage Guidelines

### Running Link Diagnostics Tests on a Port

The following example shows how to stop link diagnostic tests on a specified port:

```
switch# diagnostic stop interface fc 1/1 test link-diag
```

Related Commands	Command	Description
	<b>switchport link-diag</b>	Enables the link diagnostic mode on a diagnostic port.
	<b>diagnostic result interface fc test link-diag</b>	Displays the results of the link diagnostics tests that are performed on a diagnostic port.
	<b>diagnostic start interface fc test link-diag</b>	Runs link diagnostics tests on a diagnostic port .
	<b>show diagnostic test link-diag status</b>	Checks the status of the link diagnostics tests that are running on the switch.

# diagnostic stop module

To stop one or more diagnostic tests on a module, use the **diagnostic stop module** command. To remove this feature command, use the **no** form of the command.

**diagnostic stop module slot test** [**test-id** | **name** | **all**]

**no diagnostic stop module slot test** [**test-id** | **name** | **all**]

## Syntax Description

<i>module-number</i>	Specifies the module number. The range is from 1 to 10.
<b>test</b>	Specifies the diagnostic test selection.
<i>test-id</i>	Specifies test IDs. The range is from 1 to 10.
<b>name</b>	Specifies the test name. Can be any case-sensitive alphanumeric string up to 32 characters.
<b>all</b>	Specifies all test ID.

## Command Default

1.

## Command Modes

Configuration mode.

## Command History

Release	Modification
6.2(1)	This command was introduced.

## Usage Guidelines

None.

## Examples

The following example shows how to stop one or more diagnostic tests on a module:

```
switch# diagnostic stop module 6 test all
switch#
switch#
```

## Related Commands

Command	Description
<b>diagnostic run module</b>	Starts the selected test on a module and displays the result on the completion of the test.
<b>diagnostic start module</b>	Starts one or more diagnostic tests on a module.

# dir

To display the contents of the current directory or the specified directory, use the **dir** command in EXEC mode.

**dir** [ **bootflash** : *module directory-or-filename* | **debug** : *directory-or-filename* | **log** : *module directory-or-filename* | **modflash** : *module directory-or-filename* | **slot0** : *directory-or-filename* | **volatile** : *module directory-or-filename* ]

## Syntax Description

<b>bootflash:</b>	(Optional) Flash image that resides on the supervisor module.
<b>debug:</b>	(Optional) Provides information about the debug capture directory.
<b>log:</b>	(Optional) Provides information about the two default log files. The file dmesg contains the kernel log messages and the file messages contains the system application log messages.
<b>modflash:</b>	(Optional) Provides information about the flash image that resides in a module flash file directory.
<b>slot0:</b>	(Optional) Flash image that resides on another module.
<i>module</i>	(Optional) Module name and number.
<i>directory-or-filename</i>	(Optional) Name of the file or directory to display on a specified device. The files can be of any type. You can use wildcards in the filename. A wildcard character (*) matches all patterns. Strings after a wildcard are ignored.
<b>volatile:</b>	(Optional) Flash image on the volatile file system.

## Command Default

The default file system is specified by the **cd** command.

## Command Modes

EXEC mode.

## Command History

Release	Modification
1.2(1)	This command was introduced.
2.1(1a)	Added debug, log, and modflash keywords.

## Usage Guidelines

None.

## Examples

The following example shows how to list the files on the bootflash directory:

```
switch# dir bootflash:
40295206   Aug 05 15:23:51 1980   ilc1.bin
12456448   Jul 30 23:05:28 1980   kickstart-image1
12288      Jun 23 14:58:44 1980   lost+found/
27602159   Jul 30 23:05:16 1980   system-image1
```

```

12447232      Aug 05 15:08:30 1980  kickstart-image2
28364853      Aug 05 15:11:57 1980  system-image2
Usage for bootflash://sup-local
  135404544 bytes used
   49155072 bytes free
  184559616 bytes total

```

The following example shows how to list the files in the debug directory:

```

switch# dir debug:
Usage for debug://sup-local
  0 bytes used
 2097152 bytes free
 2097152 bytes total
switch#
switch# dir ?
 bootflash:  Directory or filename
 debug:      Directory or filename
 log:        Directory or filename
 modflash:   Directory or filename
 slot0:      Directory or filename
 volatile:   Directory or filename
 <cr>        Carriage Return

```

The following example shows how to list the files in the log file directory:

```

switch# dir log:
   31      Feb 05 05:00:57 2005  dmesg
 8445      Feb 06 10:34:35 2005  messages
Usage for log://sup-local
 35196928 bytes used
174518272 bytes free
209715200 bytes total
switch#

```

## Related Commands

Command	Description
<b>cd</b>	Changes the default directory or file system.
<b>delete</b>	Deletes a file on a flash memory device.



# disable

To disable the Call Home function, use the **disable** command in Call Home configuration submode.

**disable**

## Syntax Description

This command has no other arguments or keywords.

## Command Default

None.

## Command Modes

Call Home configuration submode.

## Command History

Release	Modification
1.0(2)	This command was introduced.

## Usage Guidelines

To enable the Call Home function, use the **enable** command.

## Examples

The following example shows how to disable the Call Home function:

```
switch# config terminal  
Enter configuration commands, one per line. End with CNTL/Z.  
switch(config)# callhome  
switch(config-callhome)# disable
```

## Related Commands

Command	Description
<b>callhome</b>	Configures the Call Home function.
<b>callhome test</b>	Sends a dummy test message to the configured destination(s).
<b>show callhome</b>	Displays configured Call Home information.

# discover

To initiate the discovery of hosts, use the **discover** command. To disable this feature, use the **no** form of the command.

**discover** **host** *host port* **target** *target port* **vsan** *vsan id* **fabric** *fabric name*  
**no discover**

## Syntax Description

<b>host</b> <i>host port</i>	Identifies the host port WWN. The format is hh:hh:hh:hh:hh:hh:hh:hh.
<b>target</b> <i>target port</i>	Identifies the target port WWN. The format is hh:hh:hh:hh:hh:hh:hh:hh.
<b>vsan</b> <i>vsan id</i>	Selects the VSAN identifier. The range is 1 to 4093.
<b>fabric</b> <i>fabric name</i>	Specifies the fabric for discovery. The maximum length is 32 characters.

## Command Default

None.

## Command Modes

Cisco SME cluster configuration submode.

## Command History

Release	Modification
3.2(2)	This command was introduced.

## Usage Guidelines

None.

## Examples

The following example discovers a host and specifies a target, a VSAN, and a fabric for discovery:

```
switch# config t
switch(config)# sme cluster clusternam1
switch(config-sme-cl)# discover host 20:00:00:00:c9:49:28:47 target 21:01:00:e0:8b:29:7e:0c
vsan 2345 fabric sw-xyz
```

The following example disables the discovery feature:

```
switch# config t
switch(config)# sme cluster clusternam1
switch(config-sme-cl)# no discover
```

## Related Commands

Command	Description
<b>show sme cluster</b>	Displays information about the Cisco SME cluster.

# discover custom-list

To selectively initiate discovery for specified domain IDs in a VSAN, use the discover custom-list command in EXEC mode.

**discover custom-list** {add | delete} **vsan** *vsan-id* **fcid** *fc-id*

## Syntax Description

<b>add</b>	Add a targets to the customized list.
<b>delete</b>	Deletes a target from the customized list.
<b>vsan</b> <i>vsan-id</i>	Discovers SCSI targets for the specified VSAN ID. The range is 1 to 4093.
<b>fcid</b> <i>fc-id</i>	Discovers SCSI targets for the specified FCID. The format is <i>0xhhhhhhh</i> , where <i>h</i> is a hexadecimal digit.

## Command Default

None.

## Command Modes

EXEC mode.

## Command History

Release	Modification
1.1(1)	This command was introduced.

## Usage Guidelines

None.

## Examples

The following example selectively initiates discovery for the specified VSAN and FCID:

```
switch# discover custom-list add vsan 1 fcid 0X123456
```

The following example deletes the specified VSAN and FCID from the customized list:

```
switch# discover custom-list delete vsan 1 fcid 0X123456
```

# discover scsi-target

To discover SCSI targets on local storage to the switch or remote storage across the fabric, use the **discover scsi-target** command in EXEC mode.

**discover scsi-target** {**custom-list** | **local** | **remote** | **vsan** *vsan-id* **fcid** *fc-id*} **os** {**aix** | **all** | **hpux** | **linux** | **solaris** | **windows**} [**lun** | **target**]

## Syntax Description

<b>custom-list</b>	Discovers SCSI targets from the customized list.
<b>local</b>	Discovers local SCSI targets.
<b>remote</b>	Discovers remote SCSI targets.
<b>vsan</b> <i>vsan-id</i>	Discovers SCSI targets for the specified VSAN ID. The range is 1 to 4093.
<b>fcid</b> <i>fc-id</i>	Discovers SCSI targets for the specified FCID. The format is <i>0xhhhhhhh</i> , where <i>h</i> is a hexadecimal digit.
<b>os</b>	Discovers the specified operating system.
<b>aix</b>	Discovers the AIX operating system.
<b>all</b>	Discovers all operating systems.
<b>hpux</b>	Discovers the HP-UX operating system.
<b>linux</b>	Discovers the Linux operating system.
<b>solaris</b>	Discovers the Solaris operating system.
<b>windows</b>	Discovers the Windows operating system.
<b>lun</b>	(Optional) Discovers SCSI targets and LUNs.
<b>target</b>	(Optional) Discovers SCSI targets.

## Command Default

None.

## Command Modes

EXEC mode.

## Command History

Release	Modification
1.3(2a)	This command was introduced.

## Usage Guidelines

On-demand discovery only discovers Nx ports present in the name server database that have registered a FC4 Type = SCSI\_FCP.

---

## Examples

The following example shows how to discover local targets assigned to all OSs:

```
switch# discover scsi-target local os all  
discovery started
```

The following example shows how to discover remote targets assigned to the Windows OS:

```
switch# discover scsi-target remote os windows  
discovery started
```

The following example shows how to discover SCSI targets for the specified VSAN (1) and FCID (0x9c03d6):

```
switch# discover scsi-target vsan 1 fcid 0x9c03d6  
discover scsi-target vsan 1 fcid 0x9c03d6  
VSAN:      1 FCID: 0x9c03d6 PWWN: 00:00:00:00:00:00:00  
PRLI RSP: 0x01 SPARM: 0x0012...
```

The following example begins discovering targets from a customized list assigned to the Linux operating system:

```
switch# discover scsi-target custom-list os linux  
discovery started
```

# distribute

To enable distribution of the Call Home function using CFS, use the **distribute** command in Call Home configuration submode. To disable this feature, use the **no** form of the command.

**distribute**  
**no distribute**

**Syntax Description** This command has no other arguments or keywords.

**Command Default** None.

**Command Modes** Call Home configuration submode.

Command History	Release	Modification
	2.0(1b)	This command was introduced.

**Usage Guidelines** None.

**Examples** The following example shows how to enable distribution of the Call Home function using CFS:

```
switch# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# callhome
switch(config-callhome)# distribute
```

Related Commands	Command	Description
	<b>callhome</b>	Configures the Call Home function.
	<b>callhome test</b>	Sends a dummy test message to the configured destination(s).
	<b>show callhome</b>	Displays configured Call Home information.

# dmm module

To specify default DMM values for migration block size, number of migration blocks and fast migration speed, use the **dmm module** command in configuration mode.

**dmm module** *mod-id* **rate-of-migration** **fast** *migration-rate* **medium** *migration-rate* **slow** *migration-rate*

## Syntax Description

<i>mod-id</i>	Specifies the module ID.
<b>rate-of-migration</b>	Migration rate can be configured as slow, medium or fast.
<b>fast</b> <i>migration-rate</i>	Specifies the rate for fast migration. Units are megabytes per second (MB/s).
<b>medium</b> <i>migration-rate</i>	Specifies the rate for medium migration. Units are MB/s.
<b>slow</b> <i>migration-rate</i>	Specifies the rate for slow migration. Units are MB/s.

## Command Default

None.

## Command Modes

Configuration mode.

## Command History

Release	Modification
3.2(1)	This command was introduced.

## Usage Guidelines

None.

## Examples

The following example shows how to set the fast migration rate to 100 MB/s, the medium migration rate to 50 MB/s, and slow migration rate to 10 MB/s:

```
switch# config t
Enter configuration commands, one per line. End with CNTL/Z.
switch(config) dmm module 3 rate_of_migration fast 100 medium 50 slow 10
```

## Related Commands

Command	Description
<b>show dmm ip-peer</b>	Displays a DMM port's IP peer.
<b>show dmm job</b>	Displays job information.

## dmm module job

To configure a data migration job, use the **dmm module *mod-id* job** command in configuration mode.

**dmm module *mod-id* job *job-id* {create|destroy|finish|get-vi vsan *vsan-id*|modify rate|schedule {hour *hour* min *minute* day *day* month *month* year *year* | now | reset} | session | set-vi *portwwn* *nodewwn* vsan *vsan-id* | start | stop | validate | verify}**

### Syntax Description

<b>module</b> <i>mod-id</i>	Specifies the module ID.
<b>job</b> <i>job-id</i>	Specifies the job ID. The range is 0 to 18446744073709551615.
<b>create</b>	Creates the job and enters DMM job configuration submode.
<b>destroy</b>	Deletes the DMM job.
<b>finish</b>	Moves the Method 2 data migration job to completed state.
<b>get-vi</b>	Retrieves the virtual initiator (VI) for the DMM job.
<b>vsan</b> <i>vsan-id</i>	Specifies the VSAN ID. The range is 1 to 4093.
<b>modify</b>	Modifies the DMM job attributes.
<b>rate</b>	Specifies the rate of the job attribute. The range is from 1 to 4. Specify 1 for a default value, 2 for slow, 3 for medium and 4 for fast rates.
<b>schedule</b>	Schedules the DMM job.
<b>hour</b> <i>hour</i>	Specifies the hour the DMM job starts. The range is 0 to 23.
<b>min</b> <i>minute</i>	Specifies the minute the DMM job starts. The range is 0 to 59.
<b>day</b> <i>day</i>	Specifies the day the DMM job starts. The range is 1 to 31.
<b>month</b> <i>month</i>	Specifies the month the DMM job starts. The range is 1 to 12.
<b>year</b> <i>year</i>	Specifies the year the DMM job starts. The range is 2000 to 2030.
<b>now</b>	Resets the schedule to start the DMM job immediately.
<b>reset</b>	Resets the DMM job to unscheduled.
<b>session</b>	Enables the Session Configuration submode.
<b>set-vi</b>	Sets the VI for the storage based job.
<i>portwwn</i>	Specifies the port WWN. The format is <i>hh:hh:hh:hh:hh:hh:hh:hh</i> , where <i>h</i> is a hexadecimal number.
<i>nodewwn</i>	Specifies the node WWN. The format is <i>hh:hh:hh:hh:hh:hh:hh:hh</i> , where <i>h</i> is a hexadecimal number.



<b>vsan</b> <i>vsan-id</i>	Specifies the VSAN ID. The range is 1 to 4093.
<b>start</b>	Starts the DMM job session.
<b>stop</b>	Stops the DMM job.
<b>validate</b>	Validates the DMM job data.
<b>verify</b>	Verifies the data migration for the specified job.

**Command Default**

None.

**Command Modes**

Configuration mode.

**Command History**

Release	Modification
3.3(1a)	The <b>finish</b> keyword is introduced.
4.1(1b)	The set- <b>vi</b> and modify rate keywords were introduced.

**Usage Guidelines**

DMM must be enabled before you can create DMM jobs. Use the **ssm enable feature dmm** command to enable DMM.

The data migration job stops executing if it encounters any errors. To restart the migration, enter the **validate** command to validate the job configuration, then enter the **restart** command to restart the job.

Before creating a storage based data migration job, use the show dmm module vi-list command to choose the VI for migrating the data and then use the set-vi command to specify the VI.

When the job is in the failed state, you can restart the job using the start command. This command will start the job from point of last failure.

**Examples**

The following example shows how to restart the job in failed stated.

```
switch(config)# dmm module 3 job 4 start
switch#
```

The following example shows how to create a job with a schedule. The job is scheduled to start on Sunday, January 6, 2008 at 11:00 P.M.

```
switch# config t
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# dmm module 3 job 1 schedule hour 23 min 0 day 6 month 1 year 2008
```

Command	Description
<b>show dmm ip-peer</b>	Displays the IP peers that the DMM port is connected to.
<b>show dmm job</b>	Displays DMM job information.
<b>show dmm module vi-list</b>	Displays the list of VIs.

# do

Use the **do** command to execute an EXEC-level command from any configuration mode or submode.

**do** *command*

## Syntax Description

<i>command</i>	Specifies the EXEC command to be executed.
----------------	--

## Command Default

None.

## Command Modes

All configuration modes.

## Command History

Release	Modification
1.1(1)	This command was introduced.
NX-OS 4.1(1b)	Added the command output for extended bbcredit interface.
NX-OS 4.1(1b)	Added a note.

## Usage Guidelines

Use this command to execute EXEC commands while configuring your switch. After the EXEC command is executed, the system returns to the mode from which you issued the do command.



**Note** The receive bbcredit value reflects the extended bbcredit configuration. Extended bbcredit range for Vegas and ISOLA cards is 256-3500.

## Examples

The following example shows how to execute the EXEC commands:

```
switch(config)# port-monitor name cisco
switch(config-port-monitor)# do
switch(config-port-monitor)#
```

The following example disables the **terminal session-timeout** command using the **do** command in configuration mode:

```
switch(config)# do terminal session-timeout 0
switch(config)#
```

The following example creates and enables the interface from configuration mode:

```
switch(config)# int fc 3/1
switch(config-if)# no shut
```

The following example shows how to receive the extended bbcredit interface:

```
switch(config-if)# do show interface fc3/2
fc3/2 is trunking
Hardware is Fiber Channel, SFP is short wave laser w/o OFC (SN)
Port WWN is 20:82:00:05:30:00:2a:1e
Peer port WWN is 20:42:00:0b:46:79:f1:80
Admin port mode is auto, trunk mode is on
Port mode is TE
Port vsan is 1
Speed is 2 Gbps
Transmit B2B Credit is 255
Receive B2B Credit is 1500
Receive data field Size is 2112
Beacon is turned off
  Trunk vsans (admin allowed and active) (1-10)
  Trunk vsans (up) (1-10)
  Trunk vsans (isolated) ()
  Trunk vsans (initializing) ()
  5 minutes input rate 504 bits/sec, 63 bytes/sec, 0 frames/sec
  5 minutes output rate 344 bits/sec, 43 bytes/sec, 0 frames/sec
    69390 frames input, 4458680 bytes
      0 discards, 0 errors
      0 CRC, 0 unknown class
      0 too long, 0 too short
    69458 frames output, 3086812 bytes
      0 discards, 0 errors
    2 input OLS, 1 LRR, 0 NOS, 2 loop inits
    1 output OLS, 1 LRR, 1 NOS, 1 loop inits
```

# dpvm abort

To discard a dynamic port VSAN membership (DPVM) Cisco Fabric Services (CFS) distribution session in progress, use the **dpvm abort** command in configuration mode.

## dpvm abort

**Syntax Description** This command has no other arguments or keywords.

**Command Default** None.

**Command Modes** Configuration mode.

Command History	Release	Modification
	2.0(x)	This command was introduced.

**Usage Guidelines** To use this command, DPVM must be enabled using the **dpvm enable** command.

**Examples** The following example shows how to discard a DPVM CFS distribution session in progress:

```
switch# config terminal
switch(config)# dpvm abort
```

Related Commands	Command	Description
	<b>dpvm database</b>	Configures the DPVM database.
	<b>dpvm distribute</b>	Enables CFS distribution for DPVM.
	<b>dpvm enable</b>	Enables DPVM.
	<b>show dpvm</b>	Displays DPVM information.

# dpvm activate

To activate the dynamic port VSAN membership (DPVM) configuration database, use the **dpvm activate** command. To deactivate the DPVM configuration database, use the **no** form of the command.

**dpvm activate [force]**  
**no dpvm activate [force]**

## Syntax Description

<b>force</b>	(Optional) Forces the activation or deactivation if conflicts exist between the configured DPVM database and the active DPVM database.
--------------	--

## Command Default

Deactivated.

## Command Modes

Configuration mode.

## Command History

Release	Modification
2.0(x)	This command was introduced.

## Usage Guidelines

To use this command, DPVM must be enabled using the **dpvm enable** command.

Activation might fail if conflicting entries are found between the configured DPVM database and the currently activated DPVM database. You can ignore the conflicts using the **force** option.

## Examples

The following example shows how to activate the DPVM database:

```
switch# config terminal
switch(config)# dpvm activate
```

The following example shows how to deactivate the DPVM database:

```
switch# config terminal
switch(config)# no dpvm activate
```

## Related Commands

Command	Description
<b>dpvm database</b>	Configures the DPVM database.
<b>dpvm enable</b>	Enables DPVM.
<b>show dpvm</b>	Displays DPVM database information.

# dpvm auto-learn

To enable the automatic learning feature (autolearn) for the active dynamic port VSAN membership (DPVM) database, use the **dpvm auto-learn** command. To disable this feature, use the **no** form of the command.

**dpvm auto-learn**  
**no dpvm auto-learn**

**Syntax Description** This command has no other arguments or keywords.

**Command Default** Disabled.

**Command Modes** Configuration mode.

Command History	Release	Modification
	2.0(x)	This command was introduced.

**Usage Guidelines** To use this command, DPVM must be enabled using the **dpvm enable** command.

When autolearn is enabled, the system automatically creates the DPVM database by learning about devices currently logged or newly logged devices with a VSAN. This is a quick way to create the DPVM which can later be edited. Autolearn features include the following:

- An autolearned entry is created by adding the device PWWN and VSAN to the active DPVM database.
- The active DPVM database must be present when autolearning is enabled.
- Autolearned entries can be deleted from the active DPVM database by the user until autolearning is disabled. Autolearned entries are not permanent in the active DPVM database until autolearning is disabled.
- If a device logs out when autolearning is enabled, the device entry is deleted from the active DPVM database.
- If a particular device logs into the switch multiple times through different ports, then only the VSAN corresponding to last login is associated with the device.
- Autolearn entries do not override previously configured activate entries.

## Examples

The following example shows how to enable autolearning for the DPVM database:

```
switch# config terminal
switch(config)# dpvm auto-learn
```

The following example shows how to disable autolearning for the DPVM database:

```
switch# config terminal
switch(config)# no dpvm auto-learn
```

**Related Commands**

Command	Description
<b>dpvm enable</b>	Enables DPVM.
<b>show dpvm</b>	Displays DPVM database information.

# dpvm commit

To apply the pending configuration pertaining to the dynamic port VSAN membership (DPVM) Cisco Fabric Services (CFS) distribution session in progress in the fabric, use the **dpvm commit** command.

## dpvm commit

**Syntax Description** This command has no other arguments or keywords.

**Command Default** None.

**Command Modes** Configuration mode.

Command History	Release	Modification
	2.0(x)	This command was introduced.

**Usage Guidelines** To use this command, DPVM must be enabled using the **dpvm enable** command.

**Examples** The following example shows how to commit changes to the DPVM database:

```
switch# config terminal
switch(config)# dpvm commit
```

Related Commands	Command	Description
	<b>dpvm distribute</b>	Enables CFS distribution for DPVM.
	<b>dpvm enable</b>	Enables DPVM.
	<b>show dpvm</b>	Displays DPVM information.



# dpvm database

To activate and configure the dynamic port VSAN membership (DPVM) database, use the **dpvm database** command. To deactivate the database, use the **no** form of the command.

**dpvm database**  
**no dpvm database**

**Syntax Description** This command has no other arguments or keywords.

**Command Default** Deactivated.

**Command Modes** Configuration mode.

Command History	Release	Modification
	2.0(x)	This command was introduced.

**Usage Guidelines** To use this command, DPVM must be enabled using the **dpvm enable** command.

The DPVM database consists of a series of device mapping entries. Each entry consists of device pWWN or nWWN along with the dynamic VSAN to be assigned. Use the **nwwn** command or **pwwn** command to add the entries to the DPVM database. This database is global to the whole switch (and fabric) and is not maintained for each VSAN.

## Examples

The following example shows how to activate the DPVM database and enter DPVM database configuration submode:

```
switch# config terminal
switch(config)# dpvm database
switch# (config-dpvm-db) #
```

The following example shows how to activate the DPVM database and enter nWWN device:

```
switch# (config-dpvm-db) # nwwn 14:21:30:12:63:39:72:81 vsan 101
Successful. Commit should follow for command to take effect.
excal-178 (config-dpvm-db) #
```

The following example shows how to activate the DPVM database and enter pWWN device:

```
switch# (config-dpvm-db) # pwwn 14:21:30:12:63:39:72:81 vsan 101
Successful. Commit should follow for command to take effect.
switch# (config-dpvm-db) #
```

## Related Commands

Command	Description
<b>dpvm enable</b>	Enables DPVM.
<b>nwwn (DPVM database configuration submode)</b>	Adds entries to the DPVM database using the nWWN.
<b>pwwn (DPVM database configuration submode)</b>	Adds entries to the DPVM database using the pWWN.

Command	Description
<b>show dpvm</b>	Displays DPVM database information.

# dpvm database copy active

To copy the active dynamic port VSAN membership (DPVM) database to the config DPVM database, use the **dpvm database copy active** command.

**dpvm database copy active**

**Syntax Description** This command has no other arguments or keywords.

**Command Default** Disabled.

**Command Modes** EXEC mode.

Command History	Release	Modification
	2.0(x)	This command was introduced.

**Usage Guidelines** To use this command, DPVM must be enabled using the **dpvm enable** command.

The following circumstances may require the active database to be copied to the config database:

- When the autolearned entries are only added to the active database.
- When the config database or entries in the config database are accidentally deleted.



**Note** If you want to copy the DPVM database and fabric distribution is enabled, you must first commit the changes.

## Examples

The following example shows how to copy the active DPVM database to the config DPVM database:

```
switch# dpvm database copy active
```

Related Commands	Command	Description
	<b>dpvm enable</b>	Enables DPVM.
	<b>show dpvm</b>	Displays DPVM database information.

# dpvm database diff

To display the active dynamic port VSAN membership (DPVM) database, use the **dpvm database diff** command.

**dpvm database diff** {**active** | **config**}

## Syntax Description

<b>active</b>	Displays differences in the DPVM active database compared to the DPVM config database.
<b>config</b>	Displays differences in the DPVM config database compared to the DPVM active database.

## Command Default

Deactivated.

## Command Modes

Configuration mode.

## Command History

Release	Modification
2.0(x)	This command was introduced.

## Usage Guidelines

To use this command, DPVM must be enabled using the **dpvm enable** command.

## Examples

The following example displays the differences in the DPVM active database when compared with the DPVM config database:

```
switch# dpvm database diff active
Legend: "+" New Entry, "-" Missing Entry, "*" Possible Conflict Entry
-----
- pwn 44:22:33:44:55:66:77:88 vsan 44
* pwn 11:22:33:44:55:66:77:88 vsan 11
```

The following example displays the differences in the DPVM config database when compared with the DPVM active database:

```
switch# dpvm database diff config
Legend: "+" New Entry, "-" Missing Entry, "*" Possible Conflict Entry
-----
- pwn 44:22:33:44:55:66:77:88 vsan 44
* pwn 11:22:33:44:55:66:77:88 vsan 11
```

## Related Commands

Command	Description
<b>dpvm enable</b>	Enables DPVM.
<b>show dpvm</b>	Displays DPVM database information.

# dpvm distribute

To enable Cisco Fabric Services (CFS) distribution for dynamic port VSAN membership (DPVM), use the **dpvm distribute** command. To disable this feature, use the **no** form of the command.

**dpvm distribute**  
**no dpvm distribute**

## Syntax Description

This command has no other arguments or keywords.

## Command Default

Enabled.

## Command Modes

Configuration mode.

## Command History

Release	Modification
2.0(x)	This command was introduced.

## Usage Guidelines

To use this command, DPVM must be enabled using the **dpvm enable** command.

Temporary changes to the DPVM database must be committed to the active DPVM database using the **dpvm commit** command before being distributed to the fabric.

## Examples

The following example shows how to disable distribution for the DPVM database:

```
switch# config terminal
switch(config)# no dpvm distribute
```

The following example shows how to enable distribution for the DPVM database:

```
switch# config terminal
switch(config)# dpvm distribute
```

## Related Commands

Command	Description
<b>dpvm enable</b>	Enables DPVM.
<b>show dpvm</b>	Displays DPVM information.

# dpvm enable

To enable dynamic port VSAN membership (DPVM), use the **dpvm enable** command. To disable DPVM, use the **no dpvm enable** command.

**dpvm enable**  
**no dpvm enable**

**Syntax Description** This command has no other arguments or keywords.

**Command Default** Disabled.

**Command Modes** Configuration mode.

Command History	Release	Modification
	2.0(x)	This command was introduced.
	NX-OS 4.1(1b)	This command was deprecated.

**Usage Guidelines** The configuration and verification commands for DPVM are only available when DPVM is enabled on the switch. When you disable this feature, all related configurations are automatically discarded.

**Examples** The following example shows how to enable DPVM:

```
switch# config terminal
switch(config)# dpvm enable
```

Related Commands	Command	Description
	<b>dpvm activate</b>	Activates the DPVM database.
	<b>dpvm database</b>	Configures the DPVM database.
	<b>show dpvm</b>	Displays DPVM database information.

# dpvm overwrite-duplicate-pwwn

To overwrite the first login information with the duplicate PWWN login, use the **dpvm overwrite-duplicate-pwwn** command.

**dpvm overwrite-duplicate-pwwn**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None.

**Command Modes** Configuration mode.

Command History	Release	Modification
	NX-OS 4.1(1b)	This command was introduced.

**Usage Guidelines** None.

**Examples** The following example shows how to overwrite the DPVM duplicate PWWN login:

```
switch#(config)# dpvm overwrite-duplicate-pwwn
switch#(config)#
```

# dscp

To configure a differentiated services code point (DSCP) in a QoS policy map class, use the **dscp** command in EXEC mode. To disable this feature, use the **no** form of the command.

**dscp** *value*

**no dscp** *value*

## Syntax Description

<i>value</i>	Configures the DSCP value. The range is 0 to 63. DSCP value 46 is reserved.
--------------	---

## Command Default

The default DSCP value is 0.

## Command Modes

QoS policy map class configuration submode.

## Command History

Release	Modification
1.3(1)	This command was introduced.

## Usage Guidelines

Before you can configure a QoS policy map class you must complete the following:

- Enable the QoS data traffic feature using the **qos Enable** command.
- Configure a QoS class map using the **qos Class-map** command.
- Configure a QoS policy map using the **qos Policy-map** command.
- Configure a QoS policy map class using the **class** command.

## Examples

The following example configures a DSCP value of 56 in QoS policy classMap1:

```
switch(config-pmap)# class classMap1
switch(config-pmap-c)# ?
Configure class-map set params:
  do          EXEC command
  dscp        DSCP for frames matching class-map.
  exit        Exit from this submode
  no          Negate a command or set its defaults
  priority    Priority to be used for frames matching class-map
switch(config-pmap-c)#
switch(config-pmap-c)# ?
Configure class-map set params:
  do          EXEC command
  dscp        DSCP for frames matching class-map.
  exit        Exit from this submode
  no          Negate a command or set its defaults
  priority    Priority to be used for frames matching class-map
switch(config-pmap-c)# dscp ?
<0-63> DSCP value. DSCP of 46 is disallowed.
switch(config-pmap-c)# dscp 56 ?
<cr> Carriage Return
switch(config-pmap-c)# dscp 56
Operation in progress. Please check class-map parameters
switch(config-pmap-c)# priority ?
  high      Frames matching class-map get high priority
```



```
low      Frames matching class-map get low priority
medium   Frames matching class-map get medium priority
switch(config-pmap-c)# priority low ?
<cr>    Carriage Return
switch(config-pmap-c)# priority low
Operation in progress. Please check class-map parameters
switch(config-pmap-c)#
```

**Related Commands**

Command	Description
<b>class</b>	Configure a QoS policy map class.
<b>qos class-map</b>	Configures a QoS class map.
<b>qos enable</b>	Enables the QoS data traffic feature on the switch.
<b>qos policy-map</b>	Configure a QoS policy map.
<b>show qos</b>	Displays the current QoS settings.

# dst-grp

To link a destination group to a subscription node, use the **dst-grp** command. To remove the destination group linked to the subscription node, use the **no** form of this command.

**dst-grp** *id*

**no dst-grp** *id*

## Syntax Description

<i>id</i>	Destination group ID. Range is from 1 to 4095.
-----------	--

## Command Default

No destination group is linked to subscription node.

## Command Modes

Telemetry subscription node configuration mode (conf-tm-sub)

## Command History

Release	Modification
8.3(1)	This command was introduced.

## Usage Guidelines

Currently, destination group ID supports only numeric ID values.

## Examples

This example shows how to link a destination group to a subscription node:

```
switch# configure
switch(config)# telemetry
switch(config-telemetry)# subscription 100
switch(conf-tm-sub)# dst-grp 100
```

This example shows how to remove a destination group linked to a subscription node:

```
switch# configure
switch(config)# telemetry
switch(config-telemetry)# subscription 100
switch(conf-tm-sub)# no dst-grp 100
```

## Related Commands

Command	Description
<b>destination-group</b>	Creates a destination group and enters destination group configuration mode.
<b>feature telemetry</b>	Enables the SAN Telemetry Streaming feature.
<b>show running-config telemetry</b>	Displays the existing telemetry configuration.
<b>show telemetry</b>	Displays telemetry configuration.

Command	Description
<b>subscription</b>	Creates a subscription node and enters subscription node configuration mode.
<b>telemetry</b>	Enters SAN Telemetry Streaming configuration mode.

# duplicate-message throttle

To enable throttling of duplicate Call Home alert messages, use the **duplicate-message throttle** command in Call Home configuration submode. To disable this feature, use the **no** form of the command.

**duplicate-message throttle**  
**no duplicate-message throttle**

**Syntax Description** This command has no other arguments or keywords.

**Command Default** Enabled.

**Command Modes** Call Home configuration submode.

Command History	Release	Modification
	2.0(x)	This command was introduced.

**Usage Guidelines** The rate of throttling is a maximum of thirty messages in 2 hours.

**Examples** The following example shows how to enable throttling of duplicate Call Home alert messages:

```
switch# config terminal
switch(config)# callhome
switch(config-callhome)# duplicate-message throttle
```

Related Commands	Command	Description
	<b>callhome</b>	Configures the Call Home function.
	<b>callhome test</b>	Sends a dummy test message to the configured destination(s).
	<b>show callhome</b>	Displays configured Call Home information.