



# Templates

---

- [Templates, on page 1](#)
- [Template Usage, on page 30](#)

## Templates

### UI Navigation

- Choose **Operations** > **Templates**.

You can add, edit, or delete templates that are configured across different Cisco Nexus, IOS-XE, IOS-XR, and Cisco MDS platforms using Cisco Nexus Dashboard Fabric Controller Web client. The following parameters are displayed for each template that is configured on Cisco Nexus Dashboard Fabric Controller Web client. Templates support JavaScript. You can use the JavaScript function in a template to perform arithmetic operations and string manipulations in the template syntax.

**Table 1: Template Table Fields and Description**

Field	Description
Name	Specifies the template name.
Supported Platforms	Specifies the platforms that the template support.
Type	Specifies the template type.
Sub Type	Specifies the template sub type.
Modified	Specifies the date and time of the template modification.
Tags	Specifies if the template is tagged to a fabric or a device.
Description	Specifies the template description.
Reference Count	Specifies the number of times a template is used.

Click the table header to sort the entries in alphabetical order of that parameter.



**Note** Templates with errors are not listed in the Templates window. You cannot import templates with errors. To import such templates, fix the errors, and import them.

The following table describes the action items, in the **Actions** drop-down list, that appears in the **Templates** window.

**Table 2: Templates Actions and Description**

Actions	Description
Create new template	Allows you to create a new template. For more information, see <a href="#">Creating a New Template, on page 3</a> .
Edit template properties	Allows you to edit the template properties. You can edit only one template at a time. For more information, see <a href="#">Editing a Template, on page 4</a> .
Edit template content	Allows you to edit the template content. You can edit only one template at a time. For more information, see <a href="#">Editing a Template, on page 4</a> .
Duplicate template	<p>Allows you to duplicate the selected template with a different name. You can edit the template as required. You can duplicate only one template at a time.</p> <p>To duplicate a template, select the check box next to the template that you want to duplicate and choose <b>Duplicate template</b>. The <b>Duplicate Template</b> window appears. Specify a name for the duplicated template. For more information about editing the duplicated template, see <a href="#">Editing a Template, on page 4</a>.</p>

Actions	Description
Delete template	<p>Allows you to delete a template. You can delete more than one template in a single instance.</p> <p>You can delete the user-defined templates. However, you cannot delete the predefined templates</p> <p>To delete a template, select the check box next to the template that you want to delete and choose <b>Delete template</b>. A warning message appears. If you are sure you want to delete the template, click <b>Confirm</b>. If not, click <b>Cancel</b>. If the template is in use or is a shipping template, you cannot delete it, and an error message appears.</p> <p><b>Note</b> Select multiple templates to delete them at the same instance.</p> <p>To delete the template permanently, delete the template that is located in your local directory: <code>C:\Cisco Systems\dcn\ndfc\data\templates\</code>.</p>
Import	<p>Allows you to import a template from your local directory, one at a time. For more information, see <a href="#">Importing a Template, on page 6</a>.</p>
Import as Zip	<p>Allows you to import .zip file, that contains more than one template that is bundled in a .zip format</p> <p>All the templates in the ZIP file are extracted and listed in the table as individual templates.</p> <p>For more information, see <a href="#">Importing a Template, on page 6</a>.</p>
Export	<p>Allows you to export the template configuration to a local directory location. You can export only one template at a time.</p> <p>To export a template, use the check box next to it to select it and choose <b>Export</b>. Select a location on your local system directory to store the template file. Click <b>Save</b>. The template file is exported to your local directory.</p>

You can only view templates with the **network-operator** role. You cannot create, edit, or save templates with this role. However, you can create or edit templates with the **network-stager** role.

This section contains the following:

## Creating a New Template

### Nexus Dashboard Fabric Controller UI Navigation

- Choose **Operations > Templates**.

To create user-defined templates and schedule jobs from the Cisco Nexus Dashboard Fabric Controller Web UI, perform the following steps:

### Procedure

---

- Step 1** In the **Templates** window, from the **Actions** drop-down list, choose **Create new template**.  
The **Create Template** window appears.
- Step 2** In the **Template Properties** page of the window, specify a template name, description, tags, and choose supported platforms for the new template. Next, choose a template type and a sub template type from the drop-down lists. Choose a content type for the template from the drop-down list.
- Note** The base templates are CLI templates.
- Step 3** Click **Next** to continue editing the template or click **Cancel** to discard the changes.  
The edited template properties are displayed in the **Template Content** page of the **Edit Template** window. For information about the structure of the Configuration Template, see the *Template Structure* section.
- Step 4** Click **Validate** to validate the template syntax.
- Note** You can continue to save the template if there are warnings only. However, if there is an error, you must edit the templates to fix the errors before you proceed. Click the line number under the Start Line column to locate the error in the template content. You will get an error if you validate a template that does not have a template name.
- Step 5** Click **Help** to open the **Editor Help** pane on the right.  
This window contains more information about the format, variables, content and data types used to build the template. Close the **Editor Help** pane.
- Step 6** Click **Errors** and **Warnings** if the links are displayed. If there are no errors or warnings, the links are not available. If errors or warnings are present, and you click the links, the **Errors & Warnings** pane appears on the right displaying the errors and warnings. Close the **Errors & Warnings** pane.
- Step 7** To build the template content, select the required theme, key binding, and font size from the drop-down list.
- Step 8** Click **Finish** to complete editing of the template, click **Cancel** to discard the changes, click **Previous** to go to the **Template Properties** page.  
The page with the message that the template was created appears. The page also displays the template name, type, and sub type, and the platforms. You can also click **Create another template** to create one more template or click **Edit <template name> template** to edit the template that was just edited.
- Step 9** Close the **Edit Template** window or Click **Back to template library** to go back to the **Templates** window.
- 

## Editing a Template

### Nexus Dashboard Fabric Controller UI Navigation

- Choose **Operations > Templates**.

You can edit the user-defined templates. However, the predefined templates and templates that are already published cannot be edited.

Use the **Edit Template** window to first edit the template properties and then edit the template content. Furthermore, you can edit either only the template properties using the **Edit template properties** action or only the template content using the **Edit template content** action. In other words, you can edit the template properties at one instance, and then, edit the template content at another instance. You can also use this window to view the template properties and content.

Perform the following steps to edit the template properties and then edit the template content:

### Procedure

---

- Step 1** In the **Templates** window, select a template. From the **Actions** drop-down list, choose **Edit template properties**.  
The **Edit Template** window appears.
- Step 2** In the **Template Properties** page of the window displays the name of the template along with its description, supported platforms, tags, and content type. You can edit the template description and tags. To edit the supported platforms, clear the selected check boxes to select other switches. Next, choose a template type and a sub template type from the drop-down lists.
- Step 3** Click **Next** to continue editing the template or click **Cancel** to discard the changes.  
The edited template properties are displayed in the **Template Content** page of the **Edit Template** window.
- Step 4** Click **Validate** to validate the template syntax.
- Note** You can continue to save the template if there are warnings only. However, if there is an error, you must edit the templates to fix the errors before you proceed. Click the line number under the Start Line column to locate the error in the template content. You will get an error if you validate a template that does not have a template name.
- Step 5** Click **Help** to open the **Editor Help** pane on the right.  
This window contains more information about the format, variables, content and data types used to build the template. Close the **Editor Help** pane.
- Step 6** Click **Errors** and **Warnings** if the links are displayed. If there are no errors or warnings, the links are not available. If errors or warnings are present, and you click the links, the **Errors & Warnings** pane appears on the right displaying the errors and warnings. Close the **Errors & Warnings** pane.
- Step 7** To build the template content, select the required theme, key binding, and font size from the drop-down list.
- Step 8** Click **Finish** to complete editing of the template, click **Cancel** to discard the changes, click **Previous** to go to the **Template Properties** page.  
The page with the message that the template is saved appears. The page also displays the template name, type, and sub type, and the platforms. You can also click **Create another template** to create one more template or click **Edit <template name> template** to edit the template that was just edited.
- Step 9** Close the **Edit Template** window or Click **Back to template library** to go back to the **Templates** window.
-

## Importing a Template

### Nexus Dashboard Fabric Controller UI Navigation

- Choose **Operations** > **Templates**.

Follow the same procedure while importing zipped templates.




---

**Note** The “\n” in the template is considered as a new line character when imported and edited, but it works fine when imported as a ZIP file.

---

To import a template from the Cisco Nexus Dashboard Fabric Controller Web UI, perform the following steps:

### Procedure

- 
- Step 1** In the **Templates** window, from the **Actions** drop-down list, choose **Import template**.  
The **Import Template** window appears.
- Step 2** Browse and select the template that is saved on your computer.
- Step 3** Click **OK** to import the template or click **Cancel** to discard the template.
- Note** After importing a zipped template file, either a successful or error message appears. Click **OK**.
- Step 4** You can edit the template parameters and content, if necessary. For more information, see [Editing a Template, on page 4](#).
- Note** When importing a zipped template file, the **Edit Template** window may not appear. However, you can edit the template parameters and content, if necessary, using the **Edit Template** action.
- Step 5** If you do not want to edit the template properties or content, then keep clicking **Next**, then **Finish** and **Back to template library** to go back to the **Templates** window.
- 

## Template Structure

The configuration template content mainly consists of four parts. Click the **Help** icon next to the **Template Content** for information about editing the content of the template.

This section contains the following:

## Template Format

This section describes the basic information of the template. The possible fields are as detailed in the table below.

Property Name	Description	Valid Values	Optional?
name	The name of the template	Text	No
description	Brief description about the template	Text	Yes
userDefined	Indicates whether the user created the template. Value is 'true' if user created.	"true" or "false"	Yes
supportedPlatforms	List of device platforms supports this configuration template. Specify 'All' to support all platforms.	N1K, N3K, N3500, N4K, N5K, N5500, N5600, N6K, N7K, N9K, MDS, VDC, N9K-9000v, IOS-XE, IOS-XR, Others, All Nexus Switches list separated by comma.	No
templateType	Specifies the type of Template used.	<ul style="list-style-type: none"> <li>• CLI</li> <li>• POAP</li> </ul> <p><b>Note</b> POAP option is not applicable for Cisco Nexus Dashboard Fabric Controller LAN Fabric deployment.</p> <ul style="list-style-type: none"> <li>• POLICY</li> <li>• SHOW</li> <li>• PROFILE</li> <li>• FABRIC</li> <li>• ABSTRACT</li> <li>• REPORT</li> </ul>	Yes

Property Name	Description	Valid Values	Optional?
templateSubType	Specifies the sub type associated with the template.		

Property Name	Description	Valid Values	Optional?
		<ul style="list-style-type: none"> <li>• CLI                             <ul style="list-style-type: none"> <li>• N/A</li> </ul> </li> <li>• POAP                             <ul style="list-style-type: none"> <li>• N/A</li> <li>• VXLAN</li> <li>• FABRICPATH</li> <li>• VLAN</li> <li>• PMN</li> </ul> </li> <li><b>Note</b> POAP option is not applicable for Cisco Nexus Dashboard Fabric Controller LAN Fabric deployment.</li> <li>• POLICY                             <ul style="list-style-type: none"> <li>• VLAN</li> <li>• INTERFACE_VLAN</li> <li>• INTERFACE_VPC</li> <li>• INTERFACE_ETHNET</li> <li>• INTERFACE_BD</li> <li>• INTERFACE_CHANNEL</li> <li>• INTERFACE_FC</li> <li>• INTERFACE_MGMT</li> <li>• INTERFACE_COBACK</li> <li>• INTERFACE_NVE</li> <li>• INTERFACE_VFC</li> <li>• INTERFACE_CHANNEL</li> <li>• DEVICE</li> <li>• FEX</li> </ul> </li> </ul>	

Property Name	Description	Valid Values	Optional?
		<ul style="list-style-type: none"> <li>• NIRA_FABRIC_LINK</li> <li>• NIER_FABRIC_LINK</li> <li>• INTERFACE</li> <li>• SHOW                             <ul style="list-style-type: none"> <li>• VLAN</li> <li>• NIERFACE_VLAN</li> <li>• INTERFACE_VPC</li> <li>• NIERFACE_ETHNET</li> <li>• INTERFACE_BD</li> <li>• NIERFACE_CHANNEL</li> <li>• INTERFACE_FC</li> <li>• NIERFACE_MGMT</li> <li>• NIERFACE_LOOBACK</li> <li>• INTERFACE_NVE</li> <li>• INTERFACE_VFC</li> <li>• NIERFACE_CHANNEL</li> </ul> </li> <li>• DEVICE</li> <li>• FEX</li> <li>• NIRA_FABRIC_LINK</li> <li>• NIER_FABRIC_LINK</li> <li>• INTERFACE</li> <li>• PROFILE                             <ul style="list-style-type: none"> <li>• VXLAN</li> </ul> </li> <li>• FABRIC                             <ul style="list-style-type: none"> <li>• NA</li> </ul> </li> </ul>	

Property Name	Description	Valid Values	Optional?
		<ul style="list-style-type: none"> <li>• ABSTRACT                             <ul style="list-style-type: none"> <li>• VLAN</li> <li>• INTERFACE_VLAN</li> <li>• INTERFACE_VPC</li> <li>• INTERFACE_ETHNET</li> <li>• INTERFACE_BD</li> <li>• <del>INTERFACE_CHANNEL</del></li> <li>• INTERFACE_FC</li> <li>• INTERFACE_MGMT</li> <li>• INTERFACE_LOOPBACK</li> <li>• INTERFACE_NVE</li> <li>• INTERFACE_VFC</li> <li>• <del>INTERFACE_CHANNEL</del></li> </ul> </li> <li>• DEVICE</li> <li>• FEX</li> <li>• NIRA_FABRIC_LINK</li> <li>• NIER_FABRIC_LINK</li> <li>• INTERFACE</li> </ul> <ul style="list-style-type: none"> <li>• REPORT                             <ul style="list-style-type: none"> <li>• UPGRADE</li> <li>• GENERIC</li> </ul> </li> </ul>	

Property Name	Description	Valid Values	Optional?
contentType		<ul style="list-style-type: none"> <li>• CLI                             <ul style="list-style-type: none"> <li>• TEMPLATE_CLI</li> </ul> </li>   <li>• POAP                             <ul style="list-style-type: none"> <li>• TEMPLATE_CLI</li> </ul> </li>   <li><b>Note</b> POAP option is not applicable for Cisco Nexus Dashboard Fabric Controller LAN Fabric deployment.</li>   <li>• POLICY                             <ul style="list-style-type: none"> <li>• TEMPLATE_CLI</li> <li>• PYTHON</li> </ul> </li>   <li>• SHOW                             <ul style="list-style-type: none"> <li>• TEMPLATE_CLI</li> </ul> </li>   <li>• PROFILE                             <ul style="list-style-type: none"> <li>• TEMPLATE_CLI</li> <li>• PYTHON</li> </ul> </li>   <li>• FABRIC                             <ul style="list-style-type: none"> <li>• PYTHON</li> </ul> </li>   <li>• ABSTRACT                             <ul style="list-style-type: none"> <li>• TEMPLATE_CLI</li> <li>• PYTHON</li> </ul> </li>   <li>• REPORT                             <ul style="list-style-type: none"> <li>• PYTHON</li> </ul> </li> </ul>	Yes
implements	Used to implement the abstract template.	Text	Yes

Property Name	Description	Valid Values	Optional?
dependencies	Used to select the specific feature of a switch.	Text	Yes
published	Used to Mark the template as read only and avoids changes to it.	“true” or “false”	Yes

## Template Variables

This section contains declared variables, the data type, default values, and valid values conditions for the parameters that are used in the template. These declared variables are used for value substitution in the template content section during the dynamic command generation process. Also these variables are used in decision making and in iteration blocks in the template content section. Variables have predefined data types. You can also add a description about the variable. The following table describes the syntax and usage for the available datatypes.

Variable Type	Valid Value	Iterative?
boolean	true false	No
enum	Example: running-config, startup-config	No
float	Floating number format	No
floatRange	Example: 10.1,50.01	Yes
Integer	Any number	No
integerRange	Contiguous numbers separated by “_”  Discrete numbers separated by “,”  Example: 1-10,15,18,20	Yes
interface	Format: <if type><slot>[/<sub slot>]/<port>  Example: eth1/1, fa10/1/2 etc.	No
interfaceRange	Example: eth10/1/20-25, eth11/1-5	Yes
ipAddress	IPv4 OR IPv6 address	No

Variable Type	Valid Value	Iterative?
ipAddressList	<p>You can have a list of IPv4, IPv6, or a combination of both types of addresses.</p> <p>Example 1: 172.22.31.97, 172.22.31.99, 172.22.31.105, 172.22.31.109</p> <p>Example 2: 2001:0cb8:85a3:0000:0000:8a2e:0370:7334,  2001:0cb8:85a3:0000:0000:8a2e:0370:7335,  2001:0cb8:85a3:1230:0000:8a2f:0370:7334</p> <p>Example 3: 172.22.31.97, 172.22.31.99,  2001:0cb8:85a3:0000:0000:8a2e:0370:7334,  172.22.31.254</p>	Yes
ipAddressWithoutPrefix	<p>Example: 192.168.1.1</p> <p>or</p> <p>Example: 1:2:3:4:5:6:7:8</p>	No
ipV4Address	IPv4 address	No
ipV4AddressWithSubnet	Example: 192.168.1.1/24	No
ipV6Address	IPv6 address	No
ipV6AddressWithPrefix	<p>Example: 1:2:3:4:5:6:7:8</p> <p>22</p>	No
ipV6AddressWithSubnet	IPv6 Address with Subnet	No
ISISNetAddress	<p>Example:</p> <p>49.0001.00a0.c96b.c490.00</p>	No
long	Example: 100	No
macAddress	14 or 17 character length MAC address format	No
string	<p>Free text, for example, used for the description of a variable</p> <p>Example:</p> <pre>string scheduledTime { regularExpr=^([01]\d 2[0-3]):([0-5]\d)\$; }</pre>	No

Variable Type	Valid Value	Iterative?
string[]	Example: {a,b,c,str1,str2}	Yes
struct	<p>Set of parameters that are bundled under a single variable.</p> <pre> struct &lt;structure name declaration &gt; { &lt;parameter type&gt; &lt;parameter 1&gt;; &lt;parameter type&gt; &lt;parameter 2&gt;; ... } [&lt;structure_inst1&gt;] [, &lt;structure_inst2&gt;] [, &lt;structure_array_inst3 []&gt;;  struct interface_detail { string inf_name; string inf_description; ipAddress inf_host; enum duplex { validValues = auto, full, half; }; }myInterface, myInterfaceArray[];                     </pre>	<p>No</p> <p><b>Note</b> If the struct variable is declared as an array, the variable is iterative.</p>
wwn (Available only in Cisco Nexus Dashboard Fabric Controller Web Client)	Example: 20:01:00:08:02:11:05:03	No

## Variable Meta Property

Each variable that is defined in the template variable section has a set of meta properties. The meta properties are mainly the validation rules that are defined for the variable.

The following table describes the various meta properties applicable for the available variable types.

Variable Type	Description	Variable Meta Property											
		default Value	valid Values	decimal Length	min	max	min Slot	max Slot	min Port	max Port	min Length	max Length	regular Expr
boolean	A boolean value. Example: true	Yes											
enum			Yes										

Variable Type	Description	Variable Meta Property											
		default Value	valid Values	decimal Length	min	max	min Slot	max Slot	min Port	max Port	min Length	max Length	regular Expr
float	signed real number Example: 75.56, -8.5	Yes	Yes	Yes	Yes	Yes							
floatRange	range of signed real numbers Example: 50.5 - 54.75	Yes	Yes	Yes	Yes	Yes							
integer	signed number Example: 50, -75	Yes	Yes		Yes	Yes							
integerRange	Range of signed numbers Example: 50-65	Yes	Yes		Yes	Yes							
interface	specific interface Example: Ethernet 5/10	Yes	Yes				Yes	Yes	Yes	Yes			
interfaceRange		Yes	Yes				Yes	Yes	Yes	Yes			
ipAddress	IP address in IPv4 or IPv6 format	Yes											

Variable Type	Description	Variable Meta Property											
		default Value	valid Values	decimal Length	min	max	min Slot	max Slot	min Port	max Port	min Length	max Length	regular Expr
ipAddressList	<p>You can have a list of IPv4, IPv6, or a combination of both types of addresses.</p> <p>Example 1:                      172.23.9,                      172.3.9,                      172.3.15,                      172.3.10</p> <p>Example 2:                      2001:0502:                      2001:0502:                      2001:0502:100</p> <p>Example 3:                      172.23.9,                      172.3.9,                      2001:0502,                      172.3.29</p> <p><b>Note</b></p>	Yes											
	<p>Separate the addresses in the list using commas and not hyphens.</p>												

Variable Type	Description	Variable Meta Property											
		default Value	valid Values	decimal Length	min	max	min Slot	max Slot	min Port	max Port	min Length	max Length	regular Expr
<del>ip4Addr</del>	IPv4 or IPv6 Address (does not require prefix)												
<del>ip4Addr</del>	IPv4 address	Yes											
<del>ip4Addr</del>	IPv4 Address with Subnet	Yes											
<del>ip6Addr</del>	IPv6 address	Yes											
<del>ip6Addr</del>	IPv6 Address with prefix	Yes											
<del>ip6Addr</del>	IPv6 Address with Subnet	Yes											
<del>ip6Addr</del>	Example: <del>4008:5:50</del>												
long	Example: 100	Yes			Yes	Yes							
<del>macAddr</del>	MAC address												

Variable Type	Description	Variable Meta Property											
		default Value	valid Values	decimal Length	min	max	min Slot	max Slot	min Port	max Port	min Length	max Length	regular Expr
string	literal string  Example for string  Regular expression string  <code>string {                      ...                      }</code>	Yes									Yes	Yes	Yes
string[]	string literals that are separated by a comma (,)  Example: {string1, string2}	Yes											

Variable Type	Description	Variable Meta Property											
		default Value	valid Values	decimal Length	min	max	min Slot	max Slot	min Port	max Port	min Length	max Length	regular Expr
struct	Set of <del>params</del> that are bundled under a single variable.  struct  <structure name declaration> > { <parameter type>  <parameter 1>; <parameter type>  <parameter 2>; ... } <struct1> [, <struct2> [, <struct3> [ ]>;												
wnn	WWN address												

**Example: Meta Property Usage**

```
##template variables

integer VLAN_ID {
min = 100;
max= 200;
};

string USER_NAME {
defaultValue = admin123;
minLength = 5;
};

struct interface_a{
```

```

string inf_name;
string inf_description;
ipAddress inf_host;
enum duplex {
    validValues = auto, full, half;
};
}myInterface;

##

```

## Variable Annotation

You can configure the variable properties marking the variables using annotations.



**Note** Variable Annotations are available for POAP only. However, the annotations do not impact on the template type 'CLI'.

The following annotations can be used in the template variable section.

Annotation Key	Valid Values	Description
AutoPopulate	Text	Copies values from one field to another
DataDepend	Text	
Description	Text	Description of the field appearing in the window
DisplayName	Text <b>Note</b> Enclose the text with quotes, if there is space.	Display name of the field appearing in the window
Enum	Text1, Text2, Text3, and so on	Lists the text or numeric values to select from
IsAlphaNumeric	"true" or "false"	Validates if the string is alphanumeric
IsAsn	"true" or "false"	
IsDestinationDevice	"true" or "false"	
IsDestinationFabric	"true" or "false"	
IsDestinationInterface	"true" or "false"	
IsDestinationSwitchName	"true" or "false"	
IsDeviceID	"true" or "false"	
IsDot1qId	"true" or "false"	

Annotation Key	Valid Values	Description
IsFEXID	“true” or “false”	
IsGateway	“true” or “false”	Validates if the IP address is a gateway
IsInternal	“true” or “false”	Makes the fields internal and does not display them on the window  <b>Note</b> Use this annotation only for the ipAddress variable.
IsManagementIP	“true” or “false”  <b>Note</b> This annotation must be marked only for variable “ipAddress”.	
IsMandatory	“true” or “false”	Validates if a value should be passed to the field mandatorily
IsMTU	“true” or “false”	
IsMultiCastGroupAddress	“true” or “false”	
IsMultiLineString	“true” or “false”	Converts a string field to multiline string text area
IsMultiplicity	“true” or “false”	
IsPassword	“true” or “false”	
IsPositive	“true” or “false”	Checks if the value is positive
IsReplicationMode	“true” or “false”	
IsShow	“true” or “false”	Displays or hides a field on the window
IsSiteId	“true” or “false”	
IsSourceDevice	“true” or “false”	
IsSourceFabric	“true” or “false”	
IsSourceInterface	“true” or “false”	

Annotation Key	Valid Values	Description
IsSourceSwitchName	“true” or “false”	
IsSwitchName	“true” or “false”	
IsRMID	“true” or “false”	
IsVPCDomainID	“true” or “false”	
IsVPCID	“true” or “false”	
IsVPCPeerLinkPort	“true” or “false”	
IsVPCPeerLinkPortChannel	“true” or “false”	
IsVPCPortChannel	“true” or “false”	
Password	Text	Validates the password field
PeerOneFEXID	“true” or “false”	
PeerTwoFEXID	“true” or “false”	
PeerOnePCID	“true” or “false”	
PeerTwoPCID	“true” or “false”	
PrimaryAssociation		
ReadOnly	“true” or “false”	Makes the field read-only
ReadOnlyOnEdit	“true” or “false”	
SecondaryAssociation	Text	
Section		
UsePool	“true” or “false”	
UseDNSReverseLookup		
Username	Text	Displays the username field on the window
Warning	Text	Provides text to override the Description annotation

#### Example: AutoPopulate Annotation

```
##template variables
string BGP_AS;
@ (AutoPopulate="BGP_AS")
```

```
    string SITE_ID;
##
```

### Example: DisplayName Annotation

```
##template variables
@(DisplayName="Host Name", Description = "Description of the host")
String hostname;
@(DisplayName="Host Address", Description = " test description" IsManagementIP=true)
ipAddress hostAddress;
##
```

### Example: IsMandatory Annotation

```
##template variables
@(IsMandatory="ipv6!=null")
ipV4Address ipv4;
@(IsMandatory="ipv4!=null")
ipV6Address ipv6;
##
```

### Example: IsMultiLineString Annotation

```
##template variables
@(IsMultiLineString=true)
string EXTRA_CONF_SPINE;
##
```

### IsShow Annotation

```
##template variables
boolean isVlan;
@(IsShow="isVlan==true")
integer vlanNo;
##

##template variables
boolean enableScheduledBackup;
@(IsShow="enableScheduledBackup==true",Description="Server time")
string scheduledTime;
##
The condition "enableScheduledBackup==true" evaluates to true/false

##template variables
@(Enum="Manual,Back2BackOnly,ToExternalOnly,Both")
string VRF_LITE_AUTOCONFIG;
@(IsShow="VRF_LITE_AUTOCONFIG!=Manual", Description="Target Mask")
integer DCI_SUBNET_TARGET_MASK
##
The condition "VRF_LITE_AUTOCONFIG!=Manual" matches string comparison to evaluate to true
or false
```

### Example: Warning Annotation

```
##template variables
@(Warning="This is a warning msg")
    string SITE_ID;
##
```

## Templates Content

This section includes the configuration commands and any parameters that you want to include in the template. These commands can include the variables declared in the template variables section. During the command generation process the variable values are substituted appropriately in the template content.



**Note** You must specify the commands that you include as if you were entering them in the global configuration command mode on any device. You must consider the command mode when you include commands.

Template content is governed by the usage of variables.

- **Scalar variables:** does not take a range or array of values which cannot be used for iteration (In the variable types table those marked iterate-able as 'No'). Scalar variables must be defined inside the template content.

```
Syntax: $$<variable name>$$
Example: $$USER_NAME$$
```

- **Iterative variables:** used for block iteration. These loop variable must be accessed as shown below inside the iteration block.

```
Syntax:@<loop variable>
Example:
foreach val in $$INTEGER_RANGE_VALUE$$ {
@val
}
```

- **Scalar Structure Variable:** Structure member variables can be accessed inside the template content.

```
Syntax: $$<structure instance name>.<member variable name>$$
Example: $$myInterface.inf_name$$
```

- **Array Structure Variable:** Structure member variables can be accessed inside the template content.

```
Syntax: $$<structure instance name>.<member variable name>$$
Example: $$myInterface.inf_name$$
```

In addition to the template variables, you can use the conditional and iterative command generation using the following statements:

- **if-else if-else Statement:** makes a logical decision in inclusion/exclusion of set of configuration command based on the value assigned for the variable in it.

```
Syntax: if(<operand 1> <logical operator> <operand 2>){
command1 ..
command2..
..
}
else if (<operand 3> <logical operator> <operand 4> )
{
Command3 ..
Command4..
..
}
else
{
```

```

Command5 ..
Command6..
..
}
Example: if-else if-else statement
if($$USER_NAME$$ == 'admin'){
Interface2/10
no shut
}
else {
Interface2/10
shut
}

```

- **foreach Statement:** used for iterating a block of commands. The iteration is performed based on the assigned loop variable value.

```

Syntax:
foreach <loop index variable> in $$<loop variable>$$ {
@<loop index variable> ..
}
Example: foreach Statement
foreach ports in $$MY_INF_RANGES$${
interface @ports
no shut
}

```

- **Optional parameters:** By default all parameters are mandatory. To make a parameter optional, you must annotate the parameter.

In the variable section, you can include the following command:

- **@(IsMandatory=false)**
- **Integer frequency;**

In the template content section, a command can be excluded or included without using “if” condition check, by assigning a value to the parameter. The optional command can be framed as below:

- **probe icmp [frequency frequency-value] [timeout seconds] [retry-count retry-count-value]**

## Advanced Features

The following are the advanced features available to configure templates.

- **Assignment Operation**

Config template supports assignment of variable values inside the template content section. The values are validated for the declared data type of the variable. If there is a mismatch, the value is not assigned.

Assignment operation can be used under the following guidelines:

- The operator on the left must be any of the template parameters or a for loop parameter.
- The operator on the right values can be any of the values from template parameters, for loop parameters, literal string values surrounded by quotes or simple string values.

If a statement does not follow these guidelines, or if it does not suit this format, it will not be considered as assignment operation. It is substituted during command generation like other normal lines.

```

Example: Template with assignment operation
##template properties
name =vlan creation;
userDefined= true;
supportedPlatforms = All;
templateType = CLI;
published = false;
##
##template variables
integerRange vlan_range;
@(internal=true)
integer vlanName;
##
##template content
foreach vlanID in $$vlan_range$${
vlan @vlanID
$$vlanName$$=@vlanID
name myvlan$$vlanName$$
}
##

```

- Evaluate methods

Config template uses the Java runtime provided Java script environment to perform arithmetic operations (such as ADD, SUBTRACT, and so on), string manipulations, and so on.

Locate the JavaScript file in the template repository path. This file contains primary set of arithmetic, string functions. You can also add custom JavaScript methods.

These methods can be called from config template content section in below format:

```

Example1:
$$somevar$$ = evalscript(add, "100", $$anothervar$$)

```

Also the *evalscript* can be called inside if conditions as below:

```

if($$range$$ > evalscript(sum, $$vlan_id$$, -10)){
do something...
}

```

You can call a method that is located at the backend of the Java script file.

- Dynamic decision

Config template provides a special internal variable “LAST\_CMD\_RESPONSE”. This variable stores the last command response from the device during the execution of the command. This can be used in the config template content to make dynamic decisions to deliver the commands that are based on the device condition.




---

**Note** The if block must be followed by an else block in a new line, which can be empty.

---

An example use case to create a VLAN, if it does not exist on the device.

```

Example: Create VLAN
##template content
show vlan id $$vlan_id$$
if($$LAST_CMD_RESPONSE$$ contains "not found"){
vlan $$vlan_id$$
}

```

```

else{
}
##

```

This special implicit variable can be used only in the “IF” blocks.

- Template referencing

You can have a base template with all the variables defined. This base template can be imported to multiple templates. The base template content is substituted in the appropriate place of the extending template. The imported template parameters and the contents can be accessed inside the extending template.

Example: Template Referencing

Base template:

```

##template properties
name =a vlan base;
userDefined= true;
supportedPlatforms = All;
templateType = CLI;
published = false;
timestamp = 2015-07-14 16:07:52;
imports = ;
##
##template variables
integer vlan_id;
##
##template content
vlan $$vlan_id$$
##

```

Derived Template:

```

##template properties
name =a vlan extended;
userDefined= true;
supportedPlatforms = All;
templateType = CLI;
published = false;
timestamp = 2015-07-14 16:07:52;
imports = a vlan base,template2;
##
##template variables
interface vlanInterface;
##
##template content
<substitute a vlan base>
interface $$vlanInterface$$
<substitute a vlan base>
##

```

When you launch the extended template, the parameter inputs for the base template are also obtained. In addition, the substituted content is used for complete CLI command generation.

## Report Template

The template type of REPORT template is python, and it has two subtypes, UPGRADE and GENERIC.

### UPGRADE

The UPGRADE template is used for pre-ISSU and post-ISSU scenarios. These templates are listed in the ISSU wizard.

Refer to the default upgrade template packaged in Nexus Dashboard Fabric Controller for more information on pre-ISSU and post-ISSU handling. The default upgrade template is `issu_vpc_check`.

## GENERIC

The **GENERIC** template is used for any generic reporting scenarios, such as, collecting information about resources, switch inventory, SFPs, and NVE VNI counters. You can also use this template to generate troubleshooting reports.

### Resources Report

This report displays information about resource usage for a specific fabric.

The **Summary** section shows all resource pools with the current usage percentages. Use the horizontal scroll bar at the bottom of the window to display more columns.

**POOL NAME:** Specifies the name of the pool.

**POOL RANGE:** Specifies the IP address range of the pool.

**SUBNET MASK:** Specifies the subnet mask.

**MAX ENTRIES:** Specifies the maximum number of entries that can be allocated from the pool.

**USAGE INSIDE RANGE:** Specifies the current number of entries allocated inside the pool range.

**USAGE OUTSIDE RANGE:** Specifies the current number of entries set outside the pool range.

**USAGE PERCENTAGE:** This is calculated by using the formula:  $(\text{Usage Inside Range}/\text{Max Entries}) * 100$ .

Click **View Details** to display a view of resources allocated or set in each resource pool. For example, the detailed section for a **SUBNET** has information about the resources that have been allocated within the subnet.

### Switch Inventory Report

This report provides a summary about the switch inventory.

Click **View Details** to display more information about the modules and licenses.

### SFP Report

This report provides information about utilization of SFPs at a fabric and device level.



---

**Note** The switch inventory and SFP reports are supported only on Cisco Nexus devices.

---

## Troubleshooting Reports

These reports are generated to help in troubleshooting scenarios. Currently, the **NVE VNI Counters** report is the only pre-defined troubleshooting report. Generating **NVE VNI Counters** reports involves performing periodic checks to identify the VNIs that are among the top hits based on network traffic. In a large-scale setup, we recommend limiting the report generation frequency to a minimum of 60 minutes.

### NVE VNI Counters Report

This report collects the **show nve vni counters** command output for each VNI in the fabric.

After comparing the oldest report and the newest report, the **Summary** section shows the top-10 hit VNIs. The top hit VNIs are displayed in these categories:

- L2 or L3 VNIs for unicast traffic

- L2 or L3 VNIs for multicast traffic
- L2 only VNIs for unicast traffic
- L2 only VNIs for multicast traffic
- L3 only VNIs for unicast traffic
- L3 only VNIs for multicast traffic

The oldest report refers to the first report that is saved in the current reporting task. If you want to select a specific report as the first report against which the current report has to be compared, delete all reports that are older than the one selected so that the selected report becomes the first and oldest report.

For example, three reports were run yesterday at 8:00 a.m., 4:00 p.m. and 11:00 p.m. If you want to use the report at 11:00 p.m. as the first and oldest report for today’s reporting, delete the two reports that were run yesterday at 8:00 a.m. and 4:00 p.m.

For a periodic report, the oldest report is the first report that is run at the start time of a period. For daily and weekly reports, the current report is compared against the previously generated report.

The **Summary** section displays a column-wise report with information about the total transmitted bytes and the VNIs. Use the horizontal scroll bar at the bottom of the window to display more columns.




---

**Note** The **Summary** section in the NVE VNI Counters report displays negative numbers in the TOTAL TX BYTES column if a report is generated after a switch reload or after clearing the counters on the switch. The numbers are displayed correctly in the subsequent reports. As a workaround, we recommend deleting all old reports or creating a new job before reloading switches or clearing counters.

---

Click **View Details** to display more information. This section shows NVE VNIs and counters on a per-switch basis.

For more information on how the reports are displayed, refer *Programmable Reports* chapter.

## Template Usage

template Type	Specifies the type of Template used.	<ul style="list-style-type: none"> <li>• POLICY</li> <li>• SHOW</li> <li>• PROFILE</li> <li>• FABRIC</li> <li>• REPORT</li> <li>• INTERNAL</li> <li>• EXEC</li> </ul>
---------------	--------------------------------------	---

<p>template content type</p>	<p>Specifies the type of content in the template.</p>	<ul style="list-style-type: none"> <li>• CLI</li> <li>• PYTHON</li> <li>• PYTHON3</li> <li>• PYTHON3_CLI</li> <li>• PYTHON_CLI</li> <li>• TEXT</li> </ul>
------------------------------	---	---

## Policy Template

For the policy template, there are two template content types: CLI and PYTHON. With CLI content type, the policy templates are parameterized CLI templates. They can have a lot of variables and CLIs. Typically, CLI policy templates are small and do not have any if-else-for etc. like constructs. An example CLI policy template for AAA server configuration is shown below:

```

1  ##template variables
2
3  # Copyright (c) 2021 by Cisco Systems, Inc.
4  # All rights reserved.
5
6  @(DisplayName="AAA Server Name/IP", Description="Name or IPv4/IPv6 Address of an AAA Server")
7  ipAddressWithoutPrefix AAA_Server;
8
9  @(DisplayName="AAA group", Description="Name of AAA Group")
10 - string AAA_GROUP {
11     minLength = 1;
12     maxLength = 127;
13 };
14
15 ##
16 ##template content
17
18 aaa group server radius $$$$GROUP$$$
19     server $$$$SERVER$$$
20
21 ##
22
23
    
```

But you can also have policy templates of template content type PYTHON. Essentially, this allows multiple CLI policy templates to be combined together with a common “source” so that they get all applied/un-applied at one go. For example, when you want to create a vPC host port, it has to be created symmetrically on both peers that are part of the vPC pair. In addition, you have to create port-channel, member interfaces, channel-group, etc. This is why a python vPC host policy template has been added. An example interface PYTHON template for setting up a routed interface is shown below:

ext\_int\_routed\_host\_11\_1    Help    Validate    No Errors    No Warnings

Theme: XCode    Key Binding: Ace    Font Size: 12

```

1  ##template variables
2
3  # Copyright (c) 2019-2022 by Cisco Systems, Inc.
4  # All rights reserved.
5  @(IsInternal=true)
6  string SERIAL_NUMBER;
7
8  @(PrimaryAssociation=true, IsInternal=true)
9  interface INTF_NAME;
10
11  @(IsMandatory=false, DisplayName="Interface IP", Description="IP address of the interface", ReadOnly=true)
12  ipAddress IP;
13
14  @(IsMandatory="IP!=null", DisplayName="IP Netmask Length", Description="IP netmask length used with the IP address (Min:1, Max:31)", ReadOnly=true)
15  integer PREFIX {
16    min = 1;
17    max = 31;
18  };
19
20  @(IsMandatory=false, DisplayName="Interface IPv6", Description="IPv6 address of the interface", ReadOnly=true)
21  ipv6Address IPV6;
22
23  @(IsMandatory="IPv6!=null", DisplayName="IPv6 Netmask Length", Description="IPv6 netmask length used with the IPv6 address (Min:1, Max:128)", ReadOnly=true)
24  integer PREFIXv6 {
25    min = 1;
26    max = 128;
27  };
28
29  @(IsMandatory=false, DisplayName="Interface VRF", Description="Interface VRF name, default VRF if not specified", ReadOnly=true)
30  string INTF_VRF {
31    minLength = 1;
32    maxLength = 32;
33  };
34
35  @(IsMandatory=false, DisplayName="Routing TAG", Description="Routing tag associated with interface IP", ReadOnly=true)
36  string ROUTING_TAG;
37
38  @(DisplayName="MTU", IsMTU=true, Description="MTU for the interface", ReadOnly=true)
39  integer MTU {
40    min = 576;
41    max = 9216;
42    defaultValue=9216;
43  };
44
45  @(DisplayName="SPEED", Description="Interface Speed", ReadOnly=true)
46  enum SPEED {
47    validValues=Auto,100Mb,1Gb,2.5Gb,5Gb,10Gb,25Gb,40Gb,50Gb,100Gb,200Gb,400Gb;
48    defaultValue=Auto;
49  };
50
51  @(IsMandatory=false, DisplayName="Interface Description", Description="Add description to the interface", ReadOnly=true)
52  string DESC {
53    minLength = 1;
54    maxLength = 254;
55  };
56
57  @(IsMandatory=false, IsMultilineString=true, DisplayName="Freeform Config", Description="Additional CLI for the interface", ReadOnly=true)
58  string CONF;
59
60  @(DisplayName="Enable Interface", Description="Uncheck to disable the interface", ReadOnly=true)
61  boolean ADMIN_STATE {
62    defaultValue=true;
63  };
64
65  @(IsInternal=true)
66  string SOURCE;
67
68  ##
69  ##template content
70
71  from com.cisco.dcbu.vinci.rest.services.jython import PTIWrapper
72  from com.cisco.dcbu.vinci.rest.services.jython import Wrapper
73  from com.cisco.dcbu.vinci.rest.services.jython import WrappersResp
74  from utility import *
75
76  def add():
77    try:
78
79      respObj = WrappersResp.getRespObj()
80      try:
81        adminState = ADMIN_STATE
82      except:
83        adminState = "true"
84      pass
85      try:
86        source = SOURCE
87      except:
88        source = INTF_NAME
89      pass
90      Wrapper.print("ext_int_routed_host_11_1_add : Source sn = %, "
91                  "source interface= %s: source: %s"
92                  % (SERIAL_NUMBER, INTF_NAME, source))
93
94      routingTag = ""
95      try:
96        if ROUTING_TAG != "":
97          routingTag = ROUTING_TAG
98      except:
99        pass
100
101      #Only valid operation is shut/no-shut from interface page
102      #In addition, this can only happen if someone does a save on the interface edit for an interface attached to this policy
103      #After that shut/no-shut from interface manager starts sending source = INTF instead of source = LINK-UUID of VRF_LITE IFC
104      #This is a bug that needs to be fixed but right now putting a workaround here
105      if source == INTF_NAME:

```

Each policy template has a template subtype like DEVICE, INTERFACE, etc. This allows the right policy template to appear at the right selection point. For example, in the Interface window, you will only see the interface policy templates.

Templates

Sub-Type contains interface x Type contains Policy x

Name	Supported Platforms	Type	Sub Type	Modified	Tags	Description	Reference Count
int_port_channel_fex	All	POLICY	INTERFACE_PORT_CH...	18 days ago	st_fex	Interface template for creating a Straight-Through FEX (ST-FEX)	0
int_l3_port_channel	All	POLICY	INTERFACE_PORT_CH...	18 days ago	l3_interface	Interface template for creating a Layer 3 port-channel	0
int_vlan_dhcp_relay_internal	All	POLICY	INTERFACE_VLAN	18 days ago	internal_policy	Interface template for DHCP relay server config for SVI	0
ios_xe_int_subintf	IOS-XE	POLICY	INTERFACE_GIGABITE...	18 days ago	interface_subinterface		0
int_subintf	All	POLICY	INTERFACE_ETHERNET	18 days ago	interface_subinterface	Interface template for creating a sub-interface	0
int_monitor_subintf	All	POLICY	INTERFACE_ETHERNET	18 days ago	interface_subinterface	Interface template for putting a sub-interface into monitor mode	0
vlan_interface_tag	N9K	POLICY	INTERFACE_VLAN	18 days ago	interface_edit_policy		0
tunnel	IOS-XE	POLICY	INTERFACE_TUNNEL	18 days ago	interface_edit_policy	Interface template for creating a tunnel interface using freeform config on CAT9000 switches	0
non_nxos_int_freeform	Others	POLICY	INTERFACE_ETHERNET	18 days ago	interface_edit_policy	Interface template for an interface using freeform config on non-NXOS switches	0
ios_xr_int_routed_host	Others	POLICY	INTERFACE_GIGABITE...	18 days ago	interface_edit_policy	Interface template for creating a L3/routed port on ASR/CSR switches	0
ios_xr_int_freeform	Others	POLICY	INTERFACE_GIGABITE...	18 days ago	interface_edit_policy	Interface template for an interface using freeform config on ASR/CSR switches	0
ios_xe_ipsec_tunnel	IOS-XE	POLICY	INTERFACE_TUNNEL	18 days ago	interface_edit_policy	Create an IPsec tunnel interface for IOS-XE devices	0
ios_xe_interface_stackwise_virtual	IOS-XE	POLICY	INTERFACE_ETHERNET	18 days ago	interface_edit_policy		4
ios_xe_interface_stackwise_dual_active	IOS-XE	POLICY	INTERFACE_ETHERNET	18 days ago	interface_edit_policy		2
ios_xe_int_trunk_host	IOS-XE	POLICY	INTERFACE_GIGABITE...	18 days ago	interface_edit_policy	Interface template for creating a trunk switchport on CAT9000 switches	202
ios_xe_int_routed_host	IOS-XE	POLICY	INTERFACE_GIGABITE...	18 days ago	interface_edit_policy	Interface template for creating a L3/routed port on CAT9000 switches	0
ios_xe_int_port_channel_trunk_host	IOS-XE	POLICY	INTERFACE_PORT_CH...	18 days ago	interface_edit_policy	Interface template for creating a port-channel trunk port on CAT9000 switches	0
ios_xe_int_port_channel_access_host	IOS-XE	POLICY	INTERFACE_PORT_CH...	18 days ago	interface_edit_policy	Interface template for creating a port-channel access port on CAT9000 switches	0

You can make a copy of any of these templates and customize them as per their needs. That is the typical use-case for customization. **Do not** modify existing policies but make a copy, and then customize as per the requirements. Otherwise, after a DCNM upgrade, the changes may be lost.

In general, a template already in use, meaning one that is already applied to some switch within any fabric, cannot be edited.



**Note** No Type-CLI templates are used in the Fabric Controller persona only. They are all replaced with more powerful Policy templates which are a super set.

## Fabric Template

A fabric template is basically a python template, specifically jython, which is java + python. A fabric template is quite comprehensive, and in that it embeds the rules that are required for deploying a fabric, including all the logic required to generate intended configuration of all switches within the entire fabric. Configuration is generated based on published Cisco best practice guidelines. In addition to the embedded rules, the fabric template also integrates with other entities such as resource manager, topology database, device roles, configuration compliance, etc. and generates the configuration accordingly for all the devices in the fabric. This is the inherent part of NDFC fabrics.

Name	Supported Platforms	Type	Sub Type	Modified	Tags	Description	Reference Count
Easy_Fabric	All	FABRIC	NA	18 days ago	Data Center VXLAN EVPN	Fabric for a VXLAN EVPN deployment with Nexus 9000 and 3000 switches.	0
Easy_Fabric_Classic	All	FABRIC	NA	18 days ago	Enhanced Classic LAN	Fabric for a fully automated 3-tier Classic LAN deployment with Nexus 9000 and 7000 switches.	0
Easy_Fabric_IOS_XE	IOS-XE	FABRIC	NA	18 days ago	Campus VXLAN EVPN	Fabric for a VXLAN EVPN Campus deployment with Catalyst 9000 switches and Nexus 9000 switches.	0
Easy_Fabric_eBGP	All	FABRIC	NA	18 days ago	BGP Fabric	Fabric for an eBGP based deployment with Nexus 9000 and 3000 switches. Optionally VXLAN EVPN can be enabled on top of the eBGP underlay.	0
External_Fabric	All	FABRIC	NA	18 days ago	Flexible Network	Fabric for flexible deployments with a mix of Nexus and Non-Nexus devices.	0
Fabric_Group	All	FABRIC	NA	18 days ago	Fabric Group	Domain that can contain Enhanced Classic LAN, Classic LAN, and External Connectivity Network fabrics.	0
LAN_Classic	All	FABRIC	NA	18 days ago	Classic LAN	Fabric to manage a legacy Classic LAN deployment with Nexus switches.	0
LAN_Monitor	All	FABRIC	NA	18 days ago	LAN Monitor	Fabric for monitoring Nexus switches for basic discovery and inventory management.	0
MSD_Fabric	All	FABRIC	NA	18 days ago	VXLAN EVPN Multi-Site	Domain that can contain multiple VXLAN EVPN Fabrics with Layer-2/Layer-3 Overlay Extensions and other Fabric Types.	0
Meta	All	FABRIC	NA	18 days ago	Internal_policy	Fabric that represents remote NDFC fabrics managed by Nexus Dashboard Orchestrator.	0

The expectation is that users will not create their own fabric templates. NDFC provides a few fabric templates out of the box such as Easy Fabric, External Fabric, MSD Fabric, eBGP Fabric, and so on.

## Profile Template

A profile template is used for provisioning of overlays (networks or VRFs). The idea is that when you apply some overlay configuration, there are multiple pieces of configurations that should go together. For example, valid layer-3 network configuration in a VXLAN EVPN fabric requires VLAN, SVI, int nve config, EVPN route-target, etc. All of these pieces are put together into what is called a configuration profile (NX-OS construct) and then effectively applied at one go. Either the whole configuration profile gets applied or nothing gets applied, on the switch. In this way, you are not left with any dangling or stray configurations on the switches. For any kind of overlay configurations, whether it is on the leaf or on the borders, NDFC employs profile templates.

There are four kinds of profile templates that are distinguished with tags as depicted below:

- Network Profile (applied to all devices with role leaf)
- Network Extension Profile (applied to all devices with role ‘border\*’)
- VRF Profile (applied to all devices with role leaf)
- VRF Extension Profile (applied to all devices with role ‘border\*’)

Templates

Type contains Profile x

Name	Supported Platforms	Type	Sub Type	Modified	Tags	Description	Reference Count
<input type="checkbox"/> Default_Network_Extension_Universal	AII,IOS-XE	PROFILE	VXLAN	18 days ago	networkExtension, xeNetwork	Default Network Universal Template for Borders	4
<input type="checkbox"/> Default_Network_Universal	AII,IOS-XE	PROFILE	VXLAN	18 days ago	xeNetwork, network	Default Network Universal Template	6
<input type="checkbox"/> Default_VRF_Extension_Universal	AII,IOS-XE	PROFILE	VXLAN	18 days ago	xeVrf, vrfExtension	Default VRF Universal Template for Borders	7
<input type="checkbox"/> Default_VRF_Universal	AII,IOS-XE	PROFILE	VXLAN	18 days ago	xeVrf, vrf	Default VRF Universal Template for Leafs	8
<input type="checkbox"/> Network_Classic	All	PROFILE	VLAN	18 days ago	network_extension, network	Network definition for Classic Easy Fabrics	0
<input type="checkbox"/> Pvlan_Secondary_Network	All	PROFILE	VXLAN	18 days ago	pvlanSecNetwork, pvlanSecNetworkExtension	PVLAN Secondary Network Template	0
<input type="checkbox"/> Routed_Network_Universal	All	PROFILE	VXLAN	18 days ago	routedNetwork	Routed Network Universal Template	0
<input type="checkbox"/> Service_Network_Universal	N9K	PROFILE	SERVICE	18 days ago	network	Default Service Network Universal Template	0
<input type="checkbox"/> VRF_Classic	All	PROFILE	VLAN	18 days ago	vrfExtension, vrf	VRF Definition For Classic Easy Fabrics	0
<input type="checkbox"/> base_external_router	N9K	PROFILE	VXLAN	18 days ago		set up base coconfiguration for core and edge routers	0
<input type="checkbox"/> ext_fabric_multisite_intf_11_1	All	PROFILE	VXLAN	18 days ago		interface template for the source/destination interface of an underlay iFC for Multi-Site	0
<input type="checkbox"/> ext_mpls_overlay	All	PROFILE	VXLAN	18 days ago	multiSiteOverlay		0
<input type="checkbox"/> ext_multisite_overlay_setup_11_1	All	PROFILE	VXLAN	18 days ago	multiSiteOverlay		4
<input type="checkbox"/> ext_multisite_rs_base_feature	N9K,N7K	PROFILE	VXLAN	18 days ago	multiSiteOverlay	set up base features for route server	0
<input type="checkbox"/> ext_multisite_rs_base_setup	N9K	PROFILE	VXLAN	18 days ago	multiSiteOverlay	set up base configurations for route server	0
<input type="checkbox"/> service_network_template	N9K	PROFILE	VXLAN	18 days ago		Network level template for processing services configuration during network attachment and detachment	0
<input type="checkbox"/> service_vrf_template	N9K	PROFILE	VXLAN	18 days ago		VRF level template for processing services configuration during VRF attachment and detachment	0
<input type="checkbox"/> vxlan_mpls_overlay	All	PROFILE	VXLAN	18 days ago	vxlanMplsOverlay		0

For more information about how to apply overlay configuration via the Networks & VRFs workflow in NDFC, see *Creating and Deploying Networks and VRFs* section.

### Additional Notes

When a policy or profile template is applied, an instance is created for each application of the template. The common terminology used for this is Policy Template Instance or PTI. A PTI is effectively a policy or profile template + the Name-value pairs that give it a specific instance, post substitution. PTIs created for a device can be viewed under the View/Edit policies option for that device in Fabric Builder. In the tabular view, the View/Edit policies button allows selection and bulk creation/deletion of policies across a subset of devices in the entire fabric. For more information, see *Viewing and Editing Policies* section.

## Changing the Contents of a Template in Use

A template in general, whether it is a policy, fabric or profile template, cannot be modified once it has been instantiated. However, there could be cases where you want to edit the content of a template, like fixing a bug in the template or changing an already deployed config. This can be achieved by toggling the **Template In-Use Override** option in **Settings > Server Settings > LAN-Fabric** tab.

### Procedure

- Step 1** Under the **LAN-Fabric** tab in **Server Settings**, check the **Template In-Use Override** check box.

Server Settings

Alarms Events Reports **LAN-Fabric** Discovery SSH VMM SNMP Admin SMTP Debug

Disable Deployment across all Fabrics

HTML Sanitization Mode\*  
 loose Mode for device intent configuration allowing special characters based on OWASP guidelines

Maximum Backups per Fabric\*  
 2 Maximum number of backups that we can have per fabric. Reducing this value may delete residual backups if current # of backups exceeds the new limit

Template In-Use Override  
 When enabled, blocks edits for predefined templates as well as those which are referenced by active policies

Template Validation Error Checking  
 Performs server side input validation for all templates

Template Validation Error Bypass  
 Allow usage of templates with input validation error failures

Save Switch Configuration Interval in minutes\*  
 120 How often the device running configuration is persisted

Save Switch Configuration Quiet Time in minutes\*  
 30 Quiet Time needed on a switch after last change before device running configuration is persisted

Periodic Configuration Compliance Run Interval in minutes\*  
 1440

Save

**Step 2** Click **Save**.

**Step 3** Edit the desired template(s).

**Step 4** Go to Fabrics Overview and click **Recalculate and Deploy**.

This will regenerate PTIs and the updated content will be picked up and used for the expected configuration (or intent).

**Step 5** After the contents are re-generated and deployed, uncheck the **Template In-Use Override** check box to avoid performance issues.