



# Deploying Cisco Nexus Data Broker Software in Clusters

---

This chapter contains the following details:

- [Installing a Cisco Nexus Data Broker Cluster](#) , on page 1
- [Upgrading a Cisco Nexus Data Broker Cluster](#), on page 3

## Installing a Cisco Nexus Data Broker Cluster

Use this procedure to install a Cisco NDB cluster.

### Before you begin

Prerequisites:

- Cisco NDB supports 2-node and 3-node clusters.
- All IP addresses must be reachable and capable of communicating with each other.
- All switches in the cluster must connect to all the controllers.
- All controllers must have the same HA clustering configuration information in the `config.ini` files.
- All the NDB instances should be of the same NDB version to form the cluster.
- If using cluster passwords, all controllers must have the same password configured in the `ndbjgroups.xml` file. See *Password Protecting for HA Clusters* section in the *Cisco Nexus Data Broker Configuration Guide*.



---

**Note** All the NDB instances to form the cluster should be of the same NDB version.

---

### Procedure

---

**Step 1** In a web browser, navigate to [www.cisco.com](http://www.cisco.com).

**Step 2** Navigate to **Support > Products > Downloads**.

**Step 3** In the **Find Products and Downloads** search box, enter *Nexus Data Broker* and click **Downloads** from the displayed list.

The file information for Release 3.10 is displayed: Cisco Nexus Data Broker Software Application:  
 ndb1000-sw-app-k9-3.10.0.zip

**Step 4** Download the Cisco Nexus Data Broker application bundle. If prompted, enter your Cisco.com username and password to login.

**Step 5** Create a directory in your Linux machine where you plan to install Cisco Nexus Data Broker.

For example, in your Home directory, create `CiscoNDB`.

**Step 6** Copy the Cisco Nexus Data Broker zip file to the created NDB directory.

**Step 7** Unzip the Cisco Nexus Data Broker zip file.

The Cisco Nexus Data Broker software is installed in a directory called `ndb`. The directory contains the following:

- `runndb.sh` file—file to launch NDB.
- `version.properties` file—NDB build version.
- configuration directory—contains the NDB initialization files. This directory also contains the startup subdirectory where configurations are saved.
- `bin` directory—contains the NDB file that has the NDB common CLI.
- `etc` directory—contains profile information.
- `lib` directory—contains NDB Java libraries.
- `logs` directory—contains NDB logs.

**Note**

The logs directory is created after the NDB application is started.

- `plugins` directory—The directory that contains the NDB plugins.
- `work` directory—webserver working directory.

**Step 8** Navigate to the `ndb/configuration` directory that was created when you installed the software.

**Step 9** Use any text editor to open the `config.ini` file and locate the following text:

```
# HA Clustering configuration (semi-colon-separated IP addresses of all controllers that are part
of the cluster.)
# supernodes=<ip1>;<ip2>;<ip3>;<ipn>
```

**Step 10** Uncomment the line which consists of supernodes and replace `<ip*>` with NDB Server IPs.

```
IPv4 example:
# HA Clustering configuration (semi-colon-separated IP addresses of all controllers that are part
of the cluster.)
supernodes=10.1.1.1;10.2.1.1;10.3.1.1
```

```
IPv6 example:
# HA Clustering configuration (semi-colon-separated IP addresses of all controllers that are part
of the cluster.)
supernodes=2001:22:11::1;2001:33::44::1;2001:55:66::1
```

- Step 11** Save the file and exit the editor.
- Step 12** Repeat steps 5 to 11 in all the Linux machines where the NDB is installed.
- Step 13** Start the Primary NDB server using the `./runndb.sh -start` command.
- Step 14** After the GUI of the primary NDB server is up, start the other NDB servers using the `./runndb.sh -start` command.
- 

## Upgrading a Cisco Nexus Data Broker Cluster

### Before you begin

#### Prerequisites:

- Cisco NDB supports 2-node and 3-node clusters. If you configure even number of nodes, the last node is not included in the cluster formation, ensuring odd number of nodes in a setup.
- All IP addresses must be reachable and capable of communicating with each other.
- All switches in the cluster must connect to all the controllers.
- All controllers must have the same HA clustering configuration information in the `config.ini` files.
- All the NDB instances should be of the same NDB version to form the cluster.
- If using cluster passwords, all controllers must have the same password configured in the `ndbjgroups.xml` file. See *Password Protecting for HA Clusters* section in the *Cisco Nexus Data Broker Configuration Guide*.



**Note** All the NDB instances to form the cluster should be of the same NDB version.

---

### Procedure

---

- Step 1** Login to the NDB primary server.
- Step 2** Navigate to **Administration > Backup/ Restore**.
- Step 3** Click **Backup Locally** to download the configuration file.
- Step 4** Stop all NDB instances using the `runxnc.xh -stop` command.
- Step 5** If TLS certification is enabled between NDB server and NDB Devices, take backup of the `tlsTrustStore` and `tlsKeyStore` files from `/xnc/configuration`.
- Step 6** Perform the previous step on all the NDB cluster instances.
- Step 7** In a web browser, navigate to `www.cisco.com`.
- Step 8** Navigate to **Support > Products > Downloads**.
- Step 9** In the Find Products and Downloads search box, enter “Nexus Data Broker” and click on ‘Downloads’ from search response list.

The file information for Release 3.10 is displayed: Cisco Nexus Data Broker Software Application:  
 ndb1000-sw-app-k9-3.10.0.zip

**Step 10** Download the Cisco Nexus Data Broker application bundle. When prompted, enter your Cisco.com username and password to login.

**Step 11** Create a directory in your Linux machine where you plan to install Cisco NDB.  
 For example, in your Home directory, create CiscoNDB.

**Step 12** Copy the Cisco Nexus Data Broker zip file to the directory that you have created.

**Step 13** Unzip the Cisco Nexus Data Broker zip file.

The Cisco Nexus Data Broker software is installed in a directory called `ndb`. The directory contains the following:

- `runndb.sh` file—file to launch NDB.
- `version.properties` file—NDB build version.
- `configuration` directory—contains the NDB initialization files. This directory also contains the `startup` subdirectory where configurations are saved.
- `bin` directory—contains the NDB file that has the NDB common CLI.
- `etc` directory—contains profile information.
- `lib` directory—contains NDB Java libraries.
- `logs` directory—contains NDB logs.

**Note**

The logs directory is created after the NDB application is started.

- `plugins` directory—The directory that contains the NDB plugins.
- `work` directory—webserver working directory.

**Step 14** Navigate to the `ndb/configuration` directory that was created when you installed the software.

**Step 15** Use any text editor to open the `config.ini` file and locate the following text:

**Step 16** Locate the following text:

```
# HA Clustering configuration (semi-colon-separated IP addresses of all controllers that are part
of the cluster.)
# supernodes=<ip1>;<ip2>;<ip3>;<ipn>
```

**Step 17** Uncomment the line which consists of supernodes and replace `<ip*>` with NDB Server IPs.

```
IPv4 example:
# HA Clustering configuration (semi-colon-separated IP addresses of all controllers that are part
of the cluster.)
supernodes=10.1.1.1;10.2.1.1;10.3.1.1

IPv6 example:
# HA Clustering configuration (semi-colon-separated IP addresses of all controllers that are part
of the cluster.)
supernodes=2001:22:11::1;2001:33::44::1;2001:55:66::1
```

**Step 18** Save the file and exit the editor.

**Step 19** Repeat the steps 7 to 18 in all the Linux machines where the NDB is installed.

- Step 20** Start the Primary NDB server using the `./runndb.sh -start` command.
- Step 21** After the GUI of the Primary NDB Server is up, start the other NDB servers using the `./runndb.sh -start` command.
- Step 22** Login to the Primary Server NDB GUI.
- Step 23** Navigate to **Administration > Backup/Restore > Actions > Restore Locally** and upload the configuration you had earlier downloaded.
- Step 24** Stop all instances of NDB in the cluster using the `./runndb.sh -stop` command.
- Step 25** If TLS certification is enabled between NDB server and NDB switches, copy the `tls TrustStore` and `tlSKeyStore` files to `ndb/configuration` taken from the step 5 for all NDB instances.
- Step 26** Start the primary NDB server using the `./runndb.sh -start` command.
- If TLS certification is enabled, use below commands to start NDB servers.
- ```
./runndb.sh -tls -tlskeystore ./configuration/tlsKeyStore -tlstruststore ./configuration/tlsTrustStore  
bin/ndb config-keystore-passwords --user <NDB_username> --password <NDB_password> --url  
https://<Cluster_NDB_IP>:8443 --verbose --prompt --keystore-password <keystore-password>  
--truststore-password <truststore-password>
```
- Step 27** Start the member NDB server(s) using the `./runndb.sh -start` command.
- If TLS certification is enabled, use below commands to start NDB servers.
- ```
./runndb.sh -tls -tlskeystore ./configuration/tlsKeyStore -tlstruststore ./configuration/tlsTrustStore  
bin/ndb config-keystore-passwords --user <NDB_username> --password <NDB_password> --url  
https://<Cluster_NDB_IP>:8443 --verbose --prompt --keystore-password <keystore-password>  
--truststore-password <truststore-password>
```
-

