



Configuring MPLS Label Imposition

This chapter contains information on how to configure multiprotocol label switching (MPLS) label imposition.

- [About MPLS Label Imposition, on page 1](#)
- [Guidelines and Limitations for MPLS Label Imposition, on page 2](#)
- [Configuring MPLS Label Imposition, on page 2](#)
- [Verifying the MPLS Label Imposition Configuration, on page 5](#)
- [Displaying MPLS Label Imposition Statistics, on page 8](#)
- [Clearing MPLS Label Imposition Statistics, on page 9](#)
- [Configuration Examples for MPLS Label Imposition, on page 9](#)

About MPLS Label Imposition

An outgoing label stack having one or more labels can be statically provisioned using the MPLS Label Stack Imposition feature. The outgoing label stack is used in the following two types of statically configured MPLS bindings:

- **Prefix and Label to Label Stack** - Here an IP prefix or an incoming label is mapped to an outgoing stack, similar to static MPLS. An incoming prefix is mapped to out-label-stack for IP-only ingress traffic.
- **Label to Label Stack** - Here only an incoming label is mapped to an outgoing stack without any prefix.

The new MPLS binding types are implemented in the static MPLS component and are available only when the **feature mpls segment-routing** command is enabled.

If configured next-hops of MPLS label imposition are SR recursive next-hops (RNH), then they are resolved to actual next-hops using RIB. The outer label of the out-label stack is imposed automatically from the SR allocated labels.

ECMP is also supported by adding a number of path configurations.



Note The static MPLS process is started when either the **feature mpls segment-routing** command or the **feature mpls static** command is run. Certain standard static MPLS commands will not be available when static MPLS is run using the **feature mpls segment-routing** command, and the commands for MPLS bindings will not be available when the **feature mpls static** command is run.

Guidelines and Limitations for MPLS Label Imposition

MPLS label imposition has the following guidelines and limitations:

- MPLS label imposition is supported for the following:
 - Cisco Nexus 9200, 9300, 9300-EX, 9300-FX and 9500 platform switches with the 9400, 9500, 9600, 9700-EX, and 9700-FX line cards.
 - Cisco Nexus 3164Q, 31128PQ, 3232C, and 3264Q switches.
 - Beginning with Cisco NX-OS Release 9.2(1) release, it is supported on Cisco Nexus 9364C Switch.
 - Beginning with Cisco NX-OS Release 9.3(3), it is supported on Cisco Nexus 9364C-GX, 9316D-GX, and 93600CD-GX switches.
- MPLS label imposition supports only IPv4.
- The maximum number of labels in an out-label stack is five for Cisco Nexus 9200, 9300-EX, and 9300-FX platform switches and three for Cisco Nexus 9300 and 9500 platform switches and Cisco Nexus 3164Q, 31128PQ, 3232C, and 3264Q switches. If you try to impose more labels, the trailing label is truncated automatically, and a syslog error message appears signaling to correct the configuration.
- Multicast is not supported for MPLS label imposition.
- In the multi-label stack configuration, changing an outgoing path is allowed only for Cisco Nexus 9200 and 9300-EX Series switches.
- Subinterfaces and port channels are not supported for MPLS label imposition.
- Prefixes and associated subnet masks learned from routing protocols (including from static routes) cannot be used as part of the label stack imposition policy.
- For label stack imposition verified scalability limits, see the [Verified Scalability Guide](#) for your device.

Configuring MPLS Label Imposition

Enabling MPLS Label Imposition

You must install and enable the MPLS feature set and then enable the MPLS segment routing feature before you can configure MPLS label imposition.

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: <pre>switch# configure terminal switch(config)#</pre>	Enters global configuration mode.

	Command or Action	Purpose
Step 2	[no] install feature-set mpls Example: switch(config)# install feature-set mpls	Installs the MPLS feature set. The no form of this command uninstalls the MPLS feature set.
Step 3	[no] feature-set mpls Example: switch(config)# feature-set mpls	Enables the MPLS feature set. The no form of this command disables the MPLS feature set.
Step 4	[no] feature mpls segment-routing Example: switch(config)# feature mpls segment-routing	Enables the MPLS segment routing feature. The no form of this command disables the MPLS segment routing feature.
Step 5	(Optional) show feature-set Example: switch(config)# show feature-set Feature Set Name ID State ----- mpls 4 enabled	Displays the status of the MPLS feature set.
Step 6	(Optional) show feature grep segment-routing Example: switch(config)# show feature grep segment-routing segment-routing 1 enabled	Displays the status of MPLS segment routing.

Reserving Labels for MPLS Label Imposition

You can reserve the labels that are to be statically assigned. Dynamic label allocation is not supported.

Before you begin

Ensure that the MPLS segment routing feature is enabled.

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: switch# configure terminal switch(config)#	Enters global configuration mode.
Step 2	[no] mpls label range min-value max-value [static min-static-value max-static-value]	Reserves a range of labels for static label assignment.

	Command or Action	Purpose
	Example: <pre>switch(config)# mpls label range 17 99 static 100 10000</pre>	The range for the minimum and maximum values is from 16 to 471804.
Step 3	(Optional) show mpls label range Example: <pre>switch(config)# show mpls label range</pre>	Displays the label range that is configured for static MPLS.
Step 4	(Optional) copy running-config startup-config Example: <pre>switch(config)# copy running-config startup-config</pre>	Copies the running configuration to the startup configuration.

Configuring MPLS Label Imposition

You can configure MPLS label imposition on the device.



Note The feature **mpls segment-routing** command cannot be enabled when the following commands are in use: **feature nv overlay**, **nv overlay evpn**, **feature vpc**, and **feature vn-segment-vlan-based**.

Before you begin

Ensure that the MPLS segment routing feature is enabled.

Set a static label range as follows: **mpls label range 16 16 static 17 50000**.

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: <pre>switch# configure terminal switch(config)#</pre>	Enters global configuration mode.
Step 2	interface <i>type slot/port</i> Example: <pre>switch(config)# interface ethernet 2/2 switch(config-if)#</pre>	Enters the interface configuration mode for the specified interface.
Step 3	[no] mpls ip forwarding Example: <pre>switch(config-if)# mpls ip forwarding</pre>	Enables MPLS on the specified interface. The no form of this command disables MPLS on the specified interface.

	Command or Action	Purpose
Step 4	mpls static configuration Example: <pre>switch(config-if)# mpls static configuration switch(config-mpls-static)#</pre>	Enters MPLS static global configuration mode.
Step 5	address-family ipv4 unicast Example: <pre>switch(config-mpls-static)# address-family ipv4 unicast switch(config-mpls-static-af)#</pre>	Enters global address family configuration mode for the specified IPv4 address family.
Step 6	lsp name Example: <pre>switch(config-mpls-static-af)# lsp lsp1 switch(config-mpls-static-lsp)#</pre>	Specifies a name for LSP.
Step 7	in-label value allocate policy prefix Example: <pre>switch(config-mpls-static-lsp)# in-label 8100 allocate policy 15.15.1.0/24 switch(config-mpls-static-lsp-inlabel)#</pre>	Configures an in-label value and a prefix value (optional).
Step 8	forward Example: <pre>switch(config-mpls-static-lsp-inlabel)# forward switch(config-mpls-static-lsp-inlabel-forw)#</pre>	Enters the forward mode.
Step 9	path number next-hop ip-address out-label-stack label-id label-id Example: <pre>switch(config-mpls-static-lsp-inlabel-forw)# path 1 next-hop 13.13.13.13 out-label-stack 16 3000</pre>	Specifies the path. The maximum number of supported paths is 32.
Step 10	(Optional) copy running-config startup-config Example: <pre>switch(config-mpls-static-lsp-inlabel-forw)# copy running-config startup-config</pre>	Copies the running configuration to the startup configuration.

Verifying the MPLS Label Imposition Configuration

To display the MPLS label imposition configuration, perform one of the following tasks:


```

8200      3132      Label 8200
12.12.3.2
8200      3132      Label 8200
12.12.4.2
8200      3132      Label 8200
12.12.1.2
8200      3132      Label 8200
12.12.2.2

Local      Out-Label  FEC                                Out-Interface
Next-Hop
8100      3131      Pol 25.25.0.0/16
12.12.1.2
8100      3131      Pol 25.25.0.0/16
12.12.2.2
8100      3131      Pol 25.25.0.0/16
12.12.3.2
8100      3131      Pol 25.25.0.0/16
12.12.4.2

```

This example shows sample output for the **show running-config mpls static** command:

```

mpls static configuration
  address-family ipv4 unicast
    lsp LI_TEST2
      in-label 8100 allocate policy 25.25.0.0 255.255.0.0
      forward
        path 1 next-hop 12.12.1.2 out-label-stack 3131 17
        path 2 next-hop 12.12.2.2 out-label-stack 3131 17
        path 3 next-hop 12.12.3.2 out-label-stack 3131 17
        path 4 next-hop 12.12.4.2 out-label-stack 3131 17

```

This example shows sample output for the **show running-config mpls static all** command.

```

switch# show running-config mpls static all

!Command: show running-config mpls static all
!Time: Mon Aug 21 14:59:46 2017

version 7.0(3)I7(1)
logging level mpls static 5
mpls static configuration
address-family ipv4 unicast
lsp 9_label_stack_LPM
in-label 72000 allocate policy 71.200.11.0 255.255.255.0
forward
path 1 next-hop 27.1.32.4 out-label-stack 21901 29701 27401 24501 25801
lsp 9_label_stack_LPM_01
in-label 72001 allocate policy 72.201.1.1 255.255.255.255
lsp DRV-01
in-label 71011 allocate policy 71.111.21.0 255.255.255.0
forward
path 1 next-hop 27.1.31.4 out-label-stack implicit-null
lsp DRV-02
in-label 71012 allocate policy 71.111.22.0 255.255.255.0
forward
path 1 next-hop 8.8.8.8 out-label-stack 28901
lsp DRV-03
switch# show forwarding mpls label 72000

slot 1
=====

```



```

" | | | | | 17
SWAP |0x1 |25.25.0.0/16 |12.12.2.2 |Eth1/51 |3131
" | | | | | 17
SWAP |0x1 |25.25.0.0/16 |12.12.3.2 |Vlan122 |3131
" | | | | | 17
SWAP |0x1 |25.25.0.0/16 |12.12.4.2 |Vlan123 |3131
" | | | | | 17
SWAP | | | | | 17

```

```

Input Pkts : 126906012      Input Bytes : 64975876096
SWAP Output Pkts: 126959183  SWAP Output Bytes: 65764550340
TUNNEL Output Pkts: 126959053  TUNNEL Output Bytes: 66272319384

```

This example shows sample output for the **show mpls forwarding statistics** command:

```

MPLS software forwarding stats summary:
Packets/Bytes sent      : 0/0
Packets/Bytes received  : 0/0
Packets/Bytes forwarded : 0/0
Packets/Bytes originated : 0/0
Packets/Bytes consumed  : 0/0
Packets/Bytes input dropped : 0/0
Packets/Bytes output dropped : 0/0

```

Clearing MPLS Label Imposition Statistics

To clear the MPLS label imposition statistics, perform these tasks:

Command	Purpose
clear forwarding [ipv4] adjacency mpls stats	Clears the MPLS IPv4 adjacency statistics.
clear forwarding mpls stats	Clears the ingress MPLS forwarding statistics.
clear mpls forwarding statistics	Clears the MPLS forwarding statistics.
clear mpls switching label statistics [interface type slot/port]	Clears the MPLS switching label statistics.

Configuration Examples for MPLS Label Imposition

This example shows how to configure MPLS label imposition by allocating a prefix and an incoming-label to out-label-stack binding:

```

switch(config-if) # mpls static configuration
switch(config-mpls-static) # address-family ipv4 unicast
switch(config-mpls-static-af) # lsp LI_TEST1
switch(config-mpls-static-lsp) # in-label 8100 allocate policy 25.25.0.0/16
switch(config-mpls-static-lsp-inlabel) # forward
switch(config-mpls-static-lsp-inlabel-forw) # path 1 next-hop 12.12.1.2 out-label-stack 3131
17
switch(config-mpls-static-lsp-inlabel-forw) # path 2 next-hop 12.12.2.2 out-label-stack 3131

```

```

17
switch(config-mpls-static-lsp-inlabel-forw) # path 3 next-hop 12.12.3.2 out-label-stack 3131
17
switch(config-mpls-static-lsp-inlabel-forw) # path 4 next-hop 12.12.4.2 out-label-stack 3131
17

```

To remove a next-hop, you can use

```
no path 1
```

To remove the named lsp, you can use

```
no lsp LI_TEST1
```

This example shows how to configure MPLS label imposition by allocating an incoming-label to out-label-stack binding (no prefix):

```

switch(config-if) # mpls static configuration
switch(config-mpls-static) # address-family ipv4 unicast
switch(config-mpls-static-af) # lsp LI_TEST1
switch(config-mpls-static-lsp) # in-label 8200 allocate
switch(config-mpls-static-lsp-inlabel) # forward
switch(config-mpls-static-lsp-inlabel-forw) # path 1 next-hop 12.12.3.2 out-label-stack 3132
16
switch(config-mpls-static-lsp-inlabel-forw) # path 2 next-hop 12.12.4.2 out-label-stack 3132
16
switch(config-mpls-static-lsp-inlabel-forw) # path 3 next-hop 12.12.1.2 out-label-stack 3132
16
switch(config-mpls-static-lsp-inlabel-forw) # path 4 next-hop 12.12.2.2 out-label-stack 3132
16

```