



Troubleshooting Installations, Upgrades, and Reboots

- [About Upgrades and Reboots, on page 1](#)
- [Upgrade and Reboot Checklist, on page 1](#)
- [Verifying Software Upgrades, on page 2](#)
- [Troubleshooting Software Upgrades and Downgrades, on page 3](#)
- [Troubleshooting Software System Reboots, on page 4](#)
- [Changing the Administrator Password, on page 15](#)

About Upgrades and Reboots

Upgrades and reboots are ongoing network maintenance activities. You should try to minimize the risk of disrupting the network when performing these operations in production environments and to know how to recover quickly when something does go wrong.



Note

This publication uses the term upgrade to refer to both Cisco NX-OS upgrades and downgrades.

Upgrade and Reboot Checklist

Use the following checklist to prepare for an upgrade or reboot:

Checklist	Done
Read the Release Notes for the release to which you are upgrading or downgrading.	
Ensure that an FTP or TFTP server is available to download the software image.	
Copy the new image onto your supervisor modules in bootflash: or slot0:.	
Use the show install all impact command to verify that the new image is healthy and the impact that the new load will have on any hardware with regard to compatibility. Check for compatibility.	
Copy the startup-config file to a snapshot configuration in NVRAM. This step creates a backup copy of the startup configuration file.	

Checklist	Done
Save your running configuration to the startup configuration.	
Back up a copy of your configuration to a remote TFTP server.	
Schedule your upgrade during an appropriate maintenance window for your network.	

After you have completed the checklist, you are ready to upgrade or reboot the systems in your network.



Note It is normal for the active supervisor to become the standby supervisor during an upgrade.



Note Up to 100 log messages with a severity level of critical and below (levels 0, 1, and 2) are saved in NVRAM. You can view this log at any time by entering the **show logging nvram** command.

Verifying Software Upgrades

You can use the **show install all status** command to watch the progress of your software upgrade or to view the ongoing **install all** command or the log of the last installed **install all** command from a console, SSH, or Telnet session. This command shows the **install all** output on both the active and standby supervisor module even if you are not connected to the console terminal.

Troubleshooting Software Upgrades and Downgrades

Software Upgrade Ends with Error

Problem	Possible Cause	Solution
The upgrade ends with an error	The standby supervisor module bootflash: file system does not have sufficient space to accept the updated image.	Use the delete command to remove unnecessary files from the file system.
	The install all command is entered on the standby supervisor module.	Enter the command on the active supervisor module only.
	A module was inserted while the upgrade was in progress.	Restart the installation.
	The system experienced a power disruption while the upgrade was in progress.	Restart the installation.
	An incorrect software image path was specified.	Specify the entire path for the remote location accurately.
	Another upgrade is already in progress.	Verify the state of the system at every stage and restart the upgrade after 10 seconds. If you restart the upgrade within 10 seconds, the command is rejected. An error message displays, indicating that an upgrade is currently in progress.
	A module failed to upgrade.	Restart the upgrade or use the install module command to upgrade the failed module.

Upgrading the Cisco NX-OS Software

You can perform an automated software upgrade on any system from the CLI.

Before you begin

Log into the system through the console, Telnet, or SSH port of the active supervisor.

Create a backup of your existing configuration file, if required.

SUMMARY STEPS

1. **install all** [nxos bootflash:filename]
2. **show module**

DETAILED STEPS

Procedure

	Command or Action	Purpose
Step 1	install all [nxos bootflash:filename]	<p>Performs the upgrade.</p> <p>Note If the configuration meets all guidelines when the install all command is used, all modules (supervisor and switching) are upgraded.</p> <p>Note If you enter the install all command without specifying a filename, the command performs a compatibility check, notifies you of the modules that will be upgraded, and confirms that you want to continue with the installation. If you choose to proceed, it installs the NXOS software image that is currently running on the switch and upgrades the BIOS of various modules from the running image if required.</p>
Step 2	show module	Exits the system console and opens a new terminal session to view the upgraded supervisor module.

Troubleshooting Software System Reboots

Power-On or Switch Reboot Hangs

Problem	Possible Cause	Solution
A power-on or switch reboot hangs for a dual supervisor configuration	The bootflash is corrupted.	See Corrupted Bootflash Recovery, on page 5 .
	The BIOS is corrupted.	Replace this module. Contact your customer support representative to return the failed module.
	The nx-os image is corrupted.	Power cycle the switch if required and press Ctrl-C when the switch displays the "Loading Boot Loader" message to interrupt the boot process at the >loader prompt.
	Boot parameters are incorrect.	Verify and correct the boot parameters and reboot.

Corrupted Bootflash Recovery

All device configurations reside in the internal bootflash. If you have a corrupted internal bootflash, you could potentially lose your configuration. Be sure to save and back up your configuration files periodically. The regular system boot goes through the following sequence:

1. The basic input/output system (BIOS) loads the loader.
2. The loader loads the nx-os image into RAM and starts the image.
3. The nx-os image reads the startup configuration file.

If the nx-os image on your system is corrupted and you cannot proceed (error state), you can interrupt the system boot sequence and recover the image by entering the BIOS configuration utility described in the following section. Access this utility only when needed to recover a corrupted internal disk.



Caution The BIOS changes explained in this section are required only to recover a corrupted bootflash.

Recovery procedures require the regular sequence to be interrupted. The internal sequence goes through three phases between the time that you turn on the system and the time that the system prompt appears on your terminal—BIOS, boot loader, and nx-os image. The following table describes the steps in the recovery interruption process.

Table 1: Recovery Interruption

Phase	Normal Prompt (appears at the end of each phase)	Recovery Prompt (appears when the system cannot progress to the next phase)	Description
BIOS	loader>	No bootable device	The BIOS begins the power-on self test, memory test, and other operating system applications. While the test is in progress, press Ctrl-C to enter the BIOS configuration utility and use the netboot option.
Boot loader	Starting nx-os	loader>	The boot loader uncompresses the loaded software to boot an image using its filename as a reference. The image is made available through bootflash. When the memory test is over, press Esc to enter the boot loader prompt.

Phase	Normal Prompt (appears at the end of each phase)	Recovery Prompt (appears when the system cannot progress to the next phase)	Description
nx-os image	Uncompressing system	switch(boot)#	<p>When the boot loader phase is over, press Ctrl-] (Control key plus right bracket key) to enter the switch(boot)# prompt. Depending on your Telnet client, these keys might be reserved, and you might need to remap the keystroke. See the documentation provided by your Telnet client. If the corruption causes the console to stop at this prompt, copy the nx-os image and reboot the system.</p> <p>The nx-os image then loads the configuration file of the last saved running configuration and returns a switch login prompt.</p>

Recovery from the loader> Prompt

Use the **help** command at the loader> prompt to display a list of commands available at this prompt or to obtain more information about a specific command in that list.

Before you begin

This procedure uses the **init system** command, which reformats the file system of the device. Be sure that you have made a backup of the configuration files before you begin this procedure.

The loader> prompt is different from the regular switch# or switch(boot)# prompt. The CLI command completion feature does not work at the loader> prompt and might result in undesired errors. You must type the command exactly as you want the command to appear.

If you boot over TFTP from the loader> prompt, you must supply the full path to the image on the remote server.

SUMMARY STEPS

1. loader> **set ip** *ip-address*
2. loader> **set gw** *gw-address*
3. loader> **cmdline recoverymode=1**
4. loader> **boot tftp:** *tftp-path*
5. switch(boot)# **init system**
6. switch(boot)# **load-nxos**

DETAILED STEPS

Procedure

	Command or Action	Purpose
Step 1	loader> set ip <i>ip-address</i> Example: loader> set ip 172.21.55.213 255.255.255.224	Specifies the local IP address and the subnet mask for the system.
Step 2	loader> set gw <i>gw-address</i> Example: loader> set gw 172.21.55.193	Specifies the IP address of the default gateway.
Step 3	loader> cmdline recoverymode=1 Example: loader> cmdline recoverymode=1	Configures the boot process to stop at the switch(boot)# prompt.
Step 4	loader> boot tftp: <i>tftp-path</i> Example: loader> boot tftp://172.28.255.18/tftpboot/n9000-dk9.6.1.2.I1.1.bin	Boots the nx-os image file from the required server. The switch(boot)# prompt indicates that you have a usable nx-os image.
Step 5	switch(boot)# init system Example: switch(boot)# init system	Enters the nx-os system. Caution Be sure that you have made a backup of the configuration files before you enter this command.
Step 6	switch(boot)# load-nxos Example: switch(boot)# load-nxos	Completes the upload of the nx-os image file.

Example

This example shows how to configure the local IP address and the subnet mask for the system:

```

loader> set ip 172.21.55.213 255.255.255.224
set ip 172.21.55.213 255.255.255.224
Correct - ip addr is 172.21.55.213, mask is 255.255.255.224
Found Intel 82546GB [2:9.0] at 0xe040, ROM address 0xf980
Probing...[Intel 82546GB]
Management interface
Link UP in 1000/full mode
Ethernet addr: 00:1B:54:C1:28:60
Address: 172.21.55.213
Netmask: 255.255.255.224
Server: 0.0.0.0
Gateway: 172.21.55.193

```

This example shows how to configure the IP address of the default gateway:

```
loader> set gw 172.21.55.193
Correct gateway addr 172.21.55.193
Address: 172.21.55.213
Netmask: 255.255.255.224
Server: 0.0.0.0
Gateway: 172.21.55.193
```

This example shows how to boot the nx-os image from the server:

```
loader> boot tftp://172.28.255.18/tftpboot/n9000-dk9.6.1.2.I1.1.bin
Address: 172.21.55.213
Netmask: 255.255.255.224
Server: 172.28.255.18
Gateway: 172.21.55.193
Filesystem type is tftp, using whole disk
Booting: /tftpboot/n9000-dk9.6.1.2.I1.1.gbin console=ttyS0,9600n8nn quiet loader
_ver="3.17.0"....
.....Image verification OK

Starting kernel...
INIT: version 2.85 booting
Checking all filesystems..r.r.r.. done.
Setting kernel variables: sysctlnet.ipv4.ip_forward = 0
net.ipv4.ip_default_ttl = 64
net.ipv4.ip_no_pmtu_disc = 1
.
Setting the System Clock using the Hardware Clock as reference...System Clock set. Local
time: Wed Oct 1
11:20:11 PST 2013
WARNING: image sync is going to be disabled after a loader netboot
Loading system software
No system image Unexporting directories for NFS kernel daemon...done.
INIT: Sending processes the KILL signal
Cisco Nexus Operating System (NX-OS) Software
TAC support: http://www.cisco.com/tac
Copyright (c) 2013, Cisco Systems, Inc. All rights reserved.
The copyrights to certain works contained in this software are
owned by other third parties and used and distributed under
license. Certain components of this software are licensed under
the GNU General Public License (GPL) version 2.0 or the GNU
Lesser General Public License (LGPL) Version 2.1. A copy of each
such license is available at
http://www.opensource.org/licenses/gpl-2.0.php and
http://www.opensource.org/licenses/lgpl-2.1.php
switch(boot)#
```

System or Process Restarts

When a recoverable or nonrecoverable error occurs, the system or a process on the system might reset. This table lists possible causes and solutions.

Problem	Possible Cause	Solution
The system or a process on the system resets.	A recoverable error occurred on the system or on a process in the system.	The system has automatically recovered from the problem. See Recovering System Restarts, on page 9 .
	A nonrecoverable error occurred on the system.	The system cannot recover automatically from the problem. See Recovering System Restarts, on page 9 to determine the cause.
	A clock module failed.	Verify that a clock module failed. Replace the failed clock module during the next maintenance window.

Recovering System Restarts

Every process restart generates a syslog message and a Call Home event. Even if the event does not affect service, you should identify and resolve the condition immediately because future occurrences could cause a service interruption.



Note After following the steps, determine the cause and resolution for the restart condition by contacting your technical support representative and asking the representative to review your core dump.

Before you begin

The following conditions apply:

- The system automatically copies the core files to a TFTP server every 4 minutes. This time interval is not configurable.
- The copy of a specific core file to a TFTP server can be manually triggered by using the **copy core://module#/pid# tftp://tftp_ip_address/file_name** command.
- If a supervisor failover occurs, the cores might be in the secondary logflash rather than the primary logflash.
- The maximum number of times that a process can be restarted is part of the high-availability (HA) policy for any process. (This parameter is not configurable.) If the process restarts more than the maximum number of times, the older core files are overwritten.
- The maximum number of core files that can be saved for any process is part of the HA policy for any process. (This parameter is not configurable, and it is set to three.)

SUMMARY STEPS

1. switch# **show log | include error**
2. switch# **show processes**
3. switch# **show process log**
4. switch# **show process log pid pid**
5. switch# **show system uptime**

6. switch# **show cores**
7. switch# **copy core:** *core path*
8. switch# **show processes log pid** *pid*
9. switch# **system cores tftp:** *tftp-path*

DETAILED STEPS

Procedure

	Command or Action	Purpose
Step 1	<p>switch# show log include error</p> <p>Example:</p> <pre>switch# show log logfile include error Sep 10 23:31:31 dot-6 % LOG_SYSMGR-3-SERVICE_TERMINATED: Service "sensor" (PID 704) has finished with error code SYSMGR_EXITCODE_SY. switch# show logging logfile include fail Jan 27 04:08:42 88 %LOG_DAEMON-3-SYSTEM_MSG: bind() fd 4, family 2, port 123, ad dr 0.0.0.0, in_classd=0 flags=1 fails: Address already in use Jan 27 04:08:42 88 %LOG_DAEMON-3-SYSTEM_MSG: bind() fd 4, family 2, port 123, ad dr 127.0.0.1, in_classd=0 flags=0 fails: Address already in use Jan 27 04:08:42 88 %LOG_DAEMON-3-SYSTEM_MSG: bind() fd 4, family 2, port 123, ad dr 127.1.1.1, in_classd=0 flags=1 fails: Address already in use Jan 27 04:08:42 88 %LOG_DAEMON-3-SYSTEM_MSG: bind() fd 4, family 2, port 123, ad dr 172.22.93.88, in_classd=0 flags=1 fails: Address already in use Jan 27 23:18:59 88 % LOG_PORT-5-IF_DOWN: Interface fc1/13 is down (Link failure or not-connected) Jan 27 23:18:59 88 % LOG_PORT-5-IF_DOWN: Interface fc1/14 is down (Link failure or not-connected) Jan 28 00:55:12 88 % LOG_PORT-5-IF_DOWN: Interface fc1/1 is down (Link failure or not-connected) Jan 28 00:58:06 88 % LOG_ZONE-2-ZS_MERGE_FAILED: Zone merge failure, Isolating port fc1/1 (VSAN 100) Jan 28 00:58:44 88 % LOG_ZONE-2-ZS_MERGE_FAILED: Zone merge failure, Isolating port fc1/1 (VSAN 100) Jan 28 03:26:38 88 % LOG_ZONE-2-ZS_MERGE_FAILED: Zone merge failure, Isolating port fc1/1 (VSAN 100) Jan 29 19:01:34 88 % LOG_PORT-5-IF_DOWN: Interface fc1/1 is down (Link failure or not-connected) switch#</pre>	Displays the syslog file so you can see which process restarted and why it restarted.

	Command or Action	Purpose
Step 2	<p>switch# show processes</p> <p>Example:</p> <pre>switch# show processes PID State PC Start_cnt TTY Process ----- 1 S 2ab8e33e 1 - init 2 S 0 1 - keventd 3 S 0 1 - ksoftirqd_CPU0 4 S 0 1 - kswapd 5 S 0 1 - bdflood 6 S 0 1 - kupdated 71 S 0 1 - kjournald 136 S 0 1 - kjournald 140 S 0 1 - kjournald 431 S 2abe333e 1 - httpd 443 S 2abfd33e 1 - xinetd 446 S 2acle33e 1 - sysmgr 452 S 2abe91a2 1 - httpd 453 S 2abe91a2 1 - httpd 456 S 2ac73419 1 S0 vsh 469 S 2abe91a2 1 - httpd 470 S 2abe91a2 1 - httpd</pre>	<p>Displays the processes that are running and the status of each process.</p> <p>The following codes are used in the system output for the state (process state):</p> <ul style="list-style-type: none"> • D = uninterruptible sleep (usually I/O) • R = runnable (on run queue) • S = sleeping • T = traced or stopped • Z = defunct (zombie) process • NR = not running • ER = should be running but currently not running <p>Note ER usually is the state that a process enters if it has been restarted too many times and has been detected as faulty by the system and disabled.</p>
Step 3	<p>switch# show process log</p> <p>Example:</p> <pre>switch# show process log Process PID Normal-exit Stack-trace Core Log-create-time ----- ntp 919 N N N Jan 27 04:08 snsm 972 N Y N Jan 24 20:50</pre>	<p>Displays the processes that have had abnormal exits and if there is a stack-trace or core dump.</p>
Step 4	<p>switch# show process log pid <i>pid</i></p> <p>Example:</p> <pre>switch# show processes log pid 898 Service: idehsd Description: ide hotswap handler Daemon Started at Mon Sep 16 14:56:04 2013 (390923 us) Stopped at Thu Sep 19 14:18:42 2013 (639239 us) Uptime: 2 days 23 hours 22 minutes 22 seconds Start type: SRV_OPTION_RESTART_STATELESS (23) Death reason: SYSMGR_DEATH_REASON_FAILURE_SIGTERM (3) Exit code: signal 15 (no core) CWD: /var/sysmgr/work Virtual Memory: CODE 08048000 - 0804D660</pre>	<p>Displays detailed information about a specific process that has restarted.</p>

	Command or Action	Purpose
	<pre> DATA 0804E660 - 0804E824 BRK 0804E9A0 - 08050000 STACK 7FFFFFFD10 Register Set: EBX 00000003 ECX 0804E994 EDX 00000008 ESI 00000005 EDI 7FFFFFFC9C EBP 7FFFFFFCAC EAX 00000008 XDS 0000002B XES 0000002B EAX 00000003 (orig) EIP 2ABF5EF4 XCS 00000023 EFL 00000246 ESP 7FFFFFFC5C XSS 0000002B Stack: 128 bytes. ESP 7FFFFFFC5C, TOP 7FFFFFFD10 0x7FFFFFFC5C: 0804F990 0804C416 00000003 0804E994 0x7FFFFFFC6C: 00000008 0804BF95 2AC451E0 2AAC24A4Q.*.\$.* 0x7FFFFFFC7C: 7FFFFFFD14 2AC2C581 0804E6BC 7FFFFFFCA8*..... 0x7FFFFFFC8C: 7FFFFFFC94 00000003 00000001 00000003 0x7FFFFFFC9C: 00000001 00000000 00000068 00000000h..... 0x7FFFFFFCAC: 7FFFFFFCE8 2AB4F819 00000001 7FFFFFFD14*..... 0x7FFFFFFCBC: 7FFFFFFD1C 0804C470 00000000 7FFFFFFCE8P..... 0x7FFFFFFCCC: 2AB4F7E9 2AAC1F00 00000001 08048A2C ...*.....*,... PID: 898 SAP: 0 UUID: 0 switch# </pre>	
Step 5	<pre> switch# show system uptime Example: switch# show system uptime Start Time: Fri Sep 13 12:38:39 2013 Up Time: 0 days, 1 hours, 16 minutes, 22 seconds </pre>	<p>Displays if the restart recently occurred.</p> <p>To determine if the restart is repetitive or a one-time occurrence, compare the length of time that the system has been up with the timestamp of each restart.</p>
Step 6	<pre> switch# show cores Example: switch# show cores Module Instance Process-name PID Date(Year-Month-Day Time) ----- 28 1 bgp-64551 5179 2013-09-13 23:51:26 </pre>	Displays all cores that are presently available for upload from the active supervisor.
Step 7	<pre> switch# copy core: core path Example: switch# copy core://5/1524 tftp://1.1.1.1/abcd </pre>	Copies the FSPF core dump to a TFTP server with an IP address.

	Command or Action	Purpose
Step 8	<pre>switch# show processes log pid pid</pre> <p>Example:</p> <pre>switch# '''show processes log pid 1473'''</pre> <pre>=====</pre> <pre>Service: ips Description: IPS Manager Started at Tue Jan 8 17:07:42 2013 (757583 us) Stopped at Thu Jan 10 06:16:45 2013 (83451 us) Uptime: 1 days 13 hours 9 minutes 9 seconds Start type: SRV_OPTION_RESTART_STATELESS (23) Death reason: SYSMGR_DEATH_REASON_FAILURE_SIGNAL (2) Exit code: signal 6 (core dumped) CWD: /var/sysmgr/work Virtual Memory: CODE 08048000 - 080FB060 DATA 080FC060 - 080FCBA8 BRK 081795C0 - 081EC000 STACK 7FFFFFFC0 TOTAL 20952 KB Register Set: EBX 000005C1 ECX 00000006 EDX 2AD721E0 ESI 2AD701A8 EDI 08109308 EBP 7FFFFFF2EC EAX 00000000 XDS 0000002B XES 0000002B EAX 00000025 (orig) EIP 2AC8CC71 XCS 00000023 EFL 00000207 ESP 7FFFFFF2C0 XSS 0000002B Stack: 2608 bytes. ESP 7FFFFFF2C0, TOP 7FFFFFFC0 0x7FFFFFF2C0: 2AC8C944 000005C1 00000006 2AC735E2 D...*.....5.* 0x7FFFFFF2D0: 2AC8C92C 2AD721E0 2AAB76F0 00000000 ,...*!.*.v.*.... 0x7FFFFFF2E0: 7FFFFFF320 2AC8C920 2AC513F8 7FFFFFF42C*...*,... 0x7FFFFFF2F0: 2AC8E0BB 00000006 7FFFFFF320 00000000 ...*..... 0x7FFFFFF300: 2AC8DFF8 2AD721E0 08109308 2AC65AFC ...*!.*.....Z.*</pre>	Displays the file named zone_server_log.889 in the log directory,

	Command or Action	Purpose
	<pre> 0x7FFFF310: 00000393 2AC6A49C 2AC621CC 2AC513F8*!.*...* 0x7FFFF320: 00000020 00000000 00000000 00000000 0x7FFFF330: 00000000 00000000 00000000 00000000 0x7FFFF340: 00000000 00000000 00000000 00000000 0x7FFFF350: 00000000 00000000 00000000 00000000 0x7FFFF360: 00000000 00000000 00000000 00000000 0x7FFFF370: 00000000 00000000 00000000 00000000 0x7FFFF380: 00000000 00000000 00000000 00000000 0x7FFFF390: 00000000 00000000 00000000 00000000 0x7FFFF3A0: 00000002 7FFFF3F4 2AAB752D 2AC5154C output abbreviated ... Stack: 128 bytes. ESP 7FFFF830, TOP 7FFFFCD0 </pre>	
Step 9	<p>switch# system cores tftp: <i>tftp-path</i></p> <p>Example:</p> <pre>switch(config)# system cores tftp://10.1.1.1/cores</pre>	<p>Configures the system to use TFTP to send the core dump to a TFTP server.</p> <p>This command causes the system to enable the automatic copy of core files to a TFTP server.</p>

Unrecoverable System Restarts

An unrecoverable system restart might occur in the following cases:

- A critical process fails and is not restartable.
- A process restarts more times than is allowed by the system configuration.
- A process restarts more frequently than is allowed by the system configuration.

The effect of a process reset is determined by the policy configured for each process. An unrecoverable reset might cause functionality loss, the active supervisor to restart, a supervisor switchover, or the system to restart.

The **show system reset-reason** command displays the following information:

- The last four reset-reason codes for a specific module in a given slot. If a module is absent, the reset-reason codes for that module are not displayed.
- The overall history of when and why expected and unexpected reloads occur.
- The time stamp of when the reset or reload occurred.
- The reason for the reset or reload of a module.
- The service that caused the reset or reload (not always available).
- The software version that was running at the time of the reset or reload.

```

switch# show system reset-reason module 27
----- reset reason for Supervisor-module 27 (from Supervisor in slot 27) ---
1) At 281000 usecs after Wed Jun 26 20:16:34 2013
   Reason: Reset Requested by CLI command reload
   Service:
   Version: 6.1(2)I1(1)
2) At 791071 usecs after Wed Jun 26 20:04:50 2013
   Reason: Reset Requested by CLI command reload
   Service:
   Version: 6.1(2)I1(1)
3) At 70980 usecs after Wed Jun 26 19:55:52 2013
   Reason: Reset Requested by CLI command reload
   Service:
   Version: 6.1(2)I1(1)
4) At 891463 usecs after Wed Jun 26 23:44:48 2013
   Reason: Reset Requested by CLI command reload
   Service:
   Version: 6.1(2)I1(1)

```

Standby Supervisor Fails to Boot

The standby supervisor does not boot after an upgrade. You may see the following system message:

```
SYSMGR-2-STANDBY_BOOT_FAILED
```

This message is printed if the standby supervisor does not complete its boot procedure (does not reach the login prompt on the local console) 3 to 6 minutes after the loader has been loaded by the BIOS. This message is usually caused by boot variables not properly set for the standby supervisor. This message can also be caused by a user intentionally interrupting the boot procedure at the loader prompt (by pressing ESC).

Connect to the local console of the standby supervisor. If the supervisor is at the loader prompt, try to use the **boot** command to continue the boot procedure. Otherwise, enter the **reload** command for the standby supervisor from a vsh session on the active supervisor, specifying the **force-dnld** option. Once the standby is online, fix the problem by setting the boot variables appropriately.

Symptom	Possible Cause	Solution
Standby supervisor does not boot.	Active supervisor nx-os image booted from TFTP.	Reload the active supervisor from bootflash:.

Recovering the Administrator Password

See [Recovering the Administrator Password](#) topic in [Password Recovery Procedure for Cisco NX-OS](#) guide to know how to recover administrator password.

Changing the Administrator Password

You must be logged in as admin to change the network administrator password.

Guidelines and Limitations for Changing the Administrator Password

Follow these guidelines and limitations to change an administrator password:

- You must be an admin to enable or disable the CLI command, no service password-recovery.
- You must be logged in as admin to change the admin password.
- You cannot change the admin password from a boot prompt if the CLI was disabled by the admin on a previous boot.



Note If you are not logged in as admin, you see an error.
