



Z Commands

- [zone-attribute-group clone vsan, on page 3](#)
- [zone-attribute-group name vsan, on page 4](#)
- [zone-attribute-group rename vsan, on page 5](#)
- [zone broadcast enable vsan, on page 6](#)
- [zone clone vsan, on page 7](#)
- [zone commit vsan, on page 8](#)
- [zone compact vsan, on page 9](#)
- [zone confirm-commit enable vsan, on page 10](#)
- [zone convert smart-zoning, on page 11](#)
- [zone convert vsan2, on page 12](#)
- [zone copy active-zoneset full-zoneset, on page 13](#)
- [zone copy vsan active-zoneset, on page 14](#)
- [zone copy vsan active-zoneset full-zoneset, on page 15](#)
- [zone default-zone permit vsan, on page 16](#)
- [zone default-zone vsan, on page 17](#)
- [zone fc2 merge throttle enable, on page 18](#)
- [zone gs, on page 19](#)
- [zone merge-control restrict vsan, on page 20](#)
- [zone mode enhanced vsan, on page 21](#)
- [zone name, on page 22](#)
- [zone name vsan, on page 23](#)
- [zone rcs enable, on page 24](#)
- [zone rename vsan, on page 25](#)
- [zone rscn address-format port, on page 26](#)
- [zone smart-zoning enable vsan, on page 27](#)
- [zoneset activate name vsan, on page 28](#)
- [zoneset activate vsan, on page 29](#)
- [zoneset capability change-abort, on page 30](#)
- [zoneset capability distribute full, on page 31](#)
- [zoneset clone vsan, on page 32](#)
- [zoneset distribute full vsan, on page 33](#)
- [zoneset distribute vsan, on page 34](#)
- [zoneset export vsan, on page 35](#)

- [zoneset import interface vsan, on page 36](#)
- [zoneset name vsan, on page 37](#)
- [zoneset overwrite-control vsan, on page 38](#)
- [zoneset rename vsan, on page 39](#)
- [zr-optics cd-min cd-max, on page 40](#)
- [zr-optics dwdm-carrier 100GHz-grid frequency, on page 41](#)
- [zr-optics dwdm-carrier 100MHz-grid frequency, on page 42](#)
- [zr-optics dwdm-carrier 50GHz-grid, on page 43](#)
- [zr-optics fec muxponder modulation dac-rate, on page 44](#)
- [zr-optics transmit-power, on page 45](#)
- [zrp-optics cd-min cd-max, on page 46](#)
- [zrp-optics dwdm-carrier 100GHz-grid frequency, on page 47](#)
- [zrp-optics dwdm-carrier 100MHz-grid frequency, on page 48](#)
- [zrp-optics dwdm-carrier 50GHz-grid, on page 49](#)
- [zrp-optics fec muxponder modulation dac-rate, on page 50](#)
- [zrp-optics transmit-power, on page 51](#)

zone-attribute-group clone vsan

zone-attribute-group clone <s0> <s1> vsan <i0>

Syntax Description

zone-attribute-group	Zone attribute group commands
clone	Attribute group clone command
<i>s0</i>	Current Attribute group name
<i>s1</i>	New attribute group name
vsan	clone zone attr group name on a vsan
<i>i0</i>	VSAN id

Command Mode

- /exec/configure

zone-attribute-group name vsan

[no] zone-attribute-group name <s0> vsan <i0>

Syntax Description

no	(Optional) Negate a command or set its defaults
zone-attribute-group	Zone attribute group commands
name	Configure attribute group
s0	Enter the name of attribute group
vsan	Configure attr-group on a VSAN
i0	VSAN id

Command Mode

- /exec/configure

zone-attribute-group rename vsan

zone-attribute-group rename <s0> <s1> vsan <i0>

Syntax Description

zone-attribute-group	Zone attribute group commands
rename	Attribute group rename command
<i>s0</i>	Current Attribute group name
<i>s1</i>	New attribute group name
vsan	rename zone attr group name on a vsan
<i>i0</i>	VSAN id

Command Mode

- /exec/configure

zone broadcast enable vsan

[no] zone broadcast enable vsan <i0>

Syntax Description

no	(Optional) Negate a command or set its defaults
broadcast	set broadcast zoning state
enable	enable broadcast zoning
vsan	enable broadcast zoning on the given vsan(s)
<i>i0</i>	VSAN id range

Command Mode

- /exec/configure

zone clone vsan

zone clone <s0> <s1> vsan <i0>

Syntax Description

clone	Zone clone command
<i>s0</i>	Current zone name
<i>s1</i>	New zone name
vsan	clone zone name on a vsan
<i>i0</i>	VSAN id

Command Mode

- /exec/configure

zone commit vsan

[no] zone commit vsan <i0> [force]

Syntax Description

no	(Optional) Negate a command or set its defaults
commit	Commit changes
vsan	Commit changes on a VSAN
<i>i0</i>	VSAN id
force	(Optional) Force commit changes

Command Mode

- /exec/configure

zone compact vsan

zone compact vsan <i0>

Syntax Description

compact	Compact zone database
vsan	Compact zone database on a VSAN
<i>i0</i>	VSAN id

Command Mode

- /exec/configure

zone confirm-commit enable vsan

[no] zone confirm-commit enable vsan <i0>

Syntax Description

no	(Optional) Negate a command or set its defaults
confirm-commit	Confirm messages during commit
enable	Enable confirm messages during commit
vsan	Enable confirm messages during commit for a VSAN
<i>i0</i>	VSAN id

Command Mode

- /exec/configure

zone convert smart-zoning

```
zone convert smart-zoning { { vsan1 <vsan_id> } | { fcalias name <fcalias_name> vsan2 <vsan_id> | zone
name1 <zone_name> vsan2 <vsan_id> | zoneset name2 <zs_name> vsan2 <vsan_id> } }
```

Syntax Description

convert	Zone convert commands
smart-zoning	Smart Zoning convert commands
vsan1	Auto-convert commands for a vsan
fcalias	Auto-convert commands for a fcalias
name	Auto-convert commands for a given fcalias
<i>fcalias_name</i>	Enter the fcalias name
zone	Auto-convert commands for a zone
name1	Auto-convert commands for a given zone
<i>zone_name</i>	Enter the zone name
zoneset	Auto-convert commands for a zoneset
name2	Auto-convert commands for a given zoneset
<i>zs_name</i>	Enter the zoneset name
vsan2	Enter the vsan
<i>vsan_id</i>	Enter the vsan

Command Mode

- /exec/configure

zone convert vsan2

```
zone convert { alias name <alias_name> | vsan1 | zone name1 <zone_name> | zoneset name2 <zs_name> }
<src_mem_type> <dst_mem_type> vsan2 <vsan_id> [ ignore-error ]
```

Syntax Description

convert	Zone convert commands
alias	Zone convert commands for an alias
name	Zone convert commands for a given alias
<i>alias_name</i>	Enter the alias name
vsan1	Zone convert commands for a vsan
zone	Zone convert commands for a zone
name1	Zone convert commands for a given zone
<i>zone_name</i>	Enter the zone name
zoneset	Zone convert commands for a zoneset
name2	Zone convert commands for a given zoneset
<i>zs_name</i>	Enter the zoneset name
<i>src_mem_type</i>	Enter the source member type
<i>dst_mem_type</i>	Enter the dest member type
vsan2	Enter the vsan
<i>vsan_id</i>	Enter the vsan
ignore-error	(Optional) ignore errors while converting

Command Mode

- /exec/configure

zone copy active-zoneset full-zoneset

```
zone copy active-zoneset full-zoneset { include-auto-zones vsan <i0> | vsan1 <i1> }
```

Syntax Description

copy	Zone Server copy command
active-zoneset	Copy from active zoneset
full-zoneset	Copy active zoneset to full zoneset
include-auto-zones	Include auto zones
vsan	Copy active zoneset on a VSAN to full zoneset
<i>i0</i>	VSAN id range
vsan1	Copy active zoneset on a VSAN to full zoneset
<i>i1</i>	VSAN id range

Command Mode

- /exec

zone copy vsan active-zoneset

zone copy vsan <i0> active-zoneset <uri1>

Syntax Description

copy	Zone Server copy command
vsan	Copy active zoneset on a VSAN
<i>i0</i>	VSAN id range
active-zoneset	Copy from active zoneset
<i>uri1</i>	Select destination filesystem

Command Mode

- /exec

zone copy vsan active-zoneset full-zoneset

zone copy vsan <i0> active-zoneset full-zoneset [include-auto-zones]

Syntax Description

copy	Zone Server copy command
vsan	Copy active zoneset on a VSAN
<i>i0</i>	VSAN id range
active-zoneset	Copy from active zoneset
full-zoneset	Copy active zoneset to full zoneset on a VSAN
include-auto-zones	(Optional) Include auto zones

Command Mode

- /exec

zone default-zone permit vsan

[no] zone default-zone permit vsan <i0>

Syntax Description

no	(Optional) Negate a command or set its defaults
default-zone	Defines default zoning behavior
permit	Default permit
vsan	Defines default zoning behavior for the specified VSAN
<i>i0</i>	VSAN id range

Command Mode

- /exec/configure

zone default-zone vsan

zone default-zone vsan <*i0*>

Syntax Description

default-zone	Defines default zoning behavior
vsan	Define default-zone properties
<i>i0</i>	VSAN id range

Command Mode

- /exec/configure

zone fc2 merge throttle enable

[no] zone fc2 merge throttle enable

Syntax Description

no	(Optional) Negate a command or set its defaults
fc2	Zone fc2 throttle commands
merge	Zone merge throttle in fc2
throttle	Zone merge throttle in fc2
enable	Enable zone merge throttle

Command Mode

- /exec/configure

zone gs

```
[no] zone gs { read vsan <i0> | read-write vsan1 <i1> }
```

Syntax Description

no	(Optional) Negate a command or set its defaults
gs	Zone generic services commands
read	Enable generic services Read only permission
vsan	Enable generic services read-only permission on given vsan
<i>i0</i>	VSAN id range
read-write	Enable generic services Read-Write Permission
vsan1	Enable generic services read-write permission on given vsan
<i>i1</i>	VSAN id range

Command Mode

- /exec/configure

zone merge-control restrict vsan

[no] zone merge-control restrict vsan <i0>

Syntax Description

no	(Optional) Negate a command or set its defaults
merge-control	Configure Merge control setting
restrict	Configure restrict merge control
vsan	Configure merge control setting on a VSAN
<i>i0</i>	VSAN id

Command Mode

- /exec/configure

zone mode enhanced vsan

[no] zone mode enhanced vsan <i0>

Syntax Description

no	(Optional) Negate a command or set its defaults
mode	Configure zoning mode
enhanced	Configure zoning mode as enhanced
vsan	Configure a zone on a VSAN
<i>i0</i>	VSAN id

Command Mode

- /exec/configure

zone name

[no] zone name <s0>

Syntax Description

no	(Optional) Negate a command or set its defaults
name	Zone name
s0	Enter the name of zone

Command Mode

- /exec/configure/zoneset

zone name vsan

[no] zone name <s0> vsan <i0>

Syntax Description

no	(Optional) Negate a command or set its defaults
name	Configure a zone
s0	Enter the name of zone
vsan	Configure a zone on a VSAN
i0	VSAN id

Command Mode

- /exec/configure

zone rcs enable

[no] zone rcs enable [vsan <i0>]

Syntax Description

no	(Optional) Negate a command or set its defaults
rcs	Configure RCS support
enable	Enable zoning RCS support
vsan	(Optional) Enable RCS support on a VSAN
<i>i0</i>	(Optional) VSAN id

Command Mode

- /exec/configure

zone rename vsan

```
zone rename <s0> <s1> vsan <i0>
```

Syntax Description

rename	Zone rename command
<i>s0</i>	Current zone name
<i>s1</i>	New zone name
vsan	rename zone name on a vsan
<i>i0</i>	VSAN id

Command Mode

- /exec/configure

zone rscn address-format port

[no] zone rscn address-format port [vsan <i0>]

Syntax Description

no	(Optional) Negate a command or set its defaults
rscn	rscn configuration changes
address-format	Configure rscn address format mode
port	Configure zone to send rscn in port address
vsan	(Optional) Configure a zone on a VSAN
<i>i0</i>	(Optional) VSAN id

Command Mode

- /exec/configure

zone smart-zoning enable vsan

[no] zone smart-zoning enable vsan <i0>

Syntax Description

no	(Optional) Negate a command or set its defaults
smart-zoning	Configure Smart Zoning
enable	Enable Smart Zoning feature
vsan	Enable Smart Zoning feature on the given VSAN
<i>i0</i>	VSAN id

Command Mode

- /exec/configure

zoneset activate name vsan

zoneset activate name <s0> vsan <i0> [force]

Syntax Description

zoneset	Zoneset configuration commands
activate	Activate a zoneset
name	Zoneset name
<i>s0</i>	Enter the name of zoneset
vsan	Activate a zoneset on the specified VSAN
<i>i0</i>	VSAN id
force	(Optional) Force name change during activation

Command Mode

- /exec/configure

zoneset activate vsan

[no] zoneset activate [name <s0>] vsan <i0>

Syntax Description

no	Negate a command or set its defaults
zoneset	Zoneset configuration commands
activate	Activate a zoneset
name	(Optional) Zoneset name
s0	(Optional) Enter the name of zoneset
vsan	Activate a zoneset on the specified VSAN
i0	VSAN id

Command Mode

- /exec/configure

zoneset capability change-abort

[no] zoneset capability change-abort

Syntax Description

no	(Optional) Negate a command or set its defaults
zoneset	Execute zoneset commands
capability	zone server capability
change-abort	Enable change abort capability

Command Mode

- /exec/configure

zoneset capability distribute full

[no] zoneset capability distribute full

Syntax Description

no	(Optional) Negate a command or set its defaults
zoneset	Zoneset configuration commands
capability	zone server capability
distribute	Enable zoneset propagation
full	Enable full-zoneset propagation

Command Mode

- /exec/configure

zoneset clone vsan

zoneset clone <s0> <s1> vsan <i0>

Syntax Description

zoneset	Zoneset configuration commands
clone	Zoneset clone command
<i>s0</i>	Current zoneset name
<i>s1</i>	New zoneset name
vsan	clone zoneset name on a vsan
<i>i0</i>	VSAN id

Command Mode

- /exec/configure

zoneset distribute full vsan

[no] zoneset distribute full vsan <i0>

Syntax Description

no	(Optional) Negate a command or set its defaults
zoneset	Zoneset configuration commands
distribute	Enable zoneset propagation
full	Enable full-zoneset propagation
vsan	Enable full zoneset propagation for the specified VSAN
<i>i0</i>	VSAN id range

Command Mode

- /exec/configure

zoneset distribute vsan

zoneset distribute vsan <i0>

Syntax Description

zoneset	Execute zoneset commands
distribute	Distributes full zoneset in the fabric
vsan	Distributes full zoneset in the fabric on a VSAN
<i>i0</i>	VSAN id

Command Mode

- /exec

zoneset export vsan

zoneset export vsan <i0>

Syntax Description

zoneset	Execute zoneset commands
export	Exports zone server database to adjacent switch
vsan	Export zone server database of a VSAN to adjacent switch
<i>i0</i>	VSAN id range

Command Mode

- /exec

zoneset import interface vsan

zoneset import interface <if0> vsan <i0>

Syntax Description

zoneset	Execute zoneset commands
import	Imports zone server database from adjacent switch
interface	Interface name
<i>if0</i>	
vsan	Imports zone server database of a VSAN on the interface
<i>i0</i>	VSAN id range

Command Mode

- /exec

zoneset name vsan

[no] zoneset name <s0> vsan <i0>

Syntax Description

no	(Optional) Negate a command or set its defaults
zoneset	Zoneset configuration commands
name	Configure a zoneset
s0	Enter the name of zoneset
vsan	Configure a zoneset on a VSAN
i0	VSAN id

Command Mode

- /exec/configure

zoneset overwrite-control vsan

[no] zoneset overwrite-control vsan <i0>

Syntax Description

no	(Optional) Negate a command or set its defaults
zoneset	Zoneset configuration commands
overwrite-control	Overwrite-control command of activating a zoneset with a different name in enhanced mode
vsan	Overwrite Name control of a zoneset activation on the specified VSAN
<i>i0</i>	VSAN id

Command Mode

- /exec/configure

zoneset rename vsan

zoneset rename <s0> <s1> vsan <i0>

Syntax Description

zoneset	Zoneset configuration commands
rename	Zoneset rename command
<i>s0</i>	Current zoneset name
<i>s1</i>	New zoneset name
vsan	rename zoneset name on a vsan
<i>i0</i>	VSAN id

Command Mode

- /exec/configure

zr-optics cd-min cd-max

zr-optics cd-min <cd_min> cd-max <cd_max>

Syntax Description

zr-optics	zr optics config
cd-min	cd-min input
<i>cd_min</i>	Optics cd-min value
cd-max	cd-max input
<i>cd_max</i>	Optics cd-max value

Command Mode

- /exec/configure/if-ethernet-all /exec/configure/if-eth-base

zr-optics dwdm-carrier 100GHz-grid frequency

zr-optics dwdm-carrier 100GHz-grid frequency <freq_100ghz_val>

Syntax Description

zr-optics	zr optics config
dwdm-carrier	dwdm-carrier input mode
100GHz-grid	Optics dwdm carrier mode 100GHz
frequency	frequency 100GHz input
<i>freq_100ghz_val</i>	Optics frequency 100GHz value

Command Mode

- /exec/configure/if-ethernet-all /exec/configure/if-eth-base

zr-optics dwdm-carrier 100MHz-grid frequency

zr-optics dwdm-carrier 100MHz-grid frequency <freq_100mhz_val>

Syntax Description

zr-optics	zr optics config
dwdm-carrier	dwdm-carrier input mode
100MHz-grid	Optics dwdm carrier mode 100MHz
frequency	frequency 100MHz input
<i>freq_100mhz_val</i>	Optics frequency 100MHz value

Command Mode

- /exec/configure/if-ethernet-all /exec/configure/if-eth-base

zr-optics dwdm-carrier 50GHz-grid

```
zr-optics dwdm-carrier 50GHz-grid { { frequency <freq_50ghz_val> } | { itu-channel <itu_chan_50ghz_val> } | { wavelength <wavelen_50ghz_val> } }
```

Syntax Description

zr-optics	zr optics config
dwdm-carrier	dwdm-carrier input mode
50GHz-grid	Optics dwdm carrier mode 50GHz
frequency	frequency 50GHz input
<i>freq_50ghz_val</i>	Optics frequency 50GHz value
itu-channel	itu-channel 50HGz input
<i>itu_chan_50ghz_val</i>	Optics itu-channel 50GHz value
wavelength	wavelength 50GHz input
<i>wavelen_50ghz_val</i>	Optics wavelength 50GHz value

Command Mode

- /exec/configure/if-ethernet-all /exec/configure/if-eth-base

zr-optics fec muxponder modulation dac-rate

[no] zr-optics fec <fec_val> muxponder <mxp_val> modulation <mod_val> dac-rate <dr_val>

Syntax Description

no	(Optional) Negate a command or set its defaults
zr-optics	zr optics config
fec	fec input
<i>fec_val</i>	Optics FEC mode
muxponder	muxponder input
<i>mxp_val</i>	muxponder input
modulation	modulation input
<i>mod_val</i>	modulation input
dac-rate	dac-rate input
<i>dr_val</i>	Optics dac rate

Command Mode

- /exec/configure/if-ethernet-all /exec/configure/if-eth-base

zr-optics transmit-power

zr-optics transmit-power <tx_pwr>

Syntax Description

zr-optics	zr optics config
transmit-power	optics transmit-power
<i>tx_pwr</i>	Optics tx-pwr value

Command Mode

- /exec/configure/if-ethernet-all /exec/configure/if-eth-base

zrp-optics cd-min cd-max

zrp-optics cd-min <cd_min> cd-max <cd_max>

Syntax Description

zrp-optics	zr optics config
cd-min	cd-min input
<i>cd_min</i>	Optics cd-min value
cd-max	cd-max input
<i>cd_max</i>	Optics cd-max value

Command Mode

- /exec/configure/if-ethernet-all /exec/configure/if-eth-base

zrp-optics dwdm-carrier 100GHz-grid frequency

zrp-optics dwdm-carrier 100GHz-grid frequency <freq_100ghz_val>

Syntax Description

zrp-optics	zr optics config
dwdm-carrier	dwdm-carrier input mode
100GHz-grid	Optics dwdm carrier mode 100GHz
frequency	frequency 100MHz input
<i>freq_100ghz_val</i>	Optics frequency 100GHz value

Command Mode

- /exec/configure/if-ethernet-all /exec/configure/if-eth-base

zrp-optics dwdm-carrier 100MHz-grid frequency

zrp-optics dwdm-carrier 100MHz-grid frequency <freq_100mhz_val>

Syntax Description

zrp-optics	zr optics config
dwdm-carrier	dwdm-carrier input mode
100MHz-grid	Optics dwdm carrier mode 100MHz
frequency	frequency 100MHz input
<i>freq_100mhz_val</i>	Optics frequency 100MHz value

Command Mode

- /exec/configure/if-ethernet-all /exec/configure/if-eth-base

zrp-optics dwdm-carrier 50GHz-grid

```
zrp-optics dwdm-carrier 50GHz-grid { { frequency <freq_50ghz_val> } | { itu-channel <itu_chan_50ghz_val> } | { wavelength <wavelen_50ghz_val> } }
```

Syntax Description

zrp-optics	zrp optics config
dwdm-carrier	dwdm-carrier input mode
50GHz-grid	Optics dwdm carrier mode 50GHz
frequency	frequency 50GHz input
<i>freq_50ghz_val</i>	Optics frequency 50GHz value
itu-channel	itu-channel 50GHz input
<i>itu_chan_50ghz_val</i>	Optics itu-channel 50Ghz value
wavelength	wavelength 50GHz input
<i>wavelen_50ghz_val</i>	Optics wavelength 50GHz value

Command Mode

- /exec/configure/if-ethernet-all /exec/configure/if-eth-base

zrp-optics fec muxponder modulation dac-rate

[no] zrp-optics fec <fec_val> muxponder <mxp_val> modulation <mod_val> dac-rate <dr_val>

Syntax Description

no	(Optional) Negate a command or set its defaults
zrp-optics	zrp optics config
fec	fec input
<i>fec_val</i>	Optics FEC mode
muxponder	muxponder input
<i>mxp_val</i>	muxponder input
modulation	modulation input
<i>mod_val</i>	modulation input
dac-rate	dac-rate input
<i>dr_val</i>	Optics dac rate

Command Mode

- /exec/configure/if-ethernet-all /exec/configure/if-eth-base

zrp-optics transmit-power

zrp-optics transmit-power <tx_pwr>

Syntax Description

zrp-optics	zr optics config
transmit-power	optics transmit-power
<i>tx_pwr</i>	Optics tx-pwr value

Command Mode

- /exec/configure/if-ethernet-all /exec/configure/if-eth-base

