

gNOI - Operation Interface

- About gNOI, on page 1
- Guidelines and Limitations for gNOI, on page 2
- Configuring gNOI, on page 2
- System .Proto, on page 2
- OS .Proto, on page 3
- Cert .Proto, on page 4
- File .Proto, on page 4
- Factory Reset .Proto, on page 5
- Troubleshooting gNOI, on page 6

About gNOI

gRPC Network Operations Interface (gNOI) defines a set of gRPC-based micro-services for executing operational commands on network devices.

gNOI uses Google Remote Procedure Call (gRPC) as the transport protocol and the configuration is same as that of gNMI. For details on gNMI configuration, see gRPC Agent. To send gNOI RPC requests, user needs a client that implements the gNOI client interface for each RPC. In Cisco NX-OS Release 10.1(1) the gNOI defines Remote Procedure Calls (RPCs) for a limited number of components and some of them are related to hardware (like optical interfaces).

Proto files are defined for the gRPC micro-services and are available at GitHub.

Table 1: Supported gNOI RPCs

Proto	gNOI RPC	Supported	
System	Ping	Yes	
	Traceroute	Yes	
	Time	Yes	
	SwitchControl Processor	Yes	
	Reboot	Yes	
	RebootStatus	Yes	
	CancelReboot	Yes	
	OS	Activate	Ys
Verify		Yes	
Cert	LoadCertificate	Yes	
File	Get	Yes	
	Stat	Yes	
	Remove	Yes	
	FactoryReset	Start	Ys

Guidelines and Limitations for gNOI

The gNOI feature has the following guidelines and limitations:

- A maximum of 16 active gNOI RPCs are supported.
- The Cisco Nexus 9000 series switches would run one endpoint with one gNMI service and two gNOI microservices.

Configuring gNOI

gNMI is a child functionality of the gRPC agent. See gRPC Agent, to enable the gRPC agent. Currently there is no separate configuration for gNOI.

Currently there is no separate config for gNOI.

System .Proto

The System proto service is a collection of operational RPCs that allows the management of a target outside the configuration and telemetry pipeline.

The following are the RPC support details for System proto:

RPC	Support	Description	Limitation
Ping	ping/ping6 cli command	Executes the ping command on the target and streams back the results. Some targets may not stream any results until all results are available. If a packet count is not explicitly provided, ping5 is used.	do_not_resolve option is not supported.
Traceroute	traceroute/traceroute6 cli command	Executes the traceroute command on the target and streams back the results. Some targets may not stream any results until all results are available. Max hop count of 30 is used.	itial_ttl, marx_ttl, wait, do_not_fragment, do_not_resolve and l4protocol options are not supported.
Time	local time	Returns the current time on the target. Typically used to test if the target is responding.	-
SwitchControl Processor	system switchover cli command	Switches from the current route processor to the provided route processor. Switchover happens instantly and the response may not be guaranteed to return to the client.	Switchover occurs instantly. As a result, the response may not be guaranteed to return to the client.
Reboot	cli: reload [module]	Causes the target to reboot.	message option is not supported. Delay option is supported for switch reload, and the path option accepts one module number.
RebootStatus	show version [module] cli command	Returns the status of the reboot for the target.	-
CancelReboot	reload cancel	Cancels any pending reboot request.	-

OS .Proto

The OS service provides an interface for OS installation on a Target. The OS package file format is platform dependent. The platform must validate that the OS package that is supplied is valid and bootable. This must include a hash check against a known good hash. It is recommended that the hash is embedded in the OS package.

The Target manages its own persistent storage, and OS installation process. It stores a set of distinct OS packages, and always proactively frees up space for incoming new OS packages. It is guaranteed that the Target always has enough space for a valid incoming OS package. The currently running OS packages must never be removed. The Client must expect that the last successfully installed package is available.

The following are the RPC support details for OS proto:

RPC	Support	Description	Limitation
Activate	install all nxos bootflash:///img_name	Sets the requested OS version as the version that is used at the next reboot. This RPC reboots the Target.	Cannot rollback or recover if the reboot fails.
Verify	show version	Verify checks the running OS version. This RPC may be called multiple times while the Target boots until it is successful.	-



Note

The Install RPC is not supported.

Cert .Proto

The certificate management service is exported by targets. Rotate, Install and other Certificate Proto RPCs are not supported.

RPC	Support	Description	Limitation
LoadCertificate	crypto ca import <trustpoint> pkcs12 <file> <passphrase></passphrase></file></trustpoint>	Loads a bundle of CA certificates.	-

File .Proto

The file proto streams messages based on the features of the file proto RPCs.

Get, Stat, and Remove RPCs support file systems such as - bootflash, bootflash://sup-remote, logflash, logflash://sup-remote, usb, volatile, volatile://sup-remote and debug. Put RPC only supports bootflash.

The following are the RPC support details for File proto:

RPC	Support	Description	Limitation
Get		Get reads and streams the contents of a file from the target. The file is streamed by sequential messages, each containing up to 64 KB of data. A final message is sent prior to closing the stream that contains the hash of the data sent. An error is returned if the file does not exist or there was an error reading the file.	Maximum file size limit is 32 MB.
Stat		Stat returns metadata about a file on the target. An error is returned if the file does not exist or if there is an error in accessing the metadata.	-
Remove		Remove removes the specified file from the target. An error is returned if the file does not exist, if it is a directory, or the remove operation encounters an error.	-

Factory Reset .Proto

This .proto currently defines only one RPC. Refer to https://github.com/openconfig/gnoi/blob/master/factory_reset/factory_reset.proto.

RPC	Support	Description	Limitation
FactoryReset	factory-reset module all [bypass-secure-erase] preserve-image force	Executes the factory-rest command on the target.	See below for detail.

FactoryReset

The gNOI factory reset operation erases all persistent storage on the specified module. This includes configuration, all log data, and the full contents of flash and (Solid State Drives) SSDs. The reset boots to the last boot image, erases all storage including license. gNOI factory reset supports two modes:

- A fast erase which can reformat and repartition only.
- A secure erase which can erase securely and wipe the data which is impossible to recover.

Option	Description	Values
factory_os	Specifies to rollback to the OS version as shipped from factory.	Setting to true on NX-OS is not supported, and it is mandatory to preserve the current boot image.
zero_fill	Specifies whether to perform more time consuming and comprehensive secure erase.	· -
		zero_fill = false: Specifies factory-reset module all bypass-secure-erase preserve-image force.

Troubleshooting gNOI

Debug gNOI

To verify the gNOI status, enter the following commands.

Show Commands

Command	Description
clear grpc gnoi rpc	Serves to clean up the counters or calls.
debug grpc events {events errors}	Debugs the events and errors from the event history.
show grpc nxsdk event-history {events errors}	
clear grpc gnoi rpc	Serves to clean up the counters or calls.

Example Output

show grpc gnmi service statistics

Gathering Debug Logs

gNOI is a child service of the gRPC agent. For more information, see gRPC Agent chapter.

Gathering Debug Logs