



Cisco Provider Connectivity Assurance Sensor SFP 1G Copper Hardware Installation Guide

First Published: 2025-02-20

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The following information is for FCC compliance of Class A devices: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio-frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case users will be required to correct the interference at their own expense.

The following information is for FCC compliance of Class B devices: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment causes interference to radio or television reception, which can be determined by turning the equipment off and on, users are encouraged to try to correct the interference by using one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Modifications to this product not authorized by Cisco could void the FCC approval and negate your authority to operate the product.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at www.cisco.com/go/offices.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <https://www.cisco.com/c/en/us/about/legal/trademarks.html>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2025 Cisco Systems, Inc. All rights reserved.



CONTENTS

CHAPTER 1	Overview	1
	Features	1
	Product ID Numbers	2

CHAPTER 2	Installation Preparation	3
	Installation Warnings	3
	Prevent ESD Damage	5

CHAPTER 3	Installation, Maintenance, and Upgrade	7
	Installing a Transceiver Module	7
	Removing a Transceiver Module	8



CHAPTER 1

Overview

- [Features, on page 1](#)
- [Product ID Numbers, on page 2](#)

Features

The Cisco[®] Provider Connectivity Assurance Sensor SFP portfolio (formerly Accedian Skylight SFP Compute Sensor) offers customers a wide variety of high-performance Gigabit Ethernet pluggable service assurance and demarcation options for enhanced mobile, Carrier Ethernet, and IP service deployments. Fully integrated with the Provider Connectivity Assurance platform, Assurance Sensor SFPs support service delivery automation, scalable metric collection, and reporting with actionable insight and machine learning-driven analytics to enable accelerated service rollout and improved operational efficiency.

See the [Cisco Provider Connectivity Assurance Sensor SFP Data Sheet](#) for product details.

Figure 1: 100/1000bT (CU) Transceiver



The following table lists the regulation and standard compliance features of the Cisco Provider Connectivity Assurance Sensor SFP.

Table 1: Regulation and Standard Compliance (Model: nNIDc)

Feature	Description
Safety	IEC 62368-1, EN IEC 62368-1, AS/NZS 62368.1, CSA/UL 62368-1, GB 4943.1, J62368-1, SASO-IEC 62368-
EMC - Emission (Class B)	CISPR32, EN 55032, FCC Part 15 (CFR 47), ICES-003, AS/NZS CISPR 32, VCCI, KN 32
EMC - Immunity	EN 55035, KN 35

Product ID Numbers

The following table lists the field-replaceable PIDs associated with the Assurance Sensor SFP. If any internal components fail, you must get a return material authorization (RMA). See the [Cisco Returns Portal](#) for more information.

Table 2: Assurance Sensor SFP PIDs

PID	Description
S1G-TE-PM-D-I	SFP-1GbE Performance Monitoring, 100/1000bT I-temp



CHAPTER 2

Installation Preparation

- [Installation Warnings, on page 3](#)
- [Prevent ESD Damage, on page 5](#)

Installation Warnings



Caution Do *not* open the appliance except under direction from TAC.

Take note of the following warnings:



Warning **Statement 1071**—Warning Definition

IMPORTANT SAFETY INSTRUCTIONS

Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents. Read the installation instructions before using, installing, or connecting the system to the power source. Use the statement number at the beginning of each warning statement to locate its translation in the translated safety warnings for this device.

SAVE THESE INSTRUCTIONS



Warning **Statement 1089**—Instructed and Skilled Person Definitions

An instructed person is someone who has been instructed and trained by a skilled person and takes the necessary precautions when working with equipment.

A skilled person or qualified personnel is someone who has training or experience in the equipment technology and understands potential hazards when working with equipment.

There are no serviceable parts inside. To avoid risk of electric shock, do not open.

**Warning****Statement 1091—Installation by an Instructed Person**

Only an instructed person or skilled person should be allowed to install, replace, or service this equipment. See statement 1089 for the definition of an instructed or skilled person.

There are no serviceable parts inside. To avoid risk of electric shock, do not open.

**Warning****Statement 2011—Voluntary Control Council for Interference (VCCI) Compliance for Class B Equipment**

This is a Class B product based on the standard of the VCCI Council. If this product is used near a radio or television receiver in a domestic environment, it may cause radio interference. Install and use the equipment according to the instruction manual.

**Warning****Statement 2015—Class B Warning for Korea**

This is a Class B device and is registered for electromagnetic compatibility (EMC) requirements for residential use. This device can be used not only in residential areas but in all other areas.

**Note****Statement 2018—Class B Notice for FCC**

Modifying the equipment without Cisco's authorization may result in the equipment no longer complying with FCC requirements for Class B digital devices. In that event, your right to use the equipment may be limited by FCC regulations, and you may be required to correct any interference to radio or television communications at your own expense.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Warning****Statement 9001—Product Disposal**

Ultimate disposal of this product should be handled according to all national laws and regulations.

Prevent ESD Damage

ESD occurs when electronic components are improperly handled, and it can damage equipment and impair electrical circuitry, which can result in intermittent or complete failure of your equipment.

Always follow ESD-prevention procedures when removing and replacing components. Ensure that the chassis is electrically connected to an earth ground. Wear an ESD-preventive wrist strap, ensuring that it makes good skin contact. Connect the grounding clip to an unpainted surface of the chassis frame to safely ground ESD voltages. To properly guard against ESD damage and shocks, the wrist strap and cord must operate effectively. If no wrist strap is available, ground yourself by touching the metal part of the chassis.

For safety, periodically check the resistance value of the antistatic strap, which should be between one and 10 megohms.



CHAPTER 3

Installation, Maintenance, and Upgrade

- [Installing a Transceiver Module, on page 7](#)
- [Removing a Transceiver Module, on page 8](#)

Installing a Transceiver Module



Caution

The metal surface of a transceiver can become hot when it is powered by the host. Caution must be taken when touching the surface during services.



Warning

- To prevent damage to a transceiver and to any connected cables, disconnect all cables before installing or removing a module.
- Prior to installing a transceiver, power capabilities of the cage must be verified with the appliance vendor.



Note

- A transceiver is a hot-pluggable device. There is no need to power down the host appliance when installing or removing a module.
- Do not remove the dust cap from the transceiver until directed to do so in the following procedure.

To install a copper transceiver module into a transceiver cage, follow these steps:

Procedure

- Step 1** Ensure that the bail latch is closed.
- Step 2** Verifying that the transceiver cage notch and hinge are along the same edge, insert the module into the transceiver cage until the module latches into place. The module is fully seated when you hear a click.
- Step 3** Remove the dust cap from the transceiver module. Save the dust cap for future use.

Step 4 Connect the connectors of the patch cord cable to the transceiver module.

Removing a Transceiver Module

To remove a copper transceiver module from a transceiver cage, follow these steps:

Procedure

Step 1 Disconnect the cable connector from the transceiver module.

Step 2 Open the bail latch by rotating it 90 degrees, grasp the transceiver module, and then carefully pull the module from the cage.

Step 3 Close the bail latch.

Step 4 Reinstall the dust cap into the transceiver module.
