



Integrating NAT with MPLS VPNs

Last Updated: December 18, 2011

Network Address Translation (NAT) Integration with MPLS VPNs feature allows multiple Multiprotocol Label Switching (MPLS) Virtual Private Networks (VPNs) to be configured on a single device to work together. NAT can differentiate which MPLS VPN it receives IP traffic from even if the MPLS VPNs are all using the same IP addressing scheme. This enhancement enables multiple MPLS VPN customers to share services while ensuring that each MPLS VPN is completely separate from the other.

- [Finding Feature Information, page 1](#)
- [Prerequisites for Integrating NAT with MPLS VPNs, page 1](#)
- [Restrictions for Integrating NAT with MPLS VPNs, page 2](#)
- [Information About Integrating NAT with MPLS VPNs, page 2](#)
- [How to Integrate NAT with MPLS VPNs, page 3](#)
- [Configuration Examples for Integrating NAT with MPLS VPNs, page 10](#)
- [Where to Go Next, page 11](#)
- [Additional References, page 11](#)
- [Feature Information for Integrating NAT with MPLS VPNs, page 13](#)

Finding Feature Information

Your software release may not support all the features documented in this module. For the latest feature information and caveats, see the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the Feature Information Table at the end of this document.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Prerequisites for Integrating NAT with MPLS VPNs

- Before performing the tasks in this module, you should be familiar with the concepts described in the “Configuring NAT for IP Address Conservation” module.



Americas Headquarters:
Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA

- All access lists required for use with the tasks in this module should be configured prior to beginning the configuration task. For information about how to configure an access list, see the *IP Access List Sequence Numbering* document at the following URL:

<http://www.cisco.com/univercd/cc/td/doc/product/software/ios122s/122snwft/release/122s14/fsaclseq.htm>

**Note**

If you specify an access list to use with a NAT command, NAT does not support the commonly used **permit ip any any** command in the access list.

Restrictions for Integrating NAT with MPLS VPNs

Inside VPN to VPN with NAT is not supported.

Information About Integrating NAT with MPLS VPNs

- [Benefits of NAT Integration with MPLS VPNs, page 2](#)
- [Implementation Options for Integrating Nat with MPLS VPNs, page 2](#)
- [Scenarios for Implementing NAT on the PE Router, page 2](#)

Benefits of NAT Integration with MPLS VPNs

MPLS service providers would like to provide value-added services such as Internet connectivity, domain name servers (DNS), and voice over IP (VoIP) service to their customers. The providers require that their customers' IP addresses be different when reaching the services. Because MPLS VPN allows customers to use overlapped IP addresses in their networks, NAT must be implemented to make the services possible.

Implementation Options for Integrating Nat with MPLS VPNs

There are two approaches to implementing NAT in the MPLS VPN network. NAT can be implemented on the customer edge (CE) router, which is already supported by NAT, or it can be implemented on a provider edge (PE) router. The NAT Integration with MPLS VPNs feature enables the implementation of NAT on a PE router in an MPLS cloud.

Scenarios for Implementing NAT on the PE Router

NAT could be implemented on the PE router in the following scenarios:


- Service point--Shared access can be from a generic interface or from a VPN interface.
- NAT point--NAT can be configured on the PE router that is directly connected to the shared access gateway, or on the PE router that is not directly connected to the shared access gateway.
- NAT interface--The shared access gateway interface most often is configured as the outside interface of NAT. The inside interface of NAT can be either the PE-CE interface of a VPN, the interface to the MPLS backbone, or both. The shared access gateway interface can also be configured as the inside interface.
- Routing type--Common service can be Internet connectivity or a common server. For Internet connectivity, a default route should be propagated to all the VPN customers that use the service. For

common server access, a static or dynamically learned route should be propagated to the VPN customers.

- NAT configuration--NAT can have different configurations: static, dynamic, pool/interface overloading, and route-map.

The figure below shows a typical NAT integration with MPLS VPNs. The PE router connected to the internet and centralized mail service is employed to do the address translation.

Figure 1 *Typical NAT Integration with MPLS VPNs*



170912

How to Integrate NAT with MPLS VPNs

Perform one or more of the following tasks depending on the type of translation you wish to configure for your network:

- [Configuring Inside Dynamic NAT with MPLS VPNs, page 4](#)
- [Configuring Inside Static NAT with MPLS VPNs, page 5](#)
- [Configuring Outside Dynamic NAT with MPLS VPNs, page 7](#)
- [Configuring Outside Static NAT with MPLS VPNs, page 8](#)

Configuring Inside Dynamic NAT with MPLS VPNs

Perform this task to configure your NAT PE router for dynamic translations to integrate with MPLS VPNs.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **ip nat pool** *name start-ip end-ip netmask netmask*
4. **ip nat** [**inside** | **outside**] **source** [**list** { *access-list-number* | *access-list-name* } | **route-map** *name*] [**interface** *type number* | **pool** *pool-name*] **vrf** *vrf-name* [**overload**]
5. Repeat Step 4 for each VPN being configured
6. **ip route vrf** *vrf-name prefix mask interface-type interface-number next-hop-address*
7. Repeat Step 6 for each VPN being configured.
8. **exit**
9. **show ip nat translations vrf** *vrf-name*

DETAILED STEPS

| Command or Action | Purpose |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 enable Example: <pre>Router> enable</pre> | Enables higher privilege levels, such as privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted. |
| Step 2 configure terminal Example: <pre>Router# configure terminal</pre> | Enters global configuration mode. |
| Step 3 ip nat pool <i>name start-ip end-ip netmask netmask</i> Example: <pre>Router(config)# ip nat pool inside 2.2.2.10 2.2.2.10 netmask 255.255.255.0</pre> | Defines a pool of IP addresses for NAT. |
| Step 4 ip nat [inside outside] source [list { <i>access-list-number</i> <i>access-list-name</i> } route-map <i>name</i>] [interface <i>type number</i> pool <i>pool-name</i>] vrf <i>vrf-name</i> [overload] Example: <pre>Router(config)# ip nat inside source list 1 pool mypool vrf shop overload</pre> | Allows NAT to be configured on a particular VPN. |

| | Command or Action | Purpose |
|---------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------|
| Step 5 | Repeat Step 4 for each VPN being configured | -- |
| Step 6 | ip route vrf <i>vrf-name prefix mask interface-type interface-number next-hop-address</i> Example: <pre>Router(config)# ip route vrf shop 0.0.0.0 0.0.0.0 ethernet 0 168.58.88.2</pre> | Allows NAT to be configured on a particular VPN. |
| Step 7 | Repeat Step 6 for each VPN being configured. | -- |
| Step 8 | exit Example: <pre>Router(config)# exit</pre> | Returns to privileged EXEC mode. |
| Step 9 | show ip nat translations vrf <i>vrf-name</i> Example: <pre>Router# show ip nat translations vrf shop</pre> | (Optional) Displays the settings used by virtual routing/forwarding (VRF) table translations. |

Configuring Inside Static NAT with MPLS VPNs

Perform this task to configure your NAT PE router for static translations to integrate with MPLS VPNs.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **ip nat inside source** {static {esp *local-ip* **interface** *type number* | *local-ip global-ip*}} [**extendable** | **mapping-id** *map-id* | **no-alias** | **no-payload** | **redundancy** *group-name* | **route-map** | **vrf** *name*]
4. Repeat Step 3 for each VPN being configured.
5. **ip route vrf** *vrf-name prefix prefix mask next-hop-address global*
6. Repeat Step 5 for each VPN being configured.
7. **exit**
8. **show ip nat translations vrf** *vrf-name*

DETAILED STEPS

| Command or Action | Purpose |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 enable Example: <pre>Router> enable</pre> | Enables higher privilege levels, such as privileged EXEC mode. <ul style="list-style-type: none"> Enter your password if prompted. |
| Step 2 configure terminal Example: <pre>Router# configure terminal</pre> | Enters global configuration mode. |
| Step 3 ip nat inside source {static {esp local-ip interface type number local-ip global-ip}} [extendable mapping-id map-id] no-alias no-payload redundancy group-name route-map vrf name] Example: <pre>Router(config)# ip nat inside source static 192.168.121.113 2.2.2.1 vrf shop</pre> | Enables inside static translation on the VRF. |
| Step 4 Repeat Step 3 for each VPN being configured. | -- |
| Step 5 ip route vrf vrf-name prefix prefix mask next-hop-address global Example: <pre>Router(config)# ip route vrf shop 0.0.0.0 0.0.0.0 168.58.88.2 global</pre> | Allows the route to be shared by several customers. |
| Step 6 Repeat Step 5 for each VPN being configured. | -- |
| Step 7 exit Example: <pre>Router(config)# exit</pre> | Returns to privileged EXEC mode. |
| Step 8 show ip nat translations vrf vrf-name Example: <pre>Router# show ip nat translations vrf shop</pre> | (Optional) Displays the settings used by VRF translations. |

Configuring Outside Dynamic NAT with MPLS VPNs

Perform this step to configure your NAT PE router for dynamic outside translations to integrate with MPLS VPNs.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **ip nat pool outside** *global-ip local-ip netmask netmask*
4. **ip nat inside source static** *local-ip global-ip vrf vrf-name*
5. Repeat Step 4 for each VRF being configured.
6. **ip nat outside source static** *global-ip local-ip vrf vrf-name*
7. **exit**
8. **show ip nat translations vrf vrf-name**

DETAILED STEPS

| | Command or Action | Purpose |
|---------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | enable Example: <pre>Router> enable</pre> | Enables higher privilege levels, such as privileged EXEC mode. <ul style="list-style-type: none"> Enter your password if prompted. |
| Step 2 | configure terminal Example: <pre>Router# configure terminal</pre> | Enters global configuration mode. |
| Step 3 | ip nat pool outside <i>global-ip local-ip netmask netmask</i> Example: <pre>Router(config)# ip nat pool outside 4.4.4.1 4.4.4.254 netmask 255.255.255.00</pre> | Allows the configured VRF to be associated with the NAT translation rule. |
| Step 4 | ip nat inside source static <i>local-ip global-ip vrf vrf-name</i> Example: <pre>Router(config)# ip nat inside source static 192.168.121.113 2.2.2.1 vrf shop</pre> | Allows the route to be shared by several customers. |
| Step 5 | Repeat Step 4 for each VRF being configured. | Allows the route to be shared by several customers. |

| Command or Action | Purpose |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------|
| Step 6 <code>ip nat outside source static <i>global-ip local-ip</i> vrf <i>vrf-name</i></code> Example: <pre>Router(config)# ip nat outside source static 168.58.88.2 4.4.4.1 vrf shop</pre> | Enables NAT translation of the outside source address. |
| Step 7 <code>exit</code> Example: <pre>Router(config)# exit</pre> | Returns to privileged EXEC mode. |
| Step 8 <code>show ip nat translations vrf <i>vrf-name</i></code> Example: <pre>Router# show ip nat translations vrf shop</pre> | (Optional) Displays the settings used by VRF translations. |

Configuring Outside Static NAT with MPLS VPNs

Perform this task to configure your NAT PE router for static outside translations to integrate with MPLS VPNs.

SUMMARY STEPS

1. `enable`
2. `configure {terminal | memory | network}`
3. `ip nat pool inside global-ip local-ip netmask netmask`
4. Repeat Step 3 for each pool being configured.
5. `ip nat inside source list access-list-number pool pool-name vrf vrf-name`
6. Repeat Step 5 for each pool being configured.
7. `ip nat outside source static global-ip local-ip vrf vrf-name`
8. Repeat Step 7 for all VPNs being configured.
9. `exit`
10. `show ip nat translations vrf vrf-name`

DETAILED STEPS

| | Command or Action | Purpose |
|---------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | enable Example: Router> enable | Enables higher privilege levels, such as privileged EXEC mode. <ul style="list-style-type: none"> Enter your password if prompted. |
| Step 2 | configure {terminal memory network} Example: Router# configure terminal | Enters global configuration mode. |
| Step 3 | ip nat pool inside <i>global-ip local-ip netmask netmask</i> Example: Router(config)# ip nat pool inside1 2.2.1.1 2.2.1.254 netmask 255.255.255.0 | Allows the configured VRF to be associated with the NAT translation rule. |
| Step 4 | Repeat Step 3 for each pool being configured. | -- |
| Step 5 | ip nat inside source list <i>access-list-number</i> pool <i>pool-name</i> vrf <i>vrf-name</i> Example: Router(config)# ip nat inside source list 1 pool inside2 vrf shop | Allows the route to be shared by several customers. |
| Step 6 | Repeat Step 5 for each pool being configured. | Defines the access list. |
| Step 7 | ip nat outside source static <i>global-ip local-ip</i> vrf <i>vrf-name</i> Example: Router(config)# ip nat outside source static 168.58.88.2 4.4.4.1 vrf shop | Allows the route to be shared by several customers. |
| Step 8 | Repeat Step 7 for all VPNs being configured. | -- |
| Step 9 | exit Example: Router(config)# exit | Returns to privileged EXEC mode. |

| Command or Action | Purpose |
|--------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------|
| Step 10 <code>show ip nat translations vrf vrf-name</code> Example: Router# <code>show ip nat translations vrf shop</code> | (Optional) Displays the settings used by VRF translations. |

Configuration Examples for Integrating NAT with MPLS VPNs

- [Configuring Inside Dynamic NAT with MPLS VPNs Example, page 10](#)
- [Configuring Inside Static NAT with MPLS VPNs Example, page 10](#)
- [Configuring Outside Dynamic NAT with MPLS VPNs Example, page 11](#)
- [Configuring Outside Static NAT with MPLS VPNs Example, page 11](#)

Configuring Inside Dynamic NAT with MPLS VPNs Example

The following example shows configuring inside Dynamic NAT with MPLS VPNs.

```
!
ip nat pool inside 2.2.2.10 2.2.2.10 netmask 255.255.255.0
ip nat inside source list 1 pool inside vrf bank overload
ip nat inside source list 1 pool inside vrf park overload
ip nat inside source list 1 pool inside vrf shop overload
!
ip route vrf shop 0.0.0.0 0.0.0.0 Ethernet1/3 168.58.88.2
ip route vrf bank 0.0.0.0 0.0.0.0 Ethernet1/3 168.58.88.2
ip route vrf park 0.0.0.0 0.0.0.0 Ethernet1/3 168.58.88.2
!
access-list 1 permit 192.168.0.0 0.0.255.255
```

Configuring Inside Static NAT with MPLS VPNs Example

The following example shows configuring inside static NAT with MPLS VPNs.

```
!
ip nat inside source static 192.168.121.113 2.2.2.1 vrf shop
ip nat inside source static 192.168.122.49 2.2.2.2 vrf shop
ip nat inside source static 192.168.121.113 2.2.2.3 vrf bank
ip nat inside source static 192.168.22.49 2.2.2.4 vrf bank
ip nat inside source static 192.168.121.113 2.2.2.5 vrf park
ip nat inside source static 192.168.22.49 2.2.2.6 vrf park
ip nat inside source static 192.168.11.1 2.2.2.11 vrf shop
ip nat inside source static 192.168.11.3 2.2.2.12 vrf shop
ip nat inside source static 140.48.5.20 2.2.2.13 vrf shop
!
ip route 2.2.2.1 255.255.255.255 Ethernet1/0 192.168.121.113
ip route 2.2.2.2 255.255.255.255 Ethernet1/0 192.168.121.113
ip route 2.2.2.3 255.255.255.255 Serial2/1.1 192.168.121.113
ip route 2.2.2.4 255.255.255.255 Serial2/1.1 192.168.121.113
ip route 2.2.2.5 255.255.255.255 FastEthernet0/0 192.168.121.113
ip route 2.2.2.6 255.255.255.255 FastEthernet0/0 192.168.121.113
ip route 2.2.2.11 255.255.255.255 Ethernet1/0 192.168.121.113
ip route 2.2.2.12 255.255.255.255 Ethernet1/0 192.168.121.113
ip route 2.2.2.13 255.255.255.255 Ethernet1/0 192.168.121.113
```

Configuring Outside Dynamic NAT with MPLS VPNs Example

The following example shows configuring outside dynamic NAT with MPLS VPNs.

```
!  
ip nat pool outside 4.4.4.1 4.4.4.254 netmask 255.255.255.0  
ip nat inside source static 192.168.121.113 2.2.2.1 vrf shop  
ip nat inside source static 192.168.122.49 2.2.2.2 vrf shop  
ip nat inside source static 192.168.121.113 2.2.2.3 vrf bank  
ip nat inside source static 192.168.22.49 2.2.2.4 vrf bank  
ip nat inside source static 192.168.121.113 2.2.2.5 vrf park  
ip nat inside source static 192.168.22.49 2.2.2.6 vrf park  
ip nat outside source list 1 pool outside  
!
```

Configuring Outside Static NAT with MPLS VPNs Example

The following example shows configuring outside static NAT with MPLS VPNs.

```
!  
ip default-gateway 10.1.15.1  
ip nat pool inside1 2.2.1.1 2.2.1.254 netmask 255.255.255.0  
ip nat pool inside2 2.2.2.1 2.2.2.254 netmask 255.255.255.0  
ip nat pool inside3 2.2.3.1 2.2.3.254 netmask 255.255.255.0  
ip nat inside source list 1 pool inside2 vrf bank  
ip nat inside source list 1 pool inside3 vrf park  
ip nat inside source list 1 pool inside1 vrf shop  
ip nat outside source static 168.58.88.2 4.4.4.1 vrf bank  
ip nat outside source static 18.68.58.1 4.4.4.2 vrf park  
ip nat outside source static 168.58.88.1 4.4.4.3 vrf shop  
ip classless  
ip route 192.170.10.0 255.255.255.0 Ethernet1/0 192.168.121.113  
ip route 192.170.11.0 255.255.255.0 Serial2/1.1 192.168.121.113  
ip route 192.170.12.0 255.255.255.0 FastEthernet0/0 192.168.121.113  
ip route vrf shop 0.0.0.0 0.0.0.0 168.58.88.2 global  
ip route vrf bank 0.0.0.0 0.0.0.0 168.58.88.2 global  
ip route vrf park 0.0.0.0 0.0.0.0 168.58.88.2 global  
no ip http server  
!  
access-list 1 permit 192.168.0.0 0.0.255.255
```

Where to Go Next

- To learn about Network Address Translation and configure NAT for IP address conservation, see the “Configuring NAT for IP Address Conservation” module.
- To verify, monitor, and maintain NAT, see the “Monitoring and Maintaining NAT” module.
- To use NAT with application level gateways, see the “Using Application Level Gateways with NAT” module.
- To configure NAT for high availability, see the “Configuring NAT for High Availability” module.

Additional References

Related Documents

| Related Topic | Document Title |
|---------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------|
| NAT commands: complete command syntax, command mode, command history, defaults, usage guidelines and examples | <i>Cisco IOS IP Addressing Services Command Reference</i> |
| NAT high availability | “Configuring NAT for High Availability” module |
| Application Level Gateways | “Using Application Level Gateways with NAT” |
| Maintain and monitor NAT | “Monitoring and Maintaining NAT” module |
| IP Address Conservation | “Configuring NAT for IP Address Conservation” module |

Standards

| Standards | Title |
|-----------|-------|
| None | -- |

MIBs

| MIBs | MIBs Link |
|--------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> None | <p>To locate and download MIBs for selected platforms, Cisco IOS releases, and feature sets, use Cisco MIB Locator found at the following URL:</p> <p>http://www.cisco.com/go/mibs</p> |

RFCs

| RFCs ¹ | Title |
|-------------------|----------------------|
| RFC 2547 | <i>BGP/MPLS VPNs</i> |

¹ Not all supported RFCs are listed.

Technical Assistance

| Description | Link |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------|
| The Cisco Support and Documentation website provides online resources to download documentation, software, and tools. Use these resources to install and configure the software and to troubleshoot and resolve technical issues with Cisco products and technologies. Access to most tools on the Cisco Support and Documentation website requires a Cisco.com user ID and password. | http://www.cisco.com/cisco/web/support/index.html |

Feature Information for Integrating NAT with MPLS VPNs

The following table provides release information about the feature or features described in this module. This table lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Table 1 Feature Information for Integrating NAT with MPLS VPNs

| Feature Name | Releases | Feature Configuration Information |
|----------------------------------------------------------------------|-----------|---------------------------------------------------------------------------------------------------------------------------------------------------------|
| Network Address Translation (NAT) Integration with MPLS VPNs feature | 12.1(13)T | This feature allows multiple Multiprotocol Label Switching (MPLS) Virtual Private Networks (VPNs) to be configured on a single device to work together. |

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: www.cisco.com/go/trademarks. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

© 2011 Cisco Systems, Inc. All rights reserved.