



# HA Support for MLDP

---

**Last Updated: October 16, 2012**

The HA Support for MLDP feature enables Cisco Multicast Label Distribution Protocol (MLDP) to checkpoint sufficient signaling and forwarding information for repopulating the necessary database on a dual Route Processor (RP) platform on which Stateful Switchover/Nonstop Forwarding (SSO/NSF) and Label Distribution Protocol (LDP) Graceful Restart are configured, after a switchover.

© 2012 Cisco Systems, Inc. All rights reserved.



---

**Americas Headquarters:**  
Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA



## Finding Feature Information

---

**Last Updated: October 16, 2012**

Your software release may not support all the features documented in this module. For the latest caveats and feature information, see [Bug Search Tool](#) and the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the feature information table at the end of this module.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to [www.cisco.com/go/cfn](http://www.cisco.com/go/cfn). An account on Cisco.com is not required.

© 2012 Cisco Systems, Inc. All rights reserved.



# Prerequisites for HA Support for MLDP

---

**Last Updated: October 16, 2012**

- Stateful Switchover/Nonstop Forwarding (SSO/NSF) and LDP Graceful Restart must be configured on the dual Route Processor (RP) platform.
- LDP Graceful Restart must be configured on the NSF router peers.
- The Cisco IOS release software installed on the active and standby RPs must support MLDP-based MVPN and HA Support for MLDP.

© 2012 Cisco Systems, Inc. All rights reserved.



---

**Americas Headquarters:**  
Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA



## Restrictions for HA Support for MLDP

---

**Last Updated: October 16, 2012**

- If Label Distribution Protocol (LDP) Graceful Restart is not enabled on the dual Route Processor (RP) platform, Nonstop Forwarding (NSF) peers will remove existing forwarding and label information from their Multicast Label Distribution Protocol (MLDP) database entries immediately following a switchover.

© 2012 Cisco Systems, Inc. All rights reserved.



## Information About HA Support for MLDP

---

**Last Updated: October 16, 2012**

The HA Support for MLDP feature enables MLDP to checkpoint label forwarding or path set information. To support NSF, MLDP uses existing PIM HA architecture to checkpoint the information to the standby RP.

MDT data group creation is a dynamic event triggered by traffic exceeding a specified threshold. When the threshold is exceeded (requiring an MDT data group to be created) or when traffic falls below the threshold (requiring the MDT data group to be deleted), the router detecting the event creates, deletes, or updates an MDT data "send" entry, creates the corresponding (S,G) state, if necessary, and sends a message to PE peers to create, delete, or update a corresponding MDT data "receive" entry and the corresponding (S,G) state.

The active RP will checkpoint the current state of the MLDP peer, paths to peers, root, paths to root, and the database and replication/branch entry onto the standby RP and use this state to recreate the MLDP state after a switchover.

© 2012 Cisco Systems, Inc. All rights reserved.



---

**Americas Headquarters:**  
Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA



## How to Monitor HA Support for MLDP

Last Updated: October 16, 2012

- [Displaying Check Pointed Information, page 6](#)
- [Displaying Data MDT Mappings for MLDP on Standby Device, page 7](#)

## Displaying Check Pointed Information

### SUMMARY STEPS

1. enable
2. show mpls mldp ha database
3. show mpls mldp ha database summary
4. show mpls mldp ha neighbor
5. show mpls mldp ha root
6. show mpls mldp ha count

### DETAILED STEPS

	Command or Action	Purpose
Step 1	enable  Example: PE2> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 2</b>	<b>show mpls mldp ha database</b>  <b>Example:</b> PE2# show mpls mldp ha database	Displays checkpoint data information.
<b>Step 3</b>	<b>show mpls mldp ha database summary</b>  <b>Example:</b> PE2# show mpls mldp ha database summary	Displays synched database information only.
<b>Step 4</b>	<b>show mpls mldp ha neighbor</b>  <b>Example:</b> PE2# show mpls mldp ha neighbor	Displays information about synched peers.
<b>Step 5</b>	<b>show mpls mldp ha root</b>  <b>Example:</b> PE2# show mpls mldp ha root	Displays synched root information.
<b>Step 6</b>	<b>show mpls mldp ha count</b>  <b>Example:</b> PE2# show mpls mldp ha count	Displays number of trees.

## Displaying Data MDT Mappings for MLDP on Standby Device

### SUMMARY STEPS

1. enable
2. show ip pim vrf *vrf* mdt send
3. show ip pim vrf *vrf* mdt recv

## DETAILED STEPS

	Command or Action	Purpose
Step 1	<p><b>enable</b></p> <p><b>Example:</b> PE1-standby&gt; enable</p>	<p>Enables privileged EXEC mode.</p> <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>
Step 2	<p><b>show ip pim vrf <i>vrf</i> mdt send</b></p> <p><b>Example:</b> PE1-standby# show ip pim vrf blue mdt send</p>	<p>Displays data MDT mappings for MLDP.</p>
Step 3	<p><b>show ip pim vrf <i>vrf</i> mdt recv</b></p> <p><b>Example:</b> PE1-standby# show ip pim vrf blue mdt recv</p>	<p>Displays data MDT mappings for MLDP.</p>

© 2012 Cisco Systems, Inc. All rights reserved.





## Additional References

---

**Last Updated: October 16, 2012**

### Related Documents

Related Topic	Document Title
Cisco IOS commands	<a href="#">Cisco IOS Master Commands List, All Releases</a>
IP Multicast commands	<a href="#">Cisco IOS IP Multicast Command Reference</a>
Cisco HA	<i>High Availability Configuration Guide</i>

### Standards and RFCs

Standard/RFC	Title
No new or modified standards are supported, and support for existing standards has not been modified.	--
No new or modified RFCs are supported, and support for existing RFCs has not been modified.	--

### MIBs

MIB	MIBs Link
--	To locate and download MIBs for selected platforms, Cisco software releases, and feature sets, use Cisco MIB Locator found at the following URL: <a href="http://www.cisco.com/go/mibs">http://www.cisco.com/go/mibs</a>



---

**Americas Headquarters:**  
Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA

**Technical Assistance**

---

<b>Description</b>	<b>Link</b>
The Cisco Support and Documentation website provides online resources to download documentation, software, and tools. Use these resources to install and configure the software and to troubleshoot and resolve technical issues with Cisco products and technologies. Access to most tools on the Cisco Support and Documentation website requires a Cisco.com user ID and password.	<a href="http://www.cisco.com/cisco/web/support/index.html">http://www.cisco.com/cisco/web/support/index.html</a>

---

© 2012 Cisco Systems, Inc. All rights reserved.



# Feature Information for HA Support for MLDP

**Last Updated: October 16, 2012**

The following table provides release information about the feature or features described in this module. This table lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to [www.cisco.com/go/cfn](http://www.cisco.com/go/cfn). An account on Cisco.com is not required.

**Table 1**      **Feature Information for HA Support for MLDP**

Feature Name	Releases	Feature Information
HA Support for MLDP	15.1(3)S 15.1(1)SY	<p>The HA Support for MLDP feature enables Cisco Multicast Label Distribution Protocol (MLDP) to checkpoint sufficient signaling and forwarding information for repopulating the necessary database on a dual Route Processor (RP) platform on which Stateful Switchover/ Nonstop Forwarding (SSO/NSF) and Label Distribution Protocol (LDP) Graceful Restart are configured, after a switchover.</p> <p>The following commands were introduced or modified: <b>show ip pim mdt recv</b>, <b>show ip pim mdt send</b>, <b>show mpls mldp ha database</b>, <b>show mpls mldp ha neighbor</b>, <b>show mpls mldp ha root</b>.</p>

© 2012 Cisco Systems, Inc. All rights reserved.



**Americas Headquarters:**  
Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA



---

**Last Updated: October 16, 2012**

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: [www.cisco.com/go/trademarks](http://www.cisco.com/go/trademarks). Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

© 2012 Cisco Systems, Inc. All rights reserved.