

Control Plane Protection

The Control Plane Protection feature is an extension of the policing functionality provided by the existing Control-Plane Policing feature. The Control-Plane Policing feature allows Quality of Service (QoS) policing of aggregate control-plane traffic destined to the route processor. The Control Plane Protection feature extends this policing functionality by allowing finer policing granularity.

The functionality added with Control Plane Protection includes a traffic classifier, which intercepts traffic and classifies it into three control-plane categories. New port-filtering and queue-thresholding features have also been added. The port-filtering feature provides for policing of packets going to closed or nonlistened TCP/UDP ports, while queue-thresholding limits the number of packets for a specified protocol that will be allowed in the control-plane IP input queue.

- Finding Feature Information, page 1
- Prerequisites for Control Plane Protection, page 1
- Restrictions for Control Plane Protection, page 2
- Information About Control Plane Protection, page 3
- How to Configure Control Plane Protection, page 7
- Additional References, page 24
- Feature Information for Control Plane Protection, page 25

Finding Feature Information

Your software release may not support all the features documented in this module. For the latest caveats and feature information, see Bug Search Tool and the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the feature information table at the end of this module.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Prerequisites for Control Plane Protection

You understand the principles of Control-Plane Policing and how to classify control-plane traffic.

 You understand the concepts and general configuration procedure (class map and policy map) for applying QoS policies on a router.

For information about control plane policing and its capabilities, see the "Control Plane Policing" module.

For information about Cisco IOS QoS and the procedure for configuring QoS in your network using the Modular Quality of Service (QoS) Command-Line Interface (CLI) (MQC), see the *QoS: Modular QoS: Command-Line Interface Configuration Guide*.

Restrictions for Control Plane Protection

Control Plane Protection for IPv4

Control Plane Protection is restricted to IPv4 input path only.

No Support for Direct ACL Configuration

The current release of Control Plane Protection does not support direct access control list (ACL) configuration in the control-plane subinterfaces, but rather can be configured using Modular QoS CLI (MQC) policies.

Requires CEF

Control Plane Protection depends on Cisco Express Forwarding (CEF) for IP packet redirection. If you disable CEF globally, this will remove all active protect and policing policies configured on the control-plane subinterfaces. Aggregate control-plane interface policies will continue to function as normal.

Control-plane Feature Policy Restriction

Policies applicable on the control-plane host subinterface are subject to the following restrictions:

- The port-filter feature policy supports only TCP/UDP-based protocols.
- The queue-thresholding feature policy supports only TCP/UDP-based protocols.

No Support for Distributed or Hardware Switching Platforms

This release does not provide support for distributed or hardware switching platforms.

Control-plane IP Traffic Classification Restrictions

The control-plane host subinterface only supports TCP/UDP-based host traffic. All IP packets entering the control-plane matching any of the following conditions are not classified any further and are redirected to the cef-exception subinterface:

- IP Packets with IP options.
- IP Packets with TTL less than or equal to 1.

Protocols Auto-detected by the Port-filter

Some Cisco IOS TCP/UDP-based services, when configured, may not be auto-detected by the port-filter. That is, they do not get listed under the **show control-plane host open ports** output and they are not classified as an open port. This type of port must be manually added to the active port-filter class-map to be unblocked.

Control-plane Policing Subinterface Restrictions

There are no restrictions on existing aggregate control-plane policing policies. New control-plane policing policies that are configured on host subinterface will not process ARP traffic since ARP traffic is processed at the cef-exception and aggregate interfaces.

Information About Control Plane Protection

Benefits of Control Plane Protection

Configuring the Control Plane Protection feature on your Cisco router provides the following benefits:

- Extends protection against DoS attacks at infrastructure routers by providing mechanism for finer policing granularity for control-plane traffic that allows you to rate-limit each type individually.
- Provides a mechanism for early dropping of packets that are directed to closed or nonlistened IOS TCP/UDP ports.
- Provides ability to limit protocol queue usage such that no single protocol flood can overwhelm the input interface.
- Provides QoS control for packets that are destined to the control-plane of Cisco routers.
- Provides ease of configuration for control plane policies using MQC Infrastructure.
- Provides better platform reliability, security and availability.
- Provides dedicated control-plane subinterface for aggregate, host, transit and cef-exception control-plane traffic processing.
- Is highly flexible: permit, deny, rate-limit.
- Provides CPU protection so it can be used for important jobs, such as routing.

Control Plane Protection Architecture

The figure below shows control-plane architecture with the Control Plane Protection feature.

BGP ----Control feature path SNMP OSPF ---Process level execution context Global IP input queue Port filter Queue-CoPP Control-plane host sub-interface threshold ing policy CoPP Control-plane transit sub-interface CoPP Control-plane cef-exception sub-interface Aggregate Control Plane Policing (CoPP) CEF input Feature or Driver redirect Classify Packet Output packet buffer buffer Incoming 8 Packets

Figure 1: Control-plane Architecture with Control Plane Protection

The following sections describe the components of the Control Plane Protections feature.

CEF Input Forwarding Path

Control-plane Interface and Subinterfaces

Control Plane Policing (CoPP) introduced the concept of early rate-limiting protocol specific traffic destined to the processor by applying QoS policies to the aggregate control-plane interface. Control Plane Protection extends this control plane functionality by providing three additional control-plane subinterfaces under the top-level (aggregate) control-plane interface. Each subinterface receives and processes a specific type of control-plane traffic. The three subinterfaces are:

CEF/FIB lookup

• Control-plane host subinterface. This interface receives all control-plane IP traffic that is directly destined for one of the router interfaces. Examples of control-plane host IP traffic include tunnel termination traffic, management traffic or routing protocols such as SSH, SNMP, BGP, OSPF, and EIGRP. All host traffic terminates on and is processed by the router. Most control plane protection features and policies operate strictly on the control-plane host subinterface. Since most critical router control plane services, such as routing protocols and management traffic, is received on the control-plane host subinterface, it is critical to protect this traffic through policing and protection policies. CoPP, port-filtering and per-protocol queue thresholding protection features can be applied on the control-plane host subinterface.



Non-IP based Layer 2 protocol packets such as ARP or CDP do not fall within the control-plane host subinterface. These packets are currently classified in the control-plane CEF-exception subinterface traffic.

- Control-plane transit subinterface. This subinterface receives all control-plane IP traffic that is software switched by the route processor. This means packets that are not directly destined to the router itself but rather traffic traversing through the router. Nonterminating tunnels handled by the router is an example of this type of control-plane traffic. Control Plane Protection allows specific aggregate policing of all traffic received at this subinterface.
- Control-plane CEF-exception subinterface. This control-plane subinterface receives all traffic that is either redirected as a result of a configured input feature in the CEF packet forwarding path for process switching or directly enqueued in the control plane input queue by the interface driver (i.e. ARP, L2 Keepalives and all non-IP host traffic). Control Plane Protection allows specific aggregate policing of this type of control plane traffic.

QoS policies attached on any of the control-plane interfaces or subinterfaces execute at interrupt level prior to packets being enqueued to the IP input queue and sent to the processor.

The transit and CEF-exception control plane subinterfaces exist in parallel to the control plane host subinterface. This release of Control Plane Protection allows for rate-limiting policies to be configured on these paths as Control Plane Policing extensions. The port-filtering and per-protocol queue thresholding features are not available on these control-plane subinterfaces.

All protection features in the control plane are implemented as MQC policies that operate using the control plane class-maps and policy-maps. New class-map and policy-map types have been created for the control plane port-filter and per-protocol queue-threshold features.

Control-plane Port-filtering

The control-plane Port-filtering feature enhances control plane protection by providing for early dropping of packets directed toward closed or nonlistened IOS TCP/UDP ports on the router. The port-filter feature policy can be applied only to the control-plane host subinterface.

The port-filter maintains a global database of all open TCP and UDP ports on the router, including random ephemeral ports created by applications. The port database is dynamically populated with entries provided by the registered applications as they start listening on their advertised ports either by configuration of an application (that is SNMP) or initiation of an application (that is, TFTP transfer). An MQC class-map using the list of open ports can be configured and a simple drop policy can be applied to drop all packets destined to closed or nonlistened ports. Port-filter class-maps also support direct match of any user configured TCP/UDP port numbers.

Control-plane Queue-thresholding

Control-plane protocol Queue-thresholding feature provides a mechanism for limiting the number of unprocessed packets a protocol can have at process-level. This feature can only be applied to the control-plane host subinterface. The intent of this feature is to prevent the input queue from being overwhelmed by any single protocol traffic. Per-protocol thresholding follows a protocol charge model. Each protocol's queue usage is limited such that no single mis-behaving protocol process can jam the interface hold queue. In this

release, only a subset of TCP/UDP protocols can be configured for thresholding. Non-IP and Layer 2 protocols such as ARP and CDP cannot be configured. You can set queue limits for the following protocols:

- bgp—Border Gateway Protocol
- dns—Domain Name Server lookup
- ftp—File Transfer Protocol
- http—World Wide Web traffic
- igmp— Internet Group Management Protocol
- snmp—Simple Network Management Protocol
- · ssh-Secure Shell Protocol
- syslog—Syslog Server
- telnet—Telnet
- tftp—Trivial File Transfer Protocol
- host-protocols—A wild card for all TCP/UDP protocol ports open on the router not specifically matched/configured

Aggregate Control-plane Services

Control-plane Policing is an existing Cisco IOS feature that allows QoS policing of aggregate control-plane traffic destined to the route processor. The Control Plane Protection feature enhances protection for the router's control-plane by providing finer granularity of policing of traffic destined to the router's processor entering through any of the three control-plane subinterfaces. The CoPP feature is intended to be the first Control Plane Protection feature encountered by packets before any other features/policies. Existing (aggregate) Control-plane Policing policies will not be affected when the Control Plane Protection functionality is enabled. The aggregate Control-plane Policing policy will be applied on all control-plane traffic types. However, Control Plane Protection allows for additional and/or separate Control-plane Policing policies to be configured and applied on the different types of control-plane subinterfaces (host, transit, CEF-exception).

Control Plane Protection Configuration

The CLI for control-plane (introduced with the Control Plane Policing feature) has been extended to allow for CoPP policies to be applied to individual control-plane subinterfaces (host, transit, CEF-exception). The command syntax for creating CoPP Service Policies remains the same. In addition, the MQC class-map and policy-map CLI was modified to allow for additional types. The port-filter and queue-threshold policy features available in the host subinterface uses these new class-map and policy-map "types".

CoPP leverages MQC to define traffic classification criteria and to specify configurable policy actions for the classified traffic. Traffic of interest must first be identified via class-maps, which are used to define packets for a particular traffic class. Once classified, enforceable policy actions for the identified traffic are created with policy-maps. The **control-plane** global command allows the control-plane service policies to be attached to the aggregate control-plane interface itself.

The CLI for configuring Control-plane Policing policies on the new control-plane subinterfaces remains basically the same as the CLI introduced for Control-plane Policing. The only difference is in how you apply or attach the CoPP policy to the different control-plane subinterfaces.

How to Configure Control Plane Protection

Defining Packet Classification Criteria for CoPP

Perform this task to define the packet classification criteria for CoPP.

Before You Begin

Before you attach an existing QoS policy to the control-plane subinterface, you must first create the policy using the MQC to define a class map and policy map for control-plane traffic.

For information about how to classify traffic and create a QoS policy, see the *QoS: Modular QoS: Command-Line Interface Configuration Guide*.



- Note
- The Control-plane Policing feature requires the MQC to configure packet classification and policing. Thus, restrictions that apply to MQC also apply to control-plane policing.
- Only the following classification (match) criteria are supported: standard and extended IP access
 lists (named or numbered) and the match ip dscp command, the match ip precedence command,
 and the match protocol arp command.
- The control-plane policing CLI does not support "type" extensions available with other protection features. This is to preserve backward-compatibility.

SUMMARY STEPS

- 1. enable
- 2. configure terminal
- 3. class-map [match-any | match-all] class-map-name
- **4.** match {access-group | name access-group-name}

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example:	• Enter your password if prompted.
	Router> enable	

	Command or Action	Purpose
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Router# configure terminal	
Step 3	<pre>class-map [match-any match-all] class-map-name Example: Router(config) # class-map match-any control-plane-class</pre>	 Enables class map global configuration command mode used to create a traffic class. • match-any — Specifies that one of the match criterion must be met for traffic entering the traffic class to be classified as part of the traffic class. • match-all — Specifies that all match criterion must be met for traffic entering the traffic class to be classified as part of the traffic class. • class-map-name — Specifies the user-defined name of the traffic class. Names can be a maximum of 40 alphanumeric characters.
Step 4	<pre>match {access-group name access-group-name} Example: Router(config-cmap) # match access-group name cpp-igp-acl</pre>	Specifies the match criteria for the class-map.

Defining a CoPP Service Policy

To define a service policy, use the policy-map global configuration command to specify the service policy name, and use the configuration commands to associate a traffic class that was configured with the class-map command, with the QoS action. The traffic class is associated with the service policy when the class command is used. You must issue the class command after entering policy-map configuration mode. After entering the class command, you are automatically in policy-map class configuration mode.

For information about how to classify traffic and create a QoS policy, see the *QoS: Modular QoS: Command-Line Interface Configuration Guide*.



Note

- Platform-specific restrictions, if any, are checked when the service policy is applied to the control-plane interface.
- The Control-plane Policing feature requires the modular QoS command-line interface (CLI) (MQC) to configure packet classification and policing. Thus, restrictions that apply to MQC also apply to control-plane policing. Also, only two MQC actions are supported in policy maps police and drop.
- Support for output policing is available only in Cisco IOS Release 12.3(4)T and later T-train releases, and only on the aggregate control-plane interface. Only input policing is available on the new control-plane host, transit and CEF-exception subinterfaces. (Note that output policing does not provide any performance benefits. It simply controls the information that is leaving the device.)

SUMMARY STEPS

- 1. enable
- 2. configure terminal
- 3. policy-map policy-map-name
- 4. class class-name
- **5.** police rate [burst-normal] [burst-max] conform-action action exceed-action action [violate-action action]

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example:	• Enter your password if prompted.
	Router> enable	
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Router# configure terminal	
Step 3	policy-map policy-map-name	Enters policy map configuration mode to define a policy.
	Example:	• <i>policy-map-name</i> —Name of a service policy map. The name can be a maximum of 40 alphanumeric characters.
	Router(config)# policy-map control-plane-policy	
Step 4	class class-name	Enters class map configuration mode, which is used to associate a service policy with a class.
	Example:	• class-name —Name of a service policy class. The name can be a
	Router(config-pmap)# class control-plane-class	maximum of 40 alphanumeric characters.

	Command or Action	Purpose
•		To configure traffic policing, use the police command in policy-map class configuration mode or policy-map class police configuration mode.
	[violate-action action]	• rate —Specifies the police rate. If the police rate is specified in
	Example:	pps, the valid value range is 1 to 2000000. If the police rate is specified in bps, the valid range of values is 8000 to 10000000000.
	Router(config-pmap-c)# police rate 50000 pps conform-action transmit exceed-action drop	• pps —(Optional) Packets per second (pps) will be used to determine the rate at which traffic is policed.
		• conform-action action —Action to take on packets that conform to the rate limit.
		• exceed-action action —Action to take on packets that exceed the rate limit.

Entering Control Plane Configuration Mode

After you have created a class of traffic and defined the service policy for the control-plane, apply the policy to either the aggregate control-plane interface or one of the subinterfaces.



- Platform-specific restrictions, if any, are checked when the service policy is applied to the control-plane interface.
- Support for output policing is available only in Cisco IOS Release 12.3(4)T and later T-train releases, and only on the aggregate control-plane interface. Only input policing is available on the new control-plane host, transit and CEF-exception subinterfaces. (Note that output policing does not provide any performance benefits. It simply controls the information that is leaving the device.)

SUMMARY STEPS

- 1. enable
- 2. configure terminal
- 3. control-plane [host | transit | cef-exception]

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.

	Command or Action	Purpose	
		Enter your password if prompted.	
	Example:		
	Router> enable		
Step 2	configure terminal	Enters global configuration mode.	
	Example:		
	Router# configure terminal		
Step 3	control-plane [host transit cef-exception]	Enters control-plane configuration mode to attach a QoS policy that manages CP traffic to specified control-plane subinterface:	
	<pre>Example: Router(config) # control-plane</pre>	 host —enters control-plane host subinterface configuration mode. transit —enters control-plane transit subinterface configuration mode. 	
		• cef-exception —enters control-plane cef-exception subinterface configuration mode.	

Applying CoPP Service Policy

Perform this task to apply CoPP service policies to a control-plane interface.

Before You Begin

Before you attach an existing QoS policy to the control-plane, you must first create the policy by using MQC to define a class map and policy map for control-plane traffic.

For information about how to classify traffic and create a QoS policy, see the *QoS: Modular QoS: Command-Line Interface Configuration Guide*.



Note

- Platform-specific restrictions, if any, are checked when the service policy is applied to the control-plane interface.
- Support for output policing is available only in Cisco IOS Release 12.3(4)T and later T-train releases, and only on the aggregate control-plane interface. Only input policing is available on the new control-plane host, transit and CEF-exception subinterfaces. (Note that output policing does not provide any performance benefits. It simply controls the information that is leaving the device.)

SUMMARY STEPS

- 1. enable
- 2. configure terminal
- 3. control-plane [host | transit | cef-exception]
- **4. service-policy** {**input** | **output**} *policy-map-name*

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example:	• Enter your password if prompted.
	Router> enable	
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Router# configure terminal	
Step 3	control-plane [host transit cef-exception]	Attaches a QoS policy that manages CP traffic to a specified subinterface, and enters the control-plane configuration mode.
	<pre>Example: Router(config) # control-plane host</pre>	• host —applies policies to host control-plane traffic
		• transit — applies policies to transit control-plane traffic
		• cef-exception —applies policies to CEF-exception control-plane traffic
Step 4	service-policy {input output}	Attaches a QoS service policy to the control-plane.
	<pre>policy-map-name Example: Router(config-cp)# service-policy input control-plane-policy</pre>	• input —Applies the specified service policy to packets received on the control-plane.
		 output —Applies the specified service policy to packets transmitted from the control-plane and enables the router to silently discard packets.
		• <i>policy-map-name</i> —Name of a service policy map (created by using the policy-map command) to be attached. The name can be a maximum of 40 alphanumeric characters.

Configuring Port-filter Policy

You can apply the port-filter policy feature to the control-plane host subinterface to block traffic destined to closed or nonlistened TCP/UDP ports. New class-map and service-policy types have been created to accommodate the port-filter configuration. The classification and match criteria for the new port-filter class-maps supports only a constrained subset of the overall global MQC match criteria. Also, the actions supported by the new port-filter service policy is limited as well. that is only the drop action is supported

Restrictions

- The classification and match criteria for the new port-filter class-maps support only a constrained subset of the overall global MQC match criteria.
- The actions supported by the new port-filter service policy is limited. Only the drop action is supported.
- The port-filter feature policy can only be attached on the control-plane host subinterface.
- Some IOS TCP/UDP-based services, when configured, may not be auto-detected by the port filter. That is, they do not get listed under the "show control plane host open ports" output and are not classified as an open port. This type of port must be manually added to the active port filter class-map to be unblocked when using the 'closed-port' match criteria.

There are three required steps to configure a port-filter policy:

Defining Port-filter Packet Classification Criteria

Before you can attach a port-filter service policy to the control-plane host subinterface, you must first create the policy using the modified MQC to define a port-filter class-map and policy-map type for control-plane traffic.

A new MQC class-map type called *port-filter* was created for the port-filter feature. You must first create one or more port-filter class-map(s) before you can create your port-filter service policy. Your port-filter class-maps will separate your traffic into "classes" of traffic in which your service policy will define actions on.



Note

- The classification and match criteria for the new port-filter class-maps supports only a constrained subset of the overall global MQC match criteria. That is, only a subset of match protocol criteria is supported.
- Some IOS TCP/UDP-based services, when configured, may not be auto-detected by the port filter. That is, they do not get listed under the "show control plane host open ports" output and are not classified as an open port. This type of port must be manually added to the active port filter class-map to be unblocked when using the 'closed-port' match criteria.

SUMMARY STEPS

- 1. enable
- 2. class-map type port-filter [match-all | match-any] class name
- **3.** match { closed-ports | not | port} { TCP | UDP} 0-65535

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example:	• Enter your password if prompted.
	Router> enable	
Step 2	class-map type port-filter [match-all match-any] class name	Creates a class map used to match packets to a specified class and enables the port-filter class-map configuration mode.
	Example: Router(config) # class-map type port-filter match-all pf-class	 match-all —performs a logical AND on the match criteria match-any —performs a logical OR on the match criteria class-name —Name of a service policy class. The name can be a maximum of 40 alphanumeric characters.
Step 3	match { closed-ports not port} { TCP UDP} 0-65535 Example: Router(config-cmap) # match closed-ports	Specifies the TCP/UDP match criteria for the class-map • closed-ports — matches automatically on all closed-ports on the router • port — allows you to manually specify a TCP/UDP port to match on. • TCP — specifies a TCP port to match on • UDP — specifies an UDP port to match on

Defining Port-filter Service Policy

You can define a port-filter service policy that provides additional control-plane protection. Defining this policy supports early dropping of packets that are directed toward closed on nonlistened TCP/UDP ports on the router.

To configure a Port-filter service policy, use the new policy-map type port-filter global configuration command to specify the port-filter service policy name, and use the following configuration commands to associate a port-filter traffic class that was configured with the class-map type port-filter command, with the port-filter drop action command. The port-filter traffic class is associated with the service policy when the class command is used. The class command must be issued after entering policy-map configuration mode. After entering the class command, you are automatically in policy-map class configuration mode.



The actions supported by the new port-filter service policy is limited. Only the drop action is supported.

SUMMARY STEPS

- 1. enable
- 2. configure terminal
- 3. policy-map type port-filter policy-map-name
- 4. class class-name
- 5. drop

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example:	• Enter your password if prompted.
	Router> enable	
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Router# configure terminal	
Step 3	policy-map type port-filter policy-map-name	Creates the port-filter service policy and enters the policy-map configuration mode.
	Example: Router(config-pcmap)# policy-map type port-filter cppr-pf-policy	• <i>policy-map-name</i> —Name of a service policy map. The name can be a maximum of 40 alphanumeric characters.
Step 4	class class-name	Associates a service policy with a class and enters class map configuration mode.
	<pre>Example: Router(config-cmap)# class pf-class</pre>	• <i>class-name</i> —Name of a service policy class. The name can be a maximum of 40 alphanumeric characters.
Step 5	drop	Applies the port-filter service policy action on the class.
	Example:	
	Router (config-cmap)# drop	

Applying Port-filter Service Policy to the Host Subinterface

Perform this task to apply port-filter service policies to a subinterface.

Before You Begin

Before you attach a port-filter service policy to the control-plane host subinterface, you must first create the policy using MQC to define a class map and policy map for the required control-plane traffic.



The port-filter feature can only be applied on the control-plane host subinterface and only as input policy.

SUMMARY STEPS

- 1. enable
- 2. configure terminal
- 3. control-plane [host | transit | cef-exception]
- **4. service-policy type port-filter** {**input**} *port-filter-policy-map-name*

	Command or Action	Purpose	
Step 1	enable	Enables privileged EXEC mode.	
	Example:	• Enter your password if prompted.	
	Router> enable		
Step 2	configure terminal	Enters the global configuration mode.	
	Example: Router# configure terminal		
Step 3	control-plane [host transit cef-exception]	Attaches a QoS policy that manages traffic to the control-plane host subinterface and enters the control-plane configuration mode.	
	Example:	Note Port-filter can only be applied to the host subinterface.	
	Router(config)# control-plane host	host —enters the control-plane host subinterface configuration mode	
Step 4	<pre>service-policy type port-filter {input} port-filter-policy-map-name Example: Router(config-cp) # service-policy input cppr-pf-policy</pre>	Attaches a QoS service policy to the control-plane host subinterface. • input — Applies the specified service policy to packets received on the control-plane. • port-filter-policy-map-name — Name of a port-filter service policy map (created using the policy-map type port-filter command) to be attached. The name can be a maximum of 40 alphanumeric characters.	

Examples

The following example shows how to configure a port-filter policy to drop all traffic destined to closed or "nonlistened" TCP/UDP ports:

```
Router(config) # class-map type port-filter pf-class
Router(config-cmap) # match closed-ports
Router(config-cmap) # exit
Router(config) # policy-map type port-filter pf-policy
Router(config-pmap) # class pf-class
Router(config-pmap-c) # drop
Router(config-pmap-c) # end
Router#
```

The following example shows how to configure a port-filter policy to drop all traffic destined to closed or "nonlistened" ports except NTP.

```
Router(config) # class-map type port-filter pf-class
Router(config-cmap) # match not port udp 123
Router(config-cmap) # match closed-ports
Router(config-cmap) # exit
Router(config) # policy-map type port-filter pf-policy
Router(config-pmap) # class pf-class
Router(config-pmap-c) # drop
Router(config-pmap-c) # end
Router#
```

Configuring Queue-threshold Policy

The Control Plane Protection feature includes a new queue-threshold policy feature that can be applied to the control-plane host subinterface. The queue-threshold feature allows you to limit the number of packets for a given higher level protocol allowed in the control-plane IP input queue. Much like the port-filter feature, new class-map and policy-map types have been created to accommodate the queue-threshold feature. As with the port-filter feature, the queue-threshold feature supports a very specific class-map and policy-map capabilities.

Restrictions

- The classification and match criteria for the new queue-threshold class-maps supports only a constrained subset of the overall global MQC match criteria. That is, only a subset of match protocol option.
- The actions supported by the new queue-threshold service policy is limited. Only the queue-limit action is supported.
- The queue-threshold feature is supported only on the control-plane host subinterface as an input policy.

There are three steps required to configure a Queue-threshold policy:

Defining Queue-threshold Packet Classification Criteria

You can define a queue-threshold service policy when you want to limit the number of unprocessed packets that a protocol can have at process level.

Before you can attach a queue-threshold service policy to the control-plane host subinterface, you must first create the policy using the modified MQC to define a queue-threshold class-map and policy-map type for control-plane traffic.

A new MQC class-map type called *queue-threshold* was created for the queue-threshold feature. You must first create one or more queue-threshold class-map(s) before you can create your queue-threshold service policy. Your queue-threshold class-maps will separate your traffic into "classes" of traffic in which your service policy will define actions on.



The classification and match criteria for the new queue-threshold class-map supports only a constrained subset of the overall global MQC match criteria. That is, only a subset of the match protocol criteria is supported.

SUMMARY STEPS

- 1. enable
- 2. configure terminal
- 3. class-map type queue-threshold [match-all | match-any] class name
- $\textbf{4.} \quad match \ protocol \ [bgp|dns|ftp|http|igmp|snmp|ssh|syslog|telnet|tftp|host-protocols]}$

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example: Router> enable	Enter your password if prompted.
Step 2	configure terminal	Enters the global configuration mode.
	Example: Router# configure terminal	
Step 3	class-map type queue-threshold [match-all match-any] class name	Applies a class map for the queue-threshold and enables the queue-threshold class-map configuration mode.
	Example: Router(config) #class-map type queue-threshold match-all cppr-pf	 match-all —performs a logical AND on the match criteria match-any —performs a logical OR on the match criteria class-name —Name of a service policy class. The name can be a maximum of 40 alphanumeric characters.
Step 4	match protocol [bgp dns ftp http igmp snmp ssh syslog telnet tftp host-protocols]	Specifies the upper layer protocol match criteria for the class-map.

Command or Action	Purpose
	• bgp Border Gateway Protocol
Example:	• dns —Domain Name Server lookup
Router(config-cmap)# match protocol bgp	• ftp —File Transfer Protocol
	• http —World Wide Web traffic
	• igmp —Internet Group Management Protocol
	• snmp —Simple Network Management Protocol
	• ssh —Secure Shell Protocol
	• syslog —Syslog Server
	• telnet —Telnet
	• tftp —Trivial File Transfer Protocol
	• host-protocols —any open TCP/UDP port on the router.

Defining a Queue-threshold Service Policy

To configure a queue-threshold service policy, use the new policy-map type called queue-threshold global configuration command to specify the queue-threshold service policy name, and use the following configuration commands to associate a queue-threshold traffic class that was configured with the class-map type queue-threshold command, with the queue-threshold queue-limit action command. The queue-threshold traffic class is associated with the service policy when the class command is used. The class command must be issued after entering policy-map configuration mode. After entering the class command, you are automatically in policy-map class configuration mode.



Note

The actions supported by the new queue-threshold service policy is limited. Only the queue-limit action is supported.

SUMMARY STEPS

- 1. enable
- 2. configure terminal
- 3. policy-map type queue-threshold policy-name
- 4. class class-name
- **5.** queue-limit number

DETAILED STEPS

	Command or Action	Purpose	
Step 1	enable	Enables privileged EXEC mode.	
	Example:	Enter your password if prompted.	
	Router> enable		
Step 2	configure terminal	Enters the global configuration mode.	
	Example:		
	Router# configure terminal		
Step 3	policy-map type queue-threshold policy-name	Enables the queue-threshold service policy configuration mode.	
	Example:	• <i>policy-name</i> —Name of a service policy map. The name ca be a maximum of 40 alphanumeric characters.	
	Router(config)# policy-map type queue-threshold cppr-qt-policy		
Step 4	class class-name	Enters class map configuration mode used to associate a service policy with a class.	
	Example:	• class-name — Name of a service policy class. The name can	
	Router(config-pcmap)# class qt-class	be a maximum of 40 alphanumeric characters.	
Step 5	queue-limit number	Applies the queue-threshold service policy action on the class.	
	Example:	Note Queue limit range is 0 to 255.	
	Router(config-cmap) #queue-limit 75		

Applying a Queue-threshold Policy to the Host Subinterface

Perform this task to apply queue-threshold service policies to the control-plane host subinterface.

Before You Begin

Before you attach a queue-threshold service policy to the control-plane host subinterface, you must first create the policy by using MQC to define a class map and policy map for the required control-plane traffic.



Note

The queue-threshold feature can only be applied on the control-plane host subinterface as an input policy.

SUMMARY STEPS

- 1. enable
- 2. configure terminal
- 3. control-plane [host | transit | cef-exception]
- **4. service-policy type queue-threshold** {**input**} *queue-threshold-policy-map-name*

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example:	• Enter your password if prompted.
	Router> enable	
Step 2	configure terminal	Enters the global configuration mode.
	Example:	
	Router# configure terminal	
Step 3	control-plane [host transit cef-exception]	Attaches a QoS queue-threshold policy that manages traffic to the host subinterface and enters control-plane configuration mode.
	<pre>Example: Router(config) # control-plane host</pre>	• host —Enters the control-plane host subinterface configuration mode.
		Note queue-threshold can only be applied to the host subinterface.
Step 4	<pre>service-policy type queue-threshold {input} queue-threshold-policy-map-name Example: Router(config-cp) # service-policy input cppr-qt-policy</pre>	 input — Applies the specified service policy to packets received on the control-plane. aueue-threshold-policy-map-name — Name of a queue-threshold

Examples

The following example shows how to configure a queue-threshold policy to set the queue limit for SNMP protocol traffic to 50, telnet traffic to 50, and all other protocols to 150.

```
Router(config) # class-map type queue-threshold qt-snmp-class
Router(config-cmap) # match protocol snmp
Router(config-cmap) # class-map type queue-threshold qt-telnet-class
```

```
Router(config-cmap)# match protocol telnet
Router(config-cmap)# class-map type queue-threshold qt-other-class
Router(config-cmap)# match host-protocols
Router(config-cmap)# exit
Router(config-pmap)# class qt-snmp-class
Router(config-pmap)# class qt-snmp-class
Router(config-pmap-c)# queue-limit 50
Router(config-pmap-c)# class qt-telnet-class
Router(config-pmap-c)# queue-limit 50
Router(config-pmap-c)# class qt-other-class
Router(config-pmap-c)# queue-limit 150
Router(config-pmap-c)# queue-limit 150
Router(config-pmap-c)# end
Router#
```

Verifying Control Plane Protection

Use the **show policy-map control-plane** command to verify Control Plane Protection configurations and to view statistics for control-plane service policies.

To display information about the service policy attached to the control-plane, perform the following optional steps.

SUMMARY STEPS

- 1. enable
- 2. show policy-map [type policy-type] control-plane [pfx | slot slot number] [all] [host | transit | cef-exception] [{input | output} [class class-name]]

	Command or Action	Purpose
Step 1 enable En		Enables privileged EXEC mode.
	Example:	• Enter your password if prompted.
	Router> enable	
Step 2	show policy-map [type policy-type]	Displays information about the control-plane.
	<pre>control-plane [pfx slot slot number] [all] [host transit cef-exception] [{input output} [class class-name]]</pre>	• policy-type — Specifies policy-map type that you want statistics for (i.e. port-filter or queue-threshold)
	• pfx — Does not apply to Control Plane Protection feature.	
	Example: Router# show policy-map control-plane all	• slot — Does not apply to Control Plane Protection feature
		• all —Information for all control plane interfaces.
		• host —Policy-map and class-map statistics for the host path.
		• transit —Policy-map and class-map statistics for transit path.
		• cef-exception —Policy-map and class-map statistics for CEF-exception path.
		• input —Statistics for the attached input policy will be displayed.

Command or Action	Purpose
	• output —Statistics for the attached output policy will be displayed.
	• class class name — Name of class whose configuration and statistics are to be displayed.

Examples

The following example shows that the aggregate CoPP policy map named "copp-transit-policy" is associated with the control-plane transit subinterface and displays the statistics for that policy:

Router# show policy-map control-plane transit

```
control-plane Transit
Service-policy input: copp-transit-policy
Class-map: copp-transit-class (match-all)
8 packets, 592 bytes
5 minute offered rate 0 bps, drop rate 0 bps
Match: any
police:
    rate 2000 pps, burst 488 packets
    conformed 8 packets; actions:
        transmit
    exceeded 0 packets; actions:
        drop
    conformed 0 pps, exceed 0 pps
Class-map: class-default (match-any)
0 packets, 0 bytes
5 minute offered rate 0 bps, drop rate 0 bps
Match: any
```

The following example shows that the policy map "TEST" is associated with the aggregate control-plane interface. This policy map polices traffic that matches the class map "TEST," while allowing all other traffic (that matches the class map "class-default") to go through as is.

Router# show policy-map control-plane

```
control-plane
Service-policy input:TEST
Class-map: TEST (match-all)
      20 packets, 11280 bytes
      5 minute offered rate 0 bps, drop rate 0 bps
      Match:access-group 101
      police:
        8000 bps, 1500 limit, 1500 extended limit
        conformed 15 packets, 6210 bytes; action:transmit
        exceeded 5 packets, 5070 bytes; action:drop
        violated 0 packets, 0 bytes; action:drop
        conformed 0 bps, exceed 0 bps, violate 0 bps
Class-map:class-default (match-any)
      105325 packets, 11415151 bytes
      5 minute offered rate 0 bps, drop rate 0 bps
      Match:any
```

Additional References

Related Documents

Related Topic	Document Title
QoS commands: complete command syntax, command modes, command history, defaults, usage guidelines, and examples	Cisco IOS Quality of Service Solutions Command Reference
QoS feature overview	"Quality of Service Overview" module

Standards

Standard	Title
No new or modified standards are supported by this feature, and support for existing standards has not been modified by this feature.	

MIBs

MIB		MIBs Link
Note	CISCO-CLASS-BASED-QOS-MIB Supported only in Cisco IOS Release 12.3(7)T.	To locate and download MIBs for selected platforms, Cisco IOS releases, and feature sets, use Cisco MIB Locator, found at the following URL: http://www.cisco.com/go/mibs

RFCs

RFC	Title
None	_

Technical Assistance

Description	Link
The Cisco Technical Support website contains thousands of pages of searchable technical content, including links to products, technologies, solutions, technical tips, and tools. Registered Cisco.com users can log in from this page to access even more content.	

Feature Information for Control Plane Protection

The following table provides release information about the feature or features described in this module. This table lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to . An account on Cisco.com is not required.

Table 1: Feature Information for Control Plane Protection

Feature Name	Releases	Feature Information
Control Plane Protection	12.4(4)T	The Control Plane Protection feature is an extension of the policing functionality provided by the existing Control-Plane Policing feature. The Control-Plane Policing feature allows QoS policing of aggregate control-plane traffic destined to the route processor. The Control Plane Protection feature extends this policing functionality by allowing finer policing granularity. The following commands were
		introduced or modified: class-map, control-plane, show policy-map control-plane

Feature Information for Control Plane Protection