



# Displaying and Clearing IP Access List Data Using ACL Manageability

---

This module describes how to display the entries in an IP access list and the number of packets that have matched each entry. Users can get these statistics globally, or per interface and per incoming or outgoing traffic direction, by using the ACL Manageability feature. Viewing details of incoming and outgoing traffic patterns on various interfaces of a network device can help secure devices against attacks coming in on a particular interface. This module also describes how to clear counters so that the count of packets matching an access list entry will restart from zero.

- [Finding Feature Information, on page 1](#)
- [Information About Displaying and Clearing IP Access List Data Using ACL Manageability, on page 2](#)
- [How to Display and Clear IP Access List Data, on page 2](#)
- [Configuration Examples for Displaying and Clearing IP Access List Data Using ACL Manageability, on page 4](#)
- [Additional References, on page 6](#)
- [Feature Information for Displaying IP Access List Information and Clearing Counters, on page 7](#)

## Finding Feature Information

Your software release may not support all the features documented in this module. For the latest caveats and feature information, see [Bug Search Tool](#) and the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the feature information table.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to [www.cisco.com/go/cfn](http://www.cisco.com/go/cfn). An account on Cisco.com is not required.

# Information About Displaying and Clearing IP Access List Data Using ACL Manageability

## Benefits of ACL Manageability

Prior to Cisco IOS Release 12.4(6)T, the ACL infrastructure in Cisco IOS software maintained only global statistics for each ACE in an ACL. With this method, if an ACL is applied to multiple interfaces, the maintained ACE statistics are the sum of incoming and outgoing packet matches (hits) on all the interfaces on which that ACL is applied.

However, if ACE statistics are maintained per interface and per incoming or outgoing traffic direction, users can view specific details of incoming and outgoing traffic patterns and the effectiveness of ACEs on the various interfaces of a network device. This type of information is useful for securing devices against attacks coming in on a particular interface.

## Support for Interface-Level ACL Statistics

With Cisco IOS Release 12.4(6)T, the ACL infrastructure in Cisco IOS software is now extended to support the maintenance, display, and clearing of ACE statistics per interface and per incoming or outgoing traffic direction for ACLs. This support is often referred to as “support for interface-level statistics.”



---

**Note** If the same access-group ACL is also used by other features, the maintained interface statistics are not updated when a packet match is detected by the other features. In this case, the sum of all the interface level statistics that are maintained for an ACL may not add up to the global statistics for that ACL.

---

## How to Display and Clear IP Access List Data

This section contains the following procedures for displaying IP access lists and the counts of packets that match (hit) each list, and for clearing IP access list counters.



---

**Note** Alternatively, if you want to deny access to a particular host or network and find out if someone from that network or host is attempting to gain access, include the **log** keyword with the corresponding **deny** statement so that the packets denied from that source are logged for you. For more information, see the “IP Access List Logging” section of the “IP Access List Overview.”

---

## Displaying Global IP ACL Statistics

Perform this task to display all IP access lists on the router and counts of packets that have matched.

**SUMMARY STEPS**

1. **enable**
2. **show ip access-list** [*access-list-number* | *access-list-name*]

**DETAILED STEPS**

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b> <b>Example:</b> Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>
<b>Step 2</b>	<b>show ip access-list</b> [ <i>access-list-number</i>   <i>access-list-name</i> ] <b>Example:</b> Router# show ip access-list limited	Displays IP access list information. <ul style="list-style-type: none"> <li>• This example displays statistics for all interfaces that use the access list named “limited.”</li> </ul>

## Displaying Interface-Level IP ACL Statistics

This section describes how to display IP ACE statistics per interface and per incoming or outgoing traffic direction for ACLs. This feature is known as ACL Manageability.



**Note**

- ACL Manageability supports:
  - Only nondistributed software switched platforms.
  - Standard and extended statically configured ACLs, and Threat Mitigation Service (TMS) dynamic ACEs.
- ACL Manageability does not support:
  - Reflexive and user-configured dynamic ACLs and dynamic ACE blocks, such as Firewall and Authentication Proxy.
  - Virtual-template and virtual-access interfaces.

>

**SUMMARY STEPS**

1. **enable**
2. **show ip access-list interface** *interface-name* [**in**| **out**]

**DETAILED STEPS**

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b> <b>Example:</b>	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>

	Command or Action	Purpose
	Router> enable	
<b>Step 2</b>	<b>show ip access-list interface <i>interface-name</i> [in out]</b> <b>Example:</b> <pre>Router# show ip access-list interface FastEthernet 0/0 in</pre>	Displays IP access list information. <ul style="list-style-type: none"> <li>• This example displays statistics about traffic coming into the FastEthernet interface.</li> <li>• To display debugging information about ACL interface-level statistics, use the <b>debug ip access-list intstats</b> command.</li> </ul>

## Clearing the Access List Counters

The system counts how many packets match (hit) each line of an access list; the counters are displayed by the **show access-lists EXEC** command. Perform this task to clear the counters of an access list. You might do this if you are trying to determine a more recent count of packets that match an access list, starting from zero.

### SUMMARY STEPS

1. enable
2. clear ip access-list counters {*access-list-number* | *access-list-name*}

### DETAILED STEPS

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b> <b>Example:</b> <pre>Router&gt; enable</pre>	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>
<b>Step 2</b>	<b>clear ip access-list counters {<i>access-list-number</i>   <i>access-list-name</i>}</b> <b>Example:</b> <pre>Router# clear access-list counters corpmark</pre>	Clears IP access list counters.

# Configuration Examples for Displaying and Clearing IP Access List Data Using ACL Manageability

## Example Displaying Global IP ACL Statistics

The following example displays global statistics for ACL 150:

```
Router# show ip access-list 150

Extended IP access list 150
 10 permit ip host 10.1.1.1 any (3 matches)
 30 permit ip host 10.2.2.2 any (27 matches)
```

## Example Displaying Input Statistics

The following example displays statistics on incoming packets gathered from the FastEthernet interface 0/1, associated with access list 150 (ACL number):

```
Router#
show ip access-list interface FastEthernet 0/1 in
Extended IP access list 150 in
 10 permit ip host 10.1.1.1 any (3 matches)
 30 permit ip host 10.2.2.2 any (12 matches)
```

## Example Displaying Output Statistics

The following example displays statistics on outgoing packets gathered from the FastEthernet interface 0/0:

```
Router#
show ip access-list interface FastEthernet 0/0 out
Extended IP access list myacl out
 5 deny ip any 10.1.0.0 0.0.255.255
 10 permit udp any any eq snmp (6 matches)
```

## Example Displaying Input and Output Statistics



---

**Note** If no direction is specified, any input and output ACLs applied to that interface are displayed.

---

The following example displays input and output statistics gathered from the FastEthernet interface 0/0:

```
Router#
show ip access-list interface FastEthernet 0/0
Extended IP access list 150 in
 10 permit ip host 10.1.1.1 any
 30 permit ip host 10.2.2.2 any (15 matches)
Extended IP access list myacl out
 5 deny ip any 10.1.0.0 0.0.255.255
 10 permit udp any any eq snmp (6 matches)
```

## Example Clearing Global and Interface Statistics for an IP Access List

The following example clears global and interface statistics for IP ACL 150:

```
Router#
clear ip access-list counters 150
```

## Example Clearing Global and Interface Statistics for All IP Access Lists

The following example clears global and interface statistics for all IP ACLs:

```
Router#
clear ip access-list counters
```

## Additional References

### Related Documents

Related Topic	Document Title
Cisco IOS commands	<a href="#">Cisco IOS Master Commands List, All Releases</a>
Security commands	<i>Cisco IOS Security Command Reference</i>

### Standards

Standard	Title
No new or modified standards are supported by this feature.	--

### MIBs

MIB	MIBs Link
No new or modified MIBs are supported by this feature.	To locate and download MIBs for selected platforms, Cisco IOS releases, and feature sets, use Cisco MIB Locator found at the following URL: <a href="http://www.cisco.com/go/mibs">http://www.cisco.com/go/mibs</a>

### RFCs

RFC	Title
No new or modified standards are supported by this feature, and support for existing standards has not been modified by this feature.	--

**Technical Assistance**

Description	Link
The Cisco Support and Documentation website provides online resources to download documentation, software, and tools. Use these resources to install and configure the software and to troubleshoot and resolve technical issues with Cisco products and technologies. Access to most tools on the Cisco Support and Documentation website requires a Cisco.com user ID and password.	<a href="http://www.cisco.com/cisco/web/support/index.html">http://www.cisco.com/cisco/web/support/index.html</a>

## Feature Information for Displaying IP Access List Information and Clearing Counters

The following table provides release information about the feature or features described in this module. This table lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to [www.cisco.com/go/cfn](http://www.cisco.com/go/cfn). An account on Cisco.com is not required.

*Table 1: Feature Information for Displaying and Clearing IP Access List Data Using ACL Manageability*

Feature Name	Releases	Feature Information
ACL Manageability	Cisco IOS XE Release 3.9S	The ACL Manageability feature enables users to display and clear Access Control Entry (ACE) statistics per interface and per incoming or outgoing traffic direction for access control lists (ACLs).

