

SNMP Support for VLAN Subinterfaces

This feature module describes the SNMP Support for VLAN Subinterfaces feature. It includes information on the benefits of the new feature, supported platforms, supported standards, and the commands necessary to configure the SNMP Support for VLAN Subinterfaces feature.

The SNMP Support for VLAN Subinterfaces feature provides mib-2 interfaces sparse table support for Fast Ethernet subinterfaces. This enhancement is similar to the functionality supported in Frame Relay subinterfaces.

- Finding Feature Information, on page 1
- Information About SNMP Support for VLAN Subinterfaces, on page 1
- How to SNMP Support for VLAN Subinterfaces, on page 2
- Configuration Examples for SNMP Support for VLAN Subinterfaces, on page 3
- Additional References, on page 4
- Feature Information for SNMP Support for VLAN Subinterfaces, on page 5

Finding Feature Information

Your software release may not support all the features documented in this module. For the latest caveats and feature information, see Bug Search Tool and the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the feature information table.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Information About SNMP Support for VLAN Subinterfaces

Benefits

Sparse table support for the interfaces table on Fast Ethernet subinterfaces provides customers accustomed to Frame Relay subinterfaces the same functionality.

Supported Platforms

Cisco 2600 series

- Cisco 3600 series
- Cisco 4000-m series
- · Cisco 7200 series
- Cisco 7500 series

How to SNMP Support for VLAN Subinterfaces

Enabling the SNMP Agent on VLAN Subinterfaces

Perform the following task to enable the SNMP agent on VLAN subinterfaces.

SUMMARY STEPS

- 1. enable
- 2. configure terminal
- 3. snmp community string
- **4.** interface type slot/port
- 5. encapsulation isl vlan-identifier
- 6. ip address ip-address mask
- **7.** end
- 8. show vlans

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example:	• Enter your password if prompted.
	Router> enable	
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Router# configure terminal	
Step 3	snmp community string	Enables the SNMP agent for remote access.
	Example:	
	Router(config)# snmp community public	
Step 4	interface type slot/port	Selects a particular Fast Ethernet interface for configuration.
	Example:	
	Router(config)# interface FastEthernet 0/1.1	

	Command or Action	Purpose
Step 5	encapsulation isl vlan-identifier	Enables the Inter-Switch Link.
	Example:	
	Router(config-if)# encapsulation isl 10	
Step 6	ip address ip-address mask	Sets a primary or secondary IP address for an interface.
	Example:	
	Router(config)# ip address 192.168.10.1 255.255.255.0	
Step 7	end	Returns to privileged EXEC mode.
	Example:	
	Router(config-if)# end	
Step 8	show vlans	Displays VLAN subinterfaces.
	Example:	
	Router# show vlans	

Configuration Examples for SNMP Support for VLAN Subinterfaces

Example Enabling the SNMP Agent for VLAN Subinterfaces

The following configuration example shows you how to enable the SNMP agent on the router with VLAN subinterfaces to monitor the SNMP application remotely:

```
snmp community public
!
interface FastEthernet4/0.100
encapsulation is1 100
ip address 192.168.10.21 255.255.255.0
!
interface FastEthernet4/0.200
encapsulation is1 200
ip address 172.21.200.11 255.255.255.0
!
interface FastEthernet4/1.1
encapsulation is1 10
ip address 171.69.2.111 255.255.255.0
```

Additional References

Related Documents

Related Topic	Document Title
Cisco IOS commands	Cisco IOS Master Commands List, All Releases
SNMP commands	Cisco IOS Network Management Command Reference

Standards

Standard	Title
None	

MIBs

MIB	MIBs Link
	To locate and download MIBs for selected platforms, Cisco software releases, and feature sets, use Cisco MIB Locator found at the following URL:
	http://www.cisco.com/go/mibs

RFCs

RFC	Title
RFC 1573	Evolution of the Interfaces Group of MIB-II

Technical Assistance

Description	Link
The Cisco Support and Documentation website provides online resources to download documentation, software, and tools. Use these resources to install and configure the software and to troubleshoot and resolve technical issues with Cisco products and technologies. Access to most tools on the Cisco Support and Documentation website requires a Cisco.com user ID and password.	

Feature Information for SNMP Support for VLAN Subinterfaces

The following table provides release information about the feature or features described in this module. This table lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Table 1: Feature Information for SNMP Support for VLAN Subinterfaces

Feature Name	Releases	Feature Information
SNMP Support for VLAN Subinterfaces	12.2	The SNMP Support for VLAN Subinterfaces feature provides mib-2 interfaces sparse table support for Fast Ethernet subinterfaces. This enhancement is similar to the functionality supported in Frame Relay subinterfaces.

Feature Information for SNMP Support for VLAN Subinterfaces