



# Configuring an Error Response Code upon an Out-of-Dialog OPTIONS Ping Failure

**Last Updated: December 20, 2011**

Cisco Unified Border Element (Cisco UBE) provides an option to configure the error response code when a dial peer is busied out because of an Out-of-Dialog OPTIONS ping failure.

The OPTIONS ping mechanism monitors the status of a remote Session Initiation Protocol (SIP) server, proxy or endpoints. Cisco UBE monitors these endpoints periodically. When there is no response from these monitored endpoints, the configured dial peer is busied out. If the dial-peer endpoint is busied out due to an OPTIONS ping failure, the call is passed on to the next dial-peer endpoint if an alternate dial peer is configured for the same destination. Otherwise the error response 404 is sent. This feature provides the option of configuring the error response code to reroute the call. Therefore when a dial peer is busied out due to the OPTIONS ping failure, the SIP error code configured in the inbound dial-peer is sent as a response.

To configure the SIP error code response, perform the following tasks:

- [Finding Feature Information, page 1](#)
- [Prerequisites for Configuring an Error Response Code upon an Out-of-Dialog OPTIONS Ping Failure, page 2](#)
- [Restrictions for Configuring an Error Response Code upon an Out-of-Dialog OPTIONS Ping Failure, page 2](#)
- [Configuring an Error Response Code upon an Out-of-Dialog OPTIONS Ping Failure at the Global Level, page 2](#)
- [Configuring an Error Response Code upon an Out-of-Dialog OPTIONS Ping Failure at the Dial Peer Level, page 4](#)
- [Troubleshooting Tips, page 6](#)
- [Feature Information for Configuring an Error Response Code upon an Out-of-Dialog OPTIONS Ping Failure, page 6](#)

## Finding Feature Information

Your software release may not support all the features documented in this module. For the latest feature information and caveats, see the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the Feature Information Table at the end of this document.



---

**Americas Headquarters:**  
Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to [www.cisco.com/go/cfn](http://www.cisco.com/go/cfn). An account on Cisco.com is not required.

## Prerequisites for Configuring an Error Response Code upon an Out-of-Dialog OPTIONS Ping Failure

- The Cisco UBE Out-of-Dialog (OOD) OPTIONS Ping for Specified SIP Servers or Endpoints feature should be configured before configuring this error response code for a ping OPTIONS failure.

### Cisco Unified Border Element

- Cisco IOS Release 15.1(1)T or a later release must be installed and running on your Cisco Unified Border Element.

### Cisco Unified Border Element (Enterprise)

- Cisco IOS XE Release 3.1S or a later release must be installed and running on your Cisco ASR 1000 Series Router.

## Restrictions for Configuring an Error Response Code upon an Out-of-Dialog OPTIONS Ping Failure

The error code configuration will not have any effect if it is configured on the outbound dial peer.

## Configuring an Error Response Code upon an Out-of-Dialog OPTIONS Ping Failure at the Global Level

The table below describes the SIP error codes.

**Table 1**      *SIP Error Codes*

Error Code Number	Description
400	Bad Request
401	Unauthorized
402	Payment Required
403	Forbidden
404	Not Found
408	Request Timed Out

Error Code Number	Description
416	Unsupported URI
480	Temporarily Unavailable
482	Loop Detected
484	Address Incomplete
486	Busy Here
487	Request Terminated
488	Not Acceptable Here
500-599	SIP 5xx--Server/Service Failure
500	Internal Server Error
502	Bad Gateway
503	Service Unavailable
600-699	SIP 6xx--Global Failure

To configure the error response code for the OPTIONS ping failure to support the Cisco Unified Border Element at the global level, perform the steps in this section.

### SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **voice service voip**
4. **sip**
5. **error-code-override options-keepalive failure sip-status-code-number**
6. **end**

### DETAILED STEPS

Command or Action	Purpose
<b>Step 1</b> <b>enable</b>  <b>Example:</b> Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>

Command or Action	Purpose
<b>Step 2</b> <code>configure terminal</code>  <b>Example:</b> <pre>Router# configure terminal</pre>	Enters global configuration mode.
<b>Step 3</b> <code>voice service voip</code>  <b>Example:</b> <pre>Router(config)# voice service voip</pre>	Enters voice service configuration mode.
<b>Step 4</b> <code>sip</code>  <b>Example:</b> <pre>Router(conf-voi-serv)# sip</pre>	Enters voice service SIP configuration mode.
<b>Step 5</b> <code>error-code-override options-keepalive failure sip-status-code-number</code>  <b>Example:</b> <pre>Router(conf-serv-sip)# error-code-override options-keepalive failure 402</pre>	Configures the specified SIP error code number. <ul style="list-style-type: none"> <li>• <i>sip-status-code-number</i> --SIP status code to be sent for an options keepalive failure. Range: 400 to 699. Default: 503.</li> <li>• The table above provides more details about these error codes.</li> </ul>
<b>Step 6</b> <code>end</code>  <b>Example:</b> <pre>Router(conf-serv-sip)# end</pre>	Exits voice service SIP configuration mode and returns to privileged EXEC mode.

## Configuring an Error Response Code upon an Out-of-Dialog OPTIONS Ping Failure at the Dial Peer Level

To configure the error response code for the OPTIONS ping failure to support the Cisco Unified Border Element at the dial-peer level, perform the steps in this section.

**SUMMARY STEPS**

1. enable
2. configure terminal
3. dial-peer voice *voice-dial-peer-tag* voip
4. voice-class sip error-code-error-override options-keepalive failure {*sip-status-code-number* | system}
5. end

**DETAILED STEPS**

Command or Action	Purpose
<p><b>Step 1</b> enable</p> <p><b>Example:</b></p> <pre>Router&gt; enable</pre>	<p>Enables privileged EXEC mode.</p> <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>
<p><b>Step 2</b> configure terminal</p> <p><b>Example:</b></p> <pre>Router# configure terminal</pre>	<p>Enters global configuration mode.</p>
<p><b>Step 3</b> dial-peer voice <i>voice-dial-peer-tag</i> voip</p> <p><b>Example:</b></p> <pre>Router(config)# dial-peer voice 234 voip</pre>	<p>Enters dial peer voice configuration mode.</p>
<p><b>Step 4</b> voice-class sip error-code-error-override options-keepalive failure {<i>sip-status-code-number</i>   system}</p> <p><b>Example:</b></p> <pre>Router(config-dial-peer)# voice-class sip error-code-override options-keepalive failure 500</pre>	<p>Configures the specified SIP error code number.</p> <ul style="list-style-type: none"> <li>• <i>sip-status-code-number</i> --SIP status code to be sent for an options keepalive failure. Range: 400 to 699. Default: 503.</li> <li>• <a href="#">Configuring an Error Response Code upon an Out-of-Dialog OPTIONS Ping Failure at the Dial Peer Level, page 4</a> provides more details about these error codes.</li> </ul> <p><b>Note</b> If the <b>system</b> keyword is configured, the global level configuration will override the dial-peer configuration.</p>
<p><b>Step 5</b> end</p> <p><b>Example:</b></p> <pre>Router(config-dial-peer)# end</pre>	<p>Exits dial peer voice configuration mode and returns to privileged EXEC mode.</p>

## Troubleshooting Tips

The following debug commands display any error that occurs with the error code response:

- **debug ccsip messages**-- shows SIP messages.

```
Router# debug ccsip messages
SIP Call messages tracing is enabled
```

- **debug ccsip all** --shows all SIP-related debugging.

```
Router# debug ccsip all
This may severely impact system performance. Continue? [confirm]
All SIP Call tracing is enabled
```

## Feature Information for Configuring an Error Response Code upon an Out-of-Dialog OPTIONS Ping Failure

The following table provides release information about the feature or features described in this module. This table lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to [www.cisco.com/go/cfn](http://www.cisco.com/go/cfn). An account on Cisco.com is not required.

Feature History Table entry for the Cisco Unified Border Element.

**Table 2** *Feature Information for Configuring an Error Response Code upon an Out-of-Dialog OPTIONS Ping Failure*

Feature Name	Releases	Feature Information
Error Response Code upon an Out-of-Dialog OPTIONS Ping Failure	15.1(1)T	This feature provides option to configure the error response code when a dial peer is busied out because of an Out-of-Dialog OPTIONS ping failure.  The following commands were introduced or modified in this release: <b>error-code-override options-keepalive failure</b> , <b>voice-class sip error-code-override options-keepalive failure</b> .

Feature History Table entry for the Cisco Unified Border Element (Enterprise)

**Table 3**      **Feature Information for Configuring an Error Response Code upon an Out-of-Dialog OPTIONS Ping Failure**

Feature Name	Releases	Feature Information
Error Response Code upon an Out-of-Dialog OPTIONS Ping Failure	Cisco IOS XE Release 3.1S	<p>This feature provides option to configure the error response code when a dial peer is busied out because of an Out-of-Dialog OPTIONS ping failure.</p> <p>The following commands were introduced or modified in this release: <b>error-code-override options-keepalive failure, voice-class sip error-code-override options-keepalive failure.</b></p>

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: [www.cisco.com/go/trademarks](http://www.cisco.com/go/trademarks). Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

© 2011 Cisco Systems, Inc. All rights reserved.