



# Providing Connectivity Using ATM Routed Bridge Encapsulation over PVCs

---

**First Published:** May 2, 2005

**Last Updated:** November 10, 2010

The Providing Connectivity Using ATM Routed Bridge Encapsulation over PVCs feature provides the functionality of bridged ATM interface support to ATM switched virtual circuits (SVCs). Unlike permanent virtual circuits (PVCs), SVCs must be triggered by ongoing traffic and can be brought down when idle for some time. The SVCs are triggered, if down, and the traffic is passed on to the SVCs belonging to bridged ATM interface.

ATM routed bridge encapsulation (RBE) is used to route IP over bridged RFC 1483 Ethernet traffic from a stub-bridged LAN.

## Finding Feature Information

Your software release may not support all the features documented in this module. For the latest feature information and caveats, see the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the “[Feature Information for Providing Connectivity Using ATM Routed Bridge Encapsulation](#)” section on page 16.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to <http://www.cisco.com/go/cfn>. An account on Cisco.com is not required.

## Contents

- [Prerequisites for Providing Connectivity Using ATM Routed Bridge Encapsulation over PVCs, page 2](#)
- [Restrictions for Providing Connectivity Using ATM Routed Bridge Encapsulation over PVCs, page 2](#)



---

**Americas Headquarters:**  
**Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA**

**Prerequisites for Providing Connectivity Using ATM Routed Bridge Encapsulation over PVCs**

- [Information About Providing Connectivity Using ATM Routed Bridge Encapsulation over PVCs, page 2](#)
- [How to Configure ATM Routed Bridge Encapsulation over PVCs, page 5](#)
- [Configuration Examples for Providing Connectivity Using ATM Routed Bridge Encapsulation, page 11](#)
- [Additional References, page 14](#)
- [Feature Information for Providing Connectivity Using ATM Routed Bridge Encapsulation, page 16](#)

## **Prerequisites for Providing Connectivity Using ATM Routed Bridge Encapsulation over PVCs**

- When ATM SVCs are used, support for a form of bridging, such as integrated routing and bridging, is required.
- Before configuring connectivity from a remote bridged Ethernet network to a routed network using ATM routed bridge encapsulation, you must understand the concepts in the [\*Understanding Broadband Access Aggregation\*](#) module.

## **Restrictions for Providing Connectivity Using ATM Routed Bridge Encapsulation over PVCs**

- Unlike PVCs, SVCs must be triggered by ongoing traffic and might be brought down after they have been idle for some time. The Bridged 1483 Encapsulated Traffic over ATM SVCs feature allows for the SVC to be triggered if down, and to pass the traffic on to the SVCs belonging to the bridged ATM interface.
- ATM RBE does not support MAC-layer access lists; only IP access lists are supported.

## **Information About Providing Connectivity Using ATM Routed Bridge Encapsulation over PVCs**


- [Overview on Bridged 1483 Encapsulated Traffic over ATM SVCs, page 2](#)
- [ATM RBE Subinterface Grouping by PVC Range, page 3](#)
- [ATM RBE Subinterface Grouping by PVC Range, page 3](#)
- [DHCP Option 82 Support for RBE, page 3](#)
- [DHCP Lease Limit per ATM RBE Unnumbered Interface, page 5](#)
- [Benefits of Providing Connectivity Using ATM Routed Bridge Encapsulation, page 5](#)

## **Overview on Bridged 1483 Encapsulated Traffic over ATM SVCs**

ATM RBE is used to route IP over bridged RFC 1483 Ethernet traffic from a stub-bridged LAN.

**Figure 1** shows an ATM subinterface on a headend router that is configured to function in ATM routed-bridge encapsulation mode. This configuration is useful when a remote bridged Ethernet network device needs connectivity to a routed network via a device bridging from an Ethernet LAN to an ATM RFC 1483 bridged encapsulation.

## **Figure 1 ATM Routed Bridge Encapsulation**



Because PVCs are statically configured along the entire path between the end systems, it would not be suitable to route bridged encapsulated traffic over them when the user wants to configure the virtual circuits (VCs) dynamically and tear down the VCs when there is no traffic.

# ATM RBE Subinterface Grouping by PVC Range

You can configure ATM routed bridge encapsulation using an ATM PVC range rather than individual PVCs. When you configure a PVC range for routed bridge encapsulation, a point-to-point subinterface is created for each PVC in the range. The number of PVCs in a range can be calculated using the following formula:

number of PVCs = (*end-vpi* - *start-vpi* + 1) x (*end-vci* - *start-vci* + 1)

Subinterface numbering begins with the subinterface on which the PVC range is configured and increases sequentially through the range.



## Note

You cannot explicitly configure the individual point-to-point subinterfaces created by the PVC range on a point-to-point subinterface. All the point-to-point subinterfaces in the range share the same configuration as the subinterface on which the PVC range is configured.

# DHCP Option 82 Support for RBE


The DHCP relay agent information option (option 82) enables a Dynamic Host Configuration Protocol (DHCP) relay agent to include information about itself when forwarding client-originated DHCP packets to a DHCP server. The DHCP server can use this information to implement IP address or other parameter-assignment policies.

The DHCP Option 82 Support for RBE feature provides support for the DHCP relay agent information option when ATM RBE is used. [Figure 2](#) shows a typical network topology in which ATM RBE and DHCP are used. The aggregation router that is using ATM RBE is also serving as the DHCP relay agent.

**Figure 2** Network Topology Using ATM RBE and DHCP

This feature communicates information to the DHCP server using a suboption of the DHCP relay agent information option called *agent remote ID*. The information sent in the agent remote ID includes an IP address identifying the relay agent and information about the ATM interface and the PVC over which the DHCP request came in. The DHCP server can use this information to make IP address assignments and security policy decisions.

[Figure 3](#) shows the format of the agent remote ID suboption.


**Figure 3** Format of the Agent Remote ID Suboption

[Table 1](#) describes the agent remote ID suboption fields displayed in [Figure 3](#).


**Table 1** Agent Remote ID Suboption Field Descriptions

Field	Description
Port Type	Port type. The value 0x01 indicates RBE. (1 byte)
Version	Option 82 version. The value 0x01 specifies the RBE version of Option 82 (1 byte).
Reserved	RBE reserved (2 bytes).
NAS IP Address	One of the interfaces on the DHCP relay agent. The <b>rbe nasip</b> command can be used to specify which IP address will be used. (4 bytes)
NAS Port	RBE-enabled virtual circuit on which the DHCP request has come in. See <a href="#">Figure 4</a> for the format of this field. (4 bytes)

[Figure 4](#) shows the format of the network access server (NAS) port field in the agent remote ID suboption.

**Figure 4** Format of the NAS Port Field

[Figure 5](#) shows the format of the interface field. If there is no module, the value of the module bit is 0.

**Figure 5 Format of the Interface Field**

## DHCP Lease Limit per ATM RBE Unnumbered Interface

The DHCP lease limit per ATM RBE Unnumbered Interface feature is enabled on a Cisco IOS DHCP relay agent connected to clients through unnumbered interfaces. The relay agent keeps information about the DHCP leases offered to the clients per subinterface. When a DHCPACK message is forwarded to the client, the relay agent increments the number of leases offered to clients on that subinterface. If a new DHCP client tries to obtain an IP address and the number of leases has already reached the configured lease limit, DHCP messages from the client will be dropped and will not be forwarded to the DHCP server.

If this feature is enabled on the Cisco IOS DHCP server directly connected to clients through unnumbered interfaces, the server allocates addresses and increments the number of leases per subinterface. If a new client tries to obtain an IP address, the server will not offer an IP address if the number of leases on the subinterface has already reached the configured lease limit.

## Benefits of Providing Connectivity Using ATM Routed Bridge Encapsulation

Bridged IP packets received on an ATM interface configured in routed-bridge mode are routed via the IP header. Such interfaces take advantage of the characteristics of a stub LAN topology commonly used for digital subscriber line (DSL) access and offer increased performance and flexibility over integrated routing and bridging (IRB).

Another benefit of ATM RBE is that it reduces the security risk associated with normal bridging or IRB by reducing the size of the nonsecured network. By using a single VC allocated to a subnet (which could be as small as a single IP address), ATM RBE uses an IP address in the subnet to limit the “trust environment” to the premises of a single customer.

ATM RBE supports Cisco Express Forwarding (CEF), fast switching, and process switching.

The DHCP Option 82 Support for RBE feature enables those service providers to use DHCP to assign IP addresses and DHCP option 82 to implement security and IP address assignment policies.

The DHCP Lease Limit per ATM RBE Unnumbered Interface feature allows an Internet service provider (ISP) to globally limit the number of leases available to clients per household or connection.

## How to Configure ATM Routed Bridge Encapsulation over PVCs

This section contains the following procedures:

- [Configuring ATM Routed Bridge Encapsulation Using PVCs, page 6](#) (required)
- [Configuring DHCP Option 82 for RBE, page 8](#) (required)
- [Configuring the DHCP Lease Limit, page 10](#) (required)
- [Troubleshooting the DHCP Lease Limit, page 10](#) (optional)

## Configuring ATM Routed Bridge Encapsulation Using PVCs

Perform the following task to configure ATM RBE using PVCs. Only the specified network layer (IP) is routed. Any remaining protocols can be passed on to bridging or other protocols. In this manner, ATM RBE can be used to route IP, while other protocols (such as IPX) are bridged normally.

### SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **interface atm slot/0.subinterface-number point-to-point**
4. **pvc vpi/vci**  
or  
**range [range-name] pvc start-vpi/start-vci end-vpi/end-vci**
5. **exit**
6. **ip address ip-address mask [secondary]**
7. **end**
8. **show arp**  
or  
**show ip cache verbose**

### DETAILED STEPS

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	<b>enable</b>  <b>Example:</b> Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>
<b>Step 2</b>	<b>configure terminal</b>  <b>Example:</b> Router# configure terminal	Enters global configuration mode.
<b>Step 3</b>	<b>interface atm slot/0.subinterface-number point-to-point</b>  <b>Example:</b> Router(config)# interface atm 5/0.5 point-to-point	Specifies an ATM point-to-point subinterface and enters subinterface mode.

Command or Action	Purpose
<b>Step 4</b> <pre>pvc vpi/vci or  range [range-name] pvc start-vpi/start-vci end-vpi/end-vci</pre>	Configures a PVC to carry the routed bridge traffic and enters ATM VC class configuration mode. Configures a range of PVCs to carry the routed bridge traffic and enters ATM PVC range configuration mode.
<b>Example:</b> Router(config-subif)# pvc 0/32 or	
<b>Example:</b> Router(config-subif)# range range1 pvc 1/200 1/299	
<b>Step 5</b> <code>exit</code>	Exits to subinterface configuration mode.
<b>Example:</b> Router(config-if-atm-vc)# exit	
<b>Step 6</b> <code>ip address ip-address mask [secondary]</code>	Provides an IP address on the same subnetwork as the remote network.
<b>Example:</b> Router(config-subif)# ip address 209.165.200.224 255.255.255.0	
<b>Step 7</b> <code>end</code>	Exits to privileged EXEC mode.
<b>Example:</b> Router(config-subif)# end	
<b>Step 8</b> <code>show arp</code> or <code>show ip cache verbose</code>	(Optional) Displays ATM RBE configuration information.
<b>Example:</b> Router# show arp or	
<b>Example:</b> Router# show ip cache verbose	

## Examples

To confirm that ATM RBE is enabled, use the `show arp` command and the `show ip cache verbose` command in privileged EXEC mode:

```
Router# show arp
```

Protocol	Address	Age (min)	Hardware Addr	Type	Interface
Internet	209.165.201.51	6	0001.c9f2.a81d	ARPA	Ethernet3/1
Internet	209.165.201.49	-	0060.0939.bb55	ARPA	Ethernet3/1
Internet	209.165.202.128	30	0010.0ba6.2020	ARPA	Ethernet3/0
Internet	209.165.201.52	6	00e0.1e8d.3f90	ARPA	ATM1/0.4
Internet	209.165.201.53	5	0007.144f.5d20	ARPA	ATM1/0.2

## How to Configure ATM Routed Bridge Encapsulation over PVCs

```

Internet 209.165.202.129      - 0060.0939.bb54  ARPA   Ethernet3/0
Internet 209.165.201.125      30  00b0.c2e9.bc55  ARPA   Ethernet3/1#
Router# show ip cache verbose
IP routing cache 3 entries, 572 bytes
 9 adds, 6 invalidates, 0 refcounts
Minimum invalidation interval 2 seconds, maximum interval 5 seconds,
  quiet interval 3 seconds, threshold 0 requests
Invalidation rate 0 in last second, 0 in last 3 seconds
Last full cache invalidation occurred 00:30:34 ago
Prefix/Length     Age     Interface Next Hop
209.165.201.51/32-24 00:30:10  Ethernet3/1 10.1.0.51 14  0001C9F2A81D00600939 BB550800
209.165.202.129/32-24 00:00:04  ATM1/0.2 10.8.100.50 28
00010000AAAA030080C2000700000007144F5D2000600939 BB1C0800
209.165.201.125/32-24 00:06:09  ATM1/0.4 10.8.101.35 28
00020000AAAA030080C20007000000E01E8D3F9000600939 BB1C0800

```

## Configuring DHCP Option 82 for RBE

Perform this task to configure the DHCP Option 82 Support for RBE feature.

### Prerequisites for Configuring DHCP Option 82 for RBE

DHCP option 82 support must be configured on the DHCP relay agent using the **ip dhcp relay information option** command before you can use the DHCP Option 82 Support for RBE feature.

### SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **ip dhcp relay information option**
4. **rbe nasip source-interface**
5. **end**

### DETAILED STEPS

	<b>Command</b>	<b>Purpose</b>
<b>Step 1</b>	<b>enable</b>	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>
	<b>Example:</b> Router> enable	
<b>Step 2</b>	<b>configure terminal</b>	Enters global configuration mode.
	<b>Example:</b> Router# configure terminal	

Command	Purpose
<b>Step 3</b> <code>ip dhcp relay information option</code>  <b>Example:</b> Router(config)# ip dhcp relay information option	Enables the DHCP option 82 support on relay agent. <ul style="list-style-type: none"> <li>Enabling the DHCP option 82 support allows the system to insert the DHCP relay agent information option in forwarded BOOT REQUEST messages to a Cisco IOS DHCP server.</li> </ul>
<b>Step 4</b> <code>rbe nasip source-interface</code>  <b>Example:</b> Router(config)# rbe nasip loopback0	Specifies the IP address of an interface on the DHCP relay agent that will be sent to the DHCP server via the Agent Remote ID suboption.
<b>Step 5</b> <code>end</code>  <b>Example:</b> Router(config)# end	Exits global configuration mode and enters privileged configuration mode.

## Configuring the DHCP Lease Limit

Perform this task to limit the number of DHCP leases allowed on ATM RBE unnumbered or serial unnumbered interfaces.

### SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **ip dhcp limit lease per interface *lease-limit***
4. **end**

### DETAILED STEPS

	<b>Command</b>	<b>Purpose</b>
<b>Step 1</b>	<b>enable</b>	Enables privileged EXEC mode. • Enter your password if prompted.
	<b>Example:</b> Router> enable	
<b>Step 2</b>	<b>configure terminal</b>	Enters global configuration mode.
	<b>Example:</b> Router# configure terminal	
<b>Step 3</b>	<b>ip dhcp limit lease per interface <i>lease-limit</i></b>	Limits the number of leases offered to DHCP clients behind an ATM RBE unnumbered or serial unnumbered interface.
	<b>Example:</b> Router(config)# ip dhcp limit lease per interface 2	
<b>Step 4</b>	<b>end</b>	Exits global configuration mode and returns to privileged EXEC mode.
	<b>Example:</b> Router(config)# end	

## Troubleshooting the DHCP Lease Limit

Perform this task to troubleshoot the DHCP lease limit.

### SUMMARY STEPS

1. **enable**
2. **debug ip dhcp server packet**
3. **debug ip dhcp server events**

**DETAILED STEPS**

	<b>Command</b>	<b>Purpose</b>
<b>Step 1</b>	<b>enable</b>	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>
	<b>Example:</b> Router> enable	
<b>Step 2</b>	<b>debug ip dhcp server packet</b>	(Optional) Decodes DHCP receptions and transmissions.
	<b>Example:</b> Router# debug ip dhcp server packet	
<b>Step 3</b>	<b>debug ip dhcp server events</b>	(Optional) Displays server events.
	<b>Example:</b> Router(config)# debug ip dhcp server events	

# Configuration Examples for Providing Connectivity Using ATM Routed Bridge Encapsulation

The following examples show various ways to provide connectivity from a remote bridged network to a routed network using ATM RBE.

- [Example: Configuring ATM RBE on PVCs, page 11](#)
- [Example: Configuring ATM RBE on an Unnumbered Interface, page 11](#)
- [Example: Concurrent Bridging and ATM RBE, page 12](#)
- [Example: DHCP Option 82 for RBE Configuration, page 12](#)
- [Example: DHCP Lease Limit, page 13](#)

## Example: Configuring ATM RBE on PVCs

The following example shows a typical ATM routed bridge encapsulation configuration:

```
enable
configure terminal
interface atm 4/0.100 point-to-point
  ip address 209.165.200.225 255.255.255.224
  pvc 0/32
end
```

## Example: Configuring ATM RBE on an Unnumbered Interface

The following example uses a static route to point to an unnumbered interface:

```
enable
configure terminal
interface loopback 0
  ip address 209.165.200.226 255.255.255.224
interface atm 4/0.100 point-to-point
```

## ■ Configuration Examples for Providing Connectivity Using ATM Routed Bridge Encapsulation

```

ip unnumbered loopback 0
pvc 0/32
  atm route-bridge ip
  exit
ip route 209.165.200.228 255.255.255.224 atm 4/0.100
end

```

## Example: Concurrent Bridging and ATM RBE

The following example shows concurrent use of ATM RBE with normal bridging. IP datagrams are route-bridged, and other protocols (such as IPX or AppleTalk) are bridged.

```

bridge 1 protocol ieee

interface atm 4/0.100 point-to-point
  ip address 209.165.200.225 255.255.255.224
  pvc 0/32
  bridge-group 1
  atm route-bridge ip

```

## Example: DHCP Option 82 for RBE Configuration

In the following example, DHCP option 82 support is enabled on the DHCP relay agent using the **ip dhcp relay information option** command. The **rbe nasip** command configures the router to forward the IP address for Loopback0 to the DHCP server.

```

ip dhcp-server 209.165.200.225
!
ip dhcp relay information option
!
interface Loopback0
  ip address 209.165.201.0 255.255.255.248
!
interface atm 4/0
  no ip address
!
interface atm 4/0.1 point-to-point
  ip unnumbered Loopback0
  ip helper-address 209.165.201.3
  atm route-bridged ip
  pvc 88/800
    encapsulation aal5snap
!
!
interface Ethernet5/1
  ip address 209.165.201.4 255.255.255.248
!
router eigrp 100
  network 209.165.201.0
  network 209.165.200.0
!
rbe nasip Loopback0

```

For the configuration example, the value (in hexadecimal) of the agent remote ID suboption would be 01010000B01018140580320. [Table 2](#) shows the value of each field within the agent remote ID suboption.

**Table 2 Agent Remote ID Suboption Field Values**

<b>Agent Remote ID Suboption Field</b>	<b>Value</b>
Port Type	0x01
Version	0x01
Reserved	undefined
NAS IP Address	0x0B010181 (hexadecimal value of 11.1.1.129)
NAS Port	<ul style="list-style-type: none"> <li>• Interface (slot/module/port)</li> <li>• VPI</li> <li>• VCI</li> </ul>

## Example: DHCP Lease Limit

In the following example, if more than three clients try to obtain an IP address from interface ATM4/0.1, the DHCPDISCOVER packets will not be forwarded to the DHCP server. If the DHCP server resides on the same router, DHCP will not reply to more than three clients.

```
ip dhcp limit lease per interface 3
!
interface loopback0
  ip address 209.165.201.3 255.255.255.248
!
interface atm 4/0.1
  no ip address
!
interface atm 4/0.1 point-to-point
  ip helper-address 172.16.1.2
  ip unnumbered loopback0
  atm route-bridged ip
  pvc 88/800
  encapsulation aal5snap
```

## ■ Additional References

# Additional References

## Related Documents

Related Topic	Document Title
Cisco IOS commands	<i>Cisco IOS Master Commands List, All Releases</i>
Broadband Access Aggregation and DSL commands	<i>Cisco IOS Broadband Access Aggregation and DSL Command Reference</i>
Broadband access aggregation concepts	<i>Understanding Broadband Access Aggregation</i>
Preparing for broadband access aggregation task	<i>Preparing for Broadband Access Aggregation</i>
DHCP commands	<i>Cisco IOS IP Addressing Services Command Reference</i>
DHCP configuration tasks	“Configuring the Cisco IOS DHCP Server” module in the <i>Cisco IOS IP Addressing Services Configuration Guide</i>

## Standards

Standards	Title
None	—

## MIBs

MIBs	MIBs Link
None	To locate and download MIBs for selected platforms, Cisco software releases, and feature sets, use Cisco MIB Locator found at the following URL: <a href="http://www.cisco.com/go/mibs">http://www.cisco.com/go/mibs</a>

## RFCs

RFCs	Title
None	—

## Technical Assistance

Description	Link
The Cisco Support website provides extensive online resources, including documentation and tools for troubleshooting and resolving technical issues with Cisco products and technologies.	<a href="http://www.cisco.com/cisco/web/support/index.html">http://www.cisco.com/cisco/web/support/index.html</a>
To receive security and technical information about your products, you can subscribe to various services, such as the Product Alert Tool (accessed from Field Notices), the Cisco Technical Services Newsletter, and Really Simple Syndication (RSS) Feeds.	
Access to most tools on the Cisco Support website requires a Cisco.com user ID and password.	

# Feature Information for Providing Connectivity Using ATM Routed Bridge Encapsulation

**Table 3** lists the features in this module and provides links to specific configuration information.

Use Cisco Feature Navigator to find information about platform support and software image support. Cisco Feature Navigator enables you to determine which software images support a specific software release, feature set, or platform. To access Cisco Feature Navigator, go to <http://www.cisco.com/go/cfn>. An account on Cisco.com is not required.

**Table 3** lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

**Table 3** *Feature Information for Providing Connectivity Using ATM Routed Bridge Encapsulation*

Feature Name	Releases	Feature Information
Bridged 1483 Encapsulated Traffic over ATM SVCs	12.4(15)T 12.2(33)SRE	<p>The Bridged 1483 Encapsulated Traffic over ATM SVCs feature provides support for bridged 1483 encapsulated packets to trigger ATM SVC and also support for sending this traffic on triggered ATM SVCs.</p> <p>The following section provides information about this feature:</p> <ul style="list-style-type: none"> <li>• <a href="#">“Information About Providing Connectivity Using ATM Routed Bridge Encapsulation over PVCs” section on page 2</a></li> </ul>

**Table 3****Feature Information for Providing Connectivity Using ATM Routed Bridge Encapsulation (continued)**

<b>Feature Name</b>	<b>Releases</b>	<b>Feature Information</b>
DHCP Option 82 Support for Routed Bridge Encapsulation	15.1(1)S 12.2(2)T	<p>This feature provides support for the DHCP relay agent information option when ATM RBE is used.</p> <p>The following sections provide information about this feature:</p> <ul style="list-style-type: none"> <li>• “<a href="#">DHCP Option 82 Support for RBE</a>” section on <a href="#">page 3</a></li> <li>• “<a href="#">Configuring DHCP Option 82 for RBE</a>” section on <a href="#">page 8</a></li> </ul> <p>The following command was introduced: <b>rbe nasip</b></p>
DHCP Lease Limit per ATM RBE Unnumbered Interface	12.3(2)T	<p>This feature limits the number of DHCP leases per subinterface offered to DHCP clients connected from an ATM RBE unnumbered interface or serial unnumbered interface of the DHCP server or DHCP relay agent.</p> <p>The following sections provide information about this feature:</p> <ul style="list-style-type: none"> <li>• “<a href="#">DHCP Lease Limit per ATM RBE Unnumbered Interface</a>” section on <a href="#">page 5</a></li> <li>• “<a href="#">Configuring the DHCP Lease Limit</a>” section on <a href="#">page 10</a></li> </ul> <p>The following command was introduced: <b>ip dhcp limit lease per interface</b></p>

Cisco and the Cisco Logo are trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and other countries. A listing of Cisco's trademarks can be found at [www.cisco.com/go/trademarks](http://www.cisco.com/go/trademarks). Third party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1005R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

© 2005–2010 Cisco Systems, Inc. All rights reserved.

■ Feature Information for Providing Connectivity Using ATM Routed Bridge Encapsulation