



## RIB Commands on Cisco IOS XR Software

---

This chapter describes the commands used to display and clear information in the Routing Information Base (RIB).

For detailed information about RIB concepts, configuration tasks, and examples, see *Implementing RIB on Cisco IOS XR Software* in *Cisco IOS XR Routing Configuration Guide*.

# address-family next-hop dampening disable

To disable Routing Information Base (RIB) next-hop dampening, use the **address-family next-hop dampening disable** command in router configuration mode. To enable RIB next-hop dampening, use the **no** form of this command.

**address-family {ipv4 | ipv6} next-hop dampening disable**

**no address-family {ipv4 | ipv6} next-hop dampening disable**

## Syntax Description

|             |   |
|-------------|---|
| <b>ipv4</b> | Specifies IP Version 4 (IPv4) address prefixes. |
| <b>ipv6</b> | Specifies IP Version 6 (IPv6) address prefixes. |

## Defaults

RIB next-hop dampening is enabled.

## Command Modes

Router configuration

## Command History

| Release       | Modification   |
|---------------|--|
| Release 3.4.0 | This command was introduced on the Cisco CRS-1 and Cisco XR 12000 Series Router. |
| Release 3.5.0 | No modification.   |
| Release 3.6.0 | No modification.   |
| Release 3.7.0 | No modification.   |

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the *Configuring AAA Services on Cisco IOS XR Software* module of the *Cisco IOS XR System Security Configuration Guide*.

Use the **address-family next-hop dampening disable** command to disable RIB next-hop dampening.

## Task ID

| Task ID | Operations  |
|---------|-------------|
| rib     | read, write |

## Examples

The following example shows how to disable RIB next-hop dampening for IPv6 address families:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# router rib
RP/0/RP0/CPU0:router(config-rib)# address-family ipv6 next-hop dampening disable
```

# clear route

To clear routes from the IP routing table, use the **clear route** command in EXEC mode.

```
clear route [vrf {vrf-name | all}] {ipv4 | ipv6 | afi-all} {unicast | multicast | safi-all} [topology
topo-name] [ip-address mask]
```

| Syntax Description          |   |  |
|-----------------------------|---|--|
| <b>vrf</b> {vrf-name   all} | (Optional) Specifies a particular VPN routing and forwarding (VRF) instance or all VRF instances.   |  |
| <b>ipv4</b>                 | Specifies IP Version 4 address prefixes.  |  |
| <b>ipv6</b>                 | Specifies IP Version 6 address prefixes.  |  |
| <b>safi-all</b>             | Specifies IP Version 4 and IP Version 6 address prefixes.   |  |
| <b>unicast</b>              | Specifies unicast address prefixes.   |  |
| <b>multicast</b>            | Specifies multicast address prefixes.   |  |
| <b>safi-all</b>             | Specifies unicast and multicast address prefixes.   |  |
| <b>topology</b> topo-name   | (Optional) Specifies topology table information and name of the topology table.   |  |
| ip-address node-id          | (Optional) Clears hardware resource counters from the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.  |  |
| ip-address                  | Network IP address about which routing information should be displayed.   |  |
| mask                        | Network mask specified in either of two ways: <ul style="list-style-type: none"> <li>• Network mask can be a four-part, dotted-decimal address. For example, 255.0.0.0 indicates that each bit equal to 1 means the corresponding address bit is a network address.</li> <li>• Network mask can be indicated as a slash (/) and number. For example, /8 indicates that the first 8 bits of the mask are 1s, and the corresponding bits of the address are the network address.</li> </ul> |  |

## Defaults

If a **vrf** *vrf-name* is not specified, routes are cleared from the default IPv4 unicast VRF.

## Command Modes

EXEC

## Command History

| Release       | Modification  |
|---------------|---|
| Release 2.0   | This command was introduced on the Cisco CRS-1.   |
| Release 3.0   | No modification.  |
| Release 3.2   | This command was supported on the Cisco XR 12000 Series Router. The <b>afi-all</b> and <b>safi-all</b> keywords were added. |
| Release 3.3.0 | The <b>vrf</b> <i>vrf-name</i> keyword and argument were added.   |
| Release 3.4.0 | The <b>all</b> keyword was added.   |

| Release       | Modification  |
|---------------|---|
| Release 3.5.0 | No modification.  |
| Release 3.6.0 | No modification.  |
| Release 3.7.0 | The <b>topology</b> <i>topo-name</i> keyword and argument were added. |

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the *Configuring AAA Services on Cisco IOS XR Software* module of the *Cisco IOS XR System Security Configuration Guide*.

Use the **clear route** command to clear routes from an IP routing table to a specific network, a matching subnet address, or all routes.

### Task ID

| Task ID | Operations  |
|---------|-------------|
| rib     | read, write |

### Examples

The following example shows how to remove all routes matching the subnet address 192.168.2.0 and mask 255.255.255.0 from the IPv4 unicast routing table:

```
RP/0/RP0/CPU0:router# clear route ipv4 unicast 192.168.2.0 255.255.255.0
```

The following example shows how to remove all routes from the IPv4 unicast routing table:

```
RP/0/RP0/CPU0:router# clear route ipv4 unicast
```

### Related Commands

| Command                    | Description                                      |
|----------------------------|--|
| <a href="#">show route</a> | Displays the current state of the routing table. |

# maximum prefix (RIB)

To set the prefix limit for the VPN routing and forwarding (VRF) instance, use the **maximum prefix** command in global VRF address family configuration mode. To set the prefix limits to the default values, use the **no** form of this command.

**maximum prefix** *maximum* [*mid-threshold*]

**no maximum prefix**

| Syntax Description |                      |  |
|--------------------|----------------------|--|
|                    | <i>maximum</i>       | Maximum number of prefixes allowed in the VRF instance. Range is 32 to 2000000.  |
|                    | <i>mid-threshold</i> | (Optional) Integer specifying at what percentage of the <i>maximum</i> argument value the software starts to generate a Simple Network Management Protocol (SNMP) trap. Range is 1 to 100. |

**Defaults** No default behavior or values

**Command Modes** Global VRF address family configuration

| Command History | Release       | Modification   |
|-----------------|---------------|--|
|                 | Release 3.3.0 | This command was introduced on the Cisco CRS-1 and Cisco XR 12000 Series Router. |
|                 | Release 3.4.0 | No modification.   |
|                 | Release 3.5.0 | No modification.   |
|                 | Release 3.6.0 | No modification.   |
|                 | Release 3.7.0 | No modification.   |

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the *Configuring AAA Services on Cisco IOS XR Software* module of the *Cisco IOS XR System Security Configuration Guide*.

Use the **maximum prefix** command to configure a maximum number of prefixes that a VRF instance is allowed to receive.

| Task ID | Task ID | Operations  |
|---------|---------|-------------|
|         | rib     | read, write |

**Examples** The following example shows how to set the maximum number of prefixes allowed to 1000:

```
RP/0/RP0/CPU0:router(config)# vrf vrf-A
```

**maximum prefix (RIB)**

```
RP/0/RP0/CPU0:router(config-vrf)# address-family ipv4 unicast  
RP/0/RP0/CPU0:router(config-vrf-af)# maximum prefix 1000
```

**Related Commands**

| <b>Command</b>                  | <b>Description</b>                    |
|---------------------------------|---------------------------------------|
| <a href="#">show rib tables</a> | Displays all tables known to the RIB. |

## RCC

To configure the route consistency checker (RCC), use the **rcc** command in global configuration mode. To remove this function, use the **no** form of this command.

```
rcc {ipv4 | ipv6} {unicast | multicast} [period {seconds} | count {entries}]
```

```
no rcc {ipv4 | ipv6} {unicast | multicast} [period | count]
```

### Syntax Description

|                         |  |
|-------------------------|--|
| <b>ipv4</b>             | Specifies IP Version 4 address prefixes.   |
| <b>ipv6</b>             | Specifies IP Version 6 address prefixes.   |
| <b>unicast</b>          | Specifies unicast address prefixes.  |
| <b>multicast</b>        | Specifies multicast address prefixes.  |
| <b>period</b> {seconds} | (Optional) Specifies the period of checks in seconds. Range is 3 to 3600.                        |
| <b>count</b> {entries}  | (Optional) Specifies the maximum number of entries to check for each scan. Range is 1 to 100000. |

### Defaults

No default behavior or values

### Command Modes

Global configuration

### Command History

| Release       | Modification   |
|---------------|--|
| Release 3.5.0 | This command was introduced on the Cisco CRS-1 and Cisco XR 12000 Series Router. |
| Release 3.6.0 | No modification.   |
| Release 3.7.0 | No modification.   |

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the *Configuring AAA Services on Cisco IOS XR Software* module of the *Cisco IOS XR System Security Configuration Guide*.

### Task ID

| Task ID | Operations  |
|---------|-------------|
| ipv4    | read, write |

### Examples

The following example shows how to configure RCC:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# rcc ipv4 unicast period 1200
```

# recursion-depth-max

To set the maximum depth for route recursion checks, use the **recursion-depth-max** command in router configuration mode. To set the recursion checks to the default value, use the **no** form of this command.

**recursion-depth-max** *maximum*

**no recursion-depth-max** *maximum*

| Syntax Description | <i>maximum</i> | Maximum depth for recursion checks. Range is 5 to 16. |
|--------------------|----------------|---|
|--------------------|----------------|---|

| Defaults | The default recursion depth is 128. |
|----------|-------------------------------------|
|----------|-------------------------------------|

| Command Modes | Router configuration |
|---------------|----------------------|
|---------------|----------------------|

| Command History | Release       | Modification   |
|-----------------|---------------|--|
|                 | Release 3.5.0 | This command was introduced on the Cisco CRS-1 and Cisco XR 12000 Series Router. |
|                 | Release 3.6.0 | No modification.   |
|                 | Release 3.7.0 | No modification.   |

| Usage Guidelines | <p>To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the <i>Configuring AAA Services on Cisco IOS XR Software</i> module of the <i>Cisco IOS XR System Security Configuration Guide</i>.</p> <p>Use the <b>recursion-depth-max</b> command to configure a specific maximum number of recursion checks in the range of 5 to 16.</p> |
|------------------|--|
|------------------|--|

| Task ID | Task ID | Operations  |
|---------|---------|-------------|
|         | rib     | read, write |

| Examples | The following example shows how to set the maximum depth for route recursion checks to 12: |
|----------|--|
|----------|--|

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# router rib
RP/0/RP0/CPU0:router(config-rib)# recursion-depth-max 12
```

# router rib

To enter Routing Information Base (RIB) configuration mode, use the **router rib** command in global configuration mode. To remove all RIB configurations and terminate the RIB routing process, use the **no** form of this command.

**router rib**

**no router rib**

## Syntax Description

This command has no arguments or keywords.

## Defaults

Router configuration mode is not enabled.

## Command Modes

Global configuration

## Command History

| Release       | Modification   |
|---------------|--|
| Release 3.4.0 | This command was introduced on the Cisco CRS-1 and Cisco XR 12000 Series Router. |
| Release 3.5.0 | No modification.   |
| Release 3.6.0 | No modification.   |
| Release 3.7.0 | No modification.   |

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the *Configuring AAA Services on Cisco IOS XR Software* module of the *Cisco IOS XR System Security Configuration Guide*.

Use the **router rib** command to enter RIB configuration mode.

## Task ID

| Task ID | Operations  |
|---------|-------------|
| bgp     | read, write |
| ospf    | read, write |
| hsrp    | read, write |
| isis    | read, write |

## Examples

The following example shows how to enter RIB configuration mode:

```
RP/0/RP0/CPU0:router(config)# router rib
```

# show rcc

To display route consistency checker (RCC) information, use the **show rcc** command in EXEC mode.

```
show rcc {ipv4 | ipv6} unicast [log | prefix netmask vrf vrf-name]
```

| Syntax Description  |  |   |
|---------------------|--|---|
| <b>ipv4</b>         |  | Specifies IP Version 4 address prefixes.  |
| <b>ipv6</b>         |  | Specifies IP Version 6 address prefixes.  |
| <b>unicast</b>      |  | Specifies unicast address prefixes.   |
| <b>log</b>          |  | (Optional) Specifies the RCC log.   |
| <i>prefix</i>       |  | (Optional) Starting prefix.   |
| <i>netmask</i>      |  | (Optional) Network mask.  |
| <b>vrf vrf-name</b> |  | (Optional) Specifies a particular VPN routing and forwarding (VRF) instance or all VRF instances. |

**Defaults** No default behavior or values

**Command Modes** EXEC

| Command History | Release       | Modification   |
|-----------------|---------------|--|
|                 | Release 3.5.0 | This command was introduced on the Cisco CRS-1 and Cisco XR 12000 Series Router.   |
|                 | Release 3.6.0 | The following keywords and arguments were added: <ul style="list-style-type: none"> <li><i>prefix</i></li> <li><i>mask</i></li> <li><b>vrf vrf-name</b></li> </ul> |
|                 | Release 3.7.0 | No modification.   |

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the *Configuring AAA Services on Cisco IOS XR Software* module of the *Cisco IOS XR System Security Configuration Guide*.

| Task ID | Task ID | Operations |
|---------|---------|------------|
|         | ipv4    | read       |

**Examples**

The following is sample output from the **show rcc** command:

```
RP/0/RP0/CPU0:router# show rcc ipv4 unicast log
```

```
ipv4-unicast: disabled, count = 1000, period = 60, table wraps = 0
```

```
-----  
node                checks performed                errors  
0/6/CPU0            0                                0  
0/4/CPU1            30                               0  
0/4/CPU0            0                                0  
0/1/CPU0            0                                0  
0/RP1/CPU0          120                              0  
0/RP0/CPU0          0                                0
```

# show rib

To display Routing Information Base (RIB) data, use the **show rib** command in EXEC mode.

```
show rib {ipv4 | ipv6} {unicast | multicast} [firsthop type interface-id] | next-hop [type interface-id] | opaques {attribute | ip-nexthop | ipfrr | safi-tunnel | summary | tunnel-nexthop} | protocols [standby] | statistics [name] [standby] | [topology topo-name | all]
```

## Syntax Description

|                                  |  |
|----------------------------------|--|
| <b>ipv4</b>                      | (Optional) Specifies IP Version 4 address prefixes.  |
| <b>ipv6</b>                      | (Optional) Specifies IP Version 6 address prefixes.  |
| <b>unicast</b>                   | (Optional) Specifies unicast address prefixes. This is the default.  |
| <b>multicast</b>                 | (Optional) Specifies multicast address prefixes.   |
| <b>firsthop</b>                  | (Optional) Specifies registered first-hop notification addresses.  |
| <i>type</i>                      | Interface type. For more information, use the question mark (?) online help function.  |
| <i>interface-id</i>              | Identifies a physical interface or a virtual interface.<br><br><b>Note</b> Use the show interfaces command to see a list of all possible interfaces currently configured on the router.<br><br>For more information about the syntax for the router, use the question mark (?) online help function. |
| <b>next-hop</b>                  | (Optional) Specifies registered next-hop notification addresses.   |
| <b>opaques</b>                   | (Optional) Specifies opaque data installed in the RIB.   |
| <b>attribute</b>                 | (Optional) Specifies opaque attributes installed in the RIB.   |
| <b>ip-nexthop</b>                | (Optional) Specifies P next-hop data installed in the RIB.   |
| <b>ipfrr</b>                     | (Optional) Specifies IP fast reroute (IPFRR) opaque data installed in the RIB.   |
| <b>safi-tunnel</b>               | (Optional) Specifies subaddress family (SAFI) tunnel opaque data installed in the RIB.   |
| <b>summary</b>                   | (Optional) Specifies a summary of opaque data installed in the RIB.  |
| <b>tunnel-nexthop</b>            | (Optional) Specifies tunnel next-hop opaque data installed in the RIB.   |
| <b>protocols</b>                 | (Optional) Specifies registered protocols.   |
| <b>statistics</b> <i>name</i>    | (Optional) Specifies RIB statistics of a given name.   |
| <b>standby</b>                   | (Optional) Specifies standby information.  |
| <b>topology</b> <i>topo-name</i> | (Optional) Specifies topology table information and name of the topology table.  |
| <b>all</b>                       | (Optional) Specifies that all topology table information should be displayed.  |

## Defaults

No default behavior or values

## Command Modes

EXEC

| Command History | Release       | Modification  |
|-----------------|---------------|---|
|                 | Release 3.3.0 | This command was introduced on the Cisco CRS-1 and Cisco XR 12000 Series Router.                          |
|                 | Release 3.4.0 | The <b>ipv4</b> , <b>ipv6</b> , and <b>standby</b> keywords were added.                                   |
|                 | Release 3.5.0 | No modification.  |
|                 | Release 3.6.0 | No modification.  |
|                 | Release 3.7.0 | The <b>topology</b> <i>topo-name</i> keyword and argument were added on the Cisco XR 12000 Series Router. |

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the *Configuring AAA Services on Cisco IOS XR Software* module of the *Cisco IOS XR System Security Configuration Guide*.

| Task ID | Task ID | Operations |
|---------|---------|------------|
|         | ipv4    | read       |

### Examples

The following example illustrates the **show rib** command:

```
RP/0/RP0/CPU0:router# show rib ipv4 multicast topology BLUE

RP/0/RP0/CPU0:router# show rib topology BLUE ipv4 multicast protocols
Protocol  Handle  Instance
isis          0      mt
```

| Related Commands | Command                          | Description                                  |
|------------------|----------------------------------|--|
|                  | <a href="#">show rib afi-all</a> | Displays both IPv4 and IPv6 RIB information. |

# show rib afi-all

To display Routing Information Base (RIB) data for both IPv4 and IPv6 address families, use the **show rib afi-all** command in EXEC mode.

```
show rib afi-all [attributes] [client-id] [clients] [extcomms] [firsthop] [history] [multicast]
                 [next-hop] [opaques] [protocols] [recursion-depth-max] [safi-all] [statistics] [tables]
                 [trace] [unicast] [vpn-attributes]
```

| Syntax                     | Description  |
|----------------------------|--|
| <b>attributes</b>          | (Optional) Displays all BGP attributes installed in RIB.   |
| <b>client-id</b>           | (Optional) Displays RIB client ID for longer history of redistributed routes sent to the client. |
| <b>clients</b>             | (Optional) Displays RIB clients.   |
| <b>extcomms</b>            | (Optional) Displays all extended communities installed in RIB.                                   |
| <b>firsthop</b>            | (Optional) Displays registered firsthop notification addresses.                                  |
| <b>history</b>             | (Optional) Displays redistributed routes sent to RIB clients.                                    |
| <b>multicast</b>           | (Optional) Displays multicast commands.  |
| <b>next-hop</b>            | (Optional) Displays registered next-hop notification addresses.                                  |
| <b>opaques</b>             | (Optional) Displays opaque data installed in RIB.  |
| <b>protocols</b>           | (Optional) Displays registered protocols.  |
| <b>recursion-depth-max</b> | (Optional) Displays maximum recursion depth in RIB.  |
| <b>safi-all</b>            | (Optional) Displays unicast and multicast commands.  |
| <b>statistics</b>          | (Optional) Displays RIB statistics.  |
| <b>tables</b>              | (Optional) Displays a list of tables known to RIB.   |
| <b>trace</b>               | (Optional) Displays RIB ltrace entries.  |
| <b>unicast</b>             | (Optional) Displays unicast commands.  |
| <b>vpn-attributes</b>      | (Optional) Displays all VPN attributes installed in RIB.   |

**Defaults** No default behavior or values

**Command Modes** EXEC

| Command History | Release       | Modification   |
|-----------------|---------------|--|
|                 | Release 3.7.0 | This command was introduced on the Cisco CRS-1 and Cisco XR 12000 Series Router. |

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the *Configuring AAA Services on Cisco IOS XR Software* module of the *Cisco IOS XR System Security Configuration Guide*.

| Task ID | Task ID | Operations |
|---------|---------|------------|
|         | ipv4    | read       |

### Examples

The following example illustrates the **show rib afi-all attributes** command:

```
RP/0/RP0/CPU0:router# show rib afi-all attributes
```

```
BGP attribute data in IPv4 RIB:
```

```
0 Attributes, for a total of 0 bytes.
```

```
BGP attribute data in IPv6 RIB:
```

```
0 Attributes, for a total of 0 bytes.
```

| Related Commands | Command                  | Description               |
|------------------|--------------------------|---------------------------|
|                  | <a href="#">show rib</a> | Displays RIB information. |

# show rib attributes

To display Border Gateway Protocol (BGP) attributes installed in the Routing Information Base (RIB), use the **show rib attributes** command in EXEC mode.

```
show rib attributes [summary] [standby]
```

| Syntax Description | summary | (Optional) Displays a summary of BGP attribute data installed in the RIB. |
|--------------------|---------|---|
|                    | standby | (Optional) Displays standby information.                                  |

**Defaults** No default behavior or values

**Command Modes** EXEC

| Command History | Release       | Modification   |
|-----------------|---------------|--|
|                 | Release 3.5.0 | This command was introduced on the Cisco CRS-1 and Cisco XR 12000 Series Router. |
|                 | Release 3.6.0 | No modification.   |
|                 | Release 3.7.0 | No modification.   |

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the *Configuring AAA Services on Cisco IOS XR Software* module of the *Cisco IOS XR System Security Configuration Guide*.

Use the **show rib attributes** command to display the BGP attributes installed in the RIB.

| Task ID | Task ID | Operations |
|---------|---------|------------|
|         | rib     | read       |

**Examples**

The following is sample output from the **show rib attributes** command:

```
RP/0/RP0/CPU0:router# show rib attributes
```

```
BGP attribute data in IPv4 RIB:
```

```
Attribute ID (0x2):size (68)
```

```
Attribute ID (0x3):size (52)
```

```
Attribute ID (0x4):size (68)
```

```
Attribute ID (0x5):size (52)
```

```
4 Attributes, for a total of 240 bytes.
```

```
Attribute ID : ID assigned for the attribute by BGP
```

```
size : size of the attribute data.
```

# show rib client-id

To display Routing Information Base (RIB) redistribution histories, use the **show rib client-id** command in EXEC mode.

**show rib client-id** *id* **redistribution history** [**standby**]

## Syntax Description

|                               |  |
|-------------------------------|--|
| <i>id</i>                     | ID of the client. Range is 0 to 4294967295.                          |
| <b>redistribution history</b> | Displays longer history of redistributed routes sent to RIB clients. |
| <b>standby</b>                | (Optional) Displays standby information.                             |

## Defaults

No default behavior or values

## Command Modes

EXEC

## Command History

| Release       | Modification   |
|---------------|--|
| Release 3.3.0 | This command was introduced on the Cisco CRS-1 and Cisco XR 12000 Series Router. |
| Release 3.4.0 | The <b>standby</b> keyword was added.  |
| Release 3.5.0 | No modification.   |
| Release 3.6.0 | No modification.   |
| Release 3.7.0 | No modification.   |

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the *Configuring AAA Services on Cisco IOS XR Software* module of the *Cisco IOS XR System Security Configuration Guide*.

Use the **show rib client-id** command to display a history of the route additions, deletions, and updates sent from RIB to the client across VRFs.

## Task ID

| Task ID | Operations |
|---------|------------|
| rib     | read       |

## Examples

The following is sample output from the **show rib client-id** command:

```
RP/0/RP0/CPU0:router# show rib client-id 13 redistribution history
```

```
PID      JID      Client                Location
151630  113     bcdl_agent           node0_5_CPU0
  Table ID: 0xe0000000
    S 80.80.80.0/24[1/0]           update, 5 path(s), 0x0   Jan 31 09:54:57.224
    S 80.80.80.0/24[1/0]           update, 6 path(s), 0x0   Jan 31 09:53:39.736
```

```

S 140.140.140.0/24[1/0]      update, 1 path(s), 0x0   Jan 31 09:53:39.729
S 80.80.80.0/24[1/0]      update, 5 path(s), 0x0   Jan 30 22:08:38.551
S 140.140.140.0/24        deleted,                  Jan 30 22:08:38.543
S 80.80.80.0/24[1/0]      update, 6 path(s), 0x0   Jan 30 22:03:05.889
S 100.100.100.0/24[1/0]   update, 1 path(s), 0x0   Jan 30 22:03:05.880

```

Table 1 describes the significant fields shown in the display.

**Table 1** *show rib client-id Field Descriptions*

| Field    | Description                                   |
|----------|---|
| PID      | Process ID of the client.                     |
| JID      | Job ID of the client.                         |
| Client   | Client name.                                  |
| Location | Location node on which the client is present. |

#### Related Commands

| Command                          | Description           |
|----------------------------------|-----------------------|
| <a href="#">show rib clients</a> | Displays RIB clients. |

# show rib clients

To display Routing Information Base (RIB) clients, use the **show rib clients** command in EXEC mode.

```
show rib [afi-all | ipv4 | ipv6] clients [protocols | redistribution [history]] [standby]
```

| Syntax Description    |            |   |
|-----------------------|------------|---|
| <b>afi-all</b>        | (Optional) | Specifies all address families.                               |
| <b>ipv4</b>           | (Optional) | Specifies IP Version 4 address prefixes. This is the default. |
| <b>ipv6</b>           | (Optional) | Specifies IP Version 6 address prefixes.                      |
| <b>protocols</b>      | (Optional) | Specifies client protocols.                                   |
| <b>redistribution</b> | (Optional) | Specifies protocols redistributed by clients                  |
| <b>history</b>        | (Optional) | Specifies redistributed routes sent to RIB clients.           |
| <b>standby</b>        | (Optional) | Displays standby information.                                 |

**Defaults** No default behavior or values

**Command Modes** EXEC

| Command History | Release       | Modification   |
|-----------------|---------------|--|
|                 | Release 3.3.0 | This command was introduced on the Cisco CRS-1 and Cisco XR 12000 Series Router. |
|                 | Release 3.4.0 | The <b>ipv4</b> , <b>ipv6</b> , and <b>standby</b> keywords were added.          |
|                 | Release 3.5.0 | No modification.   |
|                 | Release 3.6.0 | No modification.   |
|                 | Release 3.7.0 | No modification.   |

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the *Configuring AAA Services on Cisco IOS XR Software* module of the *Cisco IOS XR System Security Configuration Guide*.

Use the **show rib clients** command to display the list of clients who have registered with RIB, what protocol routes they are redistributing, and a history of the routes sent to the client.

The maximum number of redistribution entries is 5000 for Bulk Content Downloader (BDCL) and 500 for other protocols.

| Task ID | Task ID | Operations |
|---------|---------|------------|
|         | rib     | read       |

**Examples**

The following is sample output from the **show rib clients** command:

```
RP/0/RP0/CPU0:router# show rib clients

Process           Location           Client ID  Redist  Proto
isis              node0_5_CPU0      0          insync  insync
ospf              node0_5_CPU0      2          insync  insync

RP/0/RP0/CPU0:router# show rib clients redistribution

isis node0_5_CPU0
  ipv4 uni         vrf default      insync          route
  static           insync
ospf node0_5_CPU0
  ipv4 uni         vrf default      insync          route
  static           insync
  local            insync
bgp node0_5_CPU0
  ipv4 uni         vrf abc          insync          route
  static           insync
bcdl_agent node0_5_CPU0
  ipv4 uni         vrf default      insync          rib_fib
  ipv4 uni         vrf bar          insync          rib_fib
  ipv4 uni         vrf abc          insync          rib_fib
  ipv4 uni         vrf test         insync          rib_fib
```

[Table 2](#) describes the significant fields shown in the display.

**Table 2** *show rib clients Field Descriptions*

| Field     | Description  |
|-----------|--|
| Process   | Client process name.   |
| Location  | Location where the client process is running.  |
| Client ID | ID assigned to the client by RIB.  |
| Redist    | Whether the client is redistributing any protocols or not and whether it has read all routes from RIB or not. <ul style="list-style-type: none"> <li>insync—read</li> <li>outsync—not read.</li> </ul> |
| Proto     | Whether the protocol has sent all its routes to RIB and signaled update complete or not. <ul style="list-style-type: none"> <li>insync—read</li> <li>outsync—not read.</li> </ul>                      |

# show rib extcomms

To display all extended communities installed in the Routing Information Base (RIB), use the **show rib extcomms** command in EXEC mode.

```
show rib [afi-all | ipv4 | ipv6] extcomms [summary] [standby]
```

## Syntax Description

|                |  |
|----------------|--|
| <b>afi-all</b> | (Optional) Specifies all address families.                               |
| <b>ipv4</b>    | (Optional) Specifies IP Version 4 address prefixes. This is the default. |
| <b>ipv6</b>    | (Optional) Specifies IP Version 6 address prefixes.                      |
| <b>summary</b> | (Optional) Specifies a summary of all extended communities in the RIB.   |
| <b>standby</b> | (Optional) Displays standby information.                                 |

## Command Default

No default behavior or values

## Command Modes

EXEC

## Command History

| Release       | Modification   |
|---------------|--|
| Release 3.3.0 | This command was introduced on the Cisco CRS-1 and Cisco XR 12000 Series Router. |
| Release 3.4.0 | The <b>ipv4</b> , <b>ipv6</b> , and <b>standby</b> keywords were added.          |
| Release 3.5.0 | No modification.   |
| Release 3.6.0 | No modification.   |
| Release 3.7.0 | No modification.   |

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the *Configuring AAA Services on Cisco IOS XR Software* module of the *Cisco IOS XR System Security Configuration Guide*.

Use the **show rib extcomms** command to display extended communities installed in the RIB.

## Task ID

| Task ID | Operations |
|---------|------------|
| rib     | read       |

## Examples

The following is sample output from the **show rib extcomms** command:

```
RP/0/RP0/CPU0:router# show rib extcomms

Extended community data in RIB:

Extended community                               Ref count
```

```
COST:128:128:41984 1
EIGRP route-info:0x8000:0 1
EIGRP AD:1:25600 1
EIGRP RHB:255:0:16384 1
EIGRP LM:0x0:1:4470 1
```

Table 3 describes the significant fields shown in the display.

**Table 3** *show rib extcomms Field Descriptions*

| Field              | Description   |
|--------------------|---|
| Extended Community | Type of extended communities. Different protocols can add different extended communities. |
| Ref Count          | Number of routes referring to the Extended community.                                     |

# show rib firsthop

To display registered first-hop notification addresses, use the **show rib firsthop** command in EXEC mode.

```
show rib [vrf {vrf-name | all}] [afi-all | ipv4 | ipv6] [unicast | multicast | safi-all] firsthop
[client-name] [interface-type interface-instance | ip-address /prefix-length | ip-address mask |
resolved | unresolved | damped] [summary] [standby]
```

## Syntax Description

|   |  |
|---|--|
| <b>vrf</b> { <i>vrf-name</i>   <b>all</b> } | (Optional) Specifies a particular VPN routing and forwarding (VRF) instance or all VRF instances.  |
| <b>afi-all</b>                              | (Optional) Specifies all address families.   |
| <b>ipv4</b>                                 | (Optional) Specifies IP Version 4 address prefixes. This is the default.   |
| <b>ipv6</b>                                 | (Optional) Specifies IP Version 6 address prefixes.  |
| <b>unicast</b>                              | (Optional) Specifies unicast address prefixes. This is the default.  |
| <b>multicast</b>                            | (Optional) Specifies multicast address prefixes.   |
| <b>safi-all</b>                             | (Optional) Specifies unicast and multicast address prefixes.   |
| <i>client-name</i>                          | (Optional) Name of the RIB client.   |
| <i>interface-type</i>                       | (Optional) Interface type. For more information, use the question mark (?) online help function.   |
| <i>interface-number</i>                     | (Optional) Either a physical interface instance or a virtual interface instance: <ul style="list-style-type: none"> <li>Physical interface instance. Naming notation is <i>rack/slot/module/port</i> and a slash between values is required as part of the notation. <ul style="list-style-type: none"> <li><i>rack</i>: Chassis number of the rack.</li> <li><i>slot</i>: Physical slot number of the line card.</li> <li><i>module</i>: Module number. A physical layer interface module (PLIM) is always 0.</li> <li><i>port</i>: Physical port number of the interface.</li> </ul> </li> <li>Virtual interface instance. Number range varies depending on interface type.</li> </ul> For more information about the syntax for the router, use the question mark (?) online help function. |
| <i>ip-address</i>                           | (Optional) Network that BGP advertises.  |
| <i>/prefix-length</i>                       | (Optional) Length of the IP address prefix. A decimal value that indicates how many of the high-order contiguous bits of the address compose the prefix (the network portion of the address). A slash (/) must precede the decimal value.  |
| <i>ip-address mask</i>                      | (Optional) Network mask applied to the <i>ip-address</i> argument.   |
| <b>resolved</b>                             | (Optional) Specifies resolved next-hops.   |
| <b>unresolved</b>                           | (Optional) Specifies unresolved next-hops.   |
| <b>damped</b>                               | (Optional) Specifies next-hops that are damped.  |
| <b>summary</b>                              | (Optional) Specifies a summary of the next-hop information.  |
| <b>standby</b>                              | (Optional) Displays standby information.   |

**Command Default** If a **vrf** *vrf-name* is not specified, the registered first-hop notifications addresses are displayed for the default IPv4 unicast VRF.

**Command Modes** EXEC

| Command History | Release       | Modification  |
|-----------------|---------------|---|
|                 | Release 3.3.0 | This command was introduced on the Cisco CRS-1 and Cisco XR 12000 Series Router.  |
|                 | Release 3.4.0 | The following keywords were added: <ul style="list-style-type: none"> <li>• <b>all</b></li> <li>• <b>looped</b></li> <li>• <b>damped</b></li> <li>• <b>standby</b></li> </ul> |
|                 | Release 3.5.0 | No modification.  |
|                 | Release 3.6.0 | The <b>looped</b> keyword has been removed.   |
|                 | Release 3.7.0 | No modification.  |

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the *Configuring AAA Services on Cisco IOS XR Software* module of the *Cisco IOS XR System Security Configuration Guide*.

Use the **show rib firsthop** command to display the list of first hops registered by various clients with RIB and the address and interface through which they are resolved.

| Task ID | Task ID | Operations |
|---------|---------|------------|
|         | rib     | read       |

**Examples** The following is sample output from the **show rib firsthop** command:

```
RP/0/RP0/CPU0:router# show rib firsthop
```

```
Registered firsthop notifications:
```

```
0.0.0.0/0 via 1.1.0.1 - MgmtEth0/5/CPU0/0, ospf/node0_5_CPU0
1.1.0.1/32 via 1.1.0.1 - MgmtEth0/5/CPU0/0, ipv4_static/node0_5_CPU0
1.1.1.1/32 via 1.1.1.1 - MgmtEth0/5/CPU0/0, ipv4_static/node0_5_CPU0
10.10.10.1/32 via 10.10.10.1 - Loopback0, ipv4_static/node0_5_CPU0
10.10.10.3/32 via 10.10.10.3 - Loopback0, ipv4_static/node0_5_CPU0
15.15.15.1/32 via 10.10.10.1 - Loopback0, ipv4_static/node0_5_CPU0
20.20.20.1/32 via 1.1.1.1 - MgmtEth0/5/CPU0/0, ipv4_static/node0_5_CPU0
30.30.30.1/32 via 1.1.1.2 - MgmtEth0/5/CPU0/0, ipv4_static/node0_5_CPU0
```

# show rib history

To display history information for Routing Information Base (RIB) clients, use the **show rib history** command in EXEC mode.

```
show rib [afi-all | ipv4 | ipv6] history [client-id client-id] [standby]
```

| Syntax                            | Description  |
|-----------------------------------|--|
| <b>afi-all</b>                    | (Optional) Specifies all address families.   |
| <b>ipv4</b>                       | (Optional) Specifies IP Version 4 address prefixes. This is the default.                           |
| <b>ipv6</b>                       | (Optional) Specifies IP Version 6 address prefixes.  |
| <b>client-id</b> <i>client-id</i> | (Optional) Specifies the ID of the client. Range for <i>client-id</i> argument is 0 to 4294967295. |
| <b>standby</b>                    | (Optional) Displays standby information.   |

**Command Default** No default behavior or values

**Command Modes** EXEC

| Command History | Release       | Modification   |
|-----------------|---------------|--|
|                 | Release 3.3.0 | This command was introduced on the Cisco CRS-1 and Cisco XR 12000 Series Router. |
|                 | Release 3.4.0 | The <b>standby</b> keyword was added.  |
|                 | Release 3.5.0 | No modification.   |
|                 | Release 3.6.0 | No modification.   |
|                 | Release 3.7.0 | No modification.   |

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the *Configuring AAA Services on Cisco IOS XR Software* module of the *Cisco IOS XR System Security Configuration Guide*.

Use the **show rib history** command to display the list of routes that RIB has sent to various clients.

| Task ID | Task ID | Operations |
|---------|---------|------------|
|         | rib     | read       |

**Examples** The following is sample output from the **show rib history** command:

```
RP/0/RP0/CPU0:router# show rib history

JID   Client           Location
229   isis             node0_5_CPU0
```

```

Table ID: 0xe0000000
  S 80.80.80.0/24[1/0]      update, 6 path(s),      04:32:09
  S 100.100.100.0/24[1/0]  update, 1 path(s),      04:32:09
  S 40.40.40.0/24[1/0]    update, 1 path(s),      04:32:09
  S 15.15.15.0/24[1/0]    update, 1 path(s),      04:32:09
JID   Client                Location
260   ospf                    node0_5_CPU0
Table ID: 0xe0000000
  S 80.80.80.0/24[1/0]      update, 6 path(s),      04:32:09
  S 100.100.100.0/24[1/0]  update, 1 path(s),      04:32:09
  S 40.40.40.0/24[1/0]    update, 1 path(s),      04:32:09
  S 15.15.15.0/24[1/0]    update, 1 path(s),      04:32:09

```

[Table 4](#) describes the significant fields shown in the display.

**Table 4** *show rib history* Field Descriptions

| Field    | Description  |
|----------|--|
| JID      | Job ID of the client process.                          |
| Client   | Name of the client process.                            |
| Location | Information about where the client process is running. |

# show rib next-hop

To display registered next-hop notification addresses, use the **show rib next-hop** command in EXEC mode.

```
show rib [vrf {vrf-name | all}] [afi-all | ipv4 | ipv6] [unicast | multicast | safi-all] next-hop
[client-name] [interface-type interface-instance | ip-address /prefix-length | ip-address mask |
resolved | unresolved | damped] [summary] [standby]
```

## Syntax Description

|   |  |
|---|--|
| <b>vrf</b> { <i>vrf-name</i>   <b>all</b> } | (Optional) Specifies a particular VPN routing and forwarding (VRF) instance or all VRF instances.  |
| <b>afi-all</b>                              | (Optional) Specifies all address families.   |
| <b>ipv4</b>                                 | (Optional) Specifies IP Version 4 address prefixes. This is the default.   |
| <b>ipv6</b>                                 | (Optional) Specifies IP Version 6 address prefixes.  |
| <b>unicast</b>                              | (Optional) Specifies unicast address prefixes. This is the default.  |
| <b>multicast</b>                            | (Optional) Specifies multicast address prefixes.   |
| <b>safi-all</b>                             | (Optional) Specifies unicast and multicast address prefixes.   |
| <i>client-name</i>                          | (Optional) Name of the RIB client.   |
| <i>interface-type</i>                       | (Optional) Interface type. For more information, use the question mark (?) online help function.   |
| <i>interface-number</i>                     | (Optional) Either a physical interface instance or a virtual interface instance: <ul style="list-style-type: none"> <li>Physical interface instance. Naming notation is <i>rack/slot/module/port</i> and a slash between values is required as part of the notation. <ul style="list-style-type: none"> <li><i>rack</i>: Chassis number of the rack.</li> <li><i>slot</i>: Physical slot number of the line card.</li> <li><i>module</i>: Module number. A physical layer interface module (PLIM) is always 0.</li> <li><i>port</i>: Physical port number of the interface.</li> </ul> </li> <li>Virtual interface instance. Number range varies depending on interface type.</li> </ul> For more information about the syntax for the router, use the question mark (?) online help function. |
| <i>ip-address</i>                           | (Optional) Network IP address about which routing information should be displayed.   |
| <i>mask</i>                                 | (Optional) Network mask specified in either of two ways: <ul style="list-style-type: none"> <li>Network mask can be a four-part, dotted-decimal address. For example, 255.0.0.0 indicates that each bit equal to 1 means the corresponding address bit is a network address.</li> <li>Network mask can be indicated as a slash (/) and number. For example, /8 indicates that the first 8 bits of the mask are 1s, and the corresponding bits of the address are the network address.</li> </ul>   |

|                       |   |
|-----------------------|---|
| <i>/prefix-length</i> | (Optional) Length of the IP address prefix. A decimal value that indicates how many of the high-order contiguous bits of the address compose the prefix (the network portion of the address). A slash (/) must precede the decimal value. |
| <b>resolved</b>       | (Optional) Specifies resolved next-hops.  |
| <b>unresolved</b>     | (Optional) Specifies unresolved next-hops.  |
| <b>damped</b>         | (Optional) Specifies next-hops that are damped.   |
| <b>summary</b>        | (Optional) Specifies a summary of the next-hop information.   |
| <b>standby</b>        | (Optional) Displays standby information.  |

**Defaults**

No default behavior or values

**Command Modes**

EXEC

**Command History**

| Release       | Modification   |
|---------------|--|
| Release 3.5.0 | This command was introduced on the Cisco CRS-1 and Cisco XR 12000 Series Router. |
| Release 3.6.0 | The <b>looped</b> keyword has been removed.                                      |
| Release 3.7.0 | No modification.   |

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the *Configuring AAA Services on Cisco IOS XR Software* module of the *Cisco IOS XR System Security Configuration Guide*.

Use the **show rib next-hop** command to display the list of next-hops registered by various clients with RIB and the address and interface through which they are resolved.

**Task ID**

| Task ID | Operations |
|---------|------------|
| rib     | read       |

**Examples**

The following is sample output from the **show rib next-hop** command:

```
RP/0/RP0/CPU0:router# show rib next-hop
```

```
Registered nexthop notifications:
```

```
0.0.0.0/0 via 172.29.52.1 - MgmtEth0/RP1/CPU0/0, ospf/node0_RP0_CPU0
172.29.52.1/32 via 172.29.52.1 - MgmtEth0/RP1/CPU0/0, ipv4_static/node0_RP0_CPU0
```

# show rib opaques

To display opaque data installed in the Routing Information Base (RIB), use the **show rib opaques** command in EXEC mode.

```
show rib [vrf {vrf-name | all}] [afi-all | ipv4 | ipv6] [unicast | multicast | safi-all] opaques
      {attribute | ip-nexthop | ipfrr | safi-tunnel | summary | tunnel-nexthop} [rib-client-name]
      [standby]
```

## Syntax Description

|                             |   |
|-----------------------------|---|
| <b>vrf</b> {vrf-name   all} | (Optional) Specifies a particular VPN routing and forwarding (VRF) instance or all VRF instances. |
| <b>afi-all</b>              | (Optional) Specifies all address families.  |
| <b>ipv4</b>                 | (Optional) Specifies IP Version 4 address prefixes. This is the default.                          |
| <b>ipv6</b>                 | (Optional) Specifies IP Version 6 address prefixes.   |
| <b>unicast</b>              | (Optional) Specifies unicast address prefixes. This is the default.                               |
| <b>multicast</b>            | (Optional) Specifies multicast address prefixes.  |
| <b>safi-all</b>             | (Optional) Specifies unicast and multicast address prefixes.                                      |
| <b>attribute</b>            | Displays opaque attributes installed in the RIB.  |
| <b>ip-nexthop</b>           | Displays IP next-hop data installed in the RIB.   |
| <b>ipfrr</b>                | Displays IP fast reroute (IPFRR) opaque data installed in the RIB.                                |
| <b>safi-tunnel</b>          | Displays subaddress family (SAFI) tunnel opaque data installed in the RIB.                        |
| <b>summary</b>              | Displays a summary of opaque data installed in the RIB.   |
| <b>tunnel-nexthop</b>       | Displays tunnel next-hop opaque data installed in the RIB.  |
| <i>rib-client-name</i>      | (Optional) Name of the RIB client.  |
| <b>standby</b>              | (Optional) Displays standby information.  |

## Defaults

No default behavior or values

## Command Modes

EXEC

## Command History

| Release       | Modification   |
|---------------|--|
| Release 3.5.0 | This command was introduced on the Cisco CRS-1 and Cisco XR 12000 Series Router. |
| Release 3.6.0 | No modification.   |
| Release 3.7.0 | No modification.   |

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the *Configuring AAA Services on Cisco IOS XR Software* module of the *Cisco IOS XR System Security Configuration Guide*.

If information is not used by the RIB server process, it is viewed as opaque data. Use the **show rib opaques** command to display opaque data installed in the RIB.

| Task ID | Task ID | Operations |
|---------|---------|------------|
|         | rib     | read       |

### Examples

The following is sample output from the **show rib opaques** command:

```
RP/0/RP0/CPU0:router# show rib opaques safi-tunnel
```

Summary of safi tunnel opaque data in IPv4 RIB:

Opaque key: 1:10.1.0.2

Opaque data:

Tunnel Encap - ifhandle=0x1000180, type=L2TPv3, Params=[Session-id=0x1EB1127C, `Cookie=0xA73A3E0AFCD419A6] Opaque key: 65535:10.0.101.1 Opaque data:

```
RP/0/RP0/CPU0:router# show rib ipv6 opaques tunnel-nexthop
```

Summary of 6PE/6VPE IP over tunnel nexthop opaque data in IPv6 RIB:

Opaque key: 1::ffff:10.1.0.2

Opaque key: 65535::ffff:10.0.101.1

Opaque key: 65535::ffff:10.0.101.2

Opaque key: 65535::ffff:10.0.101.3

Opaque key: 65535::ffff:10.0.101.4

Opaque key: 65535::ffff:10.0.101.5

[Table 5](#) describes the significant fields shown in the display.

**Table 5** *show rib opaques Field Descriptions*

| Field        | Description   |
|--------------|---|
| Opaque key:  | Unique key for the opaque data as populated by the protocol client. |
| Opaque data: | Data for the given key.   |

# show rib protocols

To display protocols registered for route addition, use the **show rib protocols** command in EXEC mode.

```
show rib [vrf {vrf-name | all}] [afi-all | ipv4 | ipv6] [unicast | multicast | safi-all] protocols
[standby]
```

## Syntax Description

|                             |   |
|-----------------------------|---|
| <b>vrf</b> {vrf-name   all} | (Optional) Specifies a particular VPN routing and forwarding (VRF) instance or all VRF instances. |
| <b>afi-all</b>              | (Optional) Specifies all address families.  |
| <b>ipv4</b>                 | (Optional) Specifies IP Version 4 address prefixes. This is the default.                          |
| <b>ipv6</b>                 | (Optional) Specifies IP Version 6 address prefixes.   |
| <b>unicast</b>              | (Optional) Specifies unicast address prefixes. This is the default.                               |
| <b>multicast</b>            | (Optional) Specifies multicast address prefixes.  |
| <b>safi-all</b>             | (Optional) Specifies unicast and multicast address prefixes.                                      |
| <b>standby</b>              | (Optional) Displays standby information.  |

## Command Default

If a **vrf** *vrf-name* is not specified, the registered first-hop notification addresses are displayed for the default IPv4 unicast VRF.

## Command Modes

EXEC

## Command History

| Release       | Modification   |
|---------------|--|
| Release 3.3.0 | This command was introduced on the Cisco CRS-1 and Cisco XR 12000 Series Router. |
| Release 3.4.0 | The <b>all</b> and <b>standby</b> keywords were added.                           |
| Release 3.5.0 | No modification.   |
| Release 3.6.0 | No modification.   |
| Release 3.7.0 | No modification.   |

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the *Configuring AAA Services on Cisco IOS XR Software* module of the *Cisco IOS XR System Security Configuration Guide*.

Use the **show rib protocols** command to display registered protocols.

## Task ID

| Task ID | Operations |
|---------|------------|
| rib     | read       |

**Examples**

The following is sample output from the **show rib protocols** command:

```
RP/0/RP0/CPU0:router# show rib protocols
```

```
Protocol  Handle  Instance
isis      0          rib
connected 1
static    2
local     3
bgp       4          102
ospf      5          1
```

[Table 6](#) describes the significant fields shown in the display.

**Table 6** *show rib protocols Field Descriptions*

| Field    | Description                               |
|----------|---|
| Protocol | Name of the protocol.                     |
| Handle   | Handle assigned to the protocol instance. |
| Instance | Protocol instance.                        |

# show rib recursion-depth-max

To display the maximum recursion depth in the Routing Information Base (RIB), use the **show rib recursion-depth-max** command in EXEC mode.

```
show rib [afi-all | ipv4 | ipv6] recursion-depth-max [standby]
```

## Syntax Description

|                |  |
|----------------|--|
| <b>afi-all</b> | (Optional) Specifies all address families.                               |
| <b>ipv4</b>    | (Optional) Specifies IP Version 4 address prefixes. This is the default. |
| <b>ipv6</b>    | (Optional) Specifies IP Version 6 address prefixes.                      |
| <b>standby</b> | (Optional) Displays standby information.                                 |

## Command Default

No default behavior or values

## Command Modes

EXEC

## Command History

| Release       | Modification   |
|---------------|--|
| Release 3.5.0 | This command was introduced on the Cisco CRS-1 and Cisco XR 12000 Series Router. |
| Release 3.6.0 | No modification.   |
| Release 3.7.0 | No modification.   |

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the *Configuring AAA Services on Cisco IOS XR Software* module of the *Cisco IOS XR System Security Configuration Guide*.

Use the **show rib recursion-depth-max** command to display the maximum recursion depth for RIB. Recursion depth is the number of next-hops that can be specified.

## Task ID

| Task ID | Operations |
|---------|------------|
| rib     | read       |

## Examples

The following is sample output from the **show rib recursion-depth-max** command:

```
RP/0/RP0/CPU0:router# show rib recursion-depth-max

IPv4:
-----
Maximum recursion depth in RIB:

    Configured: 12
      In Use: 128
```

```
IPv6:
-----
Maximum recursion depth in RIB:

    Configured: 12
        In Use: 128
```

[Table 7](#) describes the significant fields shown in the display.

**Table 7** *show rib recursion-depth-max Field Descriptions*

| Field      | Description  |
|------------|--|
| Configured | Value of maximum recursion depth currently configured.   |
| In Use     | Value of maximum recursion depth RIB is using. This value can be different from the configured value because RIB has to be restarted after the configuration is changed for the new configuration to be effective. |

# show rib statistics

To display Routing Information Base (RIB) statistics, use the **show rib statistics** command in EXEC mode.

```
show rib [vrf {vrf-name | all}] [afi-all | ipv4 | ipv6] [unicast | multicast | safi-all] statistics
[client-name] [standby]
```

## Syntax Description

|                             |   |
|-----------------------------|---|
| <b>vrf</b> {vrf-name   all} | (Optional) Specifies a particular VPN routing and forwarding (VRF) instance or all VRF instances. |
| <b>afi-all</b>              | (Optional) Specifies all address families.  |
| <b>ipv4</b>                 | (Optional) Specifies IP Version 4 address prefixes. This is the default.                          |
| <b>ipv6</b>                 | (Optional) Specifies IP Version 6 address prefixes.   |
| <b>unicast</b>              | (Optional) Specifies unicast address prefixes. This is the default.                               |
| <b>multicast</b>            | (Optional) Specifies multicast address prefixes.  |
| <b>safi-all</b>             | (Optional) Specifies unicast and multicast address prefixes.                                      |
| <i>client-name</i>          | (Optional) Name of the RIB client.  |
| <b>standby</b>              | (Optional) Displays standby information.  |

## Command Default

If **vrf** *vrf-name* is not specified, the registered first-hop notification addresses are displayed for the default IPv4 unicast VRF.

## Command Modes

EXEC

## Command History

| Release       | Modification   |
|---------------|--|
| Release 3.4.0 | This command was introduced on the Cisco CRS-1 and Cisco XR 12000 Series Router. |
| Release 3.5.0 | No modification.   |
| Release 3.6.0 | No modification.   |
| Release 3.7.0 | No modification.   |

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the *Configuring AAA Services on Cisco IOS XR Software* module of the *Cisco IOS XR System Security Configuration Guide*.

Use the **show rib statistics** command to display RIB statistics. The statistics include requests sent from the clients to the RIB and the information redistributed to the client.

RIB maintains counters for all requests sent from a client including:

- Route operations
- Table registrations

- Next-hop registrations
- Redistribution registrations
- Attribute registrations
- Synchronization completion

RIB also maintains the results of the requests.

| Task ID | Task ID | Operations |
|---------|---------|------------|
|         | rib     | read       |

### Examples

The following is sample output from the **show rib statistics** command:

```
RP/0/RP0/CPU0:router# show rib statistics
```

```
RIB Statistics:
Received 142 batch messages
    137 route operations, 0 attribute operations
    0 opaque operations
    11 complete operations, 0 convergent operations
Results of the batch message received:
142 successes
0 forward references, 0 invalid client id, 0 unknown errors
0 memory allocation errors, 0 client lookup errors, table lookup errors 0
0 proto lookup errors, 0 client proto lookup errors
ipv4_connected/node0_RP0_CPU0 last performed route operation
with status BATCH_SUCESS at Jun 26 21:43:33.601

Received 217422 light weight messages
4 route add requests, 2 route delete requests
10 protocol registered, 1 protocol unregistered
0 protocol modify, 0 protocol purged
14 protocol redistributions, 0 unregistered protocol redistributions
0 reset protocol redistributions
3 first hop registered, 1 first hop unregistered
3 advertisements, 0 unregistered advertisement
57 bind data, 97 update completes, 217230 other requests
udp/node0_RP0_CPU0 last performed firsthop lookup operation
with status success at Jun 27 10:09:59.990

Received 0 nexthop batch messages
0 successes
0 inits
0 registers, 0 unregisters
0 register complete, 0 sync unregistered, 0 batch finished
```

[Table 8](#) describes the significant fields shown in the display.

**Table 8** *show rib statistics* Field Descriptions

| Field                                 | Description   |
|---------------------------------------|---|
| Received                              | Statistics received including batch messages and route, attribute, complete, and convergent operations. |
| Results of the batch message received | Batch message results.  |

**Table 8**      *show rib statistics Field Descriptions (continued)*

| <b>Field</b>                             | <b>Description</b>  |
|--|---|
| Received <i>n</i> light weight messages  | Number of lightweight API messages sent from RIB clients.               |
| Received <i>n</i> nexthop batch messages | Number of batch API messages sent from RIB clients received by the RIB. |

# show rib tables

To display all tables known to the Routing Information Base (RIB), use the **show rib tables** command in EXEC mode.

```
show rib [afi-all | ipv4 | ipv6] tables [summary] [standby]
```

| Syntax Description |                |  |
|--------------------|----------------|--|
|                    | <b>afi-all</b> | (Optional) Specifies all address families.                               |
|                    | <b>ipv4</b>    | (Optional) Specifies IP Version 4 address prefixes. This is the default. |
|                    | <b>ipv6</b>    | (Optional) Specifies IP Version 6 address prefixes.                      |
|                    | <b>summary</b> | (Optional) Displays summary table information.                           |
|                    | <b>standby</b> | (Optional) Displays standby information.                                 |

**Defaults** No default behavior or values

**Command Modes** EXEC

| Command History | Release       | Modification   |
|-----------------|---------------|--|
|                 | Release 3.3.0 | This command was introduced on the Cisco CRS-1 and Cisco XR 12000 Series Router. |
|                 | Release 3.4.0 | The <b>ipv4</b> , <b>ipv6</b> , and <b>standby</b> keywords were added.          |
|                 | Release 3.5.0 | The <b>summary</b> keyword was added.  |
|                 | Release 3.6.0 | No modification.   |
|                 | Release 3.7.0 | No modification.   |

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the *Configuring AAA Services on Cisco IOS XR Software* module of the *Cisco IOS XR System Security Configuration Guide*.

Use the **show rib tables** command to display all tables known to the RIB, including table attributes. Attributes include VPN routing and forwarding (VRF) instance, address family, and maximum prefix information.

| Task ID | Task ID | Operations |
|---------|---------|------------|
|         | rib     | read       |

**Examples** The following is sample output from the **show rib tables** command when entered without an address:

```
RP/0/RP0/CPU0:router# show rib tables
```

Codes: N - Prefix Limit Notified, F - Forward Referenced  
 D - Table Deleted, C - Table Reached Convergence

```

VRF          SAFI  Table ID      PrfxLmt  PrfxCnt  TblVersion  N F D C
default      uni   0xe0000000  2000000  72       137        N N N Y
default      multi 0xe0100000  2000000  0        0         N N N Y
  
```

Table 9 describes the significant fields shown in the display.

**Table 9** show rib tables Field Descriptions

| Field      | Description   |
|------------|---|
| VRF        | Name of the VRF instance.   |
| SAFI       | Subaddress family instance.   |
| Table ID   | ID of the RIB table.  |
| PrfxLmt    | Configured prefix limit for the RIB table.  |
| PrfxCnt    | Number of configured prefixes in the RIB table.   |
| TblVersion | Tables version number.  |
| N          | Message sent when prefix limit is exceeded.   |
| F          | Forward referenced. If Y is indicated, a table has been created by RIB because a client has registered for the table, but RIB has not heard from the router space infrastructure (RSI) about the table. RSI manages the tables. |
| D          | If Y is indicated, the table has been deleted in the RSI but RIB has not cleared the information.   |
| C          | Table reached convergence.  |

# show rib trace

To display all Routing Information Base (RIB) library call tracer (ltrace) entries, use the **show rib trace** command in EXEC mode.

```
show rib [afi-all | ipv4 | ipv6] trace [clear | counts | event-manager | startup | sync | timing]
[unique | wrapping] [last entries] [hexdump] [reverse] [tailif] [stats] [verbose] [file name
original location node-id | location {all | node-id}]
```

| Syntax Description                                       |   |
|--|---|
| <b>afi-all</b>   | (Optional) Specifies all address families.  |
| <b>ipv4</b>  | (Optional) Specifies IP Version 4 address prefixes. This is the default.  |
| <b>ipv6</b>  | (Optional) Specifies IP Version 6 address prefixes.   |
| <b>clear</b>   | (Optional) Displays route clear trace entries.  |
| <b>counts</b>  | (Optional) Displays counts trace entries.   |
| <b>event-manager</b>                                     | (Optional) Displays RIB event manager trace entries.  |
| <b>startup</b>   | (Optional) Displays RIB startup trace entries.  |
| <b>sync</b>  | (Optional) Displays client synchronization trace entries.   |
| <b>timing</b>  | (Optional) Displays timing trace entries.   |
| <b>unique</b>  | (Optional) Displays unique entries with counts.   |
| <b>wrapping</b>  | (Optional) Displays wrapping entries.   |
| <b>last <i>entries</i></b>                               | (Optional) Displays a specified number of the last entries. Range is 1 to 4294967295.   |
| <b>hexdump</b>   | (Optional) Displays traces in hexadecimal format.   |
| <b>reverse</b>   | (Optional) Displays the latest traces first.  |
| <b>tailif</b>  | (Optional) Displays new traces as they are added.   |
| <b>stats</b>   | (Optional) Displays statistics.   |
| <b>verbose</b>   | (Optional) Displays internal debugging information.   |
| <b>file <i>name</i> original location <i>node-id</i></b> | (Optional) Displays trace entries for a specific file for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.  |
| <b>location {<i>node-id</i>   all}</b>                   | (Optional) Displays ltrace entries for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation. The <b>all</b> keyword displays ltrace entries for all nodes. |

**Defaults** No default behavior or values

**Command Modes** EXEC

| Command History | Release       | Modification   |
|-----------------|---------------|--|
|                 | Release 3.5.0 | This command was introduced on the Cisco CRS-1 and Cisco XR 12000 Series Router. |

| Release       | Modification     |
|---------------|------------------|
| Release 3.6.0 | No modification. |
| Release 3.7.0 | No modification. |

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the *Configuring AAA Services on Cisco IOS XR Software* module of the *Cisco IOS XR System Security Configuration Guide*.

Use the **show rib tables** command to RIB display ltrace entries.

**Task ID**

| Task ID | Operations |
|---------|------------|
| rib     | read       |

**Examples**

The following is sample output from the **show rib trace** command

```
RP/0/RP0/CPU0:router# show rib trace

1784 wrapping entries (13312 possible, 0 filtered, 1784 total)
Mar 16 14:59:27.947 rib/ipv4_rib/rib-startup 0/RP0/CPU0 t1 Create: Management thread
Mar 16 14:59:27.959 rib/ipv4_rib/rib-startup 0/RP0/CPU0 t2 Create: Management event
manager
Mar 16 14:59:28.346 rib/ipv4_rib/rib-io 0/RP0/CPU0 t1 Initialise: RIB server
Mar 16 14:59:28.346 rib/ipv4_rib/rib-io 0/RP0/CPU0 t1 Initialise: Client collection
Mar 16 14:59:28.676 rib/ipv4_rib/rib-io 0/RP0/CPU0 t1 Initialise: DB collection
Mar 16 14:59:28.693 rib/ipv4_rib/rib-io 0/RP0/CPU0 t1 Initialise: Timer tree
Mar 16 14:59:28.694 rib/ipv4_rib/rib-io 0/RP0/CPU0 t1 RUMP: Bind to sysdb
/ipc/gl/ipv4-rib/ for protocol notification
Mar 16 14:59:29.102 rib/ipv4_rib/rib-startup 0/RP0/CPU0 t2 Initialise: Debugging routine
Mar 16 14:59:29.128 rib/ipv4_rib/rib-io 0/RP0/CPU0 t1 Register: read, select cb functions
Mar 16 14:59:29.137 rib/ipv4_rib/rib-startup 0/RP0/CPU0 t1 Register: cernno DLL name
lib_rib_error.dll
.
.
.
```

# show rib vpn-attributes

To display all VPN attributes installed in the Routing Information Base (RIB), use the **show rib vpn-attributes** command in EXEC mode.

```
show rib [afi-all | ipv4 | ipv6] vpn-attributes [summary] [standby]
```

| Syntax Description | Parameter      | Description   |
|--------------------|----------------|---|
|                    | <b>afi-all</b> | (Optional) Specifies all address families.          |
|                    | <b>ipv4</b>    | (Optional) Specifies IP Version 4 address prefixes. |
|                    | <b>ipv6</b>    | (Optional) Specifies IP Version 6 address prefixes. |
|                    | <b>summary</b> | (Optional) Displays VPN attribute information.      |
|                    | <b>standby</b> | (Optional) Displays standby information.            |

**Defaults** The default is IPv4 address prefixes.

**Command Modes** EXEC

| Command History | Release       | Modification   |
|-----------------|---------------|--|
|                 | Release 3.5.0 | This command was introduced on the Cisco CRS-1 and Cisco XR 12000 Series Router. |
|                 | Release 3.6.0 | No modification.   |
|                 | Release 3.7.0 | No modification.   |

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the *Configuring AAA Services on Cisco IOS XR Software* module of the *Cisco IOS XR System Security Configuration Guide*.

Use the **show rib vpn-attributes** command to display all VPN attributes installed in the RIB.

| Task ID | Task ID | Operations |
|---------|---------|------------|
|         | rib     | read       |

**Examples** The following is sample output from the **show rib vpn-attributes** command:

```
RP/0/RP0/CPU0:router# show rib vpn-attributes
```

```
Extended community data in RIB:
```

```
Extended community                               Ref count
COST:128:128:41984                               2
COST:128:129:42240                               2
COST:128:129:44544                               1
```

## show rib vpn-attributes

```

COST:128:129:169984                2
COST:128:129:307200                1
EIGRP route-info:0x0:0             6
EIGRP route-info:0x8000:0          2
EIGRP AD:444:25600                 2
EIGRP AD:444:25856                 2
EIGRP AD:444:28160                 1
EIGRP AD:444:51200                 1
EIGRP AD:444:153600                2
EIGRP RHB:255:0:16384              2
EIGRP RHB:255:1:16384              5
EIGRP RHB:255:1:256000             1
EIGRP LM:0x0:1:1500                3
EIGRP LM:0x0:1:1514                2
EIGRP LM:0x0:1:4470                3
EIGRP AR:0:192.168.0.13            6
EIGRP PM:11:0                      6

```

MVPN attribute data in RIB:

```

MVPN Attribute                      Ref count
0:0:1:f4:0:0:0:1:1:1:1:1          1
0:0:2:bc:0:0:0:1:3:3:3:3          10
0:0:2:bc:0:0:0:1:3:3:3:4          2

```

[Table 10](#) describes the significant fields shown in the display.

**Table 10** *show rib vpn-attributes Field Descriptions*

| Field              | Description  |
|--------------------|--|
| Extended Community | Extended community added by the protocol clients           |
| Ref Count          | Number of routes referring to the same extended community. |
| MVPN Attribute     | Connector attribute added by BGP to support MVPNs.         |
| Ref Count          | Number of routes referring to the same extended community. |

# show rib vrf

To display all VRF table information in the Routing Information Base (RIB), use the **show rib vrf** command in EXEC mode.

```
show rib vrf {vrf-name | all} [ipv4] [ipv6] [afi-all] [firsthop] [next-hop] [opaques] [protocols]
[statistics]
```

| Syntax Description          |   |  |
|-----------------------------|---|--|
| <b>vrf</b> {vrf-name   all} | (Optional) Specifies a particular VPN routing and forwarding (VRF) instance or all VRF instances. |  |
| <b>ipv4</b>                 | (Optional) Specifies IP Version 4 address prefixes.   |  |
| <b>ipv6</b>                 | (Optional) Specifies IP Version 6 address prefixes.   |  |
| <b>afi-all</b>              | (Optional) Specifies all address families.  |  |
| <b>firsthop</b>             | (Optional) Specifies registered first-hop notification addresses                                  |  |
| <b>next-hop</b>             | (Optional) Specifies registered next-hop notification addresses.                                  |  |
| <b>opaques</b>              | (Optional) Specifies opaque data installed in the RIB.  |  |
| <b>protocols</b>            | (Optional) Specifies registered protocols.  |  |
| <b>statistics</b> name      | (Optional) Specifies RIB statistics for the given name.   |  |

**Defaults** No default behavior or values

**Command Modes** EXEC

| Command History | Release       | Modification   |
|-----------------|---------------|--|
|                 | Release 3.7.0 | This command was introduced on the Cisco CRS-1 and Cisco XR 12000 Series Router. |

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the *Configuring AAA Services on Cisco IOS XR Software* module of the *Cisco IOS XR System Security Configuration Guide*.

| Task ID | Task ID | Operations |
|---------|---------|------------|
|         | ipv4    | read       |

**Examples** The following example illustrates the **show rib vrf all statistics** command:

```
RP/0/RP0/CPU0:router# show rib vrf all statistics
RP/0/RP0/CPU0:router#
```

■ show rib vrf

| Related Commands | Command                  | Description               |
|------------------|--------------------------|---------------------------|
|                  | <a href="#">show rib</a> | Displays RIB information. |

# show route

To display the current routes in the Routing Information Base (RIB), use the **show route** command in EXEC mode.

```
show route [vrf {vrf-name | all}] [afi-all | ipv4 | ipv6] [unicast | multicast {topology topo-name}]
safi-all] [protocol [instance] | ip-address [mask] | ip-address/prefix-length] [standby] [detail]
```

| Syntax                      | Description  |
|-----------------------------|--|
| <b>vrf</b> {vrf-name   all} | (Optional) Specifies a particular VPN routing and forwarding (VRF) instance or all VRF instances.  |
| <b>afi-all</b>              | (Optional) Specifies all address families.   |
| <b>ipv4</b>                 | (Optional) Specifies IP Version 4 address prefixes. This is the default.   |
| <b>ipv6</b>                 | (Optional) Specifies IP Version 6 address prefixes.  |
| <b>unicast</b>              | (Optional) Specifies unicast address prefixes. This is the default.  |
| <b>multicast</b>            | (Optional) Specifies multicast address prefixes.   |
| <b>topology</b> topo-name   | (Optional) Specifies topology table information and name of the topology table.  |
| <b>safi-all</b>             | (Optional) Specifies unicast and multicast address prefixes.   |
| <i>protocol</i>             | (Optional) Name of a routing protocol. If you specify a routing protocol, use one of the following keywords: <ul style="list-style-type: none"> <li>• <b>bgp</b></li> <li>• <b>eigrp</b></li> <li>• <b>isis</b></li> <li>• <b>ospf</b></li> <li>• <b>rip</b></li> <li>• <b>static</b></li> <li>• <b>local</b></li> <li>• <b>connected</b></li> </ul>   |
| <i>instance</i>             | (Optional) Number or name used to identify an instance of the specified protocol.  |
| <i>ip-address</i>           | (Optional) Network IP address about which routing information should be displayed.   |
| <i>mask</i>                 | (Optional) Network mask specified in either of two ways: <ul style="list-style-type: none"> <li>• Network mask can be a four-part, dotted-decimal address. For example, 255.0.0.0 indicates that each bit equal to 1 means the corresponding address bit is a network address.</li> <li>• Network mask can be indicated as a slash (/) and number. For example, /8 indicates that the first 8 bits of the mask are 1s, and the corresponding bits of the address are the network address.</li> </ul> |
| <i>/prefix-length</i>       | (Optional) Length of the IP address prefix. A decimal value that indicates how many of the high-order contiguous bits of the address compose the prefix (the network portion of the address). A slash (/) must precede the decimal value.  |

|                |  |
|----------------|--|
| <b>standby</b> | (Optional) Displays standby information.                           |
| <b>detail</b>  | (Optional) Displays detailed information for the specified prefix. |

**Defaults**

If a **vrf** *vrf-name* is not specified, routes are displayed for the default IPv4 unicast VRF.

**Command Modes**

EXEC

**Command History**

| Release       | Modification   |
|---------------|--|
| Release 2.0   | This command was introduced on the Cisco CRS-1.  |
| Release 3.0   | No modification.   |
| Release 3.2   | This command was supported on the Cisco XR 12000 Series Router. The <b>afi-all</b> and <b>safi-all</b> keywords were added.                            |
| Release 3.3.0 | The <b>eigrp</b> and <b>rip</b> keywords and <b>vrf</b> <i>vrf-name</i> keyword and argument were added.   |
| Release 3.4.0 | The <b>all</b> , <b>detail</b> , and <b>standby</b> keywords were added.   |
| Release 3.5.0 | No modification.   |
| Release 3.6.0 | No modification.   |
| Release 3.7.0 | The <b>topology</b> <i>topo-name</i> keyword and argument were added as options from the <b>multicast</b> keyword on the Cisco XR 12000 Series Router. |

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the *Configuring AAA Services on Cisco IOS XR Software* module of the *Cisco IOS XR System Security Configuration Guide*.

When the **afi-all** keyword is used, the *ip-address* and *mask* arguments are not available.

The **topology** keyword must be accompanied by the **ipv4 multicast** keywords, except when the **afi-all** keyword or the **safi-all** keyword is specified.

**Task ID**

| Task ID | Operations |
|---------|------------|
| rib     | read       |

**Examples**

The following is sample output from the **show route** command when entered without an address:

```
RP/0/RP0/CPU0:router# show route
```

```
Codes: C - connected, S - static, R - RIP, M - mobile, B - BGP
       D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter area
       N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
       E1 - OSPF external type 1, E2 - OSPF external type 2, E - EGP
       i - ISIS, L1 - IS-IS level-1, L2 - IS-IS level-2
       ia - IS-IS inter area, su - IS-IS summary null, * - candidate default
       U - per-user static route, o - ODR, L - local
```

Gateway of last resort is 1.0.0.1 to network 0.0.0.0

```
S* 0.0.0.0/0 [1/0] via 1.0.0.1, 13:14:59
C 1.0.0.0/16 is directly connected, 13:14:59, MgmtEth0/5/CPU0/0
L 1.0.14.15/32 is directly connected, 13:14:59, MgmtEth0/5/CPU0/0
C 3.2.3.0/24 is directly connected, 00:04:39, POS0/3/0/0
L 3.2.3.2/32 is directly connected, 00:04:39, POS0/3/0/0
O E2 5.2.5.0/24 [110/20] via 3.3.3.1, 00:04:20, POS0/3/0/0
O E2 6.2.6.0/24 [110/20] via 3.3.3.1, 00:04:20, POS0/3/0/0
C 7.2.7.0/24 is directly connected, 00:04:20, POS0/3/0/7
L 7.2.7.2/32 is directly connected, 00:04:20, POS0/3/0/7
O E2 8.2.8.0/24 [110/20] via 3.3.3.1, 00:04:20, POS0/3/0/0

C 10.3.0.0/16 is directly connected, 13:14:59, GigabitEthernet0/0/0/0
L 10.3.0.2/32 is directly connected, 13:14:59, GigabitEthernet0/0/0/0
```

Table 11 describes the significant fields shown in the display.

**Table 11** *show route Field Descriptions*

| Field                   | Description   |
|-------------------------|---|
| S*                      | Code indicating how the route was derived. See the code legend preceding the output. In this case, the route was derived from a static (candidate default). |
| [1/0]                   | First number in the brackets is the administrative distance of the information source; the second number is the metric for the route.                       |
| 1.0.0.0/16              | Address and prefix length of the remote network.  |
| MgmtEthernet 0/5/CPU0/0 | Specifies the interface through which the specified network can be reached.   |
| C                       | Code indicating how the route was derived. See the code legend preceding the output. In this case, the route was connected.                                 |
| L                       | Code indicating how the route was derived. See the code legend preceding the output. In this case, the route was local.                                     |
| O                       | Code indicating how the route was derived. See the code legend preceding the output. In this case, the route was on-demand routing (ODR).                   |
| E2                      | Code indicating how the route was derived. See the code legend preceding the output. In this case, the route was OSPF external type 2.                      |
| 8.2.8.0/24              | Address and prefix length of the remote network connected to the static route.  |
| via 3.3.3.1             | Specifies the address of the next router to the remote network.   |
| 13:14:59                | Specifies the last time the route was updated.  |

When you specify that you want information about a specific network, more detailed statistics are displayed. The following is sample output from the **show route** command when entered with an IP address:

```
RP/0/RP0/CPU0:router# show route 10.0.0.0

Routing entry for 10.0.0.0/16
  Known via "connected", distance 0, metric 0 (connected)
  Installed Mar 22 22:10:20.906
  Routing Descriptor Blocks
    directly connected, via GigabitEthernet0/0/0/0
    Route metric is 0
  No advertising protos.
```

Intermediate System-to-Intermediate System (IS-IS) includes an IP address typed length value (TLV) in its link-state packet (LSP) that helps identify the node injecting the route into the network. The IS-IS node uses one of its own interface addresses in this TLV. A loopback address is preferred among interfaces configured under IS-IS. When other networking devices calculate IP routes, they can store the this IP address as the originator address with each route in the routing table.

The following example shows the output from the **show route** command for a specific IP address on a router configured with IS-IS. Each path that is shown under the Routing Descriptor Blocks report displays two IP addresses. The first address (10.0.0.9) is the next-hop address; the second is the originator IP address from the advertising IS-IS router.

```
RP/0/RP0/CPU0:router# show route 10.0.0.1

Routing entry for 10.0.0.0/8
Known via "isis", distance 115, metric 10, type level-2
  Installed Jan 22 09:26:56.210
  Routing Descriptor Blocks:
    * 10.0.0.9, from 10.0.0.9, via GigabitEthernet2/1
      Route metric is 10
  No advertising protos.
```

Table 12 describes the significant fields shown when the **show route** command is used with an IP address (previous displays).

**Table 12** *show route with IP Address Field Descriptions*

| Field                         | Description  |
|-------------------------------|--|
| Routing entry for 10.0.0.0/16 | Network address and mask.  |
| Known via                     | Indicates how the route was derived.   |
| distance                      | Administrative distance of the information source.   |
| metric                        | Route value assigned by the routing protocol.  |
| type                          | IS-IS type level.  |
| Routing Descriptor Blocks:    | Displays the next-hop IP address followed by the information source.   |
| from ... via ...              | First address is the next-hop IP address, and the other is the information source. This report is followed by the interface for this route.  |
| Route metric                  | Best metric for this Routing Descriptor Block.   |
| No advertising protos.        | Indicates that no other protocols are advertising the route to their redistribution consumers. If the route is being advertised, protocols are listed in the following manner:<br><br>Redist Advertisers:<br>isis p<br>ospf 43 |

The following example illustrates the **show route** command with the **topology topo-name** keyword and argument specified:

```
RP/0/RP0/CPU0:router# show route ipv4 multicast topology green

Codes: C - connected, S - static, R - RIP, M - mobile, B - BGP
       D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter area
```

```

N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
E1 - OSPF external type 1, E2 - OSPF external type 2, E - EGP
i - ISIS, L1 - IS-IS level-1, L2 - IS-IS level-2
ia - IS-IS inter area, su - IS-IS summary null, * - candidate default
U - per-user static route, o - ODR, L - local

```

Gateway of last resort is not set

```

i L1 10.1.102.0/24 [115/20] via 10.1.102.41, 1w4d, GigabitEthernet0/1/0/0.1
i L1 10.3.3.0/24 [115/20] via 10.1.102.41, 1w4d, GigabitEthernet0/1/0/0.1
i L1 192.168.0.40/32 [115/20] via 10.1.102.41, 1w4d, GigabitEthernet0/1/0/0.1

```

### Related Commands

| Command                            | Description   |
|------------------------------------|---|
| <code>show interfaces</code>       | Lists interface information.  |
| <a href="#">show route summary</a> | Displays the current contents of the routing table in summary format. |

# show route backup

To display backup routes from the Routing Information Base (RIB), use the **show route backup** command in EXEC mode.

```
show route [vrf {vrf-name | all}] [afi-all | ipv4 | ipv6] [unicast | multicast {topology topo-name}]
safi-all] backup [ip-address [mask] | ip-address/prefix-length] [standby]
```

## Syntax Description

|                             |  |
|-----------------------------|--|
| <b>vrf</b> {vrf-name   all} | (Optional) Specifies a particular VPN routing and forwarding (VRF) instance or all VRF instances.  |
| <b>afi-all</b>              | (Optional) Specifies all address families.   |
| <b>ipv4</b>                 | (Optional) Specifies IP Version 4 address prefixes.  |
| <b>ipv6</b>                 | (Optional) Specifies IP Version 6 address prefixes.  |
| <b>unicast</b>              | (Optional) Specifies unicast address prefixes.   |
| <b>multicast</b>            | (Optional) Specifies multicast address prefixes.   |
| <b>topology</b> topo-name   | (Optional) Specifies topology table information and name of the topology table.  |
| <b>safi-all</b>             | (Optional) Specifies unicast and multicast address prefixes.   |
| ip-address                  | (Optional) Network IP address about which backup routing information should be displayed.  |
| mask                        | (Optional) Network mask specified in either of two ways: <ul style="list-style-type: none"> <li>• Network mask can be a four-part, dotted decimal address. For example, 255.0.0.0 indicates that each bit equal to 1 means the corresponding address bit is a network address.</li> <li>• Network mask can be indicated as a slash (/) and number. For example, /8 indicates that the first 8 bits of the mask are ones, and the corresponding bits of the address are the network address.</li> </ul> |
| /prefix-length              | (Optional) Length of the IP address prefix. A decimal value that indicates how many of the high-order contiguous bits of the address compose the prefix (the network portion of the address). A slash (/) must precede the decimal value.  |
| <b>standby</b>              | (Optional) Displays standby information.   |

## Defaults

If a **vrf** vrf-name is not specified, the backup routes from the RIB are displayed for the default IPv4 unicast VRF.

## Command Modes

EXEC

## Command History

| Release     | Modification                                    |
|-------------|---|
| Release 2.0 | This command was introduced on the Cisco CRS-1. |
| Release 3.0 | No modification.                                |

| Release       | Modification  |
|---------------|---|
| Release 3.2   | This command was supported on the Cisco XR 12000 Series Router. The <b>afi-all</b> and <b>safi-all</b> keywords were added.                     |
| Release 3.3.0 | The <b>vrf vrf-name</b> keyword and argument were added.  |
| Release 3.4.0 | The <b>all</b> and <b>standby</b> keywords were added.  |
| Release 3.5.0 | No modification.  |
| Release 3.6.0 | No modification.  |
| Release 3.7.0 | The <b>topology topo-name</b> keyword and argument were added as options from the <b>multicast</b> keyword on the Cisco XR 12000 Series Router. |

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the *Configuring AAA Services on Cisco IOS XR Software* module of the *Cisco IOS XR System Security Configuration Guide*.

Use the **show route backup** command to display information about routes that have been installed into the RIB as backup routes. This command also displays information about the currently selected active route for which there is a backup.

When the **afi-all** keyword is used, the *ip-address* and *mask* arguments are not available.

The **topology** keyword must be accompanied by the **ipv4 multicast** keywords, except when the **afi-all** keyword or the **safi-all** keyword is specified.

### Task ID

| Task ID | Operations |
|---------|------------|
| rib     | read       |

### Examples

The following is sample output from the **show route backup** command:

```
RP/0/RP0/CPU0:router# show route backup

Codes: C - connected, S - static, R - RIP, M - mobile, B - BGP
       D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter area
       N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
       E1 - OSPF external type 1, E2 - OSPF external type 2, E - EGP
       i - ISIS, L1 - IS-IS level-1, L2 - IS-IS level-2
       ia - IS-IS inter area, su - IS-IS summary null, * - candidate default
       U - per-user static route, o - ODR, L - local
S    172.73.51.0/24 is directly connected, 2d20h, POS4/0/0/1
      Backup O E2 [110/1] via 10.12.12.2, POS3/0/0/1
```

Table 13 describes the significant fields shown in the display.

**Table 13** *show route backup* Field Descriptions

| Field          | Description  |
|----------------|--|
| S              | Code indicating how the route was derived. See the legend of the codes preceding the output. |
| 172.73.51.0/24 | IP address and length of the route.  |
| 2d20h          | Time (in hh:mm:ss) since the route was installed in the RIB.                                 |

**Table 13** *show route backup Field Descriptions (continued)*

| Field      | Description   |
|------------|---|
| POS4/0/0/1 | Outbound interface for the route.   |
| Backup     | Identifies the entry as a backup version of the route, typically installed by a different routing protocol.   |
| O          | Code indicating how the route was derived. See the code legend preceding the output.  |
| E2         | Code for the type of route. This code is relevant only for OSPF and IS-IS routes.<br>The codes for an OSPF route can be:<br>none— <i>intra-area route</i><br>IA — <i>interarea route</i><br>E1— <i>external type 1</i><br>E2— <i>external type 2</i><br>N1— <i>NSSA external type 1</i><br>N2— <i>NSSA external type 2</i><br>The codes for an IS-IS route can be:<br>L1— <i>level 1</i><br>L2 — <i>level 2</i><br>ia — <i>interarea</i><br>su — <i>summary route</i> |
| [110/1]    | Distance and metric for the route.  |
| 10.12.12.2 | IP address of next-hop on the route.  |
| POS3/0/0/1 | Outbound interface for the OSPF version of the route.   |

**Related Commands**

| Command                    | Description                             |
|----------------------------|---|
| <a href="#">show route</a> | Displays the current routes in the RIB. |

# show route best-local

To display the best local address to use for return packets from the given destination, use the **show route best-local** command in EXEC mode.

```
show route [vrf {vrf-name | all}] [ipv4 | ipv6] [unicast | multicast {topology topo-name}] safi-all
best-local ip-address [standby]
```

| Syntax Description          |            |  |
|-----------------------------|------------|--|
| <b>vrf</b> {vrf-name   all} | (Optional) | Specifies a particular VPN routing and forwarding (VRF) instance or all VRF instances. |
| <b>ipv4</b>                 | (Optional) | Specifies IP Version 4 address prefixes.   |
| <b>ipv6</b>                 | (Optional) | Specifies IP Version 6 address prefixes.   |
| <b>unicast</b>              | (Optional) | Specifies unicast address prefixes.  |
| <b>multicast</b>            | (Optional) | Specifies multicast address prefixes.  |
| <b>topology</b> topo-name   | (Optional) | Specifies topology table information and name of the topology table.                   |
| <b>safi-all</b>             | (Optional) | Specifies unicast and multicast address prefixes.                                      |
| ip-address                  |            | IP address about which best local information should be displayed.                     |
| <b>standby</b>              | (Optional) | Displays standby information.  |

**Defaults** If a **vrf** vrf-name is not specified, the best local address is displayed for the default IPv4 unicast VRF.

**Command Modes** EXEC

| Command History | Release       | Modification  |
|-----------------|---------------|---|
|                 | Release 2.0   | This command was introduced on the Cisco CRS-1.   |
|                 | Release 3.0   | No modification.  |
|                 | Release 3.2   | This command was supported on the Cisco XR 12000 Series Router. The <b>afi-all</b> and <b>safi-all</b> keywords were added.                     |
|                 | Release 3.3.0 | The <b>vrf</b> vrf-name keyword and argument were added.  |
|                 | Release 3.4.0 | The <b>all</b> and <b>standby</b> keyword were added.<br>The <b>afi-all</b> keyword was removed.  |
|                 | Release 3.5.0 | No modification.  |
|                 | Release 3.6.0 | No modification.  |
|                 | Release 3.7.0 | The <b>topology</b> topo-name keyword and argument were added as options from the <b>multicast</b> keyword on the Cisco XR 12000 Series Router. |

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the *Configuring AAA Services on Cisco IOS XR Software* module of the *Cisco IOS XR System Security Configuration Guide*.

Use the **show route best-local** command to display information about the best local routes in the routing table.

The **topology** keyword must be accompanied by the **ipv4 multicast** keywords, except when the **afi-all** keyword or the **safi-all** keyword is specified.

| Task ID | Task ID | Operations |
|---------|---------|------------|
|         | rib     | read       |

### Examples

The following is sample output from the **show route best-local** command:

```
RP/0/RP0/CPU0:router# show route best-local 10.12.12.1/32
```

```
Routing entry for 10.12.12.1/32
  Known via "local", distance 0, metric 0 (connected)
  Routing Descriptor Blocks
    10.12.12.1 directly connected, via POS3/0/0/1
    Route metric is 0
```

[Table 14](#) describes the significant fields shown in the display.

**Table 14** *show route best-local Field Descriptions*

| Field                                     | Description  |
|---|--|
| Routing entry for 10.12.12.1/32           | Identifies the requested IP address.   |
| Known via                                 | Indicates how the route was derived.   |
| distance                                  | Administrative distance of the information source.   |
| metric                                    | Route value assigned by the routing protocol.  |
| Routing Descriptor Blocks:                | Displays the next-hop IP address followed by the information source.   |
| 10.12.12.1 Directly connected ... via ... | First address is the next-hop IP address, followed by a report that it is directly connected. This report is followed by the interface for this route. |

### Related Commands

| Command                          | Description   |
|----------------------------------|---|
| <a href="#">show route local</a> | Displays local addresses installed in the RIB as a receive entry. |

# show route connected

To display the current connected routes of the routing table, use the **show route connected** command in EXEC mode.

```
show route [vrf {vrf-name | all}] [afi-all | ipv4 | ipv6] [unicast | multicast {topology topo-name}]
safi-all] connected [standby]
```

| Syntax Description          |   |  |
|-----------------------------|---|--|
| <b>vrf</b> {vrf-name   all} | (Optional) Specifies a particular VPN routing and forwarding (VRF) instance or all VRF instances. |  |
| <b>afi-all</b>              | (Optional) Specifies all address families.  |  |
| <b>ipv4</b>                 | (Optional) Specifies IP Version 4 address prefixes.   |  |
| <b>ipv6</b>                 | (Optional) Specifies IP Version 6 address prefixes.   |  |
| <b>unicast</b>              | (Optional) Specifies unicast address prefixes.  |  |
| <b>multicast</b>            | (Optional) Specifies multicast address prefixes.  |  |
| <b>topology</b> topo-name   | (Optional) Specifies topology table information and name of the topology table.                   |  |
| <b>safi-all</b>             | (Optional) Specifies unicast and multicast address prefixes.                                      |  |
| <b>standby</b>              | (Optional) Displays standby information.  |  |

## Defaults

If a **vrf** *vrf-name* is not specified, the current connected routes of the routing table are displayed for the default IPv4 unicast VRF.

The **topology** keyword must be accompanied by the **ipv4** **multicast** keywords, except when the **afi-all** keyword or the **safi-all** keyword is specified.

## Command Modes

EXEC

## Command History

| Release       | Modification   |
|---------------|--|
| Release 2.0   | This command was introduced on the Cisco CRS-1.  |
| Release 3.0   | No modification.   |
| Release 3.2   | This command was supported on the Cisco XR 12000 Series Router. The <b>afi-all</b> and <b>safi-all</b> keywords were added.                            |
| Release 3.3.0 | The <b>vrf</b> <i>vrf-name</i> keyword and argument were added.  |
| Release 3.4.0 | The <b>all</b> and <b>standby</b> keywords were added.   |
| Release 3.5.0 | No modification.   |
| Release 3.6.0 | No modification.   |
| Release 3.7.0 | The <b>topology</b> <i>topo-name</i> keyword and argument were added as options from the <b>multicast</b> keyword on the Cisco XR 12000 Series Router. |

## show route connected

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the *Configuring AAA Services on Cisco IOS XR Software* module of the *Cisco IOS XR System Security Configuration Guide*.

Use the **show route connected** command to display information about connected routes in the routing table.

### Task ID

| Task ID | Operations |
|---------|------------|
| rib     | read       |

### Examples

The following is sample output from the **show route connected** command:

```
RP/0/RP0/CPU0:router# show route connected
```

```
C 1.68.0.0/16 is directly connected, 13:43:40, MgmtEth0/5/CPU0/0
C 3.3.3.0/24 is directly connected, 00:23:23, POS0/3/0/0
C 7.7.7.0/24 is directly connected, 00:33:00, POS0/3/0/7
C 10.0.0.0/16 is directly connected, 13:43:40, GigabitEthernet0/0/0/0
C 10.10.10.0/30 is directly connected, 13:43:40, Loopback0
C 11.11.11.0/24 is directly connected, 13:43:40, Loopback11
```

[Table 15](#) describes the significant fields shown in the display.

**Table 15** *show route connected* Field Descriptions

| Field             | Description  |
|-------------------|--|
| C                 | Code to indicate the route is connected.                     |
| 1.68.0.0/16       | IP address and length of the route.                          |
| 13:43:40          | Time (in hh:mm:ss) since the route was installed in the RIB. |
| MgmtEth0/5/CPU0/0 | Outbound interface for the route.                            |

### Related Commands

| Command                            | Description                               |
|------------------------------------|---|
| <a href="#">show route summary</a> | Displays the current contents of the RIB. |

# show route local

To display local routes receiving routing updates from the Routing Information Base (RIB), use the **show route local** command in EXEC mode.

```
show route [vrf {vrf-name | all}] [afi-all | ipv4 | ipv6] [unicast | multicast {topology topo-name}]
safi-all] local [interface-type interface-instance] [standby]
```

| Syntax                                      | Description   |
|---|---|
| <b>vrf</b> { <i>vrf-name</i>   <b>all</b> } | (Optional) Specifies a particular VPN routing and forwarding (VRF) instance or all VRF instances.   |
| <b>afi-all</b>                              | (Optional) Specifies all address families.  |
| <b>ipv4</b>                                 | (Optional) Specifies IP Version 4 address prefixes.   |
| <b>ipv6</b>                                 | (Optional) Specifies IP Version 6 address prefixes.   |
| <b>unicast</b>                              | (Optional) Specifies unicast address prefixes.  |
| <b>multicast</b>                            | (Optional) Specifies multicast address prefixes.  |
| <b>topology</b> <i>topo-name</i>            | (Optional) Specifies topology table information and name of the topology table.   |
| <b>safi-all</b>                             | (Optional) Specifies unicast and multicast address prefixes.  |
| <i>interface-type</i>                       | (Optional) Interface type. For more information, use the question mark (?) online help function.  |
| <i>interface-instance</i>                   | (Optional) Either a physical interface instance or a virtual interface instance as follows: <ul style="list-style-type: none"> <li>Physical interface instance. Naming notation is <i>rack/slot/module/port</i> and a slash between values is required as part of the notation. <ul style="list-style-type: none"> <li><i>rack</i>: Chassis number of the rack.</li> <li><i>slot</i>: Physical slot number of the modular services card or line card.</li> <li><i>module</i>: Module number. A physical layer interface module (PLIM) is always 0.</li> <li><i>port</i>: Physical port number of the interface.</li> </ul> </li> </ul> <p><b>Note</b> In references to a Management Ethernet interface located on a route processor card, the physical slot number is alphanumeric (RP0 or RP1) and the module is CPU0.<br/>Example: interface MgmtEth0/RP1/CPU0/0.</p> <ul style="list-style-type: none"> <li>Virtual interface instance. Number range varies depending on interface type.</li> </ul> <p>For more information about the syntax for the router, use the question mark (?) online help function.</p> |
| <b>standby</b>                              | (Optional) Displays standby information.  |

## Defaults

If a **vrf** *vrf-name* is not specified, the local routes receiving updates from the RIB are displayed for the default IPv4 unicast VRF.

## ■ show route local

**Command Modes** EXEC

| Command History | Release       | Modification  |
|-----------------|---------------|---|
|                 | Release 2.0   | This command was introduced on the Cisco CRS-1.   |
|                 | Release 3.0   | No modification.  |
|                 | Release 3.2   | This command was supported on the Cisco XR 12000 Series Router. The <b>afi-all</b> and <b>safi-all</b> keywords were added.                     |
|                 | Release 3.3.0 | The <b>vrf vrf-name</b> keyword and argument were added.  |
|                 | Release 3.4.0 | The <b>all</b> and <b>standby</b> keywords were added.  |
|                 | Release 3.5.0 | No modification.  |
|                 | Release 3.6.0 | No modification.  |
|                 | Release 3.7.0 | The <b>topology topo-name</b> keyword and argument were added as options from the <b>multicast</b> keyword on the Cisco XR 12000 Series Router. |

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the *Configuring AAA Services on Cisco IOS XR Software* module of the *Cisco IOS XR System Security Configuration Guide*.

Use the **show route local** command to display information about local routes in the routing table.

The **topology** keyword must be accompanied by the **ipv4 multicast** keywords, except when the **afi-all** keyword or the **safi-all** keyword is specified.

| Task ID | Task ID | Operations |
|---------|---------|------------|
|         | rib     | read       |

**Examples**

The following is sample output from the **show route local** command:

```
RP/0/RP0/CPU0:router# show route local

L   10.10.10.1/32 is directly connected, 00:14:36, Loopback0
L   10.91.36.98/32 is directly connected, 00:14:32, POS6/0/0/1
L   172.22.12.1/32 is directly connected, 00:13:35, POS3/0/0/1
L   192.168.20.2/32 is directly connected, 00:13:27, POS4/0/0/1
L   10.254.254.1/32 is directly connected, 00:13:26, POS5/0/0/1
```

[Table 16](#) describes the significant fields shown in the display.

**Table 16** show route local Field Descriptions

| Field         | Description                          |
|---------------|--------------------------------------|
| L             | Code to indicate the route is local. |
| 10.10.10.1/32 | IP address and length of the route.  |

**Table 16** *show route local Field Descriptions*

| Field     | Description  |
|-----------|--|
| 00:14:36  | Time (in hh:mm:ss) since the route was installed in the RIB. |
| Loopback0 | Outbound interface for the route.                            |

**Related Commands**

| Command                              | Description  |
|--------------------------------------|--|
| <a href="#">show route connected</a> | Displays information about all clients that have registered with the RIB as protocols. |

# show route longer-prefixes

To display the current routes in the Routing Information Base (RIB) that share a given number of bits with a given network, use the **show route longer-prefixes** command in EXEC mode.

```
show route [vrf {vrf-name | all}] [ipv4 | ipv6] [unicast | multicast {topology topo-name} | safi-all]
longer-prefixes {ip-address mask | ip-address/prefix-length} [standby]
```

## Syntax Description

|                             |   |
|-----------------------------|---|
| <b>vrf</b> {vrf-name   all} | (Optional) Specifies a particular VPN routing and forwarding (VRF) instance or all VRF instances.   |
| <b>ipv4</b>                 | (Optional) Specifies IP Version 4 address prefixes.   |
| <b>ipv6</b>                 | (Optional) Specifies IP Version 6 address prefixes.   |
| <b>unicast</b>              | (Optional) Specifies unicast address prefixes.  |
| <b>multicast</b>            | (Optional) Specifies multicast address prefixes.  |
| <b>topology</b> topo-name   | (Optional) Specifies topology table information and name of the topology table.   |
| <b>safi-all</b>             | (Optional) Specifies unicast and multicast address prefixes.  |
| <i>ip-address</i>           | Network IP address about which routing information should be displayed.   |
| <i>mask</i>                 | Network mask specified in either of two ways: <ul style="list-style-type: none"> <li>• Network mask can be a four-part, dotted-decimal address. For example, 255.0.0.0 indicates that each bit equal to 1 means the corresponding address bit is a network address.</li> <li>• Network mask can be indicated as a slash (/) and number. For example, /8 indicates that the first 8 bits of the mask are 1s, and the corresponding bits of the address are the network address.</li> </ul> |
| <i>/prefix-length</i>       | Length of the IP address prefix. A decimal value that indicates how many of the high-order contiguous bits of the address compose the prefix (the network portion of the address). A slash (/) must precede the decimal value.  |
| <b>standby</b>              | (Optional) Displays standby information.  |

## Defaults

If a **vrf** *vrf-name* is not specified, the current routes in the RIB sharing a specified number of bits with a network are displayed for the default IPv4 unicast VRF.

## Command Modes

EXEC

## Command History

| Release       | Modification  |
|---------------|---|
| Release 2.0   | This command was introduced on the Cisco CRS-1.   |
| Release 3.0   | No modification.  |
| Release 3.2   | This command was supported on the Cisco XR 12000 Series Router. The <b>afi-all</b> and <b>safi-all</b> keywords were added. |
| Release 3.3.0 | The <b>vrf</b> <i>vrf-name</i> keyword and argument were added.   |

| Release       | Modification   |
|---------------|--|
| Release 3.4.0 | The <b>all</b> and <b>standby</b> keywords were added.<br>The <b>afi-all</b> keyword was removed.  |
| Release 3.5.0 | No modification.   |
| Release 3.6.0 | No modification.   |
| Release 3.7.0 | The <b>topology</b> <i>topo-name</i> keyword and argument were added as options from the <b>multicast</b> keyword on the Cisco XR 12000 Series Router. |

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the *Configuring AAA Services on Cisco IOS XR Software* module of the *Cisco IOS XR System Security Configuration Guide*.

Use the **show route longer-prefixes** command to troubleshoot forwarding problems whose cause may be a long prefix.

The **topology** keyword must be accompanied by the **ipv4 multicast** keywords, except when the **afi-all** keyword or the **safi-all** keyword is specified.

### Task ID

| Task ID | Operations |
|---------|------------|
| rib     | read       |

### Examples

The following is sample output from the **show route longer-prefixes** command:

```
RP/0/RP0/CPU0:router# show route longer-prefixes 172.16.0.0/8

Codes: C - connected, S - static, R - RIP, M - mobile, B - BGP
       D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter area
       N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
       E1 - OSPF external type 1, E2 - OSPF external type 2, E - EGP
       i - ISIS, L1 - IS-IS level-1, L2 - IS-IS level-2
       ia - IS-IS inter area, su - IS-IS summary null, * - candidate default
       U - per-user static route, o - ODR, L - local

L   172.29.52.70/32 is directly connected, 4d15h, MgmtEth0/RP0/CPU0/0
L   172.29.52.71/32 is directly connected, 4d15h, MgmtEth0/RP1/CPU0/0
L   172.29.52.72/32 [0/0] via 172.29.52.72, 4d15h, MgmtEth0/RP0/CPU0/0
```

[Table 17](#) describes the significant fields shown in the display.

**Table 17** *show route longer-prefixes* Field Descriptions

| Field                   | Description  |
|-------------------------|--|
| 172.29.52.70/32         | IP address and length of the route.  |
| 4d15h                   | Time (in hh:mm:ss or <i>ndnh</i> ) since the route was installed in the RIB. |
| MgmtEth0/RP0/CP<br>U0/0 | Outbound interface for the route.  |

## ■ show route longer-prefixes

| Related Commands | Command                            | Description   |
|------------------|------------------------------------|---|
|                  | <b>router static</b>               | Establishes a static route.   |
|                  | <b>show interfaces</b>             | Lists interface information.  |
|                  | <a href="#">show route summary</a> | Displays the current contents of the routing table in summary format. |

# show route next-hop

To filter routes by the next-hop address or interface, use the **show route next-hop** command in EXEC mode.

```
show route [vrf {vrf-name | all}] [ipv4 | ipv6] [unicast | multicast {topology topo-name}] [safi-all]
next-hop [ip-address] [standby]
```

| Syntax Description          |            |  |
|-----------------------------|------------|--|
| <b>vrf</b> {vrf-name   all} | (Optional) | Specifies a particular VPN routing and forwarding (VRF) instance or all VRF instances. |
| <b>ipv4</b>                 | (Optional) | Specifies IP Version 4 address prefixes.   |
| <b>ipv6</b>                 | (Optional) | Specifies IP Version 6 address prefixes.   |
| <b>unicast</b>              | (Optional) | Specifies unicast address prefixes.  |
| <b>multicast</b>            | (Optional) | Specifies multicast address prefixes.  |
| <b>topology</b> topo-name   | (Optional) | Specifies topology table information and name of the topology table.                   |
| <b>safi-all</b>             | (Optional) | Specifies unicast and multicast address prefixes.                                      |
| ip-address                  | (Optional) | IP address about which next-hop information is to be displayed.                        |
| <b>standby</b>              | (Optional) | Displays standby information.  |

**Defaults** If a **vrf** vrf-name is not specified, the next-hop gateway or host is displayed for the default IPv4 unicast VRF.

**Command Modes** EXEC

| Command History | Release       | Modification  |
|-----------------|---------------|---|
|                 | Release 3.4.0 | Function of this command was changed. See the <b>show route resolving-next-hop</b> command.   |
|                 | Release 3.5.0 | The <i>ip-address</i> argument was changed from required to optional.   |
|                 | Release 3.6.0 | No modification.  |
|                 | Release 3.7.0 | The <b>topology</b> topo-name keyword and argument were added as options from the <b>multicast</b> keyword on the Cisco XR 12000 Series Router. |

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the *Configuring AAA Services on Cisco IOS XR Software* module of the *Cisco IOS XR System Security Configuration Guide*.

Use the **show route next-hop** command to find all routes going through a next-hop address or interface.

The **topology** keyword must be accompanied by the **ipv4 multicast** keywords, except when the **afi-all** keyword or the **safi-all** keyword is specified.

## show route next-hop

| Task ID | Task ID | Operations |
|---------|---------|------------|
|         | rib     | read       |

### Examples

The following is sample output from the **show route next-hop** command filtering routes on the next-hop address:

```
RP/0/RP0/CPU0:router# show route next-hop 1.68.0.1

Codes: C - connected, S - static, R - RIP, M - mobile, B - BGP
D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter area
N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
E1 - OSPF external type 1, E2 - OSPF external type 2, E - EGP
i - ISIS, L1 - IS-IS level-1, L2 - IS-IS level-2
ia - IS-IS inter area, su - IS-IS summary null, * - candidate default
U - per-user static route, o - ODR, L - local

Gateway of last resort is 1.68.0.1 to network 0.0.0.0

S* 0.0.0.0/0 [1/0] via 1.68.0.1, 15:01:49
S 223.255.254.254/32 [1/0] via 1.68.0.1, 15:01:49
```

The following is sample output from the **show route next-hop** command filtering routes on the next-hop interface:

```
RP/0/RP0/CPU0:router# show route next-hop GigabitEthernet 0/1/0/2

Codes: C - connected, S - static, R - RIP, M - mobile, B - BGP
D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter area
N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
E1 - OSPF external type 1, E2 - OSPF external type 2, E - EGP
i - ISIS, L1 - IS-IS level-1, L2 - IS-IS level-2
ia - IS-IS inter area, su - IS-IS summary null, * - candidate default
U - per-user static route, o - ODR, L - local

Gateway of last resort is 1.68.0.1 to network 0.0.0.0

C 11.1.1.0/24 is directly connected, 15:01:46, GigabitEthernet0/1/0/2
L 11.1.1.2/32 is directly connected, 15:01:46, GigabitEthernet0/1/0/2
```

[Table 18](#) describes the significant fields shown in the display.

**Table 18** *show route next-hop Field Descriptions*

| Field                  | Description  |
|------------------------|--|
| 11.1.1.0/24            | IP address and length of the route.  |
| 15:01:46               | Time (in hh:mm:ss or <i>ndnh</i> ) since the route was installed in the RIB. |
| GigabitEthernet0/1/0/2 | Outbound interface for the route.  |

### Related Commands

| Command           | Description   |
|-------------------|---|
| <b>show route</b> | Displays the current contents of the routing table. |

# show route quarantined

To display mutually recursive (looping) routes, use the **show route quarantined** command in EXEC mode.

```
show route [vrf {vrf-name | all}] [ipv4 | ipv6] [unicast | multicast {topology topo-name} | safi-all]
quarantined [ip-address /prefix-length | ip-address mask] [standby]
```

| Syntax Description          |   |  |
|-----------------------------|---|--|
| <b>vrf</b> {vrf-name   all} | (Optional) Specifies a particular VPN routing and forwarding (VRF) instance or all VRF instances.   |  |
| <b>ipv4</b>                 | (Optional) Specifies IP Version 4 address prefixes.   |  |
| <b>ipv6</b>                 | (Optional) Specifies IP Version 6 address prefixes.   |  |
| <b>unicast</b>              | (Optional) Specifies unicast address prefixes.  |  |
| <b>multicast</b>            | (Optional) Specifies multicast address prefixes.  |  |
| <b>topology</b> topo-name   | (Optional) Specifies topology table information and name of the topology table.   |  |
| <b>safi-all</b>             | (Optional) Specifies unicast and multicast address prefixes.  |  |
| <i>ip-address</i>           | (Optional) IP address about which looping routes information is to be displayed.  |  |
| <i>/prefix-length</i>       | (Optional) Length of the IP address prefix. A decimal value that indicates how many of the high-order contiguous bits of the address compose the prefix (the network portion of the address). A slash (/) must precede the decimal value. |  |
| <i>ip-address mask</i>      | (Optional) Network mask applied to the <i>ip-address</i> argument.  |  |
| <b>standby</b>              | (Optional) Displays standby information.  |  |

**Defaults** If a **vrf** *vrf-name* is not specified, the next-hop gateway or host is displayed for the default IPv4 unicast VRF.

**Command Modes** EXEC

| Command History | Release       | Modification   |
|-----------------|---------------|--|
|                 | Release 3.5.0 | This command was introduced on the Cisco CRS-1 and Cisco XR 12000 Series Router.   |
|                 | Release 3.6.0 | The <i>ip-address</i> argument was changed to <i>ip-address /prefix-length   ip-address mask</i> .   |
|                 | Release 3.7.0 | The <b>topology</b> <i>topo-name</i> keyword and argument were added as options from the <b>multicast</b> keyword on the Cisco XR 12000 Series Router. |

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the *Configuring AAA Services on Cisco IOS XR Software* module of the *Cisco IOS XR System Security Configuration Guide*.

RIB quarantining detects mutually recursive routes and quarantines the last route that actually completes the mutual recursion. The quarantined route is periodically evaluated to see if the mutual recursion has gone away. If the recursion still exists, the route remains quarantined. If the recursion has gone away, the route is released from quarantine.

Use the **show route quarantined** command to display mutually recursive (looping) routes.

The **topology** keyword must be accompanied by the **ipv4 multicast** keywords, except when the **afi-all** keyword or the **safi-all** keyword is specified.

**Task ID****Task ID****Operations**

| Task ID | Operations |
|---------|------------|
| rib     | read       |

**Examples**

The following is sample output from the **show route quarantined** command:

```
RP/0/RP0/CPU0:router# show route quarantined

Codes: C - connected, S - static, R - RIP, M - mobile, B - BGP
       D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter area
       N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
       E1 - OSPF external type 1, E2 - OSPF external type 2, E - EGP
       i - ISIS, L1 - IS-IS level-1, L2 - IS-IS level-2
       ia - IS-IS inter area, su - IS-IS summary null, * - candidate default
       U - per-user static route, o - ODR, L - local

S    10.10.109.1/32 [1/0] via 10.10.34.1, 00:00:01 (quarantined)
      [1/0] via 10.10.37.1, 00:00:01 (quarantined)
      [1/0] via 10.10.60.1, 00:00:01 (quarantined)
      [1/0] via 10.10.68.1, 00:00:01 (quarantined)
      [1/0] via 10.10.91.1, 00:00:01 (quarantined)
      [1/0] via 10.10.93.1, 00:00:01 (quarantined)
      [1/0] via 10.10.97.1, 00:00:01 (quarantined)
S    10.0.0.0/8 [1/0] via 11.11.11.11, 00:01:29 (quarantined)
S    10.10.0.0/16 [1/0] via 11.11.11.11, 00:01:29 (quarantined)
S    10.10.10.0/24 [1/0] via 11.11.11.11, 00:01:29 (quarantined)
S    10.10.10.10/32 [1/0] via 11.11.11.11, 00:00:09 (quarantined)
```

Table 19 describes the significant fields shown in the display.

**Table 19** show route quarantined Field Descriptions

| Field          | Description  |
|----------------|--|
| 10.10.109.1/32 | IP address and length of the route.                                  |
| [1/0]          | Distance and metric for the route.                                   |
| via 10.10.34.1 | IP address of next-hop on the route.                                 |
| 00:00:01       | Time (in hh:mm:ss or ndnh) since the route was installed in the RIB. |
| (quarantined)  | Shows that the route is quarantined.                                 |

**Related Commands**

| <b>Command</b>             | <b>Description</b>                                  |
|----------------------------|---|
| <a href="#">show route</a> | Displays the current contents of the routing table. |

# show route resolving-next-hop

To display the next-hop gateway or host to a destination address, use the **show route resolving-next-hop** command in EXEC mode.

```
show route [vrf {vrf-name | all}] [ipv4 | ipv6] [unicast | multicast { topology topo-name}] safi-all
resolving-next-hop ip-address [standby]
```

## Syntax Description

|                             |   |
|-----------------------------|---|
| <b>vrf</b> {vrf-name   all} | (Optional) Specifies a particular VPN routing and forwarding (VRF) instance or all VRF instances. |
| <b>ipv4</b>                 | (Optional) Specifies IP Version 4 address prefixes.   |
| <b>ipv6</b>                 | (Optional) Specifies IP Version 6 address prefixes.   |
| <b>unicast</b>              | (Optional) Specifies unicast address prefixes.  |
| <b>multicast</b>            | (Optional) Specifies multicast address prefixes.  |
| <b>topology</b> topo-name   | (Optional) Specifies topology table information and name of the topology table.                   |
| <b>safi-all</b>             | (Optional) Specifies unicast and multicast address prefixes.                                      |
| <i>ip-address</i>           | IP address about which resolved next-hop information is to be displayed.                          |
| <b>standby</b>              | (Optional) Displays standby information.  |

## Defaults

If a **vrf** *vrf-name* is not specified, the next-hop gateway or host is displayed for the default IPv4 unicast VRF.

## Command Modes

EXEC

## Command History

| Release       | Modification  |
|---------------|---|
| Release 2.0   | This command was introduced on the Cisco CRS-1.   |
| Release 3.0   | No modification.  |
| Release 3.2   | This command was supported on the Cisco XR 12000 Series Router. The <b>afi-all</b> and <b>safi-all</b> keywords were added.   |
| Release 3.3.0 | The <b>vrf</b> <i>vrf-name</i> keyword and argument were added.   |
| Release 3.4.0 | This command was changed from <b>show route next-hop</b> to <b>show route resolving-next-hop</b> .<br>The <b>all</b> and <b>standby</b> keywords were added.<br>The <b>afi-all</b> keyword was removed. |
| Release 3.5.0 | No modification.  |
| Release 3.6.0 | No modification.  |
| Release 3.7.0 | The <b>topology</b> <i>topo-name</i> keyword and argument were added as options from the <b>multicast</b> keyword on the Cisco XR 12000 Series Router.  |

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the *Configuring AAA Services on Cisco IOS XR Software* module of the *Cisco IOS XR System Security Configuration Guide*.

Use the **show route resolving-next-hop** command to perform a recursive route lookup on the supplied destination address and return information on the next immediate router (next-hop) to the destination.

The **topology** keyword must be accompanied by the **ipv4 multicast** keywords, except when the **afi-all** keyword or the **safi-all** keyword is specified.

**Task ID**

| Task ID | Operations |
|---------|------------|
| rib     | read       |

**Examples**

The following is sample output from the **show route resolving-next-hop** command:

```
RP/0/RP0/CPU0:router# show route resolving-next-hop 10.1.1.1

Nexthop matches 10.1.1.1/32
  Known via "local", distance 0, metric 0 (connected)
  Installed Aug 22 01:57:08.514
  Directly connected nexthops
    10.1.1.1 directly connected, via Loopback0
    Route metric is 0
```

[Table 20](#) describes the significant fields shown in the display.

**Table 20** *show route resolving-next-hop Field Descriptions*

| Field           | Description   |
|-----------------|---|
| Known via       | Name of the routing protocol that installed the matching route. |
| Route metric is | Metric of the route.  |

**Related Commands**

| Command                    | Description   |
|----------------------------|---|
| <a href="#">show route</a> | Displays the current contents of the routing table. |

# show route static

To display the current static routes of the Routing Information Base (RIB), use the **show route static** command in EXEC mode.

```
show route [vrf {vrf-name | all}] [afi-all | ipv4 | ipv6] [unicast | multicast {topology topo-name}
| safi-all] static [standby]
```

## Syntax Description

|                             |   |
|-----------------------------|---|
| <b>vrf</b> {vrf-name   all} | (Optional) Specifies a particular VPN routing and forwarding (VRF) instance or all VRF instances. |
| <b>afi-all</b>              | (Optional) Specifies all address families.  |
| <b>ipv4</b>                 | (Optional) Specifies IP Version 4 address prefixes.   |
| <b>ipv6</b>                 | (Optional) Specifies IP Version 6 address prefixes.   |
| <b>unicast</b>              | (Optional) Specifies unicast address prefixes.  |
| <b>multicast</b>            | (Optional) Specifies multicast address prefixes.  |
| <b>topology</b> topo-name   | (Optional) Specifies topology table information and name of the topology table.                   |
| <b>safi-all</b>             | (Optional) Specifies unicast and multicast address prefixes.                                      |
| <b>standby</b>              | (Optional) Displays standby information.  |

## Defaults

If a **vrf** *vrf-name* is not specified, the current static routes of the RIB are displayed for the default IPv4 unicast VRF.

## Command Modes

EXEC

## Command History

| Release       | Modification   |
|---------------|--|
| Release 2.0   | This command was introduced on the Cisco CRS-1.  |
| Release 3.0   | No modification.   |
| Release 3.2   | This command was supported on the Cisco XR 12000 Series Router. The <b>afi-all</b> and <b>safi-all</b> keywords were added.                            |
| Release 3.3.0 | The <b>vrf</b> <i>vrf-name</i> keyword and argument were added.  |
| Release 3.4.0 | The <b>all</b> and <b>standby</b> keywords were added.   |
| Release 3.5.0 | No modification.   |
| Release 3.6.0 | No modification.   |
| Release 3.7.0 | The <b>topology</b> <i>topo-name</i> keyword and argument were added as options from the <b>multicast</b> keyword on the Cisco XR 12000 Series Router. |

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the *Configuring AAA Services on Cisco IOS XR Software* module of the *Cisco IOS XR System Security Configuration Guide*.

Use the **show route static** command to display information about static routes in the routing table.

The **topology** keyword must be accompanied by the **ipv4 multicast** keywords, except when the **afi-all** keyword or the **safi-all** keyword is specified.

| Task ID | Task ID | Operations |
|---------|---------|------------|
|         | rib     | read       |

### Examples

The following is sample output from the **show route static** command:

```
RP/0/RP0/CPU0:router# show route static

S    10.1.1.0/24 is directly connected, 00:54:05, POS3/0/0/1
S    192.168.99.99/32 [1/0] via 10.12.12.2, 00:54:04
```

[Table 21](#) describes the significant fields shown in the display.

**Table 21** *show route static Field Descriptions*

| Field       | Description  |
|-------------|--|
| S           | Code to indicate the route is static.                        |
| 10.1.1.0/24 | IP address and distance for the route.                       |
| 00:54:05    | Time (in hh:mm:ss) since the route was installed in the RIB. |
| POS3/0/0/1  | Outbound interface for the route.                            |
| [1/0]       | Distance and metric for the route.                           |

### Related Commands

| Command                    | Description   |
|----------------------------|---|
| <a href="#">show route</a> | Displays the current contents of the routing table. |

# show route summary

To display the current contents of the Routing Information Base (RIB), use the **show route summary** command in EXEC mode.

```
show route [vrf {vrf-name | all}] [afi-all | ipv4 | ipv6] [unicast | multicast {topology topo-name}
| safi-all] summary [detail] [standby]
```

| Syntax Description          |   |  |
|-----------------------------|---|--|
| <b>vrf</b> {vrf-name   all} | (Optional) Specifies a particular VPN routing and forwarding (VRF) instance or all VRF instances.   |  |
| <b>afi-all</b>              | (Optional) Specifies all address families.  |  |
| <b>ipv4</b>                 | (Optional) Specifies IP Version 4 address prefixes.   |  |
| <b>ipv6</b>                 | (Optional) Specifies IP Version 6 address prefixes.   |  |
| <b>unicast</b>              | (Optional) Specifies unicast address prefixes.  |  |
| <b>multicast</b>            | (Optional) Specifies multicast address prefixes.  |  |
| <b>topology</b> topo-name   | (Optional) Specifies topology table information and name of the topology table.   |  |
| <b>safi-all</b>             | (Optional) Specifies unicast and multicast address prefixes.  |  |
| <b>detail</b>               | (Optional) Displays a detailed summary of the contents of the RIB, including the number of paths and some protocol-specific route attributes. |  |
| <b>standby</b>              | (Optional) Displays standby information.  |  |

## Defaults

If a **vrf** *vrf-name* is not specified, the contents of the RIB are displayed for the default IPv4 unicast VRF.

## Command Modes

EXEC

## Command History

| Release       | Modification   |
|---------------|--|
| Release 2.0   | This command was introduced on the Cisco CRS-1.  |
| Release 3.0   | No modification.   |
| Release 3.2   | This command was supported on the Cisco XR 12000 Series Router. The <b>afi-all</b> and <b>safi-all</b> keywords were added.                            |
| Release 3.3.0 | The <b>vrf</b> <i>vrf-name</i> keyword and argument were added.  |
| Release 3.4.0 | The <b>all</b> and <b>standby</b> keywords were added.   |
| Release 3.5.0 | No modification.   |
| Release 3.6.0 | No modification.   |
| Release 3.7.0 | The <b>topology</b> <i>topo-name</i> keyword and argument were added as options from the <b>multicast</b> keyword on the Cisco XR 12000 Series Router. |

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the *Configuring AAA Services on Cisco IOS XR Software* module of the *Cisco IOS XR System Security Configuration Guide*.

Use the **show route summary** command to display information about routes in the routing information base.

When a route summary is needed frequently—for instance, in a polling manner—use the **show route summary** command without the **detail** keyword. The **detail** keyword is used less frequently for verification purposes, because it is much more expensive (in bandwidth), requiring a scan of the entire routing database.

The **topology** keyword must be accompanied by the **ipv4 multicast** keywords, except when the **afi-all** keyword or the **safi-all** keyword is specified.

**Task ID**

| Task ID | Operations |
|---------|------------|
| rib     | read       |

**Examples**

The following is sample output from the **show route summary** command:

```
RP/0/RP0/CPU0:router# show route summary
```

| Route Source | Routes | Backup | Deleted | Memory (bytes) |
|--------------|--------|--------|---------|----------------|
| static       | 1      | 0      | 0       | 136            |
| connected    | 2      | 1      | 0       | 408            |
| local        | 3      | 0      | 0       | 408            |
| ospf         | 1673   | 2      | 0       | 272            |
| isis         | 2      | 0      | 0       | 272            |
| Total        | 10     | 1      | 0       | 1496           |

The following is sample output from the **show route summary** command with the **detail** keyword:

```
RP/0/RP0/CPU0:router# show route summary detail
```

| Route Source | Active Route | Active Path | Backup Route | Backup Path |
|--------------|--------------|-------------|--------------|-------------|
| static       | 1            | 1           | 0            | 0           |
| connected    | 2            | 2           | 1            | 1           |
| local        | 3            | 3           | 0            | 0           |
| isis         | 1            | 1           | 1            | 1           |
| Level 1:     | 0            | 0           | 1            | 1           |
| Level 2:     | 1            | 1           | 0            | 0           |
| ospf 1673    | 6            | 12          | 0            | 0           |
| Intra-Area:  | 3            | 6           | 0            | 0           |
| Inter-Area:  | 3            | 6           | 0            | 0           |
| External-1:  | 0            | 0           | 0            | 0           |
| External-2:  | 0            | 0           | 0            | 0           |
| bgp 100      | 10           | 20          | 4            | 8           |
| External:    | 5            | 10          | 4            | 8           |
| Internal:    | 5            | 10          | 0            | 0           |
| local:       | 0            | 0           | 0            | 0           |
| Total        | 7            | 7           | 2            | 2           |

[Table 22](#) describes the significant fields shown in the display.

**Table 22** *show route summary Field Descriptions*

| <b>Field</b> | <b>Description</b>  |
|--------------|---|
| Route Source | Routing protocol name.  |
| Routes       | Number of selected routes that are present in the routing table for each route source.        |
| Backup       | Number of routes that are not selected (are backup to a selected route).                      |
| Deleted      | Number of routes that have been marked for deletion in the RIB, but have not yet been purged. |
| Memory       | Number of bytes allocated to maintain all routes for the particular route source.             |

**Related Commands**

| <b>Command</b>             | <b>Description</b>                                  |
|----------------------------|---|
| <a href="#">show route</a> | Displays the current contents of the routing table. |