



# GRE Tunnel Interface Commands

---

This module describes the command line interface (CLI) commands for configuring GRE tunnel interfaces on the Cisco 8000 Series Routers.

For information on configuring GRE tunnels, see the *Interface and Hardware Component Configuration Guide for Cisco 8000 Series Routers*.

- [hw-module profile cef ttl tunnel-ip decrement disable, on page 2](#)
- [hw-module profile gue , on page 3](#)
- [hw-module profile gue underlay-hash enable, on page 5](#)
- [interface tunnel-ip, on page 6](#)
- [tunnel mode, on page 7](#)
- [tunnel source, on page 8](#)
- [tunnel destination, on page 9](#)
- [tunnel ttl disable, on page 10](#)
- [show interface tunnel accounting \(encap\), on page 11](#)
- [show interface tunnel accounting \(decap\), on page 12](#)
- [show tunnel ip ea database brief, on page 13](#)
- [show tunnel ip ma database brief, on page 14](#)

**hw-module profile cef ttl tunnel-ip decrement disable**

## hw-module profile cef ttl tunnel-ip decrement disable

To disable the decrement of TTL value of inner payload header of an IP-in-IP packet, use the **hw-module profile cef ttl tunnel-ip decrement disable** command in XR Config mode.

**hw-module profile cef ttl tunnel-ip decrement disable**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** XR Config

Command History	Release	Modification
	Release 7.0.14	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

### Example

The following example shows how you can disable the decrement of TTL value of inner payload header of an IP-in-IP packet.

```
Router# configure
Router(config)# hw-module profile cef ttl tunnel-ip decrement disable
Router(config)# commit
Thu Jun 11 08:43:52.343 UTC
LC/0/0/CPU0:Jun 11 08:43:52.505 UTC: npu_drvr[204]:
%FABRIC-NPU_DRVRR-3-HW_MODULE_PROFILE_TTL_CHASSIS_CFG_CHANGED : Hw-module profile ttl config
changed. Behaviour of IPinIP tunnel's inner header ttl decrement will be changed.
```

# hw-module profile gue

To configure unique GUE port numbers to decapsulate IPv4, IPv6, and MPLS packets using UDP, use the **hw-module profile gue udp-dest-port ipv4 <port number> ipv6 <port number> mpls <port number>** command in XR Config mode on the destination router.

```
hw-module profile gue udp-dest-port ipv4 <port number> ipv6 <port number> mpls <port number>
```

*Table 1: Command Description*

Keyword	Description
gue	The UDP destination port configuration of the GUE decapsulation tunnel.
udp-dest-port	Configure separate UDP port numbers for IPv4, IPv6, and MPLS.
ipv4	Configure unreserved UDP port numbers for IPv4 payload. The supported range is from 1000 through 64000.
ipv6	Configure unreserved UDP port numbers for IPv6 payload. The supported range is from 1000 through 64000.
mpls	Configure unreserved UDP port numbers for MPLS payload. The supported range is from 1000 through 64000.

To remove this configuration, use the no prefix of the command:

```
no hw-module profile gue udp-dest-port ipv4 <port number> ipv6 <port number> mpls <port number>
```

**Command Default** None

**Command Modes** XR Config

Command History	Release	Modification
	Release 7.3.3	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

## Example

The following example shows how you can configure unique GUE port numbers to decapsulate IPv4, IPv6, and MPLS packets using UDP.

**hw-module profile gue**

```
Router(config)#hw-module profile gue udp-dest-port ipv4 1001 ipv6 1002 mpls 1003
```

# hw-module profile gue underlay-hash enable

To use only the outer IP header (L3 and L4) for calculating the hashing for incoming GUE packets, use the **hw-module profile gue underlay-hash enable** command in mode.

**hw-module profile gue underlay-hash enable**

<b>Syntax Description</b>	<i>enable</i> To enable only the outer IP header (L3 and L4) for calculating the hashing.
---------------------------	---

<b>Command Default</b>	By default, both outer IP header (L3 and L4) and inner IP header (L3 and L4) are considered for calculating the hashing for incoming GUE packets.
------------------------	---

<b>Command Modes</b>	XR Config mode
----------------------	----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.11.1	This command was introduced.

<b>Usage Guidelines</b>	This command is currently supported only on Q200-based ASICs.
-------------------------	---

## Example

The following example shows how to enable only the outer IP header (L3 and L4) for calculating the hashing:

```
RP/0/RP0/CPU0:R2#configure
RP/0/RP0/CPU0:R2(config) #hw-module profile gue underlay-hash enable
RP/0/RP0/CPU0:R2(config) #commit
RP/0/RP0/CPU0:R2(config) #end
```

**interface tunnel-ip**

# interface tunnel-ip

Configures an IP-in-IP tunnel interface.

To remove this configuration, use the **no** prefix of the command.

```
interface tunnel-ip id
no interface tunnel-ip id
```

<b>Syntax Description</b>	<i>id</i> Specifies the tunnel interface identifier. Range is from 0 to 131070.				
<b>Command Default</b>	None				
<b>Command Modes</b>	XR Config mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th><b>Release</b></th> <th><b>Modification</b></th> </tr> </thead> <tbody> <tr> <td>7.0.12</td> <td>This command was introduced.</td></tr> </tbody> </table>	<b>Release</b>	<b>Modification</b>	7.0.12	This command was introduced.
<b>Release</b>	<b>Modification</b>				
7.0.12	This command was introduced.				
<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.				

## Example

The following example shows how you can configure an IP-in-IP tunnel interface.

```
RP/0/RP0/CPU0:router(config)# interface tunnel-ip 10
RP/0/RP0/CPU0:router(config-if)# ipv4 unnumbered loopback 20
RP/0/RP0/CPU0:router(config-if)# tunnel mode ipv4 decap
RP/0/RP0/CPU0:router(config-if)# tunnel source loopback 0
RP/0/RP0/CPU0:router(config-if)# tunnel destination 50.10.1.2/32
```

# tunnel mode

Configures the mode of encapsulation for the tunnel interface.

To remove this configuration, use the **no** prefix of the command.

```
tunnel mode { gre { ipv4 | ipv6 } [ decap ] | ipv4 [ decap ] | ipv6 [ decap ] }
no tunnel mode { gre { ipv4 | ipv6 } [ decap ] | ipv4 [ decap ] | ipv6 [ decap ] }
```

<b>Syntax Description</b>	<b>tunnel mode gre</b> Configures IP-over-GRE encapsulation for the tunnel interface. <b>tunnel mode ipv4</b> Configures generic packet tunneling over IPv4 encapsulation for the tunnel interface. <b>tunnel mode ipv6</b> Configures generic packet tunneling over IPv6 encapsulation for the tunnel interface. <b>tunnel mode gre ipv4</b> Configures GRE-over-IPv4 encapsulation for the tunnel interface. <b>tunnel mode gre ipv6</b> Configures GRE-over-IPv6 encapsulation for the tunnel interface. <b>decap</b> Configures the IP-in-IP or GRE tunnel to be used only for decapsulation.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Tunnel interface configuration mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th><b>Release</b></th> <th><b>Modification</b></th> </tr> </thead> <tbody> <tr> <td>7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	<b>Release</b>	<b>Modification</b>	7.0.12	This command was introduced.
<b>Release</b>	<b>Modification</b>				
7.0.12	This command was introduced.				
<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.				

## Example

The following example shows how you can configure the tunnel mode for an IP-in-IP tunnel interface.

```
RP/0/RP0/CPU0:router(config)# interface tunnel-ip 10
RP/0/RP0/CPU0:router(config-if)# ipv4 unnumbered loopback 20
RP/0/RP0/CPU0:router(config-if)# tunnel mode ipv4 decap
RP/0/RP0/CPU0:router(config-if)# tunnel source loopback 0
RP/0/RP0/CPU0:router(config-if)# tunnel destination 50.10.1.2/32
```

**tunnel source**

# tunnel source

Configures the source IP address for a tunnel interface.

To remove this configuration, use the **no** prefix of the command.

```
tunnel source {ipv4-address | interface-type interface-number}
no tunnel source {ipv4-address | interface-type interface-number}
```

<b>Syntax Description</b>	<i>ipv4-address</i>	Configures the specified IPv4 address as the source IP for the tunnel interface.
	<i>interface-type interface-number</i>	Configures the specified interface type as the source for the tunnel interface.
<b>Command Default</b>	None	
<b>Command Modes</b>	Tunnel interface configuration mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.
<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.	

## Example

The following example shows how you can configure the Loopback 0 interface as the tunnel source for an IP-in-IP tunnel interface.

```
RP/0/RP0/CPU0:router(config)# interface tunnel-ip 10
RP/0/RP0/CPU0:router(config-if)# ipv4 unnumbered loopback 20
RP/0/RP0/CPU0:router(config-if)# tunnel mode ipv4 decap
RP/0/RP0/CPU0:router(config-if)# tunnel source loopback 0
RP/0/RP0/CPU0:router(config-if)# tunnel destination 50.10.1.2/32
```

# tunnel destination

Configures the tunnel destination for the tunnel interface.

To remove this configuration, use the **no** prefix of the command.

```
tunnel destination { ipv4-address | ipv4 address/subnet-mask | ipv6-address | object-group-ipv4 | object-group-ipv6 }
no tunnel destination { ipv4-address | ipv4 address/subnet-mask | ipv6-address | object-group-ipv4 | object-group-ipv6 }
```

<b>Syntax Description</b>	<i>ipv4-address</i> Configures the specified IPv4 address as the destination IP for the tunnel interface. <i>ipv4-address/subnet mask</i> Configures the specified IPv4 address with subnet mask as the destination IP for the tunnel interface. <i>ipv6-address</i> Configures the specified IPv6 address as the destination IP for the tunnel interface. <i>object-group-ipv4</i> Configures the specified IPv4 object group as the destination IP for the tunnel interface. <i>object-group-ipv6</i> Configures the specified IPv6 object group as the destination IP for the tunnel interface.						
<b>Command Default</b>	None						
<b>Command Modes</b>	Tunnel interface configuration mode						
<b>Command History</b>	<table border="1"> <thead> <tr> <th><b>Release</b></th> <th><b>Modification</b></th> </tr> </thead> <tbody> <tr> <td>Release 7.5.4</td> <td>This command was modified to introduce <b>object-group-ipv4</b> and <b>object-group-ipv6</b> options.</td> </tr> <tr> <td>7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	<b>Release</b>	<b>Modification</b>	Release 7.5.4	This command was modified to introduce <b>object-group-ipv4</b> and <b>object-group-ipv6</b> options.	7.0.12	This command was introduced.
<b>Release</b>	<b>Modification</b>						
Release 7.5.4	This command was modified to introduce <b>object-group-ipv4</b> and <b>object-group-ipv6</b> options.						
7.0.12	This command was introduced.						
<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.						

## Example

The following example shows how you can configure an IPv4 address with subnet mask as the tunnel destination for an IP-in-IP tunnel interface.

```
RP/0/RP0/CPU0:router(config)# interface tunnel-ip 10
RP/0/RP0/CPU0:router(config-if)# ipv4 unnumbered loopback 20
RP/0/RP0/CPU0:router(config-if)# tunnel mode ipv4 decap
RP/0/RP0/CPU0:router(config-if)# tunnel source loopback 0
RP/0/RP0/CPU0:router(config-if)# tunnel destination 50.10.1.2/32
```

**tunnel ttl disable**

# tunnel ttl disable

Disables the decrement of TTL value of an incoming packet in a interface tunnel before encapsulation for GRE forwarding.

## **tunnel ttl disable**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** XR Config

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.3.2	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

## **Example**

The following example shows how you can disable the decrement of TTL an incoming packet before encapsulation for GRE forwarding.

```
Router# configure
Router(config)# interface tunnel-ip30016
Router(config-if)# tunnel ttl disable
Router(config-if)# commit
Thu Sep 11 08:43:52.343 UTC
```

# show interface tunnel accounting (encap)

To display accounting information about a tunnel interface in encapsulation mode, use the `show int tunnel accounting` command in XR EXEC mode.

**show interface tunnel-ip <0-131070> accounting**

**Command Default** No default behavior or values.

**Command Modes** XR EXEC

**Command History** **Release Modification**

7.3.1 This command was introduced.

## Example

This example shows how to display accounting information about a tunnel interface in encapsulation mode.

```
RP/0/RP0/CPU0:router#show interface tunnel-ip 1 accounting
Tue Aug 25 06:23:49.405 UTC
tunnel-ipl
  Protocol          Pkts In          Chars In          Pkts Out          Chars Out
  IPV4_UNICAST      0                0            1848           857822
```

show interface tunnel accounting (decap)

# show interface tunnel accounting (decap)

To display accounting information about a tunnel interface in decapsulation mode, use the `show int tunnel accounting` command in XR EXEC mode.

**show interface tunnel-ip <0-131070> accounting**

<b>Command Default</b>	No default behavior or values.				
<b>Command Modes</b>	XR EXEC				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>7.3.1</td><td>This command was introduced.</td></tr> </tbody> </table>	Release	Modification	7.3.1	This command was introduced.
Release	Modification				
7.3.1	This command was introduced.				

## Example

This example shows how to display accounting information about a tunnel interface in decapsulation mode.

```
RP/0/RP0/CPU0:router#show interface tunnel-ip 2002 accounting
tunnel-ip2002
  Protocol          Pkts In      Chars In      Pkts Out      Chars Out
  IPV4_UNICAST     106908    11759880          0            0
```

# show tunnel ip ea database brief

To display tunnel ip ea database parameters in brief, use the **show tunnel ip ea database brief** command in XR EXEC mode.

**show tunnel ip ea database brief location node-id**

<b>Syntax Description</b>	<b>location</b> <i>node-id</i> Displays information about the node location specified as <i>rack / slot / module</i> .				
<b>Command Default</b>	No default behavior or values.				
<b>Command Modes</b>	XR EXEC				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>24.1.1</td><td>This command was introduced.</td></tr> </tbody> </table>	Release	Modification	24.1.1	This command was introduced.
Release	Modification				
24.1.1	This command was introduced.				

The following is sample output from the **show tunnel ip ea database brief** command with the **location** keyword:

```
RP/0/RP0/CPU0:router#show tunnel ip ea database brief location 0/1/CPU0
Mon Nov  6 13:04:37.361 IST

----- node0_1_CPU0 -----
      Ifhandle     Src          Status      Tpt-Vrf-Tbl-ID      Dst          Mode
      Adjacency   1.1.1.1
0x90           Up          Up          0xe0000000          15.15.15.5    GREoIPv4(lite)
      Up          Up          0xe0000000          14.14.14.14    GREoIPv4
0xb0           Up          Up          0xe0000000          8.8.8.8       GREoIPv4
      Up          Up          0xe0000000          2a02:a90:4007:700::192  GREoIPv6
0xd0           Down        Down        0xe0000000
      Down        Down        0xe0800000
```

**show tunnel ip ma database brief**

## show tunnel ip ma database brief

To display tunnel ip ma database parameters in brief, use the **show tunnel ip ma database brief** command in XR EXEC mode.

### show tunnel ip ma database brief

**Syntax Description** This command has no keywords or arguments.

**Command Default** No default behavior or values.

**Command Modes** XR EXEC

**Command History** **Release Modification**

24.1.1 This command was introduced.

### Example

The following is sample output from the **show tunnel ip ma database brief** command:

```
RP/0/RP0/CPU0:router#show tunnel ip ma database brief
Mon Nov  6 13:04:28.905 IST

Interface      Src          Dst          Mode
      Caps      Status      Tpt-Vrf-Name
tunnel-ip100   1.1.1.1    15.15.15.5  GREoIPv4 (lite)
    ipv4        Up
tunnel-ip200   5.5.5.5    14.14.14.14  GREoIPv4
    ipv4  ipv6 mpls  Up
tunnel-ip300   0.0.0.0    8.8.8.8     GREoIPv4
                           Down
tunnel-ip500   ::          2a02:a90:4007:700::192  GREoIPv6
                           Down
```