

# **Prepare for Installation**



Note

The images in this chapter are only for representational purposes, unless specified otherwise. The chassis' actual appearance and size may vary.

Warning Statement 1071—Warning Definition

IMPORTANT SAFETY INSTRUCTIONS

This warning symbol means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry, and be familiar with standard practices for preventing accidents. Use the statement number provided at the end of each warning to locate its translation in the translated safety warnings that accompanied this device.

SAVE THESE INSTRUCTIONS

- Safety Guidelines, on page 1
- Compliance and Safety Information, on page 2
- Laser Safety, on page 3
- Energy Hazard, on page 4
- Preventing Electrostatic Discharge Damage, on page 4
- Cautions and Regulatory Compliance Statements for NEBS, on page 4
- Installation Guidelines, on page 5
- Procure Tools and Equipment, on page 6
- Prepare Your Location, on page 7
- Prepare Yourself, on page 7
- Prepare Rack for Chassis Installation, on page 8
- Clearance Requirements, on page 9

#### **Safety Guidelines**

Before you perform any procedure in this document, review the safety guidelines in this section to avoid injuring yourself or damaging the equipment. The following guidelines are for your safety and to protect the equipment. Because the guidelines do not include all hazards, be constantly alert.

- Keep the work area clear, smoke and dust-free during and after installation. Do not allow dirt or debris to enter into any laser-based components.
- Do not wear loose clothing, jewelry, or other items that could get caught in the router or other associated components.
- Cisco equipment operates safely when used in accordance with its specifications and product-usage instructions.
- If potentially hazardous conditions exist, do not work alone.
- Take care when connecting multiple units to the supply circuit so that wiring is not overloaded.
- This equipment must be grounded. Never defeat the ground conductor or operate the equipment in the absence of a suitably installed ground conductor. Contact the appropriate electrical inspection authority or an electrician if you are uncertain about whether suitable grounding is available.
- When installing or replacing the unit, the ground connection must always be made first and disconnected last.
- To prevent personal injury or damage to the chassis, never attempt to lift or tilt the chassis using the handles on modules (such as power supplies, fans, or cards); these types of handles are not designed to support the weight of the unit.
- Hazardous voltage or energy is present on the backplane when the system is operating. Use caution when servicing.

#### **Compliance and Safety Information**

The Cisco 8000 Series Routers are designed to meet the regulatory compliance and safety approval requirements. For detailed safety information, see Regulatory Compliance and Safety Information—Cisco 8000 Series Routers.



Statement 1089—Instructed and Skilled Person Definitions

An instructed person is someone who has been instructed and trained by a skilled person and takes the necessary precautions when working with equipment.

A skilled person or qualified personnel is someone who has training or experience in the equipment technology and understands potential hazards when working with equipment.

There are no serviceable parts inside. To avoid risk of electric shock, do not open.



g Statement 9001—Product Disposal

Ultimate disposal of this product should be handled according to all national laws and regulations.



#### **Laser Safety**

Image: Warning warning
Statement 1051—Laser Radiation

Invisible laser radiation may be emitted from disconnected fibers or connectors. Do not stare into beams or view directly with optical instruments.

Image: Warning war





g Statement 1255—Laser Compliance Statement

Pluggable optical modules comply with IEC 60825-1 Ed. 3 and 21 CFR 1040.10 and 1040.11 with or without exception for conformance with IEC 60825-1 Ed. 3 as described in Laser Notice No. 56, dated May 8, 2019.

#### **Energy Hazard**

The routers can be configured for a DC power source. Do not touch terminals while they are live. Observe the following warning to prevent injury.



Warning Statement 1086—Power Terminals

Hazardous voltage or energy may be present on power terminals. Always replace cover when terminals are not in service. Be sure uninsulated conductors are not accessible when cover is in place.

#### **Preventing Electrostatic Discharge Damage**

Many router components can be damaged by static electricity. Not exercising the proper electrostatic discharge (ESD) precautions can result in intermittent or complete component failures. To minimize the potential for ESD damage, always use an ESD-preventive antistatic wrist strap (or ankle strap) and ensure that it makes adequate skin contact.

**Note** Check the resistance value of the ESD-preventive strap periodically. The measurement should be 1–10 megohms.

Before you perform any of the procedures in this guide, attach an ESD-preventive strap to your wrist and connect the leash to the chassis.

#### **Cautions and Regulatory Compliance Statements for NEBS**

The NEBS-GR-1089-CORE regulatory compliance statements and requirements are discussed in this section.



**Warning** The intrabuilding port(s) of the equipment or subassembly, which is the management Ethernet port, must use shielded intrabuilding cabling/wiring that is grounded at both ends. Statement 7003

Warning	The intrabuilding port(s) of the equipment or subassembly, which is the management Ethernet port, must not be metallically connected to interfaces that connect to the OSP or its wiring. These interfaces are designed for use as intrabuilding interfaces only (Type 2 or Type 4 ports as described in GR-1089-CORE) and require isolation from the exposed OSP cabling. The addition of Primary Protectors is not sufficient protection in order to connect these interfaces metallically to OSP wiring. Statement 7005
Â	
Warning	This equipment shall be connected to AC mains provided with a surge protective device (SPD) at the service equipment complying with NFPA 70, the National Electrical Code (NEC). Statement 7012
Â	
Warning	This equipment is suitable for installations utilizing the Common Bonding Network (CBN). Statement 7013
Â	
Warning	This equipment is suitable for installation in Network Telecommunications Facilities. Statement 8015
Â	
Warning	This equipment is suitable for installation in locations where the NEC applies. Statement 8016

# **Installation Guidelines**

Before installing the chassis, ensure that the following guidelines are met:

- Site is properly prepared so that there is sufficient room for installation and maintenance.
- Operating environment is within the ranges that are listed in Environment and Physical specifications. For more details on environmental requirements, see Cisco 8000 Series Routers Data Sheet.
- Chassis is mounted at the bottom of the rack if it is the only unit in the rack.
- When mounting the chassis in a partially filled rack, load the rack from the bottom to the top with the heaviest component at the bottom of the rack.
- If the rack is provided with stabilizing devices, install the stabilizers before mounting or servicing the chassis in the rack.
- Airflow around the chassis and through the vents is unrestricted.
- Cabling is away from sources of electrical noise, such as radios, power lines, and fluorescent lighting fixtures. Make sure that the cabling is safely away from other devices that might damage the cables.
- Each port must match the wave-length specifications on each end of the cable, and the cable must not exceed the stipulated cable length.

Note

Cisco 8000 Series Routers function in operating temperatures of up to 40°C at sea level. For every 300 meters (1000 ft), the maximum temperature is reduced by 1°C. For more details on environmental requirements, see Cisco 8000 Series Routers Data Sheet.



For fixed-port routers that support port side exhaust fans and power supplies, the maximum temperature is reduced by 5°C (for example, 35°C at sea level or 30°C at 1500 meters).

#### **Procure Tools and Equipment**

Obtain these necessary tools and equipment for installing the chassis:

- Number 1 and number 2 Phillips screwdrivers with torque capability to rack-mount the chassis.
- 3/16-inch flat-blade screwdriver.
- Tape measure and level.
- ESD wrist strap or other grounding device.
- Antistatic mat or antistatic foam.
- Two-hole ground lug (1).
- Crimping tool for lug.
- Wire-stripping tool.

#### Accessory Kit

The following table contains the accessory kit PID and the items present in the accessory kit of the routers. The rack mount kit present in the accessory kit contains the screws and brackets required for installation.

Router	Accessory Kit	Items in Accessory Kit
Cisco 8102 Router	8200-2RU-KIT	Rack mount kit and ground lug kit
Cisco 8111-32EH-O Router	8K-1RU-KIT-S	For rack depths between 23 in. (584.2 mm) and 32.29 in. (820.16 mm)
	8K-1RU-KIT-L	For rack depths between 32.40 in. (822.96 mm) and 42 in. (1066.8 mm)
	8K-1RU-RAIL-KIT	Rack mount kit and ground lug kit

## **Prepare Your Location**

This section illustrates how the building that houses the chassis must be properly grounded to the earth ground.

V

**Note** Unless specified otherwise, the image is only for representational purposes. The rack's actual appearance and size may vary.



Note

This image is only for representational purposes. Your grounding requirement depends on your building.

Figure 1: Building with Rack Room Connected to Earth Ground



## **Prepare Yourself**

This section illustrates how to prepare yourself before removing the chassis from the sealed antistatic bag. The figures show how to cuff the ESD strap around the wrist and the ground cord that connects the cuff to the ground. ESD wrist straps are the primary means of controlling static charge on personnel.

Figure 2: Wearing the ESD Strap



# **Prepare Rack for Chassis Installation**

Install the Cisco 8100 Series Routers on a standard 19 inch, Electronic Industries Alliance (EIA) rack with mounting rails that conform to English universal hole spacing according to Section 1 of the ANSI/EIA-310-D-1992 standard.

	Note	The Cisco 8102-64H-O and Cisco 8111-32EH-O router rack mount kit contains the rack mounting brackets for 19-inch rack. To install the chassis in a 23-inch rack or an ETSI rack, you need adapter plates to accommodate the 19-inch rack mount brackets.					
	The spacing between the posts of the rack must be (EIA-310-D-1992 19-inch rack compatible) wide to accommodate the width of the chassis.						
	Before you move the chassis or mount the chassis into the rack, we recommend that you do the following:						
Step 1	Place the rack at the location where you plan to install the chassis.						
Step 2	(Optional) Secure the rack to the floor.						
	To bolt the rack to the floor, a floor bolt kit (also called an anchor embedment kit) is required. For information on bolting the rack to the floor, consult a company that specializes in floor mounting kits (such as Hilti; see Hilti.com for details). Make sure that floor mounting bolts are accessible, especially if annual retorquing of bolts is required.						
	Note E	nsure that the rack in which the chassis is being installed is grounded to earth ground.					

# **Clearance Requirements**

The chassis requires front-to-back airflow. Leave at least 6.0 in. (15.24 cm) front and rear clearance for air intake or exhaust. We recommend that you have at least 6.0 in. (15.24 cm) of space in front of the chassis to provide room to maneuver the cables to make the required connections. Leave an extra 6.0 in. (15.24 cm) rear clearance for removal and installation of power supplies and fan modules.





Figure 4: Clearances Required Around the Chassis for Cisco 8101-32H-0





#### Figure 5: Clearances Required Around the Chassis for Cisco 8111-32EH-0

1	Chassis	4	6.0 in. (15.24 cm) rear clearance for air intake/exhaus
2	6.0 in. (15.24 cm) front clearance for air intake/exhaust.	5	More 6.0 in. (15.24 cm) rear clearance for removal and installation of power supplies and fan modules
3	20.01 in. (50.82 cm) Chassis depth.		

I