



## GMPLS UNI Commands

---

- [announce srlgs](#), on page 2
- [attribute-set xro](#), on page 3
- [controller dwdm \(GMPLS\)](#), on page 4
- [destination ipv4 unicast](#), on page 6
- [dynamic](#), on page 7
- [encoding-type \(GMPLS-UNI\)](#), on page 8
- [encoding-type \(LMP\)](#), on page 9
- [exclude \(MPLS-TE\)](#), on page 10
- [gmpls optical-uni](#), on page 12
- [g-pid](#), on page 13
- [hello \(GMPLS-UNI\)](#), on page 14
- [ipcc routed \(LMP\)](#), on page 16
- [link-id ipv4 unicast \(LMP\)](#), on page 17
- [lmp](#), on page 18
- [logging events lsp-status state \(GMPLS\)](#), on page 19
- [mpls traffic-eng optical-uni reoptimize tunnel-id](#), on page 20
- [mtu \(GMPLS-UNI\)](#), on page 21
- [neighbor \(LMP\)](#), on page 22
- [neighbor interface-id unnumbered](#), on page 23
- [neighbor link-id ipv4 unicast](#), on page 24
- [path-option \(GMPLS\)](#), on page 25
- [record-route](#), on page 27
- [router-id ipv4 unicast](#), on page 28
- [show mpls traffic-eng link-management optical-uni](#), on page 29
- [signalled-name \(GMPLS\)](#), on page 32
- [signalling refresh out-of-band interval](#), on page 33
- [signalling refresh out-of-band missed](#), on page 34
- [switching-type \(GMPLS-UNI\)](#), on page 35
- [switching-type \(LMP\)](#), on page 36
- [tunnel-id \(GMPLS\)](#), on page 37
- [tunnel-properties](#), on page 38

## announce srlgs

To announce all SRLGs discovered through GMPLS signaling to RSI (Router Space Infrastructure), use the **announce srlgs** command in MPLS-TE GMPLS UNI controller mode. To disable announcing SRLGs to RSI, use the **no** form of this command.

### announce srlgs

<b>Syntax Description</b>	This command has no arguments or keywords.	
<b>Command Default</b>	None	
<b>Command Modes</b>	MPLS-TE GMPLS UNI controller configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.3.1	This command was introduced.

The following example shows how to configure SRLG announcement:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-te-gmpls-uni)# controller dwdm 0/1/0/1
RP/0/RP0/CPU0:router(config-te-gmpls-ctrl)# announce srlgs
```

# attribute-set xro

To specify an attribute set for LSP diversity for GMPLS UNI, use the **attribute-set xro** command in MPLS-TE configuration mode. To remove the settings, use the **no** form of this command.

**attribute-set xro** *attribute-set*

<b>Syntax Description</b>	<i>attribute-set</i>	Specifies the attribute set.
<b>Command Default</b>	No default behavior or values	
<b>Command Modes</b>	MPLS-TE configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.3.1	This command was introduced.
<b>Usage Guidelines</b>	An XRO attribute-set can be specified as part of the path-option, if required. An empty XRO attribute set results in the GMPLS tunnel being signaled with no exclusions, and therefore no XRO.	

## Examples

The following example shows how to configure attribute set attr01:

```
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# attribute-set xro attr01
RP/0/RP0/CPU0:router(config-te-attribute-set)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>mpls traffic-eng</b>	Enters MPLS-TE configuration mode.

## controller dwdm (GMPLS)

To specify a controller for GMPLS UNI and enter configuration commands for the controller, use the **controller dwdm** command in the appropriate mode. To return to the default behavior, use the **no** form of this command.

**controller dwdm** *controller*

<b>Syntax Description</b>	<i>controller</i> Specifies the controller in rack/slot/instance/port format.
---------------------------	---

<b>Command Default</b>	No default behavior or values
------------------------	-------------------------------

<b>Command Modes</b>	GMPLS-UNI configuration LMP GMPLS-UNI configuration RSVP configuration
----------------------	--

<b>Command History</b>	<b>Release</b> <b>Modification</b>
	Release 7.3.1 This command was introduced.

<b>Usage Guidelines</b>	The <i>controller</i> argument is the name of the GMPLS, LMP, or RSVP controller. This command forms a submode for the respective configuration.
-------------------------	--

### Examples

The following example shows how to enter the GMPLS UNI sub-mode for a specified controller interface, starting from global configuration mode:

```
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-te-gmpls)# controller dwdm 0/4/0/0
RP/0/RP0/CPU0:router(config-te-gmpls-ctrl)#
```

The following example shows how to specify an LMP controller 0/4/0/0:

```
RP/0/RP0/CPU0:router(config)# lmp
RP/0/RP0/CPU0:router(config-lmp)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni)# controller dwdm 0/4/0/0
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-ctrl)#
```

The following example shows how to specify RSVP controller 0/4/0/0:

```
RP/0/RP0/CPU0:router(config)# rsvp
RP/0/RP0/CPU0:router(config-rsvp)# controller dwdm 0/1/0/0
RP/0/RP0/CPU0:router(config-rsvp-ctrl)#
```

### Related Commands

Command	Description
mpls traffic-eng	Enters MPLS-TE configuration mode.

Command	Description
gmpls optical-uni	Enables GMPLS optical UNI and enters configuration mode for UNI.

# destination ipv4 unicast

To specify the destination of a GMPLS UNI tunnel, use the **destination ipv4 unicast** command in GMPLS-UNI controller tunnel-properties configuration sub-mode.

**destination ipv4 unicast** *address*

<b>Syntax Description</b>	<i>address</i> Specifies the tunnel destination (IPv4 address).
---------------------------	---

<b>Command Default</b>	No default behavior or values
------------------------	-------------------------------

<b>Command Modes</b>	GMPLS-UNI controller tunnel-properties configuration
----------------------	--

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.3.1	This command was introduced.

<b>Usage Guidelines</b>	The destination can be either the optical router ID of the destination node or the optical address of the desired ingress interface to the destination node. Specifying the router-id means that the ingress interface is selected by the network.
-------------------------	--

<b>Examples</b>	The following example shows how to specify a tunnel destination (10.10.3.4), starting from global configuration mode:
-----------------	---

```
RP/0/RP0/CPU0:router (config) # mpls traffic-eng
RP/0/RP0/CPU0:router (config-mpls-te) # gmpls optical-uni
RP/0/RP0/CPU0:router (config-te-gmpls) # controller dwdm 0/4/0/0
RP/0/RP0/CPU0:router (config-te-gmpls-cntl) # tunnel-properties
RP/0/RP0/CPU0:router (config-te-gmpls-tun) # destination ipv4 unicast 10.10.3.4
RP/0/RP0/CPU0:router (config-te-gmpls-tun) #
```

## Related Commands

Command	Description
<b>mpls traffic-eng</b>	Enters MPLS-TE configuration mode.
<b>gmpls optical-uni</b>	Enables GMPLS UNI functionality and enters configuration mode for UNI.
<b>controller dwdm (GMPLS)</b>	Enters GMPLS UNI sub-mode for a controller.

# dynamic

To enable the Dynamic LMP function on a UNI-C router, use the **dynamic** command in the LMP GMPLS-UNI neighbor configuration sub mode. To return to the default behavior, use the **no** form of this command.

## dynamic

**Syntax Description** This command has no arguments or keywords.

**Command Default** The Dynamic LMP function is disabled.

**Command Modes** LMP GMPLS-UNI neighbor configuration.

Command History	Release	Modification
	Release 7.3.1	This command was introduced.

**Usage Guidelines** The Dynamic LMP function validates LMP configuration consistency at the head-end and tail-end UNIs. Examples:

1. One end of a TE link is configured as an unnumbered interface, and the other end is configured with an IP address.
2. When configuring an unnumbered neighbor interface, entering the wrong neighbor interface ID.

## Examples

The following example shows how to enable the Dynamic LMP function on a UNI-C router:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# lmp
RP/0/RP0/CPU0:router(config-lmp)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni)# neighbor N1
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-nbr-n1)# dynamic
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-nbr-n1)# commit
Tue Jul 9 09:22:31.558 UTC
```

## Related Commands

Command	Description
mpls traffic-eng	Enters MPLS-TE configuration mode.
gmpls optical-uni	Enables GMPLS optical UNI and enters configuration mode for UNI.

## encoding-type (GMPLS-UNI)

To assign the LSP encoding type for the GMPLS-UNI tunnel, use the **encoding-type** command in the GMPLS-UNI controller tunnel-properties configuration sub-mode. To return to the default behavior, use the **no** form of this command.

**encoding-type** *type*

<b>Syntax Description</b>	<b>encoding-type</b> <i>type</i>	Specifies the GMPLS traffic encoding type.
<b>Command Default</b>	Lambda encoding type is enabled.	
<b>Command Modes</b>	GMPLS-UNI controller tunnel-properties configuration.	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.3.1	This command was introduced.
<b>Usage Guidelines</b>	The <b>encoding-type</b> command is available in the GMPLS UNI tunnel and LMP neighbor configuration modes. Enable the same encoding type under both the modes.	

### Examples

The following example shows how to assign the LSP encoding type for the GMPLS UNI tunnel:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-te-gmpls-uni)# controller dwdm 1/0/0/0
RP/0/RP0/CPU0:router(config-te-gmpls-ctrl)# tunnel-properties
RP/0/RP0/CPU0:router(config-te-gmpls-tun)# encoding-type lambda
RP/0/RP0/CPU0:router(config-te-gmpls-tun)# commit
Tue Jul 9 09:22:31.558 UTC
```

### Related Commands

Command	Description
mpls traffic-eng	Enters MPLS-TE configuration mode.
gmpls optical-uni	Enables GMPLS optical UNI and enters configuration mode for UNI.



## encoding-type (LMP)

To assign the LSP encoding type for LMP neighbor configuration, use the **encoding-type** command in the LMP controller neighbor configuration mode. To return to the default behavior, use the **no** form of this command.

**encoding-type** *type*

<b>Syntax Description</b>	<b>encoding-type</b> <i>type</i>	Specifies the LSP encoding type for LMP neighbor configuration.				
<b>Command Default</b>	Lambda encoding type is enabled.					
<b>Command Modes</b>	LMP controller neighbor configuration					
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.3.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.3.1	This command was introduced.	
Release	Modification					
Release 7.3.1	This command was introduced.					
<b>Usage Guidelines</b>	The <b>encoding-type</b> command is available in the GMPLS UNI tunnel and LMP neighbor configuration modes. Enable the same encoding type under both the modes.					

### Examples

The following example shows how to assign the LSP encoding type for LMP neighbor configuration:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# lmp
RP/0/RP0/CPU0:router(config-lmp)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni)# controller dwdm 1/0/0/0
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-ctrl)# link-id ipv4 unicast 10.0.0.2
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-ctrl)# neighbor N1
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-ctrl)# link-id ipv4 unicast 10.0.0.4
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-ctrl)# switching-type lsc
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-ctrl)# encoding-type lambda
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-ctrl)# commit
Tue Jul 9 09:22:31.558 UTC
```

### Related Commands

Command	Description
<b>mpls traffic-eng</b>	Enters MPLS-TE configuration mode.
<b>gmpls optical-uni</b>	Enables GMPLS optical UNI and enters configuration mode for UNI.

## exclude (MPLS-TE)

To specify exclusions for an attribute set for LSP diversity for MPLS-TE, use the **exclude** command in MPLS-TE attribute set configuration mode. To remove exclusions, use the **no** form of this command.

```
exclude { best-effort | strict } lsp source address destination address tunnel-id ID
extended-tunnel-id ID [lsp-id ID ]
```

Syntax Description		
<b>best-effort</b>		Specifies that the condition is met if possible.
<b>strict</b>		Specifies that the condition must be met.
<b>lsp</b>		Specifies that an LSP address will follow the <b>lsp</b> keyword.
<b>source</b> <i>address</i>		Specifies the source IPv4 address of the LSP from which a diverse path is required.
<b>destination</b> <i>address</i>		Specifies the destination address of the LSP from which a diverse path is required.
<b>tunnel-id</b> <i>ID</i>		Specifies the tunnel ID of the LSP from which a diverse path is required.
<b>extended-tunnel-id</b> <i>ID</i>		Specifies the extended tunnel ID (IPv4 address) of the LSP from which a diverse path is required.
<b>lsp-id</b> <i>lsp-id</i>		(Optional) Specifies the numeric LSP ID of the LSP from which a diverse path is required.

**Command Default** No default behavior or values

**Command Modes** MPLS-TE attribute-set configuration

Command History	Release	Modification
	Release 7.3.1	This command was introduced.

**Usage Guidelines** An XRO attribute-set can be specified as part of the path-option, if required. An empty XRO attribute set results in the GMPLS tunnel being signaled with no exclusions, and therefore no XRO.

Multiple LSP exclusions can be configured in the attribute-set. If this is done, multiple exclusions will be added to the path message. If the **lsp-id** is specified, only the LSP with the specified **lsp-id** will be excluded. If it is omitted, all LSPs matching the specified session (source, destination, tunnel-id, extended tunnel-id) will be excluded.

### Examples

The following example shows how to configure exclusions for the attribute set attrset01:

```
RP/0/RP0/CPU0:router (config) # mpls traffic-eng
```

```
RP/0/RP0/CPU0:router(config-mpls-te)# attribute-set xro attrset01  
RP/0/RP0/CPU0:router(config-te-attribute-set)# exclude best-effort lsp source 10.10.1.2  
destination 10.20.4.4 tunnel-id 17 extended-tunnel-id 10.10.1.2 lsp-id 17  
RP/0/RP0/CPU0:router(config-te-attribute-set)#
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<b>mpls traffic-eng</b>	Enters MPLS-TE configuration mode.
<b>attribute-set</b>	Specifies an attribute set for LSP diversity for MPLS-TE.

# gmpls optical-uni

To enable GMPLS UNI feature, use the **gmpls optical-uni** command in the appropriate mode. To return to the default behavior, use the **no** form of this command.

## gmpls optical-uni

**Syntax Description** This command has no arguments or keywords.

**Command Default** No default behavior or values

**Command Modes** MPLS-TE configuration  
LMP configuration

Command History	Release	Modification
	Release 7.3.1	This command was introduced.

**Usage Guidelines** The LMP submode enables GMPLS-UNI LMP functionality and acts as a container for other GMPLS-UNI LMP configuration commands.

**Examples** The following example shows how to enable GMPLS-UNI, starting from global configuration mode:

```
RP/0/RP0/CPU0:router (config) # mpls traffic-eng
RP/0/RP0/CPU0:router (config-mpls-te) # gmpls optical-uni
RP/0/RP0/CPU0:router (config-te-gmpls) #
```

The following example shows how to enable GMPLS UNI and enter LMP configuration mode:

```
RP/0/RP0/CPU0:router (config) # lmp
RP/0/RP0/CPU0:router (config-lmp) # gmpls optical-uni
RP/0/RP0/CPU0:router (config-lmp-gmpls) #
```

## Related Commands

Command	Description
<b>mpls traffic-eng</b>	Enters MPLS-TE configuration mode.
<b>lmp</b>	Enables GMPLS LMP functionality and enters configuration mode for LMP.

# g-pid

To assign a Generalized PID (G-PID) on the UNI-C router, use the **g-pid** command in the GMPLS-UNI controller tunnel-properties configuration sub-mode. To return to the default behavior, use the **no** form of this command.

**g-pid** *value*

<b>Syntax Description</b>	<b>g-pid</b> <i>value</i>	Specifies the G-PID value.
---------------------------	---------------------------	----------------------------

**Command Default** A G-PID value of 37, assigned for Lambda switching over optic fiber technology.

**Command Modes** GMPLS-UNI controller tunnel-properties configuration.

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.3.1	This command was introduced.

**Usage Guidelines** The G-PID value identifies the payload carried by the LSP.

**Examples** The following example shows how to configure the G-PID value:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-te-gmpls-uni)# controller dwdm 1/0/0/0
RP/0/RP0/CPU0:router(config-te-gmpls-cntl)# tunnel-properties
RP/0/RP0/CPU0:router(config-te-gmpls-tun)# g-pid 37
RP/0/RP0/CPU0:router(config-te-gmpls-tun)# commit
Tue Jul 9 09:22:31.558 UTC
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	mpls traffic-eng	Enters MPLS-TE configuration mode.
	gmpls optical-uni	Enables GMPLS optical UNI and enters configuration mode for UNI.

## hello (GMPLS-UNI)

To configure LMP hello message and hello expiry message intervals, use the **hello** command in the LMP GMPLS-UNI neighbor configuration sub mode. To return to the default behavior, use the **no** form of this command.

**hello** *interval expiry-interval*

Syntax Description		
	<i>interval</i>	Specifies the LMP hello message interval.
	<i>expiry-interval</i>	Specifies the LMP hello expiry message interval.
		<p><b>Note</b> Ensure that the LMP hello expiry message interval is at least thrice the interval of the LMP hello message.</p>

**Command Default** Interval of LMP hello messages between two LMP enabled routers is 2000 ms. An LMP hello expiry message is sent after a 6000 ms duration.

**Command Modes** LMP GMPLS-UNI neighbor configuration.

Command History	Release	Modification
	Release 7.3.1	This command was introduced.

**Usage Guidelines** An LMP hello message is sent every 2000 ms from an LMP enabled router to LMP peers. If an LMP enabled router does not receive an LMP hello message from a peer device for a 6000 ms duration, an LMP hello expiry message is sent to other LMP routers. If the LMP fast keep-alive mechanism is not used, both message intervals should be set to zero.

### Examples

The following example shows how set the hello message and hello expiry message intervals:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# lmp
RP/0/RP0/CPU0:router(config-lmp)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni)# neighbor N1
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-nbr-n1)# dynamic
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-nbr-n1)# hello 3000 10000
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-nbr-n1)# commit
Tue Jul 9 09:22:31.558 UTC
```

**Related Commands**

<b>Command</b>	<b>Description</b>
mpls traffic-eng	Enters MPLS-TE configuration mode.
gmpls optical-uni	Enables GMPLS optical UNI and enters configuration mode for UNI.

## ipcc routed (LMP)

To specify the Link Management Protocol neighbor IPCC configuration for GMPLS UNI, use the **ipcc routed** command in the neighbor sub-mode for LMP GMPLS-UNI controller configuration mode. To return to the default behavior, use the **no** form of this command.

### ipcc routed

<b>Syntax Description</b>	This command has no keywords or arguments.
<b>Command Default</b>	No default behavior or values
<b>Command Modes</b>	LMP GMPLS-UNI controller neighbor configuration

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.3.1	This command was introduced.

### Examples

The following example shows how to specify the IPCC configuration for the GMPLS-UNI controller 0/0/0/3, neighbor UN02:

```
RP/0/RP0/CPU0:router(config)# lmp
RP/0/RP0/CPU0:router(config-lmp)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni)# neighbor UN02
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-nbr-UN02)# ipcc routed
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-nbr-UN02)#
```

### Related Commands

<b>Command</b>	<b>Description</b>
<b>lmp</b>	Enables GMPLS LMP functionality and enters configuration mode for LMP.
<b>neighbor (LMP)</b>	Specifies an LMP neighbor for GMPLS and enters configuration mode for the neighbor.



## link-id ipv4 unicast (LMP)

To specify the optical interface address for an LMP link for a GMPLS UNI controller, use the **link-id ipv4 unicast** command in GMPLS-UNI controller configuration mode. To return to the default behavior, use the **no** form of this command.

**link-id ipv4 unicast** *address*

<b>Syntax Description</b>	<i>address</i> Specifies the optical unicast IPv4 address.
---------------------------	--

<b>Command Default</b>	No default behavior or values
------------------------	-------------------------------

<b>Command Modes</b>	LMP GMPLS-UNI controller configuration
----------------------	--

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.3.1	This command was introduced.

<b>Usage Guidelines</b>	This command specifies the local optical address for the link. It can be used as a tunnel destination at the tail UNI-C if the ingress link to the tail is to be specified.
-------------------------	---

<b>Examples</b>	The following example shows how to specify the link ID:
-----------------	---

```
RP/0/RP0/CPU0:router(config)# lmp
RP/0/RP0/CPU0:router(config-lmp)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni)# controller dwdm 0/4/0/0
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-ctrl)# link-id ipv4 unicast 10.10.4.2
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-ctrl)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>lmp</b>	Enables GMPLS LMP functionality and enters configuration mode for LMP.
	<b>controller (LMP)</b>	Specifies the LMP controller for GMPLS UNI and enters configuration mode for the controller.

# Imp

To enable functionality for GMPLS UNI LMP and enter LMP configuration commands, use the **imp** command in XR Config mode. To return to the default behavior, use the **no** form of this command.

## Imp

**Syntax Description** This command has no keywords or arguments.

**Command Default** No default behavior or values

**Command Modes** XR Config mode

Command History	Release	Modification
	Release 7.3.1	This command was introduced.

## Examples

The following example shows how to enable LMP functionality and enter the sub-mode for LMP configuration commands:

```
RP/0/RP0/CPU0:router(config)# imp
RP/0/RP0/CPU0:router(config-imp)#
```

## logging events lsp-status state (GMPLS)

To specify the tunnel state logging configuration for GMPLS UNI, use the **logging events lsp-status state** command in GMPLS-UNI controller tunnel-properties configuration sub-mode. To return to the default behavior, use the **no** form of this command.

### logging events lsp-status state

<b>Syntax Description</b>	This command has no keywords or arguments.				
<b>Command Default</b>	No default behavior or values				
<b>Command Modes</b>	GMPLS-UNI controller tunnel-properties configuration				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.3.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.3.1	This command was introduced.
Release	Modification				
Release 7.3.1	This command was introduced.				

### Examples

The following example shows how to specify the tunnel state logging configuration for controller 0/4/0/0:

```
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-te-gmpls)# controller dwdm 0/4/0/0
RP/0/RP0/CPU0:router(config-te-gmpls-ctrl)# tunnel-properties
RP/0/RP0/CPU0:router(config-te-gmpls-tun)# logging events lsp-status state
RP/0/RP0/CPU0:router(config-te-gmpls-tun)#
```

Related Commands	Command	Description
	<b>mpls traffic-eng</b>	Enters MPLS-TE configuration mode.
	<b>controller dwdm (GMPLS)</b>	Enters GMPLS UNI sub-mode for a controller.
	<b>tunnel-properties</b>	Enters tunnel configuration mode for a GMPLS UNI controller.

## mpls traffic-eng optical-uni reoptimize tunnel-id

To manually trigger the reoptimization of a GMPLS UNI tunnel, use the **mpls traffic-eng optical-uni reoptimize tunnel-id** command in XR Config mode.

**mpls traffic-eng optical-uni reoptimize tunnel-id** *number*

<b>Syntax Description</b>	<i>number</i> MPLS-TE tunnel identification expressed as a number. The range is from 0 to 65535.				
<b>Command Default</b>	No default behavior or values				
<b>Command Modes</b>	Global configuration				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.3.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.3.1	This command was introduced.
Release	Modification				
Release 7.3.1	This command was introduced.				

### Examples

The following example shows how to manually reoptimize a GMPLS UNI tunnel with tunnel ID 100:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls traffic-eng optical-uni reoptimize tunnel-id 100
```

## mtu (GMPLS-UNI)

To configure the maximum traffic limit (MTU) value on a GMPLS UNI controller interface, use the **mtu** command in GMPLS-UNI configuration sub-mode. To return to the default behavior, use the **no** form of this command.

**mtu** *value*

<b>Syntax Description</b>	<b>mtu</b> <i>value</i>	Specifies the MTU value for the controller interface.				
<b>Command Default</b>	An MTU of 9212 bytes is configured on a GMPLS UNI controller interface.					
<b>Command Modes</b>	GMPLS-UNI configuration					
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.3.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.3.1	This command was introduced.	
Release	Modification					
Release 7.3.1	This command was introduced.					

### Examples

The following example shows how to configure the MTU value on a GMPLS UNI controller interface:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-te-gmpls-uni)# controller dwdm 1/0/0/0
RP/0/RP0/CPU0:router(config-te-gmpls-ctrl)# mtu 9000
RP/0/RP0/CPU0:router(config-te-gmpls-ctrl)# commit
Tue Jul 9 09:22:31.558 UTC
```

### Related Commands

Command	Description
<b>mpls traffic-eng</b>	Enters MPLS-TE configuration mode.
<b>gmpls optical-uni</b>	Enables GMPLS optical UNI and enters configuration mode for UNI.

## neighbor (LMP)

To specify an LMP neighbor for GMPLS and enter commands to configure the neighbor, use the **neighbor** command in the appropriate configuration mode. To return to the default behavior, use the **no** form of this command.

**neighbor** *name*

<b>Syntax Description</b>	<i>name</i> Specifies the name of the LMP neighbor.
---------------------------	---

<b>Command Default</b>	No default behavior or values
------------------------	-------------------------------

<b>Command Modes</b>	LMP GMPLS-UNI configuration LMP Controller configuration
----------------------	---

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.3.1	This command was introduced.

<b>Usage Guidelines</b>	Under LMP controller configuration submode, this command specifies the neighbor reached via the controller. And, under the LMP GMPLS UNI submode, it creates a submode in which other properties of the neighbor can be specified. The name argument is the name of the configured neighbor.
-------------------------	--

<b>Examples</b>	The following example shows how to specify the neighbor UN01 for the GMPLS-UNI controller 0/0/0/3:
-----------------	--

```
RP/0/RP0/CPU0:router(config)# lmp
RP/0/RP0/CPU0:router(config-lmp)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni)# neighbor UN01
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-nbr-UN01)# exit
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni)# controller dwdm 0/1/0/0
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-ctrl)# neighbor UN01
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-ctrl)#
```

<b>Related Commands</b>	<table border="1"> <thead> <tr> <th><b>Command</b></th> <th><b>Description</b></th> </tr> </thead> <tbody> <tr> <td><b>lmp</b></td> <td>Enables GMPLS LMP functionality and enters configuration mode for LMP.</td> </tr> <tr> <td><b>gmpls optical-uni</b></td> <td>Enables GMPLS UNI functionality and enters configuration mode for UNI.</td> </tr> </tbody> </table>	<b>Command</b>	<b>Description</b>	<b>lmp</b>	Enables GMPLS LMP functionality and enters configuration mode for LMP.	<b>gmpls optical-uni</b>	Enables GMPLS UNI functionality and enters configuration mode for UNI.
<b>Command</b>	<b>Description</b>						
<b>lmp</b>	Enables GMPLS LMP functionality and enters configuration mode for LMP.						
<b>gmpls optical-uni</b>	Enables GMPLS UNI functionality and enters configuration mode for UNI.						

## neighbor interface-id unnumbered

To specify the neighbor's optical interface ID of an LMP link for a GMPLS UNI controller, use the **neighbor interface-id unnumbered** command in GMPLS-UNI controller configuration mode. To return to the default behavior, use the **no** form of this command.

**neighbor interface-id unnumbered** *interface-id*

<b>Syntax Description</b>	<i>interface-id</i> Specifies the optical interface ID of the neighbor.
---------------------------	---

<b>Command Default</b>	No default behavior or values
------------------------	-------------------------------

<b>Command Modes</b>	LMP GMPLS-UNI controller configuration
----------------------	--

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.3.1	This command was introduced.

<b>Usage Guidelines</b>	For the interface ID on the command line, you can use the SNMP ifindex of the interface on the neighbor node.
-------------------------	---

<b>Examples</b>	The following example shows how to specify the optical interface ID (17) of an LMP neighbor:
-----------------	--

```
RP/0/RP0/CPU0:router(config)# lmp
RP/0/RP0/CPU0:router(config-lmp)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni)# controller dwdm 0/4/0/0
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-ctrl)# neighbor interface-id unnumbered 17
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-ctrl)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>lmp</b>	Enables GMPLS LMP functionality and enters configuration mode for LMP.
	<b>controller dwdm (GMPLS)</b>	Enters GMPLS UNI sub-mode for a controller.

## neighbor link-id ipv4 unicast

To specify the neighbor's optical address of an LMP link for a GMPLS UNI controller, use the **neighbor link-id ipv4 unicast** command in GMPLS-UNI controller configuration mode. To return to the default behavior, use the **no** form of this command.

**neighbor link-id ipv4 unicast** *address*

<b>Syntax Description</b>	<i>address</i> Specifies the IPv4 address of the neighbor.
---------------------------	--

<b>Command Default</b>	No default behavior or values
------------------------	-------------------------------

<b>Command Modes</b>	LMP GMPLS-UNI controller configuration
----------------------	--

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.3.1	This command was introduced.

### Examples

The following example shows how to specify the optical IPv4 address (10.10.4.5) of an LMP neighbor for controller 0/4/0/0:

```
RP/0/RP0/CPU0:router(config)# lmp
RP/0/RP0/CPU0:router(config-lmp)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni)# controller dwdm 0/4/0/0
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-ctrl)# neighbor link-id ipv4 unicast 10.10.4.5
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-ctrl)#
```

### Related Commands

Command	Description
<b>lmp</b>	Enables GMPLS LMP functionality and enters configuration mode for LMP.
<b>controller dwdm (GMPLS)</b>	Enters GMPLS UNI sub-mode for a controller.



## path-option (GMPLS)

To specify a path option for a GMPLS UNI tunnel, use the **path-option** command in GMPLS-UNI controller tunnel-properties configuration sub-mode. To remove a path option, use the **no** form of this command.

```
path-option 10 { no-ero | explicit { name path-name | index index } } [ xro-attribute-set name ] [
signaled-label dwdm wavelength channel ] [ lockdown ] [ verbatim ]
```

Syntax Description	10	Specifies the path option index. 10 is the only supported index in this release.
	<b>explicit</b>	Specifies that LSP paths are IP explicit paths.
	<b>name</b> <i>path-name</i>	Specifies the path name of the IP explicit path.
	<b>no-ero</b>	Specifies that no ERO object is included in signalling.
	<b>xro-attribute-set</b>	(Optional) Specifies the xro attribute set for the path option.
	<i>name</i>	Specifies the name of the xro-attribute-set.
	<b>lockdown</b>	(Optional) Indicates that the tunnel does not reoptimize without user intervention. This is the only supported behavior in this release.
	<b>signaled-label</b>	(Optional) Sets a specific label for the path option.
	<b>dwdm</b>	(Optional) Specifies that it is a DWDM label.
	<b>wavelength</b>	(Optional) Specifies the DWDM wavelength to use.
	<i>channel</i>	Specifies the channel number to use. The range is form 1 to 89.
	<b>verbatim</b>	(Optional) Bypasses the topology check for explicit paths.

**Command Default** No default behavior or values

**Command Modes** GMPLS UNI controller tunnel-properties configuration

Command History	Release	Modification
	Release 7.3.1	This command was introduced.

**Usage Guidelines** The path option index is no longer fixed at 10. It is now set by the user and distinguishes path options in the same manner as for packet tunnels. The path option index may be any value between 1 and 1000 (the same range as for packet tunnels).

The **verbatim** keyword is mandatory when an explicit path is referenced by a GMPLS UNI path option, but must not be present if the **no-ero** option is in use.

### Examples

The following example shows how to specify the tunnel path option for controller 0/4/0/0, attribute set A01, starting from global configuration mode:

```

RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-te-gmpls)# controller dwdm 0/4/0/0
RP/0/RP0/CPU0:router(config-te-gmpls-ctrl)#tunnel-properties
RP/0/RP0/CPU0:router(config-te-gmpls-tun)#path-option 10 no-ero xro-attribute-set A01
lockdown
RP/0/RP0/CPU0:router(config-te-gmpls-tun)#

```

### Related Commands

Command	Description
<b>mpls traffic-eng</b>	Enters MPLS-TE configuration mode.
<b>gmpls optical-uni</b>	Enables GMPLS UNI functionality and enters configuration mode for UNI.
<b>controller dwdm (GMPLS)</b>	Enters GMPLS UNI sub-mode for a controller.
<b>tunnel-properties</b>	Enters tunnel configuration mode for a GMPLS UNI controller.
<b>attribute-set xro</b>	Enters tunnel configuration mode for a GMPLS UNI controller.

## record-route

To enable record-route functionality for the GMPLS UNI tunnel, use the **record-route** command in GMPLS-UNI controller tunnel-properties configuration sub-mode. To return to the default behavior, use the **no** form of this command

### record-route

#### Syntax Description

This command has no arguments or keywords.

#### Command Default

No default behavior or values

#### Command Modes

GMPLS-UNI controller tunnel-properties configuration

#### Command History

Release	Modification
Release 7.3.1	This command was introduced.

#### Examples

The following example shows how enable record-route functionality, starting from global configuration mode:

```
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-te-gmpls)# controller dwdm 0/4/0/0
RP/0/RP0/CPU0:router(config-te-gmpls-ctrl)# tunnel-properties
RP/0/RP0/CPU0:router(config-te-gmpls-tun)# record-route
RP/0/RP0/CPU0:router(config-te-gmpls-tun)#
```

#### Related Commands

Command	Description
<b>controller dwdm (GMPLS)</b>	Enters GMPLS UNI sub-mode for a controller.
<b>tunnel-properties</b>	Enters tunnel configuration mode for a GMPLS UNI controller.

## router-id ipv4 unicast

To configure the LMP unicast or neighbor router ID for GMPLS, use the **router-id ipv4 unicast** command in the appropriate configuration mode. To return to the default behavior, use the **no** form of this command.

**router-id ipv4 unicast** *address*

<b>Syntax Description</b>	<i>address</i> Specifies the GMPLS-UNI optical router-id (IPv4 address).
---------------------------	--

<b>Command Default</b>	No default behavior or values
------------------------	-------------------------------

<b>Command Modes</b>	LMP GMPLS UNI configuration LMP GMPLS UNI neighbor configuration
----------------------	---

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.3.1	This command was introduced.

### Examples

The following example shows how to specify a router ID (address 10.10.4.4) for GMPLS-UNI:

```
RP/0/RP0/CPU0:router(config)# lmp
RP/0/RP0/CPU0:router(config-lmp)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni)# router-id ipv4 unicast 10.10.4.4
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni)
```

The following example shows how to specify the neighbor router ID 10.10.5.5 for GMPLS UNI:

```
RP/0/RP0/CPU0:router(config)# lmp
RP/0/RP0/CPU0:router(config-lmp)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni)# neighbor UN01
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-nbr-UN01)# router-id ipv4 unicast 10.10.5.5
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-nbr-UN01)#
```

### Related Commands

Command	Description
<b>lmp</b>	Enables GMPLS LMP functionality and enters configuration mode for LMP.
<b>destination ipv4 unicast</b>	Specifies the destination of a GMPLS optical UNI tunnel.
<b>neighbor (LMP)</b>	Specifies an LMP neighbor for GMPLS and enters configuration mode for the neighbor.

# show mpls traffic-eng link-management optical-uni

To display a summary of the TE link management GMPLS-UNI states, use the **show mpls traffic-eng link-management optical-uni** command in XR EXEC mode.

**show mpls traffic-eng link-management optical-uni** [ **controller** *controller* ] [ **tabular** ]

<b>Syntax Description</b>	<b>controller</b> <i>controller</i>	(Optional) Displays information for the specified controller.
	<b>tabular</b>	(Optional) Displays information in tabular format.

**Command Default** None

**Command Modes** XR EXEC mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.3.1	This command was introduced.

**Usage Guidelines** To use this command, first enable the MPLS-TE application.

## Example

The following command displays the TE GMPLS-UNI states for the specified controller .

```
RP/0/RP0/CPU0:router# show mpls traffic-eng link-management optical-uni controller dwdm0/1/0/0
Thu Oct  4 14:52:46.147 ottawa
Optical interface: dwdm0/1/0/0
Overview:
  IM state: Up
  OLM/LMP state: Up
  Optical tunnel state: up
Connection:
  Tunnel role: Head
  Tunnel-id: 300
  Local optical router-id: 10.58.64.239
  Remote optical router-id: 10.58.40.40
  Upstream label:
    Optical label:
      Grid                : DWDM
      Channel spacing     : 50 GHz
      Identifier          : 0
      Channel Number      : 42
  Downstream label:
    Optical label:
      Grid                : DWDM
      Channel spacing     : 50 GHz
      Identifier          : 0
```

## show mpls traffic-eng link-management optical-uni

```

Channel Number      : 42
Admission Control:
  Upstream: Admitted (LSP ID: 77)
  Downstream: Admitted (LSP ID: 77)
OLM/LMP adjacency information:
  Adjacency status: Up
  Local:
    node ID: 10.58.64.239
    link interface ID: 39
    link ID: 10.20.2.1
  Neighbor:
    node ID: 10.58.40.40 (crs1-239-nr)
    link interface ID: 2
    link ID: 10.20.2.2
    IPCC: Routed to 10.58.40.40
Optical capabilities:
  Controller type: DWDM
  Channel spacing: 50 GHz
  Default channel: 58
  82 supported channels:
    -23, -22, -21, -20, -19, -18, -17, -16
    -15, -14, -13, -12, -11, -10, -9, -8
    -7, -6, -5, -4, -3, -2, -1, 0
    1, 2, 3, 4, 5, 6, 7, 8
    9, 10, 11, 12, 13, 14, 15, 16
    17, 18, 19, 20, 21, 22, 23, 24
    25, 26, 27, 28, 29, 30, 31, 32
    33, 34, 35, 36, 37, 38, 39, 40
    41, 42, 43, 44, 45, 46, 47, 48
    49, 50, 51, 52, 53, 54, 55, 56
    57, 58
RP/0/RP0/CPU0:crs239#

```

**Example**

The following command provides an overview of the TE GMPLS-UNI states in tabular format.

```

RP/0/RP0/CPU0:router# show mpls traffic-eng link-management optical-uni tabular
System Information:
Optical Links Count: 2 (Maximum Links Supported 100)

```

Interface	State		LMP adjacency	GMPLS tunnel		
	Admin	Oper		role	tun-id	state
PO0/1/0/0	up	up	up	Head	1	up
PO0/1/0/1	up	up	up	Head	2	up

The following command displays the SRLGs configured locally on the DWDM controller and the collected SRLG and latency data for the tunnel.

```

RP/0/RP0/CPU0:router# show mpls traffic-eng link-management optical-uni
System Information:
Optical Links Count: 4 (Maximum Links Supported 100)

Optical interface: dwdm0/1/0/0
Overview:
  IM state: Up
  OLM/LMP state: Up
  Optical tunnel state: up

```

```

Connection:
  Tunnel role: Head
  Tunnel-id: 1, LSP-id: 2, Extended tunnel-id: 88.0.0.8
  Tunnel source: 88.0.0.8, destination: 10.0.1.2
  Optical router-ids: Local: 88.0.0.8, Remote: 99.0.0.9
  Label source: UNI-N
  Upstream label:
Optical label:
  Grid : DWDM
  Channel spacing : 50 GHz
  Identifier : 0
  Channel Number : 59
  Downstream label:
  Optical label:
  Grid : DWDM
  Channel spacing : 50 GHz
  Identifier : 0
  Channel Number : 59
  SRLG discovery: Enabled
  SRLG announcement: announced to TenGigE 0/1/0/0
Admission Control:
  Upstream: Admitted (LSP ID: 2)
  Downstream: Admitted (LSP ID: 2)
OLM/LMP adjacency information:
  Adjacency status: Up
  Local:
    node ID: 88.0.0.8
    link interface ID: 15
    link ID: 10.0.0.1
  Neighbor:
    node ID: 99.0.0.9 (gmpls2_uni)
    link interface ID: 3
    link ID: 10.0.0.2
    IPCC: Routed to 99.0.0.9
Optical capabilities:
  Controller type: DWDM
  Channel spacing: 50 GHz
  Default channel: 59
  44 supported channels:
    -27, -25, -23, -21, -19, -17, -15, -13
    -11, -9, -7, -5, -3, -1, 1, 3
    5, 7, 9, 11, 13, 15, 17, 19
    21, 23, 25, 27, 29, 31, 33, 35
    37, 39, 41, 43, 45, 47, 49, 51
    53, 55, 57, 59
  Controller SRLGs:
    1, 2, 3, 4

```

## signalled-name (GMPLS)

To specify the signalled name to apply to the GMPLS UNI tunnel, use the **signalled-name** command in GMPLS-UNI controller tunnel-properties configuration sub-mode. To return to the default behavior, use the **no** form of this command.

**signalled-name** *name*

<b>Syntax Description</b>	<i>name</i> Specifies the signalled name to apply to the tunnel.
---------------------------	--

<b>Command Default</b>	No default behavior or values
------------------------	-------------------------------

<b>Command Modes</b>	GMPLS-UNI controller tunnel-properties configuration
----------------------	--

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.3.1	This command was introduced.

### Examples

The following example shows how to specify a signalled name for the tunnel (tunname), starting from global configuration mode:

```
RP/0/RP0/CPU0:router (config) # mpls traffic-eng
RP/0/RP0/CPU0:router (config-mpls-te) # gmpls optical-uni
RP/0/RP0/CPU0:router (config-te-gmpls) # controller dwdm 0/4/0/0
RP/0/RP0/CPU0:router (config-te-gmpls-ctrl) # tunnel-properties
RP/0/RP0/CPU0:router (config-te-gmpls-tun) # signalled-name tunname
RP/0/RP0/CPU0:router (config-te-gmpls-tun) #
```

### Related Commands

Command	Description
<b>controller dwdm (GMPLS)</b>	Enters GMPLS UNI sub-mode for a controller.
<b>tunnel-properties</b>	Enters tunnel configuration mode for a GMPLS UNI controller.



# signalling refresh out-of-band interval

To specify the out-of-band refresh interval for RSVP, use the **signalling refresh out-of-band interval** command in RSVP controller configuration mode. To return to the default behavior, use the **no** form of this command.

**signalling refresh out-of-band interval** *interval*

**Syntax Description** *interval* Specifies the refresh interval (180-86400 seconds).

**Command Default** 45 seconds

**Command Modes** RSVP controller configuration

Command History	Release	Modification
	Release 7.3.1	This command was introduced.

**Usage Guidelines** This command applies only to the RSVP sessions associated with GMPLS-UNI tunnels.

**Examples** The following example shows how to specify 200 seconds for the out-of-band interface refresh interval:

```
RP/0/RP0/CPU0:router(config)# rsvp
RP/0/RP0/CPU0:router(config-rsvp)# controller dwdm 0/4/0/0
RP/0/RP0/CPU0:router(config-rsvp-ctrl)# signalling refresh out-of-band interval 200
RP/0/RP0/CPU0:router(config-rsvp-ctrl)#
```

Related Commands	Command	Description
	<b>rsvp</b>	Enables RSVP functionality and enters configuration mode for RSVP.
	<b>controller (LMP)</b>	Specifies the RSVP controller for GMPLS UNI and enters configuration mode for the controller.
	<b>signalling refresh out-of-band missed</b>	Specifies the number of missed refresh messages allowed before states are deleted for optical tunnels.

# signalling refresh out-of-band missed

To specify the number of missed refresh messages allowed before states are deleted for optical tunnels, use the **signalling refresh out-of-band missed** command in RSVP controller configuration mode. To return to the default behavior, use the **no** form of this command.

**signalling refresh out-of-band missed** *count*

**Syntax Description** *count* Number of missed refresh messages allowed before states are deleted for optical tunnels (1-48).

**Command Default** The default value is 12.

**Command Modes** RSVP controller configuration

**Command History**

Release	Modification
Release 7.3.1	This command was introduced.

**Usage Guidelines** This command applies only to the RSVP sessions associated with GMPLS-UNI tunnels.

**Examples** The following example shows how to specify a maximum of 10 messages for the number of allowed missed refresh messages:

```
RP/0/RP0/CPU0:router(config)# rsvp
RP/0/RP0/CPU0:router(config-rsvp)# controller dwdm 0/4/0/0
RP/0/RP0/CPU0:router(config-rsvp-ctrl)# signalling refresh out-of-band missed 10
RP/0/RP0/CPU0:router(config-rsvp-ctrl)#
```

Command	Description
<b>rsvp</b>	Enables RSVP functionality and enters configuration mode for RSVP.
<b>controller (LMP)</b>	Specifies the RSVP controller for GMPLS UNI and enters configuration mode for the controller.
<b>signalling refresh out-of-band interval</b>	Specifies the out-of-band refresh interval for RSVP.

## switching-type (GMPLS-UNI)

To assign the GMPLS traffic switching type on the UNI-C router, use the **switching-type** command in the MPLS-TE GMPLS UNI controller configuration mode. To return to the default behavior, use the **no** form of this command.

**switching-type** *type*

<b>Syntax Description</b>	<b>switching-type</b> <i>type</i>	Specifies the GMPLS traffic switching type.				
<b>Command Default</b>	Lambda-Switch Capable (LSC) switching type.					
<b>Command Modes</b>	MPLS-TE GMPLS UNI controller configuration.					
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.3.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.3.1	This command was introduced.	
Release	Modification					
Release 7.3.1	This command was introduced.					
<b>Usage Guidelines</b>	The <b>switching-type</b> command is available in the GMPLS UNI tunnel and LMP neighbor configuration modes. Enable the same switching type under both the modes.					

### Examples

The following example shows how to assign the GMPLS traffic switching type for the GMPLS UNI tunnel:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-te-gmpls-uni)# controller dwdm 1/0/0/0
RP/0/RP0/CPU0:router(config-te-gmpls-ctrl)# tunnel-properties
RP/0/RP0/CPU0:router(config-te-gmpls-tun)# encoding-type lambda
RP/0/RP0/CPU0:router(config-te-gmpls-tun)# exit
RP/0/RP0/CPU0:router(config-te-gmpls-ctrl)# switching-type lsc
RP/0/RP0/CPU0:router(config-te-gmpls-ctrl)# commit
Tue Jul 9 09:22:31.558 UTC
```

### Related Commands

Command	Description
<b>gmpls optical-uni</b>	Enables GMPLS optical UNI and enters configuration mode for UNI.

## switching-type (LMP)

To assign the GMPLS traffic switching type for LMP neighbor configuration, use the **switching-type** command in the LMP controller neighbor configuration mode. To return to the default behavior, use the **no** form of this command.

**switching-type** *type*

<b>Syntax Description</b>	<b>switching-type</b> <i>type</i>	Specifies the LSP switching type for the LMP neighbor configuration.				
<b>Command Default</b>	Lambda-Switch Capable (LSC) type.					
<b>Command Modes</b>	LMP controller neighbor configuration					
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.3.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.3.1	This command was introduced.	
Release	Modification					
Release 7.3.1	This command was introduced.					
<b>Usage Guidelines</b>	The <b>switching-type</b> command is available in the GMPLS UNI tunnel and LMP neighbor configuration modes. Enable the same switching type under both the modes.					
<b>Examples</b>	<p>The following example shows how to assign the GMPLS traffic switching type for LMP neighbor configuration:</p> <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# lmp RP/0/RP0/CPU0:router(config-lmp)# gmpls optical-uni RP/0/RP0/CPU0:router(config-lmp-gmpls-uni)# controller dwdm 1/0/0/0 RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-ctrl)# link-id ipv4 unicast 10.0.0.2 RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-ctrl)# neighbor N1 RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-ctrl)# link-id ipv4 unicast 10.0.0.4 RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-ctrl)# switching-type lsc RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-ctrl)# encoding-type lambda RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-ctrl)# commit Tue Jul 9 09:22:31.558 UTC</pre>					
<b>Related Commands</b>	<table border="1"> <thead> <tr> <th>Command</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>gmpls optical-uni</td> <td>Enables GMPLS optical UNI and enters configuration mode for UNI.</td> </tr> </tbody> </table>	Command	Description	gmpls optical-uni	Enables GMPLS optical UNI and enters configuration mode for UNI.	
Command	Description					
gmpls optical-uni	Enables GMPLS optical UNI and enters configuration mode for UNI.					

## tunnel-id (GMPLS)

To specify the ID of the GMPLS UNI tunnel, use the **tunnel-id** command in GMPLS-UNI controller tunnel-properties configuration sub-mode. To return to the default behavior, use the **no** form of this command.

**tunnel-id** *number*

### Syntax Description

*number* Specifies the tunnel ID.

### Command Default

No default behavior or values

### Command Modes

GMPLS-UNI controller tunnel-properties configuration

### Command History

Release	Modification
Release 7.3.1	This command was introduced.

### Examples

The following example shows how to specify a tunnel ID (5), starting from global configuration mode:

```
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-te-gmpls)# controller dwdm 0/4/0/0
RP/0/RP0/CPU0:router(config-te-gmpls-cntl)# tunnel-properties
RP/0/RP0/CPU0:router(config-te-gmpls-tun)# tunnel-id 5
RP/0/RP0/CPU0:router(config-te-gmpls-tun)#
```

### Related Commands

Command	Description
<b>controller dwdm (GMPLS)</b>	Enters GMPLS UNI sub-mode for a controller.
<b>tunnel-properties</b>	Enters tunnel configuration mode for a GMPLS UNI controller.

# tunnel-properties

To configure tunnel-specific information for a GMPLS UNI controller, use the **tunnel-properties** command in GMPLS-UNI configuration sub-mode. To return to the default behavior, use the **no** form of this command.

## tunnel-properties

**Syntax Description** This command has no keywords or arguments.

**Command Default** No default behavior or values

**Command Modes** GMPLS-UNI configuration

Command History	Release	Modification
	Release 7.3.1	This command was introduced.

**Usage Guidelines** This command designates the controller as a tunnel-head, rather than a tunnel tail. After the tunnel properties are configured, the incoming path messages are rejected and any existing tail-end tunnel is torn down.

## Examples

The following example shows how to enter the sub-mode to configure tunnel-specific information for a GMPLS UNI controller:

```
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-te-gmpls)# controller dwdm 0/4/0/0
RP/0/RP0/CPU0:router(config-te-gmpls-ctl)# tunnel-properties
RP/0/RP0/CPU0:router(config-te-gmpls-tun)#
```

## Related Commands

Command	Description
<b>controller dwdm (GMPLS)</b>	Enters GMPLS UNI sub-mode for a controller.