



GMPLS UNI Commands

- [announce srlgs](#), on page 2
- [attribute-set xro](#), on page 3
- [controller dwdm \(GMPLS\)](#), on page 4
- [destination ipv4 unicast](#), on page 6
- [dynamic](#), on page 7
- [encoding-type \(GMPLS-UNI\)](#) , on page 8
- [encoding-type \(LMP\)](#), on page 9
- [exclude \(MPLS-TE\)](#), on page 10
- [mpls optical-uni](#), on page 12
- [g-pid](#), on page 13
- [hello \(GMPLS-UNI\)](#), on page 14
- [ipcc routed \(LMP\)](#) , on page 16
- [link-id ipv4 unicast \(LMP\)](#) , on page 17
- [lmp](#) , on page 18
- [logging events lsp-status state \(GMPLS\)](#) , on page 19
- [mpls traffic-eng optical-uni reoptimize tunnel-id](#), on page 20
- [mtu \(GMPLS-UNI\)](#), on page 21
- [neighbor \(LMP\)](#) , on page 22
- [neighbor interface-id unnumbered](#) , on page 23
- [neighbor link-id ipv4 unicast](#) , on page 24
- [path-option \(GMPLS\)](#), on page 25
- [record-route](#) , on page 27
- [router-id ipv4 unicast](#) , on page 28
- [show mpls traffic-eng link-management optical-uni](#) , on page 29
- [signalled-name \(GMPLS\)](#), on page 32
- [signalling refresh out-of-band interval](#) , on page 33
- [signalling refresh out-of-band missed](#) , on page 34
- [switching-type \(GMPLS-UNI\)](#) , on page 35
- [switching-type \(LMP\)](#), on page 36
- [tunnel-id \(GMPLS\)](#), on page 37
- [tunnel-properties](#), on page 38

announce srlgs

announce srlgs

To announce all SRLGs discovered through GMPLS signaling to RSI (Router Space Infrastructure), use the **announce srlgs** command in MPLS-TE GMPLS UNI controller mode. To disable announcing SRLGs to RSI, use the **no** form of this command.

announce srlgs

Syntax Description	This command has no arguments or keywords.				
Command Default	None				
Command Modes	MPLS-TE GMPLS UNI controller configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.3.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.3.1	This command was introduced.
Release	Modification				
Release 7.3.1	This command was introduced.				

The following example shows how to configure SRLG announcement:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-te-gmpls-uni)# controller dwdm 0/1/0/1
RP/0/RP0/CPU0:router(config-te-gmpls-cntl)# announce srlgs
```

attribute-set xro

To specify an attribute set for LSP diversity for GMPLS UNI, use the **attribute-set xro** command in MPLS-TE configuration mode. To remove the settings, use the **no** form of this command.

attribute-set xro *attribute-set*

Syntax Description	<i>attribute-set</i>		Specifies the attribute set.
Command Default	No default behavior or values		
Command Modes	MPLS-TE configuration		
Command History	Release	Modification	
	Release 7.3.1 This command was introduced.		
Usage Guidelines	An XRO attribute-set can be specified as part of the path-option, if required. An empty XRO attribute set results in the GMPLS tunnel being signaled with no exclusions, and therefore no XRO.		
Examples	The following example shows how to configure attribute set attr01:		
	<pre>RP/0/RP0/CPU0:router(config)# mpls traffic-eng RP/0/RP0/CPU0:router(config-mpls-te)# attribute-set xro attr01 RP/0/RP0/CPU0:router(config-te-attribute-set)# </pre>		
Related Commands	Command	Description	
	mpls traffic-eng	Enters MPLS-TE configuration mode.	

controller dwdm (GMPLS)

To specify a controller for GMPLS UNI and enter configuration commands for the controller, use the **controller dwdm** command in the appropriate mode. To return to the default behavior, use the **no** form of this command.

controller dwdm controller

Syntax Description	<i>controller</i> Specifies the controller in rack/slot-instance/port format.
---------------------------	---

Command Default	No default behavior or values
------------------------	-------------------------------

Command Modes	GMPLS-UNI configuration LMP GMPLS-UNI configuration RSVP configuration
----------------------	--

Command History	Release	Modification
	Release 7.3.1	This command was introduced.

Usage Guidelines	The <i>controller</i> argument is the name of the GMPLS, LMP, or RSVP controller. This command forms a submode for the respective configuration.
-------------------------	--

Examples	The following example shows how to enter the GMPLS UNI sub-mode for a specified controller interface, starting from global configuration mode:
-----------------	--

```
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-te-gmpls)# controller dwdm 0/4/0/0
RP/0/RP0/CPU0:router(config-te-gmpls-cntl)#

```

The following example shows how to specify an LMP controller 0/4/0/0:

```
RP/0/RP0/CPU0:router(config)# lmp
RP/0/RP0/CPU0:router(config-lmp)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni)# controller dwdm 0/4/0/0
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-cntl)#

```

The following example shows how to specify RSVP controller 0/4/0/0:

```
RP/0/RP0/CPU0:router(config)# rsvp
RP/0/RP0/CPU0:router(config-rsvp)# controller dwdm 0/1/0/0
RP/0/RP0/CPU0:router(config-rsvp-cntl)#

```

Related Commands	Command	Description
	mpls traffic-eng	Enters MPLS-TE configuration mode.

Command	Description
mpls optical-uni	Enables GMPLS optical UNI and enters configuration mode for UNI.

destination ipv4 unicast

destination ipv4 unicast

To specify the destination of a GMPLS UNI tunnel, use the **destination ipv4 unicast** command in GMPLS-UNI controller tunnel-properties configuration sub-mode.

destination ipv4 unicast *address*

Syntax Description	<i>address</i> Specifies the tunnel destination (IPv4 address).								
Command Default	No default behavior or values								
Command Modes	GMPLS-UNI controller tunnel-properties configuration								
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>Release 7.3.1</td><td>This command was introduced.</td></tr> </tbody> </table>	Release	Modification	Release 7.3.1	This command was introduced.				
Release	Modification								
Release 7.3.1	This command was introduced.								
Usage Guidelines	The destination can be either the optical router ID of the destination node or the optical address of the desired ingress interface to the destination node. Specifying the router-id means that the ingress interface is selected by the network.								
Examples	The following example shows how to specify a tunnel destination (10.10.3.4), starting from global configuration mode:								
	<pre>RP/0/RP0/CPU0:router(config)# mpls traffic-eng RP/0/RP0/CPU0:router(config-mpls-te)# gmpls optical-uni RP/0/RP0/CPU0:router(config-te-gmpls)# controller dwdm 0/4/0/0 RP/0/RP0/CPU0:router(config-te-gmpls-cntl)#tunnel-properties RP/0/RP0/CPU0:router(config-te-gmpls-tun)#destination ipv4 unicast 10.10.3.4 RP/0/RP0/CPU0:router(config-te-gmpls-tun)# </pre>								
Related Commands	<table border="1"> <thead> <tr> <th>Command</th><th>Description</th></tr> </thead> <tbody> <tr> <td>mpls traffic-eng</td><td>Enters MPLS-TE configuration mode.</td></tr> <tr> <td>gmppls optical-uni</td><td>Enables GMPLS UNI functionality and enters configuration mode for UNI.</td></tr> <tr> <td>controller dwdm (GMPLS)</td><td>Enters GMPLS UNI sub-mode for a controller.</td></tr> </tbody> </table>	Command	Description	mpls traffic-eng	Enters MPLS-TE configuration mode.	gmppls optical-uni	Enables GMPLS UNI functionality and enters configuration mode for UNI.	controller dwdm (GMPLS)	Enters GMPLS UNI sub-mode for a controller.
Command	Description								
mpls traffic-eng	Enters MPLS-TE configuration mode.								
gmppls optical-uni	Enables GMPLS UNI functionality and enters configuration mode for UNI.								
controller dwdm (GMPLS)	Enters GMPLS UNI sub-mode for a controller.								

dynamic

To enable the Dynamic LMP function on a UNI-C router, use the **dynamic** command in the LMP GMPLS-UNI neighbor configuration sub mode. To return to the default behavior, use the **no** form of this command.

dynamic

Syntax Description This command has no arguments or keywords.

Command Default The Dynamic LMP function is disabled.

Command Modes LMP GMPLS-UNI neighbor configuration.

Command History	Release	Modification
	7.3.1	This command was introduced.

Usage Guidelines The Dynamic LMP function validates LMP configuration consistency at the head-end and tail-end UNIs. Examples:

1. One end of a TE link is configured as an unnumbered interface, and the other end is configured with an IP address.
2. When configuring an unnumbered neighbor interface, entering the wrong neighbor interface ID.

Examples The following example shows how to enable the Dynamic LMP function on a UNI-C router:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# lmp
RP/0/RP0/CPU0:router(config-lmp)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni)# neighbor N1
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-nbr-n1)# dynamic
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-nbr-n1)# commit
Tue Jul 9 09:22:31.558 UTC
```

Related Commands

Command	Description
mpls traffic-eng	Enters MPLS-TE configuration mode.
gmpls optical-uni	Enables GMPLS optical UNI and enters configuration mode for UNI.

encoding-type (GMPLS-UNI)

encoding-type (GMPLS-UNI)

To assign the LSP encoding type for the GMPLS-UNI tunnel, use the **encoding-type** command in the GMPLS-UNI controller tunnel-properties configuration sub-mode. To return to the default behavior, use the **no** form of this command.

encoding-type *type*

Syntax Description	encoding-type <i>type</i>		Specifies the GMPLS traffic encoding type.						
Command Default	Lambda encoding type is enabled.								
Command Modes	GMPLS-UNI controller tunnel-properties configuration.								
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th><th></th></tr> </thead> <tbody> <tr> <td>Release 7.3.1</td><td>This command was introduced.</td><td></td></tr> </tbody> </table>			Release	Modification		Release 7.3.1	This command was introduced.	
Release	Modification								
Release 7.3.1	This command was introduced.								
Usage Guidelines	The encoding-type command is available in the GMPLS UNI tunnel and LMP neighbor configuration modes. Enable the same encoding type under both the modes.								
Examples	The following example shows how to assign the LSP encoding type for the GMPLS UNI tunnel:								
	<pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# mpls traffic-eng RP/0/RP0/CPU0:router(config-mpls-te)# gmpls optical-uni RP/0/RP0/CPU0:router(config-te-gmpls-uni)# controller dwdm 1/0/0/0 RP/0/RP0/CPU0:router(config-te-gmpls-cntl)# tunnel-properties RP/0/RP0/CPU0:router(config-te-gmpls-tun)# encoding-type lambda RP/0/RP0/CPU0:router(config-te-gmpls-tun)# commit Tue Jul 9 09:22:31.558 UTC</pre>								
Related Commands	<table border="1"> <thead> <tr> <th>Command</th><th>Description</th></tr> </thead> <tbody> <tr> <td>mpls traffic-eng</td><td>Enters MPLS-TE configuration mode.</td></tr> <tr> <td>gmples optical-uni</td><td>Enables GMPLS optical UNI and enters configuration mode for UNI.</td></tr> </tbody> </table>			Command	Description	mpls traffic-eng	Enters MPLS-TE configuration mode.	gmples optical-uni	Enables GMPLS optical UNI and enters configuration mode for UNI.
Command	Description								
mpls traffic-eng	Enters MPLS-TE configuration mode.								
gmples optical-uni	Enables GMPLS optical UNI and enters configuration mode for UNI.								

encoding-type (LMP)

To assign the LSP encoding type for LMP neighbor configuration, use the **encoding-type** command in the LMP controller neighbor configuration mode. To return to the default behavior, use the **no** form of this command.

encoding-type *type*

Syntax Description	encoding-type <i>type</i>		Specifies the LSP encoding type for LMP neighbor configuration.						
Command Default	Lambda encoding type is enabled.								
Command Modes	LMP controller neighbor configuration								
Command History	Release	Modification							
	7.3.1	This command was introduced.							
Usage Guidelines	The encoding-type command is available in the GMPLS UNI tunnel and LMP neighbor configuration modes. Enable the same encoding type under both the modes.								
Examples	The following example shows how to assign the LSP encoding type for LMP neighbor configuration:								
	<pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# lmp RP/0/RP0/CPU0:router(config-lmp)# gmpls optical-uni RP/0/RP0/CPU0:router(config-lmp-gmpls-uni)# controller dwdm 1/0/0/0 RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-cntl)# link-id ipv4 unicast 10.0.0.2 RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-cntl)# neighbor N1 RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-cntl)# link-id ipv4 unicast 10.0.0.4 RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-cntl)# switching-type lsc RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-cntl)# encoding-type lambda RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-cntl)# commit Tue Jul 9 09:22:31.558 UTC</pre>								
Related Commands	<table border="1"> <thead> <tr> <th>Command</th><th>Description</th></tr> </thead> <tbody> <tr> <td>mpls traffic-eng</td><td>Enters MPLS-TE configuration mode.</td></tr> <tr> <td>gmppls optical-uni</td><td>Enables GMPLS optical UNI and enters configuration mode for UNI.</td></tr> </tbody> </table>			Command	Description	mpls traffic-eng	Enters MPLS-TE configuration mode.	gmppls optical-uni	Enables GMPLS optical UNI and enters configuration mode for UNI.
Command	Description								
mpls traffic-eng	Enters MPLS-TE configuration mode.								
gmppls optical-uni	Enables GMPLS optical UNI and enters configuration mode for UNI.								

exclude (MPLS-TE)

To specify exclusions for an attribute set for LSP diversity for MPLS-TE, use the **exclude** command in MPLS-TE attribute set configuration mode. To remove exclusions, use the **no** form of this command.

```
exclude { best-effort | strict } lsp source address destination address tunnel-id ID
extended-tunnel-id ID [ lsp-id ID ]
```

Syntax Description		
best-effort		Specifies that the condition is met if possible.
strict		Specifies that the condition must be met.
lsp		Specifies that an LSP address will follow the lsp keyword.
source address		Specifies the source IPv4 address of the LSP from which a diverse path is required.
destination address		Specifies the destination address of the LSP from which a diverse path is required.
tunnel-id ID		Specifies the tunnel ID of the LSP from which a diverse path is required.
extended-tunnel-id ID		Specifies the extended tunnel ID (IPv4 address) of the LSP from which a diverse path is required.
lsp-id lsp-id		(Optional) Specifies the numeric LSP ID of the LSP from which a diverse path is required.
Command Default	No default behavior or values	
Command Modes	MPLS-TE attribute-set configuration	
Command History	Release	Modification
	Release 7.3.1	This command was introduced.
Usage Guidelines	An XRO attribute-set can be specified as part of the path-option, if required. An empty XRO attribute set results in the GMPLS tunnel being signaled with no exclusions, and therefore no XRO.	
	Multiple LSP exclusions can be configured in the attribute-set. If this is done, multiple exclusions will be added to the path message. If the lsp-id is specified, only the LSP with the specified lsp-id will be excluded. If it is omitted, all LSPs matching the specified session (source, destination, tunnel-id, extended tunnel-id) will be excluded.	
Examples	The following example shows how to configure exclusions for the attribute set attrset01:	

```
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
```

```
RP/0/RP0/CPU0:router(config-mpls-te)# attribute-set xro attrset01
RP/0/RP0/CPU0:router(config-te-attribute-set)# exclude best-effort lsp source 10.10.1.2
destination 10.20.4.4 tunnel-id 17 extended-tunnel-id 10.10.1.2 lsp-id 17
RP/0/RP0/CPU0:router(config-te-attribute-set)#

```

Related Commands	Command	Description
	mpls traffic-eng	Enters MPLS-TE configuration mode.
	attribute-set	Specifies an attribute set for LSP diversity for MPLS-TE.

mpls optical-uni

To enable GMPLS UNI feature, use the **mpls optical-uni** command in the appropriate mode. To return to the default behavior, use the **no** form of this command.

mpls optical-uni

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes MPLS-TE configuration

LMP configuration

Command History	Release	Modification
	Release 7.3.1	This command was introduced.

Usage Guidelines The LMP submode enables GMPLS-UNI LMP functionality and acts as a container for other GMPLS-UNI LMP configuration commands.

Examples The following example shows how to enable GMPLS-UNI, starting from global configuration mode:

```
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# mpls optical-uni
RP/0/RP0/CPU0:router(config-te-gmpls)#

```

The following example shows how to enable GMPLS UNI and enter LMP configuration mode:

```
RP/0/RP0/CPU0:router(config)# lmp
RP/0/RP0/CPU0:router(config-lmp)# mpls optical-uni
RP/0/RP0/CPU0:router(config-lmp-gmpls)#

```

Related Commands

Command	Description
mpls traffic-eng	Enters MPLS-TE configuration mode.
lmp	Enables GMPLS LMP functionality and enters configuration mode for LMP.

g-pid

To assign a Generalized PID (G-PID) on the UNI-C router, use the **g-pid** command in the GMPLS-UNI controller tunnel-properties configuration sub-mode. To return to the default behavior, use the **no** form of this command.

g-pid *value*

Syntax Description	g-pid <i>value</i>	Specifies the G-PID value.						
Command Default	A G-PID value of 37, assigned for Lambda switching over optic fiber technology.							
Command Modes	GMPLS-UNI controller tunnel-properties configuration.							
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>7.3.1</td><td>This command was introduced.</td></tr> </tbody> </table>		Release	Modification	7.3.1	This command was introduced.		
Release	Modification							
7.3.1	This command was introduced.							
Usage Guidelines	The G-PID value identifies the payload carried by the LSP.							
Examples	The following example shows how to configure the G-PID value:							
	<pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# mpls traffic-eng RP/0/RP0/CPU0:router(config-mpls-te)# gmpls optical-uni RP/0/RP0/CPU0:router(config-te-gmpls-uni)# controller dwdm 1/0/0/0 RP/0/RP0/CPU0:router(config-te-gmpls-cntl)# tunnel-properties RP/0/RP0/CPU0:router(config-te-gmpls-tun)# g-pid 37 RP/0/RP0/CPU0:router(config-te-gmpls-tun)# commit Tue Jul 9 09:22:31.558 UTC</pre>							
Related Commands	<table border="1"> <thead> <tr> <th>Command</th><th>Description</th></tr> </thead> <tbody> <tr> <td>mpls traffic-eng</td><td>Enters MPLS-TE configuration mode.</td></tr> <tr> <td>gmpls optical-uni</td><td>Enables GMPLS optical UNI and enters configuration mode for UNI.</td></tr> </tbody> </table>		Command	Description	mpls traffic-eng	Enters MPLS-TE configuration mode.	gmpls optical-uni	Enables GMPLS optical UNI and enters configuration mode for UNI.
Command	Description							
mpls traffic-eng	Enters MPLS-TE configuration mode.							
gmpls optical-uni	Enables GMPLS optical UNI and enters configuration mode for UNI.							

hello (GMPLS-UNI)

To configure LMP hello message and hello expiry message intervals, use the **hello** command in the LMP GMPLS-UNI neighbor configuration sub mode. To return to the default behavior, use the **no** form of this command.

hello *interval expiry-interval*

Syntax Description	<i>interval</i>	Specifies the LMP hello message interval.				
	<i>expiry-interval</i>	Specifies the LMP hello expiry message interval.				
		<p>Note Ensure that the LMP hello expiry message interval is at least thrice the interval of the LMP hello message.</p>				
Command Default	Interval of LMP hello messages between two LMP enabled routers is 2000 ms. An LMP hello expiry message is sent after a 6000 ms duration.					
Command Modes	LMP GMPLS-UNI neighbor configuration.					
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>7.3.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	7.3.1	This command was introduced.	
Release	Modification					
7.3.1	This command was introduced.					
Usage Guidelines	An LMP hello message is sent every 2000 ms from an LMP enabled router to LMP peers. If an LMP enabled router does not receive an LMP hello message from a peer device for a 6000 ms duration, an LMP hello expiry message is sent to other LMP routers. If the LMP fast keep-alive mechanism is not used, both message intervals should be set to zero.					
Examples	The following example shows how set the hello message and hello expiry message intervals:					

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# lmp
RP/0/RP0/CPU0:router(config-lmp)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni)# neighbor N1
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-nbr-n1)# dynamic
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-nbr-n1)# hello 3000 10000
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-nbr-n1)# commit
Tue Jul 9 09:22:31.558 UTC
```

Related Commands	Command	Description
	mpls traffic-eng	Enters MPLS-TE configuration mode.

Command	Description
mpls optical-uni	Enables GMPLS optical UNI and enters configuration mode for UNI.

ipcc routed (LMP)

To specify the Link Management Protocol neighbor IPCC configuration for GMPLS UNI, use the **ipcc routed** command in the neighbor sub-mode for LMP GMPLS-UNI controller configuration mode. To return to the default behavior, use the **no** form of this command.

ipcc routed

Syntax Description	This command has no keywords or arguments.				
Command Default	No default behavior or values				
Command Modes	LMP GMPLS-UNI controller neighbor configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.3.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.3.1	This command was introduced.
Release	Modification				
Release 7.3.1	This command was introduced.				

Examples

The following example shows how to specify the IPCC configuration for the GMPLS-UNI controller 0/0/0/3, neighbor UN02:

```
RP/0/RP0/CPU0:router(config)# lmp
RP/0/RP0/CPU0:router(config-lmp)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni)# neighbor UN02
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-nbr-UN02)# ipcc routed
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-nbr-UN02) #
```

Related Commands	Command	Description
	lmp	Enables GMPLS LMP functionality and enters configuration mode for LMP.
	neighbor (LMP)	Specifies an LMP neighbor for GMPLS and enters configuration mode for the neighbor.

link-id ipv4 unicast (LMP)

To specify the optical interface address for an LMP link for a GMPLS UNI controller, use the **link-id ipv4 unicast** command in GMPLS-UNI controller configuration mode. To return to the default behavior, use the **no** form of this command.

link-id ipv4 unicast *address*

Syntax Description	<i>address</i> Specifies the optical unicast IPv4 address.						
Command Default	No default behavior or values						
Command Modes	LMP GMPLS-UNI controller configuration						
Command History	<table> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>Release 7.3.1</td><td>This command was introduced.</td></tr> </tbody> </table>	Release	Modification	Release 7.3.1	This command was introduced.		
Release	Modification						
Release 7.3.1	This command was introduced.						
Usage Guidelines	This command specifies the local optical address for the link. It can be used as a tunnel destination at the tail UNI-C if the ingress link to the tail is to be specified.						
Examples	The following example shows how to specify the link ID:						
	<pre>RP/0/RP0/CPU0:router(config)# lmp RP/0/RP0/CPU0:router(config-lmp)# gmpls optical-uni RP/0/RP0/CPU0:router(config-lmp-gmpls-uni)# controller dwdm 0/4/0/0 RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-ctrl)# link-id ipv4 unicast 10.10.4.2 RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-ctrl)#</pre>						
Related Commands	<table border="1"> <thead> <tr> <th>Command</th><th>Description</th></tr> </thead> <tbody> <tr> <td>lmp</td><td>Enables GMPLS LMP functionality and enters configuration mode for LMP.</td></tr> <tr> <td>controller (LMP)</td><td>Specifies the LMP controller for GMPLS UNI and enters configuration mode for the controller.</td></tr> </tbody> </table>	Command	Description	lmp	Enables GMPLS LMP functionality and enters configuration mode for LMP.	controller (LMP)	Specifies the LMP controller for GMPLS UNI and enters configuration mode for the controller.
Command	Description						
lmp	Enables GMPLS LMP functionality and enters configuration mode for LMP.						
controller (LMP)	Specifies the LMP controller for GMPLS UNI and enters configuration mode for the controller.						

Imp

To enable functionality for GMPLS UNI LMP and enter LMP configuration commands, use the **Imp** command in XR Config mode. To return to the default behavior, use the **no** form of this command.

Imp

Syntax Description This command has no keywords or arguments.

Command Default No default behavior or values

Command Modes XR Config mode

Command History

Release	Modification
Release 7.3.1	This command was introduced.

Examples

The following example shows how to enable LMP functionality and enter the sub-mode for LMP configuration commands:

```
RP/0/RP0/CPU0:router(config)# lmp
RP/0/RP0/CPU0:router(config-lmp)#

```

logging events lsp-status state (GMPLS)

To specify the tunnel state logging configuration for GMPLS UNI, use the **logging events lsp-status state** command in GMPLS-UNI controller tunnel-properties configuration sub-mode. To return to the default behavior, use the **no** form of this command.

logging events lsp-status state

Syntax Description This command has no keywords or arguments.

Command Default No default behavior or values

Command Modes GMPLS-UNI controller tunnel-properties configuration

Command History	Release	Modification
	Release 7.3.1	This command was introduced.

Examples The following example shows how to specify the tunnel state logging configuration for controller 0/4/0/0:

```
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-te-gmpls)# controller dwdm 0/4/0/0
RP/0/RP0/CPU0:router(config-te-gmpls-ctrl)# tunnel-properties
RP/0/RP0/CPU0:router(config-te-gmpls-tun)# logging events lsp-status state
RP/0/RP0/CPU0:router(config-te-gmpls-tun)#

```

Related Commands

Command	Description
mpls traffic-eng	Enters MPLS-TE configuration mode.
controller dwdm (GMPLS)	Enters GMPLS UNI sub-mode for a controller.
tunnel-properties	Enters tunnel configuration mode for a GMPLS UNI controller.

mpls traffic-eng optical-uni reoptimize tunnel-id

mpls traffic-eng optical-uni reoptimize tunnel-id

To manually trigger the reoptimization of a GMPLS UNI tunnel, use the **mpls traffic-eng optical-uni reoptimize tunnel-id** command in XR Config mode.

mpls traffic-eng optical-uni reoptimize tunnel-id number

Syntax Description	<i>number</i> MPLS-TE tunnel identification expressed as a number. The range is from 0 to 65535.
---------------------------	--

Command Default	No default behavior or values
------------------------	-------------------------------

Command Modes	Global configuration
----------------------	----------------------

Command History	Release	Modification
------------------------	----------------	---------------------

Release 7.3.1	This command was introduced.
---------------	------------------------------

Examples	The following example shows how to manually reoptimize a GMPLS UNI tunnel with tunnel ID 100:
-----------------	---

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls traffic-eng optical-uni reoptimize tunnel-id 100
```

mtu (GMPLS-UNI)

To configure the maximum traffic limit (MTU) value on a GMPLS UNI controller interface, use the **mtu** command in GMPLS-UNI configuration sub-mode. To return to the default behavior, use the **no** form of this command.

mtu *value*

Syntax Description	mtu <i>value</i>	Specifies the MTU value for the controller interface.
---------------------------	-------------------------	---

Command Default	An MTU of 9212 bytes is configured on a GMPLS UNI controller interface.
------------------------	---

Command Modes	GMPLS-UNI configuration
----------------------	-------------------------

Command History	Release	Modification
	7.3.1	This command was introduced.

Examples	The following example shows how to configure the MTU value on a GMPLS UNI controller interface:
-----------------	---

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-te-gmpls-uni)# controller dwdm 1/0/0/0
RP/0/RP0/CPU0:router(config-te-gmpls-cntl)# mtu 9000
RP/0/RP0/CPU0:router(config-te-gmpls-cntl)# commit
Tue Jul 9 09:22:31.558 UTC
```

Related Commands	Command	Description
	mpls traffic-eng	Enters MPLS-TE configuration mode.
	gmpls optical-uni	Enables GMPLS optical UNI and enters configuration mode for UNI.

neighbor (LMP)

To specify an LMP neighbor for GMPLS and enter commands to configure the neighbor, use the **neighbor** command in the appropriate configuration mode. To return to the default behavior, use the **no** form of this command.

neighbor *name*

Syntax Description	<i>name</i> Specifies the name of the LMP neighbor.
---------------------------	---

Command Default	No default behavior or values
------------------------	-------------------------------

Command Modes	LMP GMPLS-UNI configuration LMP Controller configuration
----------------------	---

Command History	Release	Modification
	Release 7.3.1	This command was introduced.

Usage Guidelines	Under LMP controller configuration submode, this command specifies the neighbor reached via the controller. And, under the LMP GMPLS UNI submode, it creates a submode in which other properties of the neighbor can be specified. The name argument is the name of the configured neighbor.
-------------------------	--

Examples	The following example shows how to specify the neighbor UN01 for the GMPLS-UNI controller 0/0/0/3:
-----------------	--

```
RP/0/RP0/CPU0:router(config)# lmp
RP/0/RP0/CPU0:router(config-lmp)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni)# neighbor UN01
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-nbr-UN01)# exit
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni)# controller dwdm 0/1/0/0
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-cntl)# neighbor UN01
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-cntl)#

```

Related Commands	Command	Description
	lmp	Enables GMPLS LMP functionality and enters configuration mode for LMP.
	gmpls optical-uni	Enables GMPLS UNI functionality and enters configuration mode for UNI.

neighbor interface-id unnumbered

To specify the neighbor's optical interface ID of an LMP link for a GMPLS UNI controller, use the **neighbor interface-id unnumbered** command in GMPLS-UNI controller configuration mode. To return to the default behavior, use the **no** form of this command.

neighbor interface-id unnumbered *interface-id*

Syntax Description	<i>interface-id</i> Specifies the optical interface ID of the neighbor.
---------------------------	---

Command Default	No default behavior or values
------------------------	-------------------------------

Command Modes	LMP GMPLS-UNI controller configuration
----------------------	--

Command History	Release	Modification
	Release 7.3.1	This command was introduced.

Usage Guidelines	For the interface ID on the command line, you can use the SNMP ifindex of the interface on the neighbor node.
-------------------------	---

Examples	The following example shows how to specify the optical interface ID (17) of an LMP neighbor:
-----------------	--

```
RP/0/RP0/CPU0:router(config)# lmp
RP/0/RP0/CPU0:router(config-lmp)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni)# controller dwdm 0/4/0/0
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-ctrl)# neighbor interface-id unnumbered 17
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-ctrl)#
```

Related Commands	Command	Description
	lmp	Enables GMPLS LMP functionality and enters configuration mode for LMP.
	controller dwdm (GMPLS)	Enters GMPLS UNI sub-mode for a controller.

neighbor link-id ipv4 unicast

neighbor link-id ipv4 unicast

To specify the neighbor's optical address of an LMP link for a GMPLS UNI controller, use the **neighbor link-id ipv4 unicast** command in GMPLS-UNI controller configuration mode. To return to the default behavior, use the **no** form of this command.

neighbor link-id ipv4 unicast *address*

Syntax Description	<i>address</i> Specifies the IPv4 address of the neighbor.				
Command Default	No default behavior or values				
Command Modes	LMP GMPLS-UNI controller configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.3.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.3.1	This command was introduced.
Release	Modification				
Release 7.3.1	This command was introduced.				

Examples

The following example shows how to specify the optical IPv4 address (10.10.4.5) of an LMP neighbor for controller 0/4/0/0:

```
RP/0/RP0/CPU0:router(config)# lmp
RP/0/RP0/CPU0:router(config-lmp)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni)# controller dwdm 0/4/0/0
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-ctrl)# neighbor link-id ipv4 unicast 10.10.4.5
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-ctrl)#

```

Related Commands	Command	Description
	lmp	Enables GMPLS LMP functionality and enters configuration mode for LMP.
	controller dwdm (GMPLS)	Enters GMPLS UNI sub-mode for a controller.

path-option (GMPLS)

To specify a path option for a GMPLS UNI tunnel, use the **path-option** command in GMPLS-UNI controller tunnel-properties configuration sub-mode. To remove a path option, use the **no** form of this command.

```
path-option 10 { no-ero | explicit { name path-name | index index } } [ xro-attribute-set name ] [ signaled-label dwdm wavelength channel ] [ lockdown] [ verbatim]
```

Syntax Description	<p>10 Specifies the path option index. 10 is the only supported index in this release.</p> <p>explicit Specifies that LSP paths are IP explicit paths.</p> <p>name Specifies the path name of the IP explicit path. <i>path-name</i></p> <p>no-ero Specifies that no ERO object is included in signalling.</p> <p>xro-attribute-set (Optional) Specifies the xro attribute set for the path option.</p> <p>name Specifies the name of the xro-attribute-set.</p> <p>lockdown (Optional) Indicates that the tunnel does not reoptimize without user intervention. This is the only supported behavior in this release.</p> <p>signaled-label (Optional) Sets a specific label for the path option.</p> <p>dwdm (Optional) Specifies that it is a DWDM label.</p> <p>wavelength (Optional) Specifies the DWDM wavelength to use.</p> <p>channel Specifies the channel number to use. The range is from 1 to 89.</p> <p>verbatim (Optional) Bypasses the topology check for explicit paths.</p>				
Command Default	No default behavior or values				
Command Modes	GMPLS UNI controller tunnel-properties configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>Release 7.3.1</td><td>This command was introduced.</td></tr> </tbody> </table>	Release	Modification	Release 7.3.1	This command was introduced.
Release	Modification				
Release 7.3.1	This command was introduced.				
Usage Guidelines	The path option index is no longer fixed at 10. It is now set by the user and distinguishes path options in the same manner as for packet tunnels. The path option index may be any value between 1 and 1000 (the same range as for packet tunnels). The verbatim keyword is mandatory when an explicit path is referenced by a GMPLS UNI path option, but must not be present if the no-ero option is in use.				
Examples	The following example shows how to specify the tunnel path option for controller 0/4/0/0, attribute set A01, starting from global configuration mode:				

path-option (GMPLS)

```

RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-te-gmpls)# controller dwdm 0/4/0/0
RP/0/RP0/CPU0:router(config-te-gmpls-cntl)#tunnel-properties
RP/0/RP0/CPU0:router(config-te-gmpls-tun)#path-option 10 no-ero xro-attribute-set A01
lockdown
RP/0/RP0/CPU0:router(config-te-gmpls-tun)#

```

Related Commands

Command	Description
mpls traffic-eng	Enters MPLS-TE configuration mode.
gmpls optical-uni	Enables GMPLS UNI functionality and enters configuration mode for UNI.
controller dwdm (GMPLS)	Enters GMPLS UNI sub-mode for a controller.
tunnel-properties	Enters tunnel configuration mode for a GMPLS UNI controller.
attribute-set xro	Enters tunnel configuration mode for a GMPLS UNI controller.

record-route

To enable record-route functionality for the GMPLS UNI tunnel, use the **record-route** command in GMPLS-UNI controller tunnel-properties configuration sub-mode. To return to the default behavior, use the **no** form of this command

record-route

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes GMPLS-UNI controller tunnel-properties configuration

Command History	Release	Modification
	Release 7.3.1	This command was introduced.

Examples The following example shows how enable record-route functionality, starting from global configuration mode:

```
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-te-gmpls)# controller dwdm 0/4/0/0
RP/0/RP0/CPU0:router(config-te-gmpls-cntl)#tunnel-properties
RP/0/RP0/CPU0:router(config-te-gmpls-tun)#record-route
RP/0/RP0/CPU0:router(config-te-gmpls-tun)#

```

Related Commands

Command	Description
controller dwdm (GMPLS)	Enters GMPLS UNI sub-mode for a controller.
tunnel-properties	Enters tunnel configuration mode for a GMPLS UNI controller.

router-id ipv4 unicast

router-id ipv4 unicast

To configure the LMP unicast or neighbor router ID for GMPLS, use the **router-id ipv4 unicast** command in the appropriate configuration mode. To return to the default behavior, use the **no** form of this command.

router-id ipv4 unicast address

Syntax Description	<i>address</i> Specifies the GMPLS-UNI optical router-id (IPv4 address).				
Command Default	No default behavior or values				
Command Modes	LMP GMPLS UNI configuration LMP GMPLS UNI neighbor configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.3.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.3.1	This command was introduced.
Release	Modification				
Release 7.3.1	This command was introduced.				

Examples

The following example shows how to specify a router ID (address 10.10.4.4) for GMPLS-UNI:

```
RP/0/RP0/CPU0:router(config)# lmp
RP/0/RP0/CPU0:router(config-lmp)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni)# router-id ipv4 unicast 10.10.4.4
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni)
```

The following example shows how to specify the neighbor router ID 10.10.5.5 for GMPLS UNI:

```
RP/0/RP0/CPU0:router(config)# lmp
RP/0/RP0/CPU0:router(config-lmp)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni)# neighbor UN01
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-nbr-UN01)# router-id ipv4 unicast 10.10.5.5
RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-nbr-UN01) #
```

Related Commands	Command	Description
	lmp	Enables GMPLS LMP functionality and enters configuration mode for LMP.
	destination ipv4 unicast	Specifies the destination of a GMPLS optical UNI tunnel.
	neighbor (LMP)	Specifies an LMP neighbor for GMPLS and enters configuration mode for the neighbor.

show mpls traffic-eng link-management optical-uni

To display a summary of the TE link management GMPLS-UNI states, use the **show mpls traffic-eng link-management optical-uni** command in XR EXEC mode.

show mpls traffic-eng link-management optical-uni [controller *controller*] [tabular]

Syntax Description	controller <i>controller</i>	(Optional) Displays information for the specified controller.				
	tabular	(Optional) Displays information in tabular format.				
Command Default	None					
Command Modes	XR EXEC mode					
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>7.3.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>		Release	Modification	7.3.1	This command was introduced.
Release	Modification					
7.3.1	This command was introduced.					
Usage Guidelines	To use this command, first enable the MPLS-TE application.					

Example

The following command displays the TE GMPLS-UNI states for the specified controller .

```
RP/0/RP0/CPU0:router# show mpls traffic-eng link-management optical-uni controller dwdm0/1/0/0
Thu Oct  4 14:52:46.147 ottawa
Optical interface: dwdm0/1/0/0
Overview:
    IM state: Up
    OLM/LMP state: Up
    Optical tunnel state: up
Connection:
    Tunnel role: Head
    Tunnel-id: 300
    Local optical router-id: 10.58.64.239
    Remote optical router-id: 10.58.40.40
    Upstream label:
        Optical label:
            Grid          : DWDM
            Channel spacing : 50 GHz
            Identifier   : 0
            Channel Number : 42
    Downstream label:
        Optical label:
            Grid          : DWDM
            Channel spacing : 50 GHz
            Identifier   : 0
```

show mpls traffic-eng link-management optical-uni

```

    Channel Number      : 42
Admission Control:
    Upstream: Admitted (LSP ID: 77)
    Downstream: Admitted (LSP ID: 77)
OLM/LMP adjacency information:
    Adjacency status: Up
    Local:
        node ID: 10.58.64.239
        link interface ID: 39
        link ID: 10.20.2.1
    Neighbor:
        node ID: 10.58.40.40 (crs1-239-nr)
        link interface ID: 2
        link ID: 10.20.2.2
        IPCC: Routed to 10.58.40.40
Optical capabilities:
    Controller type: DWDM
    Channel spacing: 50 GHz
    Default channel: 58
    82 supported channels:
        -23, -22, -21, -20, -19, -18, -17, -16
        -15, -14, -13, -12, -11, -10, -9, -8
        -7, -6, -5, -4, -3, -2, -1, 0
        1, 2, 3, 4, 5, 6, 7, 8
        9, 10, 11, 12, 13, 14, 15, 16
        17, 18, 19, 20, 21, 22, 23, 24
        25, 26, 27, 28, 29, 30, 31, 32
        33, 34, 35, 36, 37, 38, 39, 40
        41, 42, 43, 44, 45, 46, 47, 48
        49, 50, 51, 52, 53, 54, 55, 56
        57, 58
RP/0/RP0/CPU0:crs239#

```

Example

The following command provides an overview of the TE GMPLS-UNI states in tabular format.

```

RP/0/RP0/CPU0:router# show mpls traffic-eng link-management optical-uni tabular
System Information:
Optical Links Count: 2 (Maximum Links Supported 100)

      State          LMP          GMPLS tunnel
Interface Admin Oper adjacency role tun-id state
-----
P00/1/0/0   up   up       up   Head     1   up
P00/1/0/1   up   up       up   Head     2   up

```

The following command displays the SRLGs configured locally on the DWDM controller and the collected SRLG and latency data for the tunnel.

```

RP/0/RP0/CPU0:router# show mpls traffic-eng link-management optical-uni
System Information:
Optical Links Count: 4 (Maximum Links Supported 100)

Optical interface: dwdm0/1/0/0
Overview:
    IM state: Up
    OLM/LMP state: Up
    Optical tunnel state: up

```

```

Connection:
  Tunnel role: Head
  Tunnel-id: 1, LSP-id: 2, Extended tunnel-id: 88.0.0.8
  Tunnel source: 88.0.0.8, destination: 10.0.1.2
  Optical router-ids: Local: 88.0.0.8, Remote: 99.0.0.9
  Label source: UNI-N
  Upstream label:
Optical label:
  Grid : DWDM
  Channel spacing : 50 GHz
  Identifier : 0
  Channel Number : 59
Downstream label:
  Optical label:
    Grid : DWDM
    Channel spacing : 50 GHz
    Identifier : 0
    Channel Number : 59
SRLG discovery: Enabled
SRLG announcement: announced to TenGigE 0/1/0/0
Admission Control:
  Upstream: Admitted (LSP ID: 2)
  Downstream: Admitted (LSP ID: 2)
OLM/LMP adjacency information:
  Adjacency status: Up
  Local:
    node ID: 88.0.0.8
    link interface ID: 15
    link ID: 10.0.0.1
  Neighbor:
    node ID: 99.0.0.9 (mpls2_uni)
    link interface ID: 3
    link ID: 10.0.0.2
    IPCC: Routed to 99.0.0.9
Optical capabilities:
  Controller type: DWDM
  Channel spacing: 50 GHz
  Default channel: 59
  44 supported channels:
    -27, -25, -23, -21, -19, -17, -15, -13
    -11, -9, -7, -5, -3, -1, 1, 3
    5, 7, 9, 11, 13, 15, 17, 19
    21, 23, 25, 27, 29, 31, 33, 35
    37, 39, 41, 43, 45, 47, 49, 51
    53, 55, 57, 59
Controller SRLGs:
  1, 2, 3, 4

```

signalled-name (GMPLS)

To specify the signalled name to apply to the GMPLS UNI tunnel, use the **signalled-name** command in GMPLS-UNI controller tunnel-properties configuration sub-mode. To return to the default behavior, use the **no** form of this command.

signalled-name *name*

Syntax Description	<i>name</i> Specifies the signalled name to apply to the tunnel.				
Command Default	No default behavior or values				
Command Modes	GMPLS-UNI controller tunnel-properties configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>Release 7.3.1</td><td>This command was introduced.</td></tr> </tbody> </table>	Release	Modification	Release 7.3.1	This command was introduced.
Release	Modification				
Release 7.3.1	This command was introduced.				

Examples

The following example shows how to specify a signalled name for the tunnel (tunname), starting from global configuration mode:

```
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-te-gmpls)# controller dwdm 0/4/0/0
RP/0/RP0/CPU0:router(config-te-gmpls-cntl)#tunnel-properties
RP/0/RP0/CPU0:router(config-te-gmpls-tun)#signalled-name tunname
RP/0/RP0/CPU0:router(config-te-gmpls-tun)#

```

Related Commands	Command	Description
	controller dwdm (GMPLS)	Enters GMPLS UNI sub-mode for a controller.
	tunnel-properties	Enters tunnel configuration mode for a GMPLS UNI controller.

signalling refresh out-of-band interval

To specify the out-of-band refresh interval for RSVP, use the **signalling refresh out-of-band interval** command in RSVP controller configuration mode. To return to the default behavior, use the **no** form of this command.

signalling refresh out-of-band interval *interval*

Syntax Description	<i>interval</i> Specifies the refresh interval (180-86400 seconds).
---------------------------	---

Command Default	45 seconds
------------------------	------------

Command Modes	RSVP controller configuration
----------------------	-------------------------------

Command History	Release	Modification
	Release 7.3.1	This command was introduced.

Usage Guidelines	This command applies only to the RSVP sessions associated with GMPLS-UNI tunnels.
-------------------------	---

Examples	The following example shows how to specify 200 seconds for the out-of-band interface refresh interval:
-----------------	--

```
RP/0/RP0/CPU0:router(config) # rsvp
RP/0/RP0/CPU0:router(config-rsvp) # controller dwdm 0/4/0/0
RP/0/RP0/CPU0:router(config-rsvp-ctrl) # signalling refresh out-of-band interval 200
RP/0/RP0/CPU0:router(config-rsvp-ctrl) #
```

Related Commands	Command	Description
	rsvp	Enables RSVP functionality and enters configuration mode for RSVP.
	controller (LMP)	Specifies the RSVP controller for GMPLS UNI and enters configuration mode for the controller.
	signalling refresh out-of-band missed	Specifies the number of missed refresh messages allowed before states are deleted for optical tunnels.

signalling refresh out-of-band missed

signalling refresh out-of-band missed

To specify the number of missed refresh messages allowed before states are deleted for optical tunnels, use the **signalling refresh out-of-band missed** command in RSVP controller configuration mode. To return to the default behavior, use the **no** form of this command.

signalling refresh out-of-band missed *count*

Syntax Description	<i>count</i> Number of missed refresh messages allowed before states are deleted for optical tunnels (1-48).								
Command Default	The default value is 12.								
Command Modes	RSVP controller configuration								
Command History	<table> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>Release 7.3.1</td><td>This command was introduced.</td></tr> </tbody> </table>	Release	Modification	Release 7.3.1	This command was introduced.				
Release	Modification								
Release 7.3.1	This command was introduced.								
Usage Guidelines	This command applies only to the RSVP sessions associated with GMPLS-UNI tunnels.								
Examples	The following example shows how to specify a maximum of 10 messages for the number of allowed missed refresh messages:								
<pre>RP/0/RP0/CPU0:router(config)# rsvp RP/0/RP0/CPU0:router(config-rsvp)# controller dwdm 0/4/0/0 RP/0/RP0/CPU0:router(config-rsvp-ctrl)# signalling refresh out-of-band missed 10 RP/0/RP0/CPU0:router(config-rsvp-ctrl)# </pre>									
Related Commands	<table border="1"> <thead> <tr> <th>Command</th><th>Description</th></tr> </thead> <tbody> <tr> <td>rsvp</td><td>Enables RSVP functionality and enters configuration mode for RSVP.</td></tr> <tr> <td>controller (LMP)</td><td>Specifies the RSVP controller for GMPLS UNI and enters configuration mode for the controller.</td></tr> <tr> <td>signalling refresh out-of-band interval</td><td>Specifies the out-of-band refresh interval for RSVP.</td></tr> </tbody> </table>	Command	Description	rsvp	Enables RSVP functionality and enters configuration mode for RSVP.	controller (LMP)	Specifies the RSVP controller for GMPLS UNI and enters configuration mode for the controller.	signalling refresh out-of-band interval	Specifies the out-of-band refresh interval for RSVP.
Command	Description								
rsvp	Enables RSVP functionality and enters configuration mode for RSVP.								
controller (LMP)	Specifies the RSVP controller for GMPLS UNI and enters configuration mode for the controller.								
signalling refresh out-of-band interval	Specifies the out-of-band refresh interval for RSVP.								

switching-type (GMPLS-UNI)

To assign the GMPLS traffic switching type on the UNI-C router, use the **switching-type** command in the MPLS-TE GMPLS UNI controller configuration mode. To return to the default behavior, use the **no** form of this command.

switching-type *type*

Syntax Description	switching-type <i>type</i>		Specifies the GMPLS traffic switching type.
Command Default	Lambda-Switch Capable (LSC) switching type.		
Command Modes	MPLS-TE GMPLS UNI controller configuration.		
Command History	Release	Modification	
	7.3.1	This command was introduced.	
Usage Guidelines	The switching-type command is available in the GMPLS UNI tunnel and LMP neighbor configuration modes. Enable the same switching type under both the modes.		
Examples	The following example shows how to assign the GMPLS traffic switching type for the GMPLS UNI tunnel:		
	<pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# mpls traffic-eng RP/0/RP0/CPU0:router(config-mpls-te)# gmpls optical-uni RP/0/RP0/CPU0:router(config-te-gmpls-uni)# controller dwdm 1/0/0/0 RP/0/RP0/CPU0:router(config-te-gmpls-cntl)# tunnel-properties RP/0/RP0/CPU0:router(config-te-gmpls-tun)# encoding-type lambda RP/0/RP0/CPU0:router(config-te-gmpls-tun)# exit RP/0/RP0/CPU0:router(config-te-gmpls-cntl)# switching-type lsc RP/0/RP0/CPU0:router(config-te-gmpls-cntl)# commit Tue Jul 9 09:22:31.558 UTC</pre>		
Related Commands	Command	Description	
	gmpls optical-uni	Enables GMPLS optical UNI and enters configuration mode for UNI.	

switching-type (LMP)

switching-type (LMP)

To assign the GMPLS traffic switching type for LMP neighbor configuration, use the **switching-type** command in the LMP controller neighbor configuration mode. To return to the default behavior, use the **no** form of this command.

switching-type *type*

Syntax Description	switching-type <i>type</i>		Specifies the LSP switching type for the LMP neighbor configuration.
Command Default	Lambda-Switch Capable (LSC) type.		
Command Modes	LMP controller neighbor configuration		
Command History	Release	Modification	
	Release 7.3.1	This command was introduced.	
Usage Guidelines	The switching-type command is available in the GMPLS UNI tunnel and LMP neighbor configuration modes. Enable the same switching type under both the modes.		
Examples	The following example shows how to assign the GMPLS traffic switching type for LMP neighbor configuration:		
	<pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# lmp RP/0/RP0/CPU0:router(config-lmp)# gmpls optical-uni RP/0/RP0/CPU0:router(config-lmp-gmpls-uni)# controller dwdm 1/0/0/0 RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-cntl)# link-id ipv4 unicast 10.0.0.2 RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-cntl)# neighbor N1 RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-cntl)# link-id ipv4 unicast 10.0.0.4 RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-cntl)# switching-type lsc RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-cntl)# encoding-type lambda RP/0/RP0/CPU0:router(config-lmp-gmpls-uni-cntl)# commit Tue Jul 9 09:22:31.558 UTC</pre>		
Related Commands	Command	Description	
	gmpls optical-uni	Enables GMPLS optical UNI and enters configuration mode for UNI.	

tunnel-id (GMPLS)

To specify the ID of the GMPLS UNI tunnel, use the **tunnel-id** command in GMPLS-UNI controller tunnel-properties configuration sub-mode. To return to the default behavior, use the **no** form of this command.

tunnel-id *number*

Syntax Description	<i>number</i> Specifies the tunnel ID.
---------------------------	--

Command Default	No default behavior or values
------------------------	-------------------------------

Command Modes	GMPLS-UNI controller tunnel-properties configuration
----------------------	--

Command History	Release	Modification
	Release 7.3.1	This command was introduced.

Examples	The following example shows how to specify a tunnel ID (5), starting from global configuration mode:
-----------------	--

```
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-te-gmpls)# controller dwdm 0/4/0/0
RP/0/RP0/CPU0:router(config-te-gmpls-cntl)#tunnel-properties
RP/0/RP0/CPU0:router(config-te-gmpls-tun)#tunnel-id 5
RP/0/RP0/CPU0:router(config-te-gmpls-tun)#

```

Related Commands	Command	Description
	controller dwdm (GMPLS)	Enters GMPLS UNI sub-mode for a controller.
	tunnel-properties	Enters tunnel configuration mode for a GMPLS UNI controller.

tunnel-properties

To configure tunnel-specific information for a GMPLS UNI controller, use the **tunnel-properties** command in GMPLS-UNI configuration sub-mode. To return to the default behavior, use the **no** form of this command.

tunnel-properties

Syntax Description	This command has no keywords or arguments.	
Command Default	No default behavior or values	
Command Modes	GMPLS-UNI configuration	
Command History	Release	Modification
	Release 7.3.1	This command was introduced.
Usage Guidelines	This command designates the controller as a tunnel-head, rather than a tunnel tail. After the tunnel properties are configured, the incoming path messages are rejected and any existing tail-end tunnel is torn down.	
Examples	The following example shows how to enter the sub-mode to configure tunnel-specific information for a GMPLS UNI controller:	

```
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# gmpls optical-uni
RP/0/RP0/CPU0:router(config-te-gmpls)# controller dwdm 0/4/0/0
RP/0/RP0/CPU0:router(config-te-gmpls-cntl)#tunnel-properties
RP/0/RP0/CPU0:router(config-te-gmpls-tun)#

```

Related Commands	Command	Description
	controller dwdm (GMPLS)	Enters GMPLS UNI sub-mode for a controller.