



## Implementing BFD

---

Bidirectional forwarding detection (BFD) provides low-overhead, short-duration detection of failures in the path between adjacent forwarding engines. BFD allows a single mechanism to be used for failure detection over any media and at any protocol layer, with a wide range of detection times and overhead. The fast detection of failures provides immediate reaction to failure in the event of a failed link or neighbor.

- [Prerequisites for Implementing BFD, on page 1](#)
- [Restrictions for Implementing BFD, on page 2](#)
- [Information About BFD, on page 2](#)
- [BFD hardware offload for RSVP tail-end, on page 27](#)
- [BGP BFD Strict-Mode Capabilities for Improved Interoperability, on page 35](#)
- [Bidirectional forwarding detection over VXLAN tunnel, on page 37](#)
- [Bidirectional forwarding detection on BVI, on page 44](#)
- [BFD over pseudowire headend, on page 48](#)
- [RFCs, on page 50](#)
- [Technical Assistance, on page 50](#)
- [Limiting LSA Numbers in a OSPF Link-State Database, on page 51](#)

## Prerequisites for Implementing BFD

You must be in a user group associated with a task group that includes the proper task IDs. The command reference guides include the task IDs required for each command. If you suspect user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The following prerequisites are required to implement BFD:

- If enabling BFD on Multiprotocol Label Switching (MPLS), an installed composite PIE file including the MPLS package, or a composite-package image is required. For Border Gateway Protocol (BGP), Intermediate System-to-Intermediate System (IS-IS), Static, and Open Shortest Path First (OSPF), an installed Cisco IOS XR IP Unicast Routing Core Bundle image is required.
- Interior Gateway Protocol (IGP) is activated on the router if you are using IS-IS or OSPF.
- To enable BFD for a neighbor, the neighbor router must support BFD.
- To support BFD on bundle member links, be sure that the following requirements are met:
  - The routers on either end of the bundle are connected back-to-back without a Layer 2 switch in between.

- For a BFD session to start, any one of the following configurations or states are present on the bundle member:

Link Aggregation Control Protocol (LACP) Distributing state is reached, –Or–  
EtherChannel is configured.

Hot Standby and LACP Collecting state is reached.

## Restrictions for Implementing BFD

These restrictions apply to BFD:

- Demand mode is not supported in Cisco IOS XR software.
- Echo latency detection and echo validation are not supported on bundle interfaces.
- Echo mode is not supported on BFD over bundle interfaces and on bundle VLANs, which is BFD over logical bundle (BLB).
- When BFD echo mode is enabled for IPv4, the maximum supported number of BFDv4 single-hop sessions is reduced by 50%. This limitation does not apply to BFDv6 or BFDv4 multi-hop sessions.

## Information About BFD

### BFD Packet Intervals on Physical Interfaces

When BFD is running over physical interfaces, echo mode is used only if the configured interval is less than two seconds.

BFD sessions running over physical interfaces when echo mode is enabled send BFD control packets at a slow rate of every two seconds. There is no need to duplicate control packet failure detection at a fast rate because BFD echo packets are already being sent at fast rates and link failures will be detected when echo packets are not received within the echo failure detection time.

### Control Packet Failure Detection In Asynchronous Mode

Control packet failure in asynchronous mode without echo is detected using the values of the minimum interval (`bfd minimum-interval` for non-bundle interfaces, and `bfd address-family ipv4 minimum-interval` for bundle interfaces) and multiplier (`bfd multiplier` for non-bundle interfaces, and `bfd address-family ipv4 multiplier` for bundle interfaces) commands.

For control packet failure detection, the local multiplier value is sent to the neighbor. A failure detection timer is started based on  $(I \times M)$ , where  $I$  is the negotiated interval, and  $M$  is the multiplier provided by the remote end.

Whenever a valid control packet is received from the neighbor, the failure detection timer is reset. If a valid control packet is not received from the neighbor within the time period  $(I \times M)$ , then the failure detection timer is triggered, and the neighbor is declared down.

## Priority Settings for BFD Packets

For all interfaces under over-subscription, the internal priority needs to be assigned to remote BFD Echo packets, so that these BFD packets are not overwhelmed by other data packets. In addition, CoS values need to be set appropriately, so that in the event of an intermediate switch, the reply back of remote BFD Echo packets are protected from all other packets in the switch.

As configured CoS values in ethernet headers may not be retained in Echo messages, CoS values must be explicitly configured in the appropriate egress QoS service policy. CoS values for BFD packets attached to a traffic class can be set using the `set cos` command. For more information on configuring class-based unconditional packet marking, see “Configuring Modular QoS Packet Classification” in the .

## BFD over bundles IETF mode support on a per bundle basis

*Table 1: Feature History Table*

| Feature Name     | Release         | Description   |
|------------------|-----------------|---|
| BFD over bundles | Release 25.1.1  | Introduced in this release on: Fixed Systems ( 8010 [ASIC: A100])<br><br>This feature is now supported on:<br><ul style="list-style-type: none"> <li>• 8011-4G24Y4H-I</li> </ul>  |
| BFD over bundles | Release 24.4.1  | Introduced in this release on: Fixed Systems( 8700) (select variants only*).<br><br>*This feature is now supported on:<br><ul style="list-style-type: none"> <li>• 8712-MOD-M</li> <li>• 8711-32FH-M</li> </ul>   |
| BFD over bundles | Release 24.2.11 | Introduced in this release on: Modular Systems (8800 [LC ASIC: P100]) (select variants only*).<br><br>This feature enables fast failure detection of link aggregation (LAG) member links, ensuring interoperability between different platforms. It supports per bundle basis, allowing the selection of IETF standard per bundle without requiring system reloads or process restarts.<br><br>*This feature is now supported on routers with 88-LC1-36EH line cards. |

BFD over Bundle (BoB) mode is a standard based fast failure detection of link aggregation (LAG) member links that is interoperable between different platforms. BoB support on a per bundle basis provides an option to choose IETF standard per bundle, without necessitating reloads or process restarts across various systems.

- IETF mode uses IANA assigned MAC.
- IETF BFD over Bundle sessions use destination UDP port: 6784.

### Restrictions

These limitations apply for the BFD over Bundle Mode feature:

- BFD over Bundle feature is supported only in IETF mode.
- You can use the **no bfd address-family ipv4 fast-detect** command to make BoB non-operational. You can also choose to configure a bundle to 'down' state by configuring shutdown under that particular bundle.
- For a bundle to accept the new BFD mode change, you must bring down and then recreate the existing BFD sessions.

## BFD dampening

*Table 2: Feature History Table*

| Feature Name  | Release        | Description   |
|---------------|----------------|---|
| BFD dampening | Release 25.1.1 | Introduced in this release on: Fixed Systems ( 8010 [ASIC: A100])<br>This feature is now supported on:<br><ul style="list-style-type: none"> <li>• 8011-4G24Y4H-I</li> </ul>                                |
| BFD dampening | Release 24.4.1 | Introduced in this release on: Fixed Systems( 8700) (select variants only*).<br>*This feature is now supported on:<br><ul style="list-style-type: none"> <li>• 8712-MOD-M</li> <li>• 8711-32FH-M</li> </ul> |

| Feature Name  | Release         | Description   |
|---------------|-----------------|---|
| BFD dampening | Release 24.2.11 | <p>Introduced in this release on: Modular Systems (8800 [LC ASIC: P100]) (select variants only*).</p> <p>You can now automatically dampen BFD sessions to prevent excessive notifications from flapping links, thus preventing unnecessary network instability.</p> <p>*This feature is now supported on routers with 88-LC1-36EH line cards.</p> |

Bidirectional Forwarding Detection (BFD) is a mechanism used by routing protocols to quickly realize and communicate the reachability failures to their neighbors. When BFD detects a reachability status change of a client, its neighbors are notified immediately. Sometimes it might be critical to minimize changes in routing tables so as not to impact convergence, in case of a micro failure. An unstable link that flaps excessively can cause other devices in the network to consume substantial processing resources, and that can cause routing protocols to lose synchronization with the state of the flapping link.

The BFD Dampening feature introduces a configurable exponential delay mechanism. This mechanism is designed to suppress the excessive effect of remote node reachability events flapping with BFD. The BFD Dampening feature allows the network operator to automatically dampen a given BFD session to prevent excessive notification to BFD clients, thus preventing unnecessary instability in the network. Dampening the notification to a BFD client suppresses BFD notification until the time the session under monitoring stops flapping and becomes stable.

Configuring the BFD Dampening feature, especially on a high-speed interface with routing clients, improves convergence time and stability throughout the network. BFD dampening can be applied to all types of BFD sessions, including IPv4/single-hop, Multiprotocol Label Switching-Transport Profile (MPLS-TP), and Pseudo Wire (PW) Virtual Circuit Connection Verification (VCCV).

### BFD Session Dampening

You can configure the BFD Dampening feature at the BFD template level (single-hop template). Dampening is applied to all the sessions that use the BFD template. If you choose not to have a session to be dampened, you should use a new BFD template without dampening for a new session. By default, the dampening functionality is not enabled on a template.

## BFD Hardware Offload Support for IPv4

The Bidirectional Forwarding detection (BFD) Hardware Offload feature enables the offload of a BFD session to the network processing units of the line cards, in an IPv4 network. BFD hardware offload improves scale and reduces the overall network convergence time by sending rapid failure detection packets to the routing protocols for recalculating the routing table.

### Restrictions

- This feature is not supported over MPLS LDP interface, VRRP interface, BVI interface and IRB interface.

### Configuration Example

```

/* Configure BFD over Bundle(BOB) for hardware offload. */
Router# config
Router(config)# interface Bundle-Ether 1
Router(config-if)# bfd mode ietf
Router(config-if)# bfd address-family ipv4 multiplier 3
Router (config-if)# bfd address-family ipv4 destination 10.20.20.1
Router (config-if)# bfd address-family ipv4 fast-detect
Router(config-if)# bfd address-family ipv4 minimum-interval 1200
Router(config-if)# ipv4 address 10.20.20.2/30

/* Configure BFD with a static route. */
Router(config)# router static
Router(config-static)# address-family ipv4 unicast 10.1.1.0/24 10.6.0.2 bfd fast-detect
minimum-interval 1200 multiplier 4

/* Configure BFD with IS-IS. */
Router(config)# router isis 65444
Router(config-isis)# address-family ipv4 unicast
Router(config-isis)# exit
Router(config-isis)# interface HundredGige 0/3/0/1
Router(config-isis-if)# bfd minimum-interval 1200
Router(config-isis-if)# bfd multiplier 7
Router(config-isis-if)# bfd fast-detect ipv4
Router(config-isis-if)# address-family ipv4 unicast

/* Configure BFDv4 with OSPF. */
Router(config)# router ospf main
Router(config-ospfv3)# area 0
Router(config-ospfv3-ar)# interface HundredGige 0/0/0/1
Router(config-ospfv3-ar-if)# bfd multiplier 7
Router(config-ospfv3-ar-if)# bfd fast-detect
Router(config-ospfv3-ar-if)# bfd minimum-interval 1200

/* Configuring BFD over BGP. */
Router(config)# router bgp 120
Router(config-bgp)# neighbor 10.6.6.1
Router(config-bgp-nbr)# bfd fast-detect
Router(config-bgp-nbr)# bfd multiplier 7
Router(config-bgp-nbr)# bfd minimum-interval 1200

```

### Verification

Use the **show bfd ipv4 session** command to verify the configuration:

```

Router# show bfd ipv4 session

```

| Interface     | Dest Addr  | Local Echo | det time(int*mult)  | State          |
|---------------|------------|------------|---------------------|----------------|
|               |            |            | Async H/W           | NPU            |
| Hu0/0/0/22.93 | 10.20.20.1 | 0s (0s*0)  | 12ms (4ms*3)<br>Yes | UP<br>0/0/CPU0 |

## BFD Hardware Offload Support for IPv6

The Bidirectional Forwarding detection (BFD) Hardware Offload feature enables the offload of a BFD session to the network processing units of the line cards, in an IPv6 network. BFD hardware offload feature improves scale and reduces the overall network convergence time by sending rapid failure detection packets to the routing protocols for recalculating the routing table.

## Restrictions

- This feature is not supported over MPLS LDP interface, VRRP interface, BVI interface and IRB interface.
- BFD Dampening is not supported for BFD over IPv6.
- BFD over Bundle (BOB) over IPv6 is not supported with dynamically configured link-local address. It must be statically configured.

## Configuration Example

```
/* Configure BFD over Bundle(BOB) for hardware offload. */
Router# config
Router(config)# interface Bundle-Ether 1
Router(config-if)# bfd mode ietf
Router(config-if)# bfd address-family ipv6 multiplier 3
Router (config-if)# bfd address-family ipv6 destination 10.20:20::1
Router (config-if)# bfd address-family ipv6 fast-detect
Router(config-if)# bfd address-family ipv6 minimum-interval 1200
Router(config-if)# ipv6 address 10:20:20::2/64

/* Configure BFD with a static route. */
Router(config)# router static
Router(config-static)# address-family ipv6 unicast 1011:17e4::1/128 ab11:15d2::2 bfd
fast-detect minimum-interval 1200 multiplier 3

/* Configure BFD with IS-IS. */
Router(config)# router isis 65444
Router(config-isis)# address-family ipv6 unicast
Router(config-isis)# exit
Router(config-isis)# interface HundredGige 0/3/0/1
Router(config-isis-if)# bfd minimum-interval 1200
Router(config-isis-if)# bfd multiplier 7
Router(config-isis-if)# bfd fast-detect ipv6
Router(config-isis-if)# address-family ipv6 unicast

/* Configure BFDv6 with OSPFv3. */
Router(config)# router ospfv3 main
Router(config-ospfv3)# area 0
Router(config-ospfv3-ar)# interface HundredGige 0/0/0/1
Router(config-ospfv3-ar-if)# bfd multiplier 7
Router(config-ospfv3-ar-if)# bfd fast-detect
Router(config-ospfv3-ar-if)# bfd minimum-interval 1200

/* Configuring BFD over BGP. */
Router(config)# router bgp 120
Router(config-bgp)# neighbor 2001:DB8:1::1
Router(config-bgp-nbr)# bfd fast-detect
Router(config-bgp-nbr)# bfd multiplier 7
Router(config-bgp-nbr)# bfd minimum-interval 1200
```

## Verification

Use the **show bfd ipv6 session** command to verify the configuration:

```
Router# show bfd ipv6 session
Interface          Dest Addr
-----
H/W                NPU          Echo          Async          State
-----
BE7.2              fe80::28a:96ff:fed6:9cdb
Yes                0/0/CPU0     0s(0s*0)      900ms(300ms*3)  UP
```

BE7.4  
Yes

fe80::28a:96ff:fed6:9cdb  
0/0/CPU0 0s (0s\*0)

900ms (300ms\*3) UP

# BFD multipath sessions

**Table 3: Feature History Table**

| Feature Name           | Release        | Description  |
|------------------------|----------------|--|
| BFD multipath sessions | Release 25.1.1 | Introduced in this release on: Fixed Systems ( 8010 [ASIC: A100])<br><br>This feature is now supported on: <ul style="list-style-type: none"> <li>• 8011-4G24Y4H-I</li> </ul>  |
| BFD multipath sessions | Release 24.4.1 | Introduced in this release on: Fixed Systems ( 8700).<br><br>This feature enables rapid detection of faults across multiple paths between network devices by allowing multiple BFD sessions to monitor different paths between two devices.<br><br>This feature is now supported on: <ul style="list-style-type: none"> <li>• 8712-MOD-M</li> <li>• 8711-32FH-M</li> </ul> |

BFD can be applied over virtual interfaces such as GRE tunnel interfaces, PWHE interfaces, or between interfaces that are multihops away as described in the [IPv4 multihop BFD, on page 9](#) section. These types of BFD sessions are referred to BFD Multipath sessions.

As long as one path to the destination is active, these events may or may not cause the BFD Multipath session to fail as it depends on the interval negotiated versus the convergence time taken to update forwarding plane:

- Failure of a path
- Online insertion or removal (OIR) of a line card which hosts one or more paths
- Removal of a link (by configuration) which constitutes a path
- Shutdown of a link which constitutes a path

You must configure **bfd multipath include location** *location-id* command to enable at least one line card for the underlying mechanism that can be used to send and receive packets for the multipath sessions.

If a BFD Multipath session is hosted on a line card that is being removed from the **bfd multipath include** configuration, online removed, or brought to maintenance mode, then BFD attempts to migrate all BFD Multipath sessions hosted on that line card to another one. In that case, static routes are removed from RIB and then the BFD session is established again and included to RIB.



In case of BFD multipath sessions, the input and output interface may change based on the routing table updates. If the multipath session BFD packets must get preferential treatment, then a QoS policy must be configured on the entire path, including the possible input and output interfaces of the router.

The QoS policy must classify ingress and egress BFD packets into priority level 1 or priority level 2 queue. Similar approach applies to BFD sessions on BVI and "BFD Over VLAN Over Bundle" (that is, BLB).

## IPv4 multihop BFD

*Table 4: Feature History Table*

| Feature Name      | Release         | Description   |
|-------------------|-----------------|---|
| IPv4 multihop BFD | Release 25.1.1  | Introduced in this release on: Fixed Systems ( 8010 [ASIC: A100])<br><br>This feature is now supported on:<br><ul style="list-style-type: none"> <li>• 8011-4G24Y4H-I</li> </ul>  |
| IPv4 multihop BFD | Release 24.4.1  | Introduced in this release on: Fixed Systems( 8700) (select variants only*).<br><br>*This feature is now supported on:<br><ul style="list-style-type: none"> <li>• 8712-MOD-M</li> <li>• 8711-32FH-M</li> </ul>   |
| IPv4 multihop BFD | Release 24.2.11 | Introduced in this release on: Modular Systems (8800 [LC ASIC: P100]) (select variants only*).<br><br>This feature ensures rapid identification and resolution of network issues by providing sub-second failure detection for remote destinations up to 255 hops away. It supports BFD sessions between addresses on different nodes, such as PE and CE loopback addresses or routers that are several TTL hops apart.<br><br>*This feature is now supported on routers with 88-LC1-36EH line cards. |

IPv4 Multihop BFD is a BFD session between two addresses between two nodes. An example of this feature is a BFD session between PE and CE loopback addresses or BFD sessions between routers that are several TTL hops away. The applications that support IPv4 Multihop BFD are external and internal BGP. IPv4 Multihop BFD feature supports BFD on arbitrary paths, which can span multiple network hops.

The IPv4 Multihop BFD feature provides sub-second forwarding failure detection for a destination more than one hop, and up to 255 hops, away. The **bfd multihop ttl-drop-threshold** command can be used to drop BFD packets coming from neighbors exceeding a certain number of hops.

### Configure IPv4 Multihop BFD

This section describes how you can configure IPv4 Multihop BFD feature.

```
Router# configure
Router(config)# bfd
Router(config)# multihop ttl-drop-threshold 225
Router(config)# multipath include location 0/7/CPU0
Router(config)# router bgp 100
Router(config-bgp)# neighbor 209.165.200.225
Router(config-bgp-nbr)# remote-as 2000
Router(config-bgp-nbr)# update-source loopback 1
Router(config-bgp-nbr)# bfd fast-detect
Router(config-bgp-nbr)# bfd multiplier 3
Router(config-bgp-nbr)# bfd minimum-interval 1200
Router(config-bgp-nbr-af)# route-policy pass-all in
Router(config-bgp-nbr-af)# route-policy pass-all out
Router(config-bgp-nbr-af)# commit
```

### Running Configuration

```
bfd
 multihop ttl-drop-threshold 225
 multipath include location 0/7/CPU0
router bgp 100
 neighbor 209.165.200.225
  remote-as 2000
  update-source loopback 1
  bfd fast-detect
  bfd multiplier 3
  bfd minimum-interval 1200
    route-policy PASS-ALL in
    route-policy PASS-ALL out
!
```

### Verification

The show outputs given in the following section display the details of the configuration of the IPv4 Multihop BFD feature, and the status of their configuration.

```
Router# show tech-support bfdhwoff
harddisk:
Tue Mar 20 11:20:29.214 PDT
++ Show tech start time: 2018-Mar-20.112029.PDT ++
Tue Mar 20 11:20:30 PDT 2018 Waiting for gathering to complete .....
Tue Mar 20 11:22:37 PDT 2018 Compressing show tech output Show tech output available at
0/RP0/CPU0 :
/harddisk:/showtech-bfd-hwoff-platform-2018-Mar-20.112029.PDT.tgz
++ Show tech end time: 2018-Mar-20.112237.PDT ++
```

# Configure BFD

## Configure BFD Under a Dynamic Routing Protocol or Use a Static Route

To establish a BFD neighbor, complete at least one of the following procedures to configure BFD under a dynamic routing protocol or to use a static route:

### Enabling BFD on a BGP neighbor

*Table 5: Feature History Table*

| Feature Name          | Release         | Description  |
|-----------------------|-----------------|--|
| BFD on a BGP neighbor | Release 25.1.1  | Introduced in this release on: Fixed Systems ( 8010 [ASIC: A100])<br><br>This feature is now supported on:<br><ul style="list-style-type: none"> <li>• 8011-4G24Y4H-I</li> </ul>   |
| BFD on a BGP neighbor | Release 24.4.1  | Introduced in this release on: Fixed Systems( 8700) (select variants only*).<br><br>*This feature is now supported on:<br><ul style="list-style-type: none"> <li>• 8712-MOD-M</li> <li>• 8711-32FH-M</li> </ul>  |
| BFD on a BGP neighbor | Release 24.2.11 | Introduced in this release on: Modular Systems (8800 [LC ASIC: P100]) (select variants only*).<br><br>This feature allows BGP to quickly reroute traffic when a link failure is detected, ensuring minimal disruption to network services and enhancing overall network reliability and stability.<br><br>*This feature is now supported on routers with 88-LC1-36EH line cards. |

BFD can be enabled per neighbor, or per interface. This task describes how to enable BFD for BGP on a neighbor router.

### Procedure

#### Step 1 configure

**Example:**

```
RP/0/# configure
```

Enters mode.

**Step 2** **router bgp** *autonomous-system-number***Example:**

```
RP/0/RP0/CPU0:router(config)# router bgp 120
```

Enters BGP configuration mode, allowing you to configure the BGP routing process.

**Step 3** **neighbor** *ip-address***Example:**

```
RP/0/RP0/CPU0:router(config-bgp)# neighbor 172.168.40.24
```

Places the router in neighbor configuration mode for BGP routing and configures the neighbor IP address as a BGP peer.

This example configures the IP address 172.168.40.24 as a BGP peer.

**Step 4** **remote-as** *autonomous-system-number***Example:**

```
RP/0/RP0/CPU0:router(config-bgp-nbr)# remote-as 2002
```

Creates a neighbor and assigns it a remote autonomous system.

This example configures the remote autonomous system to be 2002.

**Step 5** **bfd fast-detect****Example:**

```
RP/0/RP0/CPU0:router(config-bgp-nbr)# bfd fast-detect
```

Enables BFD between the local networking devices and the neighbor whose IP address you configured to be a BGP peer in Step 3.

In the example in Step 3, the IP address 172.168.40.24 was set up as the BGP peer. In this example, BFD is enabled between the local networking devices and the neighbor 172.168.40.24.

**Step 6** **bfd minimum-interval** *milliseconds***Example:**

```
RP/0/RP0/CPU0:router(config-bgp-nbr)# bfd minimum-interval 1200
```

Sets the BFD minimum interval. Range is 3-1200 milliseconds.

**Step 7** **bfd multiplier** *multiplier***Example:**

```
RP/0/RP0/CPU0:router(config-bgp-nbr)# bfd multiplier 7
```

Sets the BFD multiplier. This is optional, the minimum is 3 and by default the multiplier will be 3 for all protocols

**Step 8** Use the **commit** or **end** command.

**commit** —Saves the configuration changes and remains within the configuration session.

**end** —Prompts user to take one of these actions:

- **Yes** — Saves configuration changes and exits the configuration session.
- **No** —Exits the configuration session without committing the configuration changes.
- **Cancel** —Remains in the configuration session, without committing the configuration changes.

## Enabling BFD for OSPF on an interface

*Table 6: Feature History Table*

| Feature Name           | Release         | Feature Description  |
|------------------------|-----------------|--|
| BFD for OSPF and IS-IS | Release 25.1.1  | Introduced in this release on: Fixed Systems ( 8010 [ASIC: A100])<br>This feature is now supported on:<br><ul style="list-style-type: none"> <li>• 8011-4G24Y4H-I</li> </ul>   |
| BFD for OSPF and IS-IS | Release 24.4.1  | Introduced in this release on: Fixed Systems( 8700) (select variants only*).<br>*This feature is now supported on:<br><ul style="list-style-type: none"> <li>• 8712-MOD-M</li> <li>• 8711-32FH-M</li> </ul>  |
| BFD for OSPF and IS-IS | Release 24.2.11 | Introduced in this release on: Modular Systems (8800 [LC ASIC: P100]) (select variants only*).<br>This feature quickly detects link failures between adjacent routers, allowing OSPF or IS-IS to reroute traffic swiftly and maintain optimal network performance. This rapid failure detection minimizes downtime and improves overall network reliability.<br>*This feature is now supported on routers with 88-LC1-36EH line cards. |

Perform the following steps to configure BFD for Open Shortest Path First (OSPF) on an interface. The steps in the procedure are common to the steps for configuring BFD on Intermediate System-to-Intermediate System (IS-IS); only the command mode differs.



---

**Note** BFD per interface configuration is supported for OSPF and IS-IS only.

---

```
Router# configure

/* Enter OSPF configuration mode to configure the OSPF routing process. */
Router(config)# router ospf 0

/* Set the BFD minimum interval. The range is from 3 to 1200 milliseconds. */
Router(config-ospf)# bfd minimum-interval 1200

/* Set the BFD multiplier. */
Router(config-ospf)# bfd multiplier 7

/* Configure an Open Shortest Path First (OSPF) area. */
Router(config-ospf)# area 0

/* Enter interface configuration mode. */
Router(config-ospf-ar)# interface HundredGige 0/3/0/1

/* Enable BFD to detect failures in the path between adjacent forwarding engines. */
Router(config-ospf-ar-if)# bfd fast-detect
```

### Running Configuration

```
configure
router ospf 0
bfd minimum-interval 1200
bfd multiplier 7
area 0
interface HundredGige 0/3/0/1
bfd fast-detect
```

### Verification

Verify that BFD is enabled on the appropriate interface.

```
Router(config-ospf-ar-if)# show run router ospf

router ospf 0
bfd minimum-interval 1200
bfd multiplier 7
area 0
interface HundredGige 0/3/0/1
bfd fast-detect
```

## Enabling BFD on a static route

*Table 7: Feature History Table*

| Feature Name          | Release         | Feature Description   |
|-----------------------|-----------------|---|
| BFD on a static route | Release 25.1.1  | Introduced in this release on: Fixed Systems ( 8010 [ASIC: A100])<br><br>This feature is now supported on:<br><ul style="list-style-type: none"> <li>• 8011-4G24Y4H-I</li> </ul>  |
| BFD on a static route | Release 24.4.1  | Introduced in this release on: Fixed Systems( 8700) (select variants only*).<br><br>*This feature is now supported on:<br><ul style="list-style-type: none"> <li>• 8712-MOD-M</li> <li>• 8711-32FH-M</li> </ul>   |
| BFD on a static route | Release 24.2.11 | Introduced in this release on: Modular Systems (8800 [LC ASIC: P100]) (select variants only*).<br><br>This feature enhances network reliability by quickly detecting link failures and dynamically adding or removing static routes from the Routing Information Base (RIB) based on the BFD session status. This rapid failure detection ensures continuous route availability and minimizes network downtime.<br><br>*This feature is now supported on routers with 88-LC1-36EH line cards. |

The following procedure describes how to enable BFD on a static route.

```
Router(config)# configure
```

```
/*Enter static route configuration mode, and configure static routing. */
Router(config)# router static
```

```
/*Enter address family configuration mode. */
Router(config-static)# address-family ipv4 unicast 192.168.2.2/32
```

```
/*Specify an unicast destination address and next-hop IPv4 address.
Enable BFD fast-detection on the specified IPv4 unicast destination address */
Router(config-static)# 192.168.2.2 192.168.6.2 bfd fast-detect minimum-interval 1200
multiplier 3
```

**Running Configuration**

```
router static
 address-family ipv4 unicast
  192.168.2.2 192.168.6.2 bfd fast-detect minimum-interval 1200 multiplier 3
!
```

**Specifying the BFD Destination Address on a Bundle**

To specify the BFD destination address on a bundle, complete these steps:

**Procedure****Step 1** **configure****Example:**

```
RP/0/# configure
```

Enters mode.

**Step 2** **interface Bundle-Ether** *bundle-id***Example:**

```
RP/0/RP0/CPU0:router(config)# interface Bundle-Ether 1
```

Enters interface configuration mode for the specified bundle ID.

**Step 3** **bfd address-family ipv4 destination** *ip-address***Example:**

```
RP/0/RP0/CPU0:router(config-if)# bfd address-family ipv4 destination 10.20.20.1
```

Specifies the primary IPv4 address assigned to the bundle interface on a connected remote system, where *ip-address* is the 32-bit IP address in dotted-decimal format (A.B.C.D).

**Step 4** Use the **commit** or **end** command.

**commit** —Saves the configuration changes and remains within the configuration session.

**end** —Prompts user to take one of these actions:

- **Yes** — Saves configuration changes and exits the configuration session.
- **No** —Exits the configuration session without committing the configuration changes.
- **Cancel** —Remains in the configuration session, without committing the configuration changes.

**Enabling BFD Sessions on Bundle Members**

To enable BFD sessions on bundle member links, complete these steps:



## SUMMARY STEPS

1. **configure**
2. **interface Bundle-Ether** *bundle-id*
3. **bfd address-family ipv4 fast-detect**
4. Use the **commit** or **end** command.

## DETAILED STEPS

### Procedure

---

**Step 1** **configure****Example:**

```
RP/0/# configure
```

Enters mode.

**Step 2** **interface Bundle-Ether** *bundle-id***Example:**

```
Router(config)# interface Bundle-Ether 1
```

Enters interface configuration mode for the specified bundle ID.

**Step 3** **bfd address-family ipv4 fast-detect****Example:**

```
Router(config-if)# bfd address-family ipv4 fast-detect
```

Enables IPv4 BFD sessions on bundle member links.

**Step 4** Use the **commit** or **end** command.

**commit** —Saves the configuration changes and remains within the configuration session.

**end** —Prompts user to take one of these actions:

- **Yes** — Saves configuration changes and exits the configuration session.
  - **No** —Exits the configuration session without committing the configuration changes.
  - **Cancel** —Remains in the configuration session, without committing the configuration changes.
- 

## Configuring the Minimum Thresholds for Maintaining an Active Bundle

The bundle manager uses two configurable minimum thresholds to determine whether a bundle can be brought up or remain up, or is down, based on the state of its member links.

- Minimum active number of links
- Minimum active bandwidth available

Whenever the state of a member changes, the bundle manager determines whether the number of active members or available bandwidth is less than the minimum. If so, then the bundle is placed, or remains, in DOWN state. Once the number of active links or available bandwidth reaches one of the minimum thresholds, then the bundle returns to the UP state.

To configure minimum bundle thresholds, complete these steps:

## Procedure

**Step 1** **configure**

**Step 2** **interface Bundle-Ether** *bundle-id*

**Example:**

```
RP/0/RP0/CPU0:router(config)# interface Bundle-Ether 1
```

Enters interface configuration mode for the specified bundle ID.

**Step 3** **bundle minimum-active bandwidth** *kbps*

**Example:**

```
RP/0/RP0/CPU0:router(config-if)# bundle minimum-active bandwidth 580000
```

Sets the minimum amount of bandwidth required before a bundle can be brought up or remain up. The range is from 1 through a number that varies depending on the platform and the bundle type.

**Step 4** **bundle minimum-active links** *links*

**Example:**

```
RP/0/RP0/CPU0:router(config-if)# bundle minimum-active links 2
```

Sets the number of active links required before a bundle can be brought up or remain up. The range is from 1 to 32.

**Note**

When BFD is started on a bundle that is already active, the BFD state of the bundle is declared when the BFD state of all the existing active members is known.

**Step 5** **commit**

## Configuring BFD Packet Transmission Intervals and Failure Detection Times on a Bundle

BFD asynchronous packet intervals and failure detection times for BFD sessions on bundle member links are configured using a combination of the **bfd address-family ipv4 minimum-interval** and **bfd address-family ipv4 multiplier** interface configuration commands on a bundle.

The BFD control packet interval is configured directly using the **bfd address-family ipv4 minimum-interval** command. The failure detection times are determined by a combination of the interval and multiplier values in these commands.

To configure the minimum transmission interval and failure detection times for BFD asynchronous mode control packets on bundle member links, complete these steps:

## Procedure

**Step 1**      **configure**

**Step 2**      **interface Bundle-Ether** *bundle-id*

**Example:**

```
RP/0/RP0/CPU0:router(config)# interface Bundle-Ether 1
```

Enters interface configuration mode for the specified bundle ID.

**Step 3**      **bfd address-family ipv4 minimum-interval** *milliseconds*

**Example:**

```
RP/0/RP0/CPU0:router(config-if)#bfd address-family ipv4 minimum-interval 1200
```

**Note**

Specifies the minimum interval, in milliseconds, for asynchronous mode control packets on IPv4 BFD sessions on bundle member links. The range is from 3 to 1200.

**Step 4**      **bfd address-family ipv4 multiplier** *multiplier*

**Example:**

```
RP/0/RP0/CPU0:router(config-if)#bfd address-family ipv4 multiplier 30
```

Specifies a number that is used as a multiplier with the minimum interval to determine BFD control packet failure detection times and transmission intervals for IPv4 BFD sessions on bundle member links.

**Note**

Although the command allows you to configure a minimum of 2, the supported minimum is 3.

**Step 5**      **commit**

## Configure BFD over Bundles IETF Mode Support on a Per Bundle Basis

To configure BFD over Bundles IETF mode support on a per bundle basis use these steps:

## Procedure

**Step 1**      **configure**

**Step 2**      **interface Bundle-Ether** *bundle-id*

**Example:**

```
RP/0/RP0/CPU0:router(config)# interface Bundle-Ether 1
```

Enters interface configuration mode for the specified bundle ID.

**Step 3**      **bfd mode ietf**

**Example:**

```
RP/0/RP0/CPU0:router(config-if)# bfd mode ietf
```

Enables IETF mode for BFD over bundle for the specified bundle.

**Step 4**     **bfd address-family ipv4 fast-detect**

**Example:**

```
RP/0/RP0/CPU0:router(config-if)# bfd address-family ipv4 fast-detect
```

Enables IPv4 BFD sessions on the specified bundle.

**Step 5**     commit

**Step 6**     **show bundle bundle-ether** *bundle-id*

Displays the selected bundle mode.

## Enabling echo mode to test the forwarding path to a BFD peer

*Table 8: Feature History Table*

| Feature Name  | Release        | Feature Description  |
|---------------|----------------|--|
| BFD echo mode | Release 25.1.1 | Introduced in this release on: Fixed Systems ( 8010 [ASIC: A100])<br><br>This feature is now supported on:<br><ul style="list-style-type: none"> <li>• 8011-4G24Y4H-I</li> </ul>   |
| BFD echo mode | Release 24.4.1 | Introduced in this release on: Fixed Systems( 8700).<br><br>BFD echo mode improves link failure detection by sending echo packets at fast rates, eliminating the need for frequent control packet checks. When enabled, BFD sessions on physical interfaces send control packets every two seconds, while echo packets are sent more frequently to detect link failures.<br><br>This feature is now supported on:<br><ul style="list-style-type: none"> <li>• 8712-MOD-M</li> <li>• 8711-32FH-M</li> </ul> |

BFD echo mode is enabled by default for IPv4 on other physical interfaces whose minimum interval is less than three seconds.



**Note** When BFD echo mode is enabled for IPv4, the maximum supported number of BFDv4 single-hop sessions is reduced by 50%.

This limitation does not apply to BFDv6 or BFDv4 multi-hop sessions.

If you have configured a BFD minimum interval greater than three seconds on a physical interface using the **bfd minimum-interval** command, then you will need to change the interval to be less than three seconds to support and enable echo mode. This does not apply to bundle member links, which always support echo mode.

## Overriding the Default Echo Packet Source Address

If you do not specify an echo packet source address, then BFD uses the IP address of the output interface as the default source address for an echo packet.

You can use the **echo ipv4 source** command in BFD or interface BFD configuration mode to specify the IP address that you want to use as the echo packet source address.

You can override the default IP source address for echo packets for BFD on the entire router, or for a particular interface.

## Specifying the Echo Packet Source Address Globally for BFD

To specify the echo packet source IP address globally for BFD on the router, complete the following steps:

### Procedure

#### Step 1 **configure**

##### Example:

```
RP/0/# configure
```

Enters mode.

#### Step 2 **bfd**

##### Example:

```
Router(config)# bfd
```

Enters BFD configuration mode.

#### Step 3 **echo ipv4 source *ip-address***

##### Example:

```
Router(config-bfd)# echo ipv4 source 10.10.10.1
```

Specifies an IPv4 address to be used as the source address in BFD echo packets, where *ip-address* is the 32-bit IP address in dotted-decimal format (A.B.C.D).

#### Step 4 Use the **commit** or **end** command.

**commit** —Saves the configuration changes and remains within the configuration session.

**end** —Prompts user to take one of these actions:

- **Yes** — Saves configuration changes and exits the configuration session.
- **No** —Exits the configuration session without committing the configuration changes.
- **Cancel** —Remains in the configuration session, without committing the configuration changes.

## Specifying the Echo Packet Source Address on an Individual Interface

To specify the echo packet source IP address on an individual BFD interface, complete the following steps:

### Procedure

#### Step 1 **configure**

**Example:**

```
RP/0/# configure
```

Enters mode.

#### Step 2 **bfd**

**Example:**

```
Router(config)# bfd
```

Enters BFD configuration mode.

#### Step 3 **interface type interface-path-id**

**Example:**

```
Router(config-bfd)# interface HundredGige 0/1/5/0
```

Enters BFD interface configuration mode for a specific interface. In BFD interface configuration mode, you can specify an IPv4 address on an individual interface.

#### Step 4 **echo ipv4 source *ip-address***

**Example:**

```
Router(config-bfd)# echo ipv4 source 10.10.10.1
```

Specifies an IPv4 address to be used as the source address in BFD echo packets, where *ip-address* is the 32-bit IP address in dotted-decimal format (A.B.C.D).

#### Step 5 Use the **commit** or **end** command.

**commit** —Saves the configuration changes and remains within the configuration session.

**end** —Prompts user to take one of these actions:

- **Yes** — Saves configuration changes and exits the configuration session.
- **No** — Exits the configuration session without committing the configuration changes.
- **Cancel** — Remains in the configuration session, without committing the configuration changes.

---

## Disabling Echo Mode

BFD does not support asynchronous operation in echo mode in certain environments.

You can disable echo mode for BFD on the entire router, or for a particular interface.

### Disabling Echo Mode on a Router

To disable echo mode globally on the router complete the following steps:

#### DETAILED STEPS

#### Procedure

---

**Step 1**     **configure**

**Step 2**     **bfd**

**Example:**

```
Router(config)# bfd
```

Enters BFD configuration mode.

**Step 3**     **echo disable**

**Example:**

```
Router(config-bfd)# echo disable
```

Disables echo mode on the router.

**Step 4**     **commit**

---

### Disabling Echo Mode on an Individual Interface

The following procedures describe how to disable echo mode on an interface.

#### Procedure

---

**Step 1**     **configure**

**Example:**

```
RP/0/# configure
```

Enters mode.

## Step 2    **bfd**

### **Example:**

```
Router(config)# bfd
```

Enters BFD configuration mode.

## Step 3    **interface** *type interface-path-id*

### **Example:**

```
Router(config-bfd)# interface HundredGige 0/1/5/0
```

Enters BFD interface configuration mode for a specific interface. In BFD interface configuration mode, you can disable echo mode on an individual interface.

## Step 4    **echo disable**

### **Example:**

```
Router(config-bfd-if)# echo disable
```

Disables echo mode on the specified individual interface.

## Step 5    **commit**

# Minimizing BFD Session Flapping Using BFD Dampening

To configure BFD dampening to control BFD session flapping, complete the following steps.

## Procedure

## Step 1    **configure**

### **Example:**

```
RP/0/# configure
```

Enters mode.

## Step 2    **bfd**

### **Example:**

```
Router(config)# bfd
```

Enters BFD configuration mode.

## Step 3    **dampening** [**bundle-member**] {**initial-wait** | **maximum-wait** | **secondary-wait**} *milliseconds*



**Example:**

```
Router(config-bfd)# dampening initial-wait 30000
```

Specifies delays in milliseconds for BFD session startup to control flapping.

The value for **maximum-wait** should be greater than the value for **initial-wait**.

The dampening values can be defined for bundle member interfaces and for the non-bundle interfaces.

**Step 4** Use the **commit** or **end** command.

**commit** —Saves the configuration changes and remains within the configuration session.

**end** —Prompts user to take one of these actions:

- **Yes** — Saves configuration changes and exits the configuration session.
- **No** —Exits the configuration session without committing the configuration changes.
- **Cancel** —Remains in the configuration session, without committing the configuration changes.

---

## Clear and Display BFD Counters

The following procedure describes how to display and clear BFD packet counters. You can clear packet counters for BFD sessions that are hosted on a specific node or on a specific interface.

```
Router# show bfd counters all packet location 0/3/cpu0
Router# clear bfd counters all packet location 0/3/cpu0
Router# show bfd counters all packet location 0/3/cpu0
```

## BFD IPv6 in Bundle Manager Domain

A configuration to enable or disable BFD to run over a bundle interface can be in the bundle manager domain. The bundle manager can apply these configuration changes, and based on the configuration changes, request the BFD server to enable or disable BFD on certain bundle interfaces and a member links related to those bundle interfaces.

## BFD Over BGP: Example

The following example shows how to configure BFD between autonomous system 1200 and neighbor 192.168.70.24:

```
Router#configure
Router#(config)#router bgp 1200
Router#(config-bgp)#bfd multiplier 2
Router#(config-bgp)#bfd minimum-interval 1200
Router#(config-bgp)#neighbor 192.168.70.24
Router#(config-bgp-nbr)#remote-as 2
Router#(config-bgp-nbr)#bfd fast-detect
Router#(config-bgp-nbr)#commit
Router#(config-bgp-nbr)#end
Router##show run router bgp
```

## BFD Over OSPF: Example

The following example shows how to enable BFD for OSPF on a HundredGigE interface:

```
Router#configure
Router#(config)#router ospf 0
Router#(config-ospf)#area 0
Router#(config-ospf-ar)#interface HundredGige 0/3/0/1
Router#(config-ospf-ar-if)#bfd fast-detect
Router#(config-ospf-ar-if)#commit
Router#(config-ospf-ar-if)#end

Router#show run router ospf

router ospf 0
area 0
interface HundredGige 0/3/0/1
bfd fast-detect
```

## BFD Over Static Routes: Example

The following example shows how to enable BFD on an IPv4 static route. In this example, BFD sessions are established with the next-hop 10.3.3.3 when it becomes reachable.

```
Router#configure
Router#(config)#router static
Router#(config-static)#address-family ipv4 unicast
Router#(config-static)#10.2.2.0/24 10.3.3.3 bfd fast-detect
Router#(config-static)#end
```

## BFD Echo Mode Disable: Examples

The following example shows how to disable echo mode on a router:

```
Router#configure
Router#(config)#bfd
Router#r(config-bfd)#echo disable
```

The following example shows how to disable echo mode on an interface:

```
Router##configure
Router#(config)#bfd
Router#(config-bfd)#interface HundredGige 0/1/0/0
Router#(config-bfd-if)#echo disable
```

## Echo Packet Source Address: Examples

The following example shows how to specify the IP address 10.10.10.1 as the source address for BFD echo packets for all BFD sessions on the router:

```
Router#configure
Router#(config)#bfd
```

```
Router(config-bfd)#echo ipv4 source 10.10.10.1
```

The following example shows how to specify the IP address 10.10.10.1 as the source address for BFD echo packets on an individual HundredGige Ethernet interface:

```
Router#configure
Router(config)#bfd
Router(config-bfd)#interface HundredGige 0/1/0/0
Router(config-bfd-if)#echo ipv4 source 10.10.10.1
```

## BFD Dampening: Examples

The following example shows how to configure an initial and maximum delay for BFD session startup on BFD bundle members:

```
Router#configure
Router(config)#bfd
Router(config-bfd)#dampening bundle-member initial-wait 8000
Router(config-bfd)#dampening bundle-member maximum-wait 15000
```

The following example shows how to change the default initial-wait for BFD on a non-bundle interface:

```
Router#configure
Router(config)#bfd
Router(config-bfd)#dampening initial-wait 30000
Router(config-bfd)#dampening maximum-wait 35000
```

## BFD hardware offload for RSVP tail-end

*Table 9: Feature History Table*

| Feature Name  | Release        | Description  |
|---|----------------|--|
| BFD hardware offload for resource reservation protocol tail-end | Release 25.1.1 | Introduced in this release on: Fixed Systems ( 8010 [ASIC: A100])<br><br>This feature is now supported on:<br><ul style="list-style-type: none"> <li>• 8011-4G24Y4H-I</li> </ul> |

| Feature Name  | Release        | Description  |
|---|----------------|--|
| BFD hardware offload for resource reservation protocol tail-end | Release 24.4.1 | <p>Introduced in this release on: Fixed Systems( 8700).</p> <p>This feature that can detect Multiprotocol Label Switching (MPLS) Label Switched Path (LSP) data plane failures is now supported on the following hardware.</p> <p>This feature is now supported on:</p> <ul style="list-style-type: none"> <li>• 8712-MOD-M</li> <li>• 8711-32FH-M</li> </ul>  |
| BFD hardware offload for resource reservation protocol tail-end | Release 7.9.1  | <p>You can use Bidirectional Forwarding Detection (BFD) to detect Multiprotocol Label Switching (MPLS) Label Switched Path (LSP) data plane failures.</p> <p>This feature improves the scale and reduces the overall network convergence time by sending rapid failure detection packets to the routing protocols for recalculating the routing table.</p> <p>BFD process interacts with the Tail-End and LSPV processes to support BFD over Tail-End LSP feature. MPLS TE automatically establishes and maintains the LSPs across the MPLS network by using the Resource Reservation Protocol (RSVP).</p> |

You can use Bidirectional Forwarding Detection (BFD) to detect Multiprotocol Label Switching (MPLS) Label Switched Path (LSP) data plane failures. An LSP ping request is used for detecting MPLS data plane failures and also for verifying the data plane against the control plane. BFD cannot be used for verifying the data plane against the control plane. However, the control plane processing required for BFD control packets is relatively smaller than the processing required for LSP ping messages. Hence, BFD can be deployed for faster detection of data plane failure (for example, traffic black-holing) for a large number of LSPs.

This feature improves the scale and reduces the overall network convergence time by sending rapid failure detection packets to the routing protocols for recalculating the routing table.

## BFD over MPLS Traffic Engineering LSPs

Bidirectional Forwarding Detection ( BFD) over MPLS Traffic Engineering Label Switched Paths (LSPs) feature in Cisco IOS XR Software detects MPLS Label Switched Path LSP data plane failures. Since the control plane processing required for BFD control packets is relatively smaller than the processing required

for LSP Ping messages, BFD can be deployed for faster detection of data plane failure for a large number of LSPs.

The BFD over MPLS TE LSPs implementation in Cisco IOS XR Software is based on *RFC 5884: Bidirectional Forwarding Detection (BFD) for MPLS Label Switched Paths (LSPs)*. LSP Ping is an existing mechanism for detecting MPLS data plane failures and for verifying the MPLS LSP data plane against the control plane. BFD can be used for detecting MPLS data plane failures, but not for verifying the MPLS LSP data plane against the control plane. A combination of LSP Ping and BFD provides faster data plane failure detection on a large number of LSPs.

The BFD over MPLS Tail-End LSPs is used for networks that have deployed MPLS as the multi service transport and that use BFD as fast failure detection mechanism to enhance network reliability and up time by using BFD as fast failure detection traffic black holing.

BFD process interacts with the Tail-End and LSPV processes to support BFD over TE LSP feature. MPLS Tail-End automatically establishes and maintains the LSPs across the MPLS network by using the Resource Reservation Protocol (RSVP).

To know how MPLS works with RSVP Tail-End, refer to the *MPLS Configuration guide for Cisco 8000 Routers*.

BFD over MPLS Tail-End LSPs support:

- BFD async mode (BFD echo mode is not supported)
- IPv4 only, since MPLS core is IPv4
- BFD packets that carry IP DSCP 6 (Internet Control)
- Use of BFD for TE tunnel bring up, re-optimization, and path protection (Standby and FRR)
- Fastest detection time (3 ms x 3 = 9 ms)
- Optional Periodic LSP ping verification after BFD session is up
- Dampening to hold-down BFD failed path-option

There are two ways in which the BFD packets from tail-end to head-end will be used:

- BFD packets from tail-end to head-end will be IP routed
- BFD packets from tail-end to head-end will be Label Switched if MPLS LDP is available in Core with label path from tail-end to head-end.

## Configuring BFD over MPLS Traffic Engineering LSPs

.

### Enabling BFD Parameters for BFD over TE Tunnels

BFD for TE tunnel is enabled at the head-end by configuring BFD parameters under the tunnel. When BFD is enabled on the already up tunnel, TE waits for the bringup timeout before bringing down the tunnel. BFD is disabled on TE tunnels by default. Perform these tasks to configure BFD parameters and enable BFD over TE Tunnels.




---

**Note** BFD paces the creation of BFD sessions by limiting LSP ping messages to be under 50 PPS to avoid variations in CPU usage.

---

1. Enter global configuration mode.

```
Router#config
```

2. Configure MPLS OAM.

```
Router(config)# mpls oam
```

3. Configure MPLS Traffic Engineering (MPLS TE) tunnel interface and enter into MPLS TE tunnel interface configuration mode.

```
Router(config)#interface tunnel-te 65535
```

4. Enable BFD fast detection.

```
Router(config-if)#bfd fast-detect
```

5. Configure hello interval in milliseconds.

```
Router(config-if)#bfd minimum-interval 500
```




---

**Note** Hello interval range is 3 to 1000 milliseconds. Default hello interval is 100 milliseconds.

---

6. Configure BFD multiplier detection.

```
Router(config-if)#bfd multiplier 5
```




---

**Note** BFD multiplier range is 3 to 10. Default BFD multiplier is 3.

---

7. Commit the changes.

```
Router(config-if)#commit
```

## Configuring BFD Bring up Timeout

Perform these steps to configure BFD bring up timeout interval.

1. Enter global configuration mode.

```
Router#config
```

2. Configure MPLS Traffic Engineering (MPLS TE) tunnel interface and enter into MPLS TE tunnel interface configuration mode.

```
Router(config)#interface tunnel-te 65535
```

3. Enable the time interval (in seconds) to wait for the BFD session to come up.

```
Router(config-if)#bfd bringup-timeout 2400
```



---

**Note** The timeout range is 6 to 3600 seconds. Default bring up timeout interval is 60 seconds.

---

4. Commit the changes.

```
Router(config-if)#commit
```

## Configuring BFD Dampening for TE Tunnels

When BFD session fails to come up, TE exponentially backs off using the failed path-option to avoid signaling churn in the network. Perform these steps to configure dampening intervals to bring the TE tunnel up.

1. Enter global configuration mode.

```
Router# configure
```

2. Configure MPLS Traffic Engineering (MPLS TE) tunnel interface and enter into MPLS TE tunnel interface configuration mode.

```
Router(config)#interface tunnel-te 65535
```

3. Configure the initial delay interval before bringing up the tunnel.

```
Router(config-if)#bfd dampening initial-wait 360000
```



---

**Note** The initial-wait bring up delay time interval range is 1 to 518400000 milliseconds. Default initial-wait interval is 16000 milliseconds.

---

4. Configure the maximum delay interval before bringing up the tunnel.

```
Router(config-if)#bfd dampening maximum-wait 700000
```



---

**Note** The maximum-wait bring up delay time interval range is 1 to 518400000 milliseconds. Default initial-wait interval is 600000 milliseconds.

---

5. Configure the secondary delay interval before bringing up the tunnel.

```
Router(config-if)#bfd dampening secondary-wait 30000
```



---

**Note** The secondary-wait bring up delay time interval range is 1 to 518400000 milliseconds. Default secondary-wait interval is 20000 milliseconds.

---

6. Commit the changes.

```
Router(config-if)#commit
```

## Configuring Periodic LSP Ping Requests

Perform this task to configure sending periodic LSP ping requests with BFD TLV, after BFD session comes up.

1. Enter global configuration mode.

```
Router# configure
```

2. Configure MPLS Traffic Engineering (MPLS TE) tunnel interface and enter into MPLS TE tunnel interface configuration mode.

```
Router(config)#interface tunnel-te 65535
```

3. Set periodic interval for LSP ping requests in seconds.

```
Router(config-if)#bfd lsp-ping interval 300
```




---

**Note** The interval range is 60 to 3600 seconds. Default interval is 120 seconds.

---

4. Commit the changes.

```
Router(config-if)#commit
```

## Configuring BFD at the Tail-End

Use the tail-end global configuration commands to set the BFD minimum-interval and BFD multiplier parameters for all BFD over LSP sessions. The ranges and default values are the same as the BFD head-end configuration values. BFD will take the maximum value set between head-end minimum interval and tail-end minimum interval. Perform these tasks to configure BFD at the tail-end.

1. Enter global configuration mode.

```
Router# configure
```

2. Configure MPLS OAM.

```
Router(config)# mpls oam
```

3. Configure hello interval in milliseconds.

```
Router(config)#mpls traffic-eng bfd lsp tail minimum-interval 500
```




---

**Note** Hello interval range is 3 to 1000 milliseconds. Default hello interval is 100 milliseconds.

---

4. Configure BFD multiplier detection.

```
Router(config)#mpls traffic-eng bfd lsp tail multiplier 5
```




---

**Note** BFD multiplier detect range is 3 to 10. Default BFD multiplier is 3.

---

5. Commit the changes.

```
Router(config-if)#commit
```



## Configuring BFD over LSP Sessions on Line Cards

BFD over LSP sessions, both head-end and tail-end, are hosted on line cards with following configuration enabled.



**Note** For fixed box and centralized platforms, there are no line cards. Datapath is running on routing processors (RPs) which is where BFD sessions need to be created. On fixed box, the configuration must include the RPs instead of LCs. On centralized platforms, you cannot use RP in the config even though BFD sessions will be running on the RPs. You must include one of the MPAs instead of LC in the configuration.

1. Enter global configuration mode.

```
Router# configure
```

2. Enter BFD configuration mode.

```
Router(config)# bfd
```

3. Configure BFD multiple path on specific line card.

```
Router(config-bfd)# multipath include location 0/1/CPU0
```

4. Commit the changes.

```
Router(config-if)#commit
```

## BFD over MPLS TE Tunnel Tail-End Configuration

You can use the **mpls traffic-eng bfd lsp tail minimum-interval** command to configure the tail-end at a minimum interval of 3 milli seconds.

### Configuration

```
Router#config
Router(config)#mpls traffic-eng bfd lsp tail minimum-interval 3
Router(config)#commit
```

### Running Configuration

```
mpls traffic-eng bfd lsp tail minimum-interval 3
!
```

### Verification

Use the **show bfd session** command to verify the configuration on tail-end.

```
Router#show bfd session
```

| Src Addr | Dest Addr | VRF Name                 | Type Specific Data |       |
|----------|-----------|--------------------------|--------------------|-------|
| H/W      | NPU       | Local det time(int*mult) | Echo               | State |
|          |           |                          | Async              |       |
| 1.1.1.1  | 2.2.2.2   | default                  | TT32768 (LSP:2)    |       |
|          |           | n/a                      | 1500ms (500ms*3)   | UP    |

Use the **show bfd label session** to verify the configuration on head-end.

```
Router#show bfd label session
```

| Interface     | Label    | Local det | time(int*mult) | State |
|---------------|----------|-----------|----------------|-------|
| H/W           | NPU      | Echo      | Async          |       |
| tt1 (LSP:103) | 24001    | n/a       | 150ms (50ms*3) | UP    |
| Yes           | 0/1/CPU0 |           |                |       |
| tt2 (LSP:102) | 24002    | n/a       | 150ms (50ms*3) | UP    |
| Yes           | 0/1/CPU0 |           |                |       |
| tt3 (LSP:101) | 24004    | n/a       | 150ms (50ms*3) | UP    |
| Yes           | 0/1/CPU0 |           |                |       |
| tt4 (LSP:103) | 24005    | n/a       | 150ms (50ms*3) | UP    |
| Yes           | 0/1/CPU0 |           |                |       |
| tt5 (LSP:104) | 24006    | n/a       | 150ms (50ms*3) | UP    |
| Yes           | 0/1/CPU0 |           |                |       |

## Configuration Examples for Configuring BFD

### BFD over MPLS TE LSPs Examples

These examples explain how to configure BFD over MPLS TE LSPs.

#### BFD Over MPLS TE Tunnel Head-End Configuration: Example

This example shows how to configure BFD over MPLS TE Tunnel at head-end.

```
Router# bfd multipath include loc 0/1/CPU0
mpls oam
interface tunnel-te 1
bfd
  minimum-interval 500
  fast-detect
  multiplier 5
  bringup-timeout 60
  lsp-ping disable
  dampening initial-wait (default 16000 ms)
  dampening maximum-wait (default 600000 ms)
  dampening secondary-wait (default 20000 ms)
  logging events bfd-status
```

#### BFD Over MPLS TE Tunnel Tail-End Configuration: Example

This example shows how to configure BFD over MPLS TE Tunnels at tail-end.

```
Router# bfd multipath include loc 0/1/CPU0
mpls oam
mpls traffic-eng bfd lsp tail multiplier 3
mpls traffic-eng bfd lsp tail minimum-interval 500
```

# BGP BFD Strict-Mode Capabilities for Improved Interoperability

Table 10: Feature History Table

| Feature Name   | Release Information | Feature Description   |
|--|---------------------|---|
| BGP BFD Strict-Mode Capabilities for Improved Interoperability | Release 24.4.1      | <p>Introduced in this release on: Fixed Systems (8200 [ASIC: P100], 8700 [ASIC: P100]); Modular Systems (8800 [LC ASIC: P100])</p> <p>You now have the ability to upgrade your network using Cisco's BGP BFD strict-mode negotiate and strict-mode negotiate override modes. These modes improve stability and cooperation between Cisco IOS XR and Cisco IOS XE devices. They ensure BGP sessions start only when BFD sessions are active. The override option enforces this even if a peer device does not support strict-mode. The feature ensures that a BGP session is established between neighbors only after the BFD session is established and stable. This ensures that the BFD functions as intended during a failure, promoting network stability and reliability.</p> <p>This feature introduces these changes:</p> <p><b>CLI:</b></p> <ul style="list-style-type: none"> <li>The <b>bfd-state</b> keyword is introduced in the <b>show bgp sessions</b> command.</li> <li>The <b>BFDmode</b> and <b>BFDState</b> fields are added to the <b>show bgp neighbors</b> command output.</li> </ul> <p><b>YANG Data Models:</b></p> <ul style="list-style-type: none"> <li>New XPathS for <code>Cisco-IOS-XR-um-router-bgp-cfg.yang</code></li> </ul> <p>(See <a href="#">GitHub</a>, <a href="#">YANG Data Models Navigator</a>)</p> |

## BGP and BFD Interoperability Modes for Enhanced Routing Resilience

Cisco introduces two new modes: BGP BFD strict-mode negotiate and BGP BFD strict-mode negotiate override, enhancing BGP and BFD interoperability across Cisco IOS XR and Cisco IOS XE devices. These modes guarantee the establishment of BGP sessions contingent on active BFD sessions, and the override mode enforces this requirement irrespective of peer support for strict-mode. This improvement conforms to IETF standards and bolsters routing resilience.

## Addressing Interoperability Challenges

Without the enhanced BGP BFD strict-mode capabilities, network operators faced interoperability issues between Cisco IOS XR and Cisco IOS XE devices, leading to failures in establishing BGP sessions. These failures occur due to nonstandard implementations of strict-mode, compromising the reliability of the routing infrastructure. Therefore, BGP routes may be propagated without the assurance of an active underlying BFD session, risking routing instability.

### BGP and BFD Strict-Mode Negotiation Capabilities for Network Devices

These modes enable devices to negotiate BGP BFD Strict Mode, adapt to peers, ensure IETF compliance, and log interactions.

BGP BFD strict-mode negotiate:

Network devices advertise BFD Strict Mode capability and verify if the peer also advertises this capability. Upon receiving confirmation, devices initiate operations in IETF mode, establishing BGP sessions solely when the corresponding BFD session is active. If the peer does not advertise Strict Mode, devices operate without enforcing strict mode. The status of capabilities both sent and received is displayed in the **show bgp neighbor detail** output for reference.

BGP BFD strict-mode negotiate override:

Network devices actively advertise BFD Strict Mode capability and assess whether the peer reciprocates this advertisement. If the peer's advertisement is received, the devices commence operations in IETF mode. Should the peer not advertise the Strict Mode capability, devices persist in operating in IETF strict mode, effectively overriding the neighbor's capability by waiting for BFD to be up before proceeding from the Open BFD state. In cases where the peer resets the session citing unsupported Strict Mode, the device records this event against the neighbor, refrains from advertising the capability in subsequent Open messages, yet continues to operate in IETF strict mode.

### Peer Advertisement Verification for BFD Strict-Mode Negotiate Capability

Verify the peer's advertisement of Strict Mode capability for BFD Strict-mode negotiate mode.

| If ...   | Then ...   |
|--|--|
| the peer advertises strict mode capability         | the device brings up the BGP sessions only if the BFD session is up; this is in compliance with the IETF standard. |
| the peer does not advertise strict mode capability | the device starts operation without enforcing any strict mode.   |

Verify the peer's advertisement of Strict Mode capability for BFD Strict-mode negotiate override mode.

| If ...  | Then ...  |
|---|---|
| the peer advertises strict mode capability                          | the device brings up the BGP sessions only if the BFD session is up.                            |
| the peer advertises that it does not support strict mode capability | the device overrides the neighbor's capability notification and start operation in strict mode. |

# Bidirectional forwarding detection over VXLAN tunnel

Table 11: Feature History

| Feature Name   | Release Information | Feature Description  |
|--|---------------------|--|
| Bidirectional forwarding detection over VXLAN tunnel | Release 25.1.1      | Introduced in this release on: Fixed Systems (8700 [ASIC: K100], 8010 [ASIC: A100])<br><br>This feature is now supported on: <ul style="list-style-type: none"> <li>• 8712-MOD-M</li> <li>• 8011-4G24Y4H-I</li> </ul>  |
| Bidirectional forwarding detection over VXLAN tunnel | Release 24.4.1      | Introduced in this release on: Fixed Systems( 8700)(select variants only*).<br><br>*This feature which allows to monitor the health of VXLAN tunnel and detect failures in the tunnel rapidly thus ensuring faster rerouting of traffic and high availability of networks is now supported on the Cisco 8711-32FH-M routers. |
| Bidirectional forwarding detection over VXLAN tunnel | Release 24.2.11     | You can now monitor the health of VXLAN tunnel and detect failures in the tunnel rapidly which ensures faster rerouting of traffic, resulting in high availability of networks.  |

Bidirectional forwarding detection over VXLAN tunnel feature enables you to detect Layer 2 data plane failures using BFD for the underlying Virtual Extensible LAN (VXLAN) tunnel forwarding plane.

Initially, a VXLAN network is established to encapsulate the network traffic, forming secure tunnels across the Layer 3 physical infrastructure. These tunnels allow traffic to remain invisible to the internal domain network, ensuring privacy and security for all users. When the traffic volume grows, the VXLAN's load balancing capabilities distribute the data packets evenly, thus maintaining network performance and reliability.

Within the VXLAN network, the sharing of route information is implemented using either BGP or static routes. With BGP, the routes are learned and shared dynamically, while static routes provide a consistent predefined path.

To detect link failures quickly, BFD is integrated over the VXLAN tunnel. When a failure occurs in the VXLAN tunnel, BFD rapidly detects the failure, and ensures quick failover and rerouting of traffic, thus minimizing potential downtime and service interruption.



**Note** BFD over VXLAN with BGP can support up to 2000 BFD sessions (IPv4 and IPv6 combined), whereas BFD over VXLAN on static routes can support up to 10,000 BFD sessions (up to 10 percent IPv6 and 90-percent IPv4).

## Restrictions

These restrictions apply for the BFD over VXLAN feature:

- This feature is applicable to multihop (MH) BFD sessions. You can achieve the maximum number of BFD sessions only using MH BFD sessions and with a distribution ratio of 90 percent IPv4 sessions to 10 percent IPv6 sessions. If the configuration includes other types of BFD sessions, or if the proportion of IPv6 sessions exceeds 10 percent, the maximum supported scale may not be attainable. The exact number of supported BFD sessions depends on the specific types of sessions and their distribution.
- This feature is supported only in BFD asynchronous mode. Echo mode is not supported.
- The parallel operation of BFD over VXLAN with static routes at a scale of up to 10,000 sessions alongside BFD over VXLAN with BGP is not supported.
- The stated scale of up to 10,000 BFD sessions is supported only on the Cisco 8100 and 8200 series routers.
- Software-based BFD sessions cannot support short minimum-interval values when operating at higher scale. So, it is recommended to configure a minimum-interval value greater than 300 milliseconds.
- The maximum rate in packets-per-second (PPS) for BFD sessions must be below 80% to ensure the stability of BFD sessions. Exceeding this threshold may result in unstable sessions. You can use the **show bfd summary** command to check the PPS %.

## Configure BFD over VXLAN

The BFD over VXLAN feature can be configured under the following scenarios:

- BFD over VXLAN with BGP
- BFD over VXLAN with Static Routes

### BFD over VXLAN with BGP

The configuration of BFD over VXLAN with BGP includes the following:

- VRF configuration
- Multipath BFD sessions configuration
- Interfaces configuration
- Interface NVE configuration
- BGP configuration
- BFD configuration

### Configuration Example

Use the following sample configuration to configure BFD over VXLAN with BGP.

```
/* Configure VRF */  
Router# configure
```

```
Router(config)# vrf vrfl
Router(config-vrf)# exit

/* Configure Multipath BFD sessions. */
Router# configure
Router(config)# bfd
Router(config-bfd)# multipath include location 0/0/CPU0
Router(config-bfd)# exit

/* Configure Interfaces */
Router(config)# interface Loopback 0
Router(config-if)# ipv4 address 10.10.10.10 255.0.0.0
Router(config-if)# exit
Router(config)# interface Loopback 1
Router(config-if)# vrf vrfl
Router(config-if)# ipv4 address 192.168.0.0 255.255.0.0
Router(config-if)# exit

/* Configure Interface NVE for Decapsulation */
Router(config)# interface nve1
Router(config-if)# member vni 2
Router(config-nve-vni)# vrf vrfl
Router(config-nve-vni)# host-reachability protocol static
Router(config-nve-vni)# exit
Router(config-if)# overlay-encapsulation vxlan
outer(config-nve-encap-vxlan)# peer-ip lookup disable
Router(config-nve-encap-vxlan)# exit
Router(config-if)# source-interface Loopback1
Router(config-if)# commit

/* Configure BGP */
Router(config)# router bgp 1
Router(config-bgp)# bgp router-id 10.10.10.10
Router(config-bgp)# address-family ipv4 unicast
Router(config-bgp-af)# redistribute connected
Router(config-bgp-af)# exit
Router(config-bgp)# address-family ipv4 unicast
Router(config-bgp)# exit

Router(config)# router bgp 1
Router(config-bgp)# vrf vrfl
Router(config-bgp-vrf)# rd auto
Router(config-bgp-vrf)# address-family ipv4 unicast
Router(config-bgp-vrf-af)# redistribute connected
Router(config-bgp-vrf-af)# redistribute static
Router(config-bgp-vrf-af)# exit

/* Configure BFD over BGP. */
Router(config)# router bgp 1
Router(config-bgp)# neighbor 10.6.6.1
Router(config-bgp-nbr)# bfd fast-detect
Router(config-bgp-nbr)# bfd multiplier 7
Router(config-bgp-nbr)# bfd minimum-interval 1200
Router(config-bgp-nbr)# remote-as 300
Router(config-bgp-nbr)# ebgp-multihop 255
Router(config-bgp-nbr)# update-source loopback 1
Router(config-bgp-nbr)# address-family ipv4 unicast
Router(config-bgp-nbr-af)# route-policy pass-all in
Router(config-bgp-nbr-af)# route-policy pass-all out
Router(config-bgp-nbr-af)# commit
```

## Running Configuration

```

vrf vrf1
!
bfd
  multipath include location 0/0/CPU0
!
interface Loopback0
  ipv4 address 10.10.10.10 255.0.0.0
!
interface Loopback1
  vrf vrf1
  ipv4 address 192.168.0.0 255.255.0.0
!
interface nve1
  member vni 2
  vrf vrf1
  host-reachability protocol static
!
  overlay-encapsulation vxlan
  peer-ip lookup disable
!
  source-interface Loopback1
!

router bgp 1
  bgp router-id 10.10.10.10
  address-family ipv4 unicast
    redistribute connected
  !
  address-family ipv4 unicast
!

router bgp 1
  vrf vrf1
  rd auto
  address-family ipv4 unicast
    redistribute connected
    redistribute static
  !

router bgp 1
  neighbor 10.6.6.1
  bfd fast-detect
  bfd multiplier 7
  bfd minimum-interval 1200
  remote-as 300
  ebgp-multihop 255
  update-source Loopback 1
  address-family ipv4 unicast
    route-policy pass-all in
    route-policy pass-all out
!
!
!
```

## BFD over VXLAN with Static Routes

The configuration of BFD over VXLAN with static routes includes the following:

- VRF configuration
- Multipath BFD sessions configuration



- Interfaces configuration
- Interface NVE configuration
- Static routing configuration

### Configuration Example

Use the following sample configuration to configure BFD over VXLAN with static routes.

```
/* Configure VRF */
Router# configure
Router(config)# vrf vrfl
Router(config-vrf)# exit

/* Configure Multipath BFD sessions. */
Router# configure
Router(config)# bfd
Router(config-bfd)# multipath include location 0/0/CPU0
Router(config-bfd)# exit

/* Configure Interfaces */
Router(config)# interface Loopback 0
Router(config-if)# ipv4 address 10.10.10.10 255.0.0.0
Router(config-if)# ipv6 address 2001:DB8:1::1/32
Router(config-if)# exit
Router(config)# interface Loopback 1
Router(config-if)# vrf vrfl
Router(config-if)# ipv4 address 192.168.0.0 255.255.0.0
Router(config-if)# exit
Router(config)# interface TenGigE0/0/0/0/0
Router(config-if)# ipv4 address 10.12.13.10 255.0.0.0
Router(config-if)# ipv6 address 2001:DB8:13::11/16
Router(config-if)# exit

/* Configure Interface NVE for Decapsulation */
Router(config)# interface nve1
Router(config-if)# member vni 2
Router(config-nve-vni)# vrf vrfl
Router(config-nve-vni)# host-reachability protocol static
Router(config-nve-vni)# exit
Router(config-if)# overlay-encapsulation vxlan
Router(config-nve-encap-vxlan)# exit
Router(config-if)# source-interface Loopback1
Router(config-if)# commit

/* Configure Static Routing */
Router# configure
Router(config)# router static
Router(config-static)# address-family ipv4 unicast
Router(config-static-afi)# 10.10.10.10/32 10.151.11.2
Router(config-static-afi)# exit
Router(config-static)# address-family ipv6 unicast
Router(config-static-afi)# 2001:DB8:1::12/32 2001:DB8:17::122
Router(config-static-afi)# exit
Router(config-static)# vrf VRF1
Router(config-static-vrf)# address-family ipv4 unicast
Router(config-static-vrf-afi)# 10.1.1.1/32 remote-next-hop 10.13.19.10 tunnel VXLAN index
1 nve 1 evni 1 src-mac aaal.bbb1.ccc1 -> IPv4 over IPv4
Router(config-static-vrf-afi)# 209.165.201.0/27 10.1.1.1 bfd fast-detect minimum-interval
1000 multihop 192.168.0.0
Router(config-static-vrf-afi)# 10.12.12.12/32 remote-next-hop 10.13.19.10 tunnel VXLAN index
2 nve 1 evni 2 src-mac aaal.bbb1.ccc2 -> IPv4 over IPv4
```

```
Router(config-static-vrf-afi)# 209.165.202.129/27 10.12.12.12 bfd fast-detect minimum-interval
1000 multihop 192.168.12.24
Router(config-static-vrf-afi)# exit
```

## Running Configuration

```
vrf vrf1
!
bfd
  multipath include location 0/0/CPU0
!
interface Loopback0
  ipv4 address 10.10.10.10 255.0.0.0
  ipv6 address 2001:DB8:1::1/32
!
interface Loopback1
  vrf vrf1
  ipv4 address 192.168.0.0 255.255.0.0
!
interface TenGigE0/0/0/0/0
  ipv4 address 10.12.13.10 255.0.0.0
  ipv6 address 2001:DB8:13::11/16
!
interface nve1
  member vni 2
  host-reachability protocol static
!
  overlay-encapsulation vxlan
!
  source-interface Loopback1
!
router static
  address-family ipv4 unicast
    10.10.10.10/32 10.151.11.2
  !
  address-family ipv6 unicast
    2001:DB8:1::12/32 2001:DB8:17::122
  !
vrf vrf1
  address-family ipv4 unicast
    10.1.1.1/32 remote-next-hop 10.13.19.10 tunnel VXLAN index 1 nve 1 evni 1 src-mac
0022.3344.5566
    209.165.201.0/27 10.1.1.1 bfd fast-detect minimum-interval 1000 multihop 192.168.0.0
    10.12.12.12/32 remote-next-hop 10.13.19.10 tunnel VXLAN index 2 nve 1 evni 2 src-mac
0022.3344.5567
    209.165.202.129/27 10.12.12.12 bfd fast-detect minimum-interval 1000 multihop 192.168.12.24
  !
!
!
```

## Verification

- Use the **show bfd all** command to view the details of BFD over IPv4 and IPv6 sessions:

```
Router# show bfd all
Tue Dec 12 10:07:03.395 UTC

IPv4:
-----
IPV4 Sessions Up: 7200, Down: 0, Unknown/Retry: 2000, Total: 9200

IPv6:
```

```
-----
IPV6 Sessions Up: 800, Down: 0, Unknown/Retry: 0, Total: 800
```

```
Label:
```

```
-----
Label Sessions Up: 0, Down: 0, Unknown/Retry: 0, Total: 0
```

- Use the **show bfd ipv6 multihop session** command to view the details of BFD over IPv6 multihop sessions:

```
Router# show bfd ipv6 multihop session
```

```
Tue Mar 26 19:32:14.851 UTC
```

| Src Addr         | Dest Addr       | Local det time(int*mult) | State |
|------------------|-----------------|--------------------------|-------|
| VRF Name         |                 | Echo Async               |       |
| H/W              | NPU             |                          |       |
| 2001:DB8:0000::1 | 2001:DB8:FFF::1 | 0s(0s*0) 3s(1s*3)        | UP    |
| vrf5001          |                 |                          |       |
| Yes              | 0/RP0/CPU0      |                          |       |
| 2001:DB8:0000::2 | 2001:DB8:FFF::2 | 0s(0s*0) 3s(1s*3)        | UP    |
| vrf5002          |                 |                          |       |
| Yes              | 0/RP0/CPU0      |                          |       |
| 2001:DB8:0000::3 | 2001:DB8:FFF::3 | 0s(0s*0) 3s(1s*3)        | UP    |
| vrf5003          |                 |                          |       |
| Yes              | 0/RP0/CPU0      |                          |       |
| 2001:DB8:0000::4 | 2001:DB8:FFF::4 | 0s(0s*0) 3s(1s*3)        | UP    |
| vrf5004          |                 |                          |       |
| Yes              | 0/RP0/CPU0      |                          |       |
| 2001:DB8:0000::5 | 2001:DB8:FFF::5 | 0s(0s*0) 3s(1s*3)        | UP    |
| vrf5005          |                 |                          |       |
| Yes              | 0/RP0/CPU0      |                          |       |
| 2001:DB8:0000::6 | 2001:DB8:FFF::6 | 0s(0s*0) 3s(1s*3)        | UP    |
| vrf5006          |                 |                          |       |
| Yes              | 0/RP0/CPU0      |                          |       |
| 2001:DB8:0000::7 | 2001:DB8:FFF::7 | 0s(0s*0) 3s(1s*3)        | UP    |
| vrf5007          |                 |                          |       |
| Yes              | 0/RP0/CPU0      |                          |       |
| 2001:DB8:0000::8 | 2001:DB8:FFF::8 | 0s(0s*0) 3s(1s*3)        | UP    |
| vrf5008          |                 |                          |       |

- Use the **show bfd session** command to view the BFD session details. The following is a sample output from a BFD over VXLAN system configured with static routes.

```
Router# show bfd session
```

```
Tue Mar 26 19:32:00.554 UTC
```

| Src Addr      | Dest Addr | VRF Name | Local det time(int*mult) | H/W NPU | State |
|---------------|-----------|----------|--------------------------|---------|-------|
|               |           |          | Echo Async               |         |       |
| 209.165.201.1 | 10.0.0.1  | vrf5001  | Yes 0/RP0/CPU0           |         |       |
|               |           | n/a      | 3s(1s*3)                 |         | UP    |
| 209.165.201.2 | 10.0.0.2  | vrf5002  | Yes 0/RP0/CPU0           |         |       |
|               |           | n/a      | 3s(1s*3)                 |         | UP    |
| 209.165.201.3 | 10.0.0.3  | vrf5003  | Yes 0/RP0/CPU0           |         |       |
|               |           | n/a      | 3s(1s*3)                 |         | UP    |
| 209.165.201.4 | 10.0.0.4  | vrf5004  | Yes 0/RP0/CPU0           |         |       |
|               |           | n/a      | 3s(1s*3)                 |         | UP    |
| 209.165.201.5 | 10.0.0.5  | vrf5005  | Yes 0/RP0/CPU0           |         |       |
|               |           | n/a      | 3s(1s*3)                 |         | UP    |
| 209.165.201.6 | 10.0.0.6  | vrf5006  | Yes 0/RP0/CPU0           |         |       |
|               |           | n/a      | 3s(1s*3)                 |         | UP    |

209.165.201.7      10.0.0.7      vrf5007      Yes 0/RP0/CPU0  
n/a      3s(1s\*3)      UP

# Bidirectional forwarding detection on BVI

Table 12: Feature History

| Feature Name                              | Release Information | Feature Description   |
|---|---------------------|---|
| Bidirectional forwarding detection on BVI | Release 24.4.1      | <p>Introduced in this release on: Fixed Systems( 8700)(select variants only*).</p> <p>This feature that allows for low-overhead and short-duration detection of path failures between routers to an Integrated Routing and Bridging (IRB) deployment scenario is now supported on the following hardware by configuring Bidirectional Forwarding Detection (BFD) on multipath single-hop sessions using Bridge-Group Virtual Interface (BVI).</p> <p>*This feature is now supported on the Cisco 8711-32FH-M routers.</p> |
| Bidirectional forwarding detection on BVI | Release 7.10.1      | <p>Now you can extend the advantage of low-overhead and short-duration detection of path failures between routers to an Integrated Routing and Bridging (IRB) deployment scenario by configuring Bidirectional Forwarding Detection (BFD) on multipath single-hop sessions using Bridge-Group Virtual Interface (BVI). By configuring BFD on a multipath session, you can apply BFD over virtual interfaces or between interfaces that are multiple hops away.</p>  |

## Overview

To establish a VLAN that extends across a router, the router needs to actively forward frames between interfaces while maintaining the integrity of the VLAN header. If the router is configured for routing a Layer 3 (network layer) protocol, it terminates the VLAN and MAC layers at the interface on which a frame arrives. The MAC layer header information can be maintained if the router bridges the network layer protocol. However, even with standard bridging techniques, the VLAN header is still terminated.

### The Role of IRB in VLAN Spanning

VLANs facilitate network segmentation by establishing distinct broadcast domains. Routers can bridge traffic between different VLANs, but this requires the activation of VLAN trunking to enable the passage of multiple VLANs over a single link. This phenomenon, often referred to as VLAN spanning, ensures seamless connectivity.

However, in complex VLAN setups that involve multiple routers, the accurate preservation of VLAN header markings becomes imperative for effective spanning. This task can be challenging since routers usually replace the VLAN header with a new one, irrespective of whether the traffic is routed or bridged. This replacement hinders VLAN spanning, which in turn negatively impacts trunking and the facilitation of traffic bridging between VLANs.

To address this issue, Integrated Routing and Bridging (IRB) enables simultaneous routing and bridging on a router interface, while preserving the essential VLAN header integrity across routers. This ensures effective VLAN spanning within complex networks, even when multiple routers are involved

### Integrated Routing and Bridging

Using the Integrated Routing Bridging (IRB) feature, you can configure your router to simultaneously route and bridge a given network layer protocol on a single interface. This configuration ensures the preservation of the VLAN header on a frame while it traverses from one interface to another via the router. By utilizing the Bridge Group Virtual Interface (BVI), IRB enables seamless routing between bridged and routed domains. The BVI acts as a virtual interface within the router, resembling a standard routed interface that does not support bridging. However, it serves as the representation of the corresponding bridge group for the routed interfaces in the router. Moreover, BVI interface number represents the corresponding bridge group number, establishing a vital link between the BVI and the bridge group.

To enable the BVI to operate as a routed interface, you need to configure it exclusively with Layer 3 attributes, such as network layer addresses. However, any interfaces designated for protocol bridging should not have any Layer 3 characteristics configured.

### BFD over IRB

This feature uses BVI to implement BFD over IRB to establish a multipath single-hop session. Within a BFD multipath session, the application of BFD extends to virtual interfaces or interfaces that are multihop away. This feature adheres to the specifications outlined in *RFC 5883—Bidirectional Forwarding Detection (BFD) for Multihop Paths*. This integration leverages the inherent benefits of BFD, characterized by its low overhead and rapid path failure detection between routers, and extends these advantages to the context of IRB deployment. BFD over BVI feature is compatible with both IPv4 addresses and IPv6 global addresses. This feature exclusively supports asynchronous mode and does not provide support for echo mode.

## Restrictions

To communicate and exchange routing information with other routers in the network, IS-IS and OSPFv3 clients rely on IPv6 link local addresses. However, the BFD over BVI feature does not support IPv6 link local addresses and hence it does not support IS-IS and OSPFv3 clients.

## Configure BFD over BVI

### Configuration Example

```

/* Configure the line cards to allow hosting of Multipath BFD sessions. */
Router# configure
Router(config)# bfd
Router(config-bfd)# multipath include location 0/0/CPU0
Router(config-bfd)# multipath include location 0/2/CPU0
/* Configure the Layer 2 domain that should include the corresponding l2transport and BVIs.
*/
Router(config)# interface Bundle-Ether2601
Router(config-if)# exit
Router(config)# interface Bundle-Ether2601.3001
Router(config-if)# l2transport
Router(config-if)# encapsulation dot1q 3001
Router(config-if)# rewrite ingress tag pop 1 symmetric
Router(config-if)# exit
Router(config)# interface HundredGigE0/0/0/6
Router(config)# bundle id 2601 mode on
Router(config-if)# exit

/* Configure a BVI interface and assign an IP address. You should configure the BVI interface
with either IPv4 or IPv6 address or both. */
Router(config)# interface bvi3001
Router(config-if)# ipv4 address 192.168.1.1 255.255.255.0
Router(config-if)# exit

/* Configure BVI on the peer nodes */
Router(config-if)# l2vpn
Router(config-l2vpn)# bridge group bvi100
Router(config-l2vpn-bg)# bridge domain bfd-bvi
Router(config-l2vpn-bg-bd)# interface Bundle-Ether2601.3001
Router(config-l2vpn-bg-bd-ac)# exit
Router(config-l2vpn-bg-bd)# routed interface bvi bvi3001

/* Configure OSPF as the routing protocol */
Router(config)# router ospf bfd-bvi
Router(config-ospf)# router-id 192.168.1.1
Router(config-ospf)# area 0

/* Configure BFD on BVI */
Router(config-ospf-ar)# interface bvi3001
Router(config-ospf-ar-if)#
Router(config-ospf-ar-if)# bfd fast-detect
Router(config-ospf-ar-if)# bfd multiplier 3

```

## Running Configuration

```

bfd
 multipath include location 0/0/CPU0
 multipath include location 0/2/CPU0
!

interface Bundle-Ether2601
!
interface Bundle-Ether2601.3001
 l2transport
 encapsulation dot1q 3001
 rewrite ingress tag pop 1 symmetric
!
interface HundredGigE0/0/0/6
 bundle id 2601 mode on
!

```

```

interface bvi3001
  ipv4 address 192.168.1.1 255.255.255.0
  !
l2vpn
  bridge group bvi100
    bridge domain bfd-bvi
      interface Bundle-Ether2601.3001
        !
        routed interface bvi bvi3001
        !
      !
    !
  !
  !
router ospf bfd-bvi
router-id 192.168.1.1
area 0
interface bvi3001
  bfd minimum-interval bvi3001
  bfd fast-detect
  !
!
!

```

### Verification

Verify the status of L2VPN bridge domain.

Router# **show l2vpn bridge-domain brief**

Mon Apr 24 11:31:04.314 UTC

Legend: pp = Partially Programmed.

| Bridge Group:Bridge-Domain Name | ID | State  | Num ACs/up | Num PWs/up | Num PBBs/up | Num VNIs/up |
|---------------------------------|----|--------|------------|------------|-------------|-------------|
| bvi100:bfd-bvi                  | 0  | up 2/2 | 0/0        | 0/0        | 0/0         |             |

Verify the status of OSPF connectivity. The creation of a BFD session requires the neighbor to be in the FULL/BDR state. The FULL/BDR state indicates that the router is fully adjacent with the backup designated router.

Router# **show ospf neighbor**

Mon Apr 24 11:40:41.900 UTC

\* Indicates MADJ interface

# Indicates Neighbor awaiting BFD session up

Neighbors for OSPF bfd-bvi

| Neighbor ID | Pri | State    | Dead Time | Address     | Interface |
|-------------|-----|----------|-----------|-------------|-----------|
| 192.168.1.1 | 1   | FULL/BDR | 00:00:33  | 192.168.1.1 | BVI3001   |

Neighbor is up for 1d22h

Total neighbor count: 1

Verify the status of the BFD session. The output indicates the state of the BFD session is UP.

**show bfd session interface bvi3001**

Mon Apr 24 11:42:50.582 UTC

| Interface | Dest Addr   | Local det | time(int*mult) | State | Echo | Async | H/W      | NPU |
|-----------|-------------|-----------|----------------|-------|------|-------|----------|-----|
| BVI3001   | 192.168.1.1 | 0s(0s*0)  | 750ms(250ms*3) | UP    | Yes  |       | 0/2/CPU0 |     |

# BFD over pseudowire headend

Table 13: Feature History

| Feature Name                | Release Information | Feature Description  |
|-----------------------------|---------------------|--|
| BFD over pseudowire headend | Release 25.1.1      | Introduced in this release on: Fixed Systems (8700 [ASIC: K100], 8010 [ASIC: A100])<br><br>This feature is now supported on: <ul style="list-style-type: none"> <li>• 8712-MOD-M</li> <li>• 8011-4G24Y4H-I</li> </ul>  |
| BFD over pseudowire headend | Release 24.4.1      | Introduced in this release on: Fixed Systems( 8700)(select variants only*).<br><br>This feature which allows to rapidly detect failures in pseudowires, minimizing downtime and ensuring service reliability is now supported on Cisco 8711-32FH-M routers.  |
| BFD over pseudowire headend | Release 24.3.1      | Introduced in this release on: Modular Systems (8800 [LC ASIC: P100]) (select variants only*)<br><br>You can now rapidly detect failures in pseudowires, minimizing downtime and ensuring service reliability. This feature continuously monitors the pseudowire end-to-end, providing quick responses to maintain the integrity of Layer 2 VPNs and Ethernet services.<br><br>*This feature is supported on the Cisco 88-LC1-12TH24FH-E line cards. |

The Bidirectional forwarding detection over pseudowire headend (BFD over PWHE) feature enables BFD support over the customer edge (CE) to pseudowire headend - provider edge (PWHE-PE) links for fast failure detection along the path between the eBGP neighbors.

BFD over PWHE supports

- BFD sessions per pseudo-wire for end-to-end fault detection between the CE and PWHE PE
- BFDv4 for IPv4 and BFDv6 for IPv6
- BFD asynchronous mode over PWHE, and
- Pseudowire VC type 4 and type 5.

## Limitations for BFD over PWHE

These limitations apply for the BFD over PWHE feature.

- Supported only on 88-LC1-12TH24FH-E line card.
- Supports only static routes for IPv4 and IPv6.



- Supports only single-hop BFD sessions for IPv4 and IPv6.

For PWHE to be operational, the BFD agent must be hosted on one of the line cards that is part of the PWHE generic interface list. So, you must configure BFD multipath on a line card that is part of the generic interfaces list.

## Configure BFD over PWHE

To enable BFD over PWHE, you must configure the specific line card to host BFD multipath sessions.

### Procedure

**Step 1** Configure the line card to host BFD multipath sessions.

**Example:**

```
Router# configure
Router(config)# bfd multipath include location 0/5/CPU0
```

**Step 2** Configure BFD fast-detection capability on the specified IPv4 or IPv6 unicast destination address prefix and on the forwarding next-hop address.

**Example:**

```
Router# configure
Router(config)# router static
Router(config-static)# address-family ipv4 unicast
Router(config-static-afi)# 198.51.100.0/24 209.165.201.0 bfd fast-detect minimum-interval 800 multiplier 3
Router(config-static-afi)# 198.51.100.0/24 209.165.202.0 bfd fast-detect minimum-interval 800 multiplier 3
Router(config-static-afi)# exit
Router(config-static)# address-family ipv6 unicast
Router(config-static-afi)# 2001:DB8:C18:2:1::F/48 2001:DB8:D987:398:AE3:B39:333:783 bfd fast-detect minimum-interval 800 multiplier 3
Router(config-static-afi)# 2001:DB8:C18:2:1::F/48 2001:DB8:D987:398:AE3:B39:334:783 bfd fast-detect minimum-interval 800 multiplier 3
```

**Step 3** Verify the configuration.

**Example:**

```
Router# show bfd all session agent detail location 0/2/CPU0
IPv4:
-----
I/f: PW-Ether1002, Location: 0/2/CPU0
Dest: 209.165.202.0
Src: 209.165.201.0
State: UP for 0d:0h:8m:17s, number of times UP: 1
Session type: SW/V4/SH/PH
Received parameters:
Version: 1, desired tx interval: 50 ms, required rx interval: 50 ms
Required echo rx interval: 1 us, multiplier: 3, diag: None
My discr: 2210464558, your discr: 4259847, state UP, D/F/P/C/A: 0/0/1/1/0
Transmitted parameters:
Version: 1, desired tx interval: 50 ms, required rx interval: 50 ms
Required echo rx interval: 0 ms, multiplier: 3, diag: None
My discr: 4259847, your discr: 2210464558, state UP, D/F/P/C/A: 0/1/0/1/0
Timer Values:
```

```

Local negotiated async tx interval: 50 ms
Remote negotiated async tx interval: 50 ms
Desired echo tx interval: 0 s, local negotiated echo tx interval: 0 ms
Echo detection time: 0 ms(0 ms*3), async detection time: 150 ms(50 ms*3)
Label:
Internal label: 24024/0x5dd8
Local Stats:
Intervals between async packets:
Tx: Number of intervals=100, min=46 ms, max=1804 ms, avg=342 ms
   Last packet transmitted 1250 ms ago
Rx: Number of intervals=100, min=46 ms, max=1804 ms, avg=342 ms
   Last packet received 1250 ms ago
Intervals between echo packets:
Tx: Number of intervals=0, min=0 s, max=0 s, avg=0 s
   Last packet transmitted 0 s ago
Rx: Number of intervals=0, min=0 s, max=0 s, avg=0 s
   Last packet received 0 s ago
Latency of echo packets (time between tx and rx):
Number of packets: 0, min=0 ms, max=0 ms, avg=0 ms

```

---

### What to do next

For more information about Pseudowire Headend and its configurations, see *Pseudowire Headend* module in *L2VPN Configuration Guide for Cisco 8000 Series Routers, IOS XR Release 24.1.x, 24.2.x, 24.3.x*.

## RFCs

| RFCs                  | Title   |
|-----------------------|---|
| rfc5880_bfd_base      | <i>Bidirectional Forwarding Detection</i> , June 2010 |
| rfc5881_bfd_ipv4_ipv6 | <i>BFD for IPv4 and IPv6 (Single Hop)</i> , June 2010 |

## Technical Assistance

| Description   | Link  |
|---|---|
| The Cisco Technical Support website contains thousands of pages of searchable technical content, including links to products, technologies, solutions, technical tips, and tools. Registered Cisco.com users can log in from this page to access even more content. | <a href="http://www.cisco.com/techsupport">http://www.cisco.com/techsupport</a> |

# Limiting LSA Numbers in a OSPF Link-State Database

Table 14: Feature History Table

| Feature Name                                       | Release       | Description   |
|--|---------------|---|
| Limiting LSA numbers in a OSPF Link-State Database | Release 7.9.1 | <p>The nonself-generated link-state advertisements (LSAs) for a given Open Shortest Path First (OSPF) process is limited to 500000. This protection mechanism prevents routers from receiving many LSAs, preventing CPU failure and memory shortages, and is enabled by default from this release onwards. If you have over 500000 LSAs in your network, configure the <b>max-lsa</b> command with the expected LSA scale before upgrading to this release or later.</p> <p>This feature modifies the following commands:</p> <ul style="list-style-type: none"> <li>• <b>show ospf</b> to display the maximum number of redistributed prefixes.</li> <li>• <b>show ospf database database-summary detail</b> to display the number of LSA counts per router.</li> <li>• <b>show ospf database database-summary adv-router router ID</b> to display the router information and the LSAs received from a particular router.</li> </ul> |

The OSPF Link-State Database Overload Protection feature allows you to protect the OSPF routing process by limiting the number of nonself-generated link-state advertisements (LSAs) for a given Open Shortest Path First (OSPF) process. When other routers in the network have been misconfigured, they may generate a high volume of LSAs. This mechanism prevents routers from receiving a large number of LSAs, thereby preventing CPU failure and memory shortages. With this feature, the router keeps a count of the number of nonself-generated LSAs it has received.



**Note** The max-lsa limit was not enabled by default before Release 7.9.1. Starting from Release 7.9.1, this command is enabled by default and the default limit of the nonself-generated LSA is set at 500000. If you have more than 500000 LSAs in a network, you must configure the **max-lsa** command with the expected LSA scale before upgrading to Release 7.9.1 or above.

### Restriction

This feature is supported only on OSPFv2 and not on OSPFv3.

### System output messages

The range of nonself-generated LSA allowed is 1-4294967294. The threshold percentage to log warning is 75%. The system log message is generated every 5% above the default or configured threshold value until 100% is reached.

When the number of LSAs reaches or exceeds the threshold limit, the router displays the following logs:

#### When number of LSAs exceed threshold value

```
%ROUTING-OSPF-4-MAX_LSA_THR : Reached threshold (60% [configured: 60%])
for maximum number of non self-generated LSAs in vrf "default" - LSA (max:
1000 cur: 600)
```

#### When number of LSAs exceed maximum limit

```
%ROUTING-OSPF-1-MAX_LSA : Maximum number of non self-generated LSAs
exceeded in vrf "default" - LSA (max: 1000, cur: 1001)
```

#### When OSPF instance ignores all adjacencies for ignore-time period if the number of LSAs exceed the limit

```
%ROUTING-OSPF-2-MAX_LSA_IGNORE_ENTER : Max LSA exceeded in vrf "default".
Adjacencies will be kept down for 5 minutes
```

#### When OSPF instance tries to recover the adjacencies after ignore-time period

```
%ROUTING-OSPF-6-MAX_LSA_IGNORE_EXIT : Max-lsa ignore timed out in vrf
"default". Adjacencies will be brought up by accepting and sending hellos
```

#### When the ignore count is exceeded on the OSPF instance

```
%ROUTING-OSPF-1-MAX_LSA_PERM_IGNORE : Max-lsa ignore count exceeded in
vrf "default" - Staying in ignore state. Restart or Clear OSPF process
to recover
```

#### When number of LSAs exceed threshold or limit the top contributing routers information will be displayed

```
%ROUTING-OSPF-2-MAX_LSA_RTR_INFO : Top 1 LSA contributor in vrf "default".
RTR:192.168.0.4 Total:498 Type3:0 Type5:492 Type7:0 Type10:0
Type11:6 Others:0
```

The following commands displays the LSA counts:

- **show ospf database database-summary detail** command displays the number of LSA counts per router sorted by total LSA count.

Router#show ospf database database-summary detail

OSPF Router with ID (192.168.0.1) (Process ID 1)

Router 192.168.0.4 LSA summary

| LSA Type     | Count | Delete | Maxage |
|--------------|-------|--------|--------|
| Router       | 0     | 0      | 0      |
| Network      | 0     | 0      | 0      |
| Summary Net  | 0     | 0      | 0      |
| Summary ASBR | 0     | 0      | 0      |
| Type-5 Ext   | 697   | 0      | 0      |
| Type-7 Ext   | 0     | 0      | 0      |
| Opaque Link  | 0     | 0      | 0      |
| Opaque Area  | 0     | 0      | 0      |
| Opaque AS    | 6     | 0      | 0      |
| Total        | 703   | 0      | 0      |

Router 192.168.0.1 LSA summary

| LSA Type     | Count | Delete | Maxage |
|--------------|-------|--------|--------|
| Router       | 1     | 0      | 0      |
| Network      | 0     | 0      | 0      |
| Summary Net  | 0     | 0      | 0      |
| Summary ASBR | 0     | 0      | 0      |
| Type-5 Ext   | 0     | 0      | 0      |
| Type-7 Ext   | 0     | 0      | 0      |
| Opaque Link  | 0     | 0      | 0      |
| Opaque Area  | 64    | 0      | 0      |
| Opaque AS    | 0     | 0      | 0      |
| Total        | 65    | 0      | 0      |

Router 192.168.0.2 LSA summary

| LSA Type     | Count | Delete | Maxage |
|--------------|-------|--------|--------|
| Router       | 1     | 0      | 0      |
| Network      | 0     | 0      | 0      |
| Summary Net  | 21    | 0      | 0      |
| Summary ASBR | 2     | 0      | 0      |
| Type-5 Ext   | 0     | 0      | 0      |
| Type-7 Ext   | 0     | 0      | 0      |
| Opaque Link  | 0     | 0      | 0      |
| Opaque Area  | 21    | 0      | 0      |
| Opaque AS    | 0     | 0      | 0      |
| Total        | 45    | 0      | 0      |

Router 192.168.0.6 LSA summary

| LSA Type     | Count | Delete | Maxage |
|--------------|-------|--------|--------|
| Router       | 1     | 0      | 0      |
| Network      | 0     | 0      | 0      |
| Summary Net  | 21    | 0      | 0      |
| Summary ASBR | 2     | 0      | 0      |
| Type-5 Ext   | 0     | 0      | 0      |
| Type-7 Ext   | 0     | 0      | 0      |
| Opaque Link  | 0     | 0      | 0      |
| Opaque Area  | 19    | 0      | 0      |
| Opaque AS    | 0     | 0      | 0      |
| Total        | 43    | 0      | 0      |

Router 192.168.0.3 LSA summary

| LSA Type     | Count | Delete | Maxage |
|--------------|-------|--------|--------|
| Router       | 0     | 0      | 0      |
| Network      | 0     | 0      | 0      |
| Summary Net  | 0     | 0      | 0      |
| Summary ASBR | 0     | 0      | 0      |

|             |    |   |   |
|-------------|----|---|---|
| Type-5 Ext  | 7  | 0 | 0 |
| Type-7 Ext  | 0  | 0 | 0 |
| Opaque Link | 0  | 0 | 0 |
| Opaque Area | 0  | 0 | 0 |
| Opaque AS   | 6  | 0 | 0 |
| Total       | 13 | 0 | 0 |

- **show ospf database database-summary adv-router *router ID*** command displays the router information and the LSAs received from the particular router.

Router#**show ospf database database-summary adv-router 192.168.0.4**

OSPF Router with ID (192.168.0.1) (Process ID 1)

Router 192.168.0.4 LSA summary

| LSA Type     | Count | Delete | Maxage |
|--------------|-------|--------|--------|
| Router       | 0     | 0      | 0      |
| Network      | 0     | 0      | 0      |
| Summary Net  | 0     | 0      | 0      |
| Summary ASBR | 0     | 0      | 0      |
| Type-5 Ext   | 697   | 0      | 0      |
| Type-7 Ext   | 0     | 0      | 0      |
| Opaque Link  | 0     | 0      | 0      |
| Opaque Area  | 0     | 0      | 0      |
| Opaque AS    | 6     | 0      | 0      |
| Total        | 703   | 0      | 0      |

## Limiting the Maximum Redistributed Type-3 LSA Prefixes in OSPF

Table 15: Feature History Table

| Feature Name   | Release       | Description   |
|--|---------------|---|
| Limiting the Maximum Redistributed Type-3 LSA Prefixes in OSPF | Release 7.9.1 | <p>By default, the maximum redistributed Type-3 LSA prefixes for a given OSPF process is now limited to 100000. This mechanism prevents OSPF from redistributing a large number of prefixes as Type-3 LSAs and therefore preventing high CPU utilization and memory shortages.</p> <p>Once the number of redistributed prefixes is reached or exceeds the threshold value, the system log message is generated, and no more prefixes are redistributed.</p> <p>Support was added to count only the number of redistributed prefixes instead of the number of LSAs. Individual prefixes are counted when multiple prefixes are aggregated in an LSA using the <b>summary-prefix</b> command.</p> |

Redistribution allows different routing protocols to exchange routing information. This is used to allow connectivity to span multiple routing protocols. Open Shortest Path First (OSPF) supports a user-defined maximum number of prefixes (routes) that are allowed to be redistributed into OSPF from other protocols or other OSPF instances.

Prior to Release 7.9.1, the maximum redistributed-prefixes limit was applied only to those prefixes that are redistributed as Type-5 and Type-7 LSAs. Starting from Release 7.9.1, the maximum redistributed-prefixes limit is also applied to the prefixes that are redistributed as Type-3 LSAs. The maximum redistributed Type-3 LSA prefixes for a given OSPF process is limited to 100000.

If the router redistributes more than 10000 prefixes as Type 3, 5, or 7 LSAs, then you must configure a higher limit using the **maximum redistributed-prefixes** command.

Starting from Release 7.9.1, if the **redistribute protocol lsa-type summary** command is configured to redistribute the routes from particular protocol as Type-3 LSAs, then those Type-3 LSAs are accounted for maximum redistributed prefixes.

### System output messages

The range of prefixes that are redistributed as Type-3 LSAs is 1-4294967295. The threshold percentage to log warning is 75%. The system log message is generated every 5% above the default or configured threshold value until 100% is reached.

When the number of LSAs reaches or exceeds the threshold limit, the router displays the following logs:

**The redistributed prefixes count reached the maximum limit**

```
%ROUTING-OSPF-4-REDIST_THR_PFX : Reached Redistribution prefix threshold
in vrf "default", current (70%) 700 prefixes, limit 1000
```

**The redistributed prefixes count exceeds the threshold percentage**

```
%ROUTING-OSPF-1-REDIST_MAX_PFX : Redistribution prefix limit has been
reached in vrf "default" - current 1000 prefixes, limit 1000
```

**The redistributed prefixes count falls below the threshold percentage**

```
%ROUTING-OSPF-5-REDIST_MAX_PFX_RECOVER : Recovered from Redistribution
limit-hit scenario in vrf "default", prefix count less than threshold -
current (69%) 699 prefixes, limit 1000
```

The **show ospf** command displays the maximum number of redistributed prefixes, which is configured at 1000.

```
Router #show ospf
Thu Dec  8 18:16:48.332 IST

Routing Process "ospf 1" with ID 192.168.0.1
Role: Primary Active
NSR (Non-stop routing) is Enabled
Supports only single TOS(TOS0) routes
Supports opaque LSA
It is an autonomous system boundary router
Maximum number of non self-generated LSA allowed 1000
  Current number of non self-generated LSA 804
  Threshold for warning message 60%
  Ignore-time 1 minutes, reset-time 2 minutes
  Ignore-count allowed 2, current ignore-count 0
Redistributing External Routes from,
  static
Maximum number of redistributed prefixes 1000
  Threshold for warning message 70%
  Current number of redistributed prefixes 100
```