



# Segment Routing Traffic Engineering Commands

This chapter describes the commands used to configure and use Segment Routing Traffic Engineering (SR-TE).

To use commands of this module, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using any command, contact your AAA administrator for assistance.

- [affinity-map](#), on page 2
- [autoroute include ipv6 all](#), on page 3
- [bgp prefix-path-label ignore](#), on page 4
- [binding-sid](#), on page 5
- [distribute link-state \(SRTE\)](#), on page 6
- [distribute link-state](#), on page 7
- [hw-module profile cef sropt enable](#), on page 8
- [kshortest-paths](#), on page 10
- [neighbor sr-policy name targeted](#), on page 11
- [on-demand constraints](#), on page 12
- [on-demand dynamic affinity sid-algorithm](#), on page 13
- [on-demand maximum-sid-depth](#), on page 14
- [on-demand source-address](#), on page 15
- [on-demand steering](#), on page 16
- [policy binding-sid](#), on page 17
- [policy candidate-paths](#), on page 18
- [policy color](#), on page 19
- [policy source-address](#), on page 20
- [policy steering](#), on page 21
- [segment-list](#), on page 22
- [separate-next-hop](#), on page 23
- [steering labeled-services](#), on page 24
- [te-latency](#), on page 25

# affinity-map

To define an affinity map, use the **affinity-map name name bit-position bit-position** command in SR-TE sub-mode.

```
affinity-map name name bit-position bit-position
```

## Syntax Description

<b>name name</b>	Specify the name of the affinity-map.
<b>bit-position bit-position</b>	Specify the bit position in the Extended Admin Group bitmask.

## Command Default

None

## Command Modes

SR-TE configuration

## Command History

Release	Modification
Release 7.3.1	This command was introduced.

## Usage Guidelines

Configure affinity maps on the following routers:

- Routers with interfaces that have an associated admin group attribute.
- Routers that act as SR-TE head-ends for SR policies that include affinity constraints.

## Example

This example shows how to define an affinity map:

```
Router# configure
Router(config)# segment-routing
Router(config-sr)# traffic-eng
Router(config-sr-te)# affinity-map
Router(config-sr-te-affinity-map)# name RED bit-position 23
```

# autoroute include ipv6 all

To enable IPv6 autoroute support for SR-TE policies with IPv4 endpoints, use the **autoroute include ipv6 all** command in the SR-TE policy and PCC profile modes. To disable this feature, use the **no** form of this command.

**autoroute include ipv6 all**  
**no autoroute include ipv6 all**

**Syntax Description** This command has no keywords or arguments.

**Command Default** IPv6 autoroute support is disabled.

**Command Modes** SR-TE policy  
 PCC profile

Command History	Release	Modification
	Release 7.5.4	This command was introduced.

**Usage Guidelines** The **include ipv6 all** command form enables autoroute support for IPv6 prefixes, for a specified SR-TE policy. This command can be used in the SR-TE policy and PCC profile modes.

## Example

The following example shows how to configure the IPv6 autoroute function for an SR-TE policy with an IPv4 endpoint:

```
Router# configure
Router(config)# segment-routing traffic-eng policy pol12
Router(config-sr-te-policy)# autoroute include ipv6 all
Router(config-sr-te-policy)# commit
```

The following example shows how to configure the IPv6 autoroute function for a PCE-instantiated SR-TE policy with an IPv4 endpoint:

```
Router# configure
Router(config)# segment-routing traffic-eng pcc profile 10
Router(config-pcc-prof)# autoroute include ipv6 all
Router(config-pcc-prof)# commit
```

## bgp prefix-path-label ignore

To indicate BGP to ignore the programming of the service route's prefix label when recursing onto the BSID of an SR-TE policy, use the **bgp prefix-path-label ignore** command in SR-TE policy steering config mode.

**bgp prefix-path-label ignore**

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	SR-TE policy steering
----------------------	-----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.9.1	This command was introduced.

<b>Usage Guidelines</b>	This command can be configured for manual SR policies.
-------------------------	--

### Example

The following example shows how to configure BGP to ignore the programming of the service route's prefix label when recursing onto the BSID of an SR-TE policy:

```
Router(config)# segment-routing
Router(config-sr)# traffic-eng
Router(config-sr-te)# policy POLICY1
Router(config-sr-te-policy)# steering
Router(config-sr-te-policy-steering)# bgp prefix-path-label ignore
```

# binding-sid

To specify the binding SID (BSID) allocation behavior, use the **binding-sid** command in SR-TE sub-mode.

```
binding-sid { dynamic disable | explicit { enforce-srlb | fallback-dynamic } }
```

## Syntax Description

<b>dynamic disable</b>	Disables dynamic binding SID allocation. Candidate paths without an explicit BSID will be considered invalid.
<b>explicit enforce-srlb</b>	Specifies strict SRLB enforcement. If the BSID is not within the SRLB, the policy stays down.
<b>explicitfallback-dynamic</b>	Specifies that, if the BSID is not available, the BSID is allocated dynamically and the policy comes up.

## Command Default

Binding SIDs are dynamically allocated

## Command Modes

SR-TE configuration

## Command History

Release	Modification
Release 7.3.1	This command was introduced.

## Usage Guidelines

Explicit BSIDs are allocated from the segment routing local block (SRLB) or the dynamic range of labels. A best-effort is made to request and obtain the BSID for the SR-TE policy. If requested BSID is not available (if it does not fall within the available SRLB or is already used by another application or SR-TE policy), the policy stays down.

This command specifies how the BSID allocation behaves if the BSID value is not available:

- Fallback to dynamic allocation – If the BSID is not available, the BSID is allocated dynamically and the policy comes up.
- Strict SRLB enforcement – If the BSID is not within the SRLB, the policy stays down.

## Example

This example shows how to configure an SR policy to use an explicit BSID of 1000. If the BSID is not available, the BSID is allocated dynamically and the policy comes up.

```
Router# configure
Router(config)# segment-routing
Router(config-sr)# traffic-eng
Router(config-sr-te)# binding-sid explicit fallback-dynamic
Router(config-sr-te)# policy goo
Router(config-sr-te-policy)# binding-sid mpls 1000
```

## distribute link-state (SRTE)

To enable reporting of SRTE policies, use the **distribute link-state** command in the SR-TE configuration mode.

**distribute link-state** [ **report-candidate-path-inactive** ]

*Table 1: Syntax Description:*

Syntax	Description
<b>report-candidate-path-inactive</b>	Enables reporting of SRTE policies using BGP-LS.

**Command Default** The reporting of policies to BGP-LS is disabled by default.

**Command Modes** SR-TE configuration (config-sr-te)

Command History	Release	Modification
	Release 24.1.1	Supports reporting of SR-TE policies using BGP- Link State for SRv6.
	Release 7.10.1	This command was introduced and supports reporting of SR-TE policies using BGP- Link State for SR-MPLS.

Task ID	Task ID	Operation
	distribute link-state	write/read

### Example

This example shows how to enable BGP-LS reporting and syncing of SRTE Policies:

```
Router# config
Router(config)# segment-routing
Router(config-sr)# traffic-eng
Router(config-sr-te)# distribute link-state
Router(config-sr-te-distribute-ls)# report-candidate-path-inactive
Router(config-sr-te-distribute-ls)# exit
```

# distribute link-state

To enable reporting of SRTE policies, use the **distribute link-state** command in the SR-TE configuration mode.

**distribute link-state** [ **report-candidate-path-inactive** ]

*Table 2: Syntax Description:*

Syntax	Description
<b>report-candidate-path-inactive</b>	Enables reporting of SRTE policies using BGP-LS.

**Command Default** The reporting of policies to BGP-LS is disabled by default.

**Command Modes** SR-TE configuration (config-sr-te)

Command History	Release	Modification
	Release 24.1.1	Supports reporting of SR-TE policies using BGP- Link State for SRv6.
	Release 7.10.1	This command was introduced and supports reporting of SR-TE policies using BGP- Link State for SR-MPLS.

Task ID	Task ID	Operation
	distribute link-state	write/read

## Example

This example shows how to enable BGP-LS reporting and syncing of SRTE Policies:

```
Router# config
Router(config)# segment-routing
Router(config-sr)# traffic-eng
Router(config-sr-te)# distribute link-state
Router(config-sr-te-distribute-ls)# report-candidate-path-inactive
Router(config-sr-te-distribute-ls)# exit
```

# hw-module profile cef sropt enable

To enable Segment Routing Encap object optimization, use the **hw-module profile cef sropt enable** command in XR Config mode.

## hw-module profile cef sropt enable

**Syntax Description** This command has no keywords or arguments.

**Command Default** Segment Routing Encap object optimization is disabled.

**Command Modes** XR Configuration

Command History	Release	Modification
	Release 7.5.4	This command was introduced.

**Usage Guidelines** After you enter this command, you must reload the router.

Segment Routing Encap object optimization minimizes the Encap resource consumption of the forwarding ASIC. With this feature, instead of consuming an Encap entry for each outgoing path, the forwarding chain of a labeled prefix with ECMP consumes only a single global Encap entry.

SR Encap object optimization is triggered only when all ECMP paths of a labeled prefix (primary and backup) perform the same egress action (either all pop or all swap); and have the same outgoing label for the swap egress action. If this condition is not met, then the prefix is programmed with a dedicated Encap object per outgoing path.

SR Encap object optimization is supported for both labeled IPv4 /32 (SR-MPLSv4) and labeled IPv6 /128 (SR-MPLSv6).

All paths associated with the prefix (primary and backup) must have the same outgoing label value for SR Encap object optimization to be triggered. For example:

- For prefixes with LFA backup paths, the SR Encap object optimization is triggered because these backup paths do not require an extra label to be pushed.
- For prefixes with TI-LFA backup paths requiring extra labels to be pushed, the SR Encap object optimization is not triggered because all the paths associated with the prefix do not have the same outgoing label value.

Per-label per-interface egress counters are not supported when SR Encap object optimization is enabled. Instead, per-label aggregate egress counters are supported.

SR MicroLoop Avoidance is not supported when SR Encap object optimization is enabled.

## Example

This example shows how to enable Segment Routing Encap object optimization:

```
Router(config)# hw-module profile cef sropt enable
```



In order to activate/deactivate SROPT feature, you must manually reload the chassis/all line cards

```
Router(config)# commit
Router(config)# end
```

```
Router# reload location all
Proceed with reload? [confirm] y
```

```
Router# show hw-module profile cef
```

```
-----
Knob                               Status           Applied          Action
-----
CBF Enable                          Unconfigured     N/A              None
CBF forward-class-list              Unconfigured     N/A              None
BGPLU                               Unconfigured     N/A              None
LPTS ACL                            Unconfigured     N/A              None
Dark Bandwidth                     Unconfigured     N/A              None
SR-OPT Enable                       Configured     Yes            None
IP Redirect Punt                    Unconfigured     N/A              None
IPv6 Hop-limit Punt                 Unconfigured     N/A              None
MPLS Per Path Stats                 Unconfigured     N/A              None
Tunnel TTL Decrement                Unconfigured     N/A              None
High-Scale No-LDP-Over-TE           Unconfigured     N/A              None
Label over TE counters              Unconfigured     N/A              None
Highscale LDPoTE No SRoTE           Unconfigured     N/A              None
LPTS Pifib Entry Counters           Unconfigured     N/A              None
-----
```

## kshortest-paths

To set the maximum number of attempts for SRTE to compute paths that satisfy cumulative metric bounds criteria, use the **kshortest-paths** command in SR-TE configuration mode. To revert to the default number of attempts (100), use the **no** form of the command.

**kshortest-paths** *max-attempts*

**no kshortest-paths**

---

### Syntax Description

*max-attempts* Maximum number of attempts.  
Choose a value between 1 and 200.

---

### Command Default

100 attempts are made to compute paths that satisfy the cumulative metric bounds criteria.

### Command Modes

SR-TE configuration (config-sr-te)

### Command History

Release	Modification
Release 7.3.1	This command was introduced.

---

### Usage Guidelines

By default, a maximum of 100 attempts are made. To update the value, you can use this command.

You can use the **show segment-routing traffic-eng policy color** command (**Number of K-shortest-paths** field) to see the K-shortest path algorithm computation result. For example, if the **Number of K-shortest-paths** field displays 4, it means that the K-shortest path algorithm took 4 computations to find the right path. The 4 shortest paths that are computed using K-shortest path algorithm did not respect the cumulative bounds, and the fifth shortest path was valid against the bounds.

### Example

This example shows how to set the maximum number of attempts for computing paths that satisfy the cumulative metric bounds criteria:

```
Router# configure terminal
Router(config)# segment-routing traffic-eng
Router(config-sr-te)# kshortest-paths 120
Router(config-sr-te)# commit
```

# neighbor sr-policy name targeted

To configure the SR policy name under LDP, use the **neighbor sr-policy *name* targeted** command in SR-TE configuration mode.

**neighbor sr-policy *name* targeted**

*Table 3: Syntax Description*

Syntax	Description
<i>name</i>	<p>Use the command to configure the SR policy name under LDP</p> <p><i>name</i> is the auto-generated SR policy name assigned by the router when creating an LDP targeted adjacency over an SR policy.</p> <p><b>Note</b> You can use the <b>show segment-routing traffic-eng policy</b> command to display the auto generated SR policy name. Auto-generated SR policy name uses the following naming convention: <b>srte_c_color_val_ep_endpoint-address</b>. For example, srte_c_1000_ep_10.1.1.2.</p>

**Command Default** None

**Command Modes** SR-TE configuration mode

Command History	Release	Modification
	Release 7.10.1	This command was introduced.

## Example

The following example shows how to configure the SR policy name under LDP:

```
Router(config)# mpls ldp
Router(config-ldp)# address-family ipv4
Router(config-ldp-af)# neighbor sr-policy srte_c_1000_ep_10.1.1.2 targeted
Router(config-ldp-af)#commit
```

## on-demand constraints



**Note** From Cisco IOS XR Release 7.9.1, you must reconfigure all SR-ODN configurations with Flexible Algorithm constraints that use the [on-demand dynamic sid-algorithm](#) with this command.

To configure the SR Flexible Algorithm constraints, use the **constraints segments sid-algorithm** command in SR-TE sub-mode.

**on-demand color** *color* **constraints segments sid-algorithm** *algo*

<b>Syntax Description</b>	<b>sid-algorithm</b> <i>algo</i> Specify the SR Flexible Algorithm value. The <i>algo</i> range is from 128 to 255.
---------------------------	---

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	SR-TE configuration
----------------------	---------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.4.1	This command was introduced.
	Release 7.9.1	You must reconfigure all SR-ODN configurations with Flexible Algorithm constraints that use the <a href="#">on-demand dynamic sid-algorithm</a> with this command.

<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.
-------------------------	--

### Example

```
Router(config-sr-te-color)# constraints segments sid-algorithm 128
```

# on-demand dynamic affinity sid-algorithm



**Note** You must reconfigure all SR-ODN configurations with Flexible Algorithm constraints that use this command with the **constraints segments sid-algorithm algo** command.

To configure the SR Flexible Algorithm constraints, use the **on-demand dynamic sid-algorithm** command in SR-TE sub-mode.

**on-demand color color dynamic sid-algorithm algo**

**Syntax Description** **sid-algorithm algo** Specify the SR Flexible Algorithm value . The *algo* range is from 128 to 255.

**Command Default** None

**Command Modes** SR-TE configuration

Command History	Release	Modification
	Release 6.3.1	This command was introduced.
	Release 7.4.1	This command was replaced by the <b>constraints segments sid-algorithm algo</b> command.
	Release 7.9.1	You must reconfigure all SR-ODN configurations with Flexible Algorithm constraints that use this command with the <b>constraints segments sid-algorithm algo</b> command.

**Usage Guidelines** This command was replaced by the **constraints segments sid-algorithm algo** command.

## Example

```
Router(config-sr-te-color-dyn)# sid-algorithm 128
```

# on-demand maximum-sid-depth

**Syntax Description**



**Command Default**

**Command Modes**

**Command History**

**Release    Modification**

**Usage Guidelines**

**Task ID**

**Task    Operation  
ID**

**Example**

# on-demand source-address

---

**Syntax Description** 

---

**Command Default**

---

**Command Modes**

---

**Command History** 

---

**Release** **Modification** 

---

---

**Usage Guidelines**

---

**Task ID** 

---

**Task** **Operation** **ID** 

---

**Example**

# on-demand steering

**Syntax Description**



**Command Default**

**Command Modes**

**Command History**

**Release    Modification**

**Usage Guidelines**

**Task ID**

**Task    Operation  
ID**

**Example**



# policy binding-sid

**Syntax Description** 

**Command Default**

**Command Modes**

**Command History** **Release** **Modification**

**Usage Guidelines**

<b>Task ID</b>	<b>Task</b>	<b>Operation</b>
	<b>ID</b>	

**Example**

# policy candidate-paths

**Syntax Description** 

**Command Default**

**Command Modes**

**Command History**

Release	Modification
---------	--------------

**Usage Guidelines**

Task ID	Task	Operation ID
---------	------	--------------

**Example**

# policy color

---

**Syntax Description**

---

**Command Default**

---

**Command Modes**

---

**Command History**

---

**Release Modification**

---

---

**Usage Guidelines**

---

**Task ID**

---

**Task Operation ID**

---

**Example**

# policy source-address

**Syntax Description** 

**Command Default**

**Command Modes**

**Command History** **Release** **Modification**

**Usage Guidelines**

**Task ID** **Task** **Operation**  
**ID**

**Example**

# policy steering

---

**Syntax Description** 

---

**Command Default**

---

**Command Modes**

---

**Command History** 

---

**Release** **Modification** 

---

---

**Usage Guidelines**

---

**Task ID** 

---

**Task** **Operation** **ID** 

---

**Example**

# segment-list

**Syntax Description**



**Command Default**

**Command Modes**

**Command History**

**Release    Modification**

**Usage Guidelines**

**Task ID**

**Task    Operation  
ID**

**Example**

# separate-next-hop

To enable SR-TE with next-hop independent scaling optimization, use the **separate-next-hop** command in ST-TE configuration mode.

## **segment-routing traffic-eng separate-next-hop**

This command has no keywords or arguments.

---

**Command Default** None

---

**Command Modes** SR-TE configuration

---

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.3.1	This command was introduced.

---

---

**Usage Guidelines**

**Example**

# steering labeled-services

**Syntax Description**



**Command Default**

**Command Modes**

**Command History**

**Release    Modification**

**Usage Guidelines**

**Task ID**

**Task    Operation  
ID**

**Example**



# te-latency

---

**Syntax Description**

---

---

**Command Default**

---

---

**Command Modes**

---

---

**Command History**

---

---

**Release** **Modification**

---

---

**Usage Guidelines**

---

---

**Task ID**

---

---

**Task** **Operation**  
**ID**

---

**Example**

te-latency