



L2VPN Commands

This section describes the commands used to configure Gigabit Ethernet services for Layer 2 VPNs.

By default, all interfaces are Layer 3 interfaces. You can change the interface to Layer 2 interface using the **l2transport** command.

For detailed information about concepts and configuration, see the *Introduction to Layer 2 Virtual Private Networks* chapter in the L2VPN and Ethernet Services Configuration Guide for Cisco 8000 Series Routers.

- [bridge-domain, on page 2](#)
- [bridge group, on page 3](#)
- [encapsulation dot1ad, on page 4](#)
- [encapsulation dot1q, on page 5](#)
- [encapsulation dot1q second-dot1q, on page 6](#)
- [flood mode ac-ingress-replication, on page 7](#)
- [interface, on page 8](#)
- [l2vpn, on page 10](#)
- [mac withdraw, on page 11](#)
- [pw-class encapsulation mpls, on page 12](#)
- [rewrite ingress tag, on page 13](#)
- [show l2vpn, on page 15](#)
- [show l2vpn bridge-domain, on page 16](#)
- [show l2vpn database, on page 20](#)
- [show l2vpn forwarding, on page 23](#)
- [show l2vpn protection main-interface, on page 26](#)
- [show l2vpn resource, on page 29](#)
- [show l2vpn trace, on page 30](#)
- [split-horizon group, on page 32](#)
- [storm-control , on page 33](#)
- [vpws-seamless-integration, on page 35](#)

bridge-domain

To establish a bridge domain and to enter L2VPN bridge group bridge domain configuration mode, use the **bridge-domain** command in L2VPN bridge group configuration submenu.

bridge-domain *bridge-domain-name*

Syntax Description

bridge-domain-name Name of the bridge domain.

Note The maximum number of characters that can be specified in the bridge domain name is 27.

Command Default

The default value is a single bridge domain.

Command Modes

L2VPN bridge group configuration

Command History

Release	Modification
Release 7.2.12	This command was introduced.

Usage Guidelines

Use the **bridge-domain** command to enter L2VPN bridge group bridge domain configuration mode.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to configure a bridge domain:

```
Router# configure
Router(config)# l2vpn
Router(config-l2vpn)# bridge group BG1
Router(config-l2vpn-bg)# bridge-domain BD1
Router(config-l2vpn-bg-bd)#
```

Related Commands

Command	Description
l2vpn, on page 10	Enters L2VPN configuration mode.
bridge group, on page 3	Creates a bridge group
show l2vpn bridge-domain, on page 16	Display information for the bridge ports such as attachment circuits for the specific bridge domains.

bridge group

To create a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain, use the **bridge group** command in L2VPN configuration mode. To remove all the bridge domains that are created under this bridge group and to remove all network interfaces that are assigned under this bridge group, use the **no** form of this command.

```
bridge group bridge-group-name
no bridge-group bridge-group-name
```

Syntax Description	<i>bridge-group-name</i> Number of the bridge group to which the interface belongs.
---------------------------	---

Command Default	No bridge group is created.
------------------------	-----------------------------

Command Modes	L2VPN configuration
----------------------	---------------------

Command History	Release	Modification
	Release 7.2.12	This command was introduced.

Usage Guidelines	Use the bridge group command to enter L2VPN bridge group configuration mode.
-------------------------	---

Task ID	Task	Operations
	l2vpn	read, write

Examples	The following example shows that bridge group 1 is assigned:
-----------------	--

```
Router# configure
Router(config)# l2vpn
Router(config-l2vpn)# bridge group BG1
Router(config-l2vpn-bg)#
```

Related Commands	Command	Description
	l2vpn, on page 10	Enters L2VPN configuration mode.
	bridge-domain, on page 2	Establishes a bridge domain

encapsulation dot1ad

To define the matching criteria to map 802.1ad frames ingress on an interface to the appropriate service instance, use the **encapsulation dot1ad** command in the interface configuration mode.

encapsulation dot1ad *vlan-id*

Syntax Description

vlan-id VLAN ID, can be given as single ID.

Command Default

No matching criteria are defined.

Command Modes

Interface configuration

Command History

Release	Modification
Release 7.3.2	This command was introduced.

Usage Guidelines

Only one encapsulation statement can be applied to a sub-interface. Encapsulation statements cannot be applied to main interfaces.

A single encapsulation dot1ad statement specifies matching for frames with a single VLAN ID.

Examples

The following example shows how to map 802.1ad frames ingress on an interface to the appropriate service instance:

```
Router(config-if)# encapsulation dot1ad 10
```

The following example shows how to map 802.1ad frames ingress on an l2transport sub-interface:

```
Router# configure
Router(config)# interface HundredGigE 0/0/0/24.1 l2transport
Router(config-subif)# encapsulation dot1ad 10
```

encapsulation dot1q

To define the matching criteria to map 802.1Q frames ingress on an interface to the appropriate service instance, use the **encapsulation dot1q** command in the interface configuration mode.

```
encapsulation dot1q vlan-id
```

Syntax Description

vlan-id VLAN ID, can be given as single ID.

Command Default

No matching criteria are defined.

Command Modes

Interface configuration

Command History

Release	Modification
Release 7.3.2	This command was introduced.

Usage Guidelines

Only one encapsulation statement can be applied to a sub-interface. Encapsulation statements cannot be applied to main interfaces.

A single encapsulation dot1q statement specifies matching for frames with a single VLAN ID.

Examples

The following example shows how to map 802.1Q frames ingress on an interface to the appropriate service instance:

```
Router(config-if) # encapsulation dot1q 10
```

The following example shows how to map 802.1Q frames ingress on an l2transport sub-interface:

```
Router# configure  
Router(config)# interface HundredGigE 0/0/0/24.1 l2transport  
Router(config-subif) # encapsulation dot1q 10
```

encapsulation dot1q second-dot1q

To define the matching criteria to map Q-in-Q ingress frames on an interface to the appropriate service instance, use the **encapsulation dot1q second-dot1q** command in interface configuration mode. To remove the configuration, use the **no** form of this command.

```
encapsulation dot1q vlan-id [{ second-dot1q vlan-id }]
```

Syntax Description

<i>vlan-id</i>	Specifies VLAN identifier.
dot1q	Specifies IEEE 802.1Q VLAN tagged packets.
second-dot1q	

Command Default

No matching criteria are defined.

Command Modes

Interface configuration

Command History

Release	Modification
Release 24.1.1	This command was introduced.

Usage Guidelines

The following restrictions are applicable for this command:

- The outer tag must be unique and the inner tag may be a single VLAN.
- Only one encapsulation command must be configured per VLAN service instance.
- Overlapping inner VLAN ranges are not supported.

Examples

The following example shows how to map ingress frames to a VLAN service instance:

```
Router#configure
Router(config)#interface TenGigE 0/0/0/1.102 l2transport
Router(config-subif)#encapsulation dot1q 200 second-dot1q 201
Router(config-subif)#commit
Router(config-subif)#exit
Router(config)#exit
```

flood mode ac-ingress-replication

To add BUM traffic queueing support for attachment circuits in a bridge domain, use the **flood mode ac-ingress-replication** command in the L2VPN bridge group bridge domain configuration mode.

flood mode ac-ingress-replication

This command has no keywords or arguments.

Command Default BUM traffic queueing support is not supported for attachment circuits in a bridge domain.

Command Modes L2VPN bridge group bridge domain configuration

Command History	Release	Modification
	Release 7.11.1	This command was introduced.

Usage Guidelines BUM traffic queueing support for attachment circuits in a bridge domain is not supported on devices that have multiple NPUs or line cards. It is only supported on single NPU devices.

Perform this task to add BUM traffic queueing support for attachment circuits in a bridge domain

```
Router# configure
Router(config)# l2vpn
Router(config-l2vpn)# bridge group 10
Router(config-l2vpn-bg)# bridge-domain 1
Router(config-l2vpn-bg-bd)# flood mode ac-ingress-replication
Router(config-l2vpn-bg-bd)# commit
```

interface

To create a VLAN interface or subinterface, use the **interface** command in global configuration mode.

```
interface type interface-path-id . subinterface
```

Syntax Description

<i>type</i>	Type of Ethernet interface on which you want to create a VLAN interface or subinterface. Enter HundredGigabitEthernet .
<i>interface-path-id</i>	Physical interface or virtual interface followed by the interface path ID. Naming notation is <i>interface-path-id</i> . For more information about the syntax for the router, use the question mark (?) online help function.
<i>subinterface</i>	Physical interface or virtual interface followed by the subinterface path ID. Naming notation is <i>interface-path-id.subinterface</i> . The period in front of the subinterface value is required as part of the notation. For more information about the syntax for the router, use the question mark (?) online help function.

Command Default

None

Command Modes

Global configuration mode

Command History

Release	Modification
Release 7.2.12	This command was introduced.

Usage Guidelines

For the *interface-path-id* argument, use the following guidelines:

- If specifying a physical interface, the naming notation is *rack/slot/module/port*. The slash between values is required as part of the notation. An explanation of each component of the naming notation is as follows:
 - *rack*: Chassis number of the rack.
 - *slot*: Physical slot number of the line card.
 - *module*: Module number. A physical layer interface module (PLIM) is always 0.
 - *port*: Physical port number of the interface.
- If specifying an Ethernet bundle interface, the range is from 1 through 65535.

For the *subinterface* argument, the range is from 0 through 4095.

To configure a large number of subinterfaces, we recommend entering all configuration data before you commit the **interface** command.

Usage Guidelines


Note A subinterface does not pass traffic without an assigned VLAN ID.

Task ID	Task ID	Operations
	vlan	read, write

Examples

This example shows how to configure a VLAN interface on a 100-Gigabit Ethernet interface:

```
Router# configure
Router(config)# interface HundredGigE 0/0/0/24
Router(config-subif)# dot1q vlan 1
Router(config-subif)# ipv4 address 10.0.0.1/8
```

This example shows how to configure a VLAN subinterface on a 100-Gigabit Ethernet interface:

```
Router# configure
Router(config)# interface HundredGigE 0/0/0/24.1
Router(config-subif)# dot1q vlan 1
Router(config-subif)# ipv4 address 10.0.0.1/8
```

To change an interface from Layer 2 to Layer 3 mode and back, you must delete the interface first and then re-configure it in the appropriate mode.

```
Router# configure
Router(config)# interface HundredGigE 0/0/0/24
Router(config-subif)# exit
Router(config)# no interface HundredGigE 0/0/0/24
```

l2vpn

To enter L2VPN configuration mode, use the **l2vpn** command in the global configuration mode. To return to the default behavior, use the **no** form of this command.

l2vpn

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Global Configuration mode

Command History	Release	Modification
	Release 7.2.12	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

The following example shows how to enter L2VPN configuration mode:

```
Router# configure
Router(config)# l2vpn
Router(config-l2vpn)#
```

Related Commands	Command	Description
	show l2vpn, on page 15	Displays L2VPN information

mac withdraw

To enable MAC address withdrawal for a specified bridge domain, use the **mac withdraw** command in L2VPN configuration mode.

mac withdraw [**disable** | **optimize** | **state-down**]

Syntax Description	disable	optimize	state-down
	Disables MAC address withdrawal.	Enables optimization of MAC address withdrawal when the bridge port goes down.	Sends MAC address withdrawal message when the bridge port goes down.

Command Default None

Command Modes L2VPN configuration mode

Command History	Release	Modification
	Release 7.2.12	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

The following example shows how to disable MAC address withdrawal.

```
Router# configure
Router(config)# l2vpn
Router(config-l2vpn)# bridge group bg1
Router(config-l2vpn-bg)# bridge-domain bd1
Router(config-l2vpn-bg-bd)# mac
Router(config-l2vpn-bg-bd-mac)# withdraw disable
```

The following example shows how to configure MAC address withdrawal when the bridge port goes down.

```
Router# configure
Router(config)# l2vpn
Router(config-l2vpn)# bridge group bg1
Router(config-l2vpn-bg)# bridge-domain bd1
Router(config-l2vpn-bg-bd)# mac
Router(config-l2vpn-bg-bd-mac)# withdraw state-down
```

The following example shows how to configure optimization of MAC address withdrawal when the bridge port goes down.

```
Router# configure
Router(config)# l2vpn
Router(config-l2vpn)# bridge group bg1
Router(config-l2vpn-bg)# bridge-domain bd1
Router(config-l2vpn-bg-bd)# mac
Router(config-l2vpn-bg-bd-mac)# withdraw optimize
```

pw-class encapsulation mpls

To configure MPLS pseudowire encapsulation, use the **pw-class encapsulation mpls** command in L2VPN pseudowire class configuration mode. To undo the configuration, use the **no** form of this command.

```
pw-class class-name encapsulation mpls { control-word | | load-balancing flow-label | both }
pw-class class-name encapsulation mpls { control-word | | load-balancing flow-label | both }
}
```

Syntax Description		
	<i>class-name</i>	Encapsulation class name.
	control-word	Disables control word for MPLS encapsulation. Disabled by default.
	load-balancing flow-label both	Sets flow-label based load balancing.

Command Default None

Command Modes L2VPN pseudowire class configuration

Command History	Release	Modification
	Release 7.3.15	This command was introduced.

Usage Guidelines



Note All L2VPN configurations can be deleted using the **no l2vpn** command.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

This example shows how to define MPLS pseudowire encapsulation:

```
Router# configure
Router(config)# l2vpn
Router(config-l2vpn)# pw-class path1
Router(config-l2vpn-pwc)# encapsulation mpls
Router(config-l2vpn-pwc-mpls)# control-word
Router(config-l2vpn-pwc-mpls)# load-balancing flow-label both
```

rewrite ingress tag

To specify the encapsulation adjustment that is to be performed on the frame ingress to the VLAN service instance, use the **rewrite ingress tag** command in the interface configuration mode. Use the following VLAN rewrite configuration to add or modify double dot1q VLAN tags on L2 Ethernet frames. To delete the encapsulation adjustment, use the **no** form of this command.

```
rewrite ingress tag {push {dot1q vlan-id} | pop {2} | translate {1-to-2 {dot1q vlan-id
second-dot1q vlan-id} | 2-to-2 {dot1q vlan-id second-dot1q vlan-id}}} [symmetric]
```

Syntax Description		
	<i>vlan-id</i>	Specifies VLAN identifier.
	push dot1q <i>vlan-id</i> second-dot1q <i>vlan-id</i>	Pushes the pair of 802.1Q tags with VLAN IDs.
	pop {2}	Specifies removal of the pair of 802.1Q tags from the packet.
	translate 1-to-2 dot1q <i>vlan-id</i> second-dot1q <i>vlan-id</i>	Replaces the incoming tag defined by the encapsulation command by a pair of 802.1Q tags.
	translate 2-to-2 dot1q <i>vlan-id</i> second-dot1q <i>vlan-id</i>	Replaces the pair of tags defined by the encapsulation command by a pair of VLANs defined by this rewrite.
	symmetric	(Optional) A rewrite operation is applied on both ingress and egress. The operation on egress is the inverse operation as ingress.
	Note	Symmetric is the default behavior. Hence, it cannot be disabled.

Command Default The Dot1q VLAN tags in the Ethernet frame is not modified on ingress.

Command Modes Interface configuration

Command History	Release	Modification
	Release 24.1.1	This command was introduced.

Usage Guidelines The **symmetric** keyword is accepted only when a single VLAN is configured in encapsulation. Define the elements being popped with an encapsulation type before using the **pop** command. Define the elements being translated with an encapsulation type before using the **rewrite ingress tag translate** command. In the 2-to-1 option, “2” means two tags of a type defined by the **encapsulation** command.

Examples

The following example shows how to specify the encapsulation adjustment that is to be performed on the frame ingress to the VLAN service instance:

```
Router#configure
Router(config)#interface TenGigE 0/0/0/1.102 12transport
Router(config-subif)#encapsulation dot1q 200 second-dot1q 201
```

```
Router(config-subif)#rewrite ingress tag pop 2 symmetric
Router(config-subif)#commit
Router(config-subif)#exit
Router(config)#exit
```

show l2vpn

To display L2VPN information, use the **show l2vpn** command in the EXEC mode.

show l2vpn

Syntax Description	This command has no keywords or arguments.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	Release 7.2.12	This command was introduced.

Usage Guidelines	No specific guidelines impact the use of this command.
-------------------------	--

Task ID	Task	Operation ID
	l2vpn	read

Example

The following example displays output for the **show l2vpn** command. The output provides an overview of the state of the globally configured features.

```
Router# show l2vpn

Mon Oct 12 14:14:48.869 UTC
HA role      : Active
ISSU role    : Primary
Process FSM  : PrimaryActive
-----
PW-Status:  enabled
PW-Grouping: disabled
Logging PW:  disabled
Logging BD  state changes: disabled
Logging VFI state changes: disabled
Logging NSR state changes: disabled
TCN propagation: disabled
PW OAM transmit time: 30s
```

Related Commands	Command	Description
	l2vpn, on page 10	Enters L2VPN configuration mode.

show l2vpn bridge-domain

To display information for the bridge ports such as attachment circuits for the specific bridge domains, use the **show l2vpn bridge-domain** command in EXEC Mode.

```
show l2vpn bridge-domain [{ autodiscovery bgp | bd-name bridge-domain-name | brief |
detail | group bridge-domain-group-name | hardware | interface type interface-path-id | location
node-id neighbor ip-address | summary | no-statistics | p2mp tunnel-id id | standby }]
```

Syntax	Description
autodiscovery bgp	(Optional) Displays BGP autodiscovery information.
bd-name <i>bridge-domain-name</i>	(Optional) Displays filter information on the <i>bridge-domain-name</i> . The <i>bridge-domain-name</i> argument is used to name a bridge domain.
brief	(Optional) Displays brief information about the bridges.
detail	(Optional) Displays detailed information about the bridges. Also, displays the output for the Layer 2 VPN (L2VPN) to indicate whether or not the MAC withdrawal feature is enabled and the number of MAC withdrawal messages that are sent or received from the AC.
group <i>bridge-domain-group-name</i>	(Optional) Displays filter information on the bridge-domain group name. The <i>bridge-domain-group-name</i> argument is used to name the bridge domain group.
hardware	(Optional) Displays hardware information.
interface <i>type interface-path-id</i>	(Optional) Displays the filter information for the interface on the bridge domain. Note Use the show interfaces command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
location <i>node-id</i>	(Optional) Displays the location specific information of the node.
neighbor <i>ip-address</i>	(Optional) Displays the bridge domains that contain the ACs to match the filter for the neighbor. The <i>ip-address</i> argument is used to specify IP address of the neighbor.
no-statistics	(Optional) Disables the collection of statistics for the bridge domain.
p2mp tunnel-id <i>id</i>	(Optional) Displays the bridge domain that contain the p2mp enabled bridge domain. The tunnel-id <i>id</i> argument is used too specify the tunnel of the p2mp brigde domain.
summary	(Optional) Displays the summary information for the bridge domain.
standby	(Optional) Displays whether the node is in the standby mode.

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	Release 7.2.12	This command was introduced.

Usage Guidelines Use the **interface** keyword to display only the bridge domain that contains the specified interface as an attachment circuit. In the sample output, only the attachment circuit matches the filter that is displayed.

Task ID	Task ID	Operations
		l2vpn

Examples

This is the sample output for **show l2vpn bridge-domain** command with VLAN parameters configured:

```
Router# show l2vpn bridge-domain bd-name BG1_BD1 detail
Legend: pp = Partially Programmed.
Bridge group: bgl, bridge-domain: bgl_bd1, id: 0, state: up, ShgId: 0, MSTi: 0
  Coupled state: disabled
  MAC learning: enabled
  MAC withdraw: enabled
    MAC withdraw for Access PW: enabled
    MAC withdraw sent on: bridge port up
    MAC withdraw relaying (access to access): disabled
  Flooding:
    Broadcast & Multicast: enabled
    Unknown unicast: enabled
  MAC aging time: 300 s, Type: inactivity
  MAC limit: 4000, Action: none, Notification: syslog
  MAC limit reached: no
  MAC port down flush: enabled
  MAC Secure: disabled, Logging: disabled
  Split Horizon Group: none
  Dynamic ARP Inspection: disabled, Logging: disabled
  IP Source Guard: disabled, Logging: disabled
  DHCPv4 snooping: disabled
  IGMP Snooping: enabled
  IGMP Snooping profile: none
  MLD Snooping profile: none
  Storm Control: disabled
  Bridge MTU: 1500
  MIB cvplsConfigIndex: 1
  Filter MAC addresses:
  P2MP PW: disabled
  Create time: 30/03/2015 22:25:38 (00:26:08 ago)
  No status change since creation
  ACs: 2 (2 up), VFIs: 1, PWs: 0 (0 up), PBBs: 0 (0 up)
  List of ACs:
    AC: BV11, state is up
      Type Routed-Interface
      MTU 1514; XC ID 0x80000001; interworking none
      BVI MAC address:
```

show l2vpn bridge-domain

```

    1000.4444.0001
AC: HundredgiabitEthernet0/0/0/0.1, state is up
  Type VLAN; Num Ranges: 1
  Outer Tag: 1
  VLAN ranges: [1001, 1001]
  MTU 1508; XC ID 0x508000a; interworking none
  MAC learning: enabled
  Flooding:
    Broadcast & Multicast: enabled
    Unknown unicast: enabled
  MAC aging time: 300 s, Type: inactivity
  MAC limit: 4000, Action: none, Notification: syslog
  MAC limit reached: no
  MAC port down flush: enabled
  MAC Secure: disabled, Logging: disabled
  Split Horizon Group: none
  Dynamic ARP Inspection: disabled, Logging: disabled
  IP Source Guard: disabled, Logging: disabled
  DHCPv4 snooping: disabled
  IGMP Snooping: enabled
  IGMP Snooping profile: none
  MLD Snooping profile: none
  Storm Control: bridge-domain policer
  Static MAC addresses:

  Storm control drop counters:
    packets: broadcast 0, multicast 0, unknown unicast 0
    bytes: broadcast 0, multicast 0, unknown unicast 0
  Dynamic ARP inspection drop counters:
    packets: 0, bytes: 0
  IP source guard drop counters:
    packets: 0, bytes: 0
List of VNIs:
  VNI 1, state is up
  XC ID 0x80000014
  Encap type VXLAN
  Overlay nve100, Source 10.0.0.1, Multicast Group 225.1.1.1, UDP Port 4789
  Anycast VTEP 100.1.1.1, Anycast Multicast Group 224.10.10.1
  MAC learning: enabled
  Flooding:
    Broadcast & Multicast: enabled
    Unknown unicast: enabled
  MAC aging time: 300 s, Type: inactivity
  MAC limit: 4000, Action: none, Notification: syslog
  MAC limit reached: no
  MAC port down flush: enabled
  MAC Secure: disabled, Logging: disabled
  Split Horizon Group: none
  Dynamic ARP Inspection: disabled, Logging: disabled
  IP Source Guard: disabled, Logging: disabled
  DHCPv4 snooping: disabled
  IGMP Snooping: enabled
  IGMP Snooping profile: none
  MLD Snooping profile: none
  Storm Control: bridge-domain policer

List of Access PWs:
List of VFIs:
  VFI bgl_bdl_vfi (up)
  VFI Statistics:
    drops: illegal VLAN 0, illegal length 0

```

Verify the EVPN and VPLS status.

```
Router# show l2vpn bridge-domain
Legend: pp = Partially Programmed.
Bridge group: vplstoevpn, bridge-domain: vplstoevpn, id: 0, state: up, ShgId: 0, MSTi: 0
Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
Filter MAC addresses: 0
ACs: 1 (1 up), VFIs: 1, PWs: 2 (1 up), PBBs: 0 (0 up), VNIs: 0 (0 up)
List of EVPNs:
  EVPN, state: up
List of ACs:
  Hu0/0/0/0, state: up, Static MAC addresses: 0, MSTi: 5
List of Access PWs:
List of VFIs:
  VFI vpls (up)
    Neighbor 172.16.0.1 pw-id 12, state: down, Static MAC addresses: 0
    Neighbor 192.168.0.1 pw-id 13, state: up, Static MAC addresses: 0
```

This indicates that VPLS and EVPN L2 bridging for the same VPN instance coexists and EVPN takes precedence over VPLS.

Related Commands

Command	Description
l2vpn, on page 10	Enters L2VPN configuration mode.
show l2vpn, on page 15	Displays L2VPN information

show l2vpn database

To display L2VPN database, use the **show l2vpn database** command in EXEC mode.

```
show l2vpn database {ac | node}
```

Syntax Description	ac Displays L2VPN Attachment Circuit (AC) database				
	node Displays L2VPN node database.				
Command Default	None				
Command Modes	EXEC mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.2.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.2.12	This command was introduced.
Release	Modification				
Release 7.2.12	This command was introduced.				
Usage Guidelines	Even when xSTP (extended spanning tree protocol) operates in the PVRST mode, the output of the show or debug commands flag prefix is displayed as MSTP or MSTi, instead of PVRST.				
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>l2vpn</td> <td>read</td> </tr> </tbody> </table>	Task ID	Operation	l2vpn	read
Task ID	Operation				
l2vpn	read				

The following example displays output for the **show l2vpn database ac** command:

```
Router# show l2vpn database ac

Mon Oct 12 14:15:47.731 UTC
Bundle-Ether1:
  Other-Segment MTU: 0
  Other-Segment status flags: 0x3
  Signaled capability valid: Yes
  Signaled capability flags: 0x360018
  Configured capability flags: 0x0
  XCID: 0xa0000001
  PSN Type: Undefined
  ETH data:
    Xconnect tags: 0
    Vlan rewrite tag: 0
  AC defn:
    ac-ifname: Bundle-Ether1
    capabilities: 0x00368079
    extra-capabilities: 0x00000000
    parent-ifh: 0x00000000
    ac-type: 0x04
    interworking: 0x00
  AC info:
    seg-status-flags: 0x00000003
    segment mtu/l2-mtu: 1500/1514
```

```

HundredGigE0/0/0/0.1:
  Other-Segment MTU: 0
  Other-Segment status flags: 0x3
  Signaled capability valid: Yes
  Signaled capability flags: 0x360018
  Configured capability flags: 0x0
  XCID: 0xea
  PSN Type: Undefined
  ETH data:
    Xconnect tags: 0
    Vlan rewrite tag: 0
  AC defn:
    ac-iframe: HundredGigE0_0_0_0.1
    capabilities: 0x00368079
    extra-capabilities: 0x00000000
    parent-ifh: 0x08000018
    ac-type: 0x15
    interworking: 0x00
  AC info:
    seg-status-flags: 0x00000003
    segment mtu/l2-mtu: 1504/1518

```

The following example displays output for the **show l2vpn database node** command:

```

Router# show l2vpn database node
Mon Oct 12 14:16:30.540 UTC
Node ID: 0x1000 (0/RP0/CPU0)
MA: vlan_ma      inited:1, flags:0x 2, circuits:3744
  AC event trace history [Total events: 4]
  -----
  Time           Event                               Num Rcvd   Num Sent
  ====          =====
  10/12/2015 12:46:00 Process joined                       0           0
  10/12/2015 12:46:00 Process init success                 0           0
  10/12/2015 12:46:00 Replay start rcvd                   0           0
  10/12/2015 12:46:00 Replay end rcvd                      0           0

MA: ether_ma     inited:1, flags:0x 2, circuits:2
  AC event trace history [Total events: 4]
  -----
  Time           Event                               Num Rcvd   Num Sent
  ====          =====
  10/12/2015 12:41:19 Process joined                       0           0
  10/12/2015 12:41:19 Process init success                 0           0
  10/12/2015 12:41:19 Replay start rcvd                   0           0
  10/12/2015 12:41:19 Replay end rcvd                      0           0

MA: atm_ma       inited:0, flags:0x 0, circuits:0
MA: hdlc_ma      inited:0, flags:0x 0, circuits:0
MA: fr_ma        inited:0, flags:0x 0, circuits:0
MA: ppp_ma       inited:0, flags:0x 0, circuits:0
MA: cem_ma       inited:0, flags:0x 0, circuits:0
MA: vif_ma       inited:0, flags:0x 0, circuits:0
MA: pwhe_ma      inited:0, flags:0x 0, circuits:0
MA: nve_mgr      inited:0, flags:0x 0, circuits:0
MA: mstp         inited:0, flags:0x 0, circuits:0
MA: span         inited:0, flags:0x 0, circuits:0
MA: erp          inited:0, flags:0x 0, circuits:0
MA: erp_test     inited:0, flags:0x 0, circuits:0

```

show l2vpn database

```
MA: mstp_test   initied:0, flags:0x 0, circuits:0
MA: evpn        initied:0, flags:0x 0, circuits:0
```

Related Commands

Command	Description
l2vpn, on page 10	Enters L2VPN configuration mode.
show l2vpn, on page 15	Displays L2VPN information

show l2vpn forwarding

To display forwarding information from the layer2_fib manager, use the **show l2vpn forwarding** command in EXEC mode.

show l2vpn forwarding {**counter** | **debug** | **detail** | **hardware** | **interface** | **location** [*node-id*] | **private**}

Syntax Description		
counter		Displays the cross-connect counters.
debug		Displays debug information.
detail		Displays detailed information from the layer2_fib manager.
hardware		Displays hardware-related layer2_fib manager information.
interface		Displays the match AC subinterface.
location <i>node-id</i>		Displays layer2_fib manager information for the specified location. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
private		Output includes private information.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	Release 7.2.12	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	l2vpn	read

Examples

The following sample output is from the **show l2vpn forwarding** command:

```
Router# show l2vpn forwarding location 0/RP0/CPU0
Mon Oct 12 14:19:11.771 UTC
Segment 1                               Segment 2                               State
-----
Hu0/0/0/0.234                           ac Hu0/0/0/26.234                       UP
Hu0/0/0/0.233                           ac Hu0/0/0/26.233                       UP
Hu0/0/0/0.232                           ac Hu0/0/0/26.232                       UP
Hu0/0/0/0.231                           ac Hu0/0/0/26.231                       UP
Hu0/0/0/0.230                           ac Hu0/0/0/26.230                       UP
```

The following sample output is from the **show l2vpn forwarding counter location** command:

```
Router# show l2vpn forwarding counter location 0/RP0/CPU0

Mon Oct 12 14:18:01.194 UTC
Legend: ST = State, DN = Down

Segment 1                               Segment 2                               ST Byte
-----                               -----                               -
Hu0/0/0/0.234                           ac Hu0/0/0/26.234                       UP 15098997504
Hu0/0/0/0.233                           ac Hu0/0/0/26.233                       UP 15098997568
Hu0/0/0/0.232                           ac Hu0/0/0/26.232                       UP 15098997504
Hu0/0/0/0.231                           ac Hu0/0/0/26.231                       UP 15098997568
HU0/0/0/0.230                           ac Hu0/0/0/26.230                       UP 15098997568
```

The following sample output is from the **show l2vpn forwarding summary location** command:

```
Router# show l2vpn forwarding summary location 0/RP0/CPU0
Thu Oct 22 06:14:17.767 UTC
To Resynchronize MAC table from the Network Processors, use the command...
    l2vpn resynchronize forwarding mac-address-table location <r/s/i>

Major version num:721, minor version num:2
Shared memory timestamp:0x19c9b0f580
Global configuration:
Number of forwarding xconnect entries:0
  Up:0  Down:0
  AC-PW(atom):0 AC-PW(iid):0 AC-PW(l2tpv2):0 AC-PW(l2tpv3):0
  AC-PW(l2tpv3-ipv6):0
  AC-AC:0 AC-BP:0 (PWHE AC-BP:0) AC-Unknown:0
  PW-BP:0 PW-Unknown:0
  PBB-BP:0 PBB-Unknown:0
  EVPN-BP:0 EVPN-Unknown:0
  VNI-BP:0 VNI-Unknown:0
  Monitor-Session-PW:0 Monitor-Session-Unknown:0
Number of xconnects down due to:
  AIB:0 L2VPN:0 L3FIB:0 VPDN:0
Number of xconnect updates dropped due to:
  Invalid XID: 0 VPWS PW, 0 VPLS PW, 0 Virtual-AC, 0 PBB,
  0 EVPN
  0 VNI
  0 Global
  Exceeded max allowed: 0 VPLS PW, 0 Bundle-AC
Number of p2p xconnects: 0
Number of bridge-port xconnects: 0
Number of nexthops:0
Number of bridge-domains: 0
  0 with routed interface
  0 with PBB-EVPN enabled
  0 with EVPN enabled
  0 with p2mp enabled
Number of bridge-domain updates dropped: 0
Number of total macs: 0
  0 Static macs
  0 Routed macs
  0 BMAC
  0 Source BMAC
  0 Locally learned macs
  0 Remotely learned macs
Number of total ipmacs: 0
  0 Locally learned ip4macs
  0 Remotely learned ip4macs
```



```

0 Locally learned ip6macs
0 Remotely learned ip6macs
Number of total P2MP Ptree entries: 0
Number of PWHE Main-port entries: 0
Number of EVPN Multicast Replication lists: 0 (0 default, 0 stitching, 0 isid)

```

The following sample output is from the **show l2vpn forwarding detail location** command:

```

Router# show l2vpn forwarding detail location 0/RP0/CPU0

Mon Oct 12 14:18:47.187 UTC
Local interface: HundredGigE 0/0/0/24, Xconnect id: 0x1, Status: up
  Segment 1
    AC, HundredGigE 0/0/0/24, status: Bound
    Statistics:
      packets: received 238878391, sent 313445
      bytes: received 15288217024, sent 20060480
      packets dropped: PLU 0, tail 0
      bytes dropped: PLU 0, tail 0
  Segment 2
    AC, HundredGigE 0/0/0/24, status: Bound

Local interface: HundredGigE 0/0/0/25, Xconnect id: 0x2, Status: up
  Segment 1
    AC, HundredGigE 0/0/0/25, status: Bound
    Statistics:
      packets: received 238878392, sent 313616
      bytes: received 15288217088, sent 20071424
      packets dropped: PLU 0, tail 0
      bytes dropped: PLU 0, tail 0
  Segment 2
    AC, HundredGigE 0/0/0/25, status: Bound

Local interface: HundredGigE 0/0/0/24, Xconnect id: 0x3, Status: up
  Segment 1
    AC, HundredGigE 0/0/0/24, status: Bound
    Statistics:
      packets: received 238878391, sent 313476
      bytes: received 15288217024, sent 20062464
      packets dropped: PLU 0, tail 0
      bytes dropped: PLU 0, tail 0
  Segment 2
    AC, HundredGigE 0/0/0/24, status: Bound

```

Related Commands

Command	Description
l2vpn, on page 10	Enters L2VPN configuration mode.
show l2vpn, on page 15	Displays L2VPN information
show l2vpn database, on page 20	Displays L2VPN database

show l2vpn protection main-interface

To display an overview of the main interface or instance operational information, use the **show l2vpn protection main-interface** command in EXEC mode.

```
show l2vpn protection main-interface [ interface name { Interface } ] [{ brief | detail | private
}]
```

Syntax Description		
	<i>interface name</i>	Interface name of the Ethernet ring G.8032 name.
	<i>interface</i>	The forwarding interface ID in number or in Rack/Slot/Instance/Port format as required.
	brief	Brief information about the G.8032 ethernet ring configuration.
	detail	Information in detail about the G.8032 ethernet ring configuration.
	private	Private information about the G.8032 ethernet ring configuration.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 7.2.12	This command was introduced.
	Release 7.7.1	The command output was enhanced to include protection access gateway subtype indication MST-AG.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	l2vpn	read

Example

This example shows the output from the **show l2vpn protection main-interface** command:

```
RP/0/0/CPU0:router# show l2vpn protection main-interface

Main Interface ID          Subintf Count  Protected  Blocked
-----
GigabitEthernet0/0/0/0    1              None       No
```

```

Instance : 0
  State      : FORWARDING
  Sub-Intf # : 1
  Flush #    : 0
  Sub-interfaces : GigabitEthernet0/0/0/0.4

```

Main Interface ID	Subintf Count	Protected	Blocked
GigabitEthernet0/0/0/1	1	None	No

```

Instance : 0
  State      : FORWARDING
  Sub-Intf # : 1
  Flush #    : 0
  Sub-interfaces : GigabitEthernet0/0/0/0.4

```

```

RP/0/0/CPU0:ios#show l2vpn protection main-interface gigabitEthernet 0/0/0/1
Tue Mar 15 10:54:13.366 EDT

```

Main Interface ID	# of subIntf	Protected	Protect Type
GigabitEthernet0/0/0/1	2	Yes	MST-AG

```

Instance : 0
  State      : FORWARDING
  Sub-Intf # : 1
  Flush #    : 1

```

```

Instance : 1
  State      : BLOCKED
  Sub-Intf # : 1
  Flush #    : 0

```

```

RP/0/0/CPU0:ios#show l2vpn protection main-interface gigabitEthernet 0/0/0/2
Tue Mar 15 10:54:15.044 EDT

```

Main Interface ID	# of subIntf	Protected	Protect Type
GigabitEthernet0/0/0/2	2	Yes	STP

```

Instance : 0
  State      : FORWARDING
  Sub-Intf # : 1
  Flush #    : 0

```

```

Instance : 1
  State      : FORWARDING
  Sub-Intf # : 1
  Flush #    : 0

```

```

RP/0/0/CPU0:router# show l2vpn protection main-interface brief

```

Main Interface ID	Ref Count	Instance	Protected	State
GigabitEthernet0/0/0/0	3	2	No	FORWARDING
GigabitEthernet0/0/0/1	1	1	No	FORWARDING

```

RP/0/RSP0/CPU0:router# show l2vpn protection main-interface detail

```

Main Interface ID	# of subIntf	Protected
GigabitEthernet0/1/0/19	4	No

Main Interface ID	# of subIntf	Protected

show l2vpn protection main-interface

```

GigabitEthernet0/1/0/20      3          No
-----
Main Interface ID           # of subIntf Protected
-----
GigabitEthernet0/1/0/3      2          No
-----
Main Interface ID           # of subIntf Protected
-----
GigabitEthernet0/1/0/30    1          No
-----
Main Interface ID           # of subIntf Protected
-----
GigabitEthernet0/1/0/7     4          No

```

RP/0/0/CPU0:router# show l2vpn protection main-interface private

```

Main Interface ID           Ref Count  Protected  Blocked  If Handle  Registered
-----
GigabitEthernet0/0/0/0     3          None       No       0x20000020 No

```

Instance : 0

```

State       : FORWARDING      Config ID : 0
Sub-Intf #  : 0                Ack       # : 0
Bridge D #  : 0                N-Ack    # : 0
Flush #     : 0                Rcv       # : 0
Sub-interfaces : GigabitEthernet0/0/0/0.4

```

Instance event trace history [Total events: 1, Max listed: 8]

```

-----
Time          Event                      State          Action
=====
01/01/1970 01:00:01 Rcv state IF known      Invalid        134833160
07/02/2010 10:13:03 Update L2FIB             FORWARDING     0
01/01/1970 01:00:25 Rcvd AC MA create + UP I/F ST FORWARDING     0

```

Related Commands

Command	Description
l2vpn	Enters L2VPN configuration mode.

show l2vpn resource

To display the memory state in the L2VPN process, use the **show l2vpn resource** command in EXEC mode.

show l2vpn resource

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	Release 7.2.12	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	l2vpn	read

Examples

The following example shows a sample output for the **show l2vpn resource** command:

```
Router# show l2vpn resource
Wed Oct 14 11:27:23.447 UTC
Memory: Normal
```

This table describes the significant fields shown in the display.

Table 1: show l2vpn resource Command Field Descriptions

Field	Description
Memory	Displays memory status.

Related Commands	Command	Description
	l2vpn, on page 10	Enters L2VPN configuration mode.
	show l2vpn, on page 15	Displays L2VPN information

show l2vpn trace

To display trace data for L2VPN, use the **show l2vpn trace** command in EXEC mode.

```
show l2vpn trace [checker] |[file filename filepath] |[last entry] |[location node-id]
|[udir path] [reverse] |[stats] |[tailf] |[usec] |[verbose] |[wide]
```

Syntax Description	Parameter	Description
	checker	Displays trace data for the L2VPN Uberverifier.
	file filename filepath	Displays trace data for the specified file.
	hexdump	Display traces data in hexadecimal format.
	last entry	Display last <n> entries
	location node-id	Displays trace data for the specified location.
	reverse	Display latest traces first
	stats	Display trace statistics
	tailf	Display new traces as they are added
	unique	Display unique entries with counts
	usec	Display usec details with timestamp
	udir path	Display a temporary directory to copy traces from remote locations
	verbose	Display internal debugging information
	wide	Display trace data excluding buffer name, node name, tid
	wrapping	Display wrapping entries

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	Release 7.2.12	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	l2vpn	read

This example displays output for the **show l2vpn trace** command:

```
Router# show l2vpn trace
Mon Oct 12 14:22:09.082 UTC
188 unique entries (2596 possible, 0 filtered)
Oct 12 12:37:44.197 l2vpn/policy 0/RP0/CPU0 1# t4349 POLICY:320: l2vpn_policy_reg_agent
started - route_policy_supported=False, forward_class_supported=False
Oct 12 12:39:21.870 l2vpn/fwd-pd 0/RP0/CPU0 1# t5664 FWD_PD:731:
Oct 12 12:39:21.883 l2vpn/fwd-err 0/RP0/CPU0 1# t5664 FWD_ERR|ERR:76: Major version mis-match,
SHM: 0x0 Expected: 0x1
Oct 12 12:39:21.883 l2vpn/fwd-err 0/RP0/CPU0 1# t5664 FWD_ERR|ERR:87: Magic number mis-match,
SHM: 0x0 Expected: 0xa7b6c3d8
Oct 12 12:39:21.884 l2vpn/err 0/RP0/CPU0 1# t5664 FWD_ERR|ERR:76: Major version mis-match,
SHM: 0x0 Expected: 0x1
Oct 12 12:39:21.884 l2vpn/err 0/RP0/CPU0 1# t5664 FWD_ERR|ERR:87: Magic number mis-match,
SHM: 0x0 Expected: 0xa7b6c3d8
Oct 12 12:39:21.890 l2vpn/fwd-detail 0/RP0/CPU0 1# t5664 FWD_DETAIL:263: PWGROUP Table init
succeeded
Oct 12 12:39:21.890 l2vpn/fwd-detail 0/RP0/CPU0 2# t5664 FWD_DETAIL:416: l2tp session table
rebuilt
Oct 12 12:39:21.903 l2vpn/fwd-common 0/RP0/CPU0 1# t5664 FWD_COMMON:39: L2FIB_OBJ_TRACE:
trace_buf=0x7d48e0
Oct 12 12:39:25.613 l2vpn/issu 0/RP0/CPU0 1# t5664 ISSU:790: ISSU - imdr init called;
'infra/imdr' detected the 'informational' condition 'the service is not supported in the
node'
Oct 12 12:39:25.613 l2vpn/issu 0/RP0/CPU0 1# t5664 ISSU:430: ISSU - attempt to start
COLLABORATOR wait timer while not in ISSU mode
Oct 12 12:39:25.638 l2vpn/fwd-common 0/RP0/CPU0 1# t5664 FWD_COMMON:4241: show edm thread
initialized
Oct 12 12:39:25.781 l2vpn/fwd-mac 0/RP0/CPU0 1# t5664 FWD_MAC|ERR:783: Mac aging init
Oct 12 12:39:25.781 l2vpn/fwd-mac 0/RP0/CPU0 2# t5664 FWD_MAC:1954: l2vpn_gsp_cons_init
returned Success
Oct 12 12:39:25.781 l2vpn/err 0/RP0/CPU0 1# t5664 FWD_MAC|ERR:783: Mac aging init
Oct 12 12:39:25.782 l2vpn/fwd-aib 0/RP0/CPU0 4# t5664 FWD_AIB:446: aib connection opened
successfully
Oct 12 12:39:25.783 l2vpn/fwd-mac 0/RP0/CPU0 2# t5664 FWD_MAC:2004: Client successfully
joined gsp group
Oct 12 12:39:25.783 l2vpn/fwd-mac 0/RP0/CPU0 1# t5664 FWD_MAC:781: Initializing the txlist
IPC thread
Oct 12 12:39:25.783 l2vpn/fwd-mac 0/RP0/CPU0 1# t5664 FWD_MAC:3195: gsp_optimal_msg_size =
31264 (real: True)
Oct 12 12:39:25.783 l2vpn/fwd-mac 0/RP0/CPU0 1# t5664 FWD_MAC:626: Entering mac aging timer
init
Oct 12 12:39:25.783 l2vpn/fwd-mac 0/RP0/CPU0 1# t7519 FWD_MAC:725: Entering event loop for
mac txlist thread
Oct 12 12:39:25.797 l2vpn/fwd-mac 0/RP0/CPU0 1# t4222 FWD_MAC:2221: learning_client_colocated
0, is_client_netio 1
```

Related Commands

Command	Description
l2vpn, on page 10	Enters L2VPN configuration mode.
show l2vpn, on page 15	Displays L2VPN information
show l2vpn resource, on page 29	Displays the memory state in the L2VPN process.

split-horizon group

To add an AC to a split horizon group, use the **split-horizon group** command in L2VPN bridge group bridge domain attachment circuit configuration mode.

split-horizon group

Syntax Description	This command has no keywords or arguments.	
Command Default	None	
Command Modes	L2VPN bridge group bridge domain attachment circuit configuration mode	
Command History	Release	Modification
	Release 7.11.1	This command was introduced.

Usage Guidelines Only one split horizon group exists for ACs per bridge domain. By default, the group does not have any ACs. You can configure individual ACs to become members of the group using the **split-horizon group** configuration command.

You can configure an entire physical interface or EFPs within an interface to become members of the split horizon group.

Task ID	Task ID	Operations
	l2vpn	Read, write

Examples

The following example shows the split horizon group configuration:

```
Router# configure
Router(config)# l2vpn
Router(config-l2vpn)# bridge group bg
Router(config-l2vpn-bg)# bridge-domain bd
Router(config-l2vpn-bg-bd-ac)# interface Ten0/7/0/22/0 <- (split-horizon group 0, default)
Router(config-l2vpn-bg-bd-ac)# interface Ten0/7/0/22/1.1
Router(config-l2vpn-bg-bd-ac)# split-horizon group <- (split-horizon group 2)
Router(config-l2vpn-bg-bd-ac)# neighbor 10.0.0.1 pw-id 1
Router(config-l2vpn-bg-bd-pw)# split-horizon group <- (split-horizon group 2)
Router(config-l2vpn-bg-bd-pw)# vfi vf
Router(config-l2vpn-bg-bd-vfi)# neighbor 172.16.0.1 pw-id 10001 <- (split-horizon group 1,
default)
Router(config-l2vpn-bg-bd-vfi-pw)# commit
```


storm-control

To enable storm control on an access circuit (AC) under a VPLS bridge, use the **storm-control** command in l2vpn bridge group bridge-domain access circuit configuration mode. To disable storm control, use the **no** form of this command.

```
storm-control { broadcast | multicast | unknown-unicast } { pps pps-value | kbps kbps-value }
no storm-control { broadcast | multicast | unknown-unicast } { pps pps-value | kbps kbps-value }
```

Syntax Description		
broadcast		Configures storm control for broadcast traffic.
multicast		Configures storm control for multicast traffic.
unknown-unicast		Configures storm control for unknown unicast traffic. <ul style="list-style-type: none"> Storm control does not apply to bridge protocol data unit (BPDU) packets. All BPDU packets are processed as if traffic storm control is not configured. Storm control does not apply to internal communication and control packets, route updates, SNMP management traffic, Telnet sessions, or any other packets addressed to the router.
pps pps-value		Configures the packets-per-second (pps) storm control threshold for the specified traffic type. Valid values range from 1 to 160000.
kbps kbps-value		Configures the storm control in kilo bits per second (kbps). The range is from 64 to 1280000.

Command Default Storm control is disabled by default.

Command Modes l2vpn bridge group bridge-domain access circuit configuration

Command History	Release	Modification
	Release 7.3.2	This command was introduced.

- Usage Guidelines**
- Storm control is supported on main ports only.
 - Storm control configuration is supported at the bridge-port level, and not at the bridge-domain level.
 - PW-level storm control is not supported.
 - Storm control is not supported through QoS input policy.
 - Although pps is configurable, it is not natively supported. PPS configuration is converted to a kbps value assuming a 256 byte packet size when configuring the hardware policers.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

The following example enables two storm control thresholds on an access circuit:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group BG1
RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain BD1
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# interface HundredGigE0/0/0/0
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-ac)# storm-control broadcast kbps 4500
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-ac)# commit
```

vpws-seamless-integration

To enable EVPN-VPWS seamless integration, use the **vpws-seamless-integration** command in L2VPN configuration mode. To disable EVPN-VPWS seamless integration, use the **no** form of this command.

vpws-seamless-integration

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes L2VPN configuration mode

Command History	Release	Modification
	Release 7.8.1	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	L2VPN	read, write

Examples

The following example shows how to enable EVPN-VPWS integration on an edge device for BGP PW.

```
Router# configure
Router(config)# l2vpn xconnect group 1
Router(config-l2vpn-xc)# mp2mp 2
Router(config-l2vpn-xc-mp2mp)# autodiscovery bgp
Router(config-l2vpn-xc-mp2mp-ad)# signaling-protocol bgp
Router(config-l2vpn-xc-mp2mp-ad-sig)# ce-id 3
Router(config-l2vpn-xc-mp2mp-ad-sig-ce)# vpws-seamless-integration
```

The following example shows how to enable EVPN-VPWS integration for TLDP PW.

```
Router# configure
Router(config)# l2vpn xconnect group 1
Router(config-l2vpn-xc)# p2p p1
Router(config-l2vpn-xc-p2p)# interface BE1.1
Router(config-l2vpn-xc-p2p)# neighbor 1.1.1.1 pw-id 1
Router(config-l2vpn-xc-p2p-pw)# exit
Router(config-l2vpn-xc-p2p)# vpws-seamless-integration
```

