



MPLS Traffic Engineering Commands



Note All commands applicable for the Cisco NCS 5500 Series Router are also supported on the Cisco NCS 540 Series Router that is introduced from Cisco IOS XR Release 6.3.2. References to earlier releases in Command History tables apply to only the Cisco NCS 5500 Series Router.



- Note**
- Starting with Cisco IOS XR Release 6.6.25, all commands applicable for the Cisco NCS 5500 Series Router are also supported on the Cisco NCS 560 Series Routers.
 - Starting with Cisco IOS XR Release 6.3.2, all commands applicable for the Cisco NCS 5500 Series Router are also supported on the Cisco NCS 540 Series Router.
 - References to releases before Cisco IOS XR Release 6.3.2 apply to only the Cisco NCS 5500 Series Router.
 - Cisco IOS XR Software Release 7.0.1 specific updates are not applicable for the following variants of Cisco NCS 540 Series Routers:
 - N540-28Z4C-SYS-A
 - N540-28Z4C-SYS-D
 - N540X-16Z4G8Q2C-A
 - N540X-16Z4G8Q2C-D
 - N540-12Z20G-SYS-A
 - N540-12Z20G-SYS-D
 - N540X-12Z16G-SYS-A
 - N540X-12Z16G-SYS-D

This module describes the commands used to configure Multiprotocol Label Switching (MPLS) Traffic Engineering (TE) on .

Your network must support the following Cisco features before you can enable MPLS-TE:

- MPLS
- IP Cisco Express Forwarding (CEF)
- Intermediate System-to-Intermediate System (IS-IS) or Open Shortest Path First (OSPF) routing protocol
- Resource Reservation Protocol (RSVP)

MPLS Label Distribution Protocol (LDP), Resource Reservation Protocol (RSVP), and Universal Control Plane (UCP) command descriptions are documented separately.

For detailed information about MPLS concepts, configuration tasks, and examples, see *MPLS Configuration Guide for Cisco NCS 5500 Series Routers* and *MPLS Configuration Guide for Cisco NCS 540 Series Routers*.

- [adjustment-threshold \(MPLS-TE\), on page 6](#)
- [admin-weight, on page 7](#)
- [affinity, on page 8](#)
- [affinity-map, on page 12](#)
- [application \(MPLS-TE\), on page 14](#)
- [attribute-flags, on page 15](#)
- [attribute-names, on page 16](#)
- [attribute-set, on page 17](#)
- [auto-bw \(MPLS-TE\), on page 21](#)
- [auto-bw collect frequency \(MPLS-TE\), on page 23](#)
- [autoroute announce, on page 24](#)
- [autoroute destination, on page 26](#)
- [autoroute metric, on page 27](#)
- [auto-tunnel backup \(MPLS-TE\), on page 28](#)
- [backup-bw, on page 29](#)
- [backup-path tunnel-te, on page 31](#)
- [bidirectional, on page 33](#)
- [bw-limit \(MPLS-TE\), on page 34](#)
- [clear mpls traffic-eng auto-bw \(MPLS-TE EXEC\), on page 36](#)
- [clear mpls traffic-eng auto-tunnel backup unused, on page 38](#)
- [clear mpls traffic-eng auto-tunnel mesh, on page 39](#)
- [clear mpls traffic-eng counters auto-tunnel mesh, on page 40](#)
- [clear mpls traffic-eng counters auto-tunnel backup, on page 41](#)
- [clear mpls traffic-eng counters global, on page 42](#)
- [clear mpls traffic-eng counters signaling, on page 43](#)
- [clear mpls traffic-eng counters soft-preemption, on page 44](#)
- [clear mpls traffic-eng fast-reroute log, on page 45](#)
- [clear mpls traffic-eng link-management statistics, on page 46](#)
- [collect-bw-only \(MPLS-TE\), on page 47](#)
- [destination \(MPLS-TE\), on page 48](#)
- [disable \(explicit-path\), on page 49](#)
- [ds-te bc-model, on page 50](#)
- [ds-te mode, on page 51](#)
- [ds-te te-classes, on page 53](#)
- [exclude srlg \(auto-tunnel backup\), on page 55](#)

- fast-reroute, on page 56
- fast-reroute protect, on page 57
- fast-reroute timers promotion, on page 58
- flooding thresholds, on page 59
- forward-class, on page 60
- forwarding-adjacency, on page 61
- index exclude-address, on page 63
- index exclude-srlg, on page 65
- index next-address, on page 66
- interface (MPLS-TE), on page 68
- interface (SRLG), on page 70
- interface tunnel-te, on page 71
- ipv4 unnumbered (MPLS), on page 73
- ipv4 unnumbered mpls traffic-eng, on page 74
- link-management timers bandwidth-hold, on page 75
- link-management timers periodic-flooding, on page 76
- link-management timers preemption-delay, on page 77
- load-share, on page 78
- load-share unequal, on page 79
- match mpls disposition, on page 80
- maxabs (MPLS-TE), on page 81
- mpls traffic-eng, on page 82
- mpls traffic-eng auto-bw apply (MPLS-TE), on page 83
- mpls traffic-eng fast-reroute promote, on page 85
- mpls traffic-eng level, on page 86
- mpls traffic-eng link-management flood, on page 87
- mpls traffic-eng path-protection switchover tunnel-te, on page 88
- mpls traffic-eng reoptimize (EXEC), on page 89
- mpls traffic-eng reoptimize events link-up, on page 90
- mpls traffic-eng router-id (MPLS-TE router), on page 91
- mpls traffic-eng repotimize mesh group, on page 93
- mpls traffic-eng srlg, on page 94
- nhop-only (auto-tunnel backup), on page 96
- overflow threshold (MPLS-TE), on page 97
- path-option (MPLS-TE), on page 99
- path-protection (MPLS-TE), on page 102
- path-protection timers reopt-after-switchover, on page 103
- path-selection cost-limit, on page 104
- path-selection ignore overload (MPLS-TE), on page 105
- path-selection loose-expansion affinity (MPLS-TE), on page 107
- path-selection loose-expansion metric (MPLS-TE), on page 108
- path-selection metric (MPLS-TE), on page 109
- path-selection metric (interface), on page 110
- policy-class, on page 111
- priority (MPLS-TE), on page 113
- record-route, on page 114

- [redirect default-route nexthop](#), on page 115
- [redirect nexthop](#), on page 116
- [reoptimize \(MPLS-TE\)](#), on page 117
- [reoptimize timers delay \(MPLS-TE\)](#), on page 118
- [route-priority](#), on page 120
- [router-id secondary \(MPLS-TE\)](#), on page 122
- [set destination-address](#), on page 123
- [set ipv4 df](#), on page 124
- [set source-address](#), on page 125
- [show explicit-paths](#), on page 126
- [show interfaces tunnel-te accounting](#), on page 128
- [show mpls traffic-eng affinity-map](#), on page 129
- [show mpls traffic-eng attribute-set](#), on page 131
- [show mpls traffic-eng autoroute](#), on page 133
- [show mpls traffic-eng auto-tunnel backup](#), on page 135
- [show mpls traffic-eng auto-tunnel mesh](#), on page 138
- [show mpls traffic-eng collaborator-timers](#), on page 141
- [show mpls traffic-eng counters signaling](#), on page 143
- [show mpls traffic-eng ds-te te-class](#), on page 147
- [show mpls traffic-eng forwarding](#), on page 148
- [show mpls traffic-eng forwarding-adjacency](#), on page 150
- [show mpls traffic-eng igp-areas](#), on page 151
- [show mpls traffic-eng link-management admission-control](#), on page 154
- [show mpls traffic-eng link-management advertisements](#), on page 158
- [show mpls traffic-eng link-management bandwidth-allocation](#), on page 161
- [show mpls traffic-eng link-management igp-neighbors](#), on page 164
- [show mpls traffic-eng link-management interfaces](#), on page 166
- [show mpls traffic-eng link-management statistics](#), on page 169
- [show mpls traffic-eng link-management summary](#), on page 171
- [show mpls traffic-eng maximum tunnels](#), on page 173
- [show mpls traffic-eng preemption log](#), on page 176
- [show mpls traffic-eng topology](#), on page 178
- [show mpls traffic-eng tunnels](#), on page 186
- [show mpls traffic-eng tunnels auto-bw brief](#), on page 215
- [show mpls traffic-eng link-management soft-preemption](#), on page 217
- [show srlg](#), on page 219
- [signalled-bandwidth](#), on page 222
- [signalled-name](#), on page 224
- [signalling advertise explicit-null \(MPLS-TE\)](#), on page 225
- [snmp traps mpls traffic-eng](#), on page 226
- [soft-preemption](#), on page 228
- [soft-preemption fr-rewrite](#), on page 229
- [srlg](#), on page 230
- [timers loose-path \(MPLS-TE\)](#), on page 231
- [timers removal unused \(auto-tunnel backup\)](#), on page 232
- [timeout \(soft-preemption\)](#), on page 233

- [topology holddown sigerr \(MPLS-TE\)](#), on page 234
- [tunnel-id \(auto-tunnel backup\)](#), on page 235

adjustment-threshold (MPLS-TE)

To configure the tunnel bandwidth threshold to trigger an adjustment, use the **adjustment-threshold** command in MPLS-TE automatic bandwidth interface configuration mode. To disable this feature, use the **no** form of this command.

adjustment-threshold *percentage* [**min** *minimum bandwidth*]
no adjustment-threshold *percentage* [**min** *minimum bandwidth*]

Syntax Description	<i>percentage</i>	Configures the bandwidth percent threshold to trigger an adjustment if the largest sample percentage is higher or lower than the current tunnel bandwidth. The range is from 1 to 100. The default is 5.
	min <i>minimum bandwidth</i>	(Optional) Configures the bandwidth change value to trigger an adjustment. The tunnel bandwidth is changed only if the largest sample is higher or lower than the current tunnel bandwidth, in kbps. The range is from 10 to 4294967295. The default is 10.

Command Default	<i>percentage: 5</i>
	<i>minimum bandwidth: 10</i>
	MPLS-TE automatic bandwidth interface configuration

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines	If you configure or modify the adjustment threshold while the automatic bandwidth is already running, the next bandwidth application is impacted for that tunnel. The new adjustment threshold determines if an actual bandwidth takes place.
-------------------------	---

Examples	The following example configures the tunnel bandwidth threshold to trigger an adjustment:
-----------------	---

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-te 1
RP/0/RP0/CPU0:router(config-if)# auto-bw
RP/0/RP0/CPU0:router(config-if-tunte-autobw)# adjustment-threshold 20 min 500
```

admin-weight

To override the Interior Gateway Protocol (IGP) administrative weight (cost) of the link, use the **admin-weight** command in MPLS-TE interface configuration mode. To return to the default behavior, use the **no** form of this command.

admin-weight *weight*
no admin-weight *weight*

Syntax Description	<i>weight</i> Administrative weight (cost) of the link. Range is 0 to 4294967295.	
Command Default	<i>weight</i> : IGP Weight (default OSPF 1, IS-IS 10)	
Command Modes	MPLS-TE interface configuration	
Command History	Release	Modification
	Release 6.0	This command was introduced.
Usage Guidelines	To use the admin-weight command for MPLS LSP path computations, path-selection metric must be configured to TE.	
Task ID	Task ID	Operations
	mpls-te	read, write
Examples	The following example shows how to override the IGP cost of the link and sets the cost to 20. <pre> RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# mpls traffic-eng RP/0/RP0/CPU0:router(config-mpls-te)# interface HundredGigE 0/0/0/3 RP/0/RP0/CPU0:router(config-mpls-te-if)# admin-weight 20 </pre>	

affinity

To configure an affinity (attributes which MPLS-TE tunnel requires in its links) for an MPLS-TE tunnel, use the **affinity** command in interface configuration mode. To disable this behavior, use the **no** form of this command.

affinity {*affinity-value* **mask** *mask-value* | **exclude** *name* | **exclude-all** | **include** *name* | **include-strict** *name* | **flex-algo** *name*}

no affinity {*affinity-value* **mask** *mask-value* | **exclude** *name* | **exclude-all** | **include** *name* | **include-strict** *name*}

Syntax Description	<i>affinity-value</i>	Attribute values that are required for links to carry this tunnel. A 32-bit decimal number. Range is from 0x0 to 0xFFFFFFFF, representing 32 attributes (bits), where the value of an attribute is 0 or 1.
	mask <i>mask-value</i>	Checks the link attribute. A 32-bit decimal number. Range is 0x0 to 0xFFFFFFFF, representing 32 attributes (bits), where the value of an attribute mask is 0 or 1.
	exclude <i>name</i>	Configures a particular affinity to exclude.
	exclude-all	Excludes all affinities.
	include <i>name</i>	Configures the affinity to include in the loose sense.
	include-strict <i>name</i>	Configures the affinity to include in the strict sense.

Command Default

affinity-value: 0X00000000
mask-value: 0x0000FFFF

Command Modes

Interface configuration

Command History

Release	Modification
Release 6.0	This command was introduced.

Usage Guidelines

Affinity determines the link attributes of the tunnel (that is, the attributes for which the tunnel has an affinity). The attribute mask determines which link attribute the router should check. If a bit in the mask is 0, the attribute value of a link or that bit is irrelevant. If a bit in the mask is 1, the attribute value of that link and the required affinity of the tunnel for that bit must match.

A tunnel can use a link if the tunnel affinity equals the link attributes and the tunnel affinity mask.

If there is an affinity failure, a 5-minute timer is started at the LSP headend. If the tunnel is not able to reoptimize within the timeframe, it is torn down. However, if you execute the **mpls traffic-eng reoptimize disable affinity-failure** command, no timer is started and the tunnel is not torn down. At a subsequent time, other triggers for reoptimization may start the timer for the LSPs with affinity failure.

Any properties set to 1 in the affinity should be 1 in the mask. The affinity and mask should be set as follows:


```
tunnel_affinity=tunnel_affinity and tunnel_affinity_mask
```

You can configure up to 16 affinity constraints under a given tunnel. These constraints are used to configure affinity constraints for the tunnel:

Include constraint

Specifies that a link is considered for CSPF if it contains all affinities associated with the include constraint. An acceptable link contains more affinity attributes than those associated with the include statement. You can have multiple include statements under a tunnel configuration.

Include-strict constraint

Specifies that a link is considered for CSPF if it contains only the colors associated with the include-strict statement. The link cannot have any additional colors. In addition, a link without a color is rejected.

Exclude constraint

Specifies that a link satisfies an exclude constraint if it does not have all the colors associated with the constraint. In addition, a link that does not have any attribute satisfies an exclude constraint.

Exclude-all constraint

Specifies that only the links without any attribute are considered for CSPF. An exclude-all constraint is not associated with any color; whereas, all other constraint types are associated with up to 10 colors.

You set 1 bit for each color; however, the sample output shows multiple bits at the same time. For example, you can configure red and orange colors on HundredGigabitEthernet 0/0/0/3 from the **interface** command. The sample output from the [show mpls traffic-eng link-management interfaces, on page 166](#) command shows that the Attributes field is set to 0x21, which means that there are 0x20 and 0x1 bits on the link.

Task ID

Task Operations

```
mpls-te read,
write
```

Examples

This example shows how to configure the tunnel affinity and mask:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-te 1
RP/0/RP0/CPU0:router(config-if)# affinity 0101 mask 303
```

This example shows that a link is eligible for CSPF if the color is red. The link can have any additional colors.

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-te 1
RP/0/RP0/CPU0:router(config-if)# affinity include red
```

This example shows that a link is eligible for CSPF if it has at least red and orange colors. The link can have any additional colors.

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-te 1
RP/0/RP0/CPU0:router(config-if)# affinity include red orange
```

This sample output shows that the include constraint from the **show mpls traffic-eng tunnels** command is 0x20 and 0x1:

```
Name: tunnel-te1 Destination: 0.0.0.0
Status:
  Admin:    up Oper: down  Path: not valid  Signalling: Down
  G-PID: 0x0800 (internally specified)

Config Parameters:
  Bandwidth:      0 kbps (CT0) Priority:  7  7
  Number of configured name based affinity constraints: 1
  Name based affinity constraints in use:
  Include bit map      : 0x21
  Metric Type: TE (default)
  AutoRoute: disabled LockDown: disabled
  Loadshare:      0 equal loadshares
  Auto-bw: disabled(0/0) 0 Bandwidth Requested:      0
  Direction: unidirectional
  Endpoint switching capability: unknown, encoding type: unassigned
  Transit switching capability: unknown, encoding type: unassigned

Reason for the tunnel being down: No destination is configured
History:
```

This example shows that a tunnel can go over a link that contains red or orange affinity. A link is eligible for CSPF if it has a red color or an orange color. Thus, a link with red and any other colors and a link with orange and other additional colors must meet the constraint.

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-te 1
RP/0/RP0/CPU0:router(config-if)# affinity include red
RP/0/RP0/CPU0:router(config-if)# affinity include orange
```

This sample output shows that the include constraint from the **show mpls traffic-eng tunnels** command is 0x20 or 0x1:

```
Name: tunnel-te1 Destination: 0.0.0.0
Status:
  Admin:    up Oper: down  Path: not valid  Signalling: Down
  G-PID: 0x0800 (internally specified)

Config Parameters:
  Bandwidth:      0 kbps (CT0) Priority:  7  7
  Number of configured name based affinity constraints: 2
  Name based affinity constraints in use:
    Include bit map      : 0x1
    Include bit map      : 0x20
  Metric Type: TE (default)
  AutoRoute: disabled LockDown: disabled
  Loadshare:      0 equal loadshares
  Auto-bw: disabled(0/0) 0 Bandwidth Requested:      0
  Direction: unidirectional
```

```
Endpoint switching capability: unknown, encoding type: unassigned  
Transit switching capability: unknown, encoding type: unassigned
```

```
Reason for the tunnel being down: No destination is configured  
History:
```

This example shows that a link is eligible for CSPF if it has only red color. The link must not have any additional colors.

```
RP/0/RP0/CPU0:router# configure  
RP/0/RP0/CPU0:router(config)# interface tunnel-te 1  
RP/0/RP0/CPU0:router(config-if)# affinity include-strict red
```

This example shows that a link is eligible for CSPF if it does not have the red attribute.

```
RP/0/RP0/CPU0:router# configure  
RP/0/RP0/CPU0:router(config)# interface tunnel-te 1  
RP/0/RP0/CPU0:router(config-if)# affinity exclude red
```

This example shows that a link is eligible for CSPF if it does not have red and blue attributes. Thus, a link that has only a red attribute or only a blue attribute is eligible for CSPF.

```
RP/0/RP0/CPU0:router# configure  
RP/0/RP0/CPU0:router(config)# interface tunnel-te 1  
RP/0/RP0/CPU0:router(config-if)# affinity exclude red blue
```

This example shows that a link is eligible for CSPF if it does not have either a red or a blue attribute.

```
RP/0/RP0/CPU0:router# configure  
RP/0/RP0/CPU0:router(config)# interface tunnel-te 1  
RP/0/RP0/CPU0:router(config-if)# affinity exclude red  
RP/0/RP0/CPU0:router(config-if)# affinity exclude blue
```

affinity-map

To assign a numerical value to each affinity name, use the **affinity-map** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

affinity-map *affinity name* {*affinity value* | **bit-position** *value*}
no affinity-map *affinity name* {*affinity value* | **bit-position** *value*}

Syntax Description	<i>affinity name</i>	Affinity map name-to-value designator (in hexadecimal, 0-ffffff).
	<i>affinity value</i>	Affinity map value designator. Range is from 1 to 80000000.
	bit-position	Configures the value of an affinity map for the bit position of the 32-bit number.
	<i>value</i>	Bit position value. Range is from 0 to 31. Range is from 0 to 255.

Command Default No default behavior or values

Command Modes MPLS-TE configuration

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines The name-to-value mapping must represent a single bit of a 32-bit value.
 Repeat the affinity-map command to define multiple colors up to a maximum of 256 colors.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples The following example shows how to assign a numerical value to each affinity name:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# affinity-map red 1
RP/0/RP0/CPU0:router(config-mpls-te)# affinity-map blue 2
```

The following example shows how to configure the value of 15 for an affinity map by bit position:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
```

```
RP/0/RP0/CPU0:router(config-mpls-te)# affinity-map red2 bit-position 15
```

application (MPLS-TE)

To configure the application frequency, in minutes, for the applicable tunnel, use the **application** command in MPLS-TE automatic bandwidth interface configuration mode. To disable this feature, use the **no** form of this command.

application *minutes*
no application *minutes*

Syntax Description	<i>minutes</i> Frequency, in minutes, for the automatic bandwidth application. The range is from 5 to 10080 (7 days). The default is 1440.				
Command Default	<i>minutes</i> : 1440 (24 hours)				
Command Modes	MPLS-TE automatic bandwidth interface configuration				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 6.0</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 6.0	This command was introduced.
Release	Modification				
Release 6.0	This command was introduced.				
Usage Guidelines	If you configure and modify the application frequency, the application period can reset and restart for that tunnel. The next bandwidth application for the tunnel happens within the specified minutes.				
Task ID	<table> <tr> <th>Task ID</th><th>Operations</th></tr> <tr> <td>mpls-te</td><td>read, write</td></tr> </table>	Task ID	Operations	mpls-te	read, write
Task ID	Operations				
mpls-te	read, write				
Examples	The following example shows how to configure application frequency to 1000 minutes for MPLS-TE interface 1: <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# interface tunnel-te 1 RP/0/RP0/CPU0:router(config-if)# auto-bw RP/0/RP0/CPU0:router(config-if-tunte-autobw)# application 1000</pre>				

attribute-flags

To configure attribute flags for an interface, use the **attribute-flags** command in MPLS-TE interface configuration mode. To return to the default behavior, use the **no** form of this command.

attribute-flags *attribute-flags*
no attribute-flags *attribute-flags*

Syntax Description	<i>attribute-flags</i> Links attributes that are compared to the affinity bits of a tunnel during selection of a path. Range is 0x0 to 0xFFFFFFFF, representing 32 attributes (bits) where the value of an attribute is 0 or 1.				
Command Default	<i>attributes</i> : 0x0				
Command Modes	MPLS-TE interface configuration				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 6.0</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 6.0	This command was introduced.
Release	Modification				
Release 6.0	This command was introduced.				
Usage Guidelines	The attribute-flags command assigns attributes to a link so that tunnels with matching attributes (represented by their affinity bits) prefer this link instead of others that do not match. The interface attribute is flooded globally so that it can be used as a tunnel headend path selection criterion.				
Task ID	<table> <tr> <th>Task ID</th><th>Operations</th></tr> <tr> <td>mpls-te</td><td>read, write</td></tr> </table>	Task ID	Operations	mpls-te	read, write
Task ID	Operations				
mpls-te	read, write				
Examples	The following example shows how to set attribute flags to 0x0101: <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# mpls traffic-eng RP/0/RP0/CPU0:router(config-mpls-te)# interface HundredGigE 0/0/0/3 RP/0/RP0/CPU0:router(config-mpls-te-if)# attribute-flags 0x0101</pre>				

attribute-names

To configure attributes for the interface, use the **attribute-names** command in MPLS-TE interface configuration mode. To return to the default behavior, use the **no** form of this command.

attribute-names *attribute name*
no attribute-names *attribute name*

Syntax Description	<i>attribute name</i> Attribute name expressed using alphanumeric or hexadecimal characters.Up to 32 attribute-names can be assigned. index Specifies an entry index for attribute names. <i>index-number</i> Specifies the index number. Range is from 1 to 8.				
Command Default	No default behavior or values				
Command Modes	MPLS-TE interface configuration				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 6.0</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 6.0	This command was introduced.
Release	Modification				
Release 6.0	This command was introduced.				
Usage Guidelines	The name-to-value mapping must represent a single bit of a 32-bit256-bit value.				
Task ID	<table> <tr> <th>Task ID</th><th>Operations</th></tr> <tr> <td>mpls-te</td><td>read, write</td></tr> </table>	Task ID	Operations	mpls-te	read, write
Task ID	Operations				
mpls-te	read, write				
Examples	The following example shows how to assign an attribute name (in this case, red) to a TE link: <pre> RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# mpls traffic-eng RP/0/RP0/CPU0:router(config-mpls-te)# interface HundredGigabitEthernet 0/0/0/3 RP/0/RP0/CPU0:router(config-mpls-te-if)# attribute-name red </pre>				

attribute-set

To configure attribute-set for auto-backup tunnels, use the **attribute-set** command in MPLS-TE configuration mode.

```
attribute-set auto-backup attribute-set-name {affinity {affinity-value mask mask-value | exclude name | exclude-all | include name | include-strict name} | logging events lsp-status {reoptimize | state} | policy-class {range | default} | priority setup-range hold-range | record-route}
```

To configure attribute-set for auto-mesh tunnels, use the **attribute-set** command in MPLS-TE configuration mode.

```
attribute-set auto-mesh attribute-set-name {affinity {affinity-value mask mask-value | exclude name | exclude-all | include name | include-strict name} | auto-bw collect-bw-only | autoroute announce | bandwidth bandwidth | fast-reroute [protect {bandwidth node | node bandwidth}] | logging events lsp-status {insufficient-bandwidth | reoptimize | reroute | state} | policy-class {range | default} | priority setup-range hold-range | record-route | signalled-bandwidth bandwidth [class-type cl] | soft-preemption}
```

To configure attribute-set for a path-option, use the **attribute-set** command in MPLS-TE configuration mode.

```
attribute-set path-option attribute-set-name {affinity {affinity-value mask mask-value | exclude name | exclude-all | include name | include-strict name} | signalled-bandwidth bandwidth [class-type cl]}
```

To disable this behavior, use the **no** form of this command.

```
no attribute-set
```

Syntax Description

auto-backup	Specifies the values of an attribute set for the auto-backup group.
auto-mesh	Specifies the values of an attribute set for the auto-mesh group.
path-option	Specifies the values of an attribute set for the path option.
xro	Specifies that the attribute-set is used to define an XRO.
<i>attribute-set-name</i>	A 32-bit character string, specifies the name of the attribute-set template.
<i>affinity-value</i>	Attribute values that are required for links to carry this tunnel. A 32-bit decimal number, representing 32 attributes (bits), where the value of an attribute is 0 or 1. Range is from 0x0 to 0xFFFF.
mask <i>mask-value</i>	Checks the link attribute. A 32-bit decimal number, representing 32 attributes (bits), where the value of an attribute mask is 0 or 1. Range is from 0x0 to 0xFFFF.

exclude <i>name</i>	Configures a specific affinity that is to be excluded.
exclude-all	Excludes all affinities.
include <i>name</i>	Configures the affinity to include in the loose sense.
include-strict <i>name</i>	Configures the affinity to include in the strict sense.
logging	Per-interface logging configuration.
events	Per-interface logging events.
lsp-status	Enables interface LSP state change alarms.
reoptimize	Enables interface LSP REOPT change alarms.
state	Enables interface LSP UP/DOWN change alarms.
policy-class	Specifies class for policy-based tunnel selection.
<i>range</i>	Tunnel policy class range 1 to 7.
default	Default class for policy-based tunnel selection.
priority	Specifies the tunnel priority.
<i>setup-range</i>	Specifies setup priority. Range is 0 to 7.
<i>hold-range</i>	Specifies hold priority. Range is 0 to 7.
record-route	Records the route used by the tunnel.
signalled-bandwidth	Specifies the tunnel bandwidth requirement to be signaled.
<i>bandwidth</i>	Bandwidth required for an MPLS-TE tunnel, specified in kilobits per second. By default, bandwidth is reserved in the global pool. Range is from 0 to 4294967295.
class-type <i>ct</i>	(Optional) Configures the class type of the tunnel bandwidth request. Range is 0 to 1. Class-type 0 is equivalent to global-pool. Class-type 1 is equivalent to subpool.
soft-preemption	Enables the soft-preemption feature on this tunnel.

Command Default

affinity-value: 0x0
mask-value: 0xFFFF

Command Modes

MPLS TE configuration

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines

The values specified for an attribute within a **path-option attribute-set** does not prevent the configuration of the same attribute at the tunnel level. However, only one level is taken into consideration. The configuration at the **path-option** level is considered more specific than the one at the level of the tunnel, and is therefore used.

Attributes that are **not** specified within an **attribute-set** picks their default values, as usual, from the configuration at the tunnel level, the configuration at the global mpls level, or default values.

An XRO attribute-set can be specified as part of the path-option, if required. An empty XRO attribute set results in the GMPLS tunnel being signaled with no exclusions, and therefore no XRO.

Task ID	Task ID	Operation
	mpls-te	read, write

This example shows how to configure an attribute-set to a TE interface for an auto-backup tunnel:

```
RP/0/RP0/CPU0:router# config
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# interface HundredGigabitEthernet 0/0/0/3
RP/0/RP0/CPU0:router(config-mpls-te-if)# auto-tunnel backup
RP/0/RP0/CPU0:router(config-mpls-te-if-auto-backup)# attribute-set ab
RP/0/RP0/CPU0:router(config-mpls-te-if-auto-backup)#
```

This example shows how to configure an attribute-set to a TE interface for an auto-mesh tunnel:

```
RP/0/RP0/CPU0:router# config
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# auto-tunnel mesh
RP/0/RP0/CPU0:router(config-te-auto-mesh)# group 1
RP/0/RP0/CPU0:router(config-te-mesh-group)# attribute-set aml
RP/0/RP0/CPU0:router(config-te-mesh-group)# destination-list dll
```

This example shows how to configure the attribute-set for auto-backup tunnels:

```
RP/0/RP0/CPU0:router# config
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# attribute-set auto-backup ab
RP/0/RP0/CPU0:router(config-te-attribute-set)# affinity 0x1 mask 0x1
RP/0/RP0/CPU0:router(config-te-attribute-set)# priority 3 3
RP/0/RP0/CPU0:router(config-te-attribute-set)# policy-class 6
RP/0/RP0/CPU0:router(config-te-attribute-set)# logging events lsp-status reoptimize
RP/0/RP0/CPU0:router(config-te-attribute-set)# logging events lsp-status state
RP/0/RP0/CPU0:router(config-te-attribute-set)# policy-class default
RP/0/RP0/CPU0:router(config-te-attribute-set)# record-route
```

This example shows how to configure the attribute-set for auto-mesh tunnels:

```
RP/0/RP0/CPU0:router# config
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# attribute-set auto-mesh mesh1
RP/0/RP0/CPU0:router(config-te-attribute-set)# affinity include red blue
```

```
RP/0/RP0/CPU0:router(config-te-attribute-set)# affinity include-strict yellow green
RP/0/RP0/CPU0:router(config-te-attribute-set)# affinity exclude orange
RP/0/RP0/CPU0:router(config-te-attribute-set)# affinity exclude-all
RP/0/RP0/CPU0:router(config-te-attribute-set)# policy-class default
```

This example shows how to configure the tunnel affinity and signalled-bandwidth for a path-option:

```
RP/0/RP0/CPU0:router# config
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# attribute-set path-option myset
RP/0/RP0/CPU0:router(config-te-attribute-set)# affinity 0x3 mask 0x3
RP/0/RP0/CPU0:router(config-te-attribute-set)# signalled-bandwidth 2000
```

The following example shows how to configure attribute set attr01:

```
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# attribute-set xro attr01
RP/0/RP0/CPU0:router(config-te-attribute-set)#
```

auto-bw (MPLS-TE)

To configure automatic bandwidth on a tunnel interface and to enter MPLS-TE automatic bandwidth interface configuration mode, use the **auto-bw** command in MPLS-TE interface configuration mode. To disable the automatic bandwidth on that tunnel, use the **no** form of this command.

auto-bw
no auto-bw

Syntax Description	This command has no arguments or keywords.				
Command Default	By default, automatic bandwidth is not enabled.				
Command Modes	MPLS-TE interface configuration				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 6.0</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 6.0	This command was introduced.
Release	Modification				
Release 6.0	This command was introduced.				

Usage Guidelines	Use the auto-bw command to enter MPLS-TE automatic bandwidth interface configuration mode. The auto-bw and load-share unequal commands should not be used together. The load-share unequal command determines the load-share for a tunnel based on the bandwidth. However, the MPLS-TE automatic bandwidth feature changes the bandwidth around. If you are configuring both the load-share unequal command and the MPLS-TE automatic bandwidth feature, it is recommended that you specify an explicit load-share value configuration under each MPLS-TE automatic bandwidth tunnel. The following automatic bandwidth scenarios are described: • If you configure the automatic bandwidth on a tunnel, the automatic bandwidth is enabled on that tunnel. If no other configuration is specified, defaults for the various parameters are used, the operation stops. • The automatic operation (for example, output rate collection) starts when the automatic bandwidth is enabled on one tunnel. If automatic bandwidth is disabled from all tunnels, the operation stops. • If the output rate collection is already active when the automatic bandwidth is configured on a tunnel, the statistics collection for that tunnel starts at the next collection configuration.
-------------------------	--



Note Because the collection timer is already running, the first collection event for that tunnel happens in less than C minutes (for example, on an average of C/2 minutes).

Task ID	Task ID	Operations
	mpls-te	read, write

Examples

The following example shows how to enter MPLS-TE automatic bandwidth interface configuration mode:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router# interface tunnel-te 1
RP/0/RP0/CPU0:router(config-if)# auto-bw
RP/0/RP0/CPU0:router(config-if-tunte-autobw)#
```

auto-bw collect frequency (MPLS-TE)

To configure the automatic bandwidth collection frequency, use the **auto-bw collect frequency** command in MPLS-TE configuration mode. To reset the automatic bandwidth frequency to its default value, use the **no** form of this command.

auto-bw collect frequency *minutes*
no auto-bw collect frequency *minutes*

Syntax Description	<i>minutes</i> Interval between automatic bandwidth adjustments, in minutes. The range is from 1 to 10080. The default is 5.	
Command Default	<i>minutes</i> : 5 In addition, the no form of this command resets to the default.	
Command Modes	MPLS-TE configuration	
Command History	Release	Modification
	Release 6.0	This command was introduced.
Usage Guidelines	The auto-bw collect frequency command configures the automatic bandwidth collection frequency for all the tunnels. Modifying the global collection frequency does not restart the tunnel for the current application period. The application period continues with the modified collection frequency.	
Task ID	Task ID	Operations
	mpls-te	read, write
Examples	The following example configures a tunnel for an automatic bandwidth adjustment of 100 minutes: <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# mpls traffic-eng RP/0/RP0/CPU0:router(config-mpls-te)# auto-bw collect frequency 100</pre>	

autoroute announce

To specify that the Interior Gateway Protocol (IGP) should use the tunnel (if the tunnel is up) in its enhanced shortest path first (SPF) calculation, use the **autoroute announce** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

```

autoroute announce [include-ipv6] [metric value]
no autoroute announce
    
```

Syntax Description	include-ipv6 (Optional) Announces the MPLS-TE tunnel to IS-IS IGP for IPv6 routing.
metric <i>value</i>	(Optional) Specify the MPLS-TE tunnel metric that the Interior Gateway Protocol (IGP) enhanced Shortest Path First (SPF) calculation uses.

Syntax Description This command has no arguments or keywords.

Command Default Announces IPv4 tunnel

Command Modes Interface configuration

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines

When more than one IGP is configured, the tunnel is announced as autoroute to the IGP that is used to compute the TE tunnel path.

When the **autoroute announce** command is configured, the route metric of the tunnel path to the destination equals the route metric of the shortest IGP path to that destination.

The **autoroute announce metric** configuration overrides the [autoroute metric, on page 27](#) configuration, if present.



Note IS-IS is the only IGP supporting IPv6 MPLS-TE tunnel announcements.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples

This example shows how to configure IGP to use the tunnel in its enhanced SPF calculation when the tunnel is up:

```

RP/0/RP0/CPU0:router# configure
    
```



```
RP/0/RP0/CPU0:router(config)# interface tunnel-te 1  
RP/0/RP0/CPU0:router(config-if)# autoroute announce
```

This example shows how to make IPv6 announcements for MPLS-TE tunnel to the IGP:

```
RP/0/RP0/CPU0:router#configure  
RP/0/RP0/CPU0:router(config)#interface tunnel-te 65534  
RP/0/RP0/CPU0:router(config-if)#autoroute announce  
RP/0/RP0/CPU0:router(config-if-tunte-aa)#include-ipv6
```

autoroute destination

To install multiple static routes in the routing information base (RIB) per MPLS TE tunnel, use the **autoroute destination** command in interface TE tunnel configuration mode. To disable autoroute destination, use the **no** form of this command.

```

autoroute destination ip-address
no autoroute destination ip-address
    
```

Syntax Description	ip-address	Specifies the host address of the route to be installed in the RIB. A maximum of six routes can be specified apart from the default route.
Command Default	Autoroute destination is disabled.	
Command Modes	Interface Tunnel TE	
Command History	Release	Modification
	Release 6.0	This command was introduced.
Usage Guidelines	No specific guidelines impact the use of this command.	
Task ID	Task ID	Operation
	mpls-te	read, write

This example shows how to configure installing four routes in RIB for TE tunnel 10:

```

RP/0/RP0/CPU0:router#configure
RP/0/RP0/CPU0:router(config)#interface tunnel-te 10
RP/0/RP0/CPU0:router(config-if)# autoroute destination 192.168.1.2
RP/0/RP0/CPU0:router(config-if)# autoroute destination 192.168.2.2
RP/0/RP0/CPU0:router(config-if)# autoroute destination 192.168.3.2
RP/0/RP0/CPU0:router(config-if)# autoroute destination 192.168.4.2
    
```

autoroute metric

To specify the MPLS-TE tunnel metric that the Interior Gateway Protocol (IGP) enhanced Shortest Path First (SPF) calculation uses, use the **autoroute metric** command in interface configuration mode. If no specific metric is to be specified, use the **no** form of this command.

autoroute metric {**absolute** | **relative**} *value*
no autoroute metric {**absolute** | **relative**} *value*

Syntax Description	absolute	Enables the absolute metric mode; you can enter a positive metric value.
	relative	Enables the relative metric mode; you can enter a positive, negative, or zero value.
	<i>value</i>	Metric that the IGP enhanced SPF calculation uses. Relative value range is from –10 to 10. Absolute value range is from 1 to 2147483647.

Command Default The relative value is 0.

Command Modes Interface configuration

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines The **autoroute metric** command overwrites the default tunnel route metric of the shortest IGP path to the destination.



Note The [autoroute announce, on page 24](#) configuration overrides the **autoroute metric** configuration, if present.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples

The following example shows how to configure the IGP enhanced SPF calculation using MPLS-TE tunnel metric as relative negative 1:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-te 1
RP/0/RP0/CPU0:router(config-if)# autoroute metric relative -1
```

auto-tunnel backup (MPLS-TE)

To automatically build next-hop (NHOP) and next-next-hop (NNHOP) backup tunnels, and to enter auto-tunnel backup configuration mode, use the **auto-tunnel backup** command in MPLS-TE configuration mode. To clear the NHOP and NNHOP backup tunnels, use the **no** form of this command.

auto-tunnel backup
no auto-tunnel backup

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes MPLS-TE configuration

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines The range of *tunnel-ID* is required to be mentioned for the auto-tunnel backup tunnels; otherwise, none of the tunnels are created.

The **no** form of this command deletes both NHOP and NNHOP backup tunnels that are configured using either the **auto-tunnel backup** command or the **nhop-only** command.

Task ID	Task ID	Operation
	mpls-te	read, write

Example

The following example automatically builds NHOP and NNHOP backup tunnels:

```
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# auto-tunnel backup
```

backup-bw

To configure the backup bandwidth for an MPLS-TE backup tunnel (that is used to protect a physical interface), use the **backup-bw** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

```
backup-bw {backup bandwidth {any-class-type | class-type ct} | global-pool {bandwidth | unlimited}
| sub-pool {bandwidth | unlimited} | unlimited {any-class-type | class-type ct}}
no backup-bw {backup bandwidth {any-class-type | class-type ct} | global-pool {bandwidth | unlimited}
| sub-pool {bandwidth | unlimited} | unlimited {any-class-type | class-type ct}}
```

Syntax Description

<i>backup bandwidth</i>	Backup bandwidth in any-pool provided by an MPLS-TE backup tunnel. Bandwidth is specified in kilobits per second (kbps). Range is 1 to 4294967295.
any-class-type	Displays the backup bandwidth assigned to any class-type protected tunnels.
class-type ct	Displays the class type of the backup bandwidth. Range is 0 to 1.
global-pool bandwidth	(In Prestandard DS-TE with RDM) Displays the backup bandwidth in global pool provided by an MPLS-TE backup tunnel. Bandwidth is specified in kilobits per second. Range is 1 to 4294967295.
unlimited	Displays the unlimited bandwidth.
sub-pool bandwidth	(In Prestandard DS-TE with RDM) Displays the backup bandwidth in sub-pool provided by an MPLS-TE backup tunnel. Bandwidth is specified in kilobits per second. Range bandwidth is 1 to 4294967295. Only label switched paths (LSPs) using bandwidth from the sub-pool can use the backup tunnel.

Command Default

Any class-type unlimited.

Command Modes

Interface configuration

Command History

Release	Modification
Release 6.0	This command was introduced.

Usage Guidelines

Backup bandwidth can be limited or unlimited or specific to a global pool, sub-pool, or non-specific any-pool. Backup with backup-bw in global-pool protects global-pool LSPs only; backup-bw in sub-pool protects sub-pool LSPs only.

Backup tunnels configured with limited backup bandwidth (from any/global/sub pool) are not assigned to protect LSPs configured with zero signaled bandwidth.

Backup bandwidth provides bandwidth protection for fast reroute (FRR). Bandwidth protection for FRR supports DiffServ-TE with two bandwidth pools (class-types).

Class-type 0 is strictly equivalent to global-pool; class-type 1 is strictly equivalent to sub-pool bandwidth using the Russian Doll Model (RDM).

Task ID	Task ID	Operations
	mpls-te	read, write

Examples

The following example shows how to configure backup tunnel 1 for use only by LSPs that take their bandwidth from the global pool (class-type 0 tunnels). Backup tunnel 1 does not provide bandwidth protection.

```
RP/0/RP0/CPU0:router(config)# interface tunnel-te 1
RP/0/RP0/CPU0:router(config-if)# backup-bw global-pool unlimited
```

or

```
RP/0/RP0/CPU0:router(config)# interface tunnel-te 1
RP/0/RP0/CPU0:router(config-if)# backup-bw unlimited class-type 0
```

In the following example, backup tunnel 2 is used by LSPs that take their bandwidth from the sub-pool (class-type 1 tunnels) only. Backup tunnel 2 provides bandwidth protection for up to 1000 units.

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-te 2
RP/0/RP0/CPU0:router(config-if)# backup-bw sub-pool 1000
```

or

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-te 2
RP/0/RP0/CPU0:router(config-if)# backup-bw 1000 class-type 1
```

backup-path tunnel-te

To set an MPLS-TE tunnel to protect a physical interface against failure, use the **backup-path tunnel-te** command in MPLS-TE interface configuration mode. To return to the default behavior, use the **no** form of this command.

backup-path tunnel-te *tunnel-number*
no backup-path tunnel-te *tunnel-number*

Syntax Description	<i>tunnel-number</i> Number of the tunnel protecting the interface. Range is 0 to 65535.
---------------------------	--

Command Default	No default behavior or values
------------------------	-------------------------------

Command Modes	MPLS-TE interface configuration
----------------------	---------------------------------

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines When the protected interface is down (shut down or removed), the traffic it was carrying (for the other label switched paths [LSPs], referred to as the protected LSPs) is rerouted, using fast reroute (FRR) onto the backup tunnels.

The following guidelines pertain to the FRR process:

- Multiple (backup) tunnels can protect the same interface by entering this command multiple times for different tunnels. The same (backup) tunnel can protect multiple interfaces by entering this command for each interface.
- The backup tunnel used to protect a physical interface must have a valid IP address configured.
- The backup tunnel cannot pass through the same interface that it is protecting.
- TE tunnels that are configured with the FRR option, cannot be used as backup tunnels.
- For the backup tunnel to provide protection to the protected LSP, the backup tunnel must have a terminating-end node in the path of a protected LSP.
- The source IP address of the backup tunnel and the merge point (MP) address (the terminating-end address of the backup tunnel) must be reachable.



Note You must configure record-route on TE tunnels that are protected by multiple backup tunnels merging at a single node.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples

The following example shows how to protect the interface using tunnels:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# interface HundredGigabitEthernet 0/0/0/3
RP/0/RP0/CPU0:router(config-mpls-te-if)# backup-path tunnel-te 100
RP/0/RP0/CPU0:router(config-mpls-te-if)# backup-path tunnel-te 150
```


bidirectional

To configure a bidirectional LSP for a MPLS TE tunnel and define other parameters for the LSP, use the **bidirectional** command in the MPLS-TE interface configuration mode.

bidirectional association {**id** *value* | **source-address** *IP address* | **global-id** *value* | **type** **co-routed** | **fault-oam**}

Syntax Description	bidirectional	Configures a bidirectional LSP.
	association	Specifies association parameters for the bidirectional LSP.
	id <i>value</i>	Value number that identifies the association. Range is 0 to 65535.
	source-address <i>value</i>	Specifies the source IP address of the LSP from which a reverse path is required.
	global-id <i>value</i>	Value number that identifies the global ID. Range is 0 to 4294967295. The default value is 0.
	co-routed	Configures co-routed LSPs with bidirectional CSPF.
	fault-oam	Configures fault OAM for the bidirectional co-routed LSPs.
Command Default	Tunnel interfaces are disabled.	
Command Modes	Interface configuration mode	
Command History	Release	Modification
	Release 6.0	This command was introduced.
Usage Guidelines	No specific guidelines impact the use of this command.	
Task ID	Task ID	Operation
	mpls-te	read, write

Example

This example shows you how to configure an associated bidirectional co-routed MPLS-TE tunnel.

```
RP/0/RSP0/CPU0:router# configure
RRP/0/RSP0/CPU0:router(config)# interface tunnel-te 1
RP/0/RSP0/CPU0:router(config-if)# bidirectional
RP/0/RSP0/CPU0:router(config-if-bidir)# association id 1 source-address 11.0.0.1
RP/0/RSP0/CPU0:router(config-if-bidir)#association type co-routed
```

bw-limit (MPLS-TE)

To configure the minimum and maximum automatic bandwidth to be set on a tunnel, use the **bw-limit** command in MPLS-TE automatic bandwidth interface configuration mode. To disable this feature, use the **no** form of this command.

bw-limit **min** *bandwidth* [**max** *bandwidth*]
no bw-limit

Syntax Description	min <i>bandwidth</i>	Configures the minimum automatic bandwidth, in kbps, on a tunnel. The range is from 0 to 4294967295. The default is 0.
	max <i>bandwidth</i>	Configures the maximum automatic bandwidth, in kbps, on a tunnel. The range is from 0 to 4294967295. The default is 4294967295.
Command Default	min: 0 max: 4294967295	
Command Modes	MPLS-TE automatic bandwidth interface configuration	
Command History	Release	Modification
	Release 6.0	This command was introduced.
Usage Guidelines	Both the min and max keywords must be configured. The bw-limit command automatically sets the minimum bandwidth to the default value of 0, or the bw-limit command automatically sets the maximum to the default value of 4294967295 kbps. If the value of the min keyword is greater than the max keyword, the bw-limit command is rejected. If you configure and modify the minimum or maximum bandwidth while the automatic bandwidth is already running, the next bandwidth application for that tunnel is impacted. For example, if the current tunnel requested bandwidth is 30 Mbps and the minimum bandwidth is modified to 50 Mbps, the next application sets the tunnel bandwidth to 50 Mbps.	
Task ID	Task ID	Operations
	mpls-te	read, write
Examples	The following example shows how to configure the minimum and maximum bandwidth for the tunnel: <pre> RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# interface tunnel-te 1 RP/0/RP0/CPU0:router(config-if)# auto-bw </pre>	

```
RP/0/RP0/CPU0:router(config-if-tunte-autobw)# bw-limit min 30 max 80
```

clear mpls traffic-eng auto-bw (MPLS-TE EXEC)

To clear automatic bandwidth sampled output rates and to restart the application period for the specified tunnel, use the **clear mpls traffic-eng auto-bw** command in XR EXEC mode.

clear mpls traffic-eng auto-bw{all | internal | tunnel-te *tunnel-number*}

Syntax Description	all	Clears the automatic bandwidth sampled output rates for all tunnels.
	internal	Clears all the automatic bandwidth internal data structures.
	tunnel-te <i>tunnel-number</i>	Clears the automatic bandwidth sampled output rates for a specific tunnel. The <i>tunnel-number</i> argument is the tunnel ID used to clear the sampled output rates.

Command Default No default behavior or values

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines If no tunnel is specified, the **clear mpls traffic-eng auto-bw** command clears all the automatic bandwidth enabled tunnels.

For each tunnel in which the automatic bandwidth adjustment is enabled, information is maintained about the sampled output rates and the time remaining until the next bandwidth adjustment. The application period is restarted and values such as the largest collected bandwidth get reset. The tunnel continues to use the current bandwidth until the next application.

Task ID	Task ID	Operations
	mpls-te	execute

Examples The following example displays the information for the automatic bandwidth for tunnel number 0 from the **show mpls traffic-eng tunnels auto-bw brief** command:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng tunnels 0 auto-bw brief
```

Tunnel	LSP Name	Last appl ID	Requested BW (kbps)	Signalled BW (kbps)	Highest BW (kbps)	Application BW (kbps)	Time Left
tunnel-te0		278	100	100	100	150	12m 38s

The following example shows how to clear the automatic bandwidth sampled output rates for tunnel number 0:

```
RP/0/RP0/CPU0:router# clear mpls traffic-eng auto-bw tunnel-te 0
```

```
RP/0/RP0/CPU0:router# show mpls traffic-eng tunnels 0 auto-bw brief
```

Tunnel	LSP Name	Last appl ID	Requested BW (kbps)	Signalled BW (kbps)	Highest BW (kbps)	Application BW (kbps)	Time Left
tunnel-te0		278	100	100	100	0	24m 0s

clear mpls traffic-eng auto-tunnel backup unused

To remove unused automatic backup tunnels, use the **clear mpls traffic-eng auto-tunnel backup unused** command in XR EXEC mode.

clear mpls traffic-eng auto-tunnel backup unused {all | tunnel-te *tunnel-number*}

Syntax Description	all	Clears all the unused automatic backup tunnels.
	tunnel-te <i>tunnel-number</i>	Clears a specific unused automatic backup tunnel.

Command Default No default behavior or values

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines The **unused** auto-tunnel backup tunnel is the tunnel that is not assigned to protect any FRR tunnel. The behavior of this command is the same as the expiration of the **timers removal unused** command in which, when the timeout value is reached, the automatic backup tunnel is removed.

Task ID	Task ID	Operation
	mpls-te	execute

Example

The following example displays the information for the unused backup automatic tunnels from the **show mpls traffic-eng tunnels unused** command:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng tunnels unused
```

The following example shows how to clear the unused backup automatic tunnels:

```
RP/0/RP0/CPU0:router# clear mpls traffic-eng auto-tunnel backup unused all
RP/0/RP0/CPU0:router# show mpls traffic-eng tunnels unused
```

clear mpls traffic-eng auto-tunnel mesh

To clear all unused auto-tunnel mesh destinations, use the **clear mpls traffic-eng auto-tunnel mesh** command in XR EXEC mode.

clear mpls traffic-eng auto-tunnel mesh unused {all | tunnel-te}

Syntax Description	all	Clears all applicable unused auto-tunnel destinations.
	tunnel-te id	Clears an unused auto-tunnel destinations identified by a tunnel identifier.

Command Default None

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	mpls-te	execute

Examples This is sample output from the **clear mpls traffic-eng auto-tunnel mesh** command:

```
clear mpls traffic-eng auto-tunnel mesh
```

clear mpls traffic-eng counters auto-tunnel mesh

To clear all auto-tunnel mesh counters, use the **clear mpls traffic-eng counters auto-tunnel mesh** command in XR EXEC mode.

clear mpls traffic-eng counters auto-tunnel mesh

This command has no arguments or keywords.

Command Default	None	
Command Modes	XR EXEC mode	
Command History	Release	Modification
	Release 6.0	This command was introduced.
Usage Guidelines	No specific guidelines impact the use of this command.	
Task ID	Task ID	Operations
	mpls-te	execute

Examples This is sample output from the **clear mpls traffic-eng counters auto-tunnel mesh** command:

```
RP/0/RP0/CPU0:routerclear mpls traffic-eng counters auto-tunnel mesh
```


clear mpls traffic-eng counters auto-tunnel backup

To clear MPLS-TE automatic tunnel backup counters, use the **clear mpls traffic-eng counters auto-tunnel backup** command in XR EXEC mode.

clear mpls traffic-eng counters auto-tunnel backup

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	No default behavior or values
------------------------	-------------------------------

Command Modes	XR EXEC mode
----------------------	--------------

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines	No specific guidelines impact the use of this command.
-------------------------	--

Task ID	Task ID	Operation
	mpls-te	execute

Example

The following example removes all counters for the automatic backup tunnels:

```
RP/0/RP0/CPU0:router# clear mpls traffic-eng counters auto-tunnel backup
```

clear mpls traffic-eng counters global

To clear the internal MPLS-TE tunnel counters, use the **clear mpls traffic-eng counters global** command in XR EXEC mode.

clear mpls traffic-eng counters global

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	mpls-te	execute

Examples The following example shows how to clear the internal MPLS-TE tunnel counters:

```
RP/0/RP0/CPU0:router# clear mpls traffic-eng counters global
```

clear mpls traffic-eng counters signaling

To clear (set to zero) the MPLS tunnel signaling counters, use the **clear mpls traffic-eng counters signaling** command in XR EXEC mode.

clear mpls traffic-eng counters signaling {all | [{heads | mids | tails}] | name *name* | summary}

Syntax Description	all	Clears counters for all MPLS-TE tunnels.
	heads	(Optional) Displays tunnels with their heads at this router.
	mids	(Optional) Displays tunnels with their midpoints at this router.
	tails	(Optional) Displays tunnels with their tails at this router.
	name <i>name</i>	Clears counters for an MPLS-TE tunnel with the specified name.
	summary	Clears the counter's summary.

Command Default	No default behavior or values
-----------------	-------------------------------

Command Modes	XR EXEC mode
---------------	--------------

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines	Use the clear mpls traffic-eng counters signaling command to set all MPLS counters to zero so that changes can be seen easily.
------------------	---

Task ID	Task ID	Operations
	mpls-te	read, write

Examples

The following example shows how to clear all counters:

```
RP/0/RP0/CPU0:router# clear mpls traffic-eng counters signaling all
```

clear mpls traffic-eng counters soft-preemption

To clear (set to zero) the counters for soft-preemption statistics, use the **clear mpls traffic-eng counters soft-preemption** command in XR EXEC mode.

clear mpls traffic-eng counters {all | soft-preemption}

Syntax Description	all	Clears counters for all MPLS-TE tunnels.
	soft-preemption	Clears the statistics for soft preemption counters.

Command Default None

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines When all counters are cleared using the **clear mpls traffic-eng counters all** command, the counters for soft-preemption statistics are automatically cleared.

Task ID	Task ID	Operations
	mpls-te	execute

Examples This example shows how to clear all counters:

```
RP/0/RP0/CPU0:router# clear mpls traffic-eng counters signaling all
```

clear mpls traffic-eng fast-reroute log

To clear the log of MPLS fast reroute (FRR) events, use the **clear mpls traffic-eng fast-reroute log** command in XR EXEC mode.

clear mpls traffic-eng fast-reroute log

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples

The following example shows sample output before clearing the log of FRR events:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng fast-reroute log
```

Node	Protected LSPs Interface	Rewrites	When	Switching Time (usec)
0/0/CPU0	PO0/1/0/1 1	1	Feb 27 19:12:29.064000	147
0/1/CPU0	PO0/1/0/1 1	1	Feb 27 19:12:29.060093	165
0/2/CPU0	PO0/1/0/1 1	1	Feb 27 19:12:29.063814	129
0/3/CPU0	PO0/1/0/1 1	1	Feb 27 19:12:29.062861	128

```
RP/0/RP0/CPU0:router# clear mpls traffic-eng fast-reroute log
```

clear mpls traffic-eng link-management statistics

To clear all the MPLS-TE admission control statistics, use the **clear mpls traffic-eng link-management statistics** command in XR EXEC mode.

clear mpls traffic-eng link-management statistics

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples The following example shows how to clear all the MPLS-TE statistics for admission control:

```
RP/0/RP0/CPU0:router# clear mpls traffic-eng link-management statistics
```

collect-bw-only (MPLS-TE)

To configure only the bandwidth collection without adjusting the bandwidth automatically, use the **collect-bw-only** command in MPLS-TE automatic bandwidth interface configuration mode. To disable this feature, use the **no** form of this command.

collect-bw-only
no collect-bw-only

Syntax Description	This command has no arguments or keywords.
Command Default	Bandwidth collection is either enabled or disabled.
Command Modes	MPLS-TE automatic bandwidth interface configuration

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines	If you enable the collect-bw-only command while the automatic bandwidth is already running on a tunnel, the bandwidth application is disabled from that moment. Before you enable the actual bandwidth application, you can get the status of the automatic bandwidth behavior.
	If you disable the collect-bw-only command on a tunnel from which the automatic bandwidth is already running, the actual bandwidth application takes place on the tunnel at the next application period.
	It is also possible to manually activate a bandwidth application regardless of the collect bandwidth only flag that is being specified on a tunnel. To activate the bandwidth application, use the mpls traffic-eng auto-bw apply (MPLS-TE), on page 83 command in XR EXEC mode.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples	The following example shows how to enable only the bandwidth collection without adjusting the automatic bandwidth:
-----------------	--

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-te 1
RP/0/RP0/CPU0:router(config-if)# auto-bw
RP/0/RP0/CPU0:router(config-if-tunte-autobw)# collect-bw-only
```

destination (MPLS-TE)

To configure the destination address of a TE tunnel, use the **destination** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

destination *ip-address*
no destination *ip-address*

Syntax Description	<i>ip-address</i> Destination address of the MPLS-TE router ID.
---------------------------	---

Command Default	No default behavior or values
------------------------	-------------------------------

Command Modes	Interface configuration
----------------------	-------------------------

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines



Note The tunnel destination address must be a unique MPLS-TE router ID; it cannot be an MPLS-TE link address on a node.

For Point-to-Point (P2P) tunnels, the **destination** command is used as a single-line command.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples

The following example shows how to set the destination address for tunnel-te1 to 10.10.10.10:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-te1
RP/0/RP0/CPU0:router(config-if)# destination 10.10.10.10
```


disable (explicit-path)

To prevent the path from being used by MPLS-TE tunnels while it is configured, use the **disable** command in explicit path configuration mode. To return to the default behavior, use the **no** form of this command.

disable
no disable

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	Explicit path is enabled.
------------------------	---------------------------

Command Modes	Explicit path configuration
----------------------	-----------------------------

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines	No specific guidelines impact the use of this command.
-------------------------	--

Task ID	Task ID	Operations
	mpls-te	read, write

Examples

The following example shows how to disable explicit path 200:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# explicit-path identifier 200
RP/0/RP0/CPU0:router(config-expl-path)# disable
```

ds-te bc-model

To enable a specific bandwidth constraint model (Maximum Allocation Model or Russian Doll Model) on the entire label switched router (LSR), use the **ds-te bc-model** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

ds-te bc-model mam
no ds-te bc-model mam

Syntax Description

mam Enables the Maximum Allocation Model (MAM) bandwidth constraints model.

Command Default

RDM is the default bandwidth constraint model.

Command Modes

MPLS-TE configuration

Command History

Release	Modification
Release 6.0	This command was introduced.

Usage Guidelines

You can configure both the MAM and RDM bandwidth values on a single interface before swapping to an alternate global MPLS-TE BC model.

If you configure bandwidth constraints without configuring the corresponding bandwidth constraint values, the router uses default bandwidth constraint values.

MAM is not supported in prestandard DS-TE mode. MAM and RDM are supported in IETF DS-TE mode; RDM is supported in prestandard DS-TE mode.



Note

Changing the bandwidth constraints model affects the entire router and may have a major impact on system performance as nonzero-bandwidth tunnels are torn down.

Task ID

Task ID **Operations**

mpls-te read,
write

Examples

The following example shows how to enable the MAM bandwidth constraints model:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# ds-te bc-model mam
```

ds-te mode

To configure standard differentiated-service TE mode (DS-TE), use the **ds-te mode** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

ds-te mode ietf
no ds-te mode ietf

Syntax Description	ietf Enables IETF standard mode.
---------------------------	---

Command Default	Prestandard DS-TE is the default differentiated service mode.
------------------------	---

Command Modes	MPLS-TE configuration
----------------------	-----------------------

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines	The following two DS-TE modes are supported: • Prestandard mode • The Cisco proprietary mechanism for IGP and RSVP signalling are used and DS-TE does not interoperate with third-party vendor equipment. • IETF mode • Standard defined extensions are used for IGP and RSVP signalling and DS-TE in this mode interoperates with third-party equipment. • IETF mode supports two bandwidth constraint models: the Russian Doll Model (RDM) and Maximum Allocation Model (MAM). • RDM is the default model. • Router advertises variable-length bandwidth constraints, max-reservable- bandwidth, and unreserved bandwidths in TE-classes. • tunnels must have valid class-type and priority configured as per TE-class map in use; otherwise, tunnels remain down. • TE-class map (a set of tunnel priority and class-type values) is enabled to interpret unreserved bandwidth values advertised in IGP; therefore, TE-class map must be identical on all nodes for TE tunnels to be successfully established
-------------------------	---

For DS-TE to function properly, DS-TE modes must be configured identically on all MPLS-TE nodes.

If you need to change the DS-TE mode, you must bring down all tunnel interfaces and after the change, you should flood the updated bandwidth values through the network.



Note Changing the DS-TE mode affects the entire LSR and can have a major impact on system performance when tunnels are torn down.

Task ID

Task ID	Operations
---------	------------

mpls-te	read, write
---------	----------------

Examples

The following example shows how to enable IETF standard mode:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# ds-te mode ietf
```

ds-te te-classes

To enter DS-TE te-class map configuration mode, use the **ds-te te-classes** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

```
ds-te te-classes te-class te_class_index {class-type class_type_number {priority pri_number} |
unused}
no ds-te te-classes te-class te_class_index {class-type class_type_number {priority pri_number} |
unused}
```

Syntax Description

te-class	Configures the te-class map.
<i>te_class_index</i>	TE class-map index. Range is 0 to 7.
class-type	Configures the class type.
<i>class_type_number</i>	Class type value in the te-class map. Range is 0 to 1.
priority	Configures the TE tunnel priority.
<i>pri_number</i>	TE tunnel priority value. Range is 0 to 7.
unused	Marks the TE-class as unused.

Command Default

The following default te-class maps are used in IETF DS-TE mode:

te-class index	class-type	priority
0	0	7
1	1	7
2	UNUSED	—
3	UNUSED	—
4	0	0
5	1	0
6	UNUSED	—
7	UNUSED	—



Note

The default mapping has 4 TE-classes used with 2 class-types and, 4 TE-classes are unused. TE-class map is not used in prestandard DS-TE mode.

Command Modes

MPLS-TE configuration

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines In IETF DS-TE mode, modified semantic of the unreserved bandwidth TLV is used. Each of the eight available bandwidth values advertised in the IGP corresponds to a TE class. Because IGP advertises only eight bandwidth values, only eight TE-Classes can be supported in a IETF DS-TE network. The TE-Class mapping must be configured the same way on every router in a DS-TE domain. There is, however, no method to automatically detect or enforce this required consistency.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples The following example shows how to configure a TE-class 7 parameter:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# ds-te te-classes te-class 7 class-type 0 priority 4
```

exclude srlg (auto-tunnel backup)

To specify that automatic backup tunnels should avoid Shared Risk Link Groups (SRLGs) of protected interface, use the **exclude srlg** command in auto-tunnel backup configuration mode. To disable this feature, use the **no** form of this command.

```
exclude srlg [preferred]
no exclude srlg [preferred]
```

Syntax Description	preferred (Optional) Causes the backup tunnel to avoid SRLGs of its protected interface(s); however, the backup tunnel is created if SRLGs are not avoided.				
Command Default	Strict SRLG				
Command Modes	Auto-tunnel backup configuration				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 6.0</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 6.0	This command was introduced.
Release	Modification				
Release 6.0	This command was introduced.				
Usage Guidelines	Strict SRLG configuration of this command means that the path computed for the backup tunnel that is automatically created, must not contain any links that are part of the excluded SRLG groups. If such a path cannot be found, the backup tunnel does not come up. Configuration of the preferred option allows the automatic backup tunnel to come up even if a path that excludes SRLGs can not be found.				
Task ID	<table> <tr> <th>Task ID</th><th>Operation</th></tr> <tr> <td>mpls-te</td><td>read, write</td></tr> </table>	Task ID	Operation	mpls-te	read, write
Task ID	Operation				
mpls-te	read, write				

Example

In the following example, automatic backup tunnels must avoid SRLGs of the protected interface.

```
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)#
RP/0/RP0/CPU0:router(config-mpls-te-if)# auto-tunnel backup
RP/0/RP0/CPU0:router(config-mpls-te-if-auto-backup)# exclude srlg preferred
```

fast-reroute

To enable fast-reroute (FRR) protection for an MPLS-TE tunnel, use the **fast-reroute** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

fast-reroute
no fast-reroute

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	FRR is disabled.
------------------------	------------------

Command Modes	Interface configuration
----------------------	-------------------------

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines	When a protected link used by the fast-reroutable label switched path (LSP) fails, the traffic is rerouted to a previously assigned backup tunnel. Configuring FRR on the tunnel informs all the nodes that the LSP is traversing that this LSP desires link/node/bandwidth protection.
-------------------------	---

You must allow sufficient time after an RSP RP switchover before triggering FRR on standby RSPs RPs to synchronize with the active RSP RP (verified using the **show redundancy** command). All TE tunnels must be in the recovered state and the database must be in the ready state for all ingress and egress line cards. To verify this information, use the **show mpls traffic-eng tunnels** and **show mpls traffic-eng fast-reroute database** commands.



Note	Wait approximately 60 seconds before triggering FRR after verifying the database state.
-------------	---

Task ID	Task ID	Operations
	mpls-te	read, write

Examples	The following example shows how to enable FRR on an MPLS-TE tunnel:
-----------------	---

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-te 1
RP/0/RP0/CPU0:router(config-if)# fast-reroute
```


fast-reroute protect

To enable node and bandwidth protection for an MPLS-TE tunnel, use the **fast-reroute protect** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

fast-reroute protect {**bandwidth** | **node**}
no fast-reroute protect

Syntax Description	bandwidth	Enables bandwidth protection request.
	node	Enables node protection request.

Command Default FRR is disabled.

Command Modes Interface configuration

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples The following example shows how to enable bandwidth protection for a specified TE tunnel:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)#interface tunnel-te 1
RP/0/RP0/CPU0:router(config-if)# fast-reroute protect bandwidth
```

fast-reroute timers promotion

To configure how often the router considers switching a protected MPLS-TE tunnel to a new backup tunnel if additional backup-bandwidth or a better backup tunnel becomes available, use the **fast-reroute timers promotion** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

fast-reroute timers promotion *interval*
no fast-reroute timers promotion

Syntax Description	<i>interval</i> Interval, in seconds, between scans to determine if a label switched path (LSP) should use a new, better backup tunnel. Range is 0 to 604800. A value of 0 disables backup tunnel promotions.				
Command Default	<i>interval</i> : 300				
Command Modes	MPLS-TE configuration				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 6.0</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 6.0	This command was introduced.
Release	Modification				
Release 6.0	This command was introduced.				
Usage Guidelines	Setting the interval to a low value puts more load on the CPU because it has to scan all protected LSPs more frequently. It is not recommended that the timer be configured below the default value of 300 seconds. Pacing mechanisms have been implemented to distribute the load on the CPU when backup promotion is active. Because of this, when a large number of protected LSPs are promoted, some delay is noticeable in backup promotion. If the promotion timer is configured to a very low value (depending on the number of protected LSPs) some protected LSPs may never get promoted. To disable the timer, set the value to zero.				
Task ID	<table> <tr> <th>Task ID</th><th>Operations</th></tr> <tr> <td>mpls-te</td><td>read, write</td></tr> </table>	Task ID	Operations	mpls-te	read, write
Task ID	Operations				
mpls-te	read, write				
Examples	The following example shows how to specify that LSPs are scanned every 600 seconds (10 minutes) to determine if they should be promoted to a better backup tunnel: <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# mpls traffic-eng RP/0/RP0/CPU0:router(config-mpls-te)# fast-reroute timers promotion 600</pre>				

flooding thresholds

To set the reserved bandwidth thresholds for a link, use the **flooding thresholds** command in MPLS-TE interface configuration mode. To return to the default behavior, use the **no** form of this command.

flooding thresholds {**down** | **up**} *percent* [{*percent1 percent2 percent3 ... percent 15*}]
no flooding thresholds {**down** | **up**}

Syntax Description	down	Configures the threshold for decreased resource availability.
	up	Configures the threshold for increased resource availability.
	<i>percent</i> [<i>percent</i>]	Bandwidth threshold level. Range is 0 to 100 for all 16 levels.
Command Default	down: 100, 99, 98, 97, 96, 95, 90, 85 , 80, 75 , 60, 45, 30, 15	
	up: 5, 30, 45, 60, 75, 80, 85, 90, 95, 97 , 98, 99, 100	
Command Modes	MPLS-TE interface configuration	
Command History	Release	Modification
	Release 6.0	This command was introduced.
Usage Guidelines	You can configure up to 16 flooding threshold values. The first value is mandatory; the next 15 are optional. When a threshold is crossed, MPLS-TE link management advertises updated link information. If no thresholds are crossed, changes can be flooded periodically unless periodic flooding was disabled.	
Task ID	Task ID	Operations
	mpls-te	read, write

Examples

The following example shows how to set the reserved bandwidth threshold for the link for decreased resource availability (down) and for increased resource availability (up) thresholds:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# interface HundredGigabitEthernet
0/0/0/3
RP/0/RP0/CPU0:router(config-mpls-te-if)# flooding thresholds down 100 75 25
RP/0/RP0/CPU0:router(config-mpls-te-if)# flooding thresholds up 25 50 100
```

forward-class

To define the forwarding path in the MPLS-TE interface, use the **forward-class** command in MPLS-TE configuration mode. To remove forward-class configuration, use the **no** form of this command.

forward-class *forward-class*

no forward-class

<i>forward-class</i>	Forward class for the tunnel. Range is 1 to 7.
----------------------	--

Command Default	No default behavior or values	
Command Modes	MPLS-TE configuration	
Command History	Release	Modification
	Release 6.0	This command was introduced.
Usage Guidelines	No specific guidelines impact the use of this command.	
Task ID	Task ID	Operations
	mpls-te	read, write

Examples

The following example shows how to define forwarding path in the MPLS-TE interface:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)#interface tunnel-te 1
RP/0/RP0/CPU0:router(config-if)#forward-class 1
```

forwarding-adjacency

To configure an MPLS-TE forwarding adjacency, use the **forwarding-adjacency** command in interface configuration mode. By configuring forwarding adjacency, the MPLS-TE tunnels are considered to be links by the IGP. If no forwarding adjacency is to be defined, use the **no** form of this command.

forwarding-adjacency [**holdtime** *time*][**include-ipv6**]
no forwarding-adjacency [**holdtime** *time*][**include-ipv6**]

Syntax Description	holdtime <i>time</i> (Optional) Configures the hold time value, in milliseconds, that is associated with each forwarding-adjacency LSP. The hold time is the duration after which the state change of LSP is advertised to IGP. The default value is 0. include-ipv6 (Optional) Announces the MPLS-TE tunnel as an IPv6 forwarding adjacency.
---------------------------	---

Command Default	holdtime <i>time</i> : 0
------------------------	---------------------------------

Command Modes	Interface configuration
----------------------	-------------------------

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines If you do not specify a **holdtime** *time* value, a delay is introduced with the following results:

- When forwarding-adjacency is configured on a tunnel that is up, TE notifies IGP without any additional delay.
- When forwarding-adjacency is configured on a tunnel that is down, TE does not notify IGP.
- When a tunnel on which forwarding-adjacency has been configured comes up, TE holds the notification to IGP for the period of holdtime (assuming non-zero holdtime). When the holdtime elapses, TE notifies IGP if the tunnel is still up.

The paths that traffic is taking to the destination can be manipulated by adjusting the forwarding adjacency link metric. To do that, use the **bandwidth** command. The unit of possible bandwidth values is in kbps.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples This example shows how to configure forwarding adjacency with a holdtime value of 60 milliseconds:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-te 888
RP/0/RP0/CPU0:router(config-if)# forwarding-adjacency holdtime 60
```

This example shows how to announce MPLS-TE tunnel as an IPv6 forwarding adjacency:

```
RP/0/RP0/CPU0:router#configure
RP/0/RP0/CPU0:router(config)#interface tunnel-te 65534
RP/0/RP0/CPU0:router(config-if)#forwarding-adjacency
RP/0/RP0/CPU0:router(config-if-tunte-fwdadj)#include-ipv6
```

index exclude-address

To exclude an address from a tunnel path entry at a specific index, use the **index exclude-address** command in explicit path configuration mode. To return to the default behavior, use the **no** form of this command.

```
index index-id exclude-address { ipv4 unicast IP address }
no index index-id
```

Syntax Description	<i>index-id</i>	Index number at which the path entry is inserted or modified. Range is 1 to 65535.
	ipv4 unicast <i>IP address</i>	Excludes the IPv4 unicast address.

Command Default No default behavior or values

Command Modes Explicit path configuration

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines You cannot include or exclude addresses from an IP explicit path unless explicitly configured using the **exclude-address** keyword.

Use the **exclude-address** keyword only after entering the explicit path configuration mode.

If you use the **exclude-address** keyword and specify the IP address of a link, the constraint-based routine does not consider that link when it sets up MPLS-TE paths. If the excluded address is a flooded MPLS-TE router ID, the constraint-based shortest path first (SPF) routine does not consider that entire node.



Note The person who performs the configuration must know the IDs of the routers, as it may not be apparent if the value refers to the link or to the node.

MPLS-TE accepts IP explicit paths composed of all excluded addresses configured using the **exclude-address** keyword.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples

The following example shows how to exclude address 192.168.3.2 at index 3 of the explicit path 200:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# explicit-path identifier 200
```

```
RP/0/RP0/CPU0:router(config-expl-path)# index 3 exclude-address ipv4 unicast 192.168.3.2
```


index exclude-srlg

To exclude an address to get SRLGs from a tunnel path entry at a specific index, use the **index exclude-srlg** command in explicit path configuration mode. To return to the default behavior, use the **no** form of this command.

index *index-id* **exclude-srlg** **ipv4 unicast** *IP address*

no index *index-id*

Syntax Description	<i>index-id</i>	Index number at which the path entry is inserted or modified. Range is 1 to 65535.
	exclude-srlg	Specifies an IP address to get SRLG values from for exclusion.
	ipv4 unicast <i>IP address</i>	Excludes the IPv4 unicast address.
Command Default	No default behavior or values	
Command Modes	Explicit path configuration	
Command History	Release	Modification
	Release 6.0	This command was introduced.
Usage Guidelines	No specific guidelines impact the use of this command.	
Task ID	Task ID	Operation
	mpls-te	read, write

Example

The following example shows how to exclude the SRLG values from the IP address 192.168.3.2 at index 1 of the explicit path 100:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# explicit-path identifier 100
RP/0/RP0/CPU0:router(config-expl-path)# index 1 exclude-srlg ipv4 unicast 192.168.3.2
```

index next-address

To include a path entry at a specific index, use the **index next-address** command in explicit path configuration mode. To return to the default behavior, use the **no** form of this command.

index *index-id* **next-address** [{**loose** | **strict**}] **ipv4 unicast** *IP-address*
no index *index-id*

Syntax Description	<i>index-id</i>	Index number at which the path entry is inserted or modified. Range is 1 to 65535.
	ipv4 unicast <i>IP-address</i>	Includes the IPv4 unicast address (strict address).
	loose ipv4 unicast <i>IP-address</i>	(Optional) Specifies the next unicast address in the path as a loose hop.
	strict ipv4 unicast <i>IP-address</i>	(Optional) Specifies the next unicast address in the path as a strict hop.

Command Default No default behavior or values

Command Modes Explicit path configuration

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines You cannot include addresses from an IP explicit path unless explicitly configured using the **next-address** keyword.

Use the **next-address** keyword only after entering the explicit path configuration mode.



Note The person who performs the configuration must know the IDs of the routers, as it may not be apparent if the value refers to the link or to the node.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples The following example shows how to insert the **next-address** 192.168.3.2 at index 3 of the explicit path 200:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# explicit-path identifier 200
```

```
RP/0/RP0/CPU0:router(config-expl-path)# index 3 next-address ipv4 unicast 192.168.3.2
```

interface (MPLS-TE)

To enable MPLS-TE on an interface and to enter MPLS-TE interface configuration mode, use the **interface** command in XR Config mode. To return to the default behavior, use the **no** form of this command.

interface *type interface-path-id*
no interface *type interface-path-id*

Syntax Description	<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
	<i>interface-path-id</i>	Physical interface or virtual interface.
	Note	Use the show interfaces command to see a list of all possible interfaces currently configured on the router.
		For more information about the syntax for the router, use the question mark (?) online help function.

Command Default No default behavior or values

Command Modes XR Config mode

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines You must enter MPLS-TE interface mode to configure specific interface parameters on physical interfaces. Configuring MPLS-TE links or a tunnel TE interface begins the TE-control process on RSP RP.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples The following example shows how to enter the MPLS-TE interface configuration mode:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# interface HundredGigabitEthernet
0/0/0/3
```

The following example shows how to remove an interface from the MPLS-TE domain:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
```

```
RP/0/RP0/CPU0:router(config-mpls-te)# no interface HundredGigabitEthernet 0/0/0/3
```

interface (SRLG)

To enable Shared Risk Link Groups (SRLGs) on an interface and to enter SRLG interface configuration mode, use the **interface** command in SRLG configuration mode. To return to the previous configuration mode, use the **no** form of this command.

interface *type interface-path-id*
no interface *type interface-path-id*

Syntax Description	<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
	<i>interface-path-id</i>	Physical interface or virtual interface.
	Note	Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
Command Default	No default behavior or values	
Command Modes	SRLG configuration	
Command History	Release	Modification
	Release 6.0	This command was introduced.
Usage Guidelines	No specific guidelines impact the use of this command.	
Task ID	Task ID	Operation
	mpls-te	read, write

Example

The following example shows how to enter SRLG interface configuration mode:

```
RP/0/RP0/CPU0:router(config)# srlg
RP/0/RP0/CPU0:router(config-srlg)# interface HundredGigabitEthernet
0/0/0/3
RP/0/RP0/CPU0:router(config-srlg-if)# value 10
RP/0/RP0/CPU0:router(config-srlg-if)#value 50
```

interface tunnel-te

To configure an MPLS-TE tunnel interface, use the **interface tunnel-te** command in XR Config mode. To return to the default behavior, use the **no** form of this command.

```
interface tunnel-te tunnel-id
no interface tunnel-te tunnel-id
```

Syntax Description	<i>tunnel-id</i> Tunnel number. Range is 0 to 65535.
---------------------------	--

Command Default	Tunnel interfaces are disabled.
------------------------	---------------------------------

Command Modes	XR Config mode
----------------------	----------------

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines You cannot have two tunnels using the same encapsulation mode with exactly the same source and destination address. The workaround is to create a loopback interface and to use the loopback interface address as the source address of the tunnel.

Configuring MPLS-TE links or Tunnel-TE interface begins the TE-control process on RSP RP.

The **interface tunnel-te** command indicates that the tunnel interface is for an MPLS-TE tunnel and enables the various tunnel MPLS configuration options.



Note You must configure record-route on TE tunnels that are protected by multiple backup tunnels merging at a single node.

Task ID	Task ID	Operations
	interface	read, write

Examples

The following example shows how to configure tunnel interface 1:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-te 1
RP/0/RP0/CPU0:router(config-if)# ipv4 unnumbered loopback0
```

The following example shows how to set the tunnel-class attribute to map the correct traffic class to the tunnel:

interface tunnel-te

```
RP/0/RP0/CPU0:router# configure  
RP/0/RP0/CPU0:router(config)# interface tunnel-te 1  
RP/0/RP0/CPU0:router(config-if)# policy-class 1
```


ipv4 unnumbered (MPLS)

To specify the MPLS-TE tunnel Internet Protocol Version 4 (IPv4) address, use the **ipv4 unnumbered** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

ipv4 unnumbered *type interface-path-id*
no ipv4 unnumbered *type interface-path-id*

Syntax Description	<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
	<i>interface-path-id</i>	Physical interface or virtual interface.
	Note	Use the show interfaces command to see a list of all interfaces currently configured on the router.
		For more information about the syntax for the router, use the question mark (?) online help function.

Command Default	No IP address is set.
------------------------	-----------------------

Command Modes	Interface configuration
----------------------	-------------------------

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines

Tunnel-te is not signaled until an IP address is configured on the tunnel interface; therefore, the tunnel state stays down without IP address configuration.

Loopback is commonly used as the interface type.

Task ID	Task ID	Operations
	network	read, write

Examples

The following example shows how to configure the MPLS-TE tunnel to use the IPv4 address used on loopback interface 0:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-te 1
RP/0/RP0/CPU0:router(config-if)# ipv4 unnumbered loopback0
```

ipv4 unnumbered mpls traffic-eng

To specify the Internet Protocol Version 4 (IPv4) address, use the **ipv4 unnumbered mpls traffic-eng** command in XR Config mode. To remove the IPv4 address, use the **no** form of this command.

ipv4 unnumbered mpls traffic-eng *interface-path-id*
no **ipv4 unnumbered mpls traffic-eng**

Syntax Description

interface-path-id Physical interface or virtual interface.

Note Use the **show interfaces** command to see a list of all interfaces currently configured on the router.

Command Default

No default behavior or values.

Command Modes

XR Config mode .

Command History

Release	Modification
Release 6.0	This command was introduced.

Usage Guidelines

No specific guidelines impact the use of this command.

Task ID

Task ID	Operations
network	read, write

Examples

The following example shows how to specify unnumbered IPv4 address for a GigabitEthernet interface:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# ipv4 unnumbered mpls traffic-eng HundredGigabitEthernet
0/0/0/3
```

The following example shows how to specify unnumbered IPv4 address for an MPLS-TE tunnel with tunnel ID 200:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# ipv4 unnumbered mpls traffic-eng tunnel-te 200
```

link-management timers bandwidth-hold

To set the length of time that bandwidth is held for a Resource Reservation Protocol (RSVP) Path (setup) message to wait for the corresponding RSVP Resv message to return, use the **link-management timers bandwidth-hold** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

link-management timers bandwidth-hold *holdtime*
no link-management timers bandwidth-hold *holdtime*

Syntax Description	<i>holdtime</i> Number of seconds that bandwidth can be held. Range is 1 to 300. Default is 15.	
Command Default	<i>holdtime</i> : 15	
Command Modes	MPLS-TE configuration	
Command History	Release	Modification
	Release 6.0	This command was introduced.
Usage Guidelines	The link-management timers bandwidth-hold command determines the time allowed for an RSVP message to return from a neighbor RSVP node.	
Task ID	Task ID	Operations
	mpls-te	read, write
Examples	The following example shows how to set the bandwidth to be held for 10 seconds: RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# mpls traffic-eng RP/0/RP0/CPU0:router(config-mpls-te)# link-management timers bandwidth-hold 10	

link-management timers periodic-flooding

To set the length of the interval for periodic flooding, use the **link-management timers periodic-flooding** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

link-management timers periodic-flooding *interval*
no link-management timers periodic-flooding

Syntax Description	<i>interval</i> Length of the interval, in seconds, for periodic flooding. Range is 0 to 3600. A value of 0 turns off periodic flooding. The minimum value is 30.	
Command Default	<i>interval</i> : 180	
Command Modes	MPLS-TE configuration	
Command History	Release	Modification
	Release 6.0	This command was introduced.
Usage Guidelines	The link-management timers periodic-flooding command advertises the link state information changes that do not trigger immediate action, such as a change to the allocated bandwidth that does not cross a threshold.	
Task ID	Task ID	Operations
	mpls-te	read, write
Examples	The following example shows how to set the interval length for periodic flooding to 120 seconds: <pre> RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# mpls traffic-eng RP/0/RP0/CPU0:router(config-mpls-te)# link-management timers periodic-flooding 120 </pre>	

link-management timers preemption-delay

To set the length of the interval for delaying LSP preemption, use the **link-management timers preemption-delay** command in MPLS-TE configuration mode. To disable this behavior, use the **no** form of this command.

link-management timers preemption-delay bundle-capacity *sec*

Syntax Description	bundle-capacity <i>sec</i> Specifies the bundle-capacity preemption timer value in seconds.	
Command Default	None	
Command Modes	MPLS-TE configuration	
Command History	Release	Modification
	Release 6.0	This command was introduced.
Usage Guidelines	The value 0 as bundle-capacity value in the link-management timers preemption-delay command disables this timer. This means there is no delay before preemption sets in when the bundle capacity goes down.	
Task ID	Task ID	Operation
	mpls-te	read, write

This example shows how to set the interval length for preemption-delay:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# link-management timers preemption-delay bundle-capacity
180
```

load-share

To determine load-sharing balancing parameters for a specified interface, use the **load-share** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

load-share *value*
no load-share

Syntax Description	<i>value</i> Load-share value, equivalent to the bandwidth in kbps (that is, the same value in configuration). Range is 1 to 4294967295. Default is 0.	
Command Default	The default load-share for tunnels with no explicit configuration is the configured signalled bandwidth. <i>value</i> : 0 (if no value is assigned)	
Command Modes	Interface configuration	
Command History	Release	Modification
	Release 6.0	This command was introduced.
Usage Guidelines	Configuration schemas are supported for load balancing. To enable the load-share command, you must enable unequal load balancing using the load-share unequal command.	
Task ID	Task ID	Operations
	mpls-te	read, write
Examples	The following example shows how to configure load-sharing parameters on a specified interface: <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# interface tunnel-te 100 RP/0/RP0/CPU0:router(config-if)# load-share 100</pre>	

load-share unequal

To configure unequal load-sharing for an MPLS-TE tunnel, use the **load-share unequal** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

load-share unequal
no load-share unequal

Syntax Description	This command has no arguments or keywords.				
Command Default	By default, unequal load-balancing is disabled and equal load-balancing occurs.				
Command Modes	MPLS-TE configuration				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 6.0</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 6.0	This command was introduced.
Release	Modification				
Release 6.0	This command was introduced.				

Usage Guidelines

The **auto-bw** and **load-share unequal** commands should not be used together.

The **load-share unequal** command determines the load-share for a tunnel based on the bandwidth. However, the MPLS-TE automatic bandwidth feature changes the bandwidth around. If you are configuring both the **load-share unequal** command and the MPLS-TE automatic bandwidth feature, we recommend that you specify an explicit load-share value configuration under each MPLS-TE automatic bandwidth tunnel.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples

The following example shows how to enable unequal load-sharing:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# load-share unequal
```

match mpls disposition

To match Tag2IP packets while redirecting MPLS labeled packets to a new destination using PBR policy, use the **match mpls disposition** command in class-map configuration mode. To remove redirection of MPLS labeled packets, use the **no** form of this command.

match mpls disposition access-group {ipv4 | ipv6} access-list
no match mpls disposition access-group {ipv4 | ipv6} access-list

Syntax Description	access-group	Specifies an access-group.
	ipv4 ipv6	Specifies IPv4 or IPv6 address.
	access-list	Specifies an access-list.
Command Default	Match is not set.	
Command Modes	Class-map configuration	
Command History	Release	Modification
	Release 6.0	This command was introduced.
Usage Guidelines	Only Tag2IP packets can be redirected.	
Task ID	Task ID	Operation
	qos	read, write

This example shows how to configure match MPLS disposition sequence for an IPv4 address:

```
RP/0/RP0/CPU0:router#configure
RP/0/RP0/CPU0:router(config)#class-map type traffic class_mpls_src_test
RP/0/RP0/CPU0:router(config-cmap)#match mpls disposition access-group ipv4 ACL_MPLS_SRC
RP/0/RP0/CPU0:router(config-cmap)#end-class-map
```


maxabs (MPLS-TE)

To specify the maximum number of MPLS-TE tunnels that can be configured, use the **maxabs** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

maxabs tunnels tunnel-limit destinations dest-limit
no maxabs tunnels tunnel-limit destinations dest-limit

Syntax Description	tunnels	Configures all tunnels for MPLS-TE.
	tunnel-limit	Maximum number of tunnel TE interfaces. Range is 1 to 65536.
	destinations	Configures all destinations for MPLS-TE.
	dest-limit	Maximum total number of destinations that can be configured. Range is 1 to 65536.
Command Default	<i>tunnel-limit: 4096</i> <i>dest-limit: 4096</i>	
Command Modes	MPLS-TE configuration	
Command History	Release	Modification
	Release 6.0	This command was introduced.
Usage Guidelines	No specific guidelines impact the use of this command.	
Task ID	Task ID	Operations
	mpls-te	read, write
Examples	The following example shows how to set the tunnel-te configuration limit to 1000: <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# mpls traffic-eng RP/0/RP0/CPU0:router(config-mpls-te)# maxabs tunnels 1000 destinations 1000</pre>	

mpls traffic-eng

To enter MPLS-TE configuration mode, use the **mpls traffic-eng** command in XR Config mode.

mpls traffic-eng

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	No default behavior or values
------------------------	-------------------------------

Command Modes	XR Config mode
----------------------	----------------

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines	No specific guidelines impact the use of this command.
-------------------------	--

Task ID	Task ID	Operations
	mpls-te	read, write

Examples	The following example shows how to enter MPLS-TE configuration mode:
-----------------	--

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)#
```

mpls traffic-eng auto-bw apply (MPLS-TE)

To apply the highest bandwidth collected on a tunnel without waiting for the current application period to end, use the **mpls traffic-eng auto-bw apply** command in XR EXEC mode.

mpls traffic-eng auto-bw apply {all | tunnel-te *tunnel-number*}

Syntax Description	all	Applies the highest bandwidth collected instantly on all the automatic bandwidth-enabled tunnels.
	tunnel-te <i>tunnel-number</i>	Applies the highest bandwidth instantly to the specified tunnel. The range is from 0 to 65535.

Command Default No default behavior or values

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines The **mpls traffic-eng auto-bw apply** command can forcefully expire the current application period on a specified tunnel and immediately apply the highest bandwidth recorded so far instead of waiting for the application period to end on its own.



Note The predefined threshold check still applies on the configuration, and if the delta is not significant enough, the automatic bandwidth functionality overrides this command.

The bandwidth application is performed only if at least one output rate sample has been collected for the current application period.

To guarantee the application of a specific signaled bandwidth value when triggering a manual bandwidth application, follow these steps:

1. Configure the minimum and maximum automatic bandwidth to the bandwidth value that you want to apply by using the command.
2. Trigger a manual bandwidth application by using the **mpls traffic-eng auto-bw apply** command.
3. Revert the minimum and maximum automatic bandwidth value back to their original value.

Task ID	Task ID	Operations
	mpls-te	execute

Examples

The following example applies the highest bandwidth to a specified tunnel:

```
RP/0/RP0/CPU0:router# mpls traffic-eng auto-bw apply tunnel-te 1
```

mpls traffic-eng fast-reroute promote

To configure the router to assign new or more efficient backup MPLS-TE tunnels to protected MPLS-TE tunnels, use the **mpls traffic-eng fast-reroute promote** command in XR EXEC mode. To return to the default behavior, use the **no** form of this command.

mpls traffic-eng fast-reroute promote
no mpls traffic-eng fast-reroute promote

Syntax Description	This command has no arguments or keywords.	
Command Default	No default behavior or values	
Command Modes	XR EXEC mode	
Command History	Release	Modification
	Release 6.0	This command was introduced.
Usage Guidelines	No specific guidelines impact the use of this command.	
Task ID	Task ID	Operations
	mpls-te	read, write

Examples

The following example shows how to initiate backup tunnel promote and assignment:

```
RP/0/RP0/CPU0:router# mpls traffic-eng fast-reroute promote
```

mpls traffic-eng level

To configure a router running Intermediate System-to-System (IS-IS) MPLS-TE at IS-IS Level 1 and Level 2, use the **mpls traffic-eng level** command in XR Config mode. To return to the default behavior, use the **no** form of this command.

mpls traffic-eng level *isis-level*
no mpls traffic-eng level *isis-level*

Syntax Description	<i>isis-level</i> IS-IS level (1, 2, or both) where MPLS-TE is enabled.
---------------------------	---

Command Default	No default behavior or values
------------------------	-------------------------------

Command Modes	XR Config mode
----------------------	----------------

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines	The mpls traffic-eng level command is supported for IS-IS and affects the operation of MPLS-TE only if MPLS-TE is enabled for that routing protocol instance.
-------------------------	--

Task ID	Task ID	Operations
	isis	read, write

Examples	The following example shows how to configure a router running IS-IS MPLS to flood TE for IS-IS level 1:
-----------------	---

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# router isis 1
RP/0/RP0/CPU0:router(config-isis)# address-family ipv4 unicast
RP/0/RP0/CPU0:router(config-isis-af)# mpls traffic-eng level 1
RP/0/RP0/CPU0:router(config-isis-af)# metric-style wide
```

mpls traffic-eng link-management flood

To enable immediate flooding of all the local MPLS-TE links, use the **mpls traffic-eng link-management flood** command in XR EXEC mode. To return to the default behavior, use the **no** form of this command.

mpls traffic-eng link-management flood
no mpls traffic-eng link-management flood

Syntax Description	This command has no arguments or keywords.	
Command Default	No default behavior or values	
Command Modes	XR EXEC mode	
Command History	Release	Modification
	Release 6.0	This command was introduced.
Usage Guidelines	If there is no change in the LSA since last flooding, IGP may dampen the advertisement.	
Task ID	Task ID	Operations
	mpls-te	read, write
Examples	The following example shows how to initiate flooding of the local MPLS-TE links:	

```
RP/0/RP0/CPU0:router# mpls traffic-eng link-management flood
```

mpls traffic-eng path-protection switchover tunnel-te

To force a manual switchover for path-protected tunnel, use the **mpls traffic-eng path-protection switchover tunnel-te** command in XR EXEC mode. To disable this feature, use the **no** form of this command.

mpls traffic-eng path-protection switchover tunnel-te *tunnel ID*
no mpls traffic-eng path-protection switchover tunnel-te *tunnel ID*

Syntax Description	<i>tunnel ID</i> Tunnel identifier of the P2P tunnel for the path protection switchover. Range is from 0 to 65535.				
Command Default	No default behavior or values				
Command Modes	XR EXEC mode				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 6.0</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 6.0	This command was introduced.
Release	Modification				
Release 6.0	This command was introduced.				
Usage Guidelines	No specific guidelines impact the use of this command.				
Task ID	<table> <tr> <th>Task ID</th><th>Operations</th></tr> <tr> <td>mpls-te</td><td>execute</td></tr> </table>	Task ID	Operations	mpls-te	execute
Task ID	Operations				
mpls-te	execute				
Examples	The following example configures the switchover for path-protection for tunnel-te: <pre>RP/0/RP0/CPU0:router# mpls traffic-eng path-protection switchover tunnel-te 8</pre>				

mpls traffic-eng reoptimize (EXEC)

To trigger the reoptimization interval of all TE tunnels, use the **mpls traffic-eng reoptimize** command in XR EXEC mode.

mpls traffic-eng reoptimize [*tunnel-id*] [*tunnel-name*] [**all**] [**p2p**{**all** *tunnel-id*}]

Syntax Description	<i>tunnel-id</i>	(Optional) MPLS-TE tunnel identification expressed as a number. Range is from 0 to 65535.
	<i>tunnel-name</i>	(Optional) TE tunnel identification expressed as a name.
	all	(Optional) Forces an immediate reoptimization for all tunnels.
	p2p	(Optional) Forces an immediate reoptimization of all P2P TE tunnels.
	all	(Optional) Forces an immediate reoptimization for all P2P tunnels.
	<i>tunnel-id</i>	P2P TE tunnel identification to be reoptimized. Range is from 0 to 65535.
Command Default	No default behavior or values	
Command Modes	XR EXEC mode	
Command History	Release	Modification
	Release 6.0	This command was introduced.
Usage Guidelines	No specific guidelines impact the use of this command.	
Task ID	Task ID	Operations
	mpls-te	execute

Examples

The following example shows how to immediately reoptimize all TE tunnels:

```
RP/0/RP0/CPU0:router# mpls traffic-eng reoptimize
```

The following example shows how to immediately reoptimize TE tunnel-te90:

```
RP/0/RP0/CPU0:router# mpls traffic-eng reoptimize tunnel-te90
```

The following example shows how to immediately reoptimize all P2P TE tunnels:

```
RP/0/RP0/CPU0:router# mpls traffic-eng reoptimize p2p all
```

mpls traffic-eng reoptimize events link-up

To turn on automatic reoptimization of Multiprotocol Label Switching (MPLS) traffic engineering when certain events occur, such as, when an interface becomes operational, use the **mpls traffic-eng reoptimize events link-up** command in XR Config mode. To disable automatic reoptimization when link-up event occurs, use the **no** form of this command.

mpls traffic-eng reoptimize events link-up

no mpls traffic-eng reoptimize events link-up

Syntax Description	This command has no arguments or keywords.	
Command Modes	XR Config mode	
Command History	Release	Modification
	Release 6.0	This command was introduced.
Usage Guidelines	No specific guidelines impact the use of this command.	
Task ID	Task ID	Operation
	mpls-te	read, write

Example

The following example shows how to turn on automatic reoptimization when an interface becomes operational:

```
RP/0/RP0/CPU0:router# mpls traffic-eng reoptimize events link-up
```

mpls traffic-eng router-id (MPLS-TE router)

To specify that the TE router identifier for the node is the IP address associated with a given interface, use the **mpls traffic-eng router-id** command in the appropriate mode. To return to the default behavior, use the **no** form of this command.

```
mpls traffic-eng router-id type interface-path-id
no mpls traffic-eng router-id type interface-path-id
```

Syntax Description	<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
	<i>interface-path-id</i>	Physical interface or virtual interface.
	Note	Use the show interfaces command to see a list of all interfaces currently configured on the router.
		For more information about the syntax for the router, use the question mark (?) online help function.

Command Default	No default behavior or values
------------------------	-------------------------------

Command Modes	OSPF configuration
	IS-IS address family configuration

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines A routers identifier acts as a stable IP address for the TE configuration. This IP address is flooded to all nodes. You must set the destination on the destination node TE router identifier for all affected tunnels. This router ID is the address that the TE topology database at the tunnel head uses for its path calculation.



Note When the **mpls traffic-eng router-id** command is not configured, global router ID is used by MPLS-TE if there is one configured.

We suggest that you configure the **mpls traffic-eng router-id** command explicitly under the IGP; otherwise, TE uses the default algorithm to pick up the TE router-id, which can be the highest IP address of the loopback interfaces or physical interfaces.

A TE router-id configuration is highly recommended to ensure that the tunnel head-end picks up the correct source address, and the configured static RPF address at the tail-end matches the tunnel source which avoids unexpected traffic drops.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples

The following examples show how to specify the TE router identifier as the IP address associated with loopback interface:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# router ospf CORE_AS
RP/0/RP0/CPU0:router(config-ospf)# mpls traffic-eng router-id 7.7.7.7

RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# router isis 811
RP/0/RP0/CPU0:router(config-isis)# address-family ipv4 unicast
RP/0/RP0/CPU0:router(config-isis-af)# mpls traffic-eng router-id 8.8.8.8
```

mpls traffic-eng repotimize mesh group

To reoptimize all tunnels of a mesh group, use the **mpls traffic-eng repotimize mesh group** command in XR EXEC mode.

mpls traffic-eng repotimize auto-tunnel mesh group *group_id*

Syntax Description	<i>group_id</i> Defines auto-tunnel mesh group ID that is to be reoptimized. Range is 0 to 4294967295.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	XR EXEC mode
----------------------	--------------

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines	No specific guidelines impact the use of this command.
-------------------------	--

Task ID	Task ID	Operations
	mpls-te	execute

Examples This is sample out from the **mpls traffic-eng repotimize mesh group** command:

```
RP/0/RP0/CPU0:router mpls traffic-eng repotimize mesh group 10
```

mpls traffic-eng srlg

To enter MPLS-TE SRLG configuration mode, use the **mpls traffic-eng srlg** command in XR Config mode. To delete all the SRLG values and mapping configured under traffic engineering, use the **no** form of this command. To enter MPLS-TE SRLG value configuration submode, use the **mpls traffic-eng srlg value srlg value** command in the MPLS TE SRLG configuration mode. To delete all the SRLG values configured, use the **no** form of this command. To specify administrative weight associated with an SRLG value, use the **admin-weight** keyword in the MPLS TE SRLG value configuration submode.

mpls traffic-eng srlg {**admin-weight** *weight* | **value** *srlg value*} **ipv4 address** *ip-address* **next-hop ipv4 address** *next-hop-ip-address*

Syntax Description	admin-weight <i>weight</i>	Value added to link admin-weight during SRLG-aware path computation. Range is 0 to 4294967295.
	value <i>srlg-value</i>	SRLG value. Range is 0 to 4294967295.
	static	Assign SRLG to topology link based on IP address.
	ipv4 address <i>ip-address</i> next-hop ipv4 address <i>next-hop-ip-address</i>	Assign IP address of the local end-point and next-hop address of the link.

Command Default The default value for **admin-weight** keyword is 1.

Command Modes XR Config mode

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples The following example shows how to enter MPLS-TE SRLG configuration mode:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls traffic-eng srlg
RP/0/RP0/CPU0:router(config-mpls-te-srlg)#
```

The following example shows how to enter MPLS-TE SRLG value configuration submode:

```
RP/0/RP0/CPU0:router# configure  
RP/0/RP0/CPU0:router(config)# mpls traffic-eng srlg value 150  
RP/0/RP0/CPU0:router(config-mpls-te-srlg)#
```

The following example shows how to specify admin-weight in the MPLS-TE SRLG value configuration submode:

```
RP/0/RP0/CPU0:router# configure  
RP/0/RP0/CPU0:router(config)# mpls traffic-eng srlg value 150  
RP/0/RP0/CPU0:router(config-mpls-te-srlg)# admin-weight 10
```

nhop-only (auto-tunnel backup)

To configure only a next-hop automatic backup tunnel with only link protection, use the **nhop-only** command in MPLS-TE auto-tunnel backup interface configuration mode. To return to the default configuration setting for automatic backup tunnels, use the **no** form of this command.

nhop-only
no nhop-only

Syntax Description	This command has no arguments or keywords.				
Command Default	Both NHOP and NNHOP protection are enabled.				
Command Modes	Auto-tunnel backup configuration				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 6.0</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 6.0	This command was introduced.
Release	Modification				
Release 6.0	This command was introduced.				
Usage Guidelines	If you configure the nhop-only command, you destroy any next-next-hop (NNHOP) tunnel created to provide node protection for tunnels running over the specified interface. If you unconfigure the nhop-only command, you trigger a backup assignment on primary tunnels running over that link. The automatic backup tunnel feature attempts to create NNHOP backup tunnels to provide node protection for the specified tunnels.				
Task ID	<table> <tr> <th>Task ID</th><th>Operation</th></tr> <tr> <td>mpls-te</td><td>read, write</td></tr> </table>	Task ID	Operation	mpls-te	read, write
Task ID	Operation				
mpls-te	read, write				

Example

In the following example, NNHOP automatic backup tunnels are destroyed and only NHOP tunnels with link protection is configured:

```
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# interface HundredGigE 0/0/0/3
RP/0/RP0/CPU0:router(config-mpls-te-if)# auto-tunnel backup
RP/0/RP0/CPU0:router(config-mpls-te-if-auto-backup)# nhop-only
```


overflow threshold (MPLS-TE)

To configure the tunnel overflow detection, use the **overflow threshold** command in MPLS-TE automatic bandwidth interface configuration mode. To disable the overflow detection feature, use the **no** form of this command.

overflow threshold *percentage* [**min** *bandwidth*] **limit** *limit*
no overflow threshold

Syntax Description	<i>percentage</i>	Bandwidth change percent to trigger an overflow. The range is from 1 to 100.
	min <i>bandwidth</i>	(Optional) Configures the bandwidth change value, in kbps, to trigger an overflow. The range is from 10 to 4294967295. The default is 10.
	limit <i>limit</i>	Configures the number of consecutive collection intervals that exceeds the threshold. The bandwidth overflow triggers an early tunnel bandwidth update. The range is from 1 to 10. The default is none.

Command Default The default value is disabled.

Command Modes MPLS-TE automatic bandwidth interface configuration

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines

If you modify the **limit** keyword, the consecutive overflows counter for the tunnel is also reset.

If you enable or modify the minimum value, the current consecutive overflows counter for the tunnel is also reset, which effectively restarts the overflow detection from scratch.

Several number of consecutive bandwidth samples are greater than the overflow threshold (bandwidth percentage) and the minimum bandwidth configured, then a bandwidth application is updated immediately instead of waiting for the end of the application period.

Overflow detection applies only to bandwidth increase. For example, an overflow can not be triggered even if bandwidth decreases by more than the configured overflow threshold.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples The following example shows how to configure the tunnel overflow detection for tunnel-te 1:

```
RP/0/RP0/CPU0:router# configure
```

```
RP/0/RP0/CPU0:router(config)# interface tunnel-te 1  
RP/0/RP0/CPU0:router(config-if)# auto-bw  
RP/0/RP0/CPU0:router(config-if-tunte-autobw)# overflow threshold 50 limit 3
```

path-option (MPLS-TE)

To configure a path option for an MPLS-TE tunnel, use the **path-option** command in tunnel-te interface configuration mode. To return to the default behavior, use the **no** form of this command.

path-option *preference-priority* [**protecting** *number*] {**dynamic** | **explicit** {**name** *path-name* | **identifier** *path-number*}} [**protected-by** *path-option-level*] [**attribute-set** *name*] [**isis** *instance-name* **level** *level*] [**lockdown**] [**ospf** *instance-name* **area** {*value* *address*}] [**verbatim**]
no path-option *preference-priority* {**dynamic** | **explicit** {**name** *path-name* | **identifier** *path-number*}} [**protected-by** *path-option-level*] [**isis** *instance-name* **level** *level*] [**lockdown**] [**ospf** *instance-name* **area** {*value* *address*}] [**verbatim**]

Syntax Description		
<i>preference-priority</i>		Path option number. Range is from 1 to 1000.
protecting <i>number</i>		Specifies a path setup option to protect a path. The range is from 1 to 1000.
dynamic		Specifies that label switched paths (LSP) are dynamically calculated.
explicit		Specifies that LSP paths are IP explicit paths.
name <i>path-name</i>		Specifies the path name of the IP explicit path.
identifier <i>path-number</i>		Specifies a path number of the IP explicit path.
protected-by <i>path-option-level</i>	(Optional)	Configures path protection for an explicit path that is protected by another explicit path.
isis <i>instance-name</i>	(Optional)	Limits CSPF to a single IS-IS instance and area.
attribute-set <i>name</i>	(Optional)	Specifies the attribute set for the LSP.
level <i>level</i>		Configures the level for IS-IS. The range is from 1 to 2.
lockdown	(Optional)	Specifies that the LSP cannot be reoptimized.
ospf <i>instance-name</i>	(Optional)	Limits CSPF to a single OSPF instance and area.
area		Configures the area for OSPF.
<i>value</i>		Decimal value for the OSPF area ID.
<i>address</i>		IP address for the OSPF area ID.
verbatim	(Optional)	Bypasses the Topology/CSPF check for explicit paths.

Command Default No default behavior or values

Command Modes Tunnel-te interface configuration

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines

You can configure several path options for a single tunnel. For example, there can be several explicit path options and a dynamic option for one tunnel. The path setup preference is for lower (not higher) numbers, so option 1 is preferred.

When the lower number path option fails, the next path option is used to set up a tunnel automatically (unless using the lockdown option).

The **protecting** keyword specifies that you can configure path-protection for the primary LSP. The **protecting** keyword is available only for tunnel-gte interfaces.

You specify the backup path for the **path-option** command in case of the primary path failure.

CSPF areas are configured on a per-path-option basis.

The **dynamic** keyword is required to configure path-protection.

Any primary explicit path on a path protection enabled tunnel can be configured to be protected by an explicit path option level using **protected-by** keyword. Only one explicit protecting path is supported per path option.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples

The following example shows how to configure the tunnel to use a named IPv4 explicit path as verbatim and lockdown options for the tunnel. This tunnel cannot reoptimize when the FRR event goes away, unless you manually reoptimize it:

```
RP/0/RP0/CPU0:router(config)# interface tunnel-te 1
RP/0/RP0/CPU0:router(config-if)# path-option 1 explicit name test verbatim lockdown
```

The following example shows how to enable path protection on a tunnel to configure an explicit path:

```
RP/0/RP0/CPU0:router(config)# interface tunnel-te 1
RP/0/RP0/CPU0:router(config-if)# path-option 1 explicit name po4
RP/0/RP0/CPU0:router(config-if)# path-option protecting 1 explicit name po6
```

The following example shows how to limit CSPF to a single OSPF instance and area:

```
RP/0/RP0/CPU0:router(config)# interface tunnel-te 1
RP/0/RP0/CPU0:router(config-if)# path-option 1 explicit name router1 ospf 3 area 7 verbatim
```

The following example shows how to limit CSPF to a single IS-IS instance and area:

```
RP/0/RP0/CPU0:router(config)# interface tunnel-te 1
RP/0/RP0/CPU0:router(config-if)# path-option 1 dynamic isis mtbf level 1 lockdown
```

path-protection (MPLS-TE)

To enable path protection for a tunnel interface , use the **path-protection** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

path-protection
no path-protection

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes Interface configuration

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines Although not as fast as a link or node protection, presignaling a secondary Labeled Switch Path (LSP) is faster than configuring a secondary path option or allowing the tunnel's source router to dynamically recalculate a path. The actual recovery time is topology-dependent, and is affected by delay factors such as propagation delay and switch fabric latency.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples The following example shows how to enable path protection for the tunnel-te interface type:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-te 1
RP/0/RP0/CPU0:router(config-if)# path-protection
```

path-protection timers reopt-after-switchover

To configure the time to wait after a switchover occurs on a tunnel before a reoptimization is attempted for the tunnel, use the **path-protection timers reopt-after-switchover** command in MPLS-TE configuration mode. To disable this feature, use the **no** form of this command.

path-protection timers reopt-after-switchover *seconds*
no path-protection timers reopt-after-switchover *seconds*

Syntax Description	<i>seconds</i> Time, in seconds, between path-protection event and tunnel reoptimization. Range is from 0 to 604800.	
Command Default	<i>seconds</i> : 180 (3 minutes)	
Command Modes	MPLS-TE configuration	
Command History	Release	Modification
	Release 6.0	This command was introduced.
Usage Guidelines	This command is used as a triggered reoptimization, which allows a tunnel to reoptimize to a better path than the standby path after the switchover. This option is used as a one time reoptimization.	
Task ID	Task ID	Operations
	mpls-te	read, write
Examples	The following example shows how to adjust the number of seconds between when a path-protection switchover is effected on a tunnel head to when reoptimization is performed on the tunnel: <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# mpls traffic-eng RP/0/RP0/CPU0:router(config-mpls-te)# path-protection timers reopt-after-switchover 180</pre>	

path-selection cost-limit

To set the upper limit on the path aggregate admin-weight when computing paths for MPLS-TE LSPs, use the **path-selection cost-limit** command in an appropriate configuration mode. To remove the upper limit, use the **no** form of this command.

path-selection cost-limit *cost-limit-value*

Syntax Description	<i>cost-limit-value</i> Configures the path-selection cost-limit value. The range is from 1 to 4294967295.	
Command Default	The cost-limit is ignored.	
Command Modes	XR Config mode Interface tunnel TE configuration MPLS TE path-option attribute set configuration	
Command History	Release	Modification
	Release 6.0	This command was introduced.
Usage Guidelines	Path-selection cost-limit configuration works only on MPLS TE tunnels. The cost-limit configured under path-option attribute-set configuration mode takes priority and will be in effect if the cost-limit is configured under global configuration, interface tunnel TE, and path-option attribute-set configuration modes. The cost-limit is ignored by default. A LSP is created only if its path aggregate admin-weight is less than the specified path cost limit.	
Task ID	Task ID	Operation
	mpls-te	read, write

This example shows how to set the path-selection cost-limit for under MPLS TE path-option attribute-set *PO3AttrSet*.

```
RP/0/RP0/CPU0:router#configure
RP/0/RP0/CPU0:router(config)#mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)#attribute-set path-option PO3AttrSet
RP/0/RP0/CPU0:router(config-te-attribute-set)#path-selection cost-limit 50000
```


path-selection ignore overload (MPLS-TE)

To ignore the Intermediate System-to-Intermediate System (IS-IS) overload bit setting for MPLS-TE, use the **path-selection ignore overload** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

path-selection ignore overload {head | mid | tail}
no path-selection ignore overload {head | mid | tail}

Syntax Description	This command has no arguments or keywords.	
Syntax Description	head	The tunnel stays up if set-overload-bit is set by ISIS on the head router. Ignores overload node during CSPF for the head node.
	mid	The tunnel stays up if set-overload-bit is set by ISIS on the mid router. Ignores overload node during CSPF for the mid node.
	tail	The tunnel stays up if set-overload-bit is set by ISIS on the tail router. Ignores overload node during CSPF for the tail node.
Command Default	None	
Command Modes	MPLS-TE configuration	
Command History	Release	Modification
	Release 6.0	This command was introduced.
Usage Guidelines	Use the path-selection ignore overload command to ensure that label switched paths (LSPs) are not broken because of routers that have IS-IS overload bit as enabled. When the IS-IS overload bit avoidance (OLA) feature is activated, all nodes with the overload bit set, which includes head nodes, mid nodes, and tail nodes, are ignored. This means that they are still available for use with label switched paths (LSPs). This feature allows you to include an overloaded node in constraint-based shortest path first (CSPF).	
Task ID	Task ID	Operations
	mpls-te	read, write

Examples

This example shows how to use the **path-selection ignore overload head** command:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# path-selection ignore overload
```

path-selection ignore overload (MPLS-TE)

```
RP/0/RP0/CPU0:router(config-mpls-te)# path-selection ignore overload head
```

path-selection loose-expansion affinity (MPLS-TE)

To specify the affinity value to be used to expand a path to the next loose hop for a tunnel on an area border router, use the **path-selection loose-expansion affinity** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

path-selection loose-expansion affinity *affinity-value* **mask** *affinity-mask* [**class-type** *type*]
no path-selection loose-expansion affinity *affinity-value* **mask** *affinity-mask* [**class-type** *type*]

Syntax Description	<i>affinity-value</i> Attribute values required for links carrying this tunnel. A 32-bit decimal number. Range is 0x0 to 0xFFFFFFFF, representing 32 attributes (bits), where the value of an attribute is 0 or 1. mask <i>affinity-mask</i> Checks the link attribute, a 32-bit decimal number. Range is 0x0 to 0xFFFFFFFF, representing 32 attributes (bits), where the value of an attribute mask is 0 or 1. class-type <i>type</i> (Optional) Requests the class-type of the tunnel bandwidth. Range is 0 to 1.	
Command Default	<i>affinity-value</i> : 0X00000000 <i>mask-value</i> : 0xFFFFFFFF	
Command Modes	MPLS-TE configuration	
Command History	Release	Modification
	Release 6.0	This command was introduced.
Usage Guidelines	The new affinity scheme (based on names) is not supported for loose-hop expansion. New configuration does not affect the already up tunnels.	
Task ID	Task ID	Operations
	mpls-te	read, write
Examples	The following example shows how to configure affinity 0x55 with mask 0xFFFFFFFF: <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# mpls traffic-eng RP/0/RP0/CPU0:router(config-mpls-te)# path-selection loose-expansion affinity 55 mask FFFFFFFF</pre>	

path-selection loose-expansion metric (MPLS-TE)

To configure a metric type to be used to expand a path to the next loose hop for a tunnel on an area border router, use the **path-selection loose-expansion metric** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

path-selection loose-expansion metric {igp | te} [**class-type** *type*]
no path-selection loose-expansion metric {igp | te} [**class-type** *type*]

Syntax Description	igp	Configures an Interior Gateway Protocol (IGP) metric.
	te	Configures a TE metric. This is the default.
	class-type <i>type</i>	(Optional) Requests the class type of the tunnel bandwidth. Range is 0 to 1.
Command Default	The default is TE metric.	
Command Modes	MPLS-TE configuration	
Command History	Release	Modification
	Release 6.0	This command was introduced.
Usage Guidelines	New configurations do not affect tunnels that are already up.	
Task ID	Task ID	Operations
	mpls-te	read, write
Examples	The following example shows how to set the path-selection metric to use the IGP metric overwriting default: <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# mpls traffic-eng RP/0/RP0/CPU0:router(config-mpls-te)# path-selection loose-expansion metric igp</pre>	

path-selection metric (MPLS-TE)

To specify the MPLS-TE tunnel path-selection metric, use the **path-selection metric** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

```
path-selection metric {igp | te}
no path-selection metric {igp | te}
```

Syntax Description

igp Configures an Interior Gateway Protocol (IGP) metric.

te Configures a TE metric.

Command Default

The default is TE metric.

Command Modes

MPLS-TE configuration

Command History

Release	Modification
Release 6.0	This command was introduced.

Usage Guidelines

The metric type to be used for path calculation for a given tunnel is determined as follows:

- If the **path-selection metric** command was entered to specify a metric type for the tunnel, use that metric type.
- Otherwise, use the default (TE) metric.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to set the path-selection metric to use the IGP metric overwriting default:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# path-selection metric igp
```

path-selection metric (interface)

To configure an MPLS-TE tunnel path-selection metric type, use the **path-selection metric** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

path-selection metric {igp | te}
no path-selection metric {igp | te}

Syntax Description

igp Configures Interior Gateway Protocol (IGP) metrics.

te Configures TE metrics. This is the default.

Command Default

The default is TE metrics.

Command Modes

Interface configuration

Command History

Release	Modification
Release 6.0	This command was introduced.

Usage Guidelines

The metric type to be used for path calculation for a given tunnel is determined as follows:

- If the **path-selection metric** command was entered to either a metric type for the tunnel or only a metric type, use that metric type.
- Otherwise, use the default (TE) metric.

Task ID

Task ID **Operations**

mpls-te read,
write

Examples

The following example shows how to set the path-selection metric to use the IGP metric overwriting default:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-te 1
RP/0/RP0/CPU0:router(config-if)# path-selection metric igp
```

policy-class

To configure policy-based tunnel selection (PBTS) to direct traffic into specific TE tunnels, use the **policy-class** command in interface configuration mode. To disable this feature, use the **no** form of this command.

Multiple EXP values can be specified as part of a policy-class, separated by spaces. The EXP values configured to a TE tunnel effectively form a monolithic policy-class, which should not overlap with other policy-classes. Once an EXP value is used in a policy-class configuration, it can only be reused if the subsequent policy-class configurations containing that EXP value are identical. For example, if the configuration **policy-class 1 2 3** is applied to one or more tunnels, configurations such as **policy-class 1**, **policy-class 2 3**, or **policy-class 3 4 5** become invalid.

policy-class {1 - 7 | **default**}
no policy-class

Syntax Description	1 - 7 Policy-class attribute to map the correct traffic class to this policy. Multiple EXP values can be specified, separated by spaces. default Default tunnel policy class.				
Command Default	The lowest class tunnels are assigned to carry default traffic only if no default tunnel is available for forwarding.				
Command Modes	Interface configuration				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 6.0</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 6.0	This command was introduced.
Release	Modification				
Release 6.0	This command was introduced.				
Usage Guidelines	Use the policy-class command to enable policy-based tunnel selection (PBTS). See <i>Cisco IOS XR MPLS Configuration Guide for the Cisco CRS-1 Router</i> and <i>Cisco IOS XR MPLS Configuration Guide for the Cisco XR 12000 Series Router</i> for more information on PBTS. To display the configured PBTS policy-class value, use the show mpls traffic-eng tunnels command. To display information about PBTS configuration, use the show cef and show cef hardware commands in <i>Cisco IOS XR IP Addresses and Services Command Reference for the Cisco XR 12000 Series Router</i> and <i>Cisco IOS XR IP Addresses and Services Command Reference for the Cisco CRS-1 Router</i>.				
Task ID	<table> <tr> <th>Task ID</th><th>Operations</th></tr> <tr> <td>mpls-te</td><td>read, write</td></tr> </table>	Task ID	Operations	mpls-te	read, write
Task ID	Operations				
mpls-te	read, write				

Examples

The following example shows how to configure a policy class:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-te 1
```

```
RP/0/RP0/CPU0:router(config-if)# policy-class 7
```

The following example shows how to configure a policy-class that maps to multiple traffic classes:

```
RP/0/RP0/CPU0:router# configure  
RP/0/RP0/CPU0:router(config)# interface tunnel-te 1  
RP/0/RP0/CPU0:router(config-if)# policy-class 1 2 3
```

The following example shows how to configure a default policy-class tunnel:

```
RP/0/RP0/CPU0:router# configure  
RP/0/RP0/CPU0:router(config)# interface tunnel-te 1  
RP/0/RP0/CPU0:router(config-if)# policy-class default  
RP/0/RP0/CPU0:router(config-if)# commit
```


priority (MPLS-TE)

To configure the setup and reservation priority for an MPLS-TE tunnel, use the **priority** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

priority *setup-priority hold-priority*
no priority *setup-priority hold-priority*

Syntax Description	<i>setup-priority</i> Priority used when signaling a label switched path (LSP) for this tunnel to determine which existing tunnels can be preempted. Range is 0 to 7 (in which a lower number indicates a higher priority). Therefore, an LSP with a setup priority of 0 can preempt any LSP with a non-0 priority. <i>hold-priority</i> Priority associated with an LSP for this tunnel to determine if it should be preempted by other LSPs that are being signaled. Range is 0 to 7 (in which a lower number indicates a higher priority).	
Command Default	<i>setup-priority</i>: 7 <i>hold-priority</i>: 7	
Command Modes	Interface configuration	
Command History	Release	Modification
	Release 6.0	This command was introduced.
Usage Guidelines	When an LSP is signaled and an interface does not currently have enough bandwidth available for that LSP, the call admission software (if necessary) preempts lower-priority LSPs to admit the new LSP. Accordingly, the new LSP priority is the setup priority and the existing LSP priority is the hold priority. The two priorities make it possible to signal an LSP with a low setup priority (so that the LSP does not preempt other LSPs on setup) and a high hold priority (so that the LSP is not preempted after it is established). Setup priority and hold priority are typically configured to be equal, and setup priority cannot be numerically smaller than the hold priority.	
Task ID	Task ID	Operations
	mpls-te	read, write

Examples

The following example shows how to configure a tunnel with a setup and hold priority of 1:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-te 1
RP/0/RP0/CPU0:router(config-if)# priority 1 1
```

record-route

To record the route used by a tunnel, use the **record-route** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

record-route
no record-route

Syntax Description	This command has no arguments or keywords.	
Command Default	No default behavior or values	
Command Modes	Interface configuration	
Command History	Release	Modification
	Release 6.0	This command was introduced.
Usage Guidelines	You must configure record-route on TE tunnels that are protected by multiple backup tunnels merging at a single node.	
Task ID	Task ID	Operations
	mpls-te	read, write
Examples	The following example shows how to enable record-route on the TE tunnel: <pre> RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# interface tunnel-te 1 RP/0/RP0/CPU0:router(config-if)# record-route </pre>	

redirect default-route nexthop

To configure multi nexthop tracking on default-route on a VRF for IPv4 or IPv6 address family, use the **redirect default-route nexthop** command in policy-map class type configuration mode.

redirect {**ipv4** | **ipv6**} **default-route nexthop**
[vrf vrf-name] [{v4v6}] nexthop [vrf vrf-name] [{v4v6}] nexthop [vrf vrf-name] [{v4v6}]

Syntax Description	ipv4 ipv6	Specifies IPv4 or IPv6 address family.
	vrf vrf-name	Specifies the VRF name for nexthop.
	v4	Specifies IPv4 nexthop address in A.B.C.D format.
	v6	Specifies IPv6 nexthop address in X:X::X%zone format.
Command Default	No default behavior or values	
Command Modes	Policy-map class type configuration	
Command History	Release	Modification
	Release 6.0	This command was introduced.
Usage Guidelines	No specific guidelines impact the use of this command.	
Task ID	Task ID	Operation
	qos	read, write

Example

The following example shows how to configure multi nexthop tracking on default-route on a VRF for IPv4:

```
RP/0/RSP0/CPU0:Router# config
RP/0/RSP0/CPU0:Router(config)# policy-map type pbr kmd
RP/0/RSP0/CPU0:Router(config-pmap)# class type traffic acl
RP/0/RSP0/CPU0:Router(config-pmap-c)# redirect ipv4 default-route nexthop vrf vpn1 3.2.1.2
nexthop vrf vpn2 3.2.3.2 nexthop vrf vpn3 3.2.4.2
```

redirect nexthop

To configure multi nexthop tracking on a VRF for IPv4 or IPv6 address family, use the **redirect nexthop** command in policy-map class type configuration mode.

redirect {**ipv4** | **ipv6**} **nexthop**
[vrf vrf-name] [{v4 v6}] nexthop [vrf vrf-name] [{v4 v6}] nexthop [vrf vrf-name] [{v4 v6}]

Syntax Description	ipv4 ipv6	Specifies IPv4 or IPv6 address family.
	vrf vrf-name	Specifies the VRF name for nexthop.
	v4	Specifies IPv4 nexthop address in A.B.C.D format.
	v6	Specifies IPv6 nexthop address in X:X::X%zone format.
Command Default	No default behavior or values	
Command Modes	Policy-map class type configuration	
Command History	Release	Modification
	Release 6.0	This command was introduced.
Usage Guidelines	A maximum number of three nexthops can be configured. The first nexthop configured has the highest priority as compared to the last nexthop, which has the least priority. The nexthops configured must be either IPv4 or IPv6. Either a VRF name or an IPv4/IPv6 address, or both can be configured for a given nexthop. When VRF is not configured, it is presumed to be ingress interface VRF.	
Task ID	Task ID	Operation
	qos	read, write

Example

The following example shows how to configure multi nexthop tracking on a VRF for IPv4:

```
RP/0/RSP0/CPU0:Router# config
RP/0/RSP0/CPU0:Router(config)# policy-map type pbr kmd
RP/0/RSP0/CPU0:Router(config-pmap)# class type traffic acl
RP/0/RSP0/CPU0:Router(config-pmap-c)# redirect ipv4 nexthop vrf vpn1 3.2.1.2 nexthop vrf
vpn2 3.2.3.2 nexthop vrf vpn3 3.2.4.2
```

reoptimize (MPLS-TE)

To force the reoptimization interval for all TE tunnels, use the **reoptimize** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

reoptimize *frequency*
no reoptimize *frequency*

Syntax Description	<i>frequency</i> Timer frequency range, in seconds. Range is from 0 to 604800. Note: • A value of 0 disables periodic reoptimization. • Any value in the range from 1 to 60 results in periodic reoptimization that occurs every 60 seconds.					
Command Default	<i>frequency</i> : 3600					
Command Modes	MPLS-TE configuration					
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>Release 6.0</td><td>This command was introduced.</td></tr></table>		Release	Modification	Release 6.0	This command was introduced.
Release	Modification					
Release 6.0	This command was introduced.					
Usage Guidelines	No specific guidelines impact the use of this command.					
Task ID	<table><tr><th>Task ID</th><th>Operations</th></tr><tr><td>mpls-te</td><td>read, write</td></tr></table>		Task ID	Operations	mpls-te	read, write
Task ID	Operations					
mpls-te	read, write					
Examples	The following example shows how to force the reoptimization interval to 60 seconds:					

reoptimize timers delay (MPLS-TE)

To delay removal or relabeling of the old label switched paths (LSPs) (reoptimized LSP from the forwarding plane) after tunnel reoptimization, use the **reoptimize timers delay** command in MPLS-TE configuration mode. To restore the default value, use the **no** form of this command.

```
reoptimize timers delay {after-frr seconds | cleanup delay-time | installation delay-time |
path-protection seconds}
no reoptimize timers delay {after-frr seconds | cleanup delay-time | installation delay-time |
path-protection seconds}
```

Syntax Description		
	after-frr	Delays the LSP reoptimization in the event of the FRR.
	<i>seconds</i>	Reoptimization initiation delay time of the tunnel, in seconds, after an FRR event. Range is from 0 to 120.
	cleanup	Delays removal of the old LSPs after tunnel reoptimization.
	<i>delay-time</i>	Reoptimization delay time, in seconds. A value of 0 disables delay. The valid range is from 0 to 300 for cleanup time.
	installation	Delays installation of a new label after tunnel reoptimization.
	<i>delay-time</i>	Reoptimization delay time, in seconds. A value of 0 disables delay. The valid range is 0 to 3600 for installation time.
	path-protection	Delays the time between path protection switchover event and tunnel reoptimization.
	<i>seconds</i>	Time, in seconds, between path protection switchover event and tunnel reoptimization. A value of 0 disables delay. Range is from 0 to 604800.

Command Default	
	after-frr <i>delay</i> : 0
	cleanup <i>delay</i> : 20
	<i>delay-time</i> : 20
	installation <i>delay</i> : 20

path-protection: 180

Command Modes

MPLS-TE configuration

Command History

Release	Modification
Release 6.0	This command was introduced.

Usage Guidelines

A device with Multiprotocol Label Switching traffic engineering (MPLS-TE) tunnels periodically examines tunnels with established LSPs to discover whether more efficient LSPs (paths) are available. If a better LSP is available, the device signals the more efficient LSP; if the signaling is successful, the device replaces the older LSP with the new, more efficient LSP.

Sometimes the slower router-point nodes may not yet utilize the new label's forwarding plane. In this case, if the headend node replaces the labels quickly, it can result in brief packet loss. By delaying the cleanup of the old LSP using the **reoptimize timers delay cleanup** command, packet loss is avoided.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to set the reoptimization cleanup delay time to 1 minute:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# reoptimize timers delay cleanup 60
```

The following example shows how to set the reoptimization installation delay time to 40 seconds:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# reoptimize timers delay installation 40
```

The following example shows how to set the reoptimization delay time after the event of the FRR to 50 seconds:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# reoptimize timers delay after-frr 50
```

The following example shows how to set the reoptimization delay time between path protection switchover event and tunnel reoptimization to 80:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# reoptimize timers delay path-protection 80
```

route-priority

To enable users to adjust the route-priority given to TE labels into the data plane, compared to labels and route updates from other protocols, use the **route-priority** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

route-priority *role* {**middle** | **head** {**primary** | **backup**}} **queue** *queue*
no route-priority *role* {**middle** | **head** {**primary** | **backup**}}

Syntax Description	role	Defines the role of the tunnel to which the label belongs.
	middle	A tunnel mid-point.
	head backup	A tunnel head which is assigned as a FRR backup to an interface.
	head primary	All other tunnel heads.
	<i>queue</i>	Defines the queue number. Range is from 0 to 12 inclusive; lower values represent higher priority queues.

Command Default

head backup: 9
head primary: 10
middle: 10

Command Modes MPLS-TE configuration

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines Use this command to change the priority given to TE labels when updates to the forwarding plane are made from the control plane.

The priority values used by other applications are:

- 0 - Unused
- 1 - Unused
- 2 - RIB/LDP (Critical)
- 3 - Unused
- 4 - Unused
- 5 - RIB/LDP (High)

- 6 - Unused
- 7 - Unused
- 8 - RIB/LDP (Medium)
- 9 - TE backup tunnel head
- 10 - Other TE tunnels
- 11 - Unused (future TE use)
- 12 - Unused (future TE use)


Caution

The default prioritization of label updates from the control plane to the forwarding plane has been carefully chosen to avoid traffic loss under both normal operation and high system load, and to balance the needs of the various features that employ label switching. Changing these defaults may cause unpredictable behavior including traffic loss, especially when the router is experiencing high load. Use of this command is not recommended without proper understanding of its effects and possible side-effects.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to enable route-priority:

```
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# route-priority role middle queue 7
```

router-id secondary (MPLS-TE)

To configure a secondary TE router identifier in MPLS-TE to be used locally (not advertised through IGP), use the **router-id secondary** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

router-id secondary *IP address*
no router-id secondary *IP address*

Syntax Description	<i>IP address</i> IPv4 address to be used as secondary TE router ID.	
Command Default	No default behavior or values	
Command Modes	MPLS-TE configuration	
Command History	Release	Modification
	Release 6.0	This command was introduced.
Usage Guidelines	Use the router-id secondary command on tail end nodes to terminate verbatim tunnels to secondary TE RIDs as destinations. You can configure up to 32 IPv4 addresses as TE secondary router IDs.	
Task ID	Task ID	Operations
	mpls-te	read, write
Examples	The following example shows how to configure a secondary TE router identifier in MPLS-TE: <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# mpls traffic-eng RP/0/RP0/CPU0:router(config-mpls-te)# router-id secondary 1.1.1.1 RP/0/RP0/CPU0:router(config-mpls-te)# router-id secondary 2.2.2.2</pre>	

set destination-address

To set destination address while redirecting Tag2IP MPLS labeled packets using PBR policy, use the **set destination-address** command in policy map class type configuration mode. To remove this configuration, use the **no** form of this command.

```
set destination-address {ipv4 | ipv6} ip-address
no set destination-address {ipv4 | ipv6} ip-address
```

Syntax Description	ipv4 ipv6 Specifies IPv4 or IPv6 address format.
	ip-address Specifies the IPv4 or IPv6 address.

Command Default Destination IP address is not set.

Command Modes Policy-map class type Configuration

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines Only Tag2IP packets redirection is supported.

Task ID	Task ID	Operation
	qos	read, write

This example shows how to set an IPv4 address as the redirect destination address:

```
RP/0/0/CPU0:ios#configure
RP/0/0/CPU0:ios(config)#policy-map type pbr pbr_prec_exp
RP/0/0/CPU0:ios(config-pmap)#class type traffic class_prec_exp
RP/0/0/CPU0:ios(config-pmap-c)#set destination-address ipv4 3.3.3.3
```

set ipv4 df

To set or clear the do not fragment (df) bit policy before forwarding the packet in IPv4 traffic, use the `set ipv4 df` command in Policy-map configuration mode. To disable setting or clearing the df bit, use the `no` form of this command.

set ipv4 df *df-value*

Syntax Description	<i>df-value</i> Specifies the df bit value. Range is from 1 to 7.
---------------------------	---

Command Default	Set df bit policy is disabled.
------------------------	--------------------------------

Command Modes	Policy-map configuration
----------------------	--------------------------

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines	No specific guidelines impact the use of this command.
-------------------------	--

Task ID	Task ID	Operation
	qos	read, write

This example shows how to set the IPv4 df bit policy value as 1:

```
RP/0/RP0/CPU0:router(config-pmap-c)#set ipv4 df 1
```

set source-address

To set source address while redirecting Tag2IP MPLS labeled packets using PBR policy, use the **set source-address** command in policy map class type configuration mode. To remove this configuration, use the **no** form of this command.

set source-address {**ipv4** | **ipv6**} *ip-address*

Syntax Description	ipv4 ipv6	Specifies IPv4 or IPv6 address format.
	<i>ip-address</i>	Specifies the IPv4 or IPv6 address.

Command Default No default behavior or values

Command Modes Policy-map class type Configuration

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	qos	read, write

Example

This example shows how to set an IPv4 address as the source address:

```
RP/0/0/CPU0:ios#configure
RP/0/0/CPU0:ios(config)#policy-map type pbr pbr_prec_exp
RP/0/0/CPU0:ios(config-pmap)#class type traffic class_prec_exp
RP/0/0/CPU0:ios(config-pmap-c)#set source-address ipv4 1.1.1.1
```

show explicit-paths

To display the configured IP explicit paths, use the **show explicit-paths** command in XR EXEC mode.

show explicit-paths [{**name** *path-name* | **identifier** *number*}]

Syntax Description	name <i>path-name</i> (Optional) Displays the name of the explicit path.
	identifier <i>number</i> (Optional) Displays the number of the explicit path. Range is 1 to 65535.

Command Default No default behavior or values

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines An IP explicit path is a list of IP addresses that represent a node or link in the explicit path.

Task ID	Task ID	Operations
	mpls-te read	

Examples The following shows a sample output from the **show explicit-paths** command:

```
RP/0/RP0/CPU0:router# show explicit-paths

Path ToR2      status enabled
  0x1: next-address 192.168.1.2
  0x2: next-address 10.20.20.20
Path ToR3      status enabled
  0x1: next-address 192.168.1.2
  0x2: next-address 192.168.2.2
  0x3: next-address 10.30.30.30
Path 100       status enabled
  0x1: next-address 192.168.1.2
  0x2: next-address 10.20.20.20
Path 200       status enabled
  0x1: next-address 192.168.1.2
  0x2: next-address 192.168.2.2
  0x3: next-address 10.30.30.30
```

This table describes the significant fields shown in the display.

Table 1: show explicit-paths Command Field Descriptions

Field	Description
Path	Pathname or number, followed by the path status.
1: next-address	First IP address in the path.
2: next-address	Second IP address in the path.

The following shows a sample output from the **show explicit-paths** command using a specific path name:

```
RP/0/RP0/CPU0:router# show explicit-paths name ToR3

Path ToR3      status enabled
    0x1:  next-address 192.168.1.2
    0x2:  next-address 192.168.2.2
    0x3:  next-address 10.30.30.30
```

The following shows a sample output from the **show explicit-paths** command using a specific path number:

```
RP/0/RP0/CPU0:router# show explicit-paths identifier 200

Path 200      status enabled
    0x1:  next-address 192.168.1.2
    0x2:  next-address 192.168.2.2
    0x3:  next-address 10.30.30.30
```

show interfaces tunnel-te accounting

To display IPv4 and IPv6 statistics for MPLS traffic engineering (TE) tunnels, use the **show interfaces tunnel-te accounting** command in XR EXEC mode.

show interfaces tunnel-te *tunnel-number* **accounting** [{**location** *location-id* | **rates**}]

Syntax Description	<i>tunnel-number</i>	Specifies TE tunnel number. Range is from 0 to 6553.
	location <i>location-id</i>	Specifies fully qualified location of the TE tunnel.
	rates	Displays interface accounting rates.
Command Default	None	
Command Modes	XR EXEC mode	
Command History	Release	Modification
	Release 6.0	This command was introduced.
Usage Guidelines	No specific guidelines impact the use of this command.	
Task ID	Task ID	Operation
	mpls-te	read

This example displays accounting information from tunnel-te interface 1:

```
RP/0/RP0/CPU0:router#show interface tunnel-te 1 accounting

tunnel-te1
  Protocol          Pkts In      Chars In      Pkts Out      Chars Out
  IPv4_UNICAST      0             0              5             520
  IPV6_UNICAST      0             0             15            1560
```


show mpls traffic-eng affinity-map

To display the color name-to-value mappings configured on the router, use the **show mpls traffic-eng affinity-map** command in XR EXEC mode.

show mpls traffic-eng affinity-map

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines If the affinity value of an affinity associated with an affinity constraint is unknown, the **show mpls traffic-eng affinity-map** command output displays: "(refers to undefined affinity name)"

Task ID	Task ID	Operations
	mpls-te	read

Examples

The following shows a sample output from the **show mpls traffic-eng affinity-map** command:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng affinity-map
```

Affinity Name	Bit-position	Affinity Value
-----	-----	-----
bcdefghabcdefghabcdefghabcdefgha	0	1
red1	1	2
red2	2	4
red3	3	8
red4	4	10
red5	5	20
red6	6	40
red7	7	80
red8	8	100
red9	9	200
red10	10	400
red11	11	800
red12	12	1000
red13	13	2000
red14	14	4000
red15	15	8000
red16	16	10000
cdefghabcdefghabcdefghabcdefghab	17	20000
red18	18	40000
red19	19	80000

show mpls traffic-eng affinity-map

red20	20	100000
red21	21	200000
red22	22	400000
red23	23	800000
red24	24	1000000
red25	25	2000000
red26	26	4000000
red27	27	8000000
orange28	28	10000000
red28	29	20000000
red30	30	40000000
abcdefghabcdefghabcdefgh	31	80000000

Table 2: show mpls traffic-eng affinity-map Field Descriptions, on page 130describes the significant fields shown in the display.

Table 2: show mpls traffic-eng affinity-map Field Descriptions

Field	Description
Affinity Name	Affinity name associated with the tunnel affinity constraints.
Bit-position	Bit position set in the 32-bit affinity value
Affinity Value	Affinity value associated with the affinity name.

show mpls traffic-eng attribute-set

To display the attribute set for MPLS-TE, use the **show mpls traffic-eng attribute-set** command in XR EXEC mode.

show mpls traffic-eng attribute-set [{**auto-backup** | **auto-mesh** | **path-option** | **xro**][*attribute-set-name*]]

Syntax Description		
auto-backup		Displays information for the auto-backup attribute type.
auto-mesh		Displays information for the auto-mesh attribute type.
path-option		Displays information for the path-option attribute type.
xro		Displays information for the XRO attribute type.
<i>attribute-set-name</i>		Specifies the name of the attribute set to be displayed.

Command Default Displays information about all types of attribute sets.

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines To use this command, first enable the MPLS-TE application.

Task ID	Task ID	Operation
	mpls-te	read

Example

The following command shows the attribute set for auto-backup attribute type.

```
RP/0/RP0/CPU0:router# show mpls traffic-eng attribute-set auto-backup auto1
```

```
Attribute Set Name: auto1 (Type: auto-backup)
  Affinity: 0x0/0xffff (Default)
  Priority: 7 7 (Default)
  Record-route: Enabled
  Policy-class: 0 (Not configured)
  Logging: None
  List of protected interfaces (count 0)
  List of tunnel IDs (count 0)
```

The following command shows the attribute set for auto-mesh attribute type.

```
RP/0/RP0/CPU0:router# show mpls traffic-eng attribute-set auto-mesh mesh1
```

```
Attribute Set Name: mesh1 (Type: auto-mesh)
  Bandwidth: 0 kbps (CT0) (Default)
  Affinity: 0x0/0xffff (Default)
  Priority: 7 7 (Default)
  Interface Bandwidth: 0 kbps (Default)
  AutoRoute Announce: Disabled
  Auto-bw: Disabled
  Soft Preemption: Disabled
  Fast Reroute: Disabled, Protection Desired: None
  Record-route: Disabled
  Policy-class: 0 (Not configured)
  Logging: None
  List of Mesh Groups (count 0)
```

The following command shows the attribute set for path-option attribute type.

```
RP/0/RP0/CPU0:router# show mpls traffic-eng attribute-set path-option path1
```

```
Attribute Set Name: path1 (Type: path option)
  Bandwidth: 0 kbps (CT0) (Default)
  Affinity: 0x0/0xffff (Default)
  List of tunnel IDs (count 0)
```

The following command shows the attribute set for xro.

```
RP/0/RP0/CPU0:router# show mpls traffic-eng attribute-set xro
```

```
Attribute Set Name: foo (Type: XRO)
  Number of XRO constraints : 2
    LSP, best-effort, LSP-id used
      Specified by FEC: tunnel-id 55, LSP-id 88, ext. id 10.10.10.10
                        source 10.10.10.10, destination 20.20.20.20
    LSP, strict, LSP-id ignored
      Specified by FEC: tunnel-id 3, LSP-id 0, ext. id 1.1.1.1
                        source 1.1.1.1, destination 2.2.2.2
```

show mpls traffic-eng autoroute

To display tunnels that are announced to the Interior Gateway Protocol (IGP), including information about next hop and destinations, use the **show mpls traffic-eng autoroute** command in XR EXEC mode.

show mpls traffic-eng autoroute [**name** *tunnel-name*][*IP-address*]

Syntax Description	<i>IP-address</i>	(Optional) Tunnel leading to this address.
	name <i>tunnel-name</i>	Specifies a tunnel by name.

Command Default None

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines The traffic-engineering tunnels are taken into account for the enhanced shortest path first (SPF) calculation of the IGP. The **show mpls traffic-eng autoroute** command displays those tunnels that IGP is currently using in its enhanced SPF calculation (that is, those tunnels that are up and have autoroute configured).

Tunnels are organized by destination. All tunnels to a destination carry a share of the traffic tunneled to that destination.

Task ID	Task ID	Operations
	mpls-te	read

Examples

The following shows a sample output from the **show mpls traffic-eng autoroute** command:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng autoroute

Destination 103.0.0.3 has 2 tunnels in OSPF 0 area 0
tunnel-te1 (traffic share 1, nexthop 103.0.0.3)
tunnel-te2 (traffic share 1, nexthop 103.0.0.3)
```

This table describes the significant fields shown in the display.

Table 3: show mpls traffic-eng autoroute Command Field Descriptions

Field	Description
Destination	Multiprotocol Label Switching (MPLS) TE tail-end router ID.

Field	Description
traffic share	A factor, based on bandwidth, indicating how much traffic this tunnel should carry, relative to other tunnels, to the same destination. If two tunnels go to a single destination, one with a traffic share of 200 and the other with a traffic share of 100, the first tunnel carries two-thirds of the traffic.
Nexthop	Next-hop router ID of the MPLS-TE tunnel.
absolute metric	Metric with mode absolute for the MPLS-TE tunnel.
relative metric	Metric with mode relative for the MPLS-TE tunnel.

This sample output displays *Signalled-Name* information:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng autoroute
Destination 192.168.0.4 has 1 tunnels in OSPF ring area 0
  tunnel-te1 (traffic share 0, nexthop 192.168.0.4)
    Signalled-Name: rtrA_t1
```

This sample output displays IS-IS autoroute information:

```
RP/0/RP0/CPU0:router#show mpls traffic-eng autoroute
Destination 192.168.0.1 has 1 tunnels in IS-IS ring level 1
  tunnel-te1 (traffic share 0, nexthop 192.168.0.1)
    (IS-IS ring level-1, IPV4 Unicast)
    (IS-IS ring level-1, IPV6 Unicast)
```

show mpls traffic-eng auto-tunnel backup

To display information about automatically build MPLS-TE backup tunnels, use the **show mpls traffic-eng auto-tunnel backup** command in XR EXEC mode.

```
show mpls traffic-eng auto-tunnel {backup [{private | summary | unused}]}
```

Syntax Description	backup	Displays information about auto-tunnel backup.
	private	(Optional) Displays private information about the automatically build MPLS-TE backup tunnels.
	summary	(Optional) Displays the automatically build MPLS-TE backup tunnels summary information.
	unused	(Optional) Displays only unused MPLS-TE backup tunnels.
Command Default	No default behavior or values	
Command Modes	XR EXEC mode	
Command History	Release	Modification
	Release 6.0	This command was introduced.
Usage Guidelines	No specific guidelines impact the use of this command.	
Task ID	Task ID	Operation
	mpls-te read	

Example

This is sample output from the **show mpls traffic-eng auto-tunnel backup** command:

```
AutoTunnel Backup Configuration:
  Interfaces count: 4
  Unused removal timeout: 1h 0m 0s
  Configured tunnel number range: 2000-2500

AutoTunnel Backup Summary:
  AutoTunnel Backups:
    1 created, 1 up, 0 down, 0 unused
    1 NHOP, 0 NNHOP, 0 SRLG strict, 0 SRLG preferred
  Protected LSPs:
    1 NHOP, 0 NHOP+SRLG
    0 NNHOP, 0 NNHOP+SRLG
  Protected S2L Sharing Families:
```

show mpls traffic-eng auto-tunnel backup

```

        0 NHOP, 0 NHOP+SRLG
        0 NNHOP, 0 NNHOP+SRLG
Protected S2Ls:
        0 NHOP, 0 NHOP+SRLG
        0 NNHOP, 0 NNHOP+SRLG

Cumulative Counters (last cleared 05:17:19 ago):
      Total  NHOP  NNHOP
Created:      1      1      0
Connected:    1      1      0
Removed (down): 0      0      0
Removed (unused): 0      0      0
Removed (in use): 0      0      0
Range exceeded: 0      0      0

AutoTunnel Backups:
      Tunnel  State  Protection  Prot.      Protected  Protected
      Name      Offered  Flows*      Interface  Node
-----
tunnel-te2000    up NHOP                      1      Gi0/2/0/2    N/A

*Prot. Flows = Total Protected LSPs, S2Ls and S2L Sharing Families

```

This is sample output from the **show mpls traffic-eng auto-tunnel mesh** command:

```
RP/0/RP0/CPU0:router#show mpls traffic-eng auto-tunnel mesh
```

```

Auto-tunnel Mesh Global Configuration:
  Unused removal timeout: 2h
  Configured tunnel number range: 10000-12000

Auto-tunnel Mesh Groups Summary:
  Mesh Groups count: 5
  Mesh Groups Destinations count: 50

Mesh Group 40 (2 Destinations, 1 Up, 1 Down):
  Destination-list: dl-40
  Attribute-set: ta_name
  Destination: 40.40.40.40, tunnel-id: 10000, State: Up
  Destination: 10.10.10.10, tunnel-id: 10001, State: Down
Mesh Group 41 (3 Destinations, 2 Up, 1 Down):
  Destination-list: dl-40
  Attribute-set: ta_name
  Destination: 4.4.4.4, tunnel-id: 10005, State: Up
  Destination: 3.3.3.3, tunnel-id: 10006, State: Up
  Destination: 1.1.1.1, tunnel-id: 10007, State: Down
Mesh Group 51 (0 Destinations, 0 Up, 0 Down):
  Destination-list: Not configured
  Attribute-set: Not configured
Mesh Group 52 (0 Destinations, 0 Up, 0 Down):
  Destination-list: NAME1 (Not defined)
  Attribute-set: NAME2 (Not defined)
Mesh Group 53 (2 Destinations, 1 Up, 1 Down):
  Destination-list: dl-53
  Attribute-set: Not configured
  Destination: 40.40.40.40, tunnel-id: 10000, State: Up
  Destination: 10.10.10.10, tunnel-id: 10001, State: Down

```

```

Cumulative Counters (last cleared 7h ago):
      Total
Created:      100
Connected:    50
Removed (unused): 50

```



```
Removed (in use):      0
Range exceeded:        0
```

This is sample output from the **show mpls traffic-eng auto-tunnel private** command:

```
Auto-tunnel Mesh Private Information:
ID allocator overall maximum ID: 4096
ID allocator last allocated ID: 50999
ID allocator number IDs allocated: 1000
```

show mpls traffic-eng auto-tunnel mesh

To display information about automatically built MPLS-TE mesh tunnels, use the **show mpls traffic-eng auto-tunnel mesh** command in XR EXEC mode.

show mpls traffic-eng auto-tunnel mesh {*mesh-value* | **unused** | **summary** | **attribute-set** *name* | **destination** *address* | **destination-list** *name* | **down** | **up** | **tunnel** {**created** | **not-created**} | **onehop**}

Syntax Description		
mesh <i>mesh-value</i>		Displays the tunnels that belong to the specified auto-tunnel mesh group. The range of mesh group ID is from 0 to 4294967295.
attribute-set <i>name</i>		Displays mesh-groups configured with a specific attribute set.
destination <i>address</i>		Displays only the destinations with a specified address.
destination-list <i>name</i>		Displays mesh-groups configured with a specified prefix-list.
down		Displays only those tunnels that are down.
up		Displays only those tunnels that are up.
summary		Displays auto-tunnel mesh summary information.
unused		Displays only the down tunnels with no destination in the topology.
tunnel created not-created		Specifies either created destinations with tunnels, or not-created destinations without tunnels.
onehop		Displays onehop enabled mesh groups.

Command Default	None
-----------------	------

Command Modes	XR EXEC mode
---------------	--------------

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines	No specific guidelines impact the use of this command.
------------------	--

Task ID	Task ID	Operation
	MPLS-TE	read

This is sample output from the **show mpls traffic-eng auto-tunnel mesh** command:

```
RP/0/RP0/CPU0:router show mpls traffic-eng auto-tunnel mesh
```

```
Auto-tunnel Mesh Global Configuration:
Unused removal timeout: 1h 0m 0s
```

```

Configured tunnel number range: 1000-1200

Auto-tunnel Mesh Groups Summary:
  Mesh Groups count: 1
  Mesh Groups Destinations count: 3
  Mesh Groups Tunnels count:
    3 created, 0 up, 3 down, 0 FRR enabled

Mesh Group: 65 (3 Destinations)
  Status: Enabled
  Attribute-set: am-65
  Destination-list: dl-65 (Not a prefix-list)
  Recreate timer: Not running

```

Destination	Tunnel ID	State	Unused timer
192.168.0.2	1000	up	Not running
192.168.0.3	1001	up	Not running
192.168.0.4	1002	up	Not running

```

  Displayed 3 tunnels, 0 up, 3 down, 0 FRR enabled

Auto-mesh Cumulative Counters:
  Last cleared: Wed Nov  9 12:56:37 2011 (02:39:07 ago)

```

	Total
Created:	3
Connected:	0
Removed (unused):	0
Removed (in use):	0
Range exceeded:	0

This shows how to configure the **auto-tunnel mesh** command with **destination-list** and **attribute-set** keywords:

```

RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# auto-tunnel mesh
RP/0/RP0/CPU0:router(config-te-auto-mesh)# group 65
RP/0/RP0/CPU0:router(config-te-mesh-group)# disable
RP/0/RP0/CPU0:router(config-te-mesh-group)# destination-list dl-65
RP/0/RP0/CPU0:router(config-te-mesh-group)# attribute-set am-65

```



Note This **attribute-set** is an optional configuration. Without this configuration, all tunnels use default tunnel attribute values. If you configure a non-existent attribute-set, this mesh group does not create any tunnel.



Note This **destination-list** configuration is mandatory. If there is no IPv4 prefix-list by this name on the router, this mesh group creates tunnels with all routers in the network.

This sample output displays information about one-hop tunnels:

```
RP/0/RP0/CPU0:router#show mpls traffic-eng auto-tunnel mesh onehop
```

Auto-tunnel Mesh Onehop Groups Summary:

```
Mesh Groups count: 1
Mesh Groups Destinations count: 2
Mesh Groups Tunnels count:
    2 created, 2 up, 0 down, 0 FRR enabled
```

Mesh Group: 25 (2 Destinations) Onehop

```
Status: Enabled
Attribute-set: Not configured
Destination-list: dest_list (Not a prefix-list)
Recreate timer: Not running
    Destination      Tunnel ID      State  Unused timer
    -----
    10.10.10.2        3500          up    Not running
    11.11.11.2        3501          up    Not running
Displayed 2 tunnels, 2 up, 0 down, 0 FRR enabled
```

Auto-mesh Onehop Cumulative Counters:

```
Last cleared: Thu Sep 12 13:39:38 2013 (03:47:21 ago)
Total
Created: 2
Connected: 2
Removed (unused): 0
Removed (in use): 0
Range exceeded: 0
```

show mpls traffic-eng collaborator-timers

To display the current status of the MPLS-TE collaborator timers, use the **show mpls traffic-eng collaborator-timers** command in XR EXEC mode.

show mpls traffic-eng collaborator-timers

Syntax Description	This command has no arguments or keywords.				
Command Default	No default behavior or values				
Command Modes	XR EXEC mode				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 6.0</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 6.0	This command was introduced.
Release	Modification				
Release 6.0	This command was introduced.				
Usage Guidelines	The MPLS-TE process maintains the timers for all of the collaborators such as RSVP, LSD, and so forth. The show mpls traffic-eng collaborator-timers command shows the status of these timers.				
Task ID	<table> <tr> <th>Task ID</th><th>Operations</th></tr> <tr> <td>mpls-te</td><td>read</td></tr> </table>	Task ID	Operations	mpls-te	read
Task ID	Operations				
mpls-te	read				
Examples	The following sample output shows the current status of the collaborator timers:				

```
RP/0/RP0/CPU0:router# show mpls traffic-eng collaborator-timers
```

```
Collaborator Timers
-----
Timer Name: [LMRIB Restart] Index:[0]
  Duration: [60] Is running: NO
  Last start time: 02/09/2009 11:57:59
  Last stop time: 02/09/2009 11:58:00
  Last expiry time: Never expired
Timer Name: [LMRIB Recovery] Index:[1]
  Duration: [60] Is running: YES
  Last start time: 02/09/2009 11:58:00
  Last stop time: Never Stopped
  Last expiry time: 19/08/2009 17:45:24
Timer Name: [RSVP Restart] Index:[2]
  Duration: [180] Is running: NO
  Last start time: 26/08/2009 18:59:18
  Last stop time: 26/08/2009 18:59:20
  Last expiry time: Never expired
Timer Name: [RSVP Recovery] Index:[3]
  Duration: [1800] Is running: NO
  Last start time: 26/08/2009 18:59:20
  Last stop time: 26/08/2009 19:03:19
  Last expiry time: 19/08/2009 18:12:39
```

show mpls traffic-eng collaborator-timers

```

Timer Name: [LSD Restart] Index:[4]
  Duration: [60] Is running: NO
  Last start time: 19/08/2009 17:44:26
  Last stop time: 19/08/2009 17:44:26
  Last expiry time: Never expired
Timer Name: [LSD Recovery] Index:[5]
  Duration: [600] Is running: NO
  Last start time: 19/08/2009 17:44:26
  Last stop time: Never Stopped
  Last expiry time: 19/08/2009 17:53:44
Timer Name: [Clearing in progress BW for the whole topology] Index:[6]
  Duration: [60] Is running: YES
  Last start time: 02/09/2009 11:57:50
  Last stop time: Never Stopped
  Last expiry time: 02/09/2009 11:57:50

```

This table describes the significant fields shown in the display.

Table 4: show mpls traffic-eng collaborator-timers Command Field Descriptions

Field	Description
Timer Name	Timer name that is associated to a collaborator.
Index	Identification number of the timer.
Duration	Expiry delay of the timer, in seconds. For example, the duration indicates the timer interval.
Is running	Timer is running low or not.
Last start time	Last time that the collaborator process for MPLS LSD was restarted.
Last stop time	Time TE was able to reconnect to the MPLS LSD process.
Last expiry time	Time that timer expired.

show mpls traffic-eng counters signaling

To display tunnel signaling statistics, use the **show mpls traffic-eng counters signaling** command in XR EXEC mode.

show mpls traffic-eng counters {**signaling** | **soft-preemption**} {*tunnel -number* | **all** | [{**heads** | **mids** | **tails**}] | **name** *tunnel-name* | **summary**}

Syntax Description	signaling	Displays signaling counters.
	soft-preemption	Displays the statistics for the soft-preemption.
	<i>tunnel-number</i>	Statistics for the input tunnel number. The range is from 0 to 65535.
	all	Displays statistics for all tunnels.
	heads	(Optional) Displays statistics for all tunnel heads.
	mids	(Optional) Displays statistics for all tunnel midpoints.
	tails	(Optional) Displays statistics for all tunnel tails.
	name	Displays statistics for a specified tunnel.
	<i>tunnel-name</i>	Name of the specified tunnel.
	summary	Displays a summary of signaling statistics.
Command Default	None	
Command Modes	XR EXEC mode	
Command History	Release	Modification
	Release 6.0	This command was introduced.
Usage Guidelines	No specific guidelines impact the use of this command.	

show mpls traffic-eng counters signaling

Task ID

Task ID Operations

mpls-te read

Examples

This is a sample output from the **show mpls traffic-eng counters signaling** command, using the **all** keyword, which displays tunnel signaling statistics for all tunnels:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng counters signaling all
```

Tunnel Head: tunnel-te100

Cumulative Tunnel Counters:

Signalling Events	Recv	Xmit		Recv	Xmit
PathCreate	1	1	ResvCreate	1	0
PathChange	0	0	ResvChange	0	0
PathError	0	0	ResvError	0	0
PathTear	0	18	ResvTear	0	0
BackupAssign	0	1	BackupError	0	0
PathQuery	0	0	Unknown	0	0

Destination 100.0.0.4

Cumulative counters

Signalling Events	Recv	Xmit		Recv	Xmit
PathCreate	1	1	ResvCreate	1	0
PathChange	0	0	ResvChange	0	0
PathError	0	0	ResvError	0	0
PathTear	0	18	ResvTear	0	0
BackupAssign	0	1	BackupError	0	0
PathQuery	0	0	Unknown	0	0

S2L LSP ID: 2 Sub-Grp ID: 0 Destination: 100.0.0.4

Signalling Events	Recv	Xmit		Recv	Xmit
PathCreate	1	1	ResvCreate	1	0
PathChange	0	0	ResvChange	0	0
PathError	0	0	ResvError	0	0
PathTear	0	0	ResvTear	0	0
BackupAssign	0	1	BackupError	0	0
PathQuery	0	0	Unknown	0	0

Signaling Counter Summary:

Signalling Events	Recv	Xmit		Recv	Xmit
PathCreate	11	7	ResvCreate	11	4
PathChange	0	0	ResvChange	0	0
PathError	0	0	ResvError	0	0
PathTear	0	38	ResvTear	0	0
BackupAssign	0	3	BackupError	0	0
PathQuery	0	0	Unknown	0	0

This is a sample output from the **show mpls traffic-eng counters signaling** command using the **tunnel number** argument, which displays statistics for the input tunnel number:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng counters signaling 200
```

Tunnel Head: tunnel-te200

Cumulative Tunnel Counters:

Signalling Events	Recv	Xmit		Recv	Xmit
PathCreate	4	4	ResvCreate	4	0
PathChange	0	0	ResvChange	0	0
PathError	0	0	ResvError	0	0


```

PathTear          0      1      ResvTear          0      0
BackupAssign      0      4      BackupError      0      0
PathQuery         0      0      Unknown         0      0

Destination 3.3.3.3
Cumulative counters
  Signalling Events Recv      Xmit
    PathCreate       4        4      ResvCreate       4        0
    PathChange       0        0      ResvChange      0        0
    PathError        0        0      ResvError       0        0
    PathTear         0        1      ResvTear        0        0
    BackupAssign     0        4      BackupError     0        0
    PathQuery        0        0      Unknown         0        0
S2L LSP ID: 3 Sub-Grp ID: 0 Destination: 3.3.3.3
  Signalling Events Recv      Xmit
    PathCreate       3        3      ResvCreate       3        0
    PathChange       0        0      ResvChange      0        0
    PathError        0        0      ResvError       0        0
    PathTear         0        0      ResvTear        0        0
    BackupAssign     0        3      BackupError     0        0
    PathQuery        0        0      Unknown         0        0

```

This table describes the significant fields shown in the display.

Table 5: show mpls traffic-eng counters signaling Command Field Descriptions

Field	Description
Tunnel Head	Tunnel head identifier.
Match Resv Create	Number of RSVP Reservation create messages received.
Sender Create	Number of Sender Create messages sent by TE to RSVP.
Path Error	Number of RSVP Path Error messages received.
Match Resv Change	Number of RSVP Reservation change messages received.
Sender Modify	Number of Sender Modify messages sent by TE to RSVP.
Path Change	Number of RSVP Path Change messages received.
Match Resv Delete	Number of RSVP Reservation delete messages received.
Sender Delete	Number of Sender Delete messages sent by TE to RSVP.
Path Delete	Number of RSVP Path Delete messages received.
Total	Total signaling messages received from RSVP.
Unknown	Unknown messages include fast reroute events and internal messages related to process restart.

This is sample output from the **show mpls traffic-eng counters soft-preemption** command, which displays statistics for the soft preempted LSPs:

```
RP/0/RP0/CPU0:router#show mpls traffic-eng counters soft-preemption
```

show mpls traffic-eng counters signaling

```

Soft Preemption Global Counters:
  Last Cleared: Never
  Preemption Node Stats:
    Number of soft preemption events: 1
    Number of soft preempted LSPs: 1
    Number of soft preempted LSPs that timed out: 0
    Number of soft preempted LSPs that were torn down: 0
    Number of soft preempted LSPs that were fast rerouted: 0
    Minimum Time in Soft Preemption Pending State (sec): 0
    Maximum Time in Soft Preemption Pending State (sec): 0
    Average Time in Soft Preemption Pending State (sec): 0
  Headend Stats:
    Number of soft preempted LSPs: 1
    Number of reoptimized soft preempted headend-LSPs: 0
    Number of path protected switchover soft preempted headend-LSPs: 0
    Number of torn down soft preempted headend-LSPs: 0

```

This is sample output from the **show mpls traffic-eng counters signaling all** command that displays the *Signalled-Name* information:

```

RP/0/RP0/CPU0:router#show mpls traffic-eng counters signaling all
Tunnel Head: tunnel-tel
Signalled-Name: rtrA_t1
Cumulative Tunnel Counters:
  Signalling Events      Recv      Xmit  Signalling Events      Recv      Xmit
    PathCreate           2         2      ResvCreate           2         0

```

show mpls traffic-eng ds-te te-class

To display the Diff-Serv TE-class map in use, use the **show mpls traffic-eng ds-te te-class** command in XR EXEC mode.

show show mpls traffic-eng ds-te te-class

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines TE-class is used only in IETF DS-TE mode.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples The following shows a sample output from the **show mpls traffic-eng ds-te te-class** command:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng ds-te te-class

te-class 0: class-type 0 priority 7 status default
te-class 1: class-type 1 priority 7 status default
te-class 2: unused
te-class 3: unused
te-class 4: class-type 0 priority 0 status default
te-class 5: class-type 1 priority 0 status default
te-class 6: unused
te-class 7: unused
```

This table describes the significant fields shown in the display.

Table 6: show mpls traffic-eng ds-te te-class Command Field Descriptions

Field	Description
te-class	TE-class map, pair of class-type, and priority.
class-type	class-type of the tunnel.
status	Source of the TE-class map, either default or user configured.

show mpls traffic-eng forwarding

To display forwarding information on tunnels that were admitted locally, use the **show mpls traffic-eng forwarding** command in XR EXEC mode.

show mpls traffic-eng forwarding [**backup-name** *tunnel-name*] [**source** *source-address*][**tunnel-id** *tunnel-id*] [**interface** {**in** | **inout** | **out**} *type* *interface-path-id*][{ **p2p**}] {**p2p**} [**detail**]

Syntax Description	backup-name <i>tunnel-name</i>	(Optional) Restricts tunnels with this backup tunnel name.
	source <i>source-address</i>	(Optional) Restricts tunnels for this specified tunnel source IPv4 address.
	tunnel-id <i>tunnel-id</i>	(Optional) Restricts tunnels for this tunnel identifier. Range for the <i>tunnel-id</i> argument is from 0 to 65535.
	interface	(Optional) Displays information on the specified interface.
	<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
	<i>interface-path-id</i>	Physical interface or a virtual interface.
		Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
	in	Displays information for the input interface.
	inout	Displays information for either the input or output interface.
	out	Displays information for the output interface.
	p2p	(Optional) Displays only Point-to-Point (P2P) information.
	detail	(Optional) Displays detailed forwarding information.
Command Default	No default behavior or values	
Command Modes	XR EXEC mode	

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	mpls-te	read

Examples

The following shows a sample output from the **show mpls traffic-eng forwarding** command:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng forwarding
```

```
Tue Sep 15 14:22:39.609 UTC P2P tunnels
```

Tunnel ID Backup tunnel	Ingress IF	Egress IF	In lbl	Out lbl
-----	-----	-----	-----	-----
2.2.2.2 2_2 unknown	HundredGigE0/0/0/3	HundredGigE0/0/0/4	16004	16020
6.6.6.6 1_23 tt1300	-	HundredGigE0/0/0/3	16000	3
6.6.6.6 1100_9 unknown	-	HundredGigE0/0/0/3	16002	16001
6.6.6.6 1200_9 unknown	-	HundredGigE0/0/0/3	16001	16000
6.6.6.6 1300_2 unknown	-	HundredGigE0/0/0/4	16005	16021
6.6.6.6 1400_9 unknown	-	HundredGigE0/0/0/3	16003	16002

This table describes the significant fields shown in the display.

Table 7: show mpls traffic-eng forwarding Field Descriptions

Field	Description
TUNNEL ID	Tunnel identification.
Ingress IF	Ingress interface of the tunnel.
Egress IF	Egress interface of the tunnel.
In lbl	Incoming label associated with the tunnel.
Out lbl	Outgoing label associated with the tunnel.
Backup tunnel	Fast Reroute backup tunnel

show mpls traffic-eng forwarding-adjacency

To display forwarding-adjacency information for an IPv4 address, use the **show mpls traffic-eng forwarding-adjacency** command in XR EXEC mode.

show mpls traffic-eng forwarding-adjacency [*IP-address*]

Syntax Description	<i>IP-address</i> (Optional) Destination IPv4 address for forwarding adjacency.
---------------------------	---

Command Default	No default behavior or values
------------------------	-------------------------------

Command Modes	XR EXEC mode
----------------------	--------------

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines	No specific guidelines impact the use of this command.
-------------------------	--

Task ID	Task ID	Operations
	mpls-te	read

Examples

This is a sample output from the **show mpls traffic-eng forwarding-adjacency** command:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng forwarding-adjacency

destination 3.3.3.3 has 1 tunnels
tunnel-te1      (traffic share 0, next-hop 3.3.3.3)
(Adjacency Announced: yes, holdtime 0)
```

This sample output displays information on IPv6 autoroute forwarding adjacency information for IS-IS IGP:

```
RP/0/RP0/CPU0:router#show mpls traffic-eng forwarding-adjacency

destination 3.3.3.3 has 1 tunnels

tunnel-te10     (traffic share 0, next-hop 3.3.3.3)
(Adjacency Announced: yes, holdtime 0)
(IS-IS 100, IPv4 unicast)
(IS-IS 100, IPv6 unicast)
```

show mpls traffic-eng igp-areas

To display MPLS-TE internal area storage, use the **show mpls traffic-eng igp-areas** command in XR EXEC mode.

show mpls traffic-eng igp-areas [**detail**]

Syntax Description	detail (Optional) Displays detailed information about the configured MPLS-TE igp-areas and communication statistics with IGP.				
Command Default	No default behavior or values				
Command Modes	XR EXEC mode				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 6.0</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 6.0	This command was introduced.
Release	Modification				
Release 6.0	This command was introduced.				
Usage Guidelines	No specific guidelines impact the use of this command.				
Task ID	<table> <tr> <th>Task ID</th><th>Operations</th></tr> <tr> <td>mpls-te</td><td>read</td></tr> </table>	Task ID	Operations	mpls-te	read
Task ID	Operations				
mpls-te	read				

Examples

The following shows a sample output from the **show mpls traffic-eng igp-areas** command:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng igp-areas

MPLS-TE IGP Areas

Global router-id:          10.144.144.144
Global optical router-id:  Not available

IS-IS 100

  IGP ID:                    0000.0000.0044
  TE router ID configured:   10.144.144.144
                           in use:    10.144.144.144
  Link connection:          up
  Topology/tunnel connection: up

  level 2
    TE index: 1
    IGP config for TE: complete
    Local links flooded in this IGP level: 1
    Flooding beacon sent and received
    P2P tunnel heads running over this IGP level: 1
      1 AA, 0 FA
```

show mpls traffic-eng igp-areas

```

Tunnel loose-hops expanded over this IGP level: 0

OSPF 100

IGP ID: 10.144.144.144
TE router ID configured: 10.144.144.144
           in use: 10.144.144.144
Link connection: up
Topology/tunnel connection: up

area 0
  TE index: 0
  IGP config for TE: complete
  Local links flooded in this IGP area: 2
  Flooding beacon sent and received
  P2P tunnel heads running over this IGP area: 3
    1 AA, 0 FA
  Tunnel loose-hops expanded over this IGP area: 0

```

The following shows a sample output from the **show mpls traffic-eng igp-areas** command:

```

RP/0/RP0/CPU0:router# show mpls traffic-eng igp-areas

MPLS-TE IGP Areas
Global router-id: 0.0.0.0
Global optical router-id: Not available
OSPF 0
  IGP ID: 101.0.0.1
  TE router ID configured: 101.0.0.1
           in use: 101.0.0.1
  Link connection: up
  Topology/tunnel connection: up
  area 4
    TE index: 0
    IGP config for TE: complete
    Number of links in this IGP area: 1
    Number of tunnel heads running over this IGP area: 0
    Number of tunnel loose-hops expanded over this IGP area: 0
  area 3
    TE index: 1
    IGP config for TE: complete
    Number of links in this IGP area: 1
    Number of tunnel heads running over this IGP area: 0
    Number of tunnel loose-hops expanded over this IGP area: 0
  area 2
    TE index: 2
    IGP config for TE: complete
    Number of links in this IGP area: 1
    Number of tunnel heads running over this IGP area: 0
    Number of tunnel loose-hops expanded over this IGP area: 0
  area 1
    TE index: 3
    IGP config for TE: complete
    Number of links in this IGP area: 1
    Number of tunnel heads running over this IGP area: 0
    Number of tunnel loose-hops expanded over this IGP area: 0
  area 0
    TE index: 4
    IGP config for TE: complete
    Number of links in this IGP area: 2
    Number of tunnel heads running over this IGP area: 1
    Number of tunnel loose-hops expanded over this IGP area: 0

```


This table describes the significant fields shown in the display.

Table 8: show mpls traffic-eng igp-areas Command Field Descriptions

Field	Description
Global router-id	Global router ID on this node.
IGP ID	IGP System ID.
area	IGP area.
TE index	Internal index in the IGP area table.
IGP config for TE	Whether the IGP configuration is complete or missing.

show mpls traffic-eng link-management admission-control

To display which tunnels were admitted locally and their parameters, use the **show mpls traffic-eng link-management admission-control** command in XR EXEC mode.

show mpls traffic-eng link-management admission-control [**interface** *type* *interface-path-id*]

Syntax Description	interface	(Optional) Displays information on the specified interface.
	<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
	<i>interface-path-id</i>	Physical interface or virtual interface.
	Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.	

Command Default No default behavior or values

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	mpls-te	read

Examples The following shows a sample output from the **show mpls traffic-eng link-management admission-control** command:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng link-management admission-control

S System Information:
  Tunnels Count      : 2
  Tunnels Selected   : 2
Bandwidth descriptor legend:
  B0 = bw from pool 0, B1 = bw from pool 1, R = bw locked, H = bw held

TUNNEL ID              UP IF      DOWN IF      PRI STATE      BW (kbits/sec)
-----
-----
```

```

10.10.10.10 1_34      -      HundredGigE0/0/0/3  7/7 Resv Admitted 100      RB0
10.10.10.10 15_2     -      HundredGigE0/0/0/3  7/7 Resv Admitted 0
B0

```

This table describes the significant fields shown in the display.

Table 9: show mpls traffic-eng link-management admission-control Command Field Descriptions

Field	Description
Tunnels Count	Total number of tunnels admitted.
Tunnels Selected	Number of tunnels displayed.
Bandwidth descriptor legend	BW pool type and status displayed with the tunnel entry. Shown as RG (Locked BW in global pool) in the preceding sample output.
TUNNEL ID	Tunnel identification.
UP IF	Upstream interface used by the tunnel.
DOWN IF	Downstream interface used by the tunnel.
PRI	Tunnel setup priority and hold priority.
STATE	Tunnel admission status.
BW (kbps)	Tunnel bandwidth in kilobits per second. If an R follows the bandwidth number, the bandwidth is reserved. If an H follows the bandwidth number, the bandwidth is temporarily being held for a Path message. If a G follows the bandwidth number, the bandwidth is from the global pool. If an S follows the bandwidth number the bandwidth is from the sub-pool.

The following shows a sample output from the **show mpls traffic-eng link-management interface** command:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng link-management interface HundredGigE 0/0/0/3
```

```

System Information::
  Links Count          : 1

Link ID:: HundredGigE 0/0/0/3 (35.0.0.5)
  Local Intf ID: 7
  Link Status:

  Link Label Type      : PSC (inactive)
  Physical BW          : 155520 kbits/sec
  BCID                  : RDM
  Max Reservable BW    : 0 kbits/sec (reserved: 100% in, 100% out)
  BC0 (Res. Global BW): 0 kbits/sec (reserved: 100% in, 100% out)
  BC1 (Res. Sub BW)    : 0 kbits/sec (reserved: 100% in, 100% out)
  MPLS-TE Link State   : MPLS-TE on, RSVP on
  Inbound Admission    : allow-all
  Outbound Admission   : allow-if-room
  IGP Neighbor Count   : 0
  Max Res BW (RDM)     : 0 kbits/sec

```

show mpls traffic-eng link-management admission-control

```

BC0 (RDM)           : 0 kbits/sec
BC1 (RDM)           : 0 kbits/sec
Max Res BW (MAM)    : 0 kbits/sec
BC0 (MAM)           : 0 kbits/sec
BC1 (MAM)           : 0 kbits/sec
Admin Weight        : 1 (OSPF), 10 (ISIS)
Attributes           : 0x5 (name-based)
Flooding Status: (1 area)
  IGP Area[1]: ospf 100 area 0, not flooded
                (Reason: Interface has been administratively disabled)

```

This table describes the significant fields shown in the display.

Table 10: show mpls traffic-eng link-management interface Command Field Descriptions

Field	Description
Links Count	Number of links configured for MPLS-TE.
Link ID	Index of the link described.
Local Intf ID	Local interface ID.
Link Label Type	Label type of the link, for instance: PSC ¹ , TDM ² , FSC ³ .
Physical BW	Link bandwidth capacity (in kilobits per second).
BCID	Bandwidth constraint model ID (RDM or MAM).
Max Reservable BW	Maximum reservable bandwidth on this link.
BC0 (Res. Global BW)	Bandwidth constraint value for class-type 0.
BC1 (Res. Sub BW)	Bandwidth constraint value for class-type 1.
MPLS-TE Link State	Status of the link MPLS-TE-related functions.
Inbound Admission	Link admission policy for incoming tunnels.
Outbound Admission	Link admission policy for outgoing tunnels.
IGP Neighbor Count	IGP neighbors directly reachable over this link.
Max Res BW (RDM)	Maximum reservable bandwidth on this link for RDM.
BC0 (RDM)	Bandwidth constraint value for RDM.
BC1 (RDM)	Bandwidth constraint value for RDM.
Admin Weight	Administrative weight associated with this link.
Attributes	Interface attributes referring to one or more affinity names.
IGP Area[1]	IGP type and area and level used for TE flooding.

¹ PSC = Packet switch capable.

² TDM = Time-division multiplexing.

³ FSC = Fiber switch capable.

show mpls traffic-eng link-management advertisements

To display local link information that MPLS-TE link management is currently flooding into the global TE topology, use the **show mpls traffic-eng link-management advertisements** command in XR EXEC mode.

show mpls traffic-eng link-management advertisements

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines The **show mpls traffic-eng link-management advertisements** command has two output formats depending on the Diff-Serv TE Mode: one for prestandard mode and one for IETF mode.

The SRLG values are advertised for the link.

Task ID	Task ID	Operations
	mpls-te	read

Examples The following shows a sample output from the **show mpls traffic-eng link-management advertisements** command:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng link-management advertisements

Link ID:: 0 (GigabitEthernet0/2/0/1)
  Link IP Address      : 12.9.0.1
  O/G Intf ID         : 28
  Designated Router    : 12.9.0.2
  TE Metric            : 1
  IGP Metric           : 1
  Physical BW          : 1000000 kbits/sec
  BCID                 : RDM
  Max Reservable BW    : 10000 kbits/sec
  Res Global BW        : 10000 kbits/sec
  Res Sub BW           : 0 kbits/sec
  SRLGs                : 10, 20

Downstream::
                                Global Pool  Sub Pool
                                -----
  Reservable BW[0]:          10000          0 kbits/sec
  Reservable BW[1]:          10000          0 kbits/sec
  Reservable BW[2]:           9800          0 kbits/sec
```

```

Reservable BW[3]:          9800          0 kbits/sec
Reservable BW[4]:          9800          0 kbits/sec
Reservable BW[5]:          9800          0 kbits/sec
Reservable BW[6]:          9800          0 kbits/sec
Reservable BW[7]:          9800          0 kbits/sec

Attribute Flags: 0x00000004
Attribute Names: red2

Link ID:: 1 (GigabitEthernet0/2/0/2)
Link IP Address      : 14.9.0.1
O/G Intf ID         : 29
Designated Router   : 14.9.0.4
TE Metric           : 1
IGP Metric          : 1
Physical BW         : 1000000 kbits/sec
BCID                : RDM
Max Reservable BW   : 750000 kbits/sec
Res Global BW       : 750000 kbits/sec
Res Sub BW          : 0 kbits/sec

Downstream::

Global Pool      Sub Pool
-----
Reservable BW[0]: 750000          0 kbits/sec
Reservable BW[1]: 750000          0 kbits/sec
Reservable BW[2]: 750000          0 kbits/sec
Reservable BW[3]: 750000          0 kbits/sec
Reservable BW[4]: 750000          0 kbits/sec
Reservable BW[5]: 750000          0 kbits/sec
Reservable BW[6]: 750000          0 kbits/sec
Reservable BW[7]: 750000          0 kbits/sec

Attribute Flags: 0x00000000
Attribute Names:

```

This table describes the significant fields shown in the display.

Table 11: show mpls traffic-eng link-management advertisements Command Field Descriptions

Field	Description
Link ID	Index of the link described.
Link IP Address	Local IP address of the link.
TE Metric	Metric value for the TE link configured under MPLS-TE.
IGP Metric	Metric value for the TE link configured under IGP.
Physical BW	Link bandwidth capacity (in kilobits per second).
BCID	Bandwidth constraint model ID (RDM or MAM).
Max Reservable BW	Maximum reservable bandwidth on this link.
Res Global BW	Maximum reservable of global pool/BC0 bandwidth on this link.
Res Sub BW	Reservable sub-bandwidth for sub-pool /BC1 bandwidth on this link.

Field	Description
SRLGs ⁴	Links that share a common fiber or a common physical attribute. If one link fails, other links in the group may also fail. Links in the group have a shared risk.
Downstream	Direction of the LSP path message.
Reservable BW[x]	Bandwidth available for reservations in the global TE topology and subpools.
Attribute Flags	Link attribute flags being flooded.
Attribute Names	Name of the affinity attribute of a link.
BC0	Bandwidth constraint value for class-type 0
BC1	Bandwidth constraint value for class-type 1
TE-class [index]	TE-class configured on this router at given index (mapping of class-type and priority), shows available bandwidth in that class.

⁴ SRLGs = Shared Risk Link Groups.

show mpls traffic-eng link-management bandwidth-allocation

To display current local link information, use the **show mpls traffic-eng link-management bandwidth-allocation** command in XR EXEC mode.

show mpls traffic-eng link-management bandwidth-allocation [*interface type interface-path-id*]

Syntax Description	interface	(Optional) Displays information on the specified interface.
	<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
	<i>interface-path-id</i>	Physical interface or a virtual interface.
	Note	Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.

Command Default No default behavior or values

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines Advertised and current information may differ depending on how flooding is configured.

Task ID	Task ID	Operations
	mpls-te read	

Examples The following shows a sample output from the **show mpls traffic-eng link-management bandwidth-allocation** command:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng link bandwidth-allocation interface HundredGigE0/0/0/3
```

```
System Information::
  Links Count          : 4
  Bandwidth Hold time  : 15 seconds

Link ID: HundredGigE0/0/0/3 (7.2.2.1)
Local Intf ID: 4
Link Status:
  Link Label Type      : PSC
```

show mpls traffic-eng link-management bandwidth-allocation

```

Physical BW      : 155520 kbits/sec
BCID             : MAM
Max Reservable BW : 1000 kbits/sec (reserved: 0% in, 0% out)
BC0             : 600 kbits/sec (reserved: 2% in, 2% out)
BC1             : 400 kbits/sec (reserved: 0% in, 0% out)
MPLS-TE Link State : MPLS-TE on, RSVP on, admin-up, flooded
Inbound Admission : allow-all
Outbound Admission : allow-if-room
IGP Neighbor Count : 2
BW Descriptors   : 1 (including 0 BC1 descriptors)
Admin Weight     : 1 (OSPF), 10 (ISIS)
Up Thresholds    : 15 30 45 60 75 80 85 90 95 96 97 98 99 100 (default)
Down Thresholds  : 100 99 98 97 96 95 90 85 80 75 60 45 30 15 (default)

```

Bandwidth Information::**Downstream BC0 (kbits/sec):**

KEEP	PRIORITY	BW HELD	BW TOTAL HELD	BW LOCKED	BW TOTAL LOCKED
0		0	0	0	0
1		0	0	0	0
2		0	0	0	0
3		0	0	0	0
4		0	0	0	0
5		0	0	0	0
6		0	0	0	0
7		0	0	10	10

Downstream BC1 (kbits/sec):

KEEP	PRIORITY	BW HELD	BW TOTAL HELD	BW LOCKED	BW TOTAL LOCKED
0		0	0	0	0
1		0	0	0	0
2		0	0	0	0
3		0	0	0	0
4		0	0	0	0
5		0	0	0	0
6		0	0	0	0

This table describes the significant fields shown in the display.

Table 12: show mpls traffic-eng link-management bandwidth-allocation Command Field Descriptions

Field	Description
Links Count	Number of links configured for MPLS-TE.
Bandwidth Hold Time	Time, in seconds, that bandwidth can be held.
Link ID	Interface name and IP address of the link.
Link Label type	Label type of the link, for example: • PSC⁵ • TDM⁶ • FSC⁷
Physical BW	Link bandwidth capacity (in bits per second).

Field	Description
BCID	Bandwidth constraint model ID (RDM or MAM).
Max Reservable BW	Maximum reservable bandwidth on this link.
BC0	Maximum RSVP bandwidth in BC0.
BC1	Maximum RSVP bandwidth in BC1.
BW Descriptors	Number of bandwidth allocations on this link.
MPLS-TE Link State	Status of the link MPLS-TE-related functions.
Inbound Admission	Link admission policy for incoming tunnels.
Outbound Admission	Link admission policy for outgoing tunnels.
IGP Neighbor Count	IGP neighbors directly reachable over this link.
BW Descriptors	Internal bandwidth descriptors created when tunnels are admitted.
Admin Weight	Administrative weight associated with this link.
Up Thresholds	Threshold values used to determine link advertisement when available bandwidth increases.
Down Thresholds	Threshold values used to determine link advertisement when available bandwidth decreases.

⁵ PSC = Packet switch capable.

⁶ TDM = Time-division multiplexing.

⁷ FSC = Fiber switch capable.

show mpls traffic-eng link-management igp-neighbors

To display Interior Gateway Protocol (IGP) neighbors, use the **show mpls traffic-eng link-management igp-neighbors** command in XR EXEC mode.

show mpls traffic-eng link-management igp-neighbors [**igp-id** {**isis** *isis-address* | **ospf** *ospf-id*} [**{interface** *type interface-path-id IP-address*}]]

Syntax Description	igp-id	(Optional) Displays the IGP neighbors that are using a specified IGP identification.
	isis <i>isis-address</i>	Displays the specified Intermediate System-to-Intermediate System (IS-IS) neighbor system ID when neighbors are displayed by IGP ID.
	ospf <i>ospf-id</i>	Displays the specified Open Shortest Path first (OSPF) neighbor OSPF router ID when neighbors are displayed by IGP ID.
	interface	(Optional) Displays information on the specified interface.
	<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
	<i>interface-path-id</i>	Physical interface or a virtual interface.
		Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
	<i>IP-address</i>	(Optional) IGP neighbors that are using a specified IGP IP address.

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	mpls-te	read

Examples The following shows a sample output from the **show mpls traffic-eng link-management igp-neighbors** command:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng link igp-neighbors
```

```
Link ID: HundredGigE0/0/0/3  
No Neighbors
```

```
Link ID: HundredGigE0/0/0/4  
Neighbor ID: 10.90.90.90 (area: ospf area 0, IP: 10.15.12.2)
```

This table describes the significant fields shown in the display.

Table 13: show mpls traffic-eng link-management igp-neighbors Command Field Descriptions

Field	Description
Link ID	Link by which the neighbor is reached.
Neighbor ID	IGP identification information for the neighbor.

show mpls traffic-eng link-management interfaces

To display interface resources, or a summary of link management information, use the **show mpls traffic-eng link-management interfaces** command in XR EXEC mode.

show mpls traffic-eng link-management interfaces [*type interface-path-id*]

Syntax Description	type (Optional) Interface type. For more information, use the question mark (?) online help function. interface-path-id Physical interface or a virtual interface. Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.				
Command Default	No default behavior or values				
Command Modes	XR EXEC mode				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 6.0</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 6.0	This command was introduced.
Release	Modification				
Release 6.0	This command was introduced.				
Usage Guidelines	You cannot configure more than 250 links under MPLS-TE. SRLG values can be configured for the link.				
Task ID	<table> <tr> <th>Task ID</th><th>Operations</th></tr> <tr> <td>mpls-te</td><td>read</td></tr> </table>	Task ID	Operations	mpls-te	read
Task ID	Operations				
mpls-te	read				
Examples	The following sample output is from the show mpls traffic-eng link-management interfaces command: <pre> RP/0/RP0/CPU0:router# show mpls traffic-eng link-management interfaces HundredGigE 0/0/0/3 System Information:: Links Count : 7 (Maximum Links Supported 250) Link ID:: HundredGigE0/0/0/3 (12.9.0.1) Local Intf ID: 28 Link Status: Link Label Type : PSC Physical BW : 1000000 kbits/sec </pre>				

```

BCID                : RDM
Max Reservable BW   : 10000 kbits/sec (reserved: 2% in, 2% out)
BC0 (Res. Global BW): 10000 kbits/sec (reserved: 2% in, 2% out)
BC1 (Res. Sub BW)   : 0 kbits/sec (reserved: 100% in, 100% out)
MPLS TE Link State  : MPLS TE on, RSVP on, admin-up
Inbound Admission   : reject-huge
Outbound Admission  : allow-if-room
IGP Neighbor Count  : 1
Max Res BW (RDM)    : 10000 kbits/sec
BC0 (RDM)           : 10000 kbits/sec
BC1 (RDM)           : 0 kbits/sec
Max Res BW (MAM)    : 0 kbits/sec
BC0 (MAM)           : 0 kbits/sec
BC1 (MAM)           : 0 kbits/sec
Attributes          : 0x4
Attribute Names     : red2
Flooding Status: (1 area)
  IGP Area[1]: OSPF 100 area 0, flooded
    Nbr: ID 12.9.0.2, IP 0.0.0.0 (Up)
    Admin weight: not set (TE), 1 (IGP)

```

This table describes the significant fields shown in the display.

Table 14: show mpls traffic-eng link-management interfaces Command Field Descriptions

Field	Description
Links Count	Number of links configured for MPLS-TE. Maximum number of links supported is 100.
Link ID	Link identification index.
Link Label Type	Label type assigned to the link.
Physical Bandwidth	Link bandwidth capacity (in kilobits per second).
BCID	Bandwidth constraint model ID (RDM or MAM).
Max Reservable BW	Maximum reservable bandwidth on this link.
BC0	Reservable bandwidth (in kbps) on this link in BC0.
BC1	Reservable bandwidth (in kbps) on this link in BC1.
Attributes	TE link attribute in hexadecimal.
Attribute Names	Name of the affinity attribute of a link.
SRLGs ⁸ .	Links that share a common fiber or a common physical attribute. If one link fails, other links in the group may also fail. Links in the group have a shared risk.
MPLS-TE Link State	Status of the MPLS link.
Inbound Admission	Link admission policy for inbound tunnels.
Outbound Admission	Link admission policy for outbound tunnels.
IGP Neighbor Count	IGP ⁹ neighbors directly reachable over this link.

Field	Description
Admin. Weight	Administrative weight associated with this link.
Flooding Status	Status for each configured area or Flooding status for the configured area.
IGP Area	IGP type and area and level used for TE flooding.

⁸ SRLGs = Shared Risk Link Groups.

⁹ IGP = Interior Gateway Protocol .

show mpls traffic-eng link-management statistics

To display interface resources or a summary of link management information, use the **show mpls traffic-eng link-management statistics** command in XR EXEC mode.

show mpls traffic-eng link-management statistics [{summary | interface type interface-path-id}]

Syntax Description	summary	(Optional) Displays the statistics summary.
	interface	(Optional) Displays the interface for which information is requested.
	type	(Optional) Interface type. For more information, use the question mark (?) online help function.
	interface-path-id	Physical interface or virtual interface.
Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.		

Command Default No default behavior or values

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines The **show mpls traffic-eng link-management statistics** command displays resource and configuration information for all configured interfaces.

Task ID	Task ID	Operations
	mpls-te	read

Examples

The following shows a sample output from the **show mpls traffic-eng link-management statistics** command using the **summary** keyword:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng link-management statistics summary

LSP Admission Statistics:
```

```

      Setup      Setup      Setup      Setup      Tear      Tear      Tear
Requests Admits  Rejects  Errors  Requests Preempts Errors
-----
```

Path	13	12	1	0	10	0	0
Resv	8	8	0	0	5	0	0

Table 15: show mpls traffic-eng link-management statistics summary Command Field Descriptions, on page 170 describes the significant fields shown in the display.

Table 15: show mpls traffic-eng link-management statistics summary Command Field Descriptions

Field	Description
Path	Path information.
Resv	Reservation information.
Setup Requests	Number of requests for a setup.
Setup Admits	Number of admitted setups.
Setup Rejects	Number of rejected setups.
Setup Errors	Number of setup errors.
Tear Requests	Number of tear requests.
Tear Preempts	Number of paths torn down due to preemption.
Tear Errors	Number of tear errors.

show mpls traffic-eng link-management summary

To display a summary of link management information, use the **show mpls traffic-eng link-management summary** command in XR EXEC mode.

show mpls traffic-eng link-management summary

Syntax Description	This command has no arguments or keywords.				
Command Default	No default behavior or values				
Command Modes	XR EXEC mode				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 6.0</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 6.0	This command was introduced.
Release	Modification				
Release 6.0	This command was introduced.				
Usage Guidelines	You cannot configure more than 250 links for MPLS-TE/FRR.				
Task ID	<table> <tr> <th>Task ID</th><th>Operations</th></tr> <tr> <td>mpls-te</td><td>read</td></tr> </table>	Task ID	Operations	mpls-te	read
Task ID	Operations				
mpls-te	read				

Examples

The following sample output is from the **show mpls traffic-eng link-management summary** command:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng link-management summary
```

```
System Information::
  Links Count           : 6 (Maximum Links Supported 100)
  Flooding System       : enabled
  IGP Areas Count       : 2

IGP Areas
-----

IGP Area[1]:: isis    level-2
  Flooding Protocol    : ISIS
  Flooding Status      : flooded
  Periodic Flooding    : enabled (every 180 seconds)
  Flooded Links        : 4
  IGP System ID        : 0000.0000.0002.00
  MPLS-TE Router ID    : 20.20.20.20
  IGP Neighbors        : 8

IGP Area[2]:: ospf    area 0
  Flooding Protocol    : OSPF
  Flooding Status      : flooded
  Periodic Flooding    : enabled (every 180 seconds)
  Flooded Links        : 4
```

show mpls traffic-eng link-management summary

```

IGP System ID       : 20.20.20.20
MPLS-TE Router ID  : 20.20.20.20
IGP Neighbors       : 8

```

This table describes the significant fields shown in the display.

Table 16: show mpls traffic-eng link-management summary Command Field Descriptions

Field	Description
Links Count	Number of links configured for MPLS-TE. Maximum number of links supported is 100.
Flooding System	Enable status of the MPLS-TE flooding system.
IGP Areas Count	Number of IGP ¹⁰ areas described.
IGP Area	IGP type and area and level used for TE flooding.
Flooding Protocol	IGP flooding information for this area.
Flooding Status	Status of flooding for this area.
Periodic Flooding	Status of periodic flooding for this area.
Flooded Links	Links that were flooded.
IGP System ID	IGP for the node associated with this area.
MPLS-TE Router ID	MPLS-TE router ID for this node.
IGP Neighbors	Number of reachable IGP neighbors associated with this area.

¹⁰ IGP = Interior Gateway Protocol.

show mpls traffic-eng maximum tunnels

To display the maximum number of MPLS-TE tunnels that you can configure, use the **show mpls traffic-eng maximum tunnels** command in XR EXEC mode.

show mpls traffic-eng maximum tunnels

Syntax Description	This command has no keywords or arguments.	
Command Default	None	
Command Modes	XR EXEC mode	
Command History	Release	Modification
	Release 6.0	This command was introduced.
Usage Guidelines	No specific guidelines impact the use of this command.	
Task ID	Task ID	Operations
	mpls-te	read

Examples

This is sample output from the **show mpls traffic-eng maximum tunnels** command:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng maximum tunnels
```

Maximum Global Tunnel Count:

Maximum	Current Count
4096	2

Maximum Global Destination Count:

Maximum	Current Count
4096	2

Maximum AutoTunnel Backup Count:

Maximum	Current Count
200	122

This is sample output of the automatic mesh tunnels from the **show mpls traffic-eng maximum tunnels** command:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng maximum tunnels
```

Maximum Global Tunnel Count:

```
Maximum      Current Count
-----
4096         12
```

Maximum Static Tunnel Count:

```
Maximum      Current Count
-----
4096         8
```

Maximum Auto-tunnel Mesh Count:

```
Maximum      Current Count
-----
201          3
```

Maximum Global Destination Count:

```
Maximum      Current Count
-----
4096         13
```

Maximum GMPLS-UNI Tunnel Count:

```
Maximum      Current Count
-----
500          39
```

[Table 17: show mpls traffic-eng maximum tunnels Command Field Descriptions, on page 174](#) describes the significant fields shown in the display.

Table 17: show mpls traffic-eng maximum tunnels Command Field Descriptions

Field	Description
Maximum Global Tunnel Count	Maximum number of tunnel interfaces (all TE tunnel types, tunnel-te, tunnel-mte, and tunnel-gte) that can be configured.
Maximum Global Tunnel Count	Maximum number of tunnel interfaces (all TE tunnel types and tunnel-te) that can be configured.
Maximum Global Destination Count	Maximum number of tunnel destinations that can be configured.
Maximum	Table heading for the maximum number in each category.

Field	Description
Current Count	Table heading for the current count in each category.
Maximum AutoTunnel Backup Count	Maximum number of automatic backup tunnels that can be configured.
Maximum GMPLS UNI Tunnel Count	Maximum number of Generalized Multiprotocol Label Switching (GMPLS) User-Network Interface (UNI) tunnels that can be configured and the current tunnel count.
Maximum AutoTunnel Mesh Count	Maximum number of automatic mesh tunnels that can be configured.

show mpls traffic-eng preemption log

To display the log of preemption events, use the **show mpls traffic-eng preemption log** command in XR EXEC mode.

show mpls traffic-eng preemption log

Syntax Description	log Displays a log of preemption events.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	XR EXEC mode
----------------------	--------------

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines	No specific guidelines impact the use of this command.
-------------------------	--

Task ID	Task ID	Operation
	mpls-te	read

This is sample output from the **show mpls traffic-eng preemption log** command displaying the log of preemption events:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng preemption log
Bandwidth Change on GigabitEthernet0/0/0/0
Old BW (BC0/BC1): 200000/100000, New BW (BC0/BC1): 1000/500 kbps
BW Overshoot (BC0/BC1): 1000/0 kbps
Preempted BW (BC0/BC1): 35000/0 kbps; Soft 30000/0 kbps; Hard 5000/0 kbps;
Preempted 2 tunnels; Soft 1 tunnel; Hard 1 tunnel
```

TunID	LSP ID	Source	Destination	Preempt Type	Pri S/H	Bandwidth (in kbps)	BW Type
1	10002	192.168.0.1	1.0.0.0	Hard	7/7	5000	BC0
1	2	192.168.0.1	192.168.0.4	Soft	7/7	30000	BC0

This sample output displays the log of soft-preemption over FRR backup tunnels events:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng preemption log
Thu Apr 25 13:12:04.863 EDT
Bandwidth Change on GigabitEthernet0/0/0/1 at 04/25/2013 12:56:14
Old BW (BC0/BC1): 200000/100000, New BW (BC0/BC1): 100000/0 kbps
BW Overshoot (BC0/BC1): 30000/0 kbps
Preempted BW (BC0/BC1): 130000/0 kbps; Soft 60000/0 kbps; Hard 0/0 kbps; FRRSoft 70000/0
```


Preempted 2 tunnel, 2 LSP; Soft 1 tunnel, 1 LSP; Hard 0 tunnels, 0 LSPs; FRRSoft 1 tunnel, 1 LSP

TunID	LSP ID	Source	Destination	Preempt Type	Pri S/H	Bandwidth (in kbps)	BW Type
1	13	192.168.0.1	192.168.0.3	FRRSoft	7/7	70000	BC0
2	22	192.168.0.1	192.168.0.3	Soft	7/7	60000	BC0

show mpls traffic-eng topology

To display the current MPLS-TE network topology for the node, use the **show mpls traffic-eng topology** command in XR EXEC mode.

show mpls traffic-eng topology [*IP-address*] [**affinity**] [**brief**] [{**exclude-srlg** *exclude-srlg-interface-address*|**explicit-path**{**identifier** *explicit-path-id-number*|**name** *explicit-path-name*}|**priority** *level*}] [{**isis** *nsap-address*|**ospf** *ospf-address*|**path** {**destination** *IP-address*|**tunnel** *P2P-tunnel-number* }}|{**router**|**network**}]}] [**model-type** {**rdm**|**mam**}] [**srlg**][**static**]

Syntax Description	<i>IP-address</i>	(Optional) Node IP address (router identifier to interface address).
	destination <i>IP-address</i>	Displays the LSP destination IPv4 address.
	exclude-srlg	Specifies an IP address to get SRLG values from for exclusion.
	explicit-path	Displays the explicit LSP path.
	tunnel	Displays the topology path that is based on the Point-to-Point (P2P) tunnel number.
	<i>P2P -tunnel-number</i>	P2P tunnel number. Range is 0 to 65535.
	affinity	(Optional) Displays the attribute values that are required for links carrying this tunnel. A 32-bit decimal number. Range is 0x0 to 0xFFFFFFFF, representing 32 attributes (bits), where the value of an attribute is 0 or 1.
	priority <i>level</i>	(Optional) Displays the priority used when signaling a LSP for this tunnel, to determine which existing tunnels can be preempted.
	isis <i>nsap-address</i>	(Optional) Displays the node router identification, if Intermediate System-to-Intermediate System (IS-IS) is enabled.
	ospf <i>ospf-address</i>	(Optional) Displays the node router identifier, if Open Shortest Path First (OSPF) is enabled.

path	(Optional) Displays the path to a destination from this router.
router	Displays the given OSPF address type of the router node.
network	Displays the given OSPF address type of the network node.
brief	(Optional) Displays the brief form of the output that provides a less detailed version of the topology.
model-type { rdm mam }	(Optional) Displays the bandwidth constraints model type, RDM or MAM.
srlg	(Optional) Displays the SRLG information.
static	(Optional) Displays the statically configured SRLG.

Command Default No default behavior or values

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	mpls-te	read, write

Examples

The following shows a sample output from the **show mpls traffic-eng topology** command specifying the tunnel number in brief form:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng topology path tunnel 160
```

```
Tunnell160 Path Setup to 10.10.10.10: FULL_PATH
bw 100 (CT0), min_bw 0, metric: 10
setup_pri 7, hold_pri 7
affinity_bits 0x0, affinity_mask 0xffff
Hop0:10.2.2.1
Hop1:10.10.10.10
```

The following shows a sample output from the **show mpls traffic-eng topology** command specifying the destination IP address:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng topology path destination 10.10.10.10
```

```
Path Setup to 10.10.10.10:
bw 0 (CT0), min_bw 999900, metric: 10
setup_pri 7, hold_pri 7
affinity_bits 0x0, affinity_mask 0xffffffff
Hop0:10.2.2.1
Hop1:10.10.10.10
```

The following sample output shows the MPLS-TE network topology with the name of the affinity attribute of the link:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng topology
```

```
Link[1]:Point-to-Point, Nbr IGP Id:3.3.3.3, Nbr Node Id:9, gen:23
Frag Id:25, Intf Address:13.9.1.1, Intf Id:0
Nbr Intf Address:13.9.1.3, Nbr Intf Id:0
TE Metric:1, IGP Metric:1, Attribute Flags:0x0
Attribute Names:
Switching Capability:, Encoding:
BC Model ID:RDM
Physical BW:155520 (kbps), Max Reservable BW Global:116640 (kbps)
Max Reservable BW Sub:0 (kbps)
```

	Total Allocated BW (kbps)	Global Pool Reservable BW (kbps)	Sub Pool Reservable BW (kbps)
	-----	-----	-----
bw[0]:	0	116640	0
bw[1]:	0	116640	0
bw[2]:	0	116640	0
bw[3]:	0	116640	0
bw[4]:	0	116640	0
bw[5]:	0	116640	0
bw[6]:	0	116640	0
bw[7]:	0	116640	0

```
Link[2]:Broadcast, DR:12.9.0.2, Nbr Node Id:1, gen:23
Frag Id:28, Intf Address:12.9.0.1, Intf Id:0
Nbr Intf Address:0.0.0.0, Nbr Intf Id:0
TE Metric:1, IGP Metric:1, Attribute Flags:0x4
Attribute Names: red2
Switching Capability:, Encoding:
BC Model ID:RDM
Physical BW:1000000 (kbps), Max Reservable BW Global:10000 (kbps)
Max Reservable BW Sub:0 (kbps)
```

	Total Allocated BW (kbps)	Global Pool Reservable BW (kbps)	Sub Pool Reservable BW (kbps)
	-----	-----	-----
bw[0]:	0	10000	0
bw[1]:	0	10000	0
bw[2]:	0	10000	0
bw[3]:	0	10000	0
bw[4]:	0	10000	0
bw[5]:	0	10000	0
bw[6]:	0	10000	0
bw[7]:	0	10000	0

The following shows a sample output from the **show mpls traffic-eng topology** command in detail form in prestandard DS-TE mode:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng topology

My_System_id: 0000.0000.0002.00 (isis level-2)
My_System_id: 20.20.20.20 (ospf area 0)
My_BC_Model_Type: RDM

Signalling error holddown: 10 sec Global Link Generation 36

IGP Id: 0000.0000.0002.00, MPLS-TE Id: 20.20.20.20 Router Node (isis level-2)

Link[0]:Point-to-Point, Nbr IGP Id:0000.0000.0003.00, Nbr Node Id:3, gen:36
  Frag Id:0, Intf Address:7.3.3.1, Intf Id:0
  Nbr Intf Address:7.3.3.2, Nbr Intf Id:0
  TE Metric:10, IGP Metric:10, Attribute Flags:0x0
  Switching Capability:SRLGs: 10, Encoding:20
  Switching Capability:, Encoding:
BC Model ID:RDM
Physical BW:155520 (kbps), Max Reservable BW Global:100000 (kbps)
Max Reservable BW Sub:50000 (kbps)

              Total Allocated      Global Pool      Sub Pool
              BW (kbps)            Reservable
              -----            -
bw[0]:              0            100000            50000
bw[1]:              0            100000            50000
bw[2]:              0            100000            50000
bw[3]:              0            100000            50000
bw[4]:              0            100000            50000
bw[5]:              0            100000            50000
bw[6]:              0            100000            50000
bw[7]:              0            100000            50000
```

The following shows a sample output from the **show mpls traffic-eng topology** command in detail form in IETF DS-TE mode.

```
RP/0/RP0/CPU0:router# show mpls traffic-eng topology

My_System_id: 0000.0000.0001.00 (isis 1 level-2)
My_System_id: 10.10.10.10 (ospf 100 area 0)
My_BC_Model_Type: MAM

Signalling error holddown: 10 sec Global Link Generation 84

IGP Id: 0000.0000.0001.00, MPLS-TE Id: 10.10.10.10 Router Node (isis 1 level-2)

Link[0]:Point-to-Point, Nbr IGP Id:0000.0000.0002.00, Nbr Node Id:6, gen:84
  Frag Id:0, Intf Address:7.2.2.1, Intf Id:0
  Nbr Intf Address:7.2.2.2, Nbr Intf Id:0
  TE Metric:10, IGP Metric:10, Attribute Flags:0x0
  TE Metric:SRLGs: 10, IGP Metric:10, Attribute Flags:0x020
  Switching Capability:, Encoding:
BC Model ID:MAM
Physical BW:155520 (kbps), Max Reservable BW:1000 (kbps)
BC0:600 (kbps) BC1:400 (kbps)
              Total Allocated      Reservable
              BW (kbps)            BW (kbps)
              -----            -
TE-class[0]:              10            590
```

show mpls traffic-eng topology

```

TE-class[1]:          0          400
TE-class[2]:          0          0
TE-class[3]:          0          0
TE-class[4]:          0          600
TE-class[5]:          0          400
Link[1]:Point-to-Point, Nbr IGP Id:0000.0000.0002.00, Nbr Node Id:6, gen:84
Frag Id:0, Intf Address:7.1.1.1, Intf Id:0
Nbr Intf Address:7.1.1.2, Nbr Intf Id:0
TE Metric:10, IGP Metric:10, Attribute Flags:0x0
TE Metric:SRLGs: 10, IGP Metric:10, Attribute Flags:0x020
Switching Capability:, Encoding:
BC Model ID:MAM
Physical BW:155520 (kbps), Max Reservable BW:1000 (kbps) BC0:600 (kbps) BC1:400
(kbps)

```

	Total Allocated BW (kbps)	Reservable BW (kbps)
	-----	-----
TE-class[0]:	10	590
TE-class[1]:	0	400
TE-class[2]:	0	0
TE-class[3]:	0	0
TE-class[4]:	0	600
TE-class[5]:	0	400
TE-class[6]:	0	0
TE-class[7]:	0	0

The following shows a sample output for the **show mpls traffic-eng topology** command in brief form:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng topology 192.168.0.145 brief
```

```

IGP Id: 0000.0000.0010.00, MPLS TE Id: 192.168.0.145 Router Node (ISIS test level-1)
Link[0]:Point-to-Point, Nbr IGP Id:0000.0000.0234.00, Nbr Node Id:4, gen:5
Frag Id:0, Intf Address:10.3.11.145, Intf Id:0
Nbr Intf Address:10.3.11.143, Nbr Intf Id:0
TE Metric:10, IGP Metric:10, Attribute Flags:0x0
SRLGs: 10, 20
Attribute Names: red2
Switching Capability:, Encoding:
BC Model ID:RDM
Physical BW:155520 (kbps), Max Reservable BW Global:0 (kbps)
Max Reservable BW Sub:0 (kbps)

```

The following sample output shows a brief topology for the affinity attributes:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng topology affinity
```

```

affinity
Mon Mar 23 13:25:47.236 EST EST
My_System_id: 1.1.1.1 (OSPF 100 area 0)
My_System_id: 0000.0000.0001.00 (IS-IS 100 level-2)
My_BC_Model_Type: RDM

Signalling error holddown: 10 sec Global Link Generation 233

IGP Id: 0000.0000.0001.00, MPLS TE Id: 11.11.1.1 Router Node (IS-IS 100 level-2)

IGP Id: 1.1.1.1, MPLS TE Id: 1.1.1.1 Router Node (OSPF 100 area 0)
Link[0]:      Intf Address: 12.9.1.1, Nbr Intf Address: 12.9.1.2
Attribute Flags: 0x0
Attribute Names:

```

```

Link[1]:      Intf Address: 13.9.1.1, Nbr Intf Address: 13.9.1.3
             Attribute Flags: 0x0
             Attribute Names:
Link[2]:      Intf Address: 12.9.0.1, DR: 12.9.0.2
             Attribute Flags: 0x4
             Attribute Names: red2
Link[3]:      Intf Address: 14.9.0.1, DR: 14.9.0.4
             Attribute Flags: 0x0
             Attribute Names:
Link[4]:      Intf Address: 13.9.0.1, DR: 13.9.0.3
             Attribute Flags: 0x0
             Attribute Names:

IGP Id: 4.4.4.4, MPLS TE Id: 4.4.4.4 Router Node (OSPF 100 area 0)
Link[0]:      Intf Address: 34.9.1.4, Nbr Intf Address: 34.9.1.3
             Attribute Flags: 0x0
             Attribute Names:
Link[1]:      Intf Address: 14.9.0.4, DR: 14.9.0.4
             Attribute Flags: 0x1e
             Attribute Names: red1 red2 red3 red4
Link[2]:      Intf Address: 24.9.0.4, DR: 24.9.0.4
             Attribute Flags: 0x0
             Attribute Names:
Link[3]:      Intf Address: 34.9.0.4, DR: 34.9.0.3
             Attribute Flags: 0x0
             Attribute Names:
Link[4]:      Intf Address: 24.9.1.4, Nbr Intf Address: 24.9.1.2
             Attribute Flags: 0x0
             Attribute Names:

```

The following sample output for the **show mpls traffic-eng topology** command that shows the output to a single link:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng topology 12.9.1.1 link-only
```

```
Wed Sep  2 13:24:48.821 EST
```

```
IGP Id: 0000.0000.0002.00, MPLS TE Id: 2.2.2.2 Router Node (IS-IS 100 level-2)
```

```

Link[0]:Point-to-Point, Nbr IGP Id:0000.0000.0001.00, Nbr Node Id:-1, gen:277740
Frag Id:0, Intf Address:12.9.1.2, Intf Id:0
Nbr Intf Address:12.9.1.1, Nbr Intf Id:0
TE Metric:10, IGP Metric:10, Attribute Flags:0x0
Attribute Names:
Switching Capability:, Encoding:
BC Model ID:RDM
Physical BW:155520 (kbps), Max Reservable BW Global:116640 (kbps)
Max Reservable BW Sub:0 (kbps)

```

	Total Allocated BW (kbps)	Global Pool Reservable BW (kbps)	Sub Pool Reservable BW (kbps)
	-----	-----	-----
bw[0]:	0	116640	0
bw[1]:	0	116640	0
bw[2]:	0	116640	0
bw[3]:	0	116640	0
bw[4]:	0	116640	0
bw[5]:	0	116640	0
bw[6]:	0	116640	0
bw[7]:	0	116640	0

show mpls traffic-eng topology

```

IGP Id: 2.2.2.2, MPLS TE Id: 2.2.2.2 Router Node (OSPF 100 area 0)

Link[3]:Point-to-Point, Nbr IGP Id:1.1.1.1, Nbr Node Id:-1, gen:277737
Frag Id:29, Intf Address:12.9.1.2, Intf Id:0
Nbr Intf Address:12.9.1.1, Nbr Intf Id:0
TE Metric:1, IGP Metric:1, Attribute Flags:0x0
Attribute Names:
Switching Capability:, Encoding:
BC Model ID:RDM
Physical BW:155520 (kbps), Max Reservable BW Global:116640 (kbps)
Max Reservable BW Sub:0 (kbps)

                                Global Pool      Sub Pool
                                Reservable      Reservable
                                BW (kbps)       BW (kbps)
                                -----
bw[0]:                          0             116640             0
bw[1]:                          0             116640             0
bw[2]:                          0             116640             0
bw[3]:                          0             116640             0
bw[4]:                          0             116640             0
bw[5]:                          0             116640             0
bw[6]:                          0             116640             0
bw[7]:                          0             116640             0

```

The following shows a sample output for the **show mpls traffic-eng topology model-type mam** command:

```

RP/0/RP0/CPU0:router# show mpls traffic-eng topology model-type mam

IGP Id: 0000.0000.0001.00, MPLS-TE Id: 10.10.10.10 Router Node (isis 1 level-2)
Link[0]:      Intf Address:7.2.2.1, Nbr Intf Address:7.2.2.2
Link[1]:      Intf Address:7.1.1.1, Nbr Intf Address:7.1.1.2

IGP Id: 0000.0000.0002.00, MPLS-TE Id: 20.20.20.20 Router Node (isis 1 level-2)
Link[0]:      Intf Address:7.2.2.2, Nbr Intf Address:7.2.2.1
Link[1]:      Intf Address:7.1.1.2, Nbr Intf Address:7.1.1.1
Link[2]:      Intf Address:7.3.3.1, Nbr Intf Address:7.3.3.2

IGP Id: 0000.0000.0003.00, MPLS-TE Id: 30.30.30.30 Router Node (isis 1 level-2)
Link[0]:      Intf Address:7.3.3.2, Nbr Intf Address:7.3.3.1

```

The following shows a sample output from the **show mpls traffic-eng topology** command specifying the topology for the SRLG interfaces:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng topology srlg
```

```

Tue Oct  6 13:10:30.342 UTC
My_System_id: 0000.0000.0005.00 (IS-IS 1 level-2)

SRLG      Interface Addr  TE Router ID    IGP Area  ID
-----
1         51.1.2.1         100.0.0.1       IS-IS 1 level-2
2         51.1.2.1         100.0.0.1       IS-IS 1 level-2
3         51.1.2.1         100.0.0.1       IS-IS 1 level-2
4         51.1.2.1         100.0.0.1       IS-IS 1 level-2
5         51.1.2.1         100.0.0.1       IS-IS 1 level-2
6         51.1.2.1         100.0.0.1       IS-IS 1 level-2
7         51.1.2.1         100.0.0.1       IS-IS 1 level-2
8         51.1.2.1         100.0.0.1       IS-IS 1 level-2
10        50.4.5.5         100.0.0.5       IS-IS 1 level-2
30        50.4.5.5         100.0.0.5       IS-IS 1 level-2

```


77	50.4.5.5	100.0.0.5	IS-IS 1 level-2
88	50.4.5.5	100.0.0.5	IS-IS 1 level-2
1500	50.4.5.5	100.0.0.5	IS-IS 1 level-2
10000000	50.4.5.5	100.0.0.5	IS-IS 1 level-2
4294967290	50.4.5.5	100.0.0.5	IS-IS 1 level-2
4294967295	50.4.5.5	100.0.0.5	IS-IS 1 level-2

The following shows a sample output from the **show mpls traffic-eng topology path destination** command specifying the topological path with SRLG exclusion:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng topology path destination 100.0.0.2 exclude-srlg
50.4.5.5 isis 1 level 2
```

```
Tue Oct 6 13:13:44.053 UTC
Path Setup to 100.0.0.2:
bw 0 (CT0), min_bw 0, metric: 20
setup_pri 7, hold_pri 7
affinity_bits 0x0, affinity_mask 0xffff
Exclude SRLG Intf Addr : 50.4.5.5
SRLGs Excluded: 10, 30, 77, 88, 1500, 10000000
4294967290, 4294967295
Hop0:50.5.1.5
Hop1:50.5.1.1
Hop2:51.1.2.1
Hop3:51.1.2.2
Hop4:100.0.0.2
```

The following shows a sample output from the **show mpls traffic-eng topology path destination** command specifying the topological path based on a given explicit path:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng topology path destination 100.0.0.2 explicit-path
name exclude-srlg isis 1 level 2
```

```
Tue Oct 6 13:16:44.233 UTC
Path Setup to 100.0.0.2:
bw 0 (CT0), min_bw 0, metric: 20
setup_pri 7, hold_pri 7
affinity_bits 0x0, affinity_mask 0xffff
SRLGs Excluded: 10, 30, 77, 88, 1500, 10000000
4294967290, 4294967295, 1, 2, 3, 4
5, 6, 7, 8
Hop0:50.5.1.5
Hop1:50.5.1.1
Hop2:50.1.2.1
Hop3:50.1.2.2
Hop4:100.0.0.2
```

show mpls traffic-eng tunnels

To display information about MPLS-TE tunnels, use the **show mpls traffic-eng tunnels** command in XR EXEC mode.

```
show mpls traffic-eng tunnels [tunnel-number] [affinity] [all] [auto-bw] [attribute-set {all | tunnel-name}]
[auto-tunnel] [backup [{tunnel-number | auto-tunnel [mesh ] mesh-value | [name tunnel-name] |
protected-interface type interface-path-id | {static | auto}]]] [brief] [destination destination-address]
[detail] [down] [interface {in | out | inout} type interface-path-id] [name tunnel-name] [p2p]
[property { backup-tunnel | fast-reroute}] [protection [{frr | path | tunnel-id | tunnel-id | tabular}]]
[reoptimized within-last interval][role {all | head | tail | middle}] [soft-preemption {desired |
triggered}]] [source source-address] [suboptimal constraints {current | max | none}] [summary]
[tabular] [up] [class-type ct]
```

Syntax Description

<i>tunnel-number</i>	(Optional) Number of the tunnel. Range is from 0 to 65535.
attribute-set	(Optional) Restricts the display of tunnels with an attribute set.
affinity	(Optional) Displays the affinity attributes for all outgoing links. The links, which are used by the tunnel, display color information.
all	(Optional) Displays all MPLS-TE tunnels.
auto-bw	(Optional) Restricts the display to tunnels when the automatic bandwidth is enabled.
auto-tunnel	(Optional) Restricts the display of automatically created tunnels.
mesh <i>mesh-value</i>	Displays the tunnels that belong to the specified auto-tunnel mesh group.
backup	(Optional) Displays FRR¹¹ backup tunnels information. The information includes the physical interface protected by the tunnel, the number of TE LSPs¹² protected, and the bandwidth protected. (Optional) Displays backup information for automatic tunnels and FRR tunnels.
name <i>tunnel-name</i>	(Optional) Displays the tunnel with given name.
protected-interface	(Optional) Displays FRR protected interfaces.
static	(Optional) Displays static backup tunnels.
auto-tunnel	(Optional) Displays protected automatic backup tunnels.

brief	(Optional) Displays the brief form of this command.
destination <i>destination-address</i>	(Optional) Restricts the display to tunnels destined for the specified IP address.
detail	(Optional) Displays detail information about headend tunnels.
down	(Optional) Displays tunnels that are down.
interface in	(Optional) Displays tunnels that use the specified input interface.
interface out	(Optional) Displays tunnels that use the specified output interface.
interface inout	(Optional) Displays tunnels that use the specified interface as an input or output interface.
<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or a virtual interface. Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
p2p	(Optional) Displays only P2P tunnels.
property backup-tunnel	(Optional) Displays tunnels with property of backup tunnel. Selects MPLS-TE tunnels used to protect physical interfaces on this router. A tunnel configured to protect a link against failure is a backup tunnel and has the backup tunnel property.
property fast-reroute	(Optional) Displays tunnels with property of fast-reroute configured. Selects FRR-protected MPLS-TE tunnels originating on (head), transmitting (router), or terminating (tail) on this router.

protection	(Optional) Displays all protected tunnels (configured as fast-reroutable). Displays information about the protection provided to each tunnel selected by other options specified with this command. The information includes whether protection is configured for the tunnel, the protection (if any) provided to the tunnel by this router, and the tunnel bandwidth protected.
frr	(Optional) Displays all protected tunnels (configured as fast-reroutable).
path	(Optional) Displays information for the path-protection.
tunnel-id	(Optional) Displays information for the path-protection for a particular tunnel.
<i>tunnel-id</i>	(Optional) Tunnel identifier. The range is from 0 to 65535.
tabular	(Optional) Displays information for the path protection tunnel in tabular format.
reoptimized within-last <i>interval</i>	(Optional) Displays tunnels reoptimized within the last given time interval.
role all	(Optional) Displays all tunnels.
role head	(Optional) Displays tunnels with their heads at this router.
role middle	(Optional) Displays tunnels at the middle of this router.
role tail	(Optional) Displays tunnels with their tails at this router.
soft-preemption	Displays tunnels on which the soft-preemption feature is enabled.
source <i>source-address</i>	(Optional) Restricts the display to tunnels with a matching source IP address.
suboptimal constraints current	(Optional) Displays tunnels whose path metric is greater than the current shortest path constrained by the tunnel's configured options.
suboptimal constraints max	(Optional) Displays tunnels whose path metric is greater than the current shortest path, constrained by the configured options for the tunnel, and taking into consideration only the network capacity.

suboptimal constraints none	(Optional) Displays tunnels whose path metric is greater than the shortest unconstrained path.
summary	(Optional) Displays summary of configured tunnels.
tabular	(Optional) Displays a table showing TE LSPs, with one entry per line.
up	(Optional) Displays tunnels when the tunnel interface is up.
class-type ct	(Optional) Displays tunnels using the given class-type value configuration.

¹¹ FRR = Fast Reroute.

¹² LSPs = Label Switched Paths.

Command Default

None

Command Modes

XR EXEC mode

Command History

Release	Modification
Release 6.0	This command was introduced.

Usage Guidelines

Use the **brief** form of the **show mpls traffic-eng tunnels** command to display information specific to a tunnel interface. Use the command without the **brief** keyword to display information that includes the destination address, source ID, role, name, suboptimal constraints, and interface.

The **affinity** keyword is available for only the source router.

Selected tunnels would have a shorter path if they were reoptimized immediately.

To display the path-protection summary fields, you must configure the options for the path-protection.

Task ID

Task ID	Operations
mpls-te	read, write

Examples

This sample output is not changed when no area is specified for the active path-option. If the area is specified, it is added on a line of its own after the existing path-option information.

```
RP/0/RP0/CPU0:router# show mpls traffic-eng tunnels 20 detail
```

Signalling Summary:

```

    LSP Tunnels Process:  running
      RSVP Process:      running
        Forwarding:      enabled
  Periodic reoptimization: every 3600 seconds, next in 2400 seconds
```

show mpls traffic-eng tunnels

```

        Periodic FRR Promotion:  every 300 seconds, next in 16 seconds
        Auto-bw enabled tunnels:  6

Name: tunnel-te20  Destination: 130.130.130.130
Status:
  Admin:      up Oper:      up  Path:  valid  Signalling: connected

  path option 1,  type explicit rlr2r3gig_path (Basis for Setup, path weight 200)
  G-PID: 0x0800 (derived from egress interface properties)
  Bandwidth Requested: 113 kbps  CT0

Config Parameters:
  Bandwidth:      100 kbps (CT0) Priority:  7  7 Affinity: 0x0/0xffff
  Metric Type: TE (interface)
  AutoRoute:  enabled  LockDown: disabled  Policy class: not set
  Forwarding-Adjacency: disabled
  Loadshare:      0 equal loadshares
  Auto-bw: enabled
    Last BW Applied: 113 kbps CT0  BW Applications: 1
    Last Application Trigger: Periodic Application
    Bandwidth Min/Max: 0-4294967295 kbps
    Application Frequency: 5 min  Jitter: 0s  Time Left: 4m 19s
    Collection Frequency: 1 min
    Samples Collected: 0  Next: 14s
    Highest BW: 0 kbps  Underflow BW: 0 kbps
    Adjustment Threshold: 10%  10 kbps
    Overflow Detection disabled
    Underflow Detection disabled
    Fast Reroute: Disabled, Protection Desired: None
    Path Protection: Not Enabled
History:
  Tunnel has been up for: 00:18:54
  Current LSP:
    Uptime: 00:05:41
  Prior LSP:
    ID: path option 1 [3]
    Removal Trigger: reoptimization completed
Current LSP Info:
  Instance: 4, Signaling Area: IS-IS 1 level-2
  Uptime: 00:05:41 (since Mon Mar 15 00:01:36 UTC 2010)
  Outgoing Interface: HundredGigE0/0/0/3, Outgoing Label: 16009
  Router-IDs: local      110.110.110.110
               downstream 120.120.120.120
Path Info:
  Outgoing:
  Explicit Route:
    Strict, 61.10.1.2
    Strict, 61.15.1.1
    Strict, 61.15.1.2
    Strict, 130.130.130.130
  Record Route: Disabled
  Tspeg: avg rate=113 kbits, burst=1000 bytes, peak rate=113 kbits
  Session Attributes: Local Prot: Not Set, Node Prot: Not Set, BW Prot: Not Set
Resv Info: None
  Record Route: Disabled
  Fspeg: avg rate=113 kbits, burst=1000 bytes, peak rate=113 kbits
Displayed 1 (of 6) heads, 0 (of 0) midpoints, 0 (of 0) tails
Displayed 1 up, 0 down, 0 recovering, 0 recovered heads

```

This is a sample output from the **show mpls traffic-eng tunnels** command using the **property** keyword:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng tunnels property backup interface out
HundredGigE0/0/0/3
```

```
Signalling Summary:
    LSP Tunnels Process:  running, not registered with RSVP
    RSVP Process:        not running
    Forwarding:          enabled
    Periodic reoptimization: every 3600 seconds, next in 3595 seconds
    Periodic FRR Promotion: every 300 seconds, next in 295 seconds
    Periodic auto-bw collection: disabled
```

```
Name: tunnel-tel  Destination: 1.1.1.1
Status:
    Admin:    up Oper:    up  Path:  valid  Signalling: connected

    path option 1,  type dynamic  (Basis for Setup, path weight 1)
    G-PID: 0x0800 (derived from egress interface properties)
```

```
Config Parameters:
    Bandwidth:      1000 kbps (CT0) Priority:  7  7 Affinity: 0x0/0xffff
    Metric Type: TE (default)
    AutoRoute: disabled LockDown: disabled
    Loadshare:      10000 bandwidth-based
    Auto-bw: disabled(0/0) 0 Bandwidth Requested:      0
    Direction: unidirectional
    Endpoint switching capability: unknown, encoding type: unassigned
    Transit switching capability: unknown, encoding type: unassigned
    Backup FRR EXP Demotion: 1 ' 7, 2 ' 1
    Class-Attributes: 1, 2, 7
    Bandwidth-Policer: off
```

```
History:
    Tunnel has been up for: 00:00:08
    Current LSP:
        Uptime: 00:00:08
```

```
Path info (ospf 0 area 0):
    Hop0: 10.0.0.2
    Hop1: 102.0.0.2
    Displayed 1 (of 1) heads, 0 (of 0) midpoints, 0 (of 0) tails
    Displayed 0 up, 1 down, 0 recovering, 0 recovered heads
```

This table describes the significant fields shown in the display.

Table 18: show mpls traffic-eng tunnels Command Field Descriptions

Field	Description
LSP Tunnels Process	Status of the LSP ¹³ tunnels process.
RSVP Process	Status of the RSVP process.
Forwarding	Status of forwarding (enabled or disabled).
Periodic reoptimization	Time, in seconds, until the next periodic reoptimization.
Periodic FRR Promotion	Time, in seconds, till the next periodic FRR ¹⁴ promotion.
Periodic auto-bw collection	Time, in seconds, till the next periodic auto-bw collection.

Field	Description
Name	Interface configured at the tunnel head.
Destination	Tail-end router identifier.
Admin/STATUS	Configured up or down.
Oper/STATE	Operationally up or down.
Signalling	Signaling connected or down or proceeding.
Config Parameters	Configuration parameters provided by tunnel mode MPLS traffic-eng, including those specific to unequal load-balancing functionality (bandwidth, load-share, backup FRR EXP demotion, class-attributes, and bandwidth-policer).
History: Current LSP: Uptime	Time LSP has been up.
Path Info	Hop list of current LSP.

¹³ LSP = Link-State Packet.

¹⁴ FRR = Fast Reroute.

This sample output shows the link attributes of links that are traversed by the tunnel (color information):

```
RP/0/RP0/CPU0:router# show mpls traffic-eng tunnels 11 affinity
```

Signalling Summary:

```

    LSP Tunnels Process: running
    RSVP Process:      running
    Forwarding:         enabled
    Periodic reoptimization: every 3600 seconds, next in 2710 seconds
    Periodic FRR Promotion: every 300 seconds, next in 27 seconds

```

```
Auto-bw enabled tunnels: 0 (disabled)
```

```
Name: tunnel-tell Destination: 3.3.3.3
```

Status:

```
Admin: up Oper: up Path: valid Signalling: connected
```

```

path option 1, type explicit gige_1_2_3 (Basis for Setup, path weight 2)
G-PID: 0x0800 (derived from egress interface properties)
Bandwidth Requested: 200 kbps CT0

```

Config Parameters:

```

Bandwidth: 200 kbps (CT0) Priority: 2 2
Number of affinity constraints: 1
  Include bit map      : 0x4
  Include name         : red2

```

Metric Type: TE (default)

AutoRoute: disabled LockDown: disabled Policy class: not set

Forwarding-Adjacency: disabled

Loadshare: 0 equal loadshares

Auto-bw: disabled

Fast Reroute: Enabled, Protection Desired: Any


```

Path Protection: Not Enabled
History:
Tunnel has been up for: 02:55:27
Current LSP:
  Uptime: 02:02:19
Prior LSP:
  ID: path option 1 [8]
  Removal Trigger: reoptimization completed

Path info (OSPF 100 area 0):
Link0: 12.9.0.1
  Attribute flags: 0x4
  Attribute names: red2
Link1: 23.9.0.2
  Attribute flags: 0x4
  Attribute names: red2

Displayed 1 (of 8) heads, 0 (of 0) midpoints, 0 (of 0) tails
Displayed 1 up, 0 down, 0 recovering, 0 recovered heads

```

This sample output shows the brief summary of the tunnel status and configuration:

RP/0/RP0/CPU0:router# **show mpls traffic-eng tunnels brief**

```

Signalling Summary:
  LSP Tunnels Process: running
  RSVP Process: running
  Forwarding: enabled
  Periodic reoptimization: every 3600 seconds, next in 2538 seconds
  Periodic FRR Promotion: every 300 seconds, next in 38 seconds
  Auto-bw enabled tunnels: 0 (disabled)

```

TUNNEL NAME	DESTINATION	STATUS	STATE
tunnel-te1060	10.6.6.6	up	up
PE6_C12406_t607	10.7.7.7	up	up
PE6_C12406_t608	10.8.8.8	up	up
PE6_C12406_t609	10.9.9.9	up	up
PE6_C12406_t610	10.10.10.10	up	up
PE6_C12406_t621	10.21.21.21	up	up
PE7_C12406_t706	10.6.6.6	up	up
PE7_C12406_t721	10.21.21.21	up	up
Tunnel_PE8-PE6	10.6.6.6	up	up
Tunnel_PE8-PE21	10.21.21.21	up	up
Tunnel_PE9-PE6	10.6.6.6	up	up
Tunnel_PE9-PE21	10.21.21.21	up	up
Tunnel_PE10-PE6	10.6.6.6	up	up
Tunnel_PE10-PE21	10.21.21.21	up	up
PE21_C12406_t2106	10.6.6.6	up	up
PE21_C12406_t2107	10.7.7.7	up	up
PE21_C12406_t2108	10.8.8.8	up	up
PE21_C12406_t2109	10.9.9.9	up	up
PE21_C12406_t2110	10.10.10.10	up	up
PE6_C12406_t6070	10.7.7.7	up	up
PE7_C12406_t7060	10.6.6.6	up	up
tunnel-te1	200.0.0.3	up	up
HundredGigE0/0/0/3	100.0.0.1	up	up
HundredGigE0/0/0/4	200.0.0.1	up	up

```

Displayed 1 (of 1) heads, 20 (of 20) midpoints, 0 (of 0) tails
Displayed 1 up, 0 down, 0 recovering, 0 recovered heads

```

This section shows a sample output that results when automatic backup tunnels are created:

show mpls traffic-eng tunnels

```
RP/0/RP0/CPU0:router# show mpls traffic-eng tunnels brief
```

```
.
.
.
TUNNEL NAME      DESTINATION      STATUS  STATE
      tunnel-te0      200.0.0.3      up    up
      tunnel-te1      200.0.0.3      up    up
      tunnel-te2      200.0.0.3      up    up
      *tunnel-te50     200.0.0.3      up    up
      *tunnel-te60     200.0.0.3      up    up
      *tunnel-te70     200.0.0.3      up    up
      *tunnel-te80     200.0.0.3      up    up
.
.
.
* = automatically created backup tunnel
```

This is sample output that shows a summary of configured tunnels by using the **summary** keyword:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng tunnels summary
```

```
LSP Tunnels Process:  not running, disabled
                      RSVP Process:  running
                      Forwarding:    enabled
Periodic reoptimization: every 3600 seconds, next in 2706 seconds
Periodic FRR Promotion:  every 300 seconds, next in 81 seconds
Periodic auto-bw collection: disabled
```

Signalling Summary:

```
Head: 1 interfaces, 1 active signalling attempts, 1 established
      0 explicit, 1 dynamic
      1 activations, 0 deactivations
      0 recovering, 0 recovered
Mids: 0
Tails: 0
```

Fast ReRoute Summary:

```
Head:    0 FRR tunnels, 0 protected, 0 rerouted
Mid:     0 FRR tunnels, 0 protected, 0 rerouted
Summary: 0 protected, 0 link protected, 0 node protected, 0 bw protected
```

Path Protection Summary:

```
20 standby configured tunnels, 15 connected, 10 path protected
2 link-diverse, 4 node-diverse, 4 node-link-diverse
```

AutoTunnel Backup Summary:

```
AutoTunnel Backups:
      50 created, 50 up, 0 down, 8 unused
      25 NHOP, 25 NNHOP, 10 SRLG strict, 10 SRLG pref
Protected LSPs:
      10 NHOP, 20 NHOP+SRLG
      15 NNHOP, 5 NNHOP+SRLG
Protected S2L Sharing Families:
      10 NHOP, 20 NHOP+SRLG
      15 NNHOP, 5 NNHOP+SRLG
Protected S2Ls:      10 NHOP, 20 NHOP+SRLG
      15 NNHOP, 5 NNHOP+SRLG
```

This is a sample output from the **show mpls traffic-eng tunnels** command using the **protection** keyword. This command selects every MPLS-TE tunnel, known to the router, that was signaled as an FRR-protected LSP (property fast-reroute), and displays information about the protection this router provides to each selected tunnel.

```
RP/0/RP0/CPU0:router# show mpls traffic-eng tunnels protection

tunnel160
  LSP Head, Admin: up, Oper: up
  Src: 10.20.20.20, Dest: 10.10.10.10, Instance: 28
  Fast Reroute Protection: None

tunnel170
  LSP Head, Admin: up, Oper: up
  Src: 10.20.20.20, Dest: 10.10.10.10, Instance: 945
  Fast Reroute Protection: Requested
  Outbound: FRR Ready
  Backup tunnel160 to LSP nhop
    tunnel160: out I/f: HundredGigE0/0/0/3
  LSP signalling info:
    Original: out I/f: HundredGigE0/0/0/4, label: 3, nhop: 10.10.10.10
    With FRR: out I/f: tunnel160, label: 3
  LSP bw: 10 kbps, Backup level: any unlimited, type: CT0
```

This table describes the significant fields shown in the display.

Table 19: show mpls traffic-eng tunnels protection Command Field Descriptions

Field	Description
Tunnel#	Number of the MPLS-TE backup tunnel.
LSP Head/router	Node is either head or router for this LSP ¹⁵ .
Instance	LSP ID.
Backup tunnel	Backup tunnel protection for NHOP/NNHOP.
out if	Backup tunnel's outgoing interface
Original	Outgoing interface, label, and next-hop of the LSP when not using backup.
With FRR	Outgoing interface and label when using backup tunnel.
LSP BW	Signaled bandwidth of the LSP.
Backup level	Type of bandwidth protection provided—pool type and limited/unlimited bandwidth.
LSP Tunnels Process	Status of the TE process ¹⁶ .

¹⁵ LSP = Link-State Packet.

¹⁶ LSP = Label Switched Path

This is sample output from the **show mpls traffic-eng tunnels** command using the **backup** keyword. This command selects every MPLS-TE tunnel known to the router, and displays information about the FRR protection that each selected tunnel provides for interfaces on this route. The command does not generate output for tunnels that do not provide FRR protection of interfaces on this router:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng tunnels backup
```

```
tunnel160
Admin: up, Oper: up
Src: 10.20.20.20, Dest: 10.10.10.10, Instance: 28
Fast Reroute Backup Provided:
Protected I/fs: HundredGigE0/0/0/3
Protected lsps: 0
Backup BW: any-class unlimited, Inuse: 0 kbps
```

This table describes the significant fields shown in the display.

Table 20: show mpls traffic-eng tunnels backup Command Field Descriptions

Field	Description
Tunnel#	MPLS-TE backup tunnel number.
Dest	IP address of backup tunnel destination.
State	State of the backup tunnel. Values are up, down, or admin-down.
Instance	LSP ID of the tunnel.
Protected I/fs	List of interfaces protected by the backup tunnel.
Protected lsps	Number of LSPs currently protected by the backup tunnel.
Backup BW	Configured backup bandwidth type and amount. Pool from which bandwidth is acquired. Values are any-class, CT0, and CT1. Amount is either unlimited or a configured limit in kbps.
Inuse	Backup bandwidth currently in use on the backup tunnel.

This shows a sample output from the **show mpls traffic-eng tunnels** command using the **backup** and **protected-interface** keywords:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng tunnels backup protected-interface
```

```
Interface: HundredGigE0/0/0/3
Tunnel100  UNUSED : out I/f:                Admin: down  Oper: down

Interface: HundredGigE0/0/0/4
Tunnel160   NHOP : out I/f: HundredGigE0/0/0/5  Admin:   up  Oper:   up
```

This table describes the significant fields shown in the display.

Table 21: show mpls traffic-eng tunnels backup protected-interface Command Field Descriptions

Field	Description
Interface	MPLS-TE-enabled FRR protected interface.
Tunnel#	FRR protected tunnel on the interface.

Field	Description
NHOP/NNHOP/UNUSED	State of Protected tunnel. Values are unused, next hop, next-next hop.
out I/f	Outgoing interface of the backup tunnel providing the protection.

This shows a sample output from the **show mpls traffic-eng tunnels** command using the **up within-last** keywords:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng tunnels up within-last 200

Signalling Summary:
    LSP Tunnels Process:  running
    RSVP Process:        running
    Forwarding:          enabled
    Periodic reoptimization: every 3600 seconds, next in 3381 seconds
    Periodic FRR Promotion: every 300 seconds, next in 81 seconds
    Periodic auto-bw collection: disabled

Name: tunnel-tell  Destination: 30.30.30.30
Status:
    Admin:    up Oper:    up  Path:  valid  Signalling: connected

    path option 1, type explicit back (Basis for Setup, path weight 1)
G-PID: 0x0800 (derived from egress interface properties)

Config Parameters:
    Bandwidth:      0 kbps (CT0) Priority:  7  7 Affinity: 0x0/0xffff
    Number of configured name based affinities: 2
    Name based affinity constraints in use:
        Include bit map      : 0x4 (refers to undefined affinity name)
        Include-strict bit map: 0x4
Metric Type: TE (default)
    AutoRoute: disabled LockDown: disabled Loadshare:      0 bw-based
    Auto-bw: disabled(0/0) 0 Bandwidth Requested:      0
    Direction: unidirectional
Endpoint switching capability: unknown, encoding type: unassigned
Transit switching capability: unknown, encoding type: unassigned

History:
    Tunnel has been up for: 00:00:21
    Current LSP:
        Uptime: 00:00:21
    Prior LSP:
        ID: path option 1 [4]
        Removal Trigger: tunnel shutdown

Path info (ospf  area 0):
Hop0: 7.4.4.2
Hop1: 30.30.30.30

Displayed 1 (of 3) heads, 0 (of 0) midpoints, 0 (of 0) tails
Displayed 1 up, 0 down, 0 recovering, 0 recovered heads
```

This shows a sample output from the **show mpls traffic-eng tunnels** command using the **reoptimized within-last** keywords:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng tunnels reoptimized within-last 600

Signalling Summary:
```

show mpls traffic-eng tunnels

```

        LSP Tunnels Process:  running
        RSVP Process:        running
        Forwarding:          enabled
        Periodic reoptimization: every 60000 seconds, next in 41137 seconds
        Periodic FRR Promotion: every 300 seconds, next in 37 seconds
        Periodic auto-bw collection: disabled

Name: tunnel-te1  Destination: 30.30.30.30
Status:
  Admin:    up Oper:    up  Path:  valid  Signalling: connected

  path option 1, type explicit prot1 (Basis for Setup, path weight 1)
G-PID: 0x0800 (derived from egress interface properties)

Config Parameters:
  Bandwidth:      66 kbps (CT0) Priority:  7  7 Affinity: 0x0/0xffff
  Metric Type:    IGP (global)
  AutoRoute:      enabled LockDown: disabled Loadshare:      66 bw-based
  Auto-bw: disabled(0/0) 0 Bandwidth Requested:      66
  Direction:      unidirectional
Endpoint switching capability: unknown, encoding type: unassigned
Transit switching capability: unknown, encoding type: unassigned

History:
  Tunnel has been up for: 00:14:04
  Current LSP:
    Uptime: 00:03:52
    Selection: reoptimization
  Prior LSP:
    ID: path option 1 [2017]
    Removal Trigger: reoptimization completed

Path info (ospf area 0):
Hop0: 7.2.2.2
Hop1: 7.3.3.2
Hop2: 30.30.30.30
Displayed 1 (of 1) heads, 0 (of 0) midpoints, 0 (of 0) tails
Displayed 1 up, 0 down, 0 recovering, 0 recovered heads

```

This is a sample output from the **show mpls traffic-eng tunnels** command using the **detail** keyword:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng tunnels 100 detail
```

```

Name: tunnel-te1  Destination: 24.24.24.24
Status:
  Admin:    up Oper:    up

  Working Path:  valid  Signalling: connected
  Protecting Path:  valid  Protect Signalling: connected
  Working LSP is carrying traffic

  path option 1, type explicit po4 (Basis for Setup, path weight 1)
  (Basis for Standby, path weight 2)
G-PID: 0x001d (derived from egress interface properties)
Path protect LSP is present.

  path option 1, type explicit po6 (Basis for Setup, path weight 1)

Config Parameters:
  Bandwidth:      10 kbps (CT0) Priority:  7  7 Affinity: 0x0/0xffff
  Metric Type:    TE (default)
  AutoRoute:      enabled LockDown: disabled Loadshare:      10 bw-based
  Auto-bw: disabled(0/0) 0 Bandwidth Requested:      10

```

```

Direction: unidirectional
Endpoint switching capability: unknown, encoding type: unassigned
Transit switching capability: unknown, encoding type: unassigned

History:
Tunnel has been up for: 00:04:06
Current LSP:
  Uptime: 00:04:06
  Prior LSP:
    ID: path option 1 [5452]
    Removal Trigger: path verification failed
Current LSP Info:
  Instance: 71, Signaling Area: ospf optical area 0
  Uptime: 00:10:41
  Incoming Label: explicit-null
  Outgoing Interface: HundredGigE0/0/0/3, Outgoing Label: implicit-null
  Path Info:
    Explicit Route:
      Strict, 100.0.0.3
      Strict, 24.24.24.24
    Record Route: None
    Tspec: avg rate=2488320 kbits, burst=1000 bytes, peak rate=2488320 kbits
Resv Info:
  Record Route:
    IPv4 100.0.0.3, flags 0x0
    Fspec: avg rate=2488320 kbits, burst=1000 bytes, peak rate=2488320 kbits
Protecting LSP Info:
  Instance: 72, Signaling Area: ospf optical area 0
  Incoming Label: explicit-null
  Outgoing Interface: HundredGigE0/0/0/4, Outgoing Label: implicit-null
  Path Info:
    Explicit Route:
      Strict, 101.0.0.3
      Strict, 24.24.24.24
    Record Route: None
    Tspec: avg rate=2488320 kbits, burst=1000 bytes, peak rate=2488320 kbits
Resv Info:
  Record Route:
    IPv4 101.0.0.3, flags 0x0
    Fspec: avg rate=2488320 kbits, burst=1000 bytes, peak rate=2488320 kbits
Reoptimized LSP Info (Install Timer Remaining 11 Seconds):
Cleaned LSP Info (Cleanup Timer Remaining 19 Seconds):

```

This is a sample output that shows the path-protection options for tunnel-te 100 using the **detail** keyword.

```
RP/0/RP0/CPU0:router# show mpls traffic-eng tunnels 100 detail
```

```

Signalling Summary:
  LSP Tunnels Process: running
  RSVP Process: running
  Forwarding: enabled
  Periodic reoptimization: every 60 seconds, next in 31 seconds
  Periodic FRR Promotion: every 300 seconds, next in 299 seconds
  Auto-bw enabled tunnels: 0 (disabled)

Name: tunnel-te100 Destination: 33.3.33.3
Status:
  Admin: up Oper: up (Up for 02:06:14)
  Path: valid Signalling: connected

Path options:

```

show mpls traffic-eng tunnels

```

path-option 5 explicit name to-gmpl3 verbatim lockdown OSPF 0 area 0
  PCALC Error [Standby]: Wed Oct 15 15:53:24 2008
  Info: Destination IP address, 1.2.3.4, not found in topology
path-option 10 dynamic
path option 15 explicit name div-wrt-to-gmpl3 verbatim
path option 20 dynamic standby OSPF 0 area 0
  (Basis for Standby, path weight 2)
G-PID: 0x0800 (derived from egress interface properties)
Bandwidth Requested: 0 kbps CT0

Config Parameters:
  Bandwidth:          0 kbps (CT0) Priority:  7  7 Affinity: 0x0/0xffff
  Metric Type: TE (default)
  AutoRoute: disabled LockDown: disabled
  Loadshare:         0 equal loadshares
  Auto-bw: disabled(0/0) 0 Bandwidth Requested: 0
  Direction: unidirectional
  Endpoint switching capability: unknown, encoding type: unassigned
  Transit switching capability: unknown, encoding type: unassigned
  Path Protection: enabled

Reoptimization Info in Inter-area:
  Better Path Queries sent = 13; Preferred Path Exists received = 0
  Last better path query was sent 00:08:22 ago
  Last preferred path exists was received 00:00:00 ago

History:
  Tunnel has been up for: 02:15:56
  Current LSP:
    Uptime: 02:15:56
  Prior LSP:
    ID: path option 10 [22]
    Removal Trigger: path verification failed
  Current LSP Info:

    Bandwidth:          0 kbps (CT0) Priority:  7  7 Affinity: 0x0/0xffff
    Metric Type: TE (default)
    AutoRoute: disabled LockDown: disabled Policy class: not set
    Loadshare:         0 equal loadshares
    Auto-bw: disabled
    Direction: unidirectional
    Endpoint switching capability: unknown, encoding type: unassigned
    Transit switching capability: unknown, encoding type: unassigned
    Fast Reroute: Disabled, Protection Desired: None
  Reoptimization Info in Inter-area:
    Better Path Queries sent = 13; Preferred Path Exists received = 0
    Last better path query was sent 00:08:22 ago
    Last preferred path exists was received 00:00:00 ago
  Path Protection Info:
    Standby Path: Node and Link diverse Last switchover 00:08:22 ago
    Switchover Reason: Path delete request
    Number of Switchovers 13, Standby Ready 15 times

History:
  Prior LSP:
    ID: path option 10 [188]
    Removal Trigger: path option removed
  Tunnel has been up for: 00:03:58
  Current LSP:
    Uptime: 00:03:58
  Reopt. LSP:
    Setup Time: 272 seconds
  Current LSP Info:
    Instance: 1, Signaling Area: OSPF 0 area 0

```



```

Uptime: 00:03:58
Outgoing Interface: HundredGigE0/0/0/3, Outgoing Label: implicit-null
Router-IDs: local      222.22.2.2
            downstream 33.3.33.3
Path Info:
  Outgoing:
    Explicit Route:
      Strict, 23.0.0.3
      Strict, 33.3.33.3
    Record Route: None
    Tspec: avg rate=0 kbits, burst=1000 bytes, peak rate=0 kbits
    Session Attributes: Local Prot: Not Set, Node Prot: Not Set, BW Prot: Not Set
Resv Info:
  Record Route: None
  Fspec: avg rate=0 kbits, burst=1000 bytes, peak rate=0 kbits
Standby LSP Info:
  Instance: 1, Signaling Area: OSPF 0 area 0
  Uptime: 00:03:58
  Outgoing Interface: HundredGigE0/0/0/3, Outgoing Label: implicit-null
  Router-IDs: local      222.22.2.2
            downstream 33.3.33.3
  Path Info:
    Outgoing:
      Explicit Route:
        Strict, 23.0.0.3
        Strict, 33.3.33.3
      Record Route: None
      Tspec: avg rate=0 kbits, burst=1000 bytes, peak rate=0 kbits
      Session Attributes: Local Prot: Not Set, Node Prot: Not Set, BW Prot: Not Set
  Resv Info:
    Record Route: None
    Fspec: avg rate=0 kbits, burst=1000 bytes, peak rate=0 kbits
Reoptimized LSP Info:
  Instance: 5, Signaling Area: OSPF 0 area 0
  Outgoing Interface: HundredGigE0/0/0/4, Outgoing Label: 16000
  Path Info:
    Outgoing:
      Explicit Route:
        Strict, 26.0.0.6
        Strict, 36.0.0.3
        Strict, 33.3.33.3
      Record Route: None
      Tspec: avg rate=0 kbits, burst=1000 bytes, peak rate=0 kbits
      Session Attributes: Local Prot: Not Set, Node Prot: Not Set, BW Prot: Not Set
  Resv Info:
    Record Route: None
    Fspec: avg rate=0 kbits, burst=1000 bytes, peak rate=0 kbits
Delayed Clean Standby LSP Info:
  Instance: 1, Signaling Area: OSPF 0 area 0
  Uptime: 00:03:58
  Outgoing Interface: HundredGigE0/0/0/3, Outgoing Label: implicit-null
  Router-IDs: local      222.22.2.2
            downstream 33.3.33.3
  Path Info:
    Outgoing:
      Explicit Route:
        Strict, 23.0.0.3
        Strict, 33.3.33.3
      Record Route: None
      Tspec: avg rate=0 kbits, burst=1000 bytes, peak rate=0 kbits
      Session Attributes: Local Prot: Not Set, Node Prot: Not Set, BW Prot: Not Set
  Resv Info:
    Record Route: None
    Fspec: avg rate=0 kbits, burst=1000 bytes, peak rate=0 kbits

```

show mpls traffic-eng tunnels

Displayed 0 (of 2) heads, 0 (of 0) midpoints, 0 (of 0) tails
 Displayed 0 up, 0 down, 0 recovering, 0 recovered heads

This is a sample output from the **show mpls traffic-eng tunnels** command using the **role mid** keyword:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng tunnels role mid

Signalling Summary:
    LSP Tunnels Process: running
    RSVP Process: running
    Forwarding: enabled
    Periodic reoptimization: every 3600 seconds, next in 1166 seconds
    Periodic FRR Promotion: every 300 seconds, next in 90 seconds
    Periodic auto-bw collection: disabled
LSP Tunnel 10.10.10.10 1 [5508] is signalled, connection is up
Tunnel Name: FRR1_t1 Tunnel Role: Mid
InLabel: HundredGigE0/0/0/3, 33
OutLabel: HundredGigE0/0/0/4, implicit-null
Signalling Info:
    Src 10.10.10.10 Dst 30.30.30.30, Tunnel ID 1, Tunnel Instance 5508
    Path Info:1
        Incoming Address: 7.3.3.1
Incoming Explicit Route:
    Strict, 7.3.3.1
    Loose, 30.30.30.30
ERO Expansion Info:
    ospf 100 area 0, Metric 1 (TE), Affinity 0x0, Mask 0xffff, Queries 0
    Outgoing Explicit Route:
        Strict, 7.2.2.1
        Strict, 30.30.30.30
Record Route: None
    Tspec: avg rate=10 kbits, burst=1000 bytes, peak rate=10 kbits
Resv Info:
    Record Route:
        IPv4 30.30.30.30, flags 0x20
        Label 3, flags 0x1
        IPv4 7.3.3.2, flags 0x0
        Label 3, flags 0x1
    Fspec: avg rate=10 kbits, burst=1000 bytes, peak rate=10 kbits
Displayed 0 (of 1) heads, 1 (of 1) midpoints, 0 (of 1) tails
Displayed 0 up, 0 down, 0 recovering, 0 recovered heads
```

This sample output shows a tabular table for TE LSPs by using the **tabular** keyword:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng tunnels tabular
```

Tunnel Name	LSP ID	Destination Address	Source Address	Tun State	FRR State	LSP Role
tunnel-mte100	1	2.2.2.2	60.60.60.60	up	Inact	Head
tunnel-mte300	1	60.60.60.60	2.2.2.2	up	Inact	Tail
tunnel-te1060	2	10.6.6.6	10.1.1.1	up	Inact	Head
PE6_C12406_t607	2	10.7.7.7	10.6.6.6	up	Inact	Mid
PE6_C12406_t608	2	10.8.8.8	10.6.6.6	up	Inact	Mid
PE6_C12406_t609	2	10.9.9.9	10.6.6.6	up	Inact	Mid
PE6_C12406_t610	2	10.10.10.10	10.6.6.6	up	Inact	Mid
PE6_C12406_t621	2	10.21.21.21	10.6.6.6	up	Inact	Mid
PE7_C12406_t706	835	10.6.6.6	10.7.7.7	up	Inact	Mid
PE7_C12406_t721	603	10.21.21.21	10.7.7.7	up	Inact	Mid
Tunnel_PE8-PE6	4062	10.6.6.6	10.8.8.8	up	Inact	Mid

```

Tunnel_PE8-PE21    6798    10.21.21.21    10.8.8.8    up    Inact    Mid
Tunnel_PE9-PE6     4062    10.6.6.6      10.9.9.9    up    Inact    Mid
Tunnel_PE9-PE21    6795    10.21.21.21    10.9.9.9    up    Inact    Mid
Tunnel_PE10-PE6    4091    10.6.6.6      10.10.10.10 up    Inact    Mid
Tunnel_PE10-PE21   6821    10.21.21.21    10.10.10.10 up    Inact    Mid
PE21_C12406_t2106  2       10.6.6.6      10.21.21.21 up    Ready   Mid
PE21_C12406_t2107  2       10.7.7.7      10.21.21.21 up    Inact    Mid
PE21_C12406_t2108  2       10.8.8.8      10.21.21.21 up    Inact    Mid
PE21_C12406_t2109  2       10.9.9.9      10.21.21.21 up    Inact    Mid
PE21_C12406_t2110  2       10.10.10.10   10.21.21.21 up    Inact    Mid
PE6_C12406_t6070   2       10.7.7.7      10.6.6.6    up    Inact    Mid
PE7_C12406_t7060   626     10.6.6.6      10.7.7.7    up    Inact    Mid
tunnel-te1         1       200.0.0.3     200.0.0.1   up    Inact    Head InAct
tunnel-te100        1       200.0.0.3     200.0.0.1   up    Ready   Head InAct
HundredGigE0/0/0/3  2       100.0.0.1     200.0.0.1   up    Inact    Head InAct
HundredGigE0/0/0/4  6       200.0.0.1     100.0.0.1   up    Inact    Tail InAct

```

This sample output shows a tabular table indicating automatic backup tunnels when using the **tabular** keyword:

RP/0/RP0/CPU0:router# **show mpls traffic-eng tunnels tabular**

Tunnel Name	LSP ID	Destination Address	Source Address	State	FRR State	LSP Role	Path Prot
tunnel-te0	549	200.0.0.3	200.0.0.1	up	Inact	Head	InAct
tunnel-te1	546	200.0.0.3	200.0.0.1	up	Inact	Head	InAct
tunnel-te2	6	200.0.0.3	200.0.0.1	up	Inact	Head	InAct
*tunnel-te50	6	200.0.0.3	200.0.0.1	up	Active	Head	InAct
*tunnel-te60	4	200.0.0.3	200.0.0.1	up	Active	Head	InAct
*tunnel-te70	4	200.0.0.3	200.0.0.1	up	Active	Head	InAct
*tunnel-te80	3	200.0.0.3	200.0.0.1	up	Active	Head	InAct

* = automatically created backup tunnel

This table describes the significant fields shown in the display.

Table 22: show mpls traffic-eng tunnels tabular Command Field Descriptions

Field	Description
Tunnel Name	MPLS-TE tunnel name.
LSP ID	LSP ID of the tunnel.
Destination Address	Destination address of the TE tunnel (identified in Tunnel Name).
Source Address	Source address for the filtered tunnels.
Tunnel State	State of the tunnel. Values are up, down, or admin-down.
FRR State	FRR state identifier.
LSP Role	Role identifier. Values are All, Head, or Tail.

This sample output shows a path protection for tunnel ID 10:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng tunnels protection path tunnel-id 10

Tun ID 10, Src 22.2.22.2 Dst 66.6.66.6, Ext ID 22.2.22.2
  Switchover 00:08:22 ago, Standby Path: {Not found | Link diverse | Node diverse | Node
and Link diverse}
  Current LSP: LSP ID 10022, Up time 12:10:24,
    Local lbl: 16001, Out Interface: HundredGigE0/0/0/3, Out lbl: implicit-null
    Path: 1.1.1.1, 2.2.2.2, 3.3.3.3, 8.8.8.8
  Standby LSP: None | LSP ID, Up time 12:00:05,
    Local lbl: 16002, Out Interface: HundredGigE0/0/0/4, Out lbl: implicit-null
    Path 4.4.4.4, 5.5.5.5, 6.6.6.6, 7.7.7.7
```

This sample output shows the path protection in a tabular format:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng tunnels protection path tabular
```

Tunnel ID	Current LSP ID	Standby LSP ID	Protected State	Standby Diversity
155	10	11	Ready	Node and Link Diverse
1501	11	12	Ready	Node and Link Diverse
1502	10	11	Ready	Node and Link Diverse
1504	10	11	Ready	Node and Link Diverse
1505	10	11	Ready	Node and Link Diverse

This table describes the significant fields shown in the display.

Table 23: show mpls traffic-eng tunnels protection path tabular Command Field Descriptions

Field	Description
Tunnel ID	Identifier of the tunnel.
Current LSP ID	Identifier of the LSP that is carrying traffic.
Standby LSP ID	Identifier of the standby LSP that is protecting traffic.
Protected State	Values are Ready and Not Ready.
Standby Diversity	Values are Node and Link Diverse along with Node Diverse and Link Diverse. Values that state that the current and standby LSP do not have nodes or links in common. The current and standby LSP do not have nodes in common (but can share a link), or they have no links in common (but can share nodes).

This sample output shows the MPLS-TE tunnel information only for tunnels in which the automatic bandwidth is enabled using the **auto-bw** keyword:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng tunnels auto-bw

Signalling Summary:
  LSP Tunnels Process: running
  RSVP Process: running
  Forwarding: enabled
  Periodic reoptimization: every 3600 seconds, next in 636 seconds
  Periodic FRR Promotion: every 300 seconds, next in 276 seconds
  Auto-bw enabled tunnels: 1

Name: tunnel-te1 Destination: 0.0.0.0
```

```

Status:
  Admin:      up Oper: down  Path: not valid  Signalling: Down
  G-PID: 0x0800 (internally specified)
  Bandwidth Requested: 0 kbps  CT0

Config Parameters:
  Bandwidth:      0 kbps (CT0) Priority:  7  7 Affinity: 0x0/0xffff
  Metric Type: TE (default)
  AutoRoute: disabled LockDown: disabled  Policy class: not set
  Loadshare:      0 equal loadshares
Auto-bw: (collect bw only)
  Last BW Applied: 500 kbps (CT0)  BW Applications: 25
  Last Application Trigger: Periodic Application
  Bandwidth Min/Max: 10-10900 kbps
  Application Frequency: 10 min (Cfg: 10 min)  Time Left: 5m 34s
  Collection Frequency: 2 min
  Samples Collected: 2  Highest BW: 450 kbps  Next: 1m 34s
  Adjustment Threshold: 5%
  Overflow Threshold: 15%  Limit: 1/4  Early BW Applications: 0
  Direction: unidirectional
  Endpoint switching capability: unknown, encoding type: unassigned
  Transit switching capability: unknown, encoding type: unassigned
  Fast Reroute: Disabled, Protection Desired: None

Reason for the tunnel being down: No destination is configured
History:
  Displayed 1 (of 1) heads, 0 (of 0) midpoints, 0 (of 0) tails
  Displayed 0 up, 1 down, 0 recovering, 0 recovered heads

```

This table describes the significant fields shown in the display.

Table 24: show mpls traffic-eng tunnels auto-bw Command Field Descriptions

Field	Description
collect bw only	Field is displayed only if the bandwidth collection is configured in the tunnel automatic bandwidth configuration.
Last BW Applied	Last bandwidth change that is requested by the automatic bandwidth for the tunnel. In addition, this field indicates which pool is used for the bandwidth.
BW Applications	Total number of bandwidth applications that is requested by the automatic bandwidth, which includes the applications triggered by an overflow condition.
Last Application Trigger	These last application options are displayed: • Periodic Application • Overflow Detected • Manual Application
Bandwidth Min/Max	Bandwidth configured is either minimum or maximum.
Application Frequency	Configured application frequency. The Time Left field indicates the time left before the next application executes.
Collection Frequency	Globally configured collection frequency, which is the same value for all the tunnels.

Field	Description
Samples Collected	Number of samples that are collected during the current application period. This field is replaced by the Collection Disabled field if Collection Frequency is not currently configured.
Highest BW	Highest bandwidth that is collected for the application period.
Next	Time left before the next collection event.
Overflow Threshold	Overflow threshold that is configured. The Overflow field appears only if the overflow detection is configured in the tunnel automatic bandwidth configuration.
Limit	Consecutive overflow detected or configured limit.
Early BW Applications	Number of early bandwidth applications that are triggered by an overflow condition.

This is sample output from the **show mpls traffic-eng tunnels** command after the NNHOP SRLG preferred automatic backup tunnel is configured:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng tunnels 1
```

Signalling Summary:

```

    LSP Tunnels Process:  running
    RSVP Process:        running
    Forwarding:          enabled
    Periodic reoptimization: every 3600 seconds, next in 2524 seconds
    Periodic FRR Promotion: every 300 seconds, next in 49 seconds
    Auto-bw enabled tunnels: 1

```

Name: tunnel-tel Destination: 200.0.0.3 (auto backup)

Status:

```
Admin:    up Oper:    up Path:  valid Signalling: connected
```

path option 10, type explicit (autob_nnhop_srlg_tunnel1) (Basis for Setup, path weight 11)

```

path option 20, type explicit (autob_nnhop_tunnel1)
G-PID: 0x0800 (derived from egress interface properties)
Bandwidth Requested: 0 kbps CT0
Creation Time: Fri Jul 10 01:53:25.581 PST (1h 25m 17s ago)

```

Config Parameters:

```

Bandwidth:      0 kbps (CT0) Priority:  7 7 Affinity: 0x0/0xffff
Metric Type: TE (default)
AutoRoute: disabled LockDown: disabled Policy class: not set
Forwarding-Adjacency: disabled

```

Loadshare: 0 equal loadshares

```

Auto-bw: disabled
Fast Reroute: Disabled, Protection Desired: None
Path Protection: Not Enabled

```

Auto Backup:

```

Protected LSPs: 4
Protected S2L Sharing Families: 0
Protected S2Ls: 0
Protected i/f: HundredGigE0/0/0/2 Protected node: 20.0.0.2
Protection: NNHOP+SRLG
Unused removal timeout: not running

```

History:

```
Tunnel has been up for: 00:00:08
```

```

Current LSP:
  Uptime: 00:00:08
Prior LSP:
  ID: path option 1 [545]
  Removal Trigger: configuration changed

```

```

Path info (OSPF 0 area 0):
Hop0: 10.0.0.2
Hop1: 100.0.0.2
Hop2: 100.0.0.3
Hop3: 200.0.0.3

```

This table describes the significant fields shown in the display.

Table 25: show mpls traffic-eng tunnels Command Field Descriptions

Field	Description
Auto Backup	Auto backup section header.
Creation Time	Time when the tunnel was created and for what period was the tunnel created.
Protected LSPs	Number of ready and active LSPs protected by this backup.
Protected S2L Sharing Families	Number of ready and active sharing families protected by this backup.
Protected S2Ls	Number of ready and active primary tunnels protected by this backup.
Protected i/f Protected node	Interface and NNHOP node protected by this backup.
Protection: NNHOP+SRLG	Type of protection provided by this backup. Note Protection can be different when a preferred SRLG is configured and an SRLG path is not found.
Example when backup is in use: Unused removal timeout: not running Example when backup is unused: Unused removal timeout: 1h26m	Amount of time left before the unused removal timeout expires. This timer only runs when the backup is in the unused state. After the timer expires, the automatic backup tunnel is removed.

This is sample output from the **show mpls traffic-eng tunnels** command using the **detail** keyword:

```

RP/0/RP0/CPU0:router# show mpls traffic-eng tunnels 999 detail

Name: tunnel-te999  Destination: 1.1.1.1
Status:
  Admin:    up Oper:    up  Path:  valid  Signalling: connected

  path option 1, type dynamic (Basis for Setup, path weight 2)
  Path-option attribute: po
    Number of affinity constraints: 2
      Include bit map      : 0x4
      Include name         : blue
      Exclude bit map      : 0x2
      Exclude name         : red

```

show mpls traffic-eng tunnels

```

    Bandwidth: 300 (CT0)
    G-PID: 0x0800 (derived from egress interface properties)
    Bandwidth Requested: 300 kbps CT0
    Creation Time: Fri Jan 14 23:35:58 2017 (00:00:42 ago)
Config Parameters:
    Bandwidth: 100 kbps (CT0) Priority: 7 7 Affinity: 0x0/0xffff
    Metric Type: TE (default)
    Hop-limit: disabled
    AutoRoute: disabled LockDown: disabled Policy class: not set
    Forwarding-Adjacency: disabled
    Loadshare: 0 equal loadshares
    Auto-bw: disabled
    Fast Reroute: Enabled, Protection Desired: Any
    Path Protection: Not Enabled
    Soft Preemption: Disabled
SNMP Index: 42
History:
    Tunnel has been up for: 00:00:30 (since Fri Jan 14 23:36:10 EST 2017)
    Current LSP:
        Uptime: 00:00:30 (since Fri Jan 14 23:36:10 EST 2017)
Current LSP Info:
    Instance: 2, Signaling Area: OSPF 100 area 16909060
    Uptime: 00:00:30 (since Fri Jan 14 23:36:10 EST 2017)
    Outgoing Interface: HundredGigE0/0/0/4, Outgoing Label: 16005
    Router-IDs: local 3.3.3.3
                downstream 2.2.2.2
    Soft Preemption: None
    Path Info:
        Outgoing:
            Explicit Route:
                Strict, 23.9.0.2
                Strict, 12.9.0.2
                Strict, 12.9.0.1
                Strict, 1.1.1.1

    Record Route: Disabled
    Tspec: avg rate=300 kbits, burst=1000 bytes, peak rate=300 kbits
    Session Attributes: Local Prot: Set, Node Prot: Not Set, BW Prot: Not Set
                        Soft Preemption Desired: Not Set
Resv Info:
    Record Route:
        IPv4 2.2.2.2, flags 0x20
        Label 16005, flags 0x1
        IPv4 23.9.0.2, flags 0x0
        Label 16005, flags 0x1
        IPv4 1.1.1.1, flags 0x20
        Label 3, flags 0x1
        IPv4 12.9.0.1, flags 0x0
        Label 3, flags 0x1
    Fspec: avg rate=300 kbits, burst=1000 bytes, peak rate=300 kbits Displayed 1 (of 8)
heads, 0 (of 3) midpoints, 0 (of 0) tails Displayed 1 up, 0 down, 0 recovering, 0 recovered
heads

```

This is sample output from the **show mpls traffic-eng tunnels** command using the **auto-tunnel backup** keywords:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng tunnels auto-tunnel backup
```

```

AutoTunnel Backup Configuration:
  Interfaces count: 30
  Unused removal timeout: 2h
  Configured tunnel number range: 0-100

```



```

AutoTunnel Backup Summary:
    50 created, 50 up, 0 down, 8 unused
    25 NHOP, 25 NNHOP, 10 SRLG strict, 10 SRLG pref
Protected LSPs:
    10 NHOP, 20 NHOP+SRLG
    15 NNHOP, 5 NNHOP+SRLG
Protected S2L Sharing Families:
    10 NHOP, 20 NHOP+SRLG
    15 NNHOP, 5 NNHOP+SRLG
Protected S2Ls:
    10 NHOP, 20 NHOP+SRLG
    15 NNHOP, 5 NNHOP+SRLG

Cumulative Counters (last cleared 1h ago):
      Total      NHOP      NNHOP
Created:         550        300        250
Connected:       500        250        250
Removed (down):    0          0          0
Removed (unused): 200        100        100
Removed (in use):  0          0          0
Range exceeded:   0          0          0

```

This table describes the significant fields shown in the display.

Table 26: show mpls traffic-eng tunnels auto-tunnel backup Command Field Descriptions

Field	Description
AutoTunnel Backup Configuration	Header for the automatic tunnel backup configuration.
Interfaces count	Number of interfaces that have automatic tunnel backup enabled.
Unused removal timeout	Configured value and time left before expiration of the unused removal timeout attribute.
Configured tunnel number range	Configured tunnel number range.
AutoTunnel Backup Summary	Header for the automatic tunnel backup summary information.
50 created	Number of automatic backup tunnels created.
50 up	Number of automatic backup tunnels in the up state.
0 down	Number of automatic backup tunnels in the down state.
8 unused	Number of automatic backup tunnels in the unused state.
25 NHOP	Number of automatic backup tunnels created for NHOP protection.
25 NNHOP	Number of automatic backup tunnels created for NNHOP protection.
10 SRLG strict	Number of automatic backup tunnels created with the SRLG preferred attribute.

Field	Description
10 SRLG pref	Number of automatic backup tunnels created with the SRLG preferred attribute.
Protected LSPs Protected S2L Sharing Families Protected S2Ls	Headings for summary information showing current status of LSPs, S2L Sharing Families, and S2Ls that are protected by the automatic tunnel backups. Numbers include primary tunnels in FRR ready and active state.
10 NHOP	Number of automatic backup tunnels that are link protected.
20 NHOP+SRLG	Number of automatic backup tunnels that are link protected and using an SRLG diverse backup path.
15 NNHOP	Number of automatic backup tunnels that are node protected.
20 NNHOP+SRLG	Number of automatic backup tunnels that are node protected and use an SRLG diverse backup path.
Cumulative Counters (last cleared 1h ago):	Cumulative counters for automatic backup tunnels.
Headers: Total, NHOP, NNHOP	Total number of counters and breakdown of NHOP and NNHOP counters.
Created:	Cumulative number of created automatic backup tunnels since the last counter was cleared.
Connected:	Cumulative number of the connected automatic backup tunnels since the last counter was cleared. Note Counter increments only the first time that a tunnel connects.
Removed (down/unused/in use)	Number of automatic backup tunnels that are removed based on state.
Range exceeded	Number of automatic backup tunnels attempted and later rejected when the total number exceeds the configured range.

This is sample output from the **show mpls traffic-eng tunnels name tunnel-te1 detail** command, which displays the soft preemption information for the tunnel-te1 tunnel:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng tunnels name tunnel-te1 detail
Name: tunnel-te1 Destination: 192.168.0.4
Status:
  Admin:      up Oper:      up Path:  valid Signalling: connected

  path option 1, type explicit ABC1 (Basis for Setup, path weight 2)
  Last PCALC Error [Reopt]: Fri Jan 13 16:40:24 2017
  Info: Can't reach 10.10.10.2 on 192.168.0.2, from node 192.168.0.1 (bw)
```

```

Last Signalled Error: Fri Jan 13 16:38:53 2017
  Info: [2] PathErr(34,1)-(reroute, flow soft-preempted) at 10.10.10.1
G-PID: 0x0800 (derived from egress interface properties)
Bandwidth Requested: 30000 kbps CT0
Creation Time: Thu Jan 13 15:46:45 2017 (00:53:44 ago)
Config Parameters:
  Bandwidth: 30000 kbps (CT0) Priority: 7 7 Affinity: 0x0/0xffff
  Metric Type: TE (default)
  Hop-limit: disabled
  AutoRoute: enabled LockDown: disabled Policy class: not set
  Forwarding-Adjacency: disabled
  Loadshare: 0 equal loadshares
  Auto-bw: disabled
  Fast Reroute: Enabled, Protection Desired: Any
  Path Protection: Not Enabled
  Soft Preemption: Enabled
Soft Preemption:
  Current Status: Preemption pending
  Last Soft Preemption: Fri Jan 13 16:38:53 2017 (00:01:36 ago)
  Addresses of preempting links:
    10.10.10.1: Fri Jan 13 16:38:53 2017 (00:01:36 ago)
  Duration in preemption pending: 96 seconds
  Preemption Resolution: Pending
Stats:
  Number of preemption pending events: 1
  Min duration in preemption pending: 0 seconds
  Max duration in preemption pending: 0 seconds
  Average duration in preemption pending: 0 seconds
  Resolution Counters: 0 reopt complete, 0 torn down
                      0 path protection switchover
SNMP Index: 9
History:
  Tunnel has been up for: 00:52:46 (since Thu Jan 13 15:47:43 EDT 2017)
  Current LSP:
    Uptime: 00:52:46 (since Thu Jan 13 15:47:43 EDT 2017)
  Reopt. LSP:
    Last Failure:
      LSP not signalled, has no S2Ls
      Date/Time: Thu Jan 13 16:40:24 EDT 2017 [00:00:05 ago]
  Prior LSP:
    ID: path option 1 [2]
    Removal Trigger: path error
Current LSP Info:
  Instance: 2, Signaling Area: OSPF ring area 0
  Uptime: 00:52:46 (since Thu Jan 13 15:47:43 EDT 2017)
  Outgoing Interface: HundredGigE0/0/0/3, Outgoing Label: 16002
  Router-IDs: local 192.168.0.1
               downstream 192.168.0.2
  Soft Preemption: Pending
    Preemption Link: HundredGigE0/0/0/3; Address: 10.10.10.1
    Preempted at: Fri Jan 13 16:38:53 2017 (00:01:36 ago)
    Time left before hard preemption: 204 seconds
  Path Info:
    Outgoing:
      Explicit Route:
        Strict, 10.10.10.2
        Strict, 14.14.14.2
        Strict, 14.14.14.4
        Strict, 192.168.0.4
      Record Route: Empty
    Tspec: avg rate=30000 kbits, burst=1000 bytes, peak rate=30000 kbits
    Session Attributes: Local Prot: Set, Node Prot: Not Set, BW Prot: Not Set
                      Soft Preemption Desired: Set
  Resv Info:

```

show mpls traffic-eng tunnels

```

Record Route:
  IPv4 192.168.0.2, flags 0x20
  Label 16002, flags 0x1
  IPv4 10.10.10.2, flags 0x0
  Label 16002, flags 0x1
  IPv4 192.168.0.4, flags 0x20
  Label 3, flags 0x1
  IPv4 14.14.14.4, flags 0x0
  Label 3, flags 0x1
  Fspec: avg rate=30000 kbits, burst=1000 bytes, peak rate=30000 kbits
Displayed 1 (of 4) heads, 0 (of 0) midpoints, 0 (of 2) tails
Displayed 1 up, 0 down, 0 recovering, 0 recovered heads

```

This is sample output from the **show mpls traffic-eng tunnels** command with the **mesh** keyword:

```

RP/0/RP0/CPU0:router# show mpls traffic-eng tunnels auto-tunnel
Signalling Summary:
    LSP Tunnels Process:  running
    RSVP Process:        running
    Forwarding:          enabled
    Periodic reoptimization: every 3600 seconds, next in 3098 seconds
    Periodic FRR Promotion: every 300 seconds, next in 238 seconds
    Auto-bw enabled tunnels: 1000

Name: tunnel-te9000 Destination: 20.20.20.20 (auto-tunnel mesh)
Status:
  Admin:  up Oper:  up Path:  valid Signalling: connected
  path option 10, type dynamic (Basis for Setup, path weight 11)
  G-PID: 0x0800 (derived from egress interface properties)
  Bandwidth Requested: 0 kbps CT0
  Creation Time: Fri Jan 14 09:09:31 2010 (01:41:20 ago)
Config Parameters:
  Bandwidth: 0 kbps (CT0) Priority: 7 7 Affinity: 0x0/0xffff
  Metric Type: TE (default)
  AutoRoute: disabled LockDown: disabled Policy class: not set
  Forwarding-Adjacency: disabled
  Loadshare: 0 equal loadshares
  Auto-bw: disabled
  Fast Reroute: Disabled, Protection Desired: None
  Path Protection: Not Enabled
  Attribute-set: TA-NAME (type auto-mesh)
Auto-tunnel Mesh:
  Group 40: Destination-list dl-40
  Unused removal timeout: not running
  History:
    Tunnel has been up for: 01:40:53 (since Fri Jan 14 09:09:58 EST 2010)
    Current LSP:
      Uptime: 01:41:00 (since Fri Jan 14 09:09:51 EST 2010)
    Reopt. LSP:
      Last Failure:
        LSP not signalled, identical to the [CURRENT] LSP
        Date/Time: Fri Jan 14 09:42:30 EST 2010 [01:08:21 ago]

Path info (OSPF 100 area 0):
Hop0: 7.0.15.1
Hop1: 20.20.20.20

```

This shows an auto-tunnel mesh summary sample output from the **show mpls traffic-eng tunnels** command using the **summary** keyword:

```

RP/0/RP0/CPU0:router# show mpls traffic-eng tunnels summary
Fri Jan 14 10:46:34.677 EST

    LSP Tunnels Process:  running
    RSVP Process:        running

```

```

                Forwarding:  enabled
                Periodic reoptimization:  every 3600 seconds, next in 3354 seconds
                Periodic FRR Promotion:  every 300 seconds, next in 193 seconds
                Periodic auto-bw collection:  1000

Signalling Summary:
  Head: 2000 interfaces, 2000 active signalling attempts, 2000 established
        2000 explicit, 0 dynamic
        9250 activations, 7250 deactivations
        0 recovering, 2000 recovered
  Mids: 0
  Tails: 0

Fast ReRoute Summary:
  Head: 1000 FRR tunnels, 1000 protected, 0 rerouted
  Mid:  0 FRR tunnels, 0 protected, 0 rerouted
  Summary: 1000 protected, 500 link protected, 500 node protected, 0 bw protected

<snip>

Auto-tunnel Mesh Summary:
  Auto-mesh Tunnels:
    50 created, 50 up, 0 down, 25 FRR, 20 FRR enabled
  Mesh Groups:
    4 groups, 50 destinations

```

This sample output displays the *Signalled-Name* information:

```

RP/0/RP0/CPU0:router#show mpls traffic-eng tunnels
Name: tunnel-tel Destination: 192.168.0.4
Signalled-Name: rtrA_t1
Status:
  Admin:  up Oper:  up Path:  valid Signalling: connected
.
.
.

```

This sample output displays the cost-limit configuration information:

```

RP/0/RP0/CPU0:router#show mpls traffic-eng tunnels detail
Name: tunnel-tel
Signalled-Name: ios_t1
Status:
  Admin:  up Oper:  down Path:  not valid Signalling: Down
  G-PID: 0x0800 (derived from egress interface properties)
  Bandwidth Requested: 0 kbps CT0
  Creation Time: Fri Jan 15 13:00:29 2014 (5d06h ago)
Config Parameters:
  Bandwidth: 0 kbps (CT0) Priority: 7 7 Affinity: 0x0/0xffff
  Metric Type: TE (default)
  Hop-limit: disabled
  Cost-limit: 2
  AutoRoute: disabled LockDown: disabled Policy class: not set
  Forward class: 0 (default)
  Forwarding-Adjacency: disabled
  Loadshare: 0 equal loadshares
  Auto-bw: disabled
  Fast Reroute: Disabled, Protection Desired: None
  Path Protection: Not Enabled
  BFD Fast Detection: Disabled
  Reoptimization after affinity failure: Enabled
  Soft Preemption: Disabled

```

```
Reason for the tunnel being down: No destination is configured
SNMP Index: 10
Displayed 1 (of 1) heads, 0 (of 0) midpoints, 0 (of 0) tails
Displayed 0 up, 1 down, 0 recovering, 0 recovered heads
```

This sample output displays the 'Traffic switched to FRR backup tunnel' message, when the FRR backup is activated as part of soft-preemption:

```
RP/0/RP0/CPU0:router#show mpls traffic-eng tunnels detail
.
.
.
Soft Preemption: Pending
  Preemption Link: HundredGigE0/0/0/3; Address: 14.14.14.2
  Traffic switched to FRR backup tunnel-te 1000
  Preempted at: Fri Jan 27 12:56:14 2017 (00:00:03 ago)
  Time left before hard preemption: 96 seconds
.
.
.
```

show mpls traffic-eng tunnels auto-bw brief

To display the list of automatic bandwidth enabled tunnels, and to indicate if the current signaled bandwidth of the tunnel is identical to the bandwidth that is applied by the automatic bandwidth, use the **show mpls traffic-eng tunnels auto-bw brief** command in XR EXEC mode.

show mpls traffic-eng tunnels auto-bw brief

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines Use the **show mpls traffic-eng tunnels auto-bw brief** command to determine if the automatic bandwidth application has been applied on a specified tunnel. If a single tunnel is specified, only the information for that tunnel is displayed.

Task ID	Task ID	Operations
	mpls-te	read

Examples

The following sample output shows the list of automatic bandwidth enabled tunnels:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng tunnels auto-bw brief
```

Tunnel Name	LSP ID	Last appl BW (kbps)	Requested BW (kbps)	Signalled BW (kbps)	Highest BW (kbps)	Application Time Left
tunnel-te0	1	10	10	50	2h 5m	
tunnel-te1	5	500	300	420	1h 10m	

This table describes the significant fields shown in the display.

Table 27: show mpls traffic-eng tunnels auto-bw brief Field Descriptions

Field	Description
Tunnel Name	Name for the tunnel.
LSP ID	ID of the Label Switched Path that is used by the tunnel.
Last appl BW (kbps)	Last bandwidth applied (for example, requested) by the automatic-bandwidth feature for the tunnel.

 `show mpls traffic-eng tunnels auto-bw brief`

Field	Description
Requested BW (kbps)	Bandwidth that is requested for the tunnel.
Signalled BW (kbps)	Bandwidth that is actually signalled for the tunnel.
Highest BW (kbps)	Highest bandwidth measured since the last start of the application interval.
Application Time Left	Time left until the application period ends for this tunnel.

show mpls traffic-eng link-management soft-preemption

To display information about soft-preemption activity on a MPLS TE link, use the **show mpls traffic-eng link-management soft-preemption** command in XR EXEC mode.

show mpls traffic-eng link-management soft-preemption [*interfacetype interface-path-id*]

Syntax Description	interface	Displays information on the specified interface.
	<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
	<i>interface-path-id</i>	Physical interface or a virtual interface.
	Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.	
Command Default	None	
Command Modes	XR EXEC mode	
Command History	Release	Modification
	Release 6.0	This command was introduced .
Usage Guidelines	No specific guidelines impact the use of this command.	
Task ID	Task ID	Operations
	mpls-te	read

Examples

This is sample output from the **show mpls traffic-eng link-management soft-preemption** command:

```
RP/0/RP0/CPU0:router# show mpls traffic-eng link-management soft-preemption interface
HundredGigE0/0/0/3
```

show mpls traffic-eng link-management soft-preemption

Name: HundredGigE0/0/0/3; IPv4 Address: 10.2.1.10
 Total Soft Preempted Bandwidth (BC0/BC1) kbps: 1500/1000
 Currently Soft Preempted Bandwidth (BC0/BC1) kbps: 1200/800
 Released Soft Preempted Bandwidth (BC0/BC1) kbps: 300/200
 Currently Over-subscribed Bandwidth (BC0/BC1) kbps: 1000/600
 Currently Soft Preempted Tunnels: 5 tunnels

TunID	LSPID	Source	Destination	Pri S/H	BW Kbps	Class Type	Time out
50	10	10.4.4.40	10.1.1.10	2/2	400	BC0	100
51	11	10.4.4.40	10.1.1.10	2/2	600	BC0	100
52	12	10.4.4.40	10.1.1.10	3/3	200	BC0	80
53	11	10.4.4.40	10.1.1.10	3/3	500	BC1	90
54	12	10.4.4.40	10.1.1.10	4/4	300	BC1	90

show srlg

To show the SRLG interface and configuration information, use the **show srlg** command in XR EXEC mode.

```
show srlg [group group-name] [inherit-location {location}] [interface type interface-path-id]
[location {name | mgmt-nodes}] [mapping {locationname}] [name name] [optical-interface
{locationinterface-id}] [producers name] [value value-number] [trace{file filename original | hexdump
| last entries | reverse | stats | tailf | unique | verbose | wrapping}]
```

Syntax Description

group <i>group-name</i>	(Optional) Specifies a group.
inherit-location <i>location</i>	(Optional) Specifies a particular location.
interface <i>type</i>	(Optional) Displays information on the specific interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface. Note Use the show interfaces command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
location	(Optional) Specifies a node.
<i>node-id</i>	Node ID. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
all	Specifies all locations.
mgmt-nodes	Specifies all management nodes.
mapping	(Optional) Specifies a mapping
<i>location</i>	Node location
<i>name</i>	Name of the mapping
name <i>name</i>	(Optional) Specifies an SRLG name.
optical-interface <i>interface-id</i>	(Optional) Specifies an optical interface.
producers <i>name</i>	(Optional) Specifies a SRLG producer.
value <i>value-number</i>	(Optional) Displays SRLG value numbers.
trace	(Optional) Displays trace information for SRLG.
file <i>filename</i>	(Optional) Displays trace information for a specific file name.

original	Displays the original location of the file.
hexdump	(Optional) Displays traces in hexadecimal format.
last	(Optional) Displays trace information for a specific number of entries.
<i>entries</i>	Number of entries. Replace entries with the number of entries you want to display. For example, if you enter 5, the display shows the last 5 entries in the trace data. Range is 1 to 4294967295.
reverse	(Optional) Displays the latest traces first.
stats	(Optional) Displays the statistics in the command output.
tailf	(Optional) Displays the new traces as they are added in the command output.
unique	(Optional) Displays the unique entries with counts in the command output.
verbose	(Optional) Displays the information for internal debugging in the command output.
wrapping	(Optional) Displays the wrapping entries in the command output.

Command Default	No default behavior or values
------------------------	-------------------------------

Command Modes	XR EXEC mode
----------------------	--------------

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines	No specific guidelines impact the use of this command.
-------------------------	--

Task ID	Task ID	Operation
	ip-services	read

Example

The following sample output is from the **show srlg value** command.

```
System Information::
Interface Count    : 2 (Maximum Interfaces Supported 250)
```

```
Interface : HundredGigE0/0/0/3, Value Count : 2  
SRLG Values : 10,20
```

```
Interface : HundredGigE0/0/0/3, Value Count : 2  
SRLG Values : 10,30
```

```
Interface : HundredGigE0/0/0/3, Value Count : 2  
SRLG Values : 10,40
```

```
Interface : HundredGigE0/0/0/3, Value Count : 1  
SRLG Values : 100
```

signalled-bandwidth

To configure the bandwidth required for an MPLS-TE tunnel, use the **signalled-bandwidth** command in interface configuration mode. To disable the behavior, use the **no** form of this command.

signalled-bandwidth {*bandwidth* [**class-type** *ct*] | **sub-pool** *bandwidth*}
no signalled-bandwidth {*bandwidth* [**class-type** *ct*] | **sub-pool** *bandwidth*}

Syntax Description	<i>bandwidth</i>	Bandwidth required for an MPLS-TE tunnel. Bandwidth is specified in kilobits per second. By default, bandwidth is reserved in the global pool. Range is from 0 to 4294967295.
	class-type <i>ct</i>	(Optional) Configures the class type of the tunnel bandwidth request. Range is from 0 to 1. Class-type 0 is strictly equivalent to global-pool. Class-type 1 is strictly equivalent to subpool.
	sub-pool <i>bandwidth</i>	Reserves the bandwidth in the subpool instead of the global pool. Range is 1 to 4294967295. A subpool bandwidth value of 0 is not allowed.

Command Default The default is 0 in class-type 0.

Command Modes Interface configuration

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines The **signalled-bandwidth** command supports two bandwidth pools (class-types) for the Diff-Serv Aware TE (DS-TE) feature. This command is also used as the bandwidth startup value to bring up the auto bandwidth enabled tunnels.



Note The Cisco Diff-Serve Aware TE feature is compliant to IETF standard and will interoperate with third party vendor DS-TE. Both Russian Doll Model and Maximum Allocation Model for bandwidth allocation are supported. We recommended that IETF terminology be used in DS-TE bandwidth configurations, namely, Class-type (CT) and Bandwidth Constraints (BC).

Task ID	Task ID	Operations
	mpls-te	read, write

Examples This example shows how to set the bandwidth required for an MPLS-TE tunnel to 1000 in the global pool (class-type 0):

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-te 1
RP/0/RP0/CPU0:router(config-if)# signalled-bandwidth 1000

RP/0/RP0/CPU0:router(config)# interface tunnel-te 1
RP/0/RP0/CPU0:router(config-if)# signalled-bandwidth 1000 class-type 0
```

This example shows how to set the bandwidth required for an MPLS-TE tunnel to 1000 in the sub-pool (class-type 1):

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-te 1
RP/0/RP0/CPU0:router(config-if)# signalled-bandwidth sub-pool 1000

RP/0/RP0/CPU0:router(config)# interface tunnel-te 1
RP/0/RP0/CPU0:router(config-if)# signalled-bandwidth 1000 class-type 1
```

signalled-name

To configure the name of the tunnel required for an MPLS-TE tunnel, use the **signalled-name** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

```
signalled-name name
no signalled-bandwidth name
```

Syntax Description	name Name used to signal the tunnel.				
Command Default	Default name is the hostname_tID, where ID is the tunnel interface number.				
Command Modes	Interface configuration				
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>Release 6.0</td><td>This command was introduced.</td></tr></table>	Release	Modification	Release 6.0	This command was introduced.
Release	Modification				
Release 6.0	This command was introduced.				
Usage Guidelines	No specific guidelines impact the use of this command.				
Task ID	<table><tr><th>Task ID</th><th>Operations</th></tr><tr><td>mpls-te</td><td>read, write</td></tr></table>	Task ID	Operations	mpls-te	read, write
Task ID	Operations				
mpls-te	read, write				

Examples

The following example shows how to set the tunnel name:

```
RP/0/RP0/CPU0:router(config)# interface tunnel-te 1
RP/0/RP0/CPU0:router(config-if)# signalled-name tunnel-from-NY-to-NJ
```


signalling advertise explicit-null (MPLS-TE)

To specify that tunnels terminating on a router use explicit-null labels, use the **signalling advertise explicit-null** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

signalling advertise explicit-null
no signalling advertise explicit-null

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	Implicit-null labels are advertised.
------------------------	--------------------------------------

Command Modes	MPLS-TE configuration
----------------------	-----------------------

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines	Use the signalling advertise explicit-null command to specify that tunnels terminating on this router use explicit-null labels. This command applies to tunnel labels advertised to next to last (penultimate) hop. The explicit label is used to carry quality-of-service (QoS) information up to the terminating-end router of the label switched path (LSP).
-------------------------	--

Task ID	Task ID	Operations
	mpls-te	read, write

Examples	The following example shows how to configure explicit null tunnel labels:
-----------------	---

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# signalling advertise explicit-null
```

snmp traps mpls traffic-eng

To enable the router to send Multiprotocol Label Switching traffic engineering (MPLS-TE) Simple Network Management Protocol (SNMP) notifications or informs, use the **snmp traps mpls traffic-eng** command in XR Config mode. To disable this behavior, use the **no** form of this command.

snmp traps mpls traffic-eng [*notification-option*] **preempt**
no snmp traps mpls traffic-eng [*notification-option*]

Syntax Description	<i>notification-option</i> (Optional) Notification option to enable the sending of notifications to indicate changes in the status of MPLS-TE tunnels. Use one of these values: • up • down • reoptimize • reroute • cisco-ext
	preempt Enables MPLS-TE tunnel preempt trap.

Command Default	None
------------------------	------

Command Modes	XR Config mode
----------------------	----------------

Command History	<table> <tr> <th>Release</th> <th>Modification</th> </tr> <tr> <td>Release 6.0</td> <td>This command was introduced.</td> </tr> </table>	Release	Modification	Release 6.0	This command was introduced.
Release	Modification				
Release 6.0	This command was introduced.				

Usage Guidelines	If the command is entered without the <i>notification-option</i> argument, all MPLS-TE notification types are enabled.
-------------------------	---

SNMP notifications can be sent as either traps or inform requests.

The **snmp-server enable traps mpls traffic-eng** command enables both traps and inform requests for the specified notification types. To specify whether the notifications should be sent as traps or informs, use the **snmp-server host** command and specify the keyword **trap** or **informs**.

If you do not enter the **snmp traps mpls traffic-eng** command, no MPLS-TE notifications controlled by this command are sent. To configure the router to send these MPLS-TE SNMP notifications, you must enter at least one **snmp enable traps mpls traffic-eng** command. If you enter the command with no keywords, all MPLS-TE notification types are enabled. If you enter the command with a keyword, only the notification type related to that keyword is enabled. To enable multiple types of MPLS-TE notifications, you must issue a separate **snmp traps mpls traffic-eng** command for each notification type and notification option.

The **snmp traps mpls traffic-eng** command is used in conjunction with the **snmp host** command. Use the **snmp host** command to specify which host or hosts receive MPLS-TE SNMP notifications. To send notifications, you must configure at least one **snmp host** command.

For a host to receive an MPLS-TE notification controlled by this command, both the **snmp traps mpls traffic-eng** command and the **snmp host** command for that host must be enabled.

Task ID	Task ID	Operations
	mpls-te	read/write

Examples

This example shows how to configure a router to send MPLS-TE tunnel up SNMP notifications when a configured MPLS-TE tunnel leaves the down state and enters the up state:

```
RP/0/RP0/CPU0:router(config)# snmp traps mpls traffic-eng up
```

soft-preemption

To enable soft-preemption with default timeout on a head-end for the MPLS TE tunnel, use the **soft-preemption** command in MPLS TE mode. To disable this feature, use the **no** form of this command.

soft-preemption timeout *seconds*

no soft-preemption

timeout <i>seconds</i>	Defines the timeout for soft-preempted LSP, in seconds. The default timeout is 60. Range is from 30 to 300.
-------------------------------	---

Command Default The default *timeout seconds* is 60 seconds.

Command Modes MPLS TE configuration
Tunnel Interface configuration

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	MPLS-TE	write

This example shows how to enable soft-preemption on a specific tunnel:

```
RP/0/RP0/CPU0:router(config)#interface tunnel-te 50
RP/0/RP0/CPU0:router(config-if)#soft-preemption
```

This example shows how to enable soft-preemption on a node :

```
RP/0/RP0/CPU0:router(config)#mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)#soft-preemption
RP/0/RP0/CPU0:router(config-soft-preemption)#
```

soft-preemption frr-rewrite

To enable LSP traffic over backup tunnel, when LSP is soft-preempted, use the **soft-preemption frr-rewrite** command in MPLS TE configuration mode. To disable the LSP traffic over backup tunnel, use the **no** form of this command.

soft-preemption frr-rewrite
no soft-preemption frr-rewrite

Syntax Description	This command has no keywords or arguments.
---------------------------	--

Command Default	FRR LSP traffic over backup tunnel is disabled.
------------------------	---

Command Modes	MPLS TE configuration
----------------------	-----------------------

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines	The fast re-route backup tunnel must be available and ready for the traffic of the preempted LSP to be moved onto the FRR backup. The traffic will not be moved to the backup tunnel, if an LSP is already soft-preempted.
-------------------------	--

Task ID	Task ID	Operation
	mpls-te	read, write

This example shows how to enable FRR LSP traffic over backup tunnels, when the LSP is soft-preempted.

```
RP/0/RP0/CPU0:router#configure
RP/0/RP0/CPU0:router(config)#mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)#soft-preemption frr-rewrite
```

srlg

To configure an MPLS traffic engineering shared-risk link group (SRLG) value for a link on a given interface, use the **srlg** command in global configuration mode. To disable this configuration, use the **no** form of this command.

srlg *value*
no srlg *value*

Syntax Description	<i>value</i> Value number that identifies the SRLG. Range is 0 to 4294967295.				
Command Default	Shared Risk Link Group memberships are not configured.				
Command Modes	MPLS-TE interface configuration XR Config mode				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 6.0</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 6.0	This command was introduced.
Release	Modification				
Release 6.0	This command was introduced.				
Usage Guidelines	You can enter up to 30 SRLG entries on the ingress and egress ports of the interface. SRLG entries configured over 30 are silently dropped.				
Task ID	<table> <tr> <th>Task ID</th><th>Operations</th></tr> <tr> <td>mpls-te</td><td>read, write</td></tr> </table>	Task ID	Operations	mpls-te	read, write
Task ID	Operations				
mpls-te	read, write				

Examples The following example shows how to configure an SRLG with 10 member links:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# interface HundredGigE 0/0/0/3
RP/0/RP0/CPU0:router(config-mpls-te-if)# srlg 10

RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router#(config)# srlg
RP/0/RP0/CPU0:router#(config-srlg)# interface HundredGigE 0/0/0/3
RP/0/RP0/CPU0:router#(config-srlg-if)# value 10
```

timers loose-path (MPLS-TE)

To configure the period between the headend retries after path errors, use the **timers loose-path** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

timers loose-path retry-period *value*
no timers loose-path retry-period *value*

Syntax Description	retry-period <i>value</i> Configures the time, in seconds, between retries upon a path error. Range is 30 to 600.	
Command Default	<i>value</i> : 120	
Command Modes	MPLS-TE configuration	
Command History	Release	Modification
	Release 6.0	This command was introduced
Usage Guidelines	No specific guidelines impact the use of this command.	
Task ID	Task ID	Operations
	mpls-te	read, write
Examples	The following example shows how to the period between retries after path errors to 300 seconds: <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# mpls traffic-eng RP/0/RP0/CPU0:router(config-mpls-te)# timers loose-path retry-period 300</pre>	

timers removal unused (auto-tunnel backup)

To configure the frequency at which a timer scans backup autotunnels and removes tunnels that are not in use, use the **timers removal unused (auto-tunnel backup)** command in auto-tunnel backup configuration mode. To return to the default behavior, use the **no** form of this command.

timers removal unused *frequency*
no timers removal unused *frequency*

Syntax Description	<i>frequency</i> Frequency, in minutes, between backup autotunnel scans to remove tunnels that are not used. Range is 0; 5 to 10080 minutes (7 days). A value of 0 disables the scanning and removal of tunnels.	
Command Default	<i>frequency</i> : 60	
Command Modes	auto-tunnel backup configuration	
Command History	Release	Modification
	Release 6.0	This command was introduced
Usage Guidelines	The unused auto-tunnel backup tunnel is the tunnel that is not assigned to protect any FRR tunnel.	
Task ID	Task ID	Operation
	mpls-te	read, write

Example

The following example shows that unused automatic backup tunnels are removed after the 10 minute timer scan is reached.

```
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# auto-tunnel backup
RP/0/RP0/CPU0:router(config-te-auto-bk)# timers removal unused 10
```


timeout (soft-preemption)

To override the soft-preemption default timeout, use the **timeout** command in MPLS TE mode. To remove this configuration, use the **no** form of this command.

soft-preemption timeout seconds

no soft-preemption

Syntax Description	timeout seconds Defines the timeout for soft-preempted LSP, in seconds. The default timeout is 60. Range is from 30 to 300.	
Command Default	The default <i>timeout seconds</i> is 60 seconds.	
Command Modes	MPLS TE configuration	
Command History	Release	Modification
	Release 6.0	This command was introduced
Usage Guidelines	No specific guidelines impact the use of this command.	
Task ID	Task ID	Operation
	MPLS-TE	write

This example shows how to override the soft-preemption default timeout:

```
RP/0/RP0/CPU0:router(config)# mpls traffic-eng
RP/0/RP0/CPU0:router(config-mpls-te)# soft-preemption
RP/0/RP0/CPU0:router(config-soft-preemption)# timeout 60
```

topology holddown sigerr (MPLS-TE)

To specify the time that a router should ignore a link in its TE topology database in tunnel path constrained shortest path first (CSPF) computations following a TE tunnel signaling error on the link, use the **topology holddown sigerr** command in MPLS-TE configuration mode. To return to the default behavior, use the **no** form of this command.

topology holddown sigerr *seconds*
no topology holddown sigerr *seconds*

Syntax Description	<i>seconds</i> Time that the router ignores a link during tunnel path calculations, following a TE tunnel error on the link, specified in seconds. Range is 0 to 300. Default is 10.	
Command Default	<i>seconds</i> : 10	
Command Modes	MPLS-TE configuration	
Command History	Release	Modification
	Release 6.0	This command was introduced
Usage Guidelines	A router at the headend for TE tunnels can receive a Resource Reservation Protocol (RSVP) No Route error message before the router receives a topology update from the IGP routing protocol announcing that the link is down. When this happens, the headend router ignores the link in subsequent tunnel path calculations to avoid generating paths that include the link and are likely to fail when signaled. The link is ignored until the router receives a topology update from its IGP or a link holddown timeout occurs. Use the topology holddown sigerr command to change the link holddown time from its 10-second default value.	
Task ID	Task ID	Operations
	mpls-te	read, write
Examples	The following example shows how to set the link holddown time for signaling errors at 15 seconds: <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# mpls traffic-eng RP/0/RP0/CPU0:router(config-mpls-te)# topology holddown sigerr 15</pre>	

tunnel-id (auto-tunnel backup)

To configure the range of tunnel interface numbers to be used for automatic backup tunnels, use the **tunnel-id** command in auto-tunnel backup configuration mode. To delete the automatic backup tunnels, use the **no** form of this command.

tunnel-id
min *number*
max *number*
no tunnel-id

Syntax Description	min (Optional) Minimum number for automatic backup tunnels. <i>number</i> Valid values are from 0 to 65535. max (Optional) Maximum number for automatic backup tunnels.					
Command Default	No default behavior or values					
Command Modes	Auto-tunnel backup configuration					
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>Release 6.0</td><td>This command was introduced</td></tr></table>		Release	Modification	Release 6.0	This command was introduced
Release	Modification					
Release 6.0	This command was introduced					
Usage Guidelines	If you increase the tunnel ID range, the automatic backup tunnels that failed earlier will get created the next time automatic backup assignments are processed. Restrictions: • Command is rejected if the max value minusmin value is $\geq$ 1K. • Command is rejected if min value $>$ max value. • Command is rejected if min value is greater than the tunnel ID of an existing automatic backup tunnel. • Command is rejected if max value is smaller than the tunnel ID of an existing automatic backup tunnel. • Command is rejected if a statically configured tunnel ID matches with the configured min and max range of values. • Command is rejected if a static backup assignment is already configured to a tunnel with an ID within the min value /max value range.					
Task ID	<table><tr><th>Task ID</th><th>Operation</th></tr><tr><td>mple-te</td><td>read, write</td></tr></table>		Task ID	Operation	mple-te	read, write
Task ID	Operation					
mple-te	read, write					

Example

The following example allows 800 automatic backup tunnels to be created:

```
RP/0/RP0/CPU0:router(config)# mpls traffic-eng  
RP/0/RP0/CPU0:router(config-mpls-te)# auto-tunnel backup  
RP/0/RP0/CPU0:router(config-te-auto-bk)# tunnel-id min 1200 max 2000
```