



File System Commands

This chapter describes the Cisco IOS XR software commands used to manage file systems on your router.



Note The commands in this module should not be used to access or modify any Cisco IOS XR software or configuration files. Use only the documented commands for installing and configuring the router. Modifying, deleting, or moving configuration or software package files using the manual commands described in this module is not required and can result in router downtime, loss of service, and a corrupted database.

- [cd, on page 2](#)
- [cfs check, on page 3](#)
- [clear configuration ascii inconsistency, on page 5](#)
- [copy, on page 6](#)
- [delete, on page 12](#)
- [dir, on page 13](#)
- [mkdir, on page 15](#)
- [pwd, on page 17](#)
- [rmdir, on page 18](#)
- [show filesystem, on page 20](#)
- [show media, on page 22](#)

cd

To change the current working directory, use **cd** command in EXEC mode or XR EXEC mode.

cd *filesystem* :

Syntax Description	<i>filesystem</i> : (Optional) Location of the new working directory. Include the file system alias for the <i>filesystem</i> argument, followed by a colon and optionally, the name of a directory.	
Command Default	The default file directory is disk0:/usr .	
Command Modes	EXEC XR EXEC	
Command History	Release	Modification
	Release 7.0.1	This command was introduced.
Usage Guidelines	The current working directory is the directory used when EXEC commands that have an optional argument are entered without that argument. Use cd command to define the working directory. For example, when the dir command is entered without specifying the <i>filesystem</i> argument, the files in the current working directory are displayed. Use cd command without an argument to set the working directory back to the default directory, disk0:/usr. The following example shows how to change the current working directory to the root directory on the hard disk. In this example, the pwd command confirms that the working directory has changed to the root directory on the hard disk. <pre>RP/0/RP0/CPU0:router# cd harddisk: RP/0/RP0/CPU0:router# pwd harddisk:</pre> The following example shows how to change the current working directory to the default file directory by specifying the cd command without a location. In this example, the pwd command confirms that the working directory has changed to the default file directory. <pre>RP/0/RP0/CPU0:router# cd RP/0/RP0/CPU0:router# pwd disk0:/usr</pre>	

cfs check

To clear any inconsistencies between running configuration and binary startup configuration maintained on the disk use **cfs check** command in XR EXEC mode.

cfs check

Syntax Description	This command has no keywords or arguments.	
Command Default	No default behavior or values.	
Command Modes	XR EXEC mode	
Command History	Release	Modification
	Release 3.5.0	This command was introduced.
	Release 24.2.1	This command was modified to increase the commit count from 20 to 40.

Usage Guidelines

Use this command to clear any inconsistencies between running configuration and binary startup configuration maintained on the disk.

On executing this command the existing binary startup configuration maintained on the disk will be discarded and the entire binary startup configuration will be recreated from system's running configuration. This will clear any inconsistency between the two.



Note While this command runs, redundancy of the designated shelf controller (DSC) is disabled.



Note Executing this command will take a lock to the configuration database, which will prevent any commit operation until this operation completes.

Task ID	Task ID	Operations
	root-lr	read, write

Examples

The following example shows how to perform a CFS check:

```
Router# cfs check
```

```
Creating any missing directories in Configuration File system...OK
Initializing Configuration Version Manager...OK
Syncing commit database with running configuration...OK
Re-initializing cache files...OK
```

Updating Commit Database. Please wait...[OK]

Related Commands

Command	Description
show configuration history	Displays cfs check events executed successfully.
clear configuration inconsistency	Performs the same operation as cfs check , can be used interchangeably.

clear configuration ascii inconsistency

To perform an ASCII backup of the system's running configuration and to clear inconsistencies between running configuration and ASCII backup copy maintained on the disk, use the **clear configuration ascii inconsistency** command in XR EXEC mode.

clear configuration ascii inconsistency

Syntax Description

This command has no keywords or arguments.

Command Default

No default behavior or values.

Command Modes

XR EXEC mode

Command History

Release	Modification
Release 6.5.1	This command was introduced.
Release 24.2.1	This command was modified to include resetting the ASCII backup timer.

Usage Guidelines

Use this command to perform a forced ASCII backup and reset the periodic ASCII backup timer. Once the backup is complete, the router will automatically initiate the next periodic ASCII backup operation only after 55 minutes from the time the **clear configuration ascii inconsistency** command is executed.

On executing this command, the ASCII backup will synchronize with the latest running configuration up to the point of the last commit made before executing the command. This clears any inconsistencies between the running configuration and the ASCII backup copy stored on disk. Additionally, this command will reset the periodic ASCII backup timer.

Task ID

Task ID	Operations
config-services	execute

Examples

The following example shows how to perform an ASCII backup and reset the ASCII backup timer to zero:

```
Router# clear configuration ascii inconsistency
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!! It is recommended to run this command only when all nodes in router are in IOS-XR RUN state. To determine node state, run following command: 'show platform'.
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
Warning: Proceed with the command ?[confirm] y
Ascii configuration backup is in progress...
Configuration ascii backup complete
```

Related Commands

Command	Description
show configuration history	Displays clear configuration ascii inconsistency events executed successfully.

copy

To copy a file from a source (such as a network server) to a destination (such as a flash disk), use **copy** command in EXEC or Admin EXEC mode.

copy *source* {**location** *node-id* *destination* **location** {*node-id* | **all**} | **running-config**[**atomic**]}

Syntax Description

<i>source</i>	Filename including the directory path or network location of the file. The possible sources are: <i>directory-path</i> —Directory path of the file from which the file is copied. access-list { ipv4 ipv6 }—Copies an access list (EXEC mode only). apphost: —Copy from apphost: file system config: —Copy from config: file system disk0: —Copies from disk0: file system. disk1: —Copies from disk1: file system. ftp: —Copies from an FTP network server. The syntax is ftp:[[//<i>username</i>[:<i>password</i>]@] <i>location</i>]/<i>directory</i>]/<i>filename</i>. harddisk: —Copies from the hard disk drive file system (if present). http: —Copy from http: file system https: —Copy from https: file system nvr: —Copies from the NVRAM file system. prefix-list { ipv4 ipv6 }—Copies from a prefix list (EXEC mode only). roots: — Copy from roots: file system running-config —Copies from the current system configuration. tftp: —Copies from a TFTP network server. The syntax is tftp:[[//<i>location</i>]/<i>directory</i>]/<i>filename</i> xml-schema —Copies the XML schema files as a tar ball file (.tar.gz) [EXEC mode only]. sftp: —Copies from an SFTP network server. The syntax is sftp:[[//<i>username</i>[:<i>password</i>]@] <i>location</i>]/<i>directory</i>]/<i>filename</i>. scp: —Copies from an SCP network server. The syntax is scp:[[//<i>username</i>[:<i>password</i>]@] <i>location</i>]/<i>directory</i>]/<i>filename</i>.
<i>destination</i>	Filename including the directory path or network location of the file.
location <i>node-id</i>	Specifies a node. The <i>node-id</i> argument is expressed in the <i>rack/slot</i> notation.
location all	Copies to all nodes.
running-config	Applies the source configuration file to the running configuration of the system.

atomic	(Optional) Applies the changes to the running configuration only if there are no errors
---------------	---

Command Default	No default behavior or values
------------------------	-------------------------------

Command Modes	EXEC mode. Admin EXEC mode.
----------------------	--------------------------------

Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.10.1</td> <td>This command was modified to support public key authentication.</td> </tr> <tr> <td>Release 7.9.1</td> <td>This command was modified to support SFTP and SCP options.</td> </tr> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.10.1	This command was modified to support public key authentication.	Release 7.9.1	This command was modified to support SFTP and SCP options.	Release 7.0.12	This command was introduced.
Release	Modification								
Release 7.10.1	This command was modified to support public key authentication.								
Release 7.9.1	This command was modified to support SFTP and SCP options.								
Release 7.0.12	This command was introduced.								

Usage Guidelines	Source and destination can each be a configuration file, a text file, or a file system. Enter source and destination URL information, usernames, and passwords and issue the copy command. The networking device prompts for any missing information.
-------------------------	--

The exact format of the *source* and *destination* arguments vary according to the file or directory location. Enter the device or network location for the file system type.

Filenames can include the following characters:

!#\$%&' + 0 1 2 3 4 5 6 7 8 9 ; @ A B C D E F G H I J K L M N O P Q R S T U V W X Y Z [] ^ _ a b c d e f g h i j k l m n o p q r s t u v w x y z { } ~

The following characters can be used with the stated limitations:

- ` needs backslash before this character
- – cannot be the first character
- . cannot be the last character
- = cannot be the filename without other characters

The following characters cannot be used in filenames:

" () * , / : < > ? \ |

To copy a file from a source on the router to a destination on the router, specify a source **location node-id** and a destination **location node-id**. To copy the file to all nodes, use the **location all** keywords.

In the alias syntax for the **ftp:**, **rcp:**, **tftp:**, **sftp:**, and **scp:** keywords, the location is either an IP address or a hostname. The filename is specified relative to the directory used for file transfers.

When no alias is specified, the networking device looks for a file in the current directory. To view the current directory, enter the **pwd** command.



Note	During processing of the copy command, you might see the “C” character. For all files being copied, “C” indicates that the copy process is taking place. The entire copying process might take several minutes and differs from protocol to protocol and from network to network.
-------------	--

Table 1: Network Protocols Supported by Cisco IOS XR Software

Prefix	Name	Description
tftp:	Trivial File Transfer Protocol	<i>TFTP</i> is a simplified version of FTP that allows files to be transferred from one computer to another over a network, usually without the use of client authentication (for example, username and password).
ftp:	File Transfer Protocol	<i>FTP</i> is an application protocol, part of the TCP/IP protocol stack, and is used for transferring files between network nodes. FTP requires a username and password.
rcp:	Remote Copy Protocol	The rcp protocol allows users to copy files to and from a file system residing on a remote host or server on the network. The rcp protocol uses TCP to ensure the reliable delivery of data. The rcp protocol downloads require a username.
sftp:	Secure File Transfer Protocol	<i>SFTP</i> is an application protocol is used for secure transferring files between the router and and an archive server. SFTP requires a username and password.
scp:	Secure Copy Protocol	<i>SCP</i> is an application protocol is used for secure transferring files between the router and and an archive server. SFTP requires a username and password.

Additional usage guidelines are in the following sections.

Invalid Combinations of Source and Destination

Some combinations of source and destination are invalid. Specifically, you cannot copy the following:

- From a running configuration to a running configuration
- From a network device to a network device (for example, **copy ftp: rcp:**)

Using TFTP

TFTP is a simplified version of FTP that allows files to be transferred from one computer to another over a network, usually without the use of client authentication (for example, username and password).

The syntax is as follows:

copy tftp://hostname/ipaddress/directory-path pie name target-device [location {node-id | all}]

Example:

```
RP/0/RP0/CPU0:router# copy tftp://1.1.1.1/images/software.pie disk1:
```



Note Some Cisco IOS XR images may be larger than 32 MB, and the TFTP services provided by some vendors may not support a file this large. If you do not have access to a TFTP server that supports files larger than 32 MB, download the software image using FTP or rcp as described in the following sections.

Using FTP

FTP servers require a username and password for each client request. Cisco IOS XR software sends the first valid username in the following list:

1. The username and password specified in the **copy** command, if a username is specified.

The syntax is as follows:

copy ftp://username : password @ hostname or ipaddress/directory-path/pie-name target-device [location {node-id | all}]

Example:

```
RP/0/RP0/CPU0:router# copy ftp://john:secret@10.1.1.1/images/software.pie disk1:
```

2. An “anonymous” username and password. The anonymous password is “root@ip address,” where “ip address” is the IP address of the local networking device.
3. A password “username@iosname.domain” formed by the networking device. The variable “username” is the username associated with the current session, “iosname” is the configured hostname, and “domain” is the domain of the networking device.

The username and password must be associated with an account on the FTP server. If you are writing to the network server, the FTP server must be properly configured to accept the FTP write request from the user on the networking device.

If the network server has a directory structure, the configuration file or image is written to or copied from the directory associated with the username on the network server. For example, if the system image resides in the home directory of a user on the network server, specify the name of that user as the remote username.

Refer to the documentation for your FTP server for more details.

Using rcp

The rcp protocol requires a username upon each request. When you copy a configuration file or image between the networking device and an rcp server, the Cisco IOS XR software sends the first valid username in the following list:

1. The remote username specified in the **copy** command, if one is specified.
2. The username set by the **rcp client username** command, if the command is configured.
3. The networking device hostname.

For the rcp copy request to process successfully, an account must be defined on the network server for the remote username. If the network administrator of the destination server did not establish an account for the remote username, this command does not run successfully. If the network server has a directory structure, the configuration file or image is written to or copied from the directory associated with the remote username on the network server. For example, if the system image resides in the home directory of a user on the network server, specify the name of that user as the remote username.

If you are writing to the network server, the rcp server must be properly configured to accept the rcp write request from the user on the networking device. For UNIX systems, add an entry to the .rhosts file for the remote user on the rcp server. Suppose the networking device contains the following configuration lines:

```
hostname Rtrl
```

```
ip rcp remote-username User0
```

If the IP address of the networking device translates to company.com, then the .rhosts file for User0 on the rcp server should contain the following line:

```
company.com Rtrl
```

See the documentation for your rcp server for more details.

If you are using a personal computer as a file server, the computer must support remote shell (rsh) protocol.

Using xml-schema

Use the **xml-schema** keyword to obtain the most up-to-date XML schemas (.xsd files) from the router. Using this keyword is useful to prevent the use of outdated schemas in the event that router software updates include schema updates. The tar ball file includes all active schema files. It does not include schemas that are activated by specific package installation envelopes (PIEs) if those PIEs are not installed and activated on the router.

Copying to the Running Configuration

When you use the **copy** command to copy a configuration file to the **running-config** destination, the configuration in the file is applied to the running configuration of the system. This is a configuration operation. By default, the copy is carried out in a best-effort manner. This means that if some configuration lines from the file cannot be applied, the remaining configuration is still integrated into the system. In this case, a partial configuration is committed. When the **atomic** keyword is used, partial configurations are not committed. This means that even if one error occurs in the parsing or committing phase, no changes are made to the system. To view any errors when applying the configuration, use the **show configuration failed** command.

Task ID

Task ID Operations

```
filesystem execute
```

The following example shows how to copy a file from a FTP server to disk1:

```
RP/0/RP0/CPU0:router#
```

The following example shows how to copy a file from an rcp server to disk1:

```
RP/0/RP0/CPU0:router#
```

The following example shows how to copy a file from a TFTP server to disk1:

```
RP/0/RP0/CPU0:router#
```

The following example shows how to copy a file from a SCP and SFTP server using public key authentication:

```
Router#copy running-config scp://root@192.0.4.2//var/opt/run_conf_scp.txt
```

```
Router#copy running-config sftp://root@192.0.4.2//var/opt/run_conf_sftp.txt
```

delete

To delete files, use **delete** command in the appropriate mode.

Syntax Description

filename Filename of the file to be deleted.

config config: file system

apphost apphost: file system

disk0 Deletes disk0.

disk1 Deletes disk1.

harddisk Deletes the harddisk

Command Default

A filename must be specified. If a filename is entered without a file system or directory path, the present working directory is used.

Command Modes

EXEC mode.

Admin EXEC mode.

Command History

Release	Modification
Release 7.0.1	This command was introduced.

Usage Guidelines

When a file is deleted, it is removed from the system and cannot be restored (undeleted).

Use the **dir** command to display the list of files on a storage device.

The following example shows how to delete a file:

```
RP/0/RP0/CPU0:router# delete rbtest
```

```
Delete disk1:/rbtest[confirm]y
```

dir

To display a list of files on a file system or in a specific directory, use the **dir** command in the appropriate mode.

dir [/all | /ena | /recurse] [*filesystem* :] [*filename*] **location** {*node-id* | **all**}

Syntax Description	/all	(Optional) Lists deleted files, undeleted files, and files with errors.
	/ena	(Optional) Recognizes subdirectories.
	config	config: file system
	disk0	disk0: file system
	harddisk	harddisk: file system
	/recurse	(Optional) Recursively lists subdirectories.
	<i>filesystem</i> :	(Optional) Name of the directory containing the files to be displayed. Include the file system alias for the <i>filesystem</i> argument, followed by a colon, and, optionally, the name of a directory.
	<i>filename</i>	(Optional) Name of the files to display. The files can be of any type. You can use wildcards in the filename. A wildcard character (*) matches all patterns. Strings following a wildcard are ignored.
	location { <i>node-id</i> all }	(Optional) Specifies the node from which to display a list of files. The <i>node-id</i> argument is entered in the <i>rack/slot</i> notation. The all keyword specifies to display files on all nodes.

Command Default When **dir** command is entered without keywords or arguments, the contents of the present working directory are displayed.

Command Modes EXEC mode.
Admin EXEC mode.

Command History	Release	Modification
	Release 7.0.1	This command was introduced.

Usage Guidelines If you enter the **dir** command without specifying a directory, the contents of the present working directory are displayed. The **all** keyword displays all files, including deleted files. The size associated with the directory name is the total size for all files in that directory.

The following example shows how to display the contents of a directory:

```
RP/0/RP0/CPU0:router# dir harddisk:/log
```

```
Directory of harddisk:/log
```

```
5527      drwx 4096      Thu Aug 28 11:21:48 2008  boot_28_Aug_2008_11_21_49
5533      drwx 4096      Thu Aug 28 11:38:54 2008  boot_28_Aug_2008_11_38_54
5538      drwx 4096      Fri Sep  5 13:28:54 2008  boot_05_Sep_2008_13_28_54
5543      drwx 4096      Mon Sep  8 08:55:52 2008  boot_08_Sep_2008_06_59_08
--More--
```

mkdir

To create a new directory on a file system, use the **mkdir** command in the appropriate mode.

mkdir *filesystem*:[**location** {*node-id* | **all**}]

Syntax Description	filesystem:	File system on which to create a new directory.
	location { <i>node-id</i> all }	(Optional) Specifies the node where the file system is located. The <i>node-id</i> argument is expressed in the <i>rack/slot</i> notation. Use the all keyword to indicate all nodes.
	apphost	apphost: file system
	config	config: file system
	disk0	disk0: file system
	harddisk	harddisk: file system
Command Default	No default behavior or values	
Command Modes	System Admin EXEC	
	XR EXEC	
Command History	Release	Modification
	Release 7.0.1	This command was introduced.
Usage Guidelines	After you issue the mkdir command, Cisco IOS XR software prompts you to specify the name of the directory to be created. When specifying the name of the new directory, include the directory path where you want the new directory to reside. If you do not specify a directory path, the new directory is created in the /usr directory of the file system specified for the <i>filesystem:</i> argument.	
	The following example shows how to create a directory named newdir. The dir command is used to verify that the directory has been added.	

```

RP/0/RP0/CPU0:router# mkdir harddisk:

Create directory filename []?newdir
Created dir harddisk:/newdir
RP/0/RP0/CPU0:router# dir harddisk:

Directory of harddisk:

11193      drwx  4096      Fri Feb 13 06:45:05 2009  newdir
37146      drwx  4096      Sun Dec 14 15:30:48 2008  malloc_dump
43030      drwx  4096      Wed Dec 24 11:20:52 2008  tracebacks
43035      drwx  4096      Thu Jan  8 18:59:18 2009  sau
51026      drwx  4096      Sat Dec 27 02:52:46 2008  tempA
51027      drwx  4096      Sat Dec 27 02:04:10 2008  dir.not.del
-430307552 -rwx   342      Fri Jan 16 10:47:38 2009  running-config

```

```
-430305504  -rwx  39790      Mon Jan 26 23:45:56 2009  cf.dat
39929724928 bytes total (39883231232 bytes free)
```

pwd

To display the present working directory, use the **pwd** command in EXEC mode

pwd

Syntax Description

This command has no keywords or arguments.

Command Default

No default behavior or values.

Command History

Release	Modification
Release 7.0.1	This command was introduced.

Usage Guidelines

Use the **pwd** command to show what directory or file system is specified as the default by the **cd** command.

The following example shows how to display the present working directory:

```
RP/0/RP0/CPU0:router# pwd
```

```
disk0:/usr
```

rmdir

To remove an existing directory, use the **rmdir** command in the appropriate mode.

rmdir *filesystem:* **location** {*node-id* | **all**}

Syntax Description

<i>filesystem</i>	Name of the file system from which to delete a directory, followed by a colon.
location { <i>node-id</i> all }	Specifies the node where the file system is located. The <i>node-id</i> argument is expressed in the <i>rack/slot</i> notation. Use the all keyword to indicate all nodes.
apphost	apphost: file system
config	config: file system
disk0	disk0: file system
harddisk	harddisk: file system

Command Default

No default behavior or values

Command Modes

XR EXEC

System Admin EXEC

Command History

Release	Modification
Release 7.0.1	This command was introduced.

Usage Guidelines

Use the **rmdir** command to remove directories (for example, to free up disk space) from a file system. After you issue the **rmdir** command, the Cisco IOS XR software prompts you to specify the name of the directory to be deleted.

When a directory contains files, you must remove the files before deleting the directory. Use the **delete** command to remove files.

The following example shows how to delete a subdirectory from the hard disk. The **dir** command is used to verify that the directory has been deleted.

```
RP/0/RP0/CPU0:router# rmdir harddisk:
```

```
Remove directory filename []?newdir
Delete harddisk:/newdir[confirm]y
RP/0/RP0/CPU0:router# dir harddisk:
```

```
Directory of harddisk:
```

```

37146      drwx  4096      Sun Dec 14 15:30:48 2008  malloc_dump
43030      drwx  4096      Wed Dec 24 11:20:52 2008  tracebacks
43035      drwx  4096      Thu Jan  8 18:59:18 2009   sau
51026      drwx  4096      Sat Dec 27 02:52:46 2008  tempA
51027      drwx  4096      Sat Dec 27 02:04:10 2008  dir.not.del
```

```
-430307552 -rwx 342      Fri Jan 16 10:47:38 2009 running-config
-430305504 -rwx 39790    Mon Jan 26 23:45:56 2009 cf.dat

39929724928 bytes total (39883235328 bytes free)
```

show filesystem

To display the layout and contents of file systems, use the **show filesystem** command in EXEC mode.

show filesystem [**location** { *node-id* | **all** }]

Syntax Description	location { <i>node-id</i> all } (Optional) Specifies the node where the file system is located. The <i>node-id</i> argument is expressed in the <i>rack/slot</i> notation. Use the all keyword to indicate all nodes.				
Command Default	The file system for the active RP is displayed.				
Command Modes	EXEC mode				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 7.0.1</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 7.0.1	This command was introduced.
Release	Modification				
Release 7.0.1	This command was introduced.				
Usage Guidelines	Use the show filesystem command to learn the alias names (prefixes) of the file systems supported by your networking device.				

The following example shows sample output from the **show filesystem** command:

```
RP/0/RP0/CPU0:router# show filesystem
```

File Systems:

Size (b)	Free (b)	Type	Flags	Prefixes
-	-	network	rw	qsm/dev/fs/tftp: tftp:
-	-	network	rw	qsm/dev/fs/rcp: rcp:
-	-	network	rw	qsm/dev/fs/ftp: ftp:
39929724928	39852978176	harddisk	rw	harddisk:
1024606208	863584256	flash-disk	rw	disk0:
2092032	2059264	nvr	rw	nvr:
62390272	62381260	flash	rw	bootflash:

The following example shows sample output from the **show filesystem** command using the optional **location node-id** keyword and argument:

```
RP/0/RP0/CPU0:router# show filesystem location 0/rp0/cpu0
```

File Systems:

Size (b)	Free (b)	Type	Flags	Prefixes
-	-	network	rw	qsm/dev/fs/tftp: tftp:
-	-	network	rw	qsm/dev/fs/rcp: rcp:
-	-	network	rw	qsm/dev/fs/ftp: ftp:
39929724928	39883235328	harddisk	rw	harddisk:
2092032	2019328	nvr	rw	nvr:
1024606208	847888384	flash-disk	rw	disk0:
62390272	62153616	flash	rw	bootflash:

Table 2: show filesystem Field Descriptions

Field	Description
Size(b)	Amount of memory in the file system, in bytes.
Free(b)	Amount of free memory in the file system, in bytes.
Type	Type of file system.
Flags	Permissions for file system.
Prefixes	Alias for the file system.

show media

To display the current state of the disk storage media, use the **show media** command in mode.

Command Default

The disk storage media for the active RP is displayed.

Command Modes

Command History

Release	Modification
Release 7.0.1	This command was introduced.

Usage Guidelines

Use the **show media** command to view the status of the storage media on your system.

The following example displays the output of the **show media** command:

```
sysadmin-vm:0_RP0 #show media
Thu Nov 30 14:57:14.002 WET
Media Information for local node.
-----
Partition          Size      Used   Percent   Avail
rootfs:             2.7G     1.5G     59%      1.1G
apphost:            1.9G       61M      4%      1.7G
/dev/sde            870M     401M     50%     409M
harddisk:           2.4G     966M     43%     1.3G
log:                 459M      67M     16%     359M
config:             159M     2.5M      2%     144M
disk0:              1.3G     108M      9%     1.1G
-----
rootfs: = root file system (read-only)
log:    = system log files (read-only)
config: = configuration storage (read-only)
```

Table 3: show media Field Descriptions

Field	Description
Partition	Partition on the disk.
Size	Size of the partition.
Used	Partition size used.
Percent	Percentage used.
Avail	Available free partition space.