



MSTP BPDU Guard Commands

This section describes the commands used to configure MSTP BPDU Guard.



Note

All commands applicable for the Cisco NCS 5500 Series Router are also supported on the Cisco NCS 540 Series Router that is introduced from Cisco IOS XR Release 6.3.2. References to earlier releases in Command History tables apply to only the Cisco NCS 5500 Series Router.



Note

- Starting with Cisco IOS XR Release 6.6.25, all commands applicable for the Cisco NCS 5500 Series Router are also supported on the Cisco NCS 560 Series Routers.
 - Starting with Cisco IOS XR Release 6.3.2, all commands applicable for the Cisco NCS 5500 Series Router are also supported on the Cisco NCS 540 Series Router.
 - References to releases before Cisco IOS XR Release 6.3.2 apply to only the Cisco NCS 5500 Series Router.
 - Cisco IOS XR Software Release 7.0.1 specific updates are not applicable for the following variants of Cisco NCS 540 Series Routers:
 - N540-28Z4C-SYS-A
 - N540-28Z4C-SYS-D
 - N540X-16Z4G8Q2C-A
 - N540X-16Z4G8Q2C-D
 - N540-12Z20G-SYS-A
 - N540-12Z20G-SYS-D
 - N540X-12Z16G-SYS-A
 - N540X-12Z16G-SYS-D
-

For detailed information about concepts and configuration, see the Configure MSTP BPDU Guard chapter in the *L2VPN and Ethernet Services Configuration Guide for Cisco NCS 5500 Series Routers* and *L2VPN and Ethernet Services Configuration Guide for Cisco NCS 540 Series Routers*.

- [interface \(MSTP\)](#), on page 3
- [portfast](#), on page 4
- [spanning-tree mst](#), on page 5

interface (MSTP)

To enter the MSTP interface configuration submode, use the **interface** command in MSTP configuration submode.

interface *interface-type* *interface-path-id*

Syntax Description	<i>interface-type</i> Interface type. For more information, use the question mark (?) online help function.
	<i>interface-path-id</i> Physical interface.
	Note Use the show interfaces command to see a list of all possible interfaces currently configured on the router.
	For more information about the syntax for the router, use the question mark (?) online help function.

Command Default None

Command Modes MSTP configuration

Command History	Release	Modification
	Release 7.1.1	This command was introduced.

Usage Guidelines A given port may only be enabled with MSTP or PVRST.

Task ID	Task ID	Operations
	interface	read, write

Examples The following example shows how to enter the MSTP interface configuration submode:

```
Router(config-mstp)# interface GigabitEthernet 0/0/0/7
```

portfast

To enable PortFast feature on the port and enable BPDU guard, use the **portfast** command in MSTP interface configuration submode.

portfast [**bpduguard**]

Syntax Description	This command has no keywords or arguments.
---------------------------	--

Command Default	PortFast is disabled.
------------------------	-----------------------

Command Modes	MSTP interface configuration
----------------------	------------------------------

Command History	Release	Modification
	Release 7.1.1	This command was introduced.

Usage Guidelines	This command enables the portfast feature (also known as edge port). When this is enabled, MSTP treats the port as an edge port, i.e., it keeps it in forwarding state and does not generate topology changes if the port goes down or comes up. It is not expected to receive MSTP BPDUs on an edge port. BPDU guard is a Cisco extension that causes the interface to be shut down using error-disable if an MSTP BPDU is received.
-------------------------	---

Task ID	Task ID	Operations
	interface	read, write

Examples	The following example shows how to enable PortFast and BPDU guard on the port:
-----------------	--

```
Router(config-mstp-if)# portfast
Router(config-mstp-if)# portfast bpduguard
```

spanning-tree mst

To enter the MSTP configuration submode, use the **spanning-tree mst** command in global configuration mode.

spanning-tree mst *protocol-instance-identifier*

Syntax Description	<i>protocol-instance-identifier</i> String of a maximum of 25 characters that identifies the protocol instance.				
Command Default	None				
Command Modes	Global configuration				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 7.1.1</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 7.1.1	This command was introduced.
Release	Modification				
Release 7.1.1	This command was introduced.				

Usage Guidelines



Note In MSTP configuration, only one protocol instance can be configured at a time.

Task ID	Task ID	Operations
	interface	read, write

Examples

The following example shows how to enter the MSTP configuration submode:

```
Router(config)# spanning-tree mst m0
```

 spanning-tree mst