



# Ethernet Service Activation Test Commands

---

This chapter describes commands used in Ethernet Service Activation Tests.

- [ethernet service-activation-test profile, on page 2](#)
- [ethernet service-activation-test, on page 6](#)
- [show ethernet service-activation-test, on page 8](#)

# ethernet service-activation-test profile

To configure test parameters for a service activation test, use the **ethernet service-activation-test profile** command in XR Config mode.

**ethernet service-activation-test profile** *name* [ **apply-group** *text* | **color-aware** [ **cir** *cir-value* | **eir-color** [ **cos** *cos-value* | **set-dei** ] ] | **description** *text* | **duration** *time-duration* | **ethertype** *value* | **exclude-group** *text* | **frame-delay** **bins** *number-of-aggregation-bins* **width** *width-of-aggregation-bins* | **usec** *microseconds* | [ **minimum-delay** *width-of-first-aggregation-bin* | **frame-delay-range-percentile** *percentile* ] | **oam-level** *value* | **outer-cos** *cos-value* | **packet-format** *lbm* | **packet-size** *value* | **information-rate** [ **bs** *burst-size-value* | **ir** *value* ] | **measurement-combined** | **mode** *two-way* | **oam-level** *value* | **outer-cos** *cos-value* | **packet-format** *lbm* | **packet-size** [ *value* | **emix** *sequence* **h** ] ]

Syntax	Description
<b>apply-group</b> <i>text</i>	(Optional) Apply configuration from a group.
<b>eir-color</b>	(Optional) Specifies configuration for excess information rate (EIR) packets.
<b>cir</b> <i>cir-value</i>	(Optional) Specifies the color-aware configuration. The permitted values are in kbps   mbps   gbps. The range is 1 to 4294967295.
<b>cos</b> <i>cos-value</i>	(Optional) Specifies the CoS value for EIR packets. The range is 0 to 7.
<b>set-dei</b>	(Optional) Specifies the drop-eligibility-indicator (DEI) bit for EIR packets.
<b>description</b> <i>text</i>	(Optional) Specifies the description or identifier for the test.
<b>duration</b> <i>time-duration</i>	(Optional) Specifies the duration for which the SAT needs to be performed. The permitted values are in minutes   hours. The range is 1 to 1440.
<b>ethertype</b> <i>value</i>	(Optional) Specifies the ethertype to use in test packets. The permitted values are MSRP   STP   PFC   LACP   Link-OAM   ESMC   PNAC   LLDP   E-LMI   MVRP   MMRP   PTP   MIRP   VDP   PE-CSP   value <hex value>.

<b>exclude-group</b> <i>text</i>	(Optional) Specifies the apply-group configuration which needs to be excluded from a group.
<b>bin</b> <i>value</i>	(Optional) Specifies the number of aggregation bins. The range is 0 to 200.
<b>frame-delay-range-percentile</b> <i>percentile</i>	(Optional) Specifies the percentile for frame delay range. The permitted values are in <code>per-million percent</code> . The range is 1 to 99999 for per-million and 1 to 99 for percent.
<b>minimum-delay</b> <i>width-of-first-aggregation-bin</i>	(Optional) Specifies the frame delay of reporting configuration. The permitted values are in <code>milliseconds</code> . The range is 1 to 10000000.
<b>bs</b> <i>burst-size-value</i>	(Optional) Specifies the burst size to be use in tests. Entered in <code>GB KB MB</code> . The range is 1 to 1024.
<b>ir</b> <i>value</i>	(Optional) Specifies the information rate to be use in tests. The permitted values are in <code>kbps mbps gbps</code> . The range is 1 to 4294967295.
<b>measurement-combined</b>	(Optional) Displays the calculated frame loss and frame delay for SAT.
<b>mode two-way</b>	(Optional) Specifies the mode for tests.
<b>oam-level</b> <i>value</i>	(Optional) Specifies OAM level of the packets sent during the test. The range is 0 to 7.
<b>outer-cos</b> <i>cos-value</i>	(Optional) Sets the CoS to use in test packets. The range is 0 to 7.
<b>packet-format</b> <i>lbn</i>	(Optional) Enables the destination router to sends back the test traffic to the source router.
<b>packet-size</b> <i>value</i>	(Optional) Specifies the packet size and pattern to use for tests. Entered in bytes. The range is 64 to 10236.

<b>profile</b> <i>name</i>	(Optional) Specifies the profile where the SAT needs to be performed.
<b>width</b> <i>milliseconds</i>	(Optional) Specifies the width of each aggregation bin in milliseconds. The range is 1 to 10000. Or specifies the width of each aggregation bin in microseconds if usec is selected. Usec interprets the width in microseconds.
<b>usec</b> <i>microseconds</i>	Specifies the width of each aggregation bin in microseconds. The range is 1 to 10000000.
<b>emix sequence h</b>	Specifies the packet size as sequence h.

**Command Default** Disabled, by default

**Command Modes** XR Config mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 24.2.1	The command was modified to include <b>emix sequence h</b> keyword.
	Release 24.2.1	The command was modified to include <b>bins, width, minimum-delay, and frame-delay-range percentile</b> keywords.
	Release 24.1.1	The command was modified to include <b>measurement combined</b> and <b>packet-format lbm</b> keywords.
	Release 7.1.1	The command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	config-services	read, write

This example shows how to configure **measurement combined** for the SAT test profile **p1** using the **ethernet service-activation-test profile** command:

```
Router(config)#ethernet service-activation-test profile
Router(config-ethsat)#profile p1
Router(config-ethsat-prf)#outer-cos 2
Router(config-ethsat-prf)#duration 1 minutes
```

```
Router(config-ethsat-prf) #measurement combined
Router(config-ethsat-prf) #packet-size 1024
Router(config-ethsat-prf) #information-rate 1 gbps
Router(config-ethsat-prf) #commit
```

The following example shows how you can configure **bins, width, minimum-delay, frame-delay-range percentile** for measuring frame-delay range for SAT profile.

```
Router(config) #ethernet service-activation-test profile p1
Router(config-ethsat-prf) #frame-delay bins 4 width 24 minimum-delay 2 frame-delay-range
percentile percent 99
Router(config-ethsat-prf) #commit
```

The following example demonstrates how you can configure the **packet-size emix sequence h** command.

```
Router#configure
Router(config) #ethernet service activation test profile p1
Router(config-ethsat-prf) #packet-size emix sequence h
Router(config-ethsat-prf) #commit
```

# ethernet service-activation-test

To test service turn-up, installation, and troubleshooting of Ethernet-based services, execute the **ethernet-service-activation-test** command in XR EXEC mode.

```
ethernet-service-activation-test { start { interface interface-name profile profile-name duration value
destination mac-address direction { internal | external } [ source mac-address ] } | stop { all | interface
} }
```

<b>Syntax Description</b>	<b>destination</b> <i>mac-address</i>	Specifies the destination MAC address for SAT. Entered in H.H.H MAC address format.
	<b>direction</b>	Specifies the direction to be internal or external.
	<b>interface</b> <i>interface-name</i>	Specifies interface where SAT needs to be performed.
	<b>profile</b> <i>profile-name</i>	Specifies the profile where the SAT needs to be performed.
	<b>source</b> <i>mac-address</i>	(Optional) Specifies the source MAC address. Entered in H.H.H MAC address format.
	<b>start</b>	Starts the SAT.
	<b>stop</b>	Stops the SAT.
<b>Command Default</b>	Disabled, by default	
<b>Command Modes</b>	XR EXEC mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 24.1.1	The command was modified to include <b>source</b> keyword.
	Release 7.1.1	The command was introduced.
<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.	

Task ID	Task ID	Operation
	config-services	read, write

This example shows how to specify the source MAC address while executing SAT

```
Router# ethernet service-activation-test start interface TenGigE0/0/0/1 profile  
prof1 destination 00ab.6009.9c3c source 0000.1000.001d direction external
```

# show ethernet service-activation-test

To view statistics collected for a test, use the **show ethernet service-activation-test** command in EXEC mode.

**show ethernet service-activation-test** [ **in-progress** | **completed** ] [ **interface** *interface-name* ]

<b>Syntax Description</b>	<b>in-progress</b>	(Optional) Specifies statistics collected for a test which is in-progress.
	<b>completed</b>	(Optional) Specifies statistics collected for a test which is completed.
	<b>interface</b> <i>interface-name</i>	(Optional) Specifies interface where SAT needs to be performed.
<b>Command Default</b>	Enabled, by default	
<b>Command Modes</b>	EXEC mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.1.1	The command was introduced.
<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.	
<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	config-services	read

The **show ethernet service-activation-test** command displays the test statistics for an ITU-T Y.1564 SAT.

```
Router#show ethernet service-activation-test
Interface TenGigE0/0/0/19
Service activation tests permitted
Test in progress, 179 minute(s) remaining:
Duration 2 minute(s)
Information rate 5 Gbps
Color-blind
External, Two-way, Destination 0A:AA:0B:BB:0C:CC
Packet size 512, Pattern hex 0x00
Packet format: Y.1731 LBM
CoS not set
```