



VXLAN Commands

This section describes the commands used to configure VXLAN.

- [host-reachability protocol static](#), on page 2
- [interface nve](#), on page 3
- [member vni](#), on page 4
- [overlay-encapsulation vxlan](#), on page 5
- [show nve interface](#), on page 6
- [show nve vni](#), on page 7
- [source-interface loopback](#), on page 8

host-reachability protocol static

To configure the static control protocol for VXLAN tunnel endpoint reachability, use the **host-reachability protocol static** command in NVE interface configuration mode.

host-reachability protocol static

Command Default	None						
Command Modes	NVE interface configuration						
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 7.11.1</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 7.11.1	This command was introduced.		
Release	Modification						
Release 7.11.1	This command was introduced.						
Usage Guidelines	No specific guidelines impact the use of this command.						
Task ID	<table> <tr> <th>Task ID</th><th>Operation</th></tr> <tr> <td>interface</td><td>read, write</td></tr> <tr> <td>tunnel</td><td>read, write</td></tr> </table>	Task ID	Operation	interface	read, write	tunnel	read, write
Task ID	Operation						
interface	read, write						
tunnel	read, write						

Example

The following example shows control protocol configuration for VXLAN tunnel endpoint reachability.

```
Router(config)# interface nve1
Router(config-if)# member vni 2
Router(config-nve-vni)# host-reachability protocol static
Router(config-nve-vni)# commit
```

interface nve

To create a network virtualization endpoint (NVE) interface and enter the NVE interface configuration mode, use the **interface nve** command in global configuration mode. To remove the NVE interface, use the **no** form of this command.

interface nve *nve-id*

Syntax Description	<i>nve-id</i> The NVE interface ID. It can take values from 1 to 65535.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Global configuration
----------------------	----------------------

Command History	Release	Modification
	Release 7.11.1	This command was introduced.

Usage Guidelines	No specific guidelines impact the use of this command.
-------------------------	--

Task ID	Task ID	Operation
	interface	read, write

Example

The following example shows how to create an NVE interface and enter the NVE interface configuration mode.

```
Router(config)# interface nve 1  
Router(config-if)#
```

member vni

To map VXLAN to a network virtualization endpoint (NVE) interface, use the **member vni** command in the NVE interface configuration mode. To remove the VXLAN from the interface, use the **no** form of this command.

member vni *vni-number*

Syntax Description

vni-number The ID of the VXLAN to be mapped to the NVE. The valid values are from 1 to 16777215.

Command Default

None

Command Modes

NVE interface configuration

Command History

Release	Modification
Release 7.11.1	This command was introduced.

Usage Guidelines

No specific guidelines impact the use of this command.

Task ID

Task ID	Operation
interface	read, write
tunnel	read, write

Example

The following example shows the VXLAN with VNI "2" associated with the NVE "1".

```
Router(config)# interface nve 1
Router(config-if)# member vni 2
```

overlay-encapsulation vxlan

To define VXLAN as the encapsulation type for Network Virtualization Endpoint (NVE) interface, use the **overlay-encapsulation vxlan** command in NVE interface configuration mode. To remove the configured encapsulation on the NVE interface, use the **no** form of this command.

overlay-encapsulation vxlan

Command Default

None

Command Modes

NVE interface configuration

Command History

Release	Modification
Release 7.11.1	This command was introduced.

Usage Guidelines

No specific guidelines impact the use of this command.

Task ID

Task ID	Operation
interface	read, write
tunnel	read, write

Example

The following example shows an NVE interface configured for VXLAN encapsulation.

```
Router# configure
Router(config)# interface nve1
Router(config-if)# overlay-encapsulation vxlan
Router(config-nve-encap-vxlan)# commit
```

show nve interface

To display the network virtualization endpoint (NVE) interface information, use the **show nve interface** command in XR EXEC mode.

show nve interface [{ **detail** | **nve** *nve-id* }]

Syntax Description	detail	Displays detailed information about NVE interfaces.
	nve <i>nve-id</i>	Displays information only about the specified NVE interface.
Command Default	None	
Command Modes	XR EXEC	
Command History	Release	Modification
	Release 7.11.1	This command was introduced.
Usage Guidelines	No specific guidelines impact the use of this command.	
Task ID	Task ID	Operation
	interface	read

Example

This is the sample output of the **show interface nve** command anycast gateway parameters.

```
Router# show interface nve100 detail
Interface: nve100 State: Up Encapsulation: VxLAN
  Source Interface: Loopback1 (primary: 10.0.0.1)
  Source Interface State: Up
  NVE Flags: 0x1, Admin State: Up, Interface Handle 0xba0
  UDP Port: 4789
  Anycast Source Interface: Loopback100 (primary: 100.1.1.1)
```

show nve vni

To display list of all VNIs that are associated with various NVE interfaces and the associated multicast IP address that is used for multi-destination frames, use the **show nve vni** command in XR EXEC mode.

show nve vni [{ **vni_number** | **detail** | **interface nve nve-id** }]

Syntax Description	vni_number		Displays output for the specific VNI.
	detail		Displays more detailed output.
	interface nve nve-id		Displays details for the specific NVE interface.
Command Default	None		
Command Modes	XR EXEC		
Command History	Release	Modification	
	Release 7.11.1	This command was introduced.	
Usage Guidelines	No specific guidelines impact the use of this command.		
Task ID	Task ID	Operation	
	tunnel	read	

Example

The following shows an example output of this show command:

```
Router# show nve vni
Interface  VNI      MCAST      VNI State      Mode
nve3      1002      0.0.0.0     Up              L3 Control (Static)
nve1      17001     0.0.0.0     Up              L3 Control (Static)
nve2      17002     0.0.0.0     Up              L3 Control (Static)
nve3      17003     0.0.0.0     Up              L3 Control (Static)
```

source-interface loopback

To specify a loopback interface whose IP address should be set as the IP address for the NVE interface, use the **source-interface loopback** command.

source-interface loopback *interface-id*

Syntax Description	loopback	Specifies a loopback interface as providing IP address for the NVE interface.
	<i>interface-id</i>	Specifies the loopback interface ID. It can take values from 0 to 65535.
Command Default	None	
Command Modes	NVE interface configuration	
Command History	Release	Modification
	Release 7.11.1	This command was introduced.
Usage Guidelines	No specific guidelines impact the use of this command.	
Task ID	Task ID	Operation
	tunnel	read, write
	interface	read, write

Example

The following example shows how to configure the IP address of an NVE interface as the IP address of a loopback interface.

```
Router(config)# interface nve 1
Router(config-if)# source-interface loopback 1
```