



Netflow Configuration Guide for Cisco NCS 560 Series Routers, Cisco IOS XR Release 26.1.x

First Published: 2026-02-27

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at www.cisco.com/go/offices.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <https://www.cisco.com/c/en/us/about/legal/trademarks.html>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2025 Cisco Systems, Inc. All rights reserved.



CONTENTS

CHAPTER 1

Configuring NetFlow on Cisco IOS XR Software 1

- Prerequisites for Configuring NetFlow 1
- Restrictions for Configuring NetFlow 1
- Information About Configuring NetFlow 2
 - NetFlow Overview 2
 - Exporter Map Overview 3
 - Monitor Map Overview 4
 - Sampler Map Overview 4
- How to Configure NetFlow on Cisco IOS XR Software 5
 - Configuring an Exporter Map 5
 - Configuring a Sampler Map 8
 - Configuring a Monitor Map 9
 - Applying a Monitor Map and a Sampler Map to a Physical Interface 12
 - Applying a Monitor Map and a Sampler Map to a Layer 2 Bundle Interface 13
 - Clearing NetFlow Data 14
 - Configuring NetFlow Collection of MPLS Packets with IPv6 Fields 14
- Additional References 20

CHAPTER 2

Netflow Supported Features 23

- In-line Modification of Netflow Configuration 23
 - Use Case 24
- Options Template Overview 25
- Information About Configuring NetFlow 27
 - Information About Configuring NetFlow 27
 - NetFlow Configuration Submodes 27
 - MPLS Flow Monitor with IPv4 and IPv6 Support 29

Monitor GTP-U Traffic in 5G Network	31
Netflow Full Packet Capture	46
Configuring Netflow Full Packet Capture	47

CHAPTER 3

Configure IPFIX	49
IPFIX	49
Configuring IPFIX	49
IPFIX Enablement for SRv6 and Services over SRv6 Core	52
IP Flow Information Export (IPFIX) 315	57
IPFIX 315 Implementation Considerations	57
Configuring IPFIX 315	58



CHAPTER

1

Configuring NetFlow on Cisco IOS XR Software

A NetFlow flow is a unidirectional sequence of packets that arrive on a single interface, and have the same values for key fields.

NetFlow is useful for the following:

- Accounting or Billing—NetFlow data provides fine grained metering for highly flexible and detailed resource utilization accounting.
- Network Planning and Analysis—NetFlow data provides key information for strategic network planning.
- Network Monitoring—NetFlow data enables near real-time network monitoring capabilities.

This chapter includes the following sections:

- [Prerequisites for Configuring NetFlow, on page 1](#)
- [Restrictions for Configuring NetFlow, on page 1](#)
- [Information About Configuring NetFlow, on page 2](#)
- [How to Configure NetFlow on Cisco IOS XR Software, on page 5](#)
- [Additional References, on page 20](#)

Prerequisites for Configuring NetFlow

To perform these configuration tasks, your Cisco IOS XR software system administrator must assign you to a user group associated with a task group that includes the corresponding command task IDs. If you need assistance with your task group assignment, contact your system administrator.

Restrictions for Configuring NetFlow

Consider these restrictions when configuring NetFlow in Cisco IOS XR software:



Tip Do not use the management interface to export the NetFlow packets.

- NetFlow can be configured only in the ingress direction.

- A source interface must always be configured. If you do not configure a source interface, the exporter will remain in a disabled state.
- Only export format Version 9 and IPFIX is supported.
- A valid record map name must always be configured for every flow monitor map.
- NetFlow is not supported on Bridge Virtual Interface (BVI).
- NetFlow on sub-interface routed via BVI is not supported.
- Destination-based Netflow accounting is not supported, only IPv4, IPv6 and MPLS record types are supported under monitor-map.
- Output interface field is not updated in data and flow records when the traffic is routed through ACL based forwarding (ABF).
- Output interface, source, and destination prefix lengths fields is not updated in data and flow records for multicast traffic.
- Output interface, source and destination prefix lengths fields are not set in data and flow records for GRE transit traffic.
- For Netflow IPFIX315, configure the **hw-module profile netflow ipfix315** command.
- If IPFIX315 is enabled on a line card then all the ports on that line card should have IPFIX315 configured.
- For **hw-module profile qos hqos-enable**, NetFlow does not give the output interface for cases like L2 bridging, xconnect, IPFIX, and so on.
- L4 header port numbers are supported only for TCP and UDP.
- NetFlow does not give the output interface for traffic terminating on GRE tunnel.
- When SRv6 accounting (accounting prefixes in IPv6 mode **per-prefix per-nexthop SRv6-locators**) is enabled, the output interface field is not updated in data and flow records.

Information About Configuring NetFlow

NetFlow Overview

Netflow is used to create a statistical view of the flow matrix from the router - at the beginning of Netflow Overview section before explanation of flows.

A flow is exported as part of a NetFlow export User Datagram Protocol (UDP) datagram under these circumstances:

- The flow has been inactive or active for too long.
- The flow cache is getting full.
- One of the counters (packets and or bytes) has wrapped.
- The user forces the flow to export.

NetFlow export UDP datagrams are sent to an external flow collector device that provides NetFlow export data filtering and aggregation. The export of data consists of expired flows and control information.

The NetFlow infrastructure is based on the configuration and use of these maps:

- Exporter map
- Monitor map
- Sampler map

Cross AFI BGP NH information elements

Cross AFI BGP NH information elements specifies the next hop IP address for different network layer protocols in BGP routing. These elements ensure

- proper routing across diverse network environments by indicating the appropriate next hop based on the Address Family Identifier (AFI) and
- its Subsequent Address Family Identifier (SAFI).

Table 1: Feature History Table

Exporter Map Overview

An exporter map contains user network specification and transport layer details for the NetFlow export packet. The **flow exporter-map** command allows you to configure collector and version attributes. You can configure these collector information:

- Export destination IP address
- DSCP value for export packet
- Source interface
- UDP port number (This is where the collector is listening for NetFlow packets.)
- Transport protocol for export packets



Note In Cisco IOS XR Software, UDP is the only supported transport protocol for export packets.



Note NetFlow export packets use the IP address that is assigned to the source interface. If the source interface does not have an IP address assigned to it, the exporter will be inactive.

You can also configure these export version attributes:

- Template timeout
- Template data timeout
- Template options timeout

- Interface table timeout
- Sampler table timeout



Note A single flow monitor map can support up to eight exporters.

Monitor Map Overview

A monitor map contains name references to the flow record map and flow exporter map. Monitor maps are applied to an interface. You can configure these monitor map attributes:

- Number of entries in the flow cache
- Type of cache (permanent or normal). Permanent caches do not have their entries removed from the cache unless they are explicitly cleared by the user
- Active flow timeout
- Inactive flow timeout
- Update timeout
- Default timeouts
- Record type of packets sampled and collected



Note The record name specifies the type of packets that NetFlow samples as they pass through the router. Currently, MPLS, IPv4, and IPv6 packet sampling is supported.



Note The active flow and inactive flow timeouts are associated with a normal cache type. The update timeout is associated with the permanent cache type.

Sampler Map Overview

The sampler map specifies the rate at which packets (one out of n packets) are sampled. The sampler map configuration is typically geared for high-speed interfaces to optimize CPU utilization. To achieve this, start by setting the sampling rate after evaluating your network parameters such as traffic rate, number of total flows, cache size, active and inactive timers.

The sampling interval of 1:1000 packets is supported on Cisco NCS 540 Series Router.

Consider these points before applying sampler map:

- You must remove the existing netflow configuration before applying a new sampler map on an already existing netflow interface configuration.
- Sub-interfaces and physical interfaces under a port must have the same sampler map configuration.

How to Configure NetFlow on Cisco IOS XR Software

The steps that follow provide a general overview of NetFlow configuration:



Note We recommend that you not use the default ethernet VLAN (VLAN-1) in any of your network configurations. Traffic tagged with VLAN-1 may cause conflicts with other configurations.

Procedure

-
- Step 1** Create and configure an exporter map.
Step 2 Create and configure a monitor map and a sampler map.

Note

The monitor map must reference the exporter map you created in Step 1. If you do not apply an exporter-map to the monitor-map, the flow records are not exported, and aging is done according to the cache parameters specified in the monitor-map.

- Step 3** Apply the monitor map and sampler map to an interface.
These steps are described in detail in these sections:
-

Configuring an Exporter Map

Configure an exporter map and apply it to the monitor map with the **flow monitor-map** *map_name* **exporter** *map_name* command. You can configure the exporter map prior to configuring the monitor map, or you can configure the monitor map first and then configure and apply an exporter map later on.



Note Cisco IOS XR Software supports the configuration of a single collector only in the exporter map.

The steps that follow describe how to create and configure an exporter map and enable exporting of the sampler table or the interface table.

Procedure

-
- Step 1** **configure**

Example:

```
RP/0/RP0/CPU0:router#configure
```

Enters global configuration mode.

Step 2 **flow exporter-map** *map_name***Example:**

```
RP/0/RP0/CPU0:router(config)#flow exporter-map expmap-dtxr2
```

Creates an exporter map, configures the exporter map name, and enters flow exporter map configuration mode.

Step 3 **destination** *hostname_or_IP_address* [**vrf** *vrf-name*]**Example:**

```
RP/0/RP0/CPU0:router(config-fem)# destination 1.76.31.1
```

Configures the export destination for the flow exporter map. The destination can be a hostname, a VRF, or an IPv4/IPv6 address.

Step 4 **dscp** *dscp_value***Example:**

```
RP/0/RP0/CPU0:router(config-fem)# dscp 10
```

(Optional) Specifies the differentiated services codepoint (DSCP) value for export packets. Replace the *dscp_value* argument with a value in the range from 0 through 63.

Step 5 **source** *type interface-path-id***Example:**

```
RP/0/RP0/CPU0:router(config-fem)# source Loopback 0
```

Specifies a source interface, in the format *type interface-path-id*.

Step 6 **transport udp** *port***Example:**

```
RP/0/RP0/CPU0:router(config-fem)# transport udp 5999
```

(Optional) Specifies the destination port for UDP packets. Replace *port* with the destination UDP port value, in the range from 1024 through 65535.

Step 7 **version** *v9***Example:**

```
RP/0/RP0/CPU0:router(config-fem-ver)# version v9
```

(Optional) Enters flow exporter map version configuration submode.

Step 8 **options** {**interface-table** | **sampler-table** | **vrf-table**} [**timeout** *seconds*]**Example:**

```
RP/0/RP0/CPU0:router(config-fem-ver)# options sampler-table timeout 1800
```

(Optional) Configures the export timeout value for the sampler table. Replace *seconds* with the export timeout value, in the range from 1 through 604800 seconds.

Default is 1800 seconds.

Step 9 **template** [**data** | **options**] **timeout** *seconds***Example:**

```
RP/0/RP0/CPU0:router(config-fem-ver)# template data timeout 600
```

(Optional) Configures the export period for data packets. Replace *seconds* with the export timeout value, in the range from 1 through 604800 seconds.

Step 10 **commit**

Step 11 **exit**

Example:

```
RP/0/RP0/CPU0:router(config-fem-ver)# exit
```

Exits flow exporter map version configuration submode.

Step 12 **exit**

Example:

```
RP/0/RP0/CPU0:router(config)# exit
```

Enters XR EXEC mode.

Step 13 **show flow exporter-map map_name**

Example:

```
RP/0/RP0/CPU0:router# show flow exporter-map expmap-dtxr2
```

```
Flow Exporter Map : expmap-dtxr2
-----
Id                : 1
DestinationIpAddr : 1.76.31.1
VRFName           : default
SourceIfName      : Loopback0
SourceIpAddr      : 10.200.58.1
DSCP              : 10
TransportProtocol : UDP
TransportDestPort : 5999

Export Version: 9
  Common Template Timeout : 1800 seconds
  Options Template Timeout : 1800 seconds
  Data Template Timeout   : 600 seconds
  Interface-Table Export Timeout : 1800 seconds
  Sampler-Table Export Timeout : 0 seconds
  VRF-Table Export Timeout  : 0 seconds
```

Displays exporter map data.

Example

This example shows how to create a new flow exporter map called “fem1,” which uses the version 9 (V9) export format for NetFlow export packets. The data template flow-set is inserted into the V9 export packets once every 10 minutes, and the options interface table flow-set is inserted into the V9 export packet. The export packets are sent to the flow collector destination 10.1.1.1, where the source address is identical to the interface IP address of Loopback 0. The UDP destination port is 1024, and the DSCP value is 10:

```
RP/0/RP0/CPU0:router(config)# flow exporter-map fem1
```

```
RP/0/RP0/CPU0:router(config-fem)# destination 10.1.1.1
RP/0/RP0/CPU0:router(config-fem)# source Loopback 0
RP/0/RP0/CPU0:router(config-fem)# transport udp 1024
RP/0/RP0/CPU0:router(config-fem)# dscp 10
RP/0/RP0/CPU0:router(config-fem)# exit
RP/0/RP0/CPU0:router(config-fem)# version v9
RP/0/RP0/CPU0:router(config-fem-ver)# template data timeout 600
RP/0/RP0/CPU0:router(config-fem-ver)# options interface-table
RP/0/RP0/CPU0:router(config-fem-ver)# exit
```

Configuring a Sampler Map

Procedure

Step 1 **configure**

Example:

```
RP/0/RP0/CPU0:router#configure
```

Enters global configuration mode.

Step 2 **sampler-map** *map_name*

Example:

```
RP/0/RP0/CPU0:router(config)# sampler-map onein8k
RP/0/RP0/CPU0:router(config-sm)#
```

Creates a sampler map and enters sampler map configuration mode.

Step 3 **random 1 out-of** *sampling_interval*

Example:

```
RP/0/RP0/CPU0:router(config-sm)# random 1 out-of 8000
```

Configures the sampling interval to use random mode for sampling packets. Replace the *sampling_interval* argument with a number, in the range from 1 through 65535 units.

Note

The sampling interval of 1:1000 packets is supported.

Step 4 **commit**

Step 5 **exit**

Example:

```
RP/0/RP0/CPU0:router(config-sm)# exit
```

Exits sampler map configuration mode and enters the XR Config mode.

Step 6 **exit**

Example:

```
RP/0/RP0/CPU0:router(config)# exit
```

Exits the mode and enters XR EXEC mode.

Step 7 `show sampler-map map_name`**Example:**

```
RP/0/RP0/CPU0:router#show sampler-map onein8k
```

```
Sampler Map : onein8k
```

```
-----  
Id:      1  
Mode:    Random (1 out of 8000 Pkts)
```

Displays sampler map data.

Example

This example shows how to create a new sampler map called “fsm1,” which samples 1 out of 65535 packets:

```
RP/0/RP0/CPU0:router# sampler-map fsm1  
RP/0/RP0/CPU0:router(config-sm)# random 1 out-of 65535  
RP/0/RP0/CPU0:router(config)# exit
```

Configuring a Monitor Map

Procedure**Step 1** `configure`**Example:**

```
RP/0/RSP0/CPU0:router#configure
```

Enters global configuration mode.

Step 2 `flow monitor-map map_name`**Example:**

```
RP/0/RP0/CPU0:router(config)# flow monitor-map fmm-ipv4-dtxr2  
RP/0/RP0/CPU0:router(config-fmm)#
```

Creates a monitor map and configures a monitor map name and enters flow monitor map configuration submode.

Step 3 Do one of the following:

- `record ipv4`
- `record ipv4 [peer as]`
- `record ipv6`
- `record mpls [labels number]`
- `record mpls [ipv4-fields] [labels number]`

- **record mpls [ipv6-fields] [labels number]**
- **record mpls [ipv4-ipv6-fields] [labels number]**

Example:

```
RP/0/RP0/CPU0:router(config-fmm)# record ipv4
```

Configures the flow record map name for IPv4, IPv6, or MPLS.

- Use the **record ipv4** command to configure the flow record map name for IPv4. By default, you collect and export the originating autonomous system (AS) numbers.
- Use the **record ipv4 [peer-as]** command to record peer AS. Here, you collect and export the peer AS numbers.

Note

Ensure that the **bgp attribute-download** command is configured. Else, no AS is collected when the **record ipv4** or **record ipv4 peer-as** command is configured.

- Use the **record ipv6** command to configure the flow record map name for IPv6.
- Use the **record mpls labels** command with the *number* argument to specify the number of labels that you want to aggregate. By default, MPLS-aware NetFlow aggregates the top six labels of the MPLS label stack. The maximum value is 6.
- Use the **record mpls ipv4-fields** command to collect IPv4 fields in the MPLS-aware NetFlow.
- Use the **record mpls ipv6-fields** command to collect IPv6 fields in the MPLS-aware NetFlow.
- Use the **record mpls ipv4-ipv6-fields** command to collect IPv4 and IPv6 fields in the MPLS-aware NetFlow.

Note

For the **outbundlemember** option to be effective; you must configure monitor-map as following:

```
flow monitor-map nfmpls
record mpls ipv4-ipv6-fields
option outbundlemember
```

Step 4 **cache entries** *number***Example:**

```
RP/0/RP0/CPU0:router(config-fmm)# cache entries 65535
```

(Optional) Configures the number of entries in the flow cache. Replace the *number* argument with the number of flow entries allowed in the flow cache, in the range from 4096 through 1000000.

The default number of cache entries is 65535.

Step 5 **cache permanent****Example:**

```
RP/0/RP0/CPU0:router(config-fmm)# flow monitor-map fmm cache permanent
```

(Optional) Disables removal of entries from flow cache.

Step 6 **cache timeout** {*active timeout_value* | *inactive timeout_value* | **update** *timeout_value*}

Example:

```
RP/0/RP0/CPU0:router(config-fmm)# cache timeout inactive 120
```

(Optional) Configures the active, inactive, or update flow cache timeout value.

- The default timeout value for the inactive flow cache is 15 seconds.
- The default timeout value for the active flow cache is 1800 seconds.
- The default timeout value for the update flow cache is 1800 seconds.

Note

The **update** *timeout_value* keyword argument is used for permanent caches only. It specifies the timeout value that is used to export entries from permanent caches. In this case, the entries are exported but remain the cache.

Step 7 `exporter map_name`**Example:**

```
RP/0/RP0/CPU0:router(config-fmm)# exporter expmap-dtxr2
```

Associates an exporter map with a monitor map.

Note

A single flow monitor map can support up to eight exporters.

Step 8 `commit`**Step 9** `exit`**Example:**

```
RP/0/RP0/CPU0:router(config-fmm)# exit
```

Exits flow monitor map configuration submode.

Step 10 `exit`**Example:**

```
RP/0/RP0/CPU0:router(config)# exit
```

Exits XR Config mode.

Step 11 `show flow monitor-map map_name`**Example:**

```
RP/0/RP0/CPU0:router#show flow monitor-map fmm-ipv4-dtxr2
Flow Monitor Map : fmm-ipv4-dtxr2
```

```
-----
Id:                1
RecordMapName:     ipv4-raw
ExportMapName:     expmap-dtxr2
CacheAgingMode:    Normal
CacheMaxEntries:   65535
CacheActiveTout:   60 seconds
CacheInactiveTout: 120 seconds
```

```
CacheUpdateTout: N/A
CacheRateLimit: 2000
```

Displays flow monitor map data.

Example

This example shows how to create a new flow monitor map with name “fmm1”. This flow monitor map references the flow exporter map “fem1,” and sets the flow cache attributes to 10000 cache entries. The active entries from the cache are aged every 30 seconds, while the inactive entries from the cache are aged every 15 seconds. The record map for this monitor map is IPv4:

```
RP/0/RP0/CPU0:router(config)# flow monitor-map fmm1
RP/0/RP0/CPU0:router(config-fmm)# record ipv4
RP/0/RP0/CPU0:router(config-fmm)# exporter fem1
RP/0/RP0/CPU0:router(config-fmm)# cache entries 10000
RP/0/RP0/CPU0:router(config-fmm)# cache timeout active 30
RP/0/RP0/CPU0:router(config-fmm)# cache timeout inactive 15
RP/0/RP0/CPU0:router(config-fmm)# exit
```

Applying a Monitor Map and a Sampler Map to a Physical Interface

Perform these steps to apply a monitor map and a sampler map to an interface.

Procedure

Step 1 **configure**

Step 2 **interface** *type number*

Example:

```
RP/0/RP0/CPU0:router(config)# interface HundredGigE 0/4/0/8
RP/0/RP0/CPU0:router(config-if)#
```

Enters interface configuration mode.

Step 3 **flow [ipv4 | ipv6 | mpls] monitor** *monitor_map* **sampler** *sampler_map* {**ingress**}

Example:

```
RP/0/RP0/CPU0:router(config-if)# flow ipv4 monitor fmm sampler fsm ingress
```

Associates a monitor map and a sampler map with an interface.

Note

Only Ingress mode is supported.

Enter **ipv4** to enable IPV4 NetFlow on the specified interface. Enter **ipv6** to enable IPV6 NetFlow on the specified interface. Enter **mpls** to enable MPLS-aware NetFlow on the specified interface.

Step 4 **commit**

Example

This example shows how to apply the flow monitor “fmm1” and the sampler “fsm1” to the HundredGigE 0/3/0/0 interface in the ingress direction:

```
RP/0/RP0/CPU0:router(config)#interface HundredGigE 0/3/0/0
RP/0/RP0/CPU0:router(config-if)#flow ipv4 monitor fmm1 sampler fsm1 ingress
RP/0/RP0/CPU0:router(config-if)#exit
```

This example shows how to apply the flow monitor “MPLS-IPv6-fmm” and the sampler “FSM” to the HundredGigE 0/3/0/0 interface in the ingress direction:

```
RP/0/RP0/CPU0:router(config)#interface HundredGigE 0/3/0/0
RP/0/RP0/CPU0:router(config-if)# flow mpls monitor MPLS-IPv6-fmm sampler FSM ingress
RP/0/RP0/CPU0:router(config-if)#exit
```

Applying a Monitor Map and a Sampler Map to a Layer 2 Bundle Interface

Perform these steps to apply a monitor map and a sampler map to a Layer 2 bundle interface.

Procedure

Step 1 **configure**

Step 2 **interface** *type number*

Example:

```
RP/0/RP0/CPU0:router(config)# interface bundle-ethernet 1
RP/0/RP0/CPU0:router(config-if)#
```

Enters interface configuration mode.

Step 3 **flow [ipv4 | ipv6 | mpls] monitor** *monitor_map* **sampler** *sampler_map* {**ingress**}

Example:

```
RP/0/RP0/CPU0:router(config-if)# flow ipv4 monitor fmm sampler fsm ingress
```

Associates a monitor map and a sampler map with an interface.

Note

Only Ingress mode is supported.

Enter **ipv4** to enable IPV4 NetFlow on the specified interface. Enter **ipv6** to enable IPV6 NetFlow on the specified interface. Enter **mpls** to enable MPLS-aware NetFlow on the specified interface.

Step 4 **commit**

Example

This example shows how to apply the flow monitor “fmm1” and the sampler “fsm1” to the bundle-ethernet 1 interface in the ingress direction:

```
RP/0/RP0/CPU0:router(config)#interface bundle-ethernet 1
RP/0/RP0/CPU0:router(config-if)#flow ipv4 monitor fmm1 sampler fsm1 ingress
RP/0/RP0/CPU0:router(config-if)#exit
```

This example shows how to apply the flow monitor “MPLS-IPv6-fmm” and the sampler “FSM” to the bundle-ethernet 1 interface in the ingress direction:

```
RP/0/RP0/CPU0:router(config)#interface bundle-ethernet 1
RP/0/RP0/CPU0:router(config-if)# flow mpls monitor MPLS-IPv6-fmm sampler FSM ingress
RP/0/RP0/CPU0:router(config-if)#exit
```

Clearing NetFlow Data

Procedure

Step 1 **clear flow exporter** [*exporter_name*] {**restart** | **statistics**} **location** *node-id*

Example:

```
RP/0/RP0/CPU0:router# clear flow exporter statistics location 0/0/CPU0
```

Clears the flow exporter data.

Specify the **statistics** option to clear exporter statistics. Specify the **restart** option to export all of the templates that are currently configured on the specified node.

Step 2 **clear flow monitor** [*monitor_name*] **cache** [**force-export** | **statistics**] **location** *node-id*}

Example:

```
RP/0/RP0/CPU0:router# clear flow monitor cache force-export location 0/0/CPU0
```

Clears the flow monitor data.

Specify the **statistics** option to clear cache statistics. Specify the **force-export** option to export the data from cache to server first and then clear the entries from cache.

Configuring NetFlow Collection of MPLS Packets with IPv6 Fields

Procedure

Step 1 **configure**

Example:

```
RP/0/RP0/CPU0:router#configure
```

Enters global configuration mode.

Step 2 **flow exporter-map** *map_name*

Example:

```
RP/0/RP0/CPU0:router(config)#flow exporter-map expmap-dtxr2
```

Creates an exporter map, configures the exporter map name, and enters flow exporter map configuration mode.

Step 3 **version v9****Example:**

```
RP/0/RP0/CPU0:router(config-fem)#version v9
```

(Optional) Enters flow exporter map version configuration submenu.

Step 4 **options {interface-table | sampler-table} [timeout seconds]****Example:**

```
RP/0/RP0/CPU0:router(config-fem-ver)#options interface-table timeout 300
```

(Optional) Configures the export timeout value for the interface table or the sampler table. Replace *seconds* with the export timeout value, in the range from 1 through 604800 seconds. The default is 1800 seconds for both the interface table and the sample table.

You must perform this step twice to configure the export timeout value for both an interface table and a sample table.

Step 5 **template [data | options] timeout seconds****Example:**

```
RP/0/RP0/CPU0:router(config-fem-ver)#template data timeout 300
```

(Optional) Configures the export period for data packets or options packets. Replace *seconds* with the export timeout value, in the range from 1 through 604800 seconds.

You must perform this step twice to configure the export period for both data packets and options packets.

Step 6 **exit****Example:**

```
/CPU0:router(config-fem-ver)#exit
```

Exits flow exporter map version configuration mode, and enters flow exporter map configuration mode.

Step 7 **transport udp port****Example:**

```
RP/0/RP0/CPU0:router(config-fem)#transport udp 12515
```

(Optional) Specifies the destination port for UDP packets. Replace *port* with the destination UDP port value, in the range from 1024 through 65535.

Step 8 **source type interface-path-id****Example:**

```
RP/0/RP0/CPU0:router(config-fem)#source Loopback0
```

Specifies a source interface, in the format *type interface-path-id*.

Step 9 **destination hostname_or_IP_address**

Example:

```
RP/0/RP0/CPU0:router(config-fem)#destination 170.1.1.11
```

Configures the export destination for the flow exporter map. The destination can be a hostname or an IPv4/IPv6 address.

Step 10 **exit****Example:**

```
RP/0/RP0/CPU0:router(config-fem)#exit
```

Exits flow exporter map configuration mode, and enters XR Config mode.

Step 11 **flow monitor-map** *map_name***Example:**

```
RP/0/RP0/CPU0:router(config)#flow monitor-map MPLS-IPv6-fmm
```

Creates a monitor map and configures a monitor map name and enters flow monitor map configuration submode.

Step 12 **record mpls** [**ipv4-ipv6-fields**] [**labels** *number*]**Example:**

```
RP/0/RP0/CPU0:router(config-fmm)#record mpls ipv6-fields labels 3
```

Configures the flow record map name for IPv4, IPv6, or MPLS. Use the **ipv4-ipv6-fields** keyword to collect IPv4 and IPv6 fields in an MPLS-aware NetFlow.

Step 13 **exporter** *map_name***Example:**

```
RP/0/RP0/CPU0:router(config-fmm)#exporter expl
```

Associates an exporter map with a monitor map.

Note

A single flow monitor map can support up to eight exporters.

Step 14 **cache entries** *number***Example:**

```
RP/0/RP0/CPU0:router(config-fmm)#cache entries 65535
```

(Optional) Configures the number of entries in the flow cache. Replace the *number* argument with the number of flow entries allowed in the flow cache, in the range from 4096 through 1000000.

The default number of cache entries is 65535.

Step 15 **cache timeout** {**active** *timeout_value* | **inactive** *timeout_value* | **update** *timeout_value*}**Example:**

```
RP/0/RP0/CPU0:router(config-fmm)#cache timeout inactive 120
```

(Optional) Configures the active, inactive, or update flow cache timeout value.

- The default timeout value for the inactive flow cache is 15 seconds.
- The default timeout value for the active flow cache is 1800 seconds.
- The default timeout value for the update flow cache is 1800 seconds.

Note

The **inactive** and **active** keywords are not applicable to permanent caches.

Note

The **update** keyword is used for permanent caches only. It specifies the timeout value that is used to export entries from permanent caches. In this case, the entries are exported but remain the cache.

Step 16 **cache permanent****Example:**

```
RP/0/RP0/CPU0:router(config-fmm)#flow monitor-map fmm cache permanent
```

(Optional) Disables the removal of entries from flow cache.

Step 17 **exit****Example:**

```
RP/0/RP0/CPU0:router(config-fmm)#exit
```

Exits flow monitor map configuration submode.

Step 18 **sampler-map *map_name*****Example:**

```
RP/0/RP0/CPU0:router(config)#sampler-map fsm
RP/0/RP0/CPU0:router(config-sm)#
```

Creates a sampler map and enters sampler map configuration mode.

Step 19 **random 1 out-of *sampling_interval*****Example:**

```
RP/0/RP0/CPU0:router(config-sm)#random 1 out-of 65535
```

Configures the sampling interval to use random mode for sampling packets. Replace the *sampling_interval* argument with a number, in the range from 1 through 65535 units.

Step 20 **exit****Example:**

```
RP/0/RP0/CPU0:router(config-sm)#exit
```

Exits sampler map configuration mode and enters XR Config mode.

Step 21 **interface *type number*****Example:**

```
RP/0/RP0/CPU0:router(config)#interface HundredGigE 0/3/0/0
RP/0/RP0/CPU0:router(config-if)#
```

Enters interface configuration mode.

Step 22 **flow [ipv4 | ipv6 | mpls] monitor monitor_map sampler sampler_map {ingress}**

Example:

```
RP/0/RP0/CPU0:router(config-if)#flow ipv4 monitor MPLS-IPv6-fmm sampler fsm ingress
```

Associates a monitor map and a sampler map with an interface.

Enter **ipv4** to enable IPV4 NetFlow on the specified interface. Enter **ipv6** to enable IPV6 NetFlow on the specified interface. Enter **mpls** to enable MPLS-aware NetFlow on the specified interface.

Step 23 **commit**

Step 24 **exit**

Example:

```
RP/0/RP0/CPU0:router(config-if)# exit
```

Exits interface configuration submode for the Ethernet interface.

Step 25 **exit**

Example:

```
RP/0/RP0/CPU0:router(config)# exit
```

Exits XR Config mode.

Step 26 **show flow monitor-map map_name**

Example:

```
RP/0/RP0/CPU0:router#show flow monitor-map MPLS-IPv6-fmm
```

```
Flow Monitor Map : MPLS-IPv6-fmm
```

```
-----
Id:                1
RecordMapName:     ipv4-raw
ExportMapName:     expmap-dtxr2
CacheAgingMode:    Normal
CacheMaxEntries:   65535
CacheActiveTout:   60 seconds
CacheInactiveTout: 120 seconds
CacheUpdateTout:   N/A
CacheRateLimit:    2000
RP/0/RP0/CPU0:ios#
```

Displays flow monitor map data.

Step 27 **show flow exporter-map map_name**

Example:

```
RP/0/RP0/CPU0:router#show flow exporter-map expmap-dtxr2
Flow Exporter Map : expmap-dtxr2
```

```
-----
Id                : 1
DestinationIpAddr : 170.1.1.11
```

```

VRFName           : default
SourceIfName      : Loopback0
SourceIpAddr      : 10.200.58.1
DSCP              : 10
TransportProtocol : UDP
TransportDestPort : 12515

Export Version: 9
  Common Template Timeout : 300 seconds
  Options Template Timeout : 300 seconds
  Data Template Timeout : 600 seconds
  Interface-Table Export Timeout : 300 seconds
  Sampler-Table Export Timeout : 0 seconds
  VRF-Table Export Timeout : 0 seconds

```

Displays exporter map data.

Example

This configuration collects MPLS traffic with IPv4 payloads.

```

RP/0/RP0/CPU0:router(config)#flow monitor-map MPLS-IPv4-fmm
RP/0/RP0/CPU0:router(config-fmm)#record mpls IPv4-fields labels 3
RP/0/RP0/CPU0:router(config-fmm)#cache permanent
RP/0/RP0/CPU0:router(config-fmm)#exit
RP/0/RP0/CPU0:router(config)#interface HundredGigE 0/3/0/0
RP/0/RP0/CPU0:router(config-if)#flow mpls monitor MPLS-IPv4-fmm sampler fsm ingress

```

This configuration collects MPLS traffic with IPv6 payloads.

```

RP/0/RP0/CPU0:router(config)#flow monitor-map MPLS-IPv6-fmm
RP/0/RP0/CPU0:router(config-fmm)# record mpls IPv6-fields labels 3
RP/0/RP0/CPU0:router(config-fmm)#cache permanent
RP/0/RP0/CPU0:router(config-fmm)#exit
RP/0/RP0/CPU0:router(config)#interface HundredGigE 0/3/0/0
RP/0/RP0/CPU0:router(config-if)#flow mpls monitor MPLS-IPv6-fmm sampler fsm ingress

```

This example shows how to configure the NetFlow monitor to collect MPLS packets with IPv6 fields:

```

RP/0/RP0/CPU0:router#config
RP/0/RP0/CPU0:router(config)#flow exporter-map expl
RP/0/RP0/CPU0:router(config-fem)#version v9
RP/0/RP0/CPU0:router(config-fem-ver)#options interface-table timeout 300
RP/0/RP0/CPU0:router(config-fem-ver)#options sampler-table timeout 300
RP/0/RP0/CPU0:router(config-fem-ver)#template data timeout 300
RP/0/RP0/CPU0:router(config-fem-ver)#template options timeout 300
RP/0/RP0/CPU0:router(config-fem-ver)#exit
RP/0/RP0/CPU0:router(config-fem)#transport udp 12515
RP/0/RP0/CPU0:router(config-fem)#source Loopback0
RP/0/RP0/CPU0:router(config-fem)#destination 170.1.1.11
RP/0/RP0/CPU0:router(config-fem)#exit
RP/0/RP0/CPU0:router(config)#flow monitor-map MPLS-IPv6-fmm
RP/0/RP0/CPU0:router(config-fmm)#record mpls ipv6-fields labels 3
RP/0/RP0/CPU0:router(config-fmm)#exporter expl
RP/0/RP0/CPU0:router(config-fmm)#cache entries 10000
RP/0/RP0/CPU0:router(config-fmm)#cache permanent
RP/0/RP0/CPU0:router(config-fmm)#exit

RP/0/RP0/CPU0:router(config)#sampler-map FSM
RP/0/RP0/CPU0:router(config-sm)#random 1 out-of 65535
RP/0/RP0/CPU0:router(config-sm)# exit

```

```
RP/0/RP0/CPU0:router (config) #interface HundredGigE 0/3/0/0
RP/0/RP0/CPU0:router (config-if) #flow mpls monitor MPLS-IPv6-fmm sampler FSM ingress
```

This configuration collects MPLS traffic with both IPv6 and IPv4 fields.

```
RP/0/RP0/CPU0:router (config) #flow monitor-map MPLS-IPv4-IPv6-fmm
RP/0/RP0/CPU0:router (config-fmm) # record mpls IPv4-IPv6-fields labels 3
RP/0/RP0/CPU0:router (config-fmm) #cache permanent
RP/0/RP0/CPU0:router (config-fmm) #exit
RP/0/RP0/CPU0:router (config) #interface HundredGigE 0/3/0/0
RP/0/RP0/CPU0:router (config-if) #flow mpls monitor MPLS-IPv4-IPv6-fmm sampler fsm ingress
```



Note Flow records are exported using the Version 9 format.

Additional References

These sections provide references related to interface configuration.

Related Documents

Related Topic	Document Title
Cisco IOS XR interface configuration commands	<i>Interface and Hardware Component Command Reference for Cisco NCS 5500 and NCS 540 and NCS 560 Series Routers</i>
Initial system bootup and configuration information for a router using the Cisco IOS XR software.	
Information about user groups and task IDs	<i>Interface and Hardware Component Command Reference for Cisco NCS 5500 and NCS 540 and NCS 560 Series Routers</i>
Information about configuring interfaces and other components from a remote Craft Works Interface (CWI) client management application.	Cisco Craft Works Interface User Guide

Standards

Standards	Title
No new or modified standards are supported by this feature, and support for existing standards has not been modified by this feature.	—

MIBs

MIBs	MIBs Link
—	Text for MIBs: To locate and download MIBs using Cisco IOS XR software, use the MIB Locator found at the Cisco Feature Navigator.

RFCs

RFCs	Title
3954	NetFlow services export protocol Version 9.
7011	IPFIX protocol

Technical Assistance



CHAPTER 2

Netflow Supported Features

- [In-line Modification of Netflow Configuration, on page 23](#)
- [Options Template Overview, on page 25](#)
- [Information About Configuring NetFlow, on page 27](#)
- [Netflow Full Packet Capture, on page 46](#)

In-line Modification of Netflow Configuration

The In-line modification of Netflow configuration enables to add or remove flow attributes of a flow entity that is already applied to an interface.

A flow entity can be a monitor map, exporter map or a sampler map.

Netflow does not support in-line modification of all its configuration items. This table lists flow entries and flow attributes that are in-line modifiable.



Note In-line modification of flow items clears the cache counters. As a result there could be flow accounting mismatch.

Table 2: In-line Modifiable Flow Entities and Flow Attributes

Flow Entity	Flow Attribute
Monitor map Note Any modification to the cache attributes results in resetting of the cache counters. The cache flows are dropped not exported.	cache timeout active <i>seconds</i>
	cache timeout inactive <i>seconds</i>
	cache timeout update <i>seconds</i>
	cache timeout rate-limit <i>seconds</i>
	exporter
	cache entries
	cache permanent
	option outphysint bgstrings
Exporter Map Note Any modification to an exporter map results in resetting of the exporter counter.	source <source interface>
	destination <destinaiton address>
	dscp <dscp_value>
	version v9 ipfix
Sampler Map	sampling interval

Restriction

- In-line modification of the **record ipv4** flow attribute is not supported.

Use Case

Consider a netflow configuration as shown below applied on Bundle interface.

```
RP/0/RP1/CPU0:router#show running-config interface bundle-ether 8888
Thu Oct 26 14:17:17.459 UTC
interface Bundle-Ether8888
ipv4 address 192.168.108.1 255.255.255.252
  ipv6 address 192:168:108::1/126
flow ipv6 monitor MONITOR-8k sampler SAMPLER-8k ingress
!
RP/0/RP1/CPU0:router#show running-config flow monitor-map MONITOR-8k
Thu Oct 26 14:17:32.581 UTC
flow monitor-map MONITOR-8k
  record ipv6
  exporter NF-2
  cache timeout update 30
!
```

The Netflow configuration includes:

- flow monitor map—MONITOR-8k: The flow monitor map do not have cache entries configured. Cache entries are the number of entries in the flow cache.

- exporter map—NF-2
- sampler map—SAMPLE-8k

The **cache entries** attribute is in-line modifiable. Let us configure the cache entries, while the flow monitor map is in use:

```
RP/0/RP1/CPU0:router#config
RP/0/RP1/CPU0:router(config)#flow monitor-map MONITOR-8k
RP/0/RP1/CPU0:router(config-fmm)#cache entries 8000
RP/0/RP1/CPU0:router(config-fmm)#commit
Thu Oct 26 14:18:24.625 UTC
RP/0/RP1/CPU0:Oct 26 14:18:24.879 : config[67366]: %MGBL-CONFIG-6-DB_COMMIT : Configuration
committed by user '<username>'.
Use 'show configuration commit changes 1000000556' to view the changes. /*configuration
commit is successfull. */
```

The above configuration changes are committed successfully.

Verification

To verify if the monitor map has cache entries of 8000 configured, use the **show flow monitor-map** command for MONITOR-8k map:

```
RP/0/RSP0/CPU0:router# show flow monitor-map MONITOR-8k

Flow Monitor Map : MONITOR-8k
-----
Id:                1
RecordMapName:     ipv6
ExportMapName:     NF-2
CacheAgingMode:    Permanent
CacheMaxEntries:   8000
CacheActiveTout:  N/A
CacheInactiveTout: N/A
CacheUpdateTout:  30 seconds
```

Options Template Overview

NetFlow version 9 is a template-based version. The templates provide an extensible design to the record format. This feature allows enhancements to NetFlow services without requiring concurrent changes to the basic flow-record format. An options template is a special type of template record that is used to communicate the format of data related to the NetFlow process. Rather than supplying information about IP flows, the options are used to supply metadata about the NetFlow process itself. The sampler options template and the interface options template are different forms of options templates. These two tables are exported by the NetFlow process. The NetFlow process will also export the VRF table.

Sampler Table

The sampler options template consists of sampler tables. Similarly, the interface option templates consist of interface tables. By enabling the options for sampler table and interface table, it becomes easier for the collector to determine the information on data flow.

The sampler table consists of information on the active samplers. It is used by the collector to estimate the sampling rate for each data flow. The sampler table consists of the following information for each sampler:

Field Name	Value
FlowSamplerID	This ID is assigned to the sampler. It is used by the collector to retrieve information about the sampler for a data flow record.
FlowSamplerMode	This field indicates the mode in which the sampling has been performed.
FlowSamplerRandomInterval	This field indicates the rate at which the sampling is performed.
SamplerName	This field indicates the name of the sampler.

Interface Table

The interface table consists of information on interfaces that are being monitored for data flow. By using this information, the collector determines the names of interfaces associated with the data flow. The interface table consists of the following information:

Field Name	Value
ingressInterface	This field indicates the SNMP index assigned to the interface. By matching this value to the Ingress interface in the data flow record, the collector is able to retrieve the name of the interface.
interfaceDescription	This field indicates the name of the interface.

VRF Table

The VRF table consists of mapping of VRF IDs to the VRF names. By using this information, the collector determines the name of the required VRF. The VRF table consists of the following information:

Field Name	Value
ingressVRFID	The identifier of the VRF with the name in the VRF-Name field.
VRF-Name	The VRF name which has the VRFID value ingressVRFID. The value "default" indicates that the interface is not assigned explicitly to a VRF.

The data records contain ingressVRFID as an extra field in each record. The values of these fields are used to lookup the VRF Table to find the VRF names. A value 0 in these fields indicates that the VRF is unknown.

The VRF table is exported at intervals specified by the optional **timeout** keyword that can be configured manually. The default value is 1800 seconds.

Information About Configuring NetFlow

Information About Configuring NetFlow

NetFlow Configuration Submodes

In Cisco IOS XR Software, NetFlow map configuration takes place in map-specific submodes. Cisco IOS XR Software supports these NetFlow map configuration submodes:



Note The Cisco IOS XR Software allows you to issue most commands available under submodes as one single command string from mode. For example, you can issue the **record ipv4** command from the flow monitor map configuration submode as follows:

```
RP/0/RP0/CPU0:router(config)# flow monitor-map fmm
RP/0/RP0/CPU0:router(config-fmm)# record ipv4
```

Alternatively, you can issue the same command from global configuration mode, as shown in the following example:

```
RP/0/RP0/CPU0:router(config)# flow monitor-map fmm record ipv4
```

Flow Monitor Map Configuration Submode

When you issue the **flow monitor-map** *map_name* command in mode, the CLI prompt changes to “config-fmm,” indicating that you have entered the flow monitor map configuration submode.

In this sample output, the question mark (?) online help function displays all the commands available under the flow monitor map configuration submode:

```
RP/0/RP0/CPU0:router(config)# flow monitor-map fmm
RP/0/RP0/CPU0:router(config-fmm)# ?

cache      Specify flow cache attributes
commit     Commit the configuration changes to running
describe   Describe a command without taking real actions
do         Run an exec command
exit       Exit from this submode
exporter   Specify flow exporter map name
no         Negate a command or set its defaults
record     Specify a flow record map name
show      Show contents of configuration
```

Flow Exporter Map Version Configuration Submode

When you issue the **version v9** command in the flow exporter map configuration submode, the CLI prompt changes to “config-fem-ver,” indicating that you have entered the flow exporter map version configuration submode.

In this sample output, the question mark (?) online help function displays all the commands available under the flow exporter map version configuration submode:

```
RP/0/RP0/CPU0:router(config-fem)# version v9

RP/0/RP0/CPU0:router(config-fem-ver)# ?

commit      Commit the configuration changes to running
describe    Describe a command without taking real actions
do          Run an exec command
exit        Exit from this submode
no          Negate a command or set its defaults
options     Specify export of options template
show        Show contents of configuration
template    Specify template export parameters
```

Flow Monitor Map Configuration Submode

When you issue the **flow monitor-map** *map_name* command in mode, the CLI prompt changes to “config-fmm,” indicating that you have entered the flow monitor map configuration submode.

In this sample output, the question mark (?) online help function displays all the commands available under the flow monitor map configuration submode:

```
RP/0/RP0/CPU0:router(config)# flow monitor-map fmm

RP/0/RP0/CPU0:router(config-fmm)# ?

cache       Specify flow cache attributes
commit      Commit the configuration changes to running
describe    Describe a command without taking real actions
do          Run an exec command
exit        Exit from this submode
exporter    Specify flow exporter map name
no          Negate a command or set its defaults
record      Specify a flow record map name
show        Show contents of configuration
```

Sampler Map Configuration Submode

When you issue the **sampler-map** *map_name* command in mode, the CLI prompt changes to “config-sm,” indicating that you have entered the sampler map configuration submode.

In this sample output, the question mark (?) online help function displays all the commands available under the sampler map configuration submode:

```
RP/0/RP0/CPU0:router(config)# sampler-map fmm

RP/0/RP0/CPU0:router(config-sm)# ?

clear       Clear the uncommitted configuration
clear       Clear the configuration
commit      Commit the configuration changes to running
describe    Describe a command without taking real actions
do          Run an exec command
exit        Exit from this submode
no          Negate a command or set its defaults
pwd         Commands used to reach current submode
random      Use random mode for sampling packets
```

```
root      Exit to the global configuration mode
show      Show contents of configuration
```

Enabling the NetFlow BGP Data Export Function

Use the **bgp attribute-download** command to enable NetFlow BGP routing attribute collection. The routing attributes are then exported. When no routing attributes are collected, zeroes (0) are exported.

When BGP attribute download is enabled, BGP downloads the attribute information for prefixes (community, extended community, and as-path) to the Routing Information Base (RIB) and Forwarding Information Base (FIB). This enables FIB to associate the prefixes with attributes and send the NetFlow statistics along with the associated attributes.

MPLS Flow Monitor with IPv4 and IPv6 Support

Cisco IOS XR Software supports the NetFlow collection of MPLS packets. It also supports the NetFlow collection of MPLS packets carrying IPv4, IPv6, or both IPv4 and IPv6 payloads.

MPLS Cache Reorganization to Support Both IPv4 and IPv6

In Cisco IOS XR Software, at a time, you can have only one MPLS flow monitor running on an interface. If you apply an additional MPLS flow monitor to the interface, the new flow monitor overwrites the existing one.

You can configure the MPLS flow monitor to collect IPv4 fields, IPv6 fields, or IPv4-IPv6 fields. IPv4-IPv6 configuration collects both IPv4 and IPv6 addresses using one MPLS flow monitor. IPv4 configuration collects only IPv4 addresses. IPv6 configuration collects only IPv6 addresses.

The MPLS flow monitor supports up to 1,000,000 cache entries. NetFlow entries include these types of fields:

- IPv4 fields
- IPv6 fields
- MPLS with IPv4 fields
- MPLS with IPv6 fields

The maximum number of bytes per NetFlow cache entry is as follows:

- IPv4–88 bytes per entry
- IPv6–108 bytes per entry
- MPLS with IPv4 fields–108 bytes per entry
- MPLS with IPv6 fields–128 bytes per entry



Note The different types of NetFlow entries are stored in separate caches. Consequently, the number of NetFlow entries on a line card can significantly impact the amount of available memory on the line card. Also, even though the sampling rate for IPv6 is the same as the sampling rate for IPv4, the CPU utilization for IPv6 is higher due to the longer keys used by the IPv6 fields.

MPLS Packets with IPv6 Flows

Table 3: Feature History Table

Feature Name	Release Information	Feature Description
MPLS top label type 4 for BGP Labeled Unicast traffic	Release 7.4.1	<p>This feature is an enhancement to how Netflow MPLS records are verified. This feature allows the user to analyze the traffic types by providing more visibility on the granularity of the information. This feature helps you to monitor the traffic data.</p> <p>This feature introduces the new MPLS label type BGP. This label type is a field in the MPLS label that identifies the control protocol which allocates the top-of-stack label. MPLS label types enable verification of Netflow MPLS records.</p>

The collection of IPv6 flows in MPLS packets is an option. The CPU uses 128 bytes for each IPv6 field. IPv6 flows may contain these types of information:

- Source IP address
- Destination IP address
- Traffic class value
- Layer 4 protocol number
- Layer 4 source port number
- Layer 4 destination port number
- Flow ID
- Header option mask

To collect the IPv6 fields in MPLS packets, you must activate the MPLS record type, `ipv6-fields` by running the **`record mpls ipv6-fields`** command. You can also specify the number of labels to be used for aggregation with this command.

Monitor GTP-U Traffic in 5G Network

Table 4: Feature History Table

Feature Name	Release Information	Feature Description
Monitor GTP-U Traffic in 5G Network	Release 24.2.1	<p>You now get a comprehensive view of your 5G network's performance and gain detailed insights into slice utilization, deployed QoS policies, and their impact on traffic. This includes verifying deployed QoS policies, assessing 5G slice mechanisms, and tracking GTP-U endpoints for specific applications. This feature specifically applies to 5G network slicing when the GTP User Plane carries data within the core network and to the radio access network. This is achieved by exporting GTP-U related Information Elements using Netflow and IPFIX records to collectors for analysis.</p> <p>This feature introduces these changes:</p> <p>CLI:</p> <ul style="list-style-type: none"> The gtp keyword is introduced in the record ipv4 and record ipv6 commands.

Cisco 8000 routers introduces the capability to monitor the performance of GTP-U traffic in 5G networks. This feature utilizes Netflow and IPFIX to collect and analyze traffic data, offering valuable insights into network performance and facilitating effective management of 5G network traffic.

Starting from IOS-XR software release 24.2.1, three new GTP-U related information elements can be gathered in Netflow and IPFIX records for both IPv4 and IPv6 traffic. This advancement allows administrators to optimize the performance and security of their 5G networks.

The newly introduced information elements are as follows:

IE Field	IE Number
GTP_TEID	507
GTP_QFI	509
GTP_SESS_DIR	510

IE number, or Information Element Number, is a unique identifier assigned to specific elements within network communication protocols, facilitating standardized interpretation and management. For more information, refer IP Flow Information Export (IPFIX) Entities.

Benefits of GTP-U Traffic Monitoring

The following are some of the key benefits of enabling GTP-U traffic monitoring on your router.

- **Monitor Network Slicing:** 5G network slicing enables the creation of dedicated virtual networks with specific functionalities. By exporting GTP traffic records, you can conduct detailed analysis of the traffic within each slice, ensuring optimal performance and resource allocation.
- **Flexible Deployment:** GTP-U monitoring can be implemented on any network node where the outermost traffic encapsulation utilizes the GTP protocol. This capability can be activated to monitor traffic at various strategic points across the network infrastructure.
- **IPv6 Support for 5G Deployments:** With the expansion of 5G networks, there's an increasing use of IPv6, especially in scenarios where 5G base stations (gNodeBs) connect to User Plane Functions (UPFs) using IPv6. This feature ensures that flow records for such IPv6 GTP-U traffic can be captured and exported effectively.

GTP-U Traffic Record Templates

This section provides you with all the record template options available for monitoring GTP-U traffic.

IPv4-GTP-IPv4 Record

This record captures GTP-U traffic details between IPv4 interfaces, essential for monitoring and optimizing IPv4 5G network performance.

S.No	IPFIX			NetFlow V9		
	IE #	Field	Size (Bytes)	IE #	Field	Size (Bytes)
46	256	V9_ETH_TYPE	2	256	V9_ETH_TYPE	2
47	243	V9_DOT1Q_VLAN_ID	2	243	V9_DOT1Q_VLAN_ID	2
48	245	V9_DOT1Q_CUST_VLAN_ID	2	245	V9_DOT1Q_CUST_VLAN_ID	2
49	244	V9_DOT1Q_PRIORITY	1	244	V9_DOT1Q_PRIORITY	1
50	198	IN_BYTES_DELTA	8	444	V9_AS_PATH	128
1	2	V9_IN_PKTS	8	2	V9_IN_PKTS	4
2	1	V9_IN_BYTES	8	1	V9_IN_BYTES	4
3	10	V9_INPUT_SNMP	4	10	V9_INPUT_SNMP	4
4	14	V9_OUTPUT_SNMP	4	14	V9_OUTPUT_SNMP	4
5	22	V9_FIRST_SWITCHED	4	22	V9_FIRST_SWITCHED	4
6	21	V9_LAST_SWITCHED	4	21	V9_LAST_SWITCHED	4
7	89	V9_FORWARDING_STATUS	4	89	V9_FORWARDING_STATUS	1

S.No	IPFIX			NetFlow V9		
	IE #	Field	Size (Bytes)	IE #	Field	Size (Bytes)
8	61	V9_DIRECTION	1	61	V9_DIRECTION	1
9	302	SELECTOR_ID	4	48	V9_FLOW_SAMPLER_ID	2
10	234	V9_VRF_ID_INPUT	4	234	V9_VRF_ID_INPUT	4
11	235	V9_VRF_ID_OUTPUT	4	235	V9_VRF_ID_OUTPUT	4
12	55	V9_POST_QOS_TOS	1	55	V9_POST_QOS_TOS	1
13	8	V9_IPV4SRCADDR	4	8	V9_IPV4SRCADDR	4
14	12	V9_IPV4DSTADDR	4	12	V9_IPV4DSTADDR	4
15	7	V9_SRC_PORT	2	7	V9_SRC_PORT	2
16	11	V9_DST_PORT	2	11	V9_DST_PORT	2
17	9	V9_SRC_MASK	1	9	V9_SRC_MASK	1
18	13	V9_DST_MASK	1	13	V9_DST_MASK	1
19	4	V9_PROT	1	4	V9_PROT	1
20	6	V9_TCP_FLAGS	2	6	V9_TCP_FLAGS	1
21	5	V9_TOS	1	5	V9_TOS	1
22	52	V9_MIN_TTL	1	52	V9_MIN_TTL	1
23	53	V9_MAX_TTL	1	53	V9_MAX_TTL	1
24	54	V9_IP_IDENT	4	54	V9_IP_IDENT	4
25	197	IPFIX_FRAG_FLAGS	1	197	IPFIX_FRAG_FLAGS	1
26	88	V9_FRAGMENT_OFFSET	2	88	V9_FRAGMENT_OFFSET	2
27	184	IPFIX_TCP_SEQ_NUM	4	184	IPFIX_TCP_SEQ_NUM	4
28	25	V9_MIN_PKT_LEN	8	25	V9_MIN_PKT_LEN	8
29	26	V9_MAX_PKT_LEN	8	26	V9_MAX_PKT_LEN	8
30	503	IPFIX_L4_CHECKSUM	2	503	IPFIX_L4_CHECKSUM	2
31	504	IPFIX_ICMP_8_BYTES	8	504	IPFIX_ICMP_8_BYTES	8
32	507	GTP_TEID	4	507	GTP_TEID	4
33	509	GTP_QFI	1	509	GTP_QFI	1
34	510	GTP_SESS_DIR	1	510	GTP_SESS_DIR	1
35	8	V9_IPV4SRCADDR	4	8	V9_IPV4SRCADDR	4
36	12	V9_IPV4DSTADDR	4	12	V9_IPV4DSTADDR	4
37	5	V9_TOS	1	5	V9_TOS	1

S.No	IPFIX			NetFlow V9		
	IE #	Field	Size (Bytes)	IE #	Field	Size (Bytes)
38	16	V9_SRC_AS	4	16	V9_SRC_AS	4
39	17	V9_DST_AS	4	17	V9_DST_AS	4
40	18	V9_BGP_IPV4_NEXT_HOP	4	18	V9_BGP_IPV4_NEXT_HOP	4
41	63	V9_BGP_IPV6_NEXT_HOP	16	63	V9_BGP_IPV6_NEXT_HOP	16
42	15	V9_IPV4_NEXT_HOP	4	15	V9_IPV4_NEXT_HOP	4
43	62	V9_IPV6_NEXT_HOP	16	62	V9_IPV6_NEXT_HOP	16
44	56	V9_IN_SRC_MAC	6	56	V9_IN_SRC_MAC	6
45	80	V9_IN_DST_MAC	6	80	V9_IN_DST_MAC	6
46	256	V9_ETH_TYPE	2	256	V9_ETH_TYPE	2
47	243	V9_DOT1Q_VLAN_ID	2	243	V9_DOT1Q_VLAN_ID	2
48	245	V9_DOT1Q_CUST_VLAN_ID	2	245	V9_DOT1Q_CUST_VLAN_ID	2
49	244	V9_DOT1Q_PRIORITY	1	244	V9_DOT1Q_PRIORITY	1
50	198	IN_BYTES_DELTA	8	444	V9_AS_PATH	128
51				445	V9_STD_COMM	128

IPv4-GTP-IPv6 Record

This record monitors GTP-U traffic that starts in an IPv4 network and transitions into an IPv6 network, aiding in cross-network compatibility analysis.

S.No	IPFIX			NetFlow V9		
	IE #	Field	Size (Bytes)	IE #	Field	Size (Bytes)
1	2	V9_IN_PKTS	8	2	V9_IN_PKTS	4
2	1	V9_IN_BYTES	8	1	V9_IN_BYTES	4
3	10	V9_INPUT_SNMP	4	10	V9_INPUT_SNMP	4
4	14	V9_OUTPUT_SNMP	4	14	V9_OUTPUT_SNMP	4
5	22	V9_FIRST_SWITCHED	4	22	V9_FIRST_SWITCHED	4
6	21	V9_LAST_SWITCHED	4	21	V9_LAST_SWITCHED	4
7	89	V9_FORWARDING_STATUS	4	89	V9_FORWARDING_STATUS	1
8	61	V9_DIRECTION	1	61	V9_DIRECTION	1
9	302	SELECTOR_ID	4	48	V9_FLOW_SAMPLER_ID	2
10	234	V9_VRF_ID_INPUT	4	234	V9_VRF_ID_INPUT	4

S.No	IPFIX			NetFlow V9		
	IE #	Field	Size (Bytes)	IE #	Field	Size (Bytes)
11	235	V9_VRF_ID_OUTPUT	4	235	V9_VRF_ID_OUTPUT	4
12	55	V9_POST_QOS_TOS	1	55	V9_POST_QOS_TOS	1
13	27	V9_IPV6_SRC_ADDR	16	27	V9_IPV6_SRC_ADDR	16
14	28	V9_IPV6_DST_ADDR	16	28	V9_IPV6_DST_ADDR	16
15	31	V9_FLOW_LABEL	4	31	V9_FLOW_LABEL	3
16	64	V9_IPV6_OPTION_HEADERS	4	64	V9_IPV6_OPTION_HEADERS	4
17	7	V9_SRC_PORT	2	7	V9_SRC_PORT	2
18	11	V9_DST_PORT	2	11	V9_DST_PORT	2
19	30	V9_IPV6_DST_MASK	1	30	V9_IPV6_DST_MASK	1
20	29	V9_IPV6_SRC_MASK	1	29	V9_IPV6_SRC_MASK	1
21	4	V9_PROT	1	4	V9_PROT	1
22	6	V9_TCP_FLAGS	2	6	V9_TCP_FLAGS	1
23	5	V9_TOS	1	5	V9_TOS	1
24	52	V9_MIN_TTL	1	52	V9_MIN_TTL	1
25	53	V9_MAX_TTL	1	53	V9_MAX_TTL	1
26	54	V9_IP_IDENT	4	54	V9_IP_IDENT	4
27	197	IPFIX_FRAG_FLAGS	1	197	IPFIX_FRAG_FLAGS	1
28	88	V9_FRAGMENT_OFFSET	2	88	V9_FRAGMENT_OFFSET	2
29	184	IPFIX_TCP_SEQ_NUM	4	184	IPFIX_TCP_SEQ_NUM	4
30	25	V9_MIN_PKT_LEN	8	25	V9_MIN_PKT_LEN	8
31	26	V9_MAX_PKT_LEN	8	26	V9_MAX_PKT_LEN	8
32	503	IPFIX_L4_CHECKSUM	2	503	IPFIX_L4_CHECKSUM	2
33	504	IPFIX_ICMP_8_BYTES	8	504	IPFIX_ICMP_8_BYTES	8
34	507	GTP_TEID	4	507	GTP_TEID	4
35	509	GTP_QFI	1	509	GTP_QFI	1
36	510	GTP_SESS_DIR	1	510	GTP_SESS_DIR	1
37	8	V9_IPV4SRCADDR	4	8	V9_IPV4SRCADDR	4
38	12	V9_IPV4DSTADDR	4	12	V9_IPV4DSTADDR	4
39	5	V9_TOS	1	5	V9_TOS	1
40	16	V9_SRC_AS	4	16	V9_SRC_AS	4

S.No	IPFIX			NetFlow V9		
	IE #	Field	Size (Bytes)	IE #	Field	Size (Bytes)
41	17	V9_DST_AS	4	17	V9_DST_AS	4
42	18	V9_BGP_IPV4_NEXT_HOP	4	18	V9_BGP_IPV4_NEXT_HOP	4
43	63	V9_BGP_IPV6_NEXT_HOP	16	63	V9_BGP_IPV6_NEXT_HOP	16
44	15	V9_IPV4_NEXT_HOP	4	15	V9_IPV4_NEXT_HOP	4
45	62	V9_IPV6_NEXT_HOP	16	62	V9_IPV6_NEXT_HOP	16
46	56	V9_IN_SRC_MAC	6	56	V9_IN_SRC_MAC	6
47	80	V9_IN_DST_MAC	6	80	V9_IN_DST_MAC	6
48	256	V9_ETH_TYPE	2	256	V9_ETH_TYPE	2
49	243	V9_DOT1Q_VLAN_ID	2	243	V9_DOT1Q_VLAN_ID	2
50	245	V9_DOT1Q_CUST_VLAN_ID	2	245	V9_DOT1Q_CUST_VLAN_ID	2
51	244	V9_DOT1Q_PRIORITY	1	244	V9_DOT1Q_PRIORITY	1
52	198	IN_BYTES_DELTA	8	444	V9_AS_PATH	128
53				445	V9_STD_COMM	128

IPv6-GTP-IPv4 Record

This record monitors GTP-U traffic moving from an IPv6 network to an IPv4 network, ensuring seamless data flow across different network types.

S.No	IPFIX			NetFlow V9		
	IE #	Field	Size (Bytes)	IE #	Field	Size (Bytes)
1	2	V9_IN_PKTS	8	2	V9_IN_PKTS	4
2	1	V9_IN_BYTES	8	1	V9_IN_BYTES	4
3	10	V9_INPUT_SNMP	4	10	V9_INPUT_SNMP	4
4	14	V9_OUTPUT_SNMP	4	14	V9_OUTPUT_SNMP	4
5	21	V9_LAST_SWITCHED	4	21	V9_LAST_SWITCHED	4
6	22	V9_FIRST_SWITCHED	4	22	V9_FIRST_SWITCHED	4
7	89	V9_FORWARDING_STATUS	4	89	V9_FORWARDING_STATUS	1
8	61	V9_DIRECTION	1	61	V9_DIRECTION	1
9	302	SELECTOR_ID	4	48	V9_FLOW_SAMPLER_ID	2
10	234	V9_VRF_ID_INPUT	4	234	V9_VRF_ID_INPUT	4
11	235	V9_VRF_ID_OUTPUT	4	235	V9_VRF_ID_OUTPUT	4

S.No	IPFIX			NetFlow V9		
	IE #	Field	Size (Bytes)	IE #	Field	Size (Bytes)
12	55	V9_POST_QOS_TOS	1	55	V9_POST_QOS_TOS	1
13	8	V9_IPV4SRCADDR	4	8	V9_IPV4SRC4ADDR	4
14	12	V9_IPV4DSTADDR	4	12	V9_IPV4DSTADDR	4
15	7	V9_SRC_PORT	2	7	V9_SRC_PORT	2
16	11	V9_DST_PORT	2	11	V9_DST_PORT	2
17	9	V9_SRC_MASK	1	9	V9_SRRC_MASK	1
18	13	V9_DST_MASK	1	13	V9_DST_MASK	1
19	4	V9_PROT	1	4	V9_PROT	1
20	6	V9_TCP_FLAGS	2	6	V9_TCP_FLAGS	1
21	5	V9_TOS	1	5	V9_TOS	1
22	52	V9_MIN_TTL	1	52	V9_MIN_TTL	1
23	53	V9_MAX_TTL	1	53	V9_MAX_TTL	1
24	54	V9_IP_IDENT	4	54	V9_IP_IDENT	4
25	197	IPFIX_FRAG_FLAGS	1	197	IPFIX_FRAG_FLAGS	1
26	88	V9_FRAGMENT_OFFSET	2	88	V9_FRAGMENT_OFFSET	2
27	184	IPFIX_TCP_SEQ_NUM	4	184	IPFIX_TCP_SEQ_NUM	4
28	25	V9_MIN_PKT_LEN	8	25	V9_MIN_PKT_LEN	8
29	26	V9_MAX_PKT_LEN	8	26	V9_MAX_PKT_LEN	8
30	503	IPFIX_L4_CHECKSUM	2	503	IPFIX_L4_CHECKSUM	2
31	504	IPFIX_ICMP_8_BYTES	8	504	IPFIX_ICMP_8_BYTES	8
32	507	GTP_TEID	4	507	GTP_TEID	4
33	509	GTP_QFI	1	509	GTP_QFI	1
34	510	GTP_SESS_DIR	1	510	GTP_SESS_DIR	1
35	27	V9_IPV6_SRC_ADDR	16	27	V9_IPV6_SRC_ADDR	16
36	28	V9_IPV6_DST_ADDR	16	28	V9_IPV6_DST_ADDR	16
37	5	V9_TOS	1	5	V9_TOS	1
38	31	V9_FLOW_LABEL	4	31	V9_FLOW_LABEL	3
39	16	V9_SRC_AS	4	16	V9_SRC_AS	4
40	17	V9_DST_AS	4	17	V9_DST_AS	4
41	18	V9_BGP_IPV4_NEXT_HOP	4	18	V9_BGP_IPV4_NEXT_HOP	4

S.No	IPFIX			NetFlow V9		
	IE #	Field	Size (Bytes)	IE #	Field	Size (Bytes)
42	63	V9_BGP_IPV6_NEXT_HOP	16	63	V9_BGP_IPV6_NEXT_HOP	16
43	15	V9_IPV4_NEXT_HOP	4	15	V9_IPV4_NEXT_HOP	4
44	62	V9_IPV6_NEXT_HOP	16	62	V9_IPV6_NEXT_HOP	16
45	56	V9_IN_SRC_MAC	6	56	V9_IN_SRC_MAC	6
46	80	V9_IN_DST_MAC	6	80	V9_IN_DST_MAC	6
47	256	V9_ETH_TYPE	2	256	V9_ETH_TYPE	2
48	243	V9_DOT1Q_VLAN_ID	2	243	V9_DOT1Q_VLAN_ID	2
49	245	V9_DOT1Q_CUST_VLAN_ID	2	245	V9_DOT1Q_CUST_VLAN_ID	2
50	244	V9_DOT1Q_PRIORITY	1	244	V9_DOT1Q_PRIORITY	1
51	198	IN_BYTES_DELTA	8	444	V9_AS_PATH	128
52				445	V9_STD_COMM	128

IPv6-GTP-IPv6 Record

This record provides insights into GTP-U traffic within IPv6 networks, crucial for maintaining the integrity and efficiency of modern 5G infrastructures.

S.No	IPFIX			NetFlow V9		
	IE #	Field	Size (Bytes)	IE #	Field	Size (Bytes)
1	2	V9_IN_PKTS	8	2	V9_IN_PKTS	4
2	1	V9_IN_BYTES	8	1	V9_IN_BYTES	4
3	10	V9_INPUT_SNMP	4	10	V9_INPUT_SNMP	4
4	14	V9_OUTPUT_SNMP	4	14	V9_OUTPUT_SNMP	4
5	21	V9_LAST_SWITCHED	4	21	V9_LAST_SWITCHED	4
6	22	V9_FIRST_SWITCHED	4	22	V9_FIRST_SWITCHED	4
7	89	V9_FORWARDING_STATUS	4	89	V9_FORWARDING_STATUS	1
8	61	V9_DIRECTION	1	61	V9_DIRECTION	1
9	302	SELECTOR_ID	4	48	V9_FLOW_SAMPLER_ID	2
10	234	V9_VRF_ID_INPUT	4	234	V9_VRF_ID_INPUT	4
11	235	V9_VRF_ID_OUTPUT	4	235	V9_VRF_ID_OUTPUT	4
12	55	V9_POST_QOS_TOS	1	55	V9_POS_QOS_TOS	1
13	27	V9_IPV6_SRC_ADDR	16	27	V9_IPV6_SRC_ADDR	16

S.No	IPFIX			NetFlow V9		
	IE #	Field	Size (Bytes)	IE #	Field	Size (Bytes)
14	28	V9_IPV6_DST_ADDR	16	28	V9_IPV6_DST_ADDR	16
15	31	V9_FLOW_LABEL	4	31	V9_FLOW_LABEL	3
16	64	V9_IPV6_OPTION_HEADERS	4	64	V9_IPV6_OPTION_HEADERS	4
17	7	V9_SRC_PORT	2	7	V9_SRC_PORT	2
18	11	V9_DST_PORT	2	11	V9_DST_PORT	2
19	30	V9_IPV6_DST_MASK	1	30	V9_IPV6_DST_MASK	1
20	29	V9_IPV6_SRC_MASK	1	29	V9_IPV6_SRC_MASK	1
21	4	V9_PROT	1	4	V9_PROT	1
22	6	V9_TCP_FLAGS	2	6	V9_TCP_FLAGS	1
23	5	V9_TOS	1	5	V9_TOS	1
24	52	V9_MIN_TTL	1	52	V9_MIN_TTL	1
25	53	V9_MAX_TTL	1	53	V9_MAX_TTL	1
26	54	V9_IP_IDENT	4	54	V9_IP_IDENT	4
27	197	IPFIX_FRAG_FLAGS	1	197	IPFIX_FRAG_FLAGS	1
28	88	V9_FRAGMENT_OFFSET	2	88	V9_FRAGMENT_OFFSET	2
29	184	IPFIX_TCP_SEQ_NUM	4	184	IPFIX_TCP_SEQ_NUM	4
30	25	V9_MIN_PKT_LEN	8	25	V9_MIN_PKT_LEN	8
31	26	V9_MAX_PKT_LEN	8	26	V9_MAX_PKT_LEN	8
32	503	IPFIX_L4_CHECKSUM	2	503	IPFIX_L4_CHECKSUM	2
33	504	IPFIX_ICMP_8_BYTES	8	504	IPFIX_ICMP_8_BYTES	8
34	507	GTP_TEID	4	507	GTP_TEID	4
35	509	GTP_QFI	1	509	GTP_QFI	1
36	510	GTP_SESS_DIR	1	510	GTP_SESS_DIR	1
37	27	V9_IPV6_SRC_ADDR	16	27	V9_IPV6_SRC_ADDR	16
38	28	V9_IPV6_DST_ADDR	16	28	V9_IPV6_DST_ADDR	16
39	5	V9_TOS	1	5	V9_TOS	1
40	31	V9_FLOW_LABEL	4	31	V9_FLOW_LABEL	3
41	16	V9_SRC_AS	4	16	V9_SRC_AS	4
42	17	V9_DST_AS	4	17	V9_DST_AS	4
43	18	V9_BGP_IPV4_NEXT_HOP	4	18	V9_BGP_IPV4_NEXT_HOP	4

S.No	IPFIX			NetFlow V9		
	IE #	Field	Size (Bytes)	IE #	Field	Size (Bytes)
44	63	V9_BGP_IPV6_NEXT_HOP	16	63	V9_BGP_IPV6_NEXT_HOP	16
45	15	V9_IPV4_NEXT_HOP	4	15	V9_IPV4_NEXT_HOP	4
46	62	V9_IPV6_NEXT_HOP	16	62	V9_IPV6_NEXT_HOP	16
47	56	V9_IN_SRC_MAC	6	56	V9_IN_SRC_MAC	6
48	80	V9_IN_DST_MAC	6	80	V9_IN_DST_MAC	6
49	256	V9_ETH_TYPE	2	256	V9_ETH_TYPE	2
50	243	V9_DOT1Q_VLAN_ID	2	243	V9_DOT1Q_VLAN_ID	2
51	245	V9_DOT1Q_CUST_VLAN_ID	2	245	V9_DOT1Q_CUST_VLAN_ID	2
52	244	V9_DOT1Q_PRIORITY	1	244	V9_DOT1Q_PRIORITY	1
53	198	IN_BYTES_DELTA	8	444	V9_AS_PATH	128
54				445	V9_STD_COMM	128

Extended Template Records

IPv4 Peering Extended Record

This record extends monitoring capabilities to include detailed peering information for IPv4 traffic, enhancing traffic management and security measures.

S.No	IPFIX			NetFlow V9		
	IE #	Field	Size (Bytes)	IE #	Field	Size (Bytes)
1	2	V9_IN_PKTS	8	2	V9_IN_PKTS	4
2	1	V9_IN_BYTES	8	1	V9_IN_BYTES	4
3	8	V9_IPV4SRCADDR	4	8	V9_IPV4SRCADDR	4
4	12	V9_IPV4DSTADDR	4	12	V9_IPV4DSTADDR	4
5	10	V9_INPUT_SNMP	4	10	V9_INPUT_SNMP	4
6	14	V9_OUTPUT_SNMP	4	14	V9_OUTPUT_SNMP	4
7	22	V9_FIRST_SWITCHED	4	22	V9_FIRST_SWITCHED	4
8	21	V9_LAST_SWITCHED	4	21	V9_LAST_SWITCHED	4
9	7	V9_SRC_PORT	2	7	V9_SRC_PORT	2
10	11	V9_DST_PORT	2	11	V9_DST_PORT	2
11	16	V9_SRC_AS	4	16	V9_SRC_AS	4
12	17	V9_DST_AS	4	17	V9_DST_AS	4

S.No	IPFIX			NetFlow V9		
	IE #	Field	Size (Bytes)	IE #	Field	Size (Bytes)
13	18	V9_BGP_IPV4_NEXT_HOP	4	18	V9_BGP_IPV6_NEXT_HOP	4
14	63	V9_BGP_IPV6_NEXT_HOP	16	63	V9_BGP_IPV6_NEXT_HOP	16
15	15	V9_IPV4_NEXT_HOP	4	15	V9_IPV4_NEXT_HOP	4
16	62	V9_IPV6_NEXT_HOP	16	62	V9_IPV6_NEXT_HOP	16
17	9	V9_SRC_MASK	1	9	V9_SRC_MASK	1
18	13	V9_DST_MASK	1	13	V9_DST_MASK	1
19	4	V9_PROT	1	4	V9_PROT	1
20	6	V9_TCP_FLAGS	2	6	V9_TCP_FLAGS	1
21	5	V9_TOS	1	5	V9_TOS	1
22	55	V9_POST_QOS_TOS	1	55	V9_POST_QOS_TOS	1
23	61	V9_DIRECTION	1	61	V9_DIRECTION	1
24	89	V9_FORWARDING_STATUS	4	89	V9_FORWARDING_STATUS	1
25	302	SELECTOR_ID	4	48	V9_FLOW_SAMPLER_ID	2
26	234	V9_VRF_ID_INPUT	4	234	V9_VRF_ID_INPUT	4
27	235	V9_VRF_ID_OUTPUT	4	235	V9_VRF_ID_OUTPUT	4
28	52	V9_MIN_TTL	1	52	V9_MIN_TTL	1
29	53	V9_MAX_TTL	1	53	V9_MAX_TTL	1
30	54	V9_IP_IDENT	4	54	V9_IP_IDENT	4
31	197	IPFIX_FRAG_FLAGS	1	197	IPFIX_FRAG_FLAGS	1
32	88	V9_FRAGMENT_OFFSET	2	88	V9_FRAGMENT_OFFSET	2
33	184	IPFIX_TCP_SEQ_NUM	4	184	IPFIX_TCP_SEQ_NUM	4
34	25	V9_MIN_PKT_LEN	8	25	V9_MIN_PKT_LEN	8
35	26	V9_MAX_PKT_LEN	8	26	V9_MAX_PKT_LEN	8
36	503	IPFIX_L4_CHECKSUM	2	503	IPFIX_L4_CHECKSUM	2
37	504	IPFIX_ICMP_8_BYTES	8	504	IPFIX_ICMP_8_BYTES	8
38	56	V9_IN_SRC_MAC	6	56	V9_IN_SRC_MAC	6
39	80	V9_IN_DST_MAC	6	80	V9_IN_DST_MAC	6
40	256	V9_ETH_TYPE	2	256	V9_ETH_TYPE	2
41	243	V9_DOT1Q_VLAN_ID	2	243	V9_DOT1Q_VLAN_ID	2
42	245	V9_DOT1Q_CUST_VLAN_ID	2	245	V9_DOT1Q_CUST_VLAN_ID	2

S.No	IPFIX			NetFlow V9		
	IE #	Field	Size (Bytes)	IE #	Field	Size (Bytes)
43	244	V9_DOT1Q_PRIORITY	1	244	V9_DOT1Q_PRIORITY	1
44	198	IN_BYTES_DELTA	8	444	V9_AS_PATH	128
45				445	V9_STD_COMM	128

IPv6 Peering Extended Record

This record offers comprehensive peering data for IPv6 traffic, supporting advanced traffic analysis and network optimization strategies.

S.No	IPFIX			NetFlow V9		
	IE #	Field	Size (Bytes)	IE #	Field	Size (Bytes)
1	2	V9_IN_PKTS	8	2	V9_IN_PKTS	4
2	1	V9_IN_BYTES	8	1	V9_IN_BYTES	4
3	27	V9_IPV6_SRC_ADDR	16	27	V9_IPV6_SRC_ADDR	16
4	28	V9_IPV6_DST_ADDR	16	28	V9_IPV6_DST_ADDR	16
5	10	V9_INPUT_SNMP	4	10	V9_INPUT_SNMP	4
6	14	V9_OUTPUT_SNMP	4	14	V9_OUTPUT_SNMP	4
7	22	V9_FIRST_SWITCHED	4	22	V9_FIRST_SWITCHED	4
8	21	V9_LAST_SWITCHED	4	21	V9_LAST_SWITCHED	4
9	31	V9_FLOW_LABEL	4	31	V9_FLOW_LABEL	3
10	64	V9_IPV6_OPTION_HEADERS	4	64	V9_IPV6_OPTION_HEADERS	4
11	7	V9_SRC_PORT	2	7	V9_SRC_PORT	2
12	11	V9_DST_PORT	2	11	V9_DST_PORT	2
13	16	V9_SRC_AS	4	16	V9_SRC_AS	4
14	17	V9_DST_AS	4	17	V9_DST_AS	4
15	18	V9_BGP_IPV4_NEXT_HOP	4	18	V9_BGP_IPV6_NEXT_HOP	4
16	63	V9_BGP_IPV6_NEXT_HOP	16	63	V9_BGP_IPV6_NEXT_HOP	16
17	15	V9_IPV4_NEXT_HOP	4	15	V9_IPV4_NEXT_HOP	4
18	62	V9_IPV6_NEXT_HOP	16	62	V9_IPV6_NEXT_HOP	16
19	30	V9_IPV6_DST_MASK	1	30	V9_IPV6_DST_MASK	1
20	29	V9_IPV6_SRC_MASK	1	29	V9_IPV6_SRC_MASK	1
21	4	V9_PROT	1	4	V9_PROT	1

S.No	IPFIX			NetFlow V9		
	IE #	Field	Size (Bytes)	IE #	Field	Size (Bytes)
22	6	V9_TCP_FLAGS	2	6	V9_TCP_FLAGS	1
23	5	V9_TOS	1	5	V9_TOS	1
24	55	V9_POST_QOS_TOS	1	55	V9_POST_QOS_TOS	1
25	61	V9_DIRECTION	1	61	V9_DIRECTION	1
26	89	V9_FORWARDING_STATUS	4	89	V9_FORWARDING_STATUS	1
27	302	SELECTOR_ID	4	48	V9_FLOW_SAMPLER_ID	2
28	234	V9_VRF_ID_INPUT	4	234	V9_VRF_ID_INPUT	4
29	235	V9_VRF_ID_OUTPUT	4	235	V9_VRF_ID_OUTPUT	4
30	52	V9_MIN_TTL	1	52	V9_MIN_TTL	1
31	53	V9_MAX_TTL	1	53	V9_MAX_TTL	1
32	54	V9_IP_IDENT	4	54	V9_IP_IDENT	4
33	197	IPFIX_FRAG_FLAGS	1	197	IPFIX_FRAG_FLAGS	1
34	88	V9_FRAGMENT_OFFSET	2	88	V9_FRAGMENT_OFFSET	2
35	184	IPFIX_TCP_SEQ_NUM	4	184	IPFIX_TCP_SEQ_NUM	4
36	25	V9_MIN_PKT_LEN	8	25	V9_MIN_PKT_LEN	8
37	26	V9_MAX_PKT_LEN	8	26	V9_MAX_PKT_LEN	8
38	503	IPFIX_L4_CHECKSUM	2	503	IPFIX_L4_CHECKSUM	2
39	504	IPFIX_ICMP_8_BYTES	8	504	IPFIX_ICMP_8_BYTES	8
40	56	V9_IN_SRC_MAC	6	56	V9_IN_SRC_MAC	6
41	80	V9_IN_DST_MAC	6	80	V9_IN_DST_MAC	6
42	256	V9_ETH_TYPE	2	256	V9_ETH_TYPE	2
43	243	V9_DOT1Q_VLAN_ID	2	243	V9_DOT1Q_VLAN_ID	2
44	245	V9_DOT1Q_CUST_VLAN_ID	2	245	V9_DOT1Q_CUST_VLAN_ID	2
45	244	V9_DOT1Q_PRIORITY	1	244	V9_DOT1Q_PRIORITY	1
46	198	IN_BYTES_DELTA	8	444	V9_AS_PATH	128
47				445	V9_STD_COMM	128

Configure Netflow for GTP-U Traffic Monitoring

Configure a Flow Exporter

```
Router# configure
Router(config)# flow exporter-map Expol
Router(config-fem)# source-address 2001:db8::0003
```

```

Router(config-fem)# destination 2001:db8::0002
Router(config-fem)# transport udp 1024
Router(config-fem)# version v9
Router(config-fem-ver)# options interface-table
Router(config-fem-ver)# commit
Router(config-fem-ver)# root
Router(config)#exit

```

Create a Flow Monitor for GTP-U monitoring

```

Router(config)#flow monitor-map ipv6
Router(config-fmm)#record ipv6 gtp
Router(config-fmm)#exporter Expol
Router(config-fmm)#option bgpatrr
Router(config-fmm)#cache timeout active 30
Router(config-fmm)#cache timeout inactive 5
Router(config-fmm)#exit

```

Configure a Flow Sampler

```

Router(config)# configure
Router(config)# sampler-map fsm1
Router(config-sm)# random 1 out-of 262144
Router(config)# exit
Router(config)#commit
Router(config)#exit
Router#

```

Apply a Flow Monitor Map and a Flow Sampler to a physical interface

```

Router#configure
Router(config)#interface HundredGigE 0/0/0/24
Router(config-if)#flow ipv6 monitor fmm-ipv6 sampler fsm1 ingress
Router(config-if)#commit
Router(config-if)#root
Router(config)#exit

```

Running Configuration

View the running configuration

```

Router# show run

flow exporter-map Expol
  version v9
  options interface-table
  !
  transport udp 1024
  source-address 2001:db8::3
  destination 2001:db8::2
  !
flow monitor-map fmm-ipv6
  record ipv6
  exporter Expol
  cache entries 500000
  cache timeout active 60
  cache timeout inactive 20
  !
sampler-map fsm1
  random 1 out-of 262144
  !

```

```

interface HundredGigE0/0/0/24
 shutdown
 flow ipv6 monitor fmm-ipv6 sampler fsm1 ingress
 !
end

```

Verification

Monitoring Cache Record for GTP-U services

In the following example, you can verify the GTP tunnel ID, QoS flow identifier, and GTP session number from the GTPteid, GTPQFI and GTPSESSDIR field.

```
Router#show flow monitor fmm-ipv6 cache format record location 0/0/CPU0
```

```

===== Record number: 1 =====
RecordType      : GTP Tunneled Record
IPV4SrcAddr     : 0.0.0.0
IPV4DstAddr     : 0.0.0.0
IPv6SrcAddr     : 2001:db8:1::1
IPv6DstAddr     : 2001:db8:2::2
L4SrcPort       : 0
L4DestPort      : 0
IPV4Prot        : icmpv6
IPV4TOS         : 0
InputInterface  : Gi0/2/0/0
OutputInterface : 0
L4TCPFlags      : 0
ForwardStatus   : Fwd
FirstSwitched  : 00 00:08:59:286
LastSwitched   : 00 00:08:59:286
ByteCount       : 1296
PacketCount     : 1
Dir             : Ing
GTPteid       : 11
GTPQFI       : 0
GTPSESSDIR   : 0
IPv6TC         : 0
IPv6FlowLabel   : 690680
MinimumTTL      : 64
MaximumTTL      : 64
IPFragFlags     : 0
IPFragOffset    : 181
IPIdentification : 0
IPv6Ident       : 1546089621
L4SequenceNum   : 0
L4Checksum      : 0
MinPktLen       : 100
MaxPktLen       : 100
ICMPBytes       : 0x8000cf945edf0002
OuterIPV4SrcAddr : 100.100.100.1
OuterIPV4DstAddr : 200.200.200.2
OuterIPv6SrcAddr : ::
OuterIPv6DstAddr : ::
BGPNextHopV4    : 0.0.0.0
BGPNextHopV6    : ::
BGPSrcOrigAS    : 0
BGPDstOrigAS    : 0
IPV4NextHop     : 0.0.0.0
IPV6NextHop     : ::
SrcMacAddr      : 00:00:3f:11:50:20
DstMacAddr      : 45:00:00:62:00:00
EthType         : 2048
Dot1qPriority    : 0
Dot1qVlanId     : 0

```

```

CustVlanId      : 0
InputVRFID     : default
OutputVRFID    : default
===== Record number: 2 =====
RecordType     : GTP Tunneler Record
IPV4SrcAddr    : 192.168.12.2
IPV4DstAddr    : 192.168.12.1
IPV6SrcAddr    : ::
IPV6DstAddr    : ::
L4SrcPort      : 0
L4DestPort     : 0
IPV4Prot       : icmp
IPV4TOS        : 0
InputInterface : Gi0/2/0/0
OutputInterface : 0
L4TCPFlags     : 0
ForwardStatus  : Fwd
FirstSwitched  : 00 00:08:54:244
LastSwitched   : 00 00:08:54:244
ByteCount      : 64
PacketCount    : 1
Dir            : Ing
GTPTeid      : 11
GTPQFI       : 0
GTPSESSDIR  : 0
IPV6TC         : 0
IPV6FlowLabel  : 0
MinimumTTL     : 255
MaximumTTL     : 255
IPFragFlags    : 0
IPFragOffset   : 97
IPIdentification : 4
IPV6Ident      : 0
L4SequenceNum  : 0
L4Checksum     : 0
MinPktLen      : 100
MaxPktLen      : 100
ICMPBytes      : 0xabcdabcdabcdabcd
OuterIPV4SrcAddr : 100.100.100.1
OuterIPV4DstAddr : 200.200.200.2
OuterIPV6SrcAddr : ::
OuterIPV6DstAddr : ::
BGNNextHopV4   : 0.0.0.0
BGNNextHopV6   : ::
BGPSrcOrigAS   : 0
BGPDstOrigAS   : 0
IPV4NextHop    : 0.0.0.0
IPV6NextHop    : ::
SrcMacAddr     : 00:00:3f:11:50:20
DstMacAddr     : 45:00:00:62:00:00
EthType        : 2048
Dot1qPriority   : 0
Dot1qVlanId    : 0
CustVlanId     : 0
InputVRFID     : default
OutputVRFID    : default

```

Netflow Full Packet Capture

This feature captures the exact packet size of the ingress Netflow packet.

Earlier, when a L2VPN packet with a destination MAC address starting with the number 6 is received, the packet gets wrongly decoded as IPv6 packet; the packet size consequently gets reported inaccurately to the collector.

Configuring Netflow Full Packet Capture

This section describes how to configure Netflow full packet capture feature on the line card location 0/1/cpu0:



Note You should reload the line card for the changes to take effect.

```
RP/0/RP0/CPU0:router(config)# hw-module profile netflow fpc-enable location 0/1/cpu0
RP/0/RP0/CPU0:router(config)# exit
RP/0/RP0/CPU0:router # system admin
RP/0/RP0/CPU0:router(sysadmin)# hw-module reload location 0/1/cpu0
RP/0/RP0/CPU0:router(sysadmin)# commit
RP/0/RP0/CPU0:router(sysadmin)# end
```

Running Config

```
config
  hw-module profile netflow fpc-enable location 0/1/cpu0
!
sysadmin
  hw-module reload location 0/1/cpu0
!
```




CHAPTER 3

Configure IPFIX

- [IPFIX, on page 49](#)
- [Configuring IPFIX, on page 49](#)
- [IP Flow Information Export \(IPFIX\) 315, on page 57](#)

IPFIX

Internet Protocol Flow Information Export (IPFIX) is an IETF standard export protocol for sending Netflow packets. IPFIX is based on Netflow version 9.

The IPFIX feature formats Netflow data and transfers the Netflow information from an exporter to a collector using UDP as transport protocol.

Restrictions for IPFIX

These IPFIX features are not supported:


- Variable-length information element in the IPFIX template
- Stream Control Transmission Protocol (SCTP) as the transport protocol

Limitations for IPFIX

Configuring IPFIX

Consider SP-PE use case where SP (Service Provider) cloud is connected to the PE (Provider Edge) router through TenGigabit ethernet.

Figure 1: SP-PE Topology



Configuring NetFlow on PE router involves:

1. Configuring Exporter map with IPFIX as an exporter
2. Configuring Monitor map
3. Configuring Sampler map
4. Applying the Monitor map and Sampler map to an interface

Configuring Exporter map with IPFIX as the exporter version

```
flow exporter-map fem_ipfix
 destination 10.1.1.1
 source Loopback 0
 transport udp 1025
 exit
version ipfix
 template data timeout 600
 options sampler-table
 exit
```

Configuring Monitor map

```
flow monitor-map fmm1
 record ipv4
 option filtered
 exporter fem_ipfix
 cache entries 10000
 cache timeout active 1800
 cache timeout inactive 15
 exit
```

Configuring Sampler map

```
sampler-map fsm1
 random 1 out-of 4000 /*Sampling rate supported is 1:4000*/
 exit
```

Applying the Monitor map to an interface

Now apply the monitor-map **fmm1** that is configured with an exporter version IPFIX and sampler-map **fsm1** to the 10GE 0/0/0/1 interface in the ingress direction:

```
configure
interface 10GE0/0/0/1
  flow ipv4 monitor fmm1 sampler fsm1 ingress
exit
```

Verification

Use the **show flow flow-exporter map** command to verify the exporter version configured is IPFIX:

```
RP/0/RP0/CPU0:router# show flow exporter-map fem_ipfix
Flow Exporter Map : fem_ipfix
-----
Id                : 3
Packet-Length     : 1468
DestinationIpAddr : 10.1.1.1
VRFName           : default
SourceIfName      : Loopback1
SourceIpAddr      : 4.4.0.1
DSCP              : 40
TransportProtocol : UDP
TransportDestPort : 9001
```

Export Version: IPFIX

```
Common Template Timeout : 1800 seconds
Options Template Timeout : 1800 seconds
Data Template Timeout   : 1800 seconds
Interface-Table Export Timeout : 0 seconds
Sampler-Table Export Timeout : 0 seconds
VRF-Table Export Timeout : 0 seconds
```

Exported packets in an IPFIX packet structure are in the form of template set or data set. The first data template is sent when the configuration is activated on the interface.

With constant stream, the flowset data does not change, so data is decoded. Data template is updated in the case of timeout on the template. To change the timeout options in the flow exporter, use the `template options timeout` command:

```
RP/0/RP0/CPU0:router(config)#flow exporter-map ipfix_exp1
RP/0/RP0/CPU0:router(config-fem)#version ipfix
RP/0/RP0/CPU0:router(config-fem-ver)#template options
RP/0/RP0/CPU0:TU-PE3(config-fem-ver)#template options timeout
RP/0/RP0/CPU0:TU-PE3(config-fem-ver)#template options timeout 30

RP/0/RP0/CPU0:router# show flow exporter-map ipfix_exp1
version ipfix

  template data timeout 30
!
dscp 40
transport udp 9001
source Loopback0
destination 10.127.59.86
```

IPFIX Enablement for SRv6 and Services over SRv6 Core

Table 5: Feature History Table

Feature Name	Release Information	Description
IPFIX Enablement for SRv6 and Services over SRv6 Core	Release 7.10.1	<p>During the transition from conventional IP/MPLS networks to SRv6-based networks, the necessity for monitoring SRv6 traffic flow becomes crucial. This feature enables IPFIX to effectively monitor SRv6 IP traffic flow from network devices.</p> <p>The feature introduces these changes:</p> <p>CLI:</p> <ul style="list-style-type: none"> The srv6 keyword is introduced in the record ipv6 command. <p>The srv6 keyword is supported on fourth generation and later ASR 9000 Series High Density Ethernet line cards.</p>

Feature Name	Release Information	Description
Simultaneous L2 and L3 Flow Monitoring using IPFIX	Release 7.10.1	<p>This feature introduces support for simultaneous L2 and L3 flow monitoring. Now, you can configure IP Flow Information Export (IPFIX) to actively monitor and record end-to-end L2 and L3 flow information elements from network devices. Previously, only L2 or L3 flow could be monitored at a time.</p> <p>The feature introduces these changes:</p> <p>CLI:</p> <ul style="list-style-type: none"> The l2-l3 keyword is introduced in the record ipv4 command. The l2-l3 keyword is introduced in the record ipv6 command. <p>YANG DATA models:</p> <ul style="list-style-type: none"> New XPath for <code>Cisco-IOS-XR-UM-flow-cfg</code> (see Github, YANG Data Models Navigator) <p>The l2-l3 keyword is supported on fourth generation and later ASR 9000 Series High Density Ethernet line cards.</p>

During the transition from conventional IP/MPLS networks to SRv6-based networks, the requirement for information elements specific to SRv6 traffic flow arises. To address this requirement, we have introduced the **srv6** keyword within the **ipv6** command. Consequently, information related to SRv6 payload such as L2VPN and L3VPN services will also will be exported as part of IPFIX record.

Restriction and Limitation

1. IPFIX with multiple SRH is not supported in IOS XR software version 7.10.1
2. When the VLAN rewrite pop/translate option is enabled, the fourth and fifth generation of the Cisco ASR 9000 line cards do not support capturing of the VLAN information on an L2 interface.
3. SRv6 encapsulated L2VPN IPFIX records captured at the Decap PE node may show IE89 ForwardingStatus as "forwarded," but IE14 egressInterface will be 0.
4. When ASR 9000 is the endpoint of SR, Base Format 1 Segment Identifier (SID) is not supported and only the Micro-SID format for Layer 2 VPN services is supported.

Configuration

From Cisco IOS-XR Release 7.10.1, a new optional keyword, `l2-13` is introduced for the `record ipv4` and `record ipv6` option. See the following example:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router (config-fem) # flow monitor-map M-IPv4
RP/0/RP0/CPU0:router (config-fmm) # record ipv4 l2-13
RP/0/RP0/CPU0:router (config-fmm) # exporter EXP-ipfix
RP/0/RP0/CPU0:router (config-fmm) # !
RP/0/RP0/CPU0:router (config-fmm) # flow monitor-map M-IPv6
RP/0/RP0/CPU0:router (config-fmm) # record ipv6 l2-13
RP/0/RP0/CPU0:router (config-fmm) # exporter EXP-ipfix
RP/0/RP0/CPU0:router (config-fmm) # !
RP/0/RP0/CPU0:router (config-fmm) # sampler-map SAMP
RP/0/RP0/CPU0:router (config-fmm) # random 1 out-of 1000
RP/0/RP0/CPU0:router (config-fmm) # !
RP/0/RP0/CPU0:router (config-fmm) # interface GigabitEthernet0/1/0/0
RP/0/RP0/CPU0:router (config-fmm) # description CE-PE Interface
RP/0/RP0/CPU0:router (config-fmm) # ipv4 address 1.1.1.1 255.255.255.0
RP/0/RP0/CPU0:router (config-fmm) # ipv6 address 2001:DB8:c18:1::/64
RP/0/RP0/CPU0:router (config-fmm) # flow ipv4 monitor M-IPv4 sampler SAMP ingres
RP/0/RP0/CPU0:router (config-fmm) # flow ipv6 monitor M-IPv6 sampler SAMP ingres
RP/0/RP0/CPU0:router (config-fmm) # !
RP/0/RP0/CPU0:router
```

This example shows how to display IPv4 monitor-map data for a specific flow:

```
RP/0/RP0/CPU0:router# show run flow monitor-map
```

```
flow monitor-map M-IPv4
  record ipv4 l2-13
  exporter EXP
!
flow monitor-map M-IPv6
  record ipv6 l2-13
  exporter EXP
!
```

This example shows how to display l2-13 monitor-map data for IPv4 specific flow:

```
RP/0/RP0/CPU0:router# show flow monitor-map M-IPv4
```

```
Flow Monitor Map : M-IPv4
-----
Id:                3
RecordMapName:     ipv4-l2-13
ExportMapName:     EXP
CacheAgingMode:    Normal
CacheMaxEntries:   65535
CacheActiveTout:   1800 seconds
CacheInactiveTout: 15 seconds
CacheUpdateTout:   N/A
CacheRateLimit:    2000
HwCacheExists:     False
HwCacheInactTout:  50
```

This example shows how to display l2-13 monitor-map data for IPv6 specific flow:

```
RP/0/RP0/CPU0:router# show flow monitor-map M-IPv6
```

```
Flow Monitor Map : M-IPv6
```

```
-----
Id:                4
RecordMapName:     ipv6-l2-13
ExportMapName:     EXP
CacheAgingMode:    Normal
CacheMaxEntries:   65535
CacheActiveTout:   1800 seconds
CacheInactiveTout: 15 seconds
CacheUpdateTout:   N/A
CacheRateLimit:    2000
HwCacheExists:     False
HwCacheInactTout:  50
```

This example shows the complete recorded data for SRv6 L2 services :

```
RP/0/RP0/CPU0:router# show flow monitor M-IPv6 location 0/0/CPU0
```

```
Cache summary for Flow Monitor M1:
```

```
Cache size:                65535
Current entries:           3
Flows added:                4
Flows not added:           0
Ager Polls:                68143
- Active timeout           0
- Inactive timeout         1
- Immediate                 0
- TCP FIN flag             0
- Emergency aged           0
- Counter wrap aged        0
- Total                     1
Periodic export:
- Counter wrap             0
- TCP FIN flag             0
Flows exported              1
```

```
===== Record number: 1 =====
```

```
IPv6SrcAddr       : 2::2
IPv6DstAddr       : bbbb:bc00:88:e000::
BGPDstOrigAS      : 0
BGPSrcOrigAS      : 0
BGPNextHopV6     : fe80::232:17ff:fe7e:1ce1
IPv6TC            : 0
IPv6FlowLabel     : 50686
IPv6OptHdrs       : 0x0
IPV6Prot          : 143
L4SrcPort         : 0
L4DestPort        : 0
L4TCPFlags        : 0
IPV6DstPrfxLen    : 48
IPV6SrcPrfxLen    : 128
InputInterface    : Hu0/0/0/10
OutputInterface   : BE111.1
ForwardStatus     : Fwd
FirstSwitched     : 01 18:51:25:797
LastSwitched      : 01 18:51:25:797
ByteCount         : 61004304
PacketCount       : 113814
Dir               : Ing
```

```

SamplerID          : 1
InputVRFID        : default
OutputVRFID       : default
InnerIPv4SrcAddr   : 0.0.0.0
InnerIPv4DstAddr   : 0.0.0.0
InnerIPv6SrcAddr   : ::
InnerIPv6DstAddr   : ::
InnerL4SrcPort     : 0
InnerL4DestPort    : 0
SrcMacAddr        : 00:0c:29:0e:d8:32
DstMacAddr        : 00:0c:29:0e:d8:3c
EthType           : 2048
Dot1qPriority      : 0
Dot1qVlanId       : 2001
RecordType        : SRv6 L2 Service Record
SRHFlags          : 0x0
SRHTags           : 0x0
SRHSegmentsLeft   : 0
SRHNumSegments    : 0

```

This example shows the complete recorded data for IPv6 L2-L3 services :

```

RP/0/RP0/CPU0:router# show flow monitor M-IPv6 location 0/0/CPU0

RP/0/RP0/CPU0:router# show flow monitor MON-MAP-v6 location 0/0/CPU0
Thu Apr 28 11:36:47.622 IST
...
===== Record number: 1 =====
IPv6SrcAddr       : 151:1::1
IPv6DstAddr       : ff02::1:ff00:2
BGPDstOrigAS     : 0
BGPSrcOrigAS     : 0
BGPNextHopV6     : ::
IPv6TC           : 224
IPv6FlowLabel    : 0
IPv6OptHdrs      : 0x0
IPV6Prot         : icmpv6
MinimumTTL       : 255
MaximumTTL       : 255
L4SrcPort        : 0
L4DestPort       : 135
L4TCPFlags       : 0
IPV6DstPrfxLen   : 0
IPV6SrcPrfxLen   : 0
InputInterface   : BE999.1
OutputInterface  : 0
ForwardStatus    : FwdNoFrag
FirstSwitched    : 01 18:51:25:797
LastSwitched     : 01 18:51:25:797
ByteCount        : 104
PacketCount      : 1
Dir              : Ing
SamplerID        : 1
InputVRFID       : default
OutputVRFID      : default
SrcMacAddr       : 00:0c:29:0e:d8:32
DstMacAddr       : 00:0c:29:0e:d8:3c
EthType          : 2048
Dot1qPriority     : 0
Dot1qVlanId      : 100
CustVlanId       : 200

```

IP Flow Information Export (IPFIX) 315

Internet Protocol Flow Information Export (IPFIX) is an IETF standard export protocol (RFC 7011) for sending IP flow information. Router supports IPFIX 315 format to export flow information. IPFIX 315 format facilitates sending 'n' octets frame information starting from ethernet header till transport header of the traffic flow over the network. IPFIX 315 supports sending variable size packet record with variable payload information such as IPv4, IPv6, MPLS, and Nested packets like OuterIP-GRE-InnerIP and so on. The process includes sampling and exporting the traffic flow information. Along with the ethernet frame information, IPFIX 315 format exports information of incoming and outgoing interface of the sampled packet.


Use **hw-module profile netflow ipfix315 location** < linecard location > command to enable IPFIX 315.

The information of the packets flowing through a device is used for variety of purpose including network monitoring, capacity planning, traffic management, and so on,

Sampling and Exporting Information

The below figure *IPFIX 315 Export Packet Format* shows exported packet information.

Figure 2: IPFIX 315 Export Packet Format



A special cache type called Immediate Aging is used while exporting the packets. Immediate Aging ensures that the flows are exported as soon as they are added to the cache. Use the command **cache immediate** in flow monitor map configuration to enable Immediate Aging cache type.

IPFIX 315 Implementation Considerations

Here are few key points to consider before implementing IPFIX 315:

- Supported only in ingress direction.
- Supported on main interface only. The traffic on all sub-interfaces under the main interface is exported. This applies to releases up to and including IOS-XR software release 7.10.x.
- Sampling rate for bundles is per member-link and not per bundle interface.
- The outgoing interface information may not be correct incase of packets that are multicasted or broadcasted on multiple ports.

- The incoming and outgoing interface will have information of main interface and not the sub-interface even if the packet is routed via sub-interface. In case of bundles it will point to bundle main interface.
- IPFIX 315 is not supported on BVI interface.
- Sampling and exporting of the control packets is not supported.
- When you configure **ipfix315-enable**, then you must configure all the ports on that LC with `datalinkframesection flow`.
- When the HQoS profile is enabled, Netflow does not give correct Output Interface. DSP is unique for each sub-interface.
- Netflow on the L2 interface assumes IPv4/IPv6/MPLS traffic, and if the traffic is purely L2 based, then the system ignores that traffic.
- You must remove all v9 configurations before reloading an LC. Else, with the existing v9 configurations on LC reload, you might encounter a few configuration apply error. Or, flow might be seen on an interface even when apply on interface has failed.

Configuring IPFIX 315

Configuring IPFIX 315 involves:

1. Configuring Exporter map
2. Configuring Monitor map
3. Configuring Sampler map
4. Applying the Monitor map and Sampler map to an interface

Configuring Exporter map

```
flow exporter-map ipfix_exp
version ipfix
!
dscp 40
transport udp 9001
source Loopback1
destination 100.10.1.159
!
```



Note For **options** command and its configurations in Exporter Map, see [options](#).

Configuring Monitor map

```
flow monitor-map ipfix_mon
record datalinksectiondump
exporter ipfix_exp
cache immediate
cache entries 1000000
cache timeout rate-limit 1000000
!
```

Configuring Sampler map

```
sampler-map ipfix_sm
  random 1 out-of 32000
!
```



Note The default cache size is 65535, hence you can configure sampling rate as 1 out of 65535 packets. However the recommended sampling rate is 1 out of 32000 packets.

Applying the Monitor map to an interface

```
interface HundredGigE 0/0/0/18
  flow datalinkframesection monitor ipfix_mon sampler ipfix_sm ingress
```

