



## INDEX

---

### Numerics

- 4-post hardware kit
  - rack-mount [4-3](#)
- 4-post rack, mounting appliance on [4-2](#)

---

### A

- ACS deployment [1-1](#)
- adapter cards
  - troubleshooting [A-4](#)
- airflow
  - guidelines [3-8](#)
- altitude
  - guidelines [C-4](#)

---

### B

- back panel [2-5, 4-7, 8-7](#)
  - LEDs [2-6](#)

---

### C

- cable
  - connecting [4-7, 8-7, 8-11](#)
  - management [4-14, 8-10](#)
  - troubleshooting [A-4](#)
- checking
  - LEDs [4-16](#)
- checklist, installation [3-14](#)
- checklist, power up [4-14](#)
- configuration
  - site [3-8](#)

- connecting
  - cables [4-7, 8-7, 8-11](#)
  - network interface [4-8, 8-8](#)
- connections
  - troubleshooting [A-4](#)
- considerations
  - power [3-9](#)
- console port, pinouts
  - serial [4-12](#)
- cooling system
  - troubleshooting [A-3](#)
- corrosion
  - preventing damage [C-2](#)
- CPI tool
  - identification [2-3, 6-3, A-8](#)
- CSACS 1121 Series appliance
  - front view [2-4](#)

---

### D

- DHCP, enabling [8-6](#)
- dust
  - preventing damage [C-4](#)

---

### E

- electricity
  - safety with [3-3](#)
- electromagnetic interference
  - See* EMI
- electrostatic discharge [3-5](#)
  - See* ESD
- EMI

preventing effects of [C-4](#)

environment

- maintaining [C-1](#)
- site [3-8](#)

environmental

- features [A-3](#)
- specifications (table) [3-9](#)

equipment

- racks
- rack-mounting [3-9](#)
- safety with [3-3](#)

ESD

- preventing damage [C-4](#)
- preventing effects of [3-5, C-4](#)

---

## F

features

- environmental reporting [A-3](#)

front panel

- LEDs [2-5](#)
- troubleshooting [A-5](#)

front view

- CSACS 1121 Series appliance [2-4](#)
- SNS 3415 appliance [6-1](#)

---

## G

grounding (warning) [4-14](#)

guidelines

- airflow [3-8](#)
- lifting [3-5](#)
- rack installation [3-7](#)
- rack-mounting configuration [4-1, 8-1](#)
- safety [3-1](#)
- temperature maintenance [C-3](#)

---

## H

hardware

- troubleshooting procedures [A-1](#)

humidity

- maintenance guidelines [C-4](#)

---

## I

identification

- CPI [2-3, 6-3, A-8](#)

information packet and warranty [3-11](#)

installation

- checklist [3-14](#)
- IP settings [8-6](#)
- NIC modes [8-6](#)
- NIC redundancy [8-6](#)
- unpacking and inspection [7-3](#)
- verification [5-5, 9-8](#)

installing ACS server

- setup program [5-2, 9-5](#)
- post-installation tasks [12-1](#)

IP settings, DHCP or static [8-6](#)

---

## K

kit

- mounting [4-2](#)
- rack-mount hardware (table) [4-3](#)

---

## L

LEDs

- back panel [2-6](#)
- checking [4-16](#)
- front panel [2-5](#)

lifting guidelines [3-5](#)

location

serial number [2-3, A-7](#)  
 log, site [3-14, B-1](#)

---

## M

magnetism  
   preventing effects of [C-5](#)  
 maintenance [C-1](#)  
   temperature [C-3](#)  
 management  
   cable [4-14, 8-10](#)  
 method of procedures  
   *See* MOP  
 MOP [3-6, 3-10](#)

---

## N

network interface  
   connecting [4-8, 8-8](#)  
 NIC  
   LEDs  
     troubleshooting [A-6](#)  
 NIC 1 and NIC 2  
   RJ-45 pinout [4-9, 8-9](#)  
 NIC modes, setting [8-6](#)  
 NIC redundancy [8-6](#)

---

## O

overview  
   product [2-1](#)

---

## P

packing list [7-3](#)  
 planning  
   site [3-6](#)  
 post-installation tasks [12-1](#)

power  
   considerations [3-9](#)  
 power lines (warning) [3-3](#)  
 power source interruptions  
   preventing damage from [C-5](#)  
 power supplies (warning) [3-3](#)  
 power supply (warning) [3-3, 4-14](#)  
 power system  
   troubleshooting [A-3](#)  
 power up  
   procedure [4-15](#)  
 precautions  
   general precautions [3-2](#)  
 problem solving  
   *See* troubleshooting  
 procedure  
   method of [3-10](#)  
   power up [4-15](#)  
 product  
   overview [2-1](#)

---

## R

rack  
   enclosed (do not use) [3-7](#)  
   four-post (open) [3-7](#)  
 rack, mounting on 4-post [4-2](#)  
 rack installation  
   guidelines [3-7](#)  
 rack-mount  
   4-post hardware kit [4-3](#)  
 rack-mounting configuration  
   guidelines [4-1, 8-1](#)  
 radio frequency interference. *See* RFI  
 regulatory compliance [2-7, 5-8, 6-8, 9-10](#)  
 removing  
   CSACS 1121 Series appliance [4-17](#)  
 restricted access (warning) [3-3, 3-6, 4-1, 8-1](#)  
 RFI

preventing effects of [C-4](#)

RJ-45 pinout

NIC 1 and NIC 2 [4-9, 8-9](#)

---

## S

safety

guidelines [3-1](#)

SELV circuits (warning) [3-3](#)

serial

console port, pinouts [4-12](#)

serial number

location [2-3, A-7](#)

setting NIC modes [8-6](#)

setting NIC redundancy [8-6](#)

site

configuration [3-8](#)

environment [3-8](#)

maintenance factors [C-1](#)

log [3-14, B-1](#)

planning [3-6](#)

requirement, MOPs [3-10](#)

site log [B-1](#)

SNS 3415

installing ACS in SNS 3415 appliance [9-1](#)

SNS 3415 appliance overview [6-1](#)

static IP, setting [8-6](#)

---

## T

temperature

maintenance guidelines [C-3](#)

temperature and humidity guidelines [3-9](#)

tools and equipment

required [3-13](#)

trained and qualified (warning) [4-1, 8-1](#)

troubleshooting

adapter cards [A-4](#)

cables [A-4](#)

connections [A-4](#)

cooling system [A-3](#)

Ethernet LEDs [A-6](#)

front panel LEDs [A-5](#)

power system [A-3](#)

---

## U

unpacking

checking shipment [3-11](#)

unpacking the server [7-3](#)

upgrading

ACS deployment [11-2, 11-11](#)

ACS Monitoring and Report Viewer [11-10](#)

ACS server [11-11](#)

post-installation tasks [12-1](#)

---

## V

VMWare

configuring [10-5](#)

hardware requirements [10-2](#)

installing [10-1](#)

installing ACS server [10-10](#)

---

## W

warranty [3-11](#)