



Numerics

- 4-post hardware kit
 - rack-mount [4-3](#)
- 4-post rack, mounting appliance on [4-2](#)

A

- ACS deployment [1-1](#)
- adapter cards
 - troubleshooting [A-4](#)
- airflow
 - guidelines [3-8](#)
- altitude
 - guidelines [C-4](#)

B

- back panel [2-5, 4-7](#)
 - LEDs [2-6](#)

C

- cable
 - connecting [4-7, 8-8, 8-11](#)
 - management [4-17, 8-10](#)
 - troubleshooting [A-4](#)
- checking
 - LEDs [4-19](#)
- checklist, installation [3-14](#)
- checklist, power up [4-18](#)
- configuration
 - site [3-8](#)

- connecting
 - cables [4-7, 8-8, 8-11](#)
 - network interface [4-8, 8-8](#)
- connections
 - troubleshooting [A-4](#)
- considerations
 - power [3-9](#)
- console port, pinouts
 - serial [4-16](#)
- cooling system
 - troubleshooting [A-3](#)
- corrosion
 - preventing damage [C-2](#)
- CPI tool
 - identification [2-3, 6-5, A-8](#)
- CSACS 1121 Series appliance
 - front view [2-4](#)

D

- DHCP, enabling [8-7](#)
- dust
 - preventing damage [C-4](#)

E

- electricity
 - safety with [3-3](#)
- electromagnetic interference
 - See* EMI
- electrostatic discharge [3-5](#)
 - See* ESD
- EMI

preventing effects of [C-4](#)

environment

- maintaining [C-1](#)
- site [3-8](#)

environmental

- features [A-3](#)
- specifications (table) [3-9](#)

equipment

- racks
 - rack-mounting [3-9](#)
- safety with [3-3](#)

ESD

- preventing damage [C-4](#)
- preventing effects of [3-5, C-4](#)

F

features

- environmental reporting [A-3](#)

front panel

- LEDs [2-5](#)
- troubleshooting [A-5](#)

front view

- Cisco SNS 3415 appliance [6-3](#)
- CSACS 1121 Series appliance [2-4](#)

G

grounding (warning) [4-17](#)

guidelines

- airflow [3-8](#)
- lifting [3-5](#)
- rack installation [3-7](#)
- rack-mounting configuration [4-1, 8-1](#)
- safety [3-1](#)
- temperature maintenance [C-3](#)

H

hardware

- troubleshooting procedures [A-1](#)

humidity

- maintenance guidelines [C-4](#)

I

identification

- CPI [2-3, 6-5, A-8](#)

information packet and warranty [3-11](#)

installation

- checklist [3-14](#)
- IP settings [8-7](#)
- NIC modes [8-7](#)
- NIC redundancy [8-7](#)
- unpacking and inspection [7-3](#)
- verification [5-5, 9-8](#)

installing ACS server

- setup program [5-2, 9-6](#)
- post-installation tasks [12-1](#)

IP settings, DHCP or static [8-7](#)

K

kit

- mounting [4-2](#)
- rack-mount hardware (table) [4-3](#)

L

LEDs

- back panel [2-6](#)
- checking [4-19](#)
- front panel [2-5](#)

lifting guidelines [3-5](#)

location

serial number [2-3, A-7](#)
 log, site [3-14, B-1](#)

M

magnetism
 preventing effects of [C-5](#)
 maintenance [C-1](#)
 temperature [C-3](#)
 management
 cable [4-17, 8-10](#)
 method of procedures
 See MOP
 MOP [3-6, 3-10](#)

N

network interface
 connecting [4-8, 8-8](#)
 multi NIC [4-10](#)
 NIC bonding [4-11](#)
 NIC
 LEDs
 troubleshooting [A-6](#)
 NIC 1 and NIC 2
 RJ-45 pinout [4-9, 8-9](#)
 NIC modes, setting [8-7](#)
 NIC redundancy [8-7](#)

O

overview
 product [2-1](#)

P

packing list [7-3](#)
 planning

site [3-6](#)
 post-installation tasks [12-1](#)
 power
 considerations [3-9](#)
 power lines (warning) [3-3](#)
 power source interruptions
 preventing damage from [C-5](#)
 power supplies (warning) [3-3](#)
 power supply (warning) [3-3, 4-17](#)
 power system
 troubleshooting [A-3](#)
 power up
 procedure [4-18](#)
 precautions
 general precautions [3-2](#)
 problem solving
 See troubleshooting
 procedure
 method of [3-10](#)
 power up [4-18](#)
 product
 overview [2-1](#)

R

rack
 enclosed (do not use) [3-7](#)
 four-post (open) [3-7](#)
 rack, mounting on 4-post [4-2](#)
 rack installation
 guidelines [3-7](#)
 rack-mount
 4-post hardware kit [4-3](#)
 rack-mounting configuration
 guidelines [4-1, 8-1](#)
 radio frequency interference. *See* RFI
 regulatory compliance [2-7, 5-8, 6-9, 9-11](#)
 removing
 CSACS 1121 Series appliance [4-20](#)

restricted access (warning) [3-3, 3-6, 4-1, 8-1](#)

RFI

preventing effects of [C-4](#)

RJ-45 pinout

NIC 1 and NIC 2 [4-9, 8-9](#)

S

safety

guidelines [3-1](#)

SELV circuits (warning) [3-3](#)

serial

console port, pinouts [4-16](#)

serial number

location [2-3, A-7](#)

setting NIC modes [8-7](#)

setting NIC redundancy [8-7](#)

site

configuration [3-8](#)

environment [3-8](#)

maintenance factors [C-1](#)

log [3-14, B-1](#)

planning [3-6](#)

requirement, MOPs [3-10](#)

site log [B-1](#)

static IP, setting [8-7](#)

T

temperature

maintenance guidelines [C-3](#)

temperature and humidity guidelines [3-9](#)

tools and equipment

required [3-13](#)

trained and qualified (warning) [4-1, 8-1](#)

troubleshooting

adapter cards [A-4](#)

cables [A-4](#)

connections [A-4](#)

cooling system [A-3](#)

Ethernet LEDs [A-6](#)

front panel LEDs [A-5](#)

power system [A-3](#)

U

ucs

installing ACS in UCS [9-1](#)

ucs overview [6-1](#)

unpacking

checking shipment [3-11](#)

unpacking the server [7-3](#)

upgrading

ACS deployment [11-3, 11-12](#)

ACS Monitoring and Report Viewer [11-11](#)

ACS server [11-12](#)

post-installation tasks [12-1](#)

V

VMWare

configuring [10-5](#)

hardware requirements [10-2](#)

installing [10-1](#)

installing ACS server [10-11](#)

W

warranty [3-11](#)