



CHAPTER 16

IPv6 and IPv6 VPN over MPLS

Cisco Prime Network (Prime Network) supports IPv6 for:

- Gateways, clients, and units using IPv6.
- Communications between VNEs and devices in IPv6 environments, whether the device management IP address is IPv4 or IPv6.
- Polling and notification using the following protocols over IPv6:
 - SNMP v1, SNMPv2c, and SNMPv3
 - Telnet
 - SSHv2
 - ICMP
 - XML (for Cisco IOS XR devices)
 - HTTP (for Cisco UCS devices)
- All reports with devices that use IPv6 addresses.
- Fault management, including event processing and service alarm generation.

Prime Network supports correlation and path tracing for:

- 6PE and native IPv6 networks.
- IPv6 BGP address families.
- IPv6 GRE tunnels.

IPv6 VPN over MPLS, also known as 6VPE, uses the existing MPLS IPv4 core infrastructure for IPv6 transport to enable IPv6 sites to communicate over an MPLS IPv4 core network using MPLS label switch paths (LSPs). 6VPE relies on MP-BGP extensions in the IPv4 network configuration on the PE router to exchange IPv6 reachability information. Edge routers are configured to be dual-stacks running both IPv4 and IPv6, and use the IPv4-mapped IPv6 address for IPv6 prefix reachability exchange.

In 6VPE environments, Prime Network supports:

- Modeling of OSPFv3 routes between PE and CE devices.
- IPv6 addresses for BGP neighbors for MP-BGP.
- Correlation and path tracing.

Related Topics

- [User Roles Required to Work with IPv6 and 6VPE, page 16-2](#)
- [Viewing IPv6 Information, page 16-3](#)

User Roles Required to Work with IPv6 and 6VPE

This topic identifies the roles that are required to work with IPv6 and 6VPE in Prime Network Vision. Prime Network determines whether you are authorized to perform a task as follows:

- For GUI-based tasks (tasks that do not affect elements), authorization is based on the default permission that is assigned to your user account.
- For element-based tasks (tasks that do affect elements), authorization is based on the default permission that is assigned to your account. That is, whether the element is in one of your assigned scopes and whether you meet the minimum security level for that scope.

For more information on user authorization, see the [Cisco Prime Network 3.8 Administrator Guide](#).

The following tables identify the tasks that you can perform:

- [Table 16-1](#) identifies the tasks that you can perform if a selected element is **not in** one of your assigned scopes.
- [Table 16-2](#) identifies the tasks that you can perform if a selected element is **in** one of your assigned scopes.

By default, users with the Administrator role have access to all managed elements. To change the Administrator user scope, see the topic on device scopes in the [Cisco Prime Network 3.8 Administrator Guide](#).

Table 16-1 Default Permission/Security Level Required for Viewing IPv6 Properties - Element Not in User's Scope

Task	Viewer	Operator	OperatorPlus	Configurator	Administrator
View IPv6 properties	—	—	—	—	X

Table 16-2 Default Permission/Security Level Required for Viewing IPv6 Properties - Element in User's Scope

Task	Viewer	Operator	OperatorPlus	Configurator	Administrator
View IPv6 properties	X	X	X	X	X

Related Topic

- [Viewing IPv6 Information, page 16-3](#)
- [IPv6 and IPv6 VPN over MPLS, page 16-1](#)

Viewing IPv6 Information

Prime Network Vision displays IPv6 addresses when they are configured on PE and CE routers in the IP interface table. IPv6 addresses are:

- Displayed in the Prime Network Vision map pane for IPv6 links.
- Displayed in logical and physical inventory for routing and interface information, including IP, PPP, and High-Level Data Link Control (HDLC).
- Used in Cisco PathTracer to trace paths and present path trace results.

[Table 16-3](#) describes where IPv6 information appears in logical and physical inventory.

Table 16-3 IPv6 Information in Inventory

Inventory Location	Description
Logical Inventory	
6rd Tunnels	The Tunnel Edges table displays IPv6 addresses and the IPv6 prefixes that are used to translate IPv4 addresses to IPv6 addresses. For more information, see Viewing 6rd Tunnel Properties, page 17-46 .
Access Lists	<ul style="list-style-type: none"> • The Type field displays IPv6 for IPv6 access lists. • If an IPv6 access list is configured, the Access List Properties window displays IPv6 addresses in the Source, Destination, Source Wildcard, and Destination Wildcard fields.
Carrier Grade NAT	Carrier Grade NAT service types include 6rd and XLAT. For more information, see Viewing Carrier Grade NAT Properties in Logical Inventory, page 13-2 .
GRE Tunnels	The IP Address field supports IPv6 addresses. For more information, see Viewing MPLS Pseudowire over GRE Properties, page 18-32 .
IS-IS	IS-IS properties support: <ul style="list-style-type: none"> • IPv6 address families in the Metrics tab. • IPv6 addresses in the Neighbors tab and the IS-IS Neighbor Properties window. For more information, see Viewing IS-IS Properties, page 12-115 .
MPBGPs	<ul style="list-style-type: none"> • IP address family identifiers indicate the BGP peer address family: IPv4, IPv6, Layer 2 VPN, VPNv4, or VPNv6. • MP-BGP BGP neighbor entries display IPv6 addresses. For information, see Viewing MP-BGP Information, page 17-45 .
OSPFv3	IPv6 addresses are displayed for OSPF neighbor interface addresses, OSPF interface internet addresses, OSPF neighbor properties window, and OSPF interface properties window. For more information, see Viewing OSPF Properties, page 12-118 .

Table 16-3 IPv6 Information in Inventory (continued)

Inventory Location	Description
Routing Entities	<ul style="list-style-type: none"> IPv6 addresses appear in the IP Interfaces tab, the IPv6 Routing tab, and the interface properties window. IPv6 addresses are displayed in the NDP Table tab and the ARP Entry Properties window. VRRP groups using IPv6 display IPv6 addresses in the IP Interfaces Properties window in the VRRP group tab. For more information, see Viewing Routing Entities, page 17-34 .
VRFs	IPv6 addresses appear in the IPv6 tab, Sites tab, VRF Properties window, and IP Interface Properties window. For more information, see Viewing VRF Properties, page 17-30 .
Physical Inventory	
Port	IPv6 addresses appear in the Subinterfaces tab and interface properties popup window.

The IP addresses that appear depend on whether the interface has only IPv4 addresses, only IPv6 addresses, or both IPv4 and IPv6 addresses, as shown in [Table 16-4](#).

Table 16-4 IP Addresses Displayed in the Interface Table and Properties Window

Addresses	Interface Table	Properties Window
IPv4 only	Primary IPv4 address	The primary IPv4 address and any secondary IPv4 addresses.
IPv6 only	Lowest IPv6 address	All IPv6 addresses.
IPv6 and IPv4	Primary IPv4 address	All IPv4 and IPv6 addresses.

Note the following when working with IPv6 addresses:

- MPLS label switching entries and Label Switching Entities (LSEs) do not display IPv6 addresses. However, the Neighbor Discovery Protocol (NDP) table does display IPv6 addresses.
- Prime Network supports all the textual presentations of address prefixes. However, Prime Network Vision displays both the IP address and the subnet prefix, for example:

```
12AB::CD30:123:4567:89AB:CDEF, 12AB:0:0:CD30::/60
```

**Note**

Interfaces or subinterfaces that do not have IP addresses are not discovered and therefore are not shown in Prime Network Vision.

Figure 16-1 shows a port inventory view of a port with IPv4 and IPv6 addresses. In this example, one IPv4 address and multiple IPv6 addresses are provisioned on the interface.

- The primary IPv4 address appears in the interface table and properties window. If secondary IPv4 addresses were provisioned on the interface, they would appear in the properties window.
- IPv6 addresses provisioned on the interface appear in the properties window and Sub Interfaces tab.

Figure 16-1 Port with IPv4 and IPv6 Addresses

The screenshot displays the Cisco Prime Network 3.8 interface configuration for a Cisco Router IP Interface. The interface is named GigabitEthernet2/3/4.55 and is in the 'Up' state. The primary IPv4 address is 10.10.156.2 with a mask of 255.255.255.252. The interface is associated with the entity 169.254.197#2.3:GigabitEthernet2/3/4. The configuration shows a list of addresses including the primary IPv4 address and several IPv6 addresses (unicast, multicast, and link-local). The interface is connected to a subcard SPA-4XOC3-POS-V2.

Subnet	Type
10.10.156.2,255.255.255.252	Primary
2001:110:156:0:221:55ff:fedc:2db4,ffff:ffff:ffff:ffff:0:0:0:0	IPv6 Unicast
ff02:0:0:0:0:0:1,ffff:ffff:ffff:ffff:ffff:ffff:ffff:ffff	IPv6 Multicast
ff02:0:0:0:0:0:2,ffff:ffff:ffff:ffff:ffff:ffff:ffff:ffff	IPv6 Multicast
ff02:0:0:0:0:0:d,ffff:ffff:ffff:ffff:ffff:ffff:ffff:ffff	IPv6 Multicast
ff02:0:0:0:0:0:16,ffff:ffff:ffff:ffff:ffff:ffff:ffff:ffff	IPv6 Multicast
ff02:0:0:0:0:1:ffd:c:2db4,ffff:ffff:ffff:ffff:ffff:ffff:ffff:ffff	IPv6 Multicast
fe80:0:0:0:221:55ff:fedc:2db4,ffff:ffff:ffff:ffff:ffff:ffff:ffff:ffff	IPv6 Link-local

Figure 16-2 shows a port with only IPv6 addresses provisioned. In this example, the lowest IPv6 address is shown in the subinterface table, and all IPv6 addresses are shown in the interface properties window.

Figure 16-2 Port with IPv6 Addresses

The screenshot displays the configuration for the Ethernet2/0 interface on a Cisco Router (IP: 10.1.1.3). The interface is in the 'Up' state. The primary IPv6 address is 10:20:1:1:0:0:3 with a mask of ffff:ffff:ffff:0:0:0:0. The interface description is 10.1.1.3#0:Ethernet2/0.

The 'Addresses' section shows the following IPv6 addresses and their types:

Subnet	Type
10:20:1:1:0:0:3,ffff:ffff:ffff:0:0:0:0	IPv6 Unicast
fe80:0:0:0:a8bb:cff:fe00:6502,ffff:ffff:ffff:ffff:ffff:ffff	IPv6 Link-local
ff02:0:0:0:0:0:1,ffff:ffff:ffff:ffff:ffff:ffff	IPv6 Multicast
ff02:0:0:0:0:0:2,ffff:ffff:ffff:ffff:ffff:ffff	IPv6 Multicast
ff02:0:0:0:0:1:ff00:3,ffff:ffff:ffff:ffff:ffff:ffff	IPv6 Multicast
ff02:0:0:0:0:1:ff00:6502,ffff:ffff:ffff:ffff:ffff:ffff	IPv6 Multicast

Below the table, a summary table shows the interface details:

Address	Mask	VLAN Type	Operational State	VLAN ID	Inner VLAN	IP Interface	VRF Name
10:20:1:1:0:0:3	ffff:ffff:ffff:0:0:0:0					10.1.1.3 IP:Ethernet2/0	

The interface is connected, with 9% memory usage. The sub-interfaces section shows Line 1 (1 / 1 Selected).

289678

Related Topic

- [User Roles Required to Work with IPv6 and 6VPE, page 16-2](#)
- [IPv6 and IPv6 VPN over MPLS, page 16-1](#)