



Before You Start

Requirements



Note

For a list of system requirements and package dependencies, see the *System Requirements* document posted on cisco.com.

- **System Requirements**—The installer checks for system requirements. If they are not met and if it is something the installer cannot address, such as memory issues, the installation process stops.
- **Package Dependencies**—For online installations, the installer checks for required packages. If the installer cannot install any RPM dependency, it reports an error and skips the corresponding RPM installation. You must then install these dependencies and re-run the installer.

There is one exception to this automatic package installation. For RHEL operating systems, you must manually install an RHEL package repository (createrepo) using the Red Hat installation DVD.

- **License**—A license determines which WAE features are available to use, and is a requirement for using the products. If you have questions about obtaining a license, contact your support representative.
- **Server time synchronization**—The NTP (Network Time Protocol) must be used to synchronize times on all routers, servers used in the collection and deployment process, and servers used in high-availability clusters. Failure to synchronize these clocks can produce such issues as the following.
 - Messages might expire prematurely, which manifests as an unresponsive WAE northbound interface. Depending on where the JMS messages expire, you may or may not see indications of this in the logs.
 - Certain collection tools, such as `sam_getplan` and `flow_get`, might produce inaccurate traffic tables.
 - Collection tools will produce an inaccurate `NetIntHistory` table.
 - All lines in the collection logs will have incorrect timestamps.
- **/etc/hosts requirements**—Various web services require the server's hostname to be present in the `/etc/hosts` file. This is standard configuration practice, but some Linux systems do not have it. Both the unqualified and fully-qualified hostnames must be present. Make sure that the following line is present in `/etc/hosts`.

```
<server IP address> <hostname> <fully-qualified hostname>
```

Example: `192.168.0.15 wae-server wae-server.my.company.com`

Best Practices

- **Security**—The server's SSL certificate for a domain is customer specific. The web server installation is tied to a preferred Certification Authority (CA) provider, which in turn issues valid certificates to web clients. To prevent users from seeing messages for untrusted certificates, configure the certificate to be signed by one of the client's trusted CAs. The fully-qualified domain name (FQDN) of the WAE server should match the FQDN of the certificate issued by the CA.
- **BIOS setting (if applicable)**—To improve collection performance, change or disable the power management setting to permit maximum CPU performance.

Pre-Installation

These pre-installation steps are valid for both online and offline installations.

-
- Step 1** Download the WAE software package. In a web browser, go to the [Cisco download site](#), and use the Search feature to find the applicable product.
- Step 2** Log in to the server as root or a user with administrative capabilities.
- Step 3** Ensure there are no local firewalls blocking the services. This step is beyond the scope of these instructions, though following is an example. For a list of available ports, see the *System Requirements* document.

Example: This shows how to disable the iptables firewall as root.

```
service iptables save
service iptables stop
sudo chkconfig iptables off
```

Change Default wae-web-server Parameters

If this is an upgrade and if you want to change the default manner in which the `wae-web-server` starts, or if you want to change the manner in which it restarts, edit the `/opt/cariden/etc/sysconfig/wae-web-server.cfg` file. The following are the most frequently used parameters.

Action	Parameter
Change the default HTTP port	<code>http-port=8080</code>
Change the default HTTPS port	<code>https-port=8443</code>
Enable (true) or disable (false) the automatic redirect from HTTP to HTTPS	<code>http-redirect=true</code>
Enable (true) or disable (false) the automatic upgrade of the Collector server database. For information on database upgrades, see the Collector Server Upgrades chapter.	<code>autoupgrade=true</code>

**Note**

Ports 1 through 1023 are privilege ports and cannot be used without root access.
